

2016	Alpheon	Alpheon	Chassis Control Module	●	●	●	●	●	●	S025
2016	Alpheon	Alpheon	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S030
2016	Alpheon	Alpheon	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Alpheon	Alpheon	Rear Seat Heating Control Module	●	●	●	●	●	○	
2016	Alpheon	Alpheon	Seat Memory Control Module	●	●	●	●	●	●	S031
2016	Alpheon	Alpheon	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Alpheon	Alpheon	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2016	Alpheon	Alpheon	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2016	Alpheon	Alpheon	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Alpheon	Alpheon	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Alpheon	Alpheon	Suspension Control Module	●	●	●	●	●	●	S038
2016	Alpheon	Alpheon	Power Steering Control Module	●	●	●	●	○	●	
2016	Alpheon	Alpheon	Radio	●	●	●	●	●	○	
2016	Alpheon	Alpheon	Rear Audio Control Module	●	●	●	●	●	○	
2016	Buick	Cascada	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Buick	Cascada	Transmission Control Module	●	●	●	●	●	●	S023
2016	Buick	Cascada	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021

2016	Buick	Cascada	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2016	Buick	Cascada	Passenger Presence Module	●	●	●	●	●	●	S043
2016	Buick	Cascada	HVAC Control Module	●	●	●	●	●	●	S033
2016	Buick	Cascada	Power Supply Transformer	●	●	●	●	●	○	
2016	Buick	Cascada	Instrument Cluster	●	●	●	●	●	●	S022
2016	Buick	Cascada	Parking Assist Control Module	●	●	●	●	●	●	
2016	Buick	Cascada	Folding Top Control Module	●	●	●	●	●	●	
2016	Buick	Cascada	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S045 S001 S029 S025 S030 S046
2016	Buick	Cascada	Multimedia Player Interface Module	●	●	●	●	○	●	
2016	Buick	Cascada	Radio	●	●	●	●	●	○	
2016	Buick	Cascada	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2016	Buick	Cascada	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2016	Buick	Cascada	Power Steering Control Module	●	●	●	●	○	●	S047
2016	Buick	Cascada	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Buick	Cascada	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Buick	Cascada	Frontview Camera Module	●	●	●	●	●	●	
2016	Buick	Enclave	Transmission Control Module	●	●	●	●	●	●	S048

2016	Buick	Enclave	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Buick	Enclave	Head-Up Display Module	●	●	●	●	●	○	
2016	Buick	Enclave	Instrument Cluster	●	●	●	●	●	○	
2016	Buick	Enclave	Theft Deterrent Module	●	●	●	●	○	○	
2016	Buick	Enclave	Headlamp Control Module	●	●	●	○	○	○	
2016	Buick	Enclave	Liftgate Control Module	●	●	●	●	○	●	S049
2016	Buick	Enclave	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2016	Buick	Enclave	Front Seat Heating Control Module	●	●	●	●	○	○	
2016	Buick	Enclave	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Buick	Enclave	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Buick	Enclave	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Buick	Enclave	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Buick	Enclave	Seat Memory Control Module	●	●	●	●	●	○	
2016	Buick	Enclave	HVAC Control Module	●	●	●	●	●	●	S052 S032 S033
2016	Buick	Enclave	Body Control Module	●	●	●	●	●	●	S001 S053
2016	Buick	Enclave	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2016	Buick	Enclave	Passenger Presence Module	●	●	●	●	○	●	S043

2016	Buick	Enclave	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2016	Buick	Enclave	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2016	Buick	Enclave	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S029 S025 S030
2016	Buick	Enclave	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2016	Buick	Enclave	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2016	Buick	Enclave	Personal Audio Link Control Module	●	●	●	○	○	●	S056
2016	Buick	Enclave	Radio	●	●	●	●	●	●	
2016	Buick	Enclave	Rear Audio Control Module	●	●	●	●	●	○	
2016	Buick	Enclave	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034 S036
2016	Buick	Encore	Transmission Control Module	●	●	●	●	●	●	S023
2016	Buick	Encore	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Buick	Encore	Instrument Cluster	●	●	●	●	●	●	S022
2016	Buick	Encore	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2016	Buick	Encore	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Buick	Encore	Parking Assist Control Module	●	●	●	●	●	●	

2016	Buick	Encore	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Buick	Encore	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Buick	Encore	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Buick	Encore	Seat Memory Control Module	●	●	●	●	●	●	S031
2016	Buick	Encore	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Buick	Encore	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	Buick	Encore	Radio	●	●	●	●	●	○	
2016	Buick	Encore	Electronic Brake Control Module	●	●	●	●	●	●	S035
2016	Buick	Encore	Power Steering Control Module	●	●	●	●	○	●	
2016	Buick	Encore	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Buick	Encore	Chassis Control Module	●	●	●	●	●	●	S025
2016	Buick	Envision	Transmission Control Module	●	●	●	●	●	●	S023
2016	Buick	Envision	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S045 S029 S025 S030 S001 S059 S046
2016	Buick	Envision	Telematics Communication Interface Control Module	●	●	●	●	●	●	
2016	Buick	Envision	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036

2016	Buick	Envision	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Buick	Envision	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Buick	Envision	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Buick	Envision	Parking Assist Control Module	●	●	●	●	●	●	
2016	Buick	Envision	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Buick	Envision	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Buick	Envision	Headlamp Control Module	●	●	●	●	●	●	
2016	Buick	Envision	Rear Differential Clutch Control Module	●	●	●	●	●	●	S060
2016	Buick	Envision	Steering Column Lock Control Module	●	●	●	●	○	●	
2016	Buick	Envision	Electronic Brake Control Module	●	●	●	●	●	●	S036 S036 S036
2016	Buick	Envision	Power Steering Control Module	●	●	●	●	○	●	S047
2016	Buick	Envision	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2016	Buick	Envision	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Buick	Envision	Passenger Presence Module	●	●	●	●	●	●	S043
2016	Buick	Envision	HVAC Control Module	●	●	●	●	●	●	S033
2016	Buick	Envision	Long Range Radar Sensor Module	●	●	●	●	○	●	S061

2016	Buick	Envision	Power Supply Transformer	●	●	●	●	●	○	
2016	Buick	Envision	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Buick	Envision	Liftgate Control Module	●	●	●	●	●	●	S049 S062
2016	Buick	Envision	Radio	●	●	●	●	●	●	S063 S064
2016	Buick	Envision	Instrument Cluster	●	●	●	●	●	●	S022
2016	Buick	Envision	Video Processing Control Module	●	●	●	●	●	○	
2016	Buick	Envision	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Buick	Envision	Amplifier	●	●	●	●	○	○	
2016	Buick	Envision	Radio Controls	●	●	●	●	○	●	S065
2016	Buick	LaCrosse	Battery Energy Control Module	○	○	●	●	○	○	
2016	Buick	LaCrosse	Drive Motor Control Module	●	●	●	●	○	○	
2016	Buick	LaCrosse	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2016	Buick	LaCrosse	Telematics Communication Interface Control Module	●	●	●	●	●	●	
2016	Buick	LaCrosse	Head-Up Display Module	●	●	●	●	●	○	
2016	Buick	LaCrosse	Instrument Cluster	●	●	●	●	●	●	S022
2016	Buick	LaCrosse	Headlamp Control Module	●	●	●	●	●	○	

2016	Buick	LaCrosse	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2016	Buick	LaCrosse	Transmission Control Module	●	●	●	●	●	●	S023
2016	Buick	LaCrosse	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Buick	LaCrosse	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Buick	LaCrosse	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Buick	LaCrosse	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Buick	LaCrosse	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Buick	LaCrosse	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	Buick	LaCrosse	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Buick	LaCrosse	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Buick	LaCrosse	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S030
2016	Buick	LaCrosse	Amplifier	●	●	●	●	○	○	
2016	Buick	LaCrosse	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Buick	LaCrosse	HVAC Controls	●	●	●	●	●	●	S065
2016	Buick	LaCrosse	Radio Controls	●	●	●	●	○	●	S065
2016	Buick	LaCrosse	Media Disc Player	●	●	●	●	●	○	
2016	Buick	LaCrosse	Radio	●	●	●	●	●	●	S063 S064

2016	Buick	LaCrosse	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Buick	LaCrosse	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2016	Buick	LaCrosse	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2016	Buick	LaCrosse	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Buick	LaCrosse	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Buick	LaCrosse	Suspension Control Module	●	●	●	●	●	○	
2016	Buick	LaCrosse	Power Steering Control Module	●	●	●	●	○	●	S047
2016	Buick	LaCrosse	Rear Audio Control Module	●	●	●	●	●	○	
2016	Buick	Regal	Transmission Control Module	●	●	●	●	●	●	S023
2016	Buick	Regal	Battery Energy Control Module	○	○	●	●	○	○	
2016	Buick	Regal	Drive Motor Control Module	●	●	●	●	○	○	
2016	Buick	Regal	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2016	Buick	Regal	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Buick	Regal	Instrument Cluster	●	●	●	●	●	●	S022
2016	Buick	Regal	Rear Differential Clutch Control Module	●	●	●	●	●	○	

2016	Buick	Regal	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2016	Buick	Regal	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Buick	Regal	Amplifier	●	●	●	●	○	○	
2016	Buick	Regal	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Buick	Regal	HVAC Controls	●	●	●	●	●	●	S065
2016	Buick	Regal	Radio Controls	●	●	●	●	○	●	S065
2016	Buick	Regal	Radio	●	●	●	●	●	●	S063 S064
2016	Buick	Regal	Infotainment Control Touchpad	●	●	●	●	●	○	
2016	Buick	Regal	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036 S036
2016	Buick	Regal	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Buick	Regal	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Buick	Regal	Chassis Control Module	●	●	●	●	●	●	S025
2016	Buick	Regal	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S030
2016	Buick	Regal	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Buick	Regal	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Buick	Regal	Left Side Object Detection Control Module	●	●	●	○	●	○	

2016	Buick	Regal	Seat Memory Control Module	●	●	●	●	●	●	S031
2016	Buick	Regal	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2016	Buick	Regal	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Buick	Regal	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2016	Buick	Regal	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Buick	Regal	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Buick	Regal	Suspension Control Module	●	●	●	●	●	○	
2016	Buick	Regal	Power Steering Control Module	●	●	●	●	○	●	S047
2016	Buick	Verano	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Buick	Verano	Instrument Cluster	●	●	●	●	●	●	S022
2016	Buick	Verano	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Buick	Verano	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Buick	Verano	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Buick	Verano	Parking Assist Control Module	●	●	●	●	●	●	
2016	Buick	Verano	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Buick	Verano	HVAC Control Module	●	●	●	●	●	●	S032 S033

2016	Buick	Verano	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Buick	Verano	Transmission Control Module	●	●	●	●	●	●	S023
2016	Buick	Verano	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Buick	Verano	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Buick	Verano	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2016	Buick	Verano	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S029 S025 S030
2016	Buick	Verano	Chassis Control Module	●	●	●	●	●	●	S025
2016	Buick	Verano	Radio	●	●	●	●	●	○	
2016	Buick	Verano	Multimedia Player Interface Module	●	●	●	●	○	●	
2016	Buick	Verano	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2016	Buick	Verano	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S070 S036
2016	Buick	Verano	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Buick	Verano	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Buick	Verano	Power Steering Control Module	●	●	●	●	○	●	S047
2016	Cadillac	ATS	Transmission Control Module	●	●	●	●	●	●	S023
2016	Cadillac	ATS	Steering Column Lock Control Module	●	●	●	●	○	●	

2016	Cadillac	ATS	Telematics Communication Interface Control Module	●	●	●	●	●	●	
2016	Cadillac	ATS	Instrument Cluster	●	●	●	●	●	●	S022
2016	Cadillac	ATS	Trailer Interface Control Module	●	●	●	●	●	●	S022
2016	Cadillac	ATS	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2016	Cadillac	ATS	Headlamp Control Module	●	●	●	●	●	●	
2016	Cadillac	ATS	Active Safety Control Module	●	●	●	●	●	○	
2016	Cadillac	ATS	Frontview Camera Module	●	●	●	●	○	●	S051
2016	Cadillac	ATS	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Cadillac	ATS	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Cadillac	ATS	Pedestrian Impact Detection Module	●	●	●	●	○	●	
2016	Cadillac	ATS	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Cadillac	ATS	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Cadillac	ATS	Transfer Case Control Module	●	●	●	●	●	●	S072 S073 S074
2016	Cadillac	ATS	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2016	Cadillac	ATS	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036

2016	Cadillac	ATS	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Cadillac	ATS	Power Steering Control Module	●	●	●	●	○	●	S075
2016	Cadillac	ATS	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Cadillac	ATS	Suspension Control Module	●	●	●	●	●	●	S076 S077 S077 S038
2016	Cadillac	ATS	Seat Belt Retractor Motor Module - Left	●	●	●	●	●	●	S078
2016	Cadillac	ATS	Seat Belt Retractor Motor Module - Right	●	●	●	●	●	●	S078
2016	Cadillac	ATS	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Cadillac	ATS	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2016	Cadillac	ATS	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Cadillac	ATS	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Cadillac	ATS	Long Range Radar Sensor Module	●	●	●	●	○	●	S061
2016	Cadillac	ATS	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	ATS	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	ATS	Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	ATS	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021

2016	Cadillac	CT6	Passenger Presence Module	●	●	●	●	●	●	S043
2016	Cadillac	CT6	Seat Belt Retractor Motor Module - Left	●	●	●	●	●	●	S078
2016	Cadillac	CT6	Active Safety Control Module	●	●	●	●	●	○	
2016	Cadillac	CT6	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Cadillac	CT6	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Cadillac	CT6	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Cadillac	CT6	Seat Belt Retractor Motor Module - Right	●	●	●	●	●	●	S078
2016	Cadillac	CT6	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Cadillac	CT6	Instrument Cluster	●	●	●	●	●	●	S022
2016	Cadillac	CT6	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Cadillac	CT6	Trailer Interface Control Module	●	●	●	●	●	●	S022
2016	Cadillac	CT6	Video Processing Control Module	●	●	●	●	●	○	
2016	Cadillac	CT6	Amplifier	●	●	●	●	○	○	
2016	Cadillac	CT6	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Cadillac	CT6	Navigation Control Module	●	●	●	●	●	●	
2016	Cadillac	CT6	Radio	●	●	●	●	●	●	S063 S064
2016	Cadillac	CT6	HVAC Control Module	●	●	●	●	●	●	S033
2016	Cadillac	CT6	Long Range Radar Sensor Module	●	●	●	●	○	●	S061

2016	Cadillac	CT6	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	CT6	Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	CT6	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	CT6	Serial Data Gateway Module	●	●	●	○	○	○	
2016	Cadillac	CT6	Seat Memory Control Module - Passenger	●	●	●	●	●	○	
2016	Cadillac	CT6	Seat Memory Control Module - Left Rear	●	●	●	●	●	○	
2016	Cadillac	CT6	Seat Memory Control Module - Right Rear	●	●	●	●	●	○	
2016	Cadillac	CT6	Electronic Brake Control Module	●	●	●	●	●	●	S036 S036 S036
2016	Cadillac	CT6	Power Steering Control Module	●	●	●	●	○	●	S047
2016	Cadillac	CT6	Suspension Control Module	●	●	●	●	●	●	S038
2016	Cadillac	CT6	Radio Controls	●	●	●	●	○	●	S065
2016	Cadillac	CT6	HVAC Controls	●	●	●	●	●	●	S065
2016	Cadillac	CT6	Brake Booster Control Module	●	●	●	●	○	○	
2016	Cadillac	CTS	Transmission Control Module	●	●	●	●	●	●	S082
2016	Cadillac	CTS	Steering Column Lock Control Module	●	●	●	●	○	●	
2016	Cadillac	CTS	Telematics Communication Interface Control Module	●	●	●	●	●	●	
2016	Cadillac	CTS	Instrument Cluster	●	●	●	●	●	●	S022

2016	Cadillac	CTS	Trailer Interface Control Module	●	●	●	●	●	●	S022
2016	Cadillac	CTS	Headlamp Control Module	●	●	●	●	●	●	
2016	Cadillac	CTS	Transfer Case Control Module	●	●	●	●	●	●	S072 S073 S074
2016	Cadillac	CTS	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S045 S029 S025 S030 S001 S059 S046
2016	Cadillac	CTS	Active Safety Control Module	●	●	●	●	●	○	
2016	Cadillac	CTS	Frontview Camera Module	●	●	●	●	○	●	S051
2016	Cadillac	CTS	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Cadillac	CTS	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Cadillac	CTS	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Cadillac	CTS	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Cadillac	CTS	Pedestrian Impact Detection Module	●	●	●	●	○	●	
2016	Cadillac	CTS	Seat Belt Retractor Motor Module - Left	●	●	●	●	●	●	S078
2016	Cadillac	CTS	Seat Belt Retractor Motor Module - Right	●	●	●	●	●	●	S078
2016	Cadillac	CTS	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Cadillac	CTS	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036

2016	Cadillac	CTS	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Cadillac	CTS	Amplifier	●	●	●	●	○	○	
2016	Cadillac	CTS	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Cadillac	CTS	Radio/HVAC Controls	●	●	●	●	●	○	
2016	Cadillac	CTS	Navigation Control Module	●	●	●	●	●	●	
2016	Cadillac	CTS	Radio	●	●	●	●	●	●	S063 S064
2016	Cadillac	CTS	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Cadillac	CTS	HVAC Control Module	●	●	●	●	●	●	S033
2016	Cadillac	CTS	Long Range Radar Sensor Module	●	●	●	●	○	●	S061
2016	Cadillac	CTS	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	CTS	Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	CTS	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	CTS	Rear Differential Clutch Control Module	●	●	●	●	●	●	S079
2016	Cadillac	CTS	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Cadillac	CTS	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2016	Cadillac	CTS	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2016	Cadillac	CTS	Parking Brake Control Module	●	●	●	●	●	●	S037

2016	Cadillac	CTS	Power Steering Control Module	●	●	●	●	○	●	S075
2016	Cadillac	CTS	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Cadillac	CTS	Suspension Control Module	●	●	●	●	●	●	S076 S077 S077 S038
2016	Cadillac	CTS	Video Processing Control Module	●	●	●	●	●	○	
2016	Cadillac	CTS	Seat Memory Control Module - Passenger	●	●	●	●	●	○	
2016	Cadillac	CTS	Vehicle Performance Data Recorder	●	●	●	●	●	○	
2016	Cadillac	ELR	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	
2016	Cadillac	ELR	Battery Charger Control Module	○	○	●	●	○	○	
2016	Cadillac	ELR	Battery Energy Control Module	○	○	●	●	○	○	
2016	Cadillac	ELR	Coolant Heater Control Module	●	●	●	●	○	○	
2016	Cadillac	ELR	Drive Motor Control Module 1	●	●	●	●	○	○	
2016	Cadillac	ELR	Drive Motor Control Module 2	●	●	●	●	○	○	
2016	Cadillac	ELR	Transmission Control Module	●	●	●	●	●	○	
2016	Cadillac	ELR	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2016	Cadillac	ELR	Hybrid Powertrain Control Module	●	●	●	●	●	○	
2016	Cadillac	ELR	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S083 S084 S085 S086 S087 S088 S089 S090
2016	Cadillac	ELR	Steering Column Lock Control Module	●	●	●	●	○	●	

2016	Cadillac	ELR	Instrument Cluster	●	●	●	●	●	●	S022
2016	Cadillac	ELR	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Cadillac	ELR	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Cadillac	ELR	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Cadillac	ELR	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Cadillac	ELR	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Cadillac	ELR	Headlamp Control Module	●	●	●	●	●	●	
2016	Cadillac	ELR	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2016	Cadillac	ELR	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Cadillac	ELR	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Cadillac	ELR	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S091
2016	Cadillac	ELR	Electronic Brake Control Module	●	●	●	●	●	●	S092 S036 S036 S036
2016	Cadillac	ELR	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Cadillac	ELR	Power Steering Control Module	●	●	●	●	○	●	
2016	Cadillac	ELR	Suspension Control Module	●	●	●	●	●	○	
2016	Cadillac	ELR	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	

2016	Cadillac	ELR	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2016	Cadillac	ELR	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2016	Cadillac	ELR	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Cadillac	ELR	Amplifier	●	●	●	●	○	○	
2016	Cadillac	ELR	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Cadillac	ELR	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2016	Cadillac	ELR	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Cadillac	ELR	Radio/HVAC Controls	●	●	●	●	●	○	
2016	Cadillac	ELR	Radio	●	●	●	●	●	●	S063 S064
2016	Cadillac	Escalade	Transmission Control Module	●	●	●	●	●	●	S048
2016	Cadillac	Escalade	Steering Column Lock Control Module	●	●	●	●	○	●	
2016	Cadillac	Escalade	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Cadillac	Escalade	Instrument Cluster	●	●	●	●	●	●	S022
2016	Cadillac	Escalade	Liftgate Control Module	●	●	●	●	●	●	S049 S062
2016	Cadillac	Escalade	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Cadillac	Escalade	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030

2016	Cadillac	Escalade	Active Safety Control Module	●	●	●	●	●	○	
2016	Cadillac	Escalade	Frontview Camera Module	●	●	●	●	○	●	S051
2016	Cadillac	Escalade	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Cadillac	Escalade	Video Processing Control Module	●	●	●	●	●	○	
2016	Cadillac	Escalade	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Cadillac	Escalade	Passenger Presence Module	●	●	●	●	●	●	S043
2016	Cadillac	Escalade	Seat Belt Retractor Motor Module - Left	●	●	●	●	●	●	S078
2016	Cadillac	Escalade	Seat Belt Retractor Motor Module - Right	●	●	●	●	●	●	S078
2016	Cadillac	Escalade	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	Cadillac	Escalade	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Cadillac	Escalade	Transfer Case Control Module	●	●	●	●	●	●	S080
2016	Cadillac	Escalade	Amplifier	●	●	●	●	○	○	
2016	Cadillac	Escalade	Assist Step Control Module	●	●	●	●	●	●	
2016	Cadillac	Escalade	Media Disc Player	●	●	●	●	●	○	
2016	Cadillac	Escalade	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Cadillac	Escalade	Radio	●	●	●	●	●	●	S063 S064
2016	Cadillac	Escalade	Electronic Brake Control Module	●	●	●	●	●	●	S036

2016	Cadillac	Escalade ESV	Instrument Cluster	●	●	●	●	●	●	S022
2016	Cadillac	Escalade ESV	Liftgate Control Module	●	●	●	●	●	●	S049 S062
2016	Cadillac	Escalade ESV	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2016	Cadillac	Escalade ESV	Transmission Control Module	●	●	●	●	●	●	S048
2016	Cadillac	Escalade ESV	Active Safety Control Module	●	●	●	●	●	○	
2016	Cadillac	Escalade ESV	Frontview Camera Module	●	●	●	●	○	●	S051
2016	Cadillac	Escalade ESV	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Cadillac	Escalade ESV	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Cadillac	Escalade ESV	Video Processing Control Module	●	●	●	●	●	○	
2016	Cadillac	Escalade ESV	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Cadillac	Escalade ESV	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Cadillac	Escalade ESV	Seat Belt Retractor Motor Module - Left	●	●	●	●	●	●	S078
2016	Cadillac	Escalade ESV	Seat Belt Retractor Motor Module - Right	●	●	●	●	●	●	S078
2016	Cadillac	Escalade ESV	Passenger Presence Module	●	●	●	●	●	●	S043
2016	Cadillac	Escalade ESV	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	Cadillac	Escalade ESV	Transfer Case Control Module	●	●	●	●	●	●	S080
2016	Cadillac	Escalade ESV	Amplifier	●	●	●	●	○	○	

2016	Cadillac	Escalade ESV	Assist Step Control Module	●	●	●	●	●	●	
2016	Cadillac	Escalade ESV	Media Disc Player	●	●	●	●	●	○	
2016	Cadillac	Escalade ESV	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Cadillac	Escalade ESV	HVAC Controls	●	●	●	●	●	●	S065
2016	Cadillac	Escalade ESV	Radio Controls	●	●	●	●	○	●	S065
2016	Cadillac	Escalade ESV	Radio	●	●	●	●	●	●	S063 S064
2016	Cadillac	Escalade ESV	Electronic Brake Control Module	●	●	●	●	●	●	S036
2016	Cadillac	Escalade ESV	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2016	Cadillac	Escalade ESV	Power Steering Control Module	●	●	●	●	●	●	S064
2016	Cadillac	Escalade ESV	Suspension Control Module	●	●	●	●	●	●	
2016	Cadillac	Escalade ESV	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2016	Cadillac	Escalade ESV	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Cadillac	Escalade ESV	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Cadillac	Escalade ESV	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	Escalade ESV	Right Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	Escalade ESV	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	Escalade ESV	Left Rear Radar Short Range Sensor Module	●	●	●	●	○	○	
2016	Cadillac	Escalade ESV	Long Range Radar Sensor Module	●	●	●	●	○	●	S061

2016	Cadillac	Escalade ESV	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Cadillac	Escalade ESV	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Cadillac	Escalade ESV	Seat Memory Control Module - Passenger	●	●	●	●	●	○	
2016	Cadillac	SRX	Steering Column Lock Control Module	●	●	●	●	○	●	
2016	Cadillac	SRX	Telematics Communication Interface Control Module	●	●	●	●	●	●	
2016	Cadillac	SRX	Trailer Interface Control Module	●	●	●	●	●	●	S022
2016	Cadillac	SRX	Instrument Cluster	●	●	●	●	●	●	S022
2016	Cadillac	SRX	Transmission Control Module	●	●	●	●	●	●	S048
2016	Cadillac	SRX	Headlamp Control Module	●	●	●	●	●	●	
2016	Cadillac	SRX	Liftgate Control Module	●	●	●	●	●	●	S049 S062
2016	Cadillac	SRX	Active Safety Control Module	●	●	●	●	●	○	
2016	Cadillac	SRX	Frontview Camera Module	●	●	●	●	○	●	S051
2016	Cadillac	SRX	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Cadillac	SRX	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Cadillac	SRX	Rear Seat Heating Control Module	●	●	●	●	●	○	

2016	Cadillac	SRX	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Cadillac	SRX	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Cadillac	SRX	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2016	Cadillac	SRX	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Cadillac	SRX	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2016	Cadillac	SRX	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Cadillac	SRX	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S094 S046
2016	Cadillac	SRX	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2016	Cadillac	SRX	Amplifier	●	●	●	●	○	○	
2016	Cadillac	SRX	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Cadillac	SRX	Radio/HVAC Controls	●	●	●	●	●	○	
2016	Cadillac	SRX	Media Disc Player	●	●	●	●	●	○	
2016	Cadillac	SRX	Navigation Control Module	●	●	●	●	●	●	
2016	Cadillac	SRX	Rear Audio Control Module	●	●	●	●	●	○	
2016	Cadillac	SRX	Radio	●	●	●	●	●	●	S063 S064

2016	Cadillac	SRX	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2016	Cadillac	SRX	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2016	Cadillac	SRX	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Cadillac	SRX	Suspension Control Module	●	●	●	●	●	○	
2016	Cadillac	SRX	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Cadillac	SRX	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	SRX	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	SRX	Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	SRX	Long Range Radar Sensor Module	●	●	●	●	○	●	S061
2016	Cadillac	SRX	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Cadillac	XTS	Transmission Control Module	●	●	●	●	●	●	S048
2016	Cadillac	XTS	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Cadillac	XTS	Headlamp Control Module	●	●	●	●	●	●	
2016	Cadillac	XTS	Instrument Cluster	●	●	●	●	●	●	S022
2016	Cadillac	XTS	Active Safety Control Module	●	●	●	●	●	○	
2016	Cadillac	XTS	Frontview Camera Module	●	●	●	●	○	●	S051

2016	Cadillac	XTS	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Cadillac	XTS	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Cadillac	XTS	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Cadillac	XTS	Seat Memory Control Module - Passenger	●	●	●	●	●	○	
2016	Cadillac	XTS	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Cadillac	XTS	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2016	Cadillac	XTS	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Cadillac	XTS	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2016	Cadillac	XTS	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Cadillac	XTS	Amplifier	●	●	●	●	○	○	
2016	Cadillac	XTS	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Cadillac	XTS	Radio/HVAC Controls	●	●	●	●	●	○	
2016	Cadillac	XTS	Media Disc Player	●	●	●	●	●	○	
2016	Cadillac	XTS	Radio	●	●	●	●	●	●	S063 S064
2016	Cadillac	XTS	Chassis Control Module	●	●	●	●	●	●	S025
2016	Cadillac	XTS	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2016	Cadillac	XTS	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Cadillac	XTS	Long Range Radar Sensor Module	●	●	●	●	○	●	S061

2016	Cadillac	XTS	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	XTS	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	XTS	Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2016	Cadillac	XTS	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Cadillac	XTS	Steering Column Lock Control Module	●	●	●	●	○	●	
2016	Cadillac	XTS	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2016	Cadillac	XTS	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Cadillac	XTS	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2016	Cadillac	XTS	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Cadillac	XTS	Suspension Control Module	●	●	●	●	●	●	S076 S077 S077 S038
2016	Cadillac	XTS	Power Steering Control Module	●	●	●	●	●	○	
2016	Cadillac	XTS	Video Processing Control Module	●	●	●	●	●	○	
2016	Chevrolet	Beat	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	Beat	Engine Control Module	●	●	●	●	●	●	S095 S096

2016	Chevrolet	Beat	Transmission Control Module	●	●	●	●	●	○	
2016	Chevrolet	Beat	Fuel Injector Control Module	●	●	●	●	●	○	
2016	Chevrolet	Beat	Instrument Cluster	●	●	●	●	●	○	
2016	Chevrolet	Beat	Radio	●	●	●	●	●	○	
2016	Chevrolet	Beat		●	●	●	●	●	●	
2016	Chevrolet	Beat	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Chevrolet	Beat	Electronic Brake Control Module	●	●	●	●	●	●	
2016	Chevrolet	Beat	Power Steering Control Module	●	●	●	●	○	●	S047
2016	Chevrolet	Beat	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036
2016	Chevrolet	Beat	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Chevrolet	Camaro	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	Camaro	Mobile Telephone Control Module	●	●	●	●	●	●	
2016	Chevrolet	Camaro	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2016	Chevrolet	Camaro	Transmission Control Module	●	●	●	●	●	●	S023
2016	Chevrolet	Camaro	Passenger Presence Module	●	●	●	●	●	●	S043
2016	Chevrolet	Camaro	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036
2016	Chevrolet	Camaro	Keyless Entry Control Module	●	●	●	●	●	○	

2016	Chevrolet	Camaro	Serial Data Gateway Module	●	●	●	○	○	○	
2016	Chevrolet	Camaro	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Camaro	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Chevrolet	Camaro	Folding Top Control Module	●	●	●	●	●	○	
2016	Chevrolet	Camaro	Auxiliary Gage Module	●	●	●	●	●	○	
2016	Chevrolet	Camaro	HVAC Control Module	●	●	●	●	●	●	S033
2016	Chevrolet	Camaro	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Chevrolet	Camaro	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Chevrolet	Camaro	Electronic Brake Control Module	●	●	●	●	●	●	S036 S036
2016	Chevrolet	Camaro	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Chevrolet	Camaro	Power Steering Control Module	●	●	●	●	○	●	S075
2016	Chevrolet	Camaro	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Chevrolet	Camaro	Amplifier	●	●	●	●	○	○	
2016	Chevrolet	Camaro	Radio	●	●	●	●	●	●	S063 S064
2016	Chevrolet	Camaro	Head-Up Display Module	●	●	●	●	●	○	
2016	Chevrolet	Camaro	Suspension Control Module	●	●	●	●	●	●	S076 S077 S077 S038
2016	Chevrolet	Camaro	Radio Controls	●	●	●	●	○	●	S065
2016	Chevrolet	Camaro	HVAC Controls	●	●	●	●	●	●	S065
2016	Chevrolet	Camaro	Media Disc Player	●	●	●	●	●	○	
2016	Chevrolet	Camaro	Human Machine Interface Control Module	●	●	●	●	●	●	S064

2016	Chevrolet	Camaro	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Chevrolet	Camaro	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Chevrolet	Caprice	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	Caprice	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2016	Chevrolet	Caprice	Transmission Control Module	●	●	●	●	●	●	S048
2016	Chevrolet	Caprice	Fuel Injector Control Module	○	○	●	●	●	○	
2016	Chevrolet	Caprice	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2016	Chevrolet	Caprice	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Chevrolet	Caprice	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	Chevrolet	Caprice	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Chevrolet	Caprice	Head-Up Display Module	●	●	●	●	●	○	
2016	Chevrolet	Caprice	Instrument Cluster	●	●	●	●	●	●	S022 S097
2016	Chevrolet	Caprice	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Chevrolet	Caprice	Electronic Brake Control Module	●	●	●	●	●	●	S036
2016	Chevrolet	Caprice	Parking Brake Control Module	●	●	●	●	●	●	S037

2016	Chevrolet	Caprice	Power Steering Control Module	●	●	●	●	○	●	
2016	Chevrolet	Caprice	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Chevrolet	Caprice	Suspension Control Module	●	●	●	●	●	●	S076 S077 S077 S038
2016	Chevrolet	Caprice	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Chevrolet	Caprice	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Chevrolet	Caprice	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Chevrolet	Caprice	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Chevrolet	Caprice	Trailer Interface Control Module	●	●	●	●	●	●	
2016	Chevrolet	Caprice	Parking Assist Control Module	●	●	●	●	●	●	
2016	Chevrolet	Caprice	HVAC Controls	●	●	●	●	●	●	
2016	Chevrolet	Caprice	Radio Controls	●	●	●	●	●	●	S022
2016	Chevrolet	Cheyenne	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	Cheyenne	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2016	Chevrolet	Cheyenne	Transmission Control Module	●	●	●	●	●	●	S048
2016	Chevrolet	Cheyenne	Transfer Case Control Module	●	●	●	●	●	●	S080
2016	Chevrolet	Cheyenne	Fuel Injector Control Module	●	●	●	●	●	○	

2016	Chevrolet	Cheyenne	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Chevrolet	Cheyenne	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Cheyenne	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	Chevrolet	Cheyenne	Passenger Presence Module	●	●	●	●	●	●	S043
2016	Chevrolet	Cheyenne	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Chevrolet	Cheyenne	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Chevrolet	Cheyenne	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Chevrolet	Cheyenne	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Chevrolet	Cheyenne	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2016	Chevrolet	Cheyenne	Power Steering Control Module	●	●	●	●	●	●	S064
2016	Chevrolet	Cheyenne	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2016	Chevrolet	Cheyenne	Suspension Control Module	●	●	●	●	●	●	
2016	Chevrolet	Cheyenne	Amplifier	●	●	●	●	○	○	
2016	Chevrolet	Cheyenne	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Chevrolet	Cheyenne	HVAC Controls	●	●	●	●	●	●	S065
2016	Chevrolet	Cheyenne	Radio Controls	●	●	●	●	○	●	S065
2016	Chevrolet	Cheyenne	Media Disc Player	●	●	●	●	●	○	
2016	Chevrolet	Cheyenne	Radio	●	●	●	●	●	●	S063 S064

2016	Chevrolet	Cheyenne	Assist Step Control Module	●	●	●	●	●	●	
2016	Chevrolet	Cheyenne	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Chevrolet	City Express	Body Control Module	●	●	●	●	●	●	S098
2016	Chevrolet	City Express	Underhood Fuse Block	●	●	●	●	●	○	
2016	Chevrolet	City Express	Engine Control Module	●	●	●	●	●	●	S025 S028 S099
2016	Chevrolet	City Express	Transmission Control Module	●	●	●	●	○	●	S100 S101
2016	Chevrolet	City Express	Passenger Presence Module	○	○	○	●	○	●	
2016	Chevrolet	City Express	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	○	
2016	Chevrolet	City Express	Instrument Cluster	●	●	○	●	○	●	
2016	Chevrolet	City Express	Tire Pressure Indicator Module	●	●	●	●	●	●	S019
2016	Chevrolet	City Express	Electronic Brake Control Module	●	●	●	●	●	●	
2016	Chevrolet	City Express	Power Steering Control Module	●	●	●	●	○	○	
2016	Chevrolet	City Express	Radio	●	●	●	●	○	○	
2016	Chevrolet	Cobalt	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Cobalt	Transmission Control Module	●	●	●	●	●	●	S023
2016	Chevrolet	Cobalt	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Chevrolet	Cobalt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2016	Chevrolet	Cobalt	Electronic Brake Control Module	●	●	●	●	●	●	
2016	Chevrolet	Cobalt	HVAC Control Module	●	●	●	●	●	○	
2016	Chevrolet	Cobalt	Parking Assist Control Module	●	●	●	●	●	●	

2016	Chevrolet	Cobalt	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2016	Chevrolet	Cobalt	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S103 S103 S104 S105 S105 S106 S106 S107 S107 S108 S108 S109 S110 S111 S111 S045 S045 S112 S112 S113 S029 S114 S114 S115 S116 S117 S118 S118
2016	Chevrolet	Cobalt	Radio	●	●	●	●	●	○	
2016	Chevrolet	Cobalt	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Chevrolet	Corvette	Steering Column Lock Control Module	●	●	●	●	○	●	
2016	Chevrolet	Corvette	Telematics Communication Interface Control Module	●	●	●	●	●	●	
2016	Chevrolet	Corvette	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Corvette	Transmission Control Module	●	●	●	●	●	●	S023
2016	Chevrolet	Corvette	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2016	Chevrolet	Corvette	Rear Differential Clutch Control Module	●	●	●	●	●	●	S079
2016	Chevrolet	Corvette	Folding Top Control Module	●	●	●	●	●	○	
2016	Chevrolet	Corvette	Inside Rearview Mirror	●	●	●	●	●	○	

2016	Chevrolet	Corvette	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Chevrolet	Corvette	Seat Memory Control Module - Passenger	●	●	●	●	●	○	
2016	Chevrolet	Corvette	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Chevrolet	Corvette	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	Chevrolet	Corvette	Passenger Presence Module	●	●	●	●	●	●	S043
2016	Chevrolet	Corvette	Amplifier	●	●	●	●	○	○	
2016	Chevrolet	Corvette	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Chevrolet	Corvette	Radio/HVAC Controls	●	●	●	●	●	○	
2016	Chevrolet	Corvette	Vehicle Performance Data Recorder	●	●	●	●	●	○	
2016	Chevrolet	Corvette	Radio	●	●	●	●	●	●	S063 S064
2016	Chevrolet	Corvette	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Chevrolet	Corvette	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Chevrolet	Corvette	Video Processing Control Module	●	●	●	●	●	○	
2016	Chevrolet	Corvette	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034 S036
2016	Chevrolet	Corvette	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Chevrolet	Corvette	Power Steering Control Module	●	●	●	●	○	●	S075
2016	Chevrolet	Corvette	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Chevrolet	Corvette	Suspension Control Module	●	●	●	●	●	●	S038

2016	Chevrolet	Corvette	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Chevrolet	Corvette	Liftgate Control Module	●	●	●	●	○	○	
2016	Chevrolet	Damas	Engine Control Module	●	●	●	●	●	●	S095 S096
2016	Chevrolet	Enjoy	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	
2016	Chevrolet	Enjoy	Electronic Brake Control Module	●	●	●	●	●	○	
2016	Chevrolet	Enjoy	Instrument Cluster	●	●	○	○	○	○	
2016	Chevrolet	Enjoy	Engine Control Module	●	●	●	●	●	○	
2016	Chevrolet	Equinox	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	Equinox	Transmission Control Module	●	●	●	●	●	●	S048
2016	Chevrolet	Equinox	Liftgate Control Module	●	●	●	●	●	●	S049 S062
2016	Chevrolet	Equinox	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2016	Chevrolet	Equinox	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Equinox	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Chevrolet	Equinox	Radio	●	●	●	●	●	○	
2016	Chevrolet	Equinox	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2016	Chevrolet	Equinox	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	

2016	Chevrolet	Equinox	Power Steering Control Module	●	●	●	●	○	●	
2016	Chevrolet	Equinox	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Chevrolet	Equinox	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Chevrolet	Equinox	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2016	Chevrolet	Equinox	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S046
2016	Chevrolet	Equinox	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Chevrolet	Equinox	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Chevrolet	Equinox	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Chevrolet	Equinox	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Chevrolet	Equinox	Seat Memory Control Module	●	●	●	●	●	●	S031
2016	Chevrolet	Equinox	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Chevrolet	Equinox	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021

2016	Chevrolet	Express	Engine Control Module	●	●	●	●	●	●	S112 S103 S119 S120 S121 S122 S029 S123 S124 S125 S126 S127 S128 S129 S130 S131 S132 S030 S133 S134 S135 S136 S137 S138 S139 S140 S141 S142 S143 S144 S145 S146 S147 S148 S149 S150 S151 S152 S153
2016	Chevrolet	Express	Auxiliary Heater Control Module	●	●	●	●	●	●	S025
2016	Chevrolet	Express	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141 S154
2016	Chevrolet	Express	Theft Deterrent Module	●	●	●	●	○	○	
2016	Chevrolet	Express	Instrument Cluster	●	●	●	●	●	○	
2016	Chevrolet	Express	Transmission Control Module	●	●	●	●	●	●	S048
2016	Chevrolet	Express	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	Express	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2016	Chevrolet	Express	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Chevrolet	Express	Body Control Module	●	●	●	●	●	●	S001 S053
2016	Chevrolet	Express	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2016	Chevrolet	Express	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2016	Chevrolet	Express	Radio	●	●	●	●	●	●	

2016	Chevrolet	Express	Electronic Brake Control Module	●	●	●	●	●	●	S036
2016	Chevrolet	Express	Chime Alarm Control Module	●	●	●	○	●	○	
2016	Chevrolet	Labo	Engine Control Module	●	●	●	●	●	●	S095 S096
2016	Chevrolet	Lacetti	Transmission Control Module	●	●	●	●	●	●	S023
2016	Chevrolet	Lacetti	Fuel Injector Control Module	●	●	●	●	●	○	
2016	Chevrolet	Lacetti	Engine Control Module	●	●	●	●	●	●	S026 S044 S045 S025
2016	Chevrolet	Lacetti	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	○	
2016	Chevrolet	Lacetti	Electronic Brake Control Module	●	●	●	●	●	○	
2016	Chevrolet	Matiz	Engine Control Module	●	●	●	●	●	●	S095 S096
2016	Chevrolet	Matiz	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	○	
2016	Chevrolet	Matiz	Electronic Brake Control Module	●	●	●	●	●	○	
2016	Chevrolet	Max	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	○	
2016	Chevrolet	Max	Engine Control Module	●	●	●	●	●	●	S095 S096 S155
2016	Chevrolet	Max	Electronic Brake Control Module	●	●	●	●	●	○	
2016	Chevrolet	Move	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	○	
2016	Chevrolet	Move	Engine Control Module	●	●	●	●	●	●	S095 S096 S155
2016	Chevrolet	Move	Electronic Brake Control Module	●	●	●	●	●	○	
2016	Chevrolet	Nexia	Engine Control Module	●	●	●	●	●	●	S095 S096
2016	Chevrolet	Onix	Instrument Cluster	●	●	●	●	●	●	S022

2016	Chevrolet	Orlando	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2016	Chevrolet	Orlando	Parking Assist Control Module	●	●	●	●	●	●	
2016	Chevrolet	Orlando	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2016	Chevrolet	Orlando	Power Steering Control Module	●	●	●	●	○	●	S047
2016	Chevrolet	Orlando	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Chevrolet	Orlando	Transmission Control Module	●	●	●	●	●	●	S023
2016	Chevrolet	Orlando	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2016	Chevrolet	Orlando	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Chevrolet	Orlando	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Chevrolet	Orlando	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Chevrolet	Orlando	Rear Seat Heating Control Module	●	●	●	●	●	○	
2016	Chevrolet	Orlando	Fuel Injector Control Module	●	●	●	●	●	○	
2016	Chevrolet	Orlando	Multimedia Player Interface Module	●	●	●	●	○	●	
2016	Chevrolet	Orlando	Radio	●	●	●	●	●	○	
2016	Chevrolet	Orlando	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Chevrolet	Orlando	Mobile Telephone Control Module	●	●	●	●	●	●	

2016	Chevrolet	Orlando	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2016	Chevrolet	Orlando	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Chevrolet	Orlando	Digital Radio Receiver Control Module	●	●	●	●	●	●	
2016	Chevrolet	Prisma	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Prisma	Electronic Brake Control Module	●	●	●	●	●	●	
2016	Chevrolet	Prisma	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2016	Chevrolet	Prisma	Transmission Control Module	●	●	●	●	●	●	S023
2016	Chevrolet	Prisma	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Chevrolet	Prisma	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Chevrolet	Prisma	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2016	Chevrolet	Prisma	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2016	Chevrolet	Prisma	HVAC Control Module	●	●	●	●	●	○	
2016	Chevrolet	Prisma	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Chevrolet	Prisma	Radio	●	●	●	●	●	○	
2016	Chevrolet	S10	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S045 S029 S025 S030

2016	Chevrolet	S10	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	S10	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2016	Chevrolet	S10	Electronic Brake Control Module	●	●	●	●	●	●	S070
2016	Chevrolet	S10	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Chevrolet	S10	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2016	Chevrolet	S10	Transmission Control Module	●	●	●	●	●	●	S048
2016	Chevrolet	S10	Trailer Interface Control Module	●	●	●	●	●	●	S022
2016	Chevrolet	S10	Radio	●	●	●	●	●	○	
2016	Chevrolet	S10	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2016	Chevrolet	S10	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Chevrolet	S10	Instrument Cluster	●	●	●	●	●	●	
2016	Chevrolet	S10	Transfer Case Control Module	●	●	●	●	●	●	S080
2016	Chevrolet	S10	HVAC Control Module	●	●	●	●	●	●	S033

2016	Chevrolet	Savana	Engine Control Module	●	●	●	●	●	●	S112 S103 S119 S120 S121 S122 S029 S123 S124 S125 S126 S127 S128 S129 S130 S131 S132 S030 S133 S134 S135 S136 S137 S138 S139 S140 S141 S142 S143 S144 S145 S146 S147 S148 S149 S150 S151 S152 S153
2016	Chevrolet	Savana	Auxiliary Heater Control Module	●	●	●	●	●	●	S025
2016	Chevrolet	Savana	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141 S154
2016	Chevrolet	Savana	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	Savana	Instrument Cluster	●	●	●	●	●	○	
2016	Chevrolet	Savana	Theft Deterrent Module	●	●	●	●	○	○	
2016	Chevrolet	Savana	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2016	Chevrolet	Savana	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Chevrolet	Savana	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2016	Chevrolet	Savana	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2016	Chevrolet	Savana	Transmission Control Module	●	●	●	●	●	●	S048
2016	Chevrolet	Savana	Body Control Module	●	●	●	●	●	●	S001 S053

2016	Chevrolet	Savana	Electronic Brake Control Module	●	●	●	●	●	●	S036
2016	Chevrolet	Savana	Radio	●	●	●	●	●	●	
2016	Chevrolet	Savana	Chime Alarm Control Module	●	●	●	○	●	○	
2016	Chevrolet	Silverado	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S156 S086
2016	Chevrolet	Silverado	Hybrid Powertrain Control Module	●	●	●	●	●	●	S157
2016	Chevrolet	Silverado	Engine Control Module	●	●	●	●	●	●	S112 S103 S119 S120 S121 S122 S029 S123 S124 S125 S126 S127 S128 S129 S130 S131 S132 S030 S133 S134 S135 S136 S137 S138 S139 S140 S141 S142 S143 S144 S145 S146 S147 S148 S149 S150 S151 S152 S153
2016	Chevrolet	Silverado	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141 S154
2016	Chevrolet	Silverado	Power Take-Off Control Module	●	●	●	●	●	●	S158 S159
2016	Chevrolet	Silverado	Telematics Communication Interface Control Module	●	●	●	●	●	●	
2016	Chevrolet	Silverado	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Silverado	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Chevrolet	Silverado	Transmission Control Module	●	●	●	●	●	●	S048
2016	Chevrolet	Silverado	Transfer Case Control Module	●	●	●	●	●	●	S080

2016	Chevrolet	Silverado	Fuel Injector Control Module	●	●	●	●	●	○	
2016	Chevrolet	Silverado	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Chevrolet	Silverado	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	Chevrolet	Silverado	Passenger Presence Module	●	●	●	●	●	●	S043
2016	Chevrolet	Silverado	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Chevrolet	Silverado	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Chevrolet	Silverado	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Chevrolet	Silverado	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Chevrolet	Silverado	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2016	Chevrolet	Silverado	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2016	Chevrolet	Silverado	Power Steering Control Module	●	●	●	●	●	●	S064
2016	Chevrolet	Silverado	Suspension Control Module	●	●	●	●	●	●	
2016	Chevrolet	Silverado	Amplifier	●	●	●	●	○	○	
2016	Chevrolet	Silverado	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Chevrolet	Silverado	HVAC Controls	●	●	●	●	●	●	S065
2016	Chevrolet	Silverado	Radio Controls	●	●	●	●	○	●	S065
2016	Chevrolet	Silverado	Media Disc Player	●	●	●	●	●	○	
2016	Chevrolet	Silverado	Radio	●	●	●	●	●	●	S063 S064

2016	Chevrolet	Sonic	Telematics Communication Interface Control Module	●	●	●	●	●	●	
2016	Chevrolet	Sonic	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Sonic	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2016	Chevrolet	Sonic	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Chevrolet	Sonic	Electronic Brake Control Module	●	●	●	●	●	●	
2016	Chevrolet	Sonic	HVAC Control Module	●	●	●	●	●	○	
2016	Chevrolet	Sonic	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Chevrolet	Sonic	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036 S036
2016	Chevrolet	Sonic	Power Steering Control Module	●	●	●	●	○	●	
2016	Chevrolet	Sonic	Parking Assist Control Module	●	●	●	●	●	●	
2016	Chevrolet	Sonic	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Chevrolet	Sonic	Transmission Control Module	●	●	●	●	●	●	S023
2016	Chevrolet	Sonic	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Chevrolet	Sonic	Chassis Control Module	●	●	●	●	●	●	S025
2016	Chevrolet	Sonic	Radio	●	●	●	●	●	○	
2016	Chevrolet	Sonic	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	

2016	Chevrolet	Sonic	Fuel Injector Control Module	○	○	●	●	●	○	
2016	Chevrolet	Spark EV	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	
2016	Chevrolet	Spark EV	Battery Charger Control Module	○	○	●	●	○	○	
2016	Chevrolet	Spark EV	Battery Energy Control Module	○	○	●	●	○	○	
2016	Chevrolet	Spark EV	Coolant Heater Control Module	●	●	●	○	○	○	
2016	Chevrolet	Spark EV	DC Charging Control Module	○	○	●	●	○	○	
2016	Chevrolet	Spark EV	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2016	Chevrolet	Spark EV	Drive Motor Control Module	●	●	●	●	○	○	
2016	Chevrolet	Spark EV	Hybrid Powertrain Control Module	●	●	●	●	●	●	
2016	Chevrolet	Spark EV	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S084 S083 S160 S161 S087 S088 S089
2016	Chevrolet	Spark EV	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	Spark EV	Engine Control Module	●	●	●	●	●	●	S030
2016	Chevrolet	Spark EV	Electronic Brake Control Module	●	●	●	●	●	●	S092 S036 S036 S036
2016	Chevrolet	Spark EV	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Chevrolet	Spark EV	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Chevrolet	Spark EV	Instrument Cluster	●	●	●	●	●	●	S022 S022

2016	Chevrolet	Spark EV	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2016	Chevrolet	Spark EV	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Chevrolet	Spark EV	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	Chevrolet	Spark EV	Passenger Presence Module	●	●	●	●	●	●	S043
2016	Chevrolet	Spark EV	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Chevrolet	Spark EV	Power Steering Control Module	●	●	●	●	○	●	S047
2016	Chevrolet	Spark EV	Pedestrian Alert Sound Control Module	●	●	●	●	●	○	
2016	Chevrolet	Spark EV	Radio	●	●	●	●	●	○	
2016	Chevrolet	Spin	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Spin	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2016	Chevrolet	Spin	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	Spin	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Chevrolet	Spin	HVAC Control Module	●	●	●	●	●	○	
2016	Chevrolet	Spin	Radio	●	●	●	●	●	○	

2016	Chevrolet	Spin	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S103 S103 S104 S105 S105 S106 S106 S107 S107 S108 S108 S109 S110 S111 S111 S045 S045 S112 S112 S113 S029 S114 S114 S115 S116 S117 S118 S118
2016	Chevrolet	Spin	Electronic Brake Control Module	●	●	●	●	●	●	S035
2016	Chevrolet	Spin	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Chevrolet	Spin	Transmission Control Module	●	●	●	●	●	●	S023
2016	Chevrolet	Spin	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Chevrolet	Spin	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Chevrolet	SS	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	SS	Transmission Control Module	●	●	●	●	●	●	S048
2016	Chevrolet	SS	Fuel Injector Control Module	○	○	●	●	●	○	
2016	Chevrolet	SS	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021

2016	Chevrolet	SS	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Chevrolet	SS	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	Chevrolet	SS	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Chevrolet	SS	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Chevrolet	SS	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2016	Chevrolet	SS	Instrument Cluster	●	●	●	●	●	●	S022 S097
2016	Chevrolet	SS	Head-Up Display Module	●	●	●	●	●	○	
2016	Chevrolet	SS	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Chevrolet	SS	Electronic Brake Control Module	●	●	●	●	●	●	S036
2016	Chevrolet	SS	Power Steering Control Module	●	●	●	●	○	●	
2016	Chevrolet	SS	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Chevrolet	SS	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Chevrolet	SS	Suspension Control Module	●	●	●	●	●	●	S076 S077 S077 S038
2016	Chevrolet	SS	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Chevrolet	SS	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Chevrolet	SS	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Chevrolet	SS	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Chevrolet	SS	Trailer Interface Control Module	●	●	●	●	●	●	

2016	Chevrolet	SS	Parking Assist Control Module	●	●	●	●	●	●	
2016	Chevrolet	SS	HVAC Controls	●	●	●	●	●	●	
2016	Chevrolet	SS	Radio Controls	●	●	●	●	●	●	S022
2016	Chevrolet	SS	Radio	●	●	●	●	●	○	
2016	Chevrolet	Suburban	Steering Column Lock Control Module	●	●	●	●	○	●	
2016	Chevrolet	Suburban	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	Suburban	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Suburban	Liftgate Control Module	●	●	●	●	●	●	S049 S062
2016	Chevrolet	Suburban	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2016	Chevrolet	Suburban	Transmission Control Module	●	●	●	●	●	●	S048
2016	Chevrolet	Suburban	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Chevrolet	Suburban	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Chevrolet	Suburban	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Chevrolet	Suburban	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Chevrolet	Suburban	Passenger Presence Module	●	●	●	●	●	●	S043
2016	Chevrolet	Suburban	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	Chevrolet	Suburban	Keyless Entry Control Module	●	●	●	●	●	○	

2016	Chevrolet	Suburban	Transfer Case Control Module	●	●	●	●	●	●	S080
2016	Chevrolet	Suburban	Amplifier	●	●	●	●	○	○	
2016	Chevrolet	Suburban	Assist Step Control Module	●	●	●	●	●	●	
2016	Chevrolet	Suburban	Media Disc Player	●	●	●	●	●	○	
2016	Chevrolet	Suburban	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Chevrolet	Suburban	HVAC Controls	●	●	●	●	●	●	S065
2016	Chevrolet	Suburban	Radio Controls	●	●	●	●	○	●	S065
2016	Chevrolet	Suburban	Radio	●	●	●	●	●	●	S063 S064
2016	Chevrolet	Suburban	Electronic Brake Control Module	●	●	●	●	●	●	S036
2016	Chevrolet	Suburban	Power Steering Control Module	●	●	●	●	●	●	S064
2016	Chevrolet	Suburban	Suspension Control Module	●	●	●	●	●	●	
2016	Chevrolet	Suburban	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2016	Chevrolet	Suburban	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Chevrolet	Suburban	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Chevrolet	Suburban	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2016	Chevrolet	Suburban	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Chevrolet	Suburban	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Chevrolet	Suburban	Seat Memory Control Module - Passenger	●	●	●	●	●	○	
2016	Chevrolet	Tahoe	Steering Column Lock Control Module	●	●	●	●	○	●	

2016	Chevrolet	Tahoe	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	Tahoe	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Tahoe	Liftgate Control Module	●	●	●	●	●	●	S049 S062
2016	Chevrolet	Tahoe	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2016	Chevrolet	Tahoe	Transmission Control Module	●	●	●	●	●	●	S048
2016	Chevrolet	Tahoe	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Chevrolet	Tahoe	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Chevrolet	Tahoe	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Chevrolet	Tahoe	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	Chevrolet	Tahoe	Passenger Presence Module	●	●	●	●	●	●	S043
2016	Chevrolet	Tahoe	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	Chevrolet	Tahoe	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Chevrolet	Tahoe	Transfer Case Control Module	●	●	●	●	●	●	S080
2016	Chevrolet	Tahoe	Amplifier	●	●	●	●	○	○	
2016	Chevrolet	Tahoe	Assist Step Control Module	●	●	●	●	●	●	
2016	Chevrolet	Tahoe	Media Disc Player	●	●	●	●	●	○	

2016	Chevrolet	Tahoe	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Chevrolet	Tahoe	HVAC Controls	●	●	●	●	●	●	S065
2016	Chevrolet	Tahoe	Radio Controls	●	●	●	●	○	●	S065
2016	Chevrolet	Tahoe	Radio	●	●	●	●	●	●	S063 S064
2016	Chevrolet	Tahoe	Electronic Brake Control Module	●	●	●	●	●	●	S036
2016	Chevrolet	Tahoe	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2016	Chevrolet	Tahoe	Suspension Control Module	●	●	●	●	●	●	
2016	Chevrolet	Tahoe	Power Steering Control Module	●	●	●	●	●	●	S064
2016	Chevrolet	Tahoe	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Chevrolet	Tahoe	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	Chevrolet	Tahoe	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2016	Chevrolet	Tahoe	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Chevrolet	Tahoe	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Chevrolet	Tahoe	Seat Memory Control Module - Passenger	●	●	●	●	●	○	
2016	Chevrolet	Tavera	Engine Control Module	●	●	●	●	●	○	
2016	Chevrolet	Tracker	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Tracker	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029

2016	Chevrolet	Tracker	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	Chevrolet	Tracker	Electronic Brake Control Module	●	●	●	●	●	●	
2016	Chevrolet	Tracker	Power Steering Control Module	●	●	●	●	○	●	
2016	Chevrolet	Tracker	Parking Assist Control Module	●	●	●	●	●	●	
2016	Chevrolet	Tracker	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Chevrolet	Tracker	Transmission Control Module	●	●	●	●	●	●	S023
2016	Chevrolet	Tracker	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Chevrolet	Tracker	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Chevrolet	Tracker	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	Chevrolet	Tracker	Radio	●	●	●	●	●	○	
2016	Chevrolet	Tracker	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Chevrolet	Tracker	Trailer Interface Control Module	●	●	●	●	●	●	S022
2016	Chevrolet	Tracker	Fuel Injector Control Module	○	○	●	●	●	○	
2016	Chevrolet	Tracker	HVAC Control Module	●	●	●	●	●	○	
2016	Chevrolet	Trailblazer	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S162 S029 S025 S030

2016	Chevrolet	Traverse	Instrument Cluster	●	●	●	●	●	○	
2016	Chevrolet	Traverse	Theft Deterrent Module	●	●	●	●	○	○	
2016	Chevrolet	Traverse	Liftgate Control Module	●	●	●	●	○	●	S049
2016	Chevrolet	Traverse	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2016	Chevrolet	Traverse	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2016	Chevrolet	Traverse	Front Seat Heating Control Module	●	●	●	●	○	○	
2016	Chevrolet	Traverse	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Chevrolet	Traverse	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Chevrolet	Traverse	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Chevrolet	Traverse	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Chevrolet	Traverse	Seat Memory Control Module	●	●	●	●	●	○	
2016	Chevrolet	Traverse	Transmission Control Module	●	●	●	●	●	●	S048
2016	Chevrolet	Traverse	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2016	Chevrolet	Traverse	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2016	Chevrolet	Traverse	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Chevrolet	Traverse	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S029 S025 S030

2016	Chevrolet	Traverse	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034 S036
2016	Chevrolet	Traverse	Radio	●	●	●	●	●	●	
2016	Chevrolet	Traverse	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2016	Chevrolet	Traverse	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2016	Chevrolet	Traverse	Personal Audio Link Control Module	●	●	●	○	○	●	S056
2016	Chevrolet	Traverse	Rear Audio Control Module	●	●	●	●	●	○	
2016	Chevrolet	Traverse	Body Control Module	●	●	●	●	●	●	S001 S053
2016	Chevrolet	Traverse	HVAC Control Module	●	●	●	●	●	●	S052 S032 S033
2016	Chevrolet	Trax	Telematics Communication Interface Control Module	●	●	●	●	●	●	
2016	Chevrolet	Trax	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Trax	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2016	Chevrolet	Trax	Electronic Brake Control Module	●	●	●	●	●	●	
2016	Chevrolet	Trax	Power Steering Control Module	●	●	●	●	○	●	
2016	Chevrolet	Trax	Parking Assist Control Module	●	●	●	●	●	●	
2016	Chevrolet	Trax	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Chevrolet	Trax	Transmission Control Module	●	●	●	●	●	●	S023

2016	Chevrolet	Volt	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2016	Chevrolet	Volt	Hybrid Powertrain Control Module	●	●	●	●	●	●	S163
2016	Chevrolet	Volt	Electronic Brake Control Module	●	●	●	●	●	●	S036 S036 S036
2016	Chevrolet	Volt	Drive Motor Control Module 1	●	●	●	●	○	○	
2016	Chevrolet	Volt	Drive Motor Control Module 2	●	●	●	●	○	○	
2016	Chevrolet	Volt	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S001 S029 S025 S091 S046 S164
2016	Chevrolet	Volt	Steering Column Lock Control Module	●	●	●	●	○	●	
2016	Chevrolet	Volt	Instrument Cluster	●	●	●	●	●	●	S022
2016	Chevrolet	Volt	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	Chevrolet	Volt	Passenger Presence Module	●	●	●	●	○	●	S043
2016	Chevrolet	Volt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2016	Chevrolet	Volt	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Chevrolet	Volt	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Chevrolet	Volt	Radio	●	●	●	●	●	●	S063 S064
2016	Chevrolet	Volt	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	Chevrolet	Volt	HVAC Control Module	●	●	●	●	●	●	S032 S033

2016	Chevrolet	Volt	Long Range Radar Sensor Module	●	●	●	●	○	●	S061
2016	Chevrolet	Volt	Brake Booster Control Module	●	●	●	●	○	○	
2016	Chevrolet	Volt	Power Steering Control Module	●	●	●	●	○	●	S047
2016	Chevrolet	Volt	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Chevrolet	Work	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	○	
2016	Chevrolet	Work	Engine Control Module	●	●	●	●	●	●	S095 S096 S155
2016	Chevrolet	Work	Electronic Brake Control Module	●	●	●	●	●	○	
2016	GMC	Acadia	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	GMC	Acadia	Head-Up Display Module	●	●	●	●	●	○	
2016	GMC	Acadia	Instrument Cluster	●	●	●	●	●	○	
2016	GMC	Acadia	Theft Deterrent Module	●	●	●	●	○	○	
2016	GMC	Acadia	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2016	GMC	Acadia	Liftgate Control Module	●	●	●	●	○	●	S049
2016	GMC	Acadia	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2016	GMC	Acadia	Front Seat Heating Control Module	●	●	●	●	○	○	
2016	GMC	Acadia	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	GMC	Acadia	Left Side Object Detection Control Module	●	●	●	○	●	○	

2016	GMC	Canyon	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	GMC	Canyon	Instrument Cluster	●	●	●	●	●	●	
2016	GMC	Canyon	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S045 S029 S025 S030
2016	GMC	Canyon	Transmission Control Module	●	●	●	●	●	●	S048
2016	GMC	Canyon	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	GMC	Canyon	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	GMC	Canyon	Passenger Presence Module	●	●	●	●	●	●	S043
2016	GMC	Canyon	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2016	GMC	Canyon	Amplifier	●	●	●	●	○	○	
2016	GMC	Canyon	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	GMC	Canyon	Radio	●	●	●	●	●	●	S063 S064
2016	GMC	Canyon	Electronic Brake Control Module	●	●	●	●	●	●	S036
2016	GMC	Canyon	Power Steering Control Module	●	●	●	●	●	●	S093 S035
2016	GMC	Canyon	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	GMC	Canyon	Trailer Interface Control Module	●	●	●	●	●	●	S022

2016	GMC	Savana	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2016	GMC	Savana	Radio	●	●	●	●	●	●	
2016	GMC	Savana	Electronic Brake Control Module	●	●	●	●	●	●	S036
2016	GMC	Savana	Chime Alarm Control Module	●	●	●	○	●	○	
2016	GMC	Sierra	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S156 S086
2016	GMC	Sierra	Engine Control Module	●	●	●	●	●	●	S112 S103 S119 S120 S121 S122 S029 S123 S124 S125 S126 S127 S128 S129 S130 S131 S132 S030 S133 S134 S135 S136 S137 S138 S139 S140 S141 S142 S143 S144 S145 S146 S147 S148 S149 S150 S151 S152 S153
2016	GMC	Sierra	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141 S154
2016	GMC	Sierra	Power Take-Off Control Module	●	●	●	●	●	●	S158 S159
2016	GMC	Sierra	Telematics Communication Interface Control Module	●	●	●	●	●	●	
2016	GMC	Sierra	Instrument Cluster	●	●	●	●	●	●	S022
2016	GMC	Sierra	Hybrid Powertrain Control Module	●	●	●	●	●	●	S157
2016	GMC	Sierra	Transmission Control Module	●	●	●	●	●	●	S048

2016	GMC	Sierra	Fuel Injector Control Module	●	●	●	●	●	○	
2016	GMC	Sierra	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	GMC	Sierra	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	GMC	Sierra	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	GMC	Sierra	Passenger Presence Module	●	●	●	●	●	●	S043
2016	GMC	Sierra	Transfer Case Control Module	●	●	●	●	●	●	S080
2016	GMC	Sierra	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	GMC	Sierra	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	GMC	Sierra	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	GMC	Sierra	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	GMC	Sierra	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2016	GMC	Sierra	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	GMC	Sierra	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2016	GMC	Sierra	Power Steering Control Module	●	●	●	●	●	●	S064
2016	GMC	Sierra	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2016	GMC	Sierra	Suspension Control Module	●	●	●	●	●	●	

2016	GMC	Sierra	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	GMC	Sierra	Amplifier	●	●	●	●	○	○	
2016	GMC	Sierra	Assist Step Control Module	●	●	●	●	●	●	
2016	GMC	Sierra	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	GMC	Sierra	HVAC Controls	●	●	●	●	●	●	S065
2016	GMC	Sierra	Radio Controls	●	●	●	●	○	●	S065
2016	GMC	Sierra	Media Disc Player	●	●	●	●	●	○	
2016	GMC	Sierra	Radio	●	●	●	●	●	●	S063 S064
2016	GMC	Terrain	Telematics Communication Interface Control Module	●	●	●	●	●	●	
2016	GMC	Terrain	Liftgate Control Module	●	●	●	●	●	●	S049 S062
2016	GMC	Terrain	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2016	GMC	Terrain	Instrument Cluster	●	●	●	●	●	●	S022
2016	GMC	Terrain	Transmission Control Module	●	●	●	●	●	●	S048
2016	GMC	Terrain	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	GMC	Terrain	Radio	●	●	●	●	●	○	
2016	GMC	Terrain	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2016	GMC	Terrain	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2016	GMC	Terrain	Power Steering Control Module	●	●	●	●	○	●	
2016	GMC	Terrain	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	

2016	GMC	Terrain	Passenger Presence Module	●	●	●	●	○	●	S043
2016	GMC	Terrain	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2016	GMC	Terrain	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S046
2016	GMC	Terrain	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	GMC	Terrain	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	GMC	Terrain	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	GMC	Terrain	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	GMC	Terrain	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	GMC	Terrain	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	GMC	Terrain	Seat Memory Control Module	●	●	●	●	●	●	S031
2016	GMC	Yukon	Steering Column Lock Control Module	●	●	●	●	○	●	
2016	GMC	Yukon	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	GMC	Yukon	Instrument Cluster	●	●	●	●	●	●	S022
2016	GMC	Yukon	Liftgate Control Module	●	●	●	●	●	●	S049 S062

2016	GMC	Yukon	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2016	GMC	Yukon	Transmission Control Module	●	●	●	●	●	●	S048
2016	GMC	Yukon	Parking Assist Control Module	●	●	●	●	●	●	S081
2016	GMC	Yukon	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	GMC	Yukon	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	GMC	Yukon	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2016	GMC	Yukon	Passenger Presence Module	●	●	●	●	●	●	S043
2016	GMC	Yukon	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2016	GMC	Yukon	Keyless Entry Control Module	●	●	●	●	●	○	
2016	GMC	Yukon	Transfer Case Control Module	●	●	●	●	●	●	S080
2016	GMC	Yukon	Amplifier	●	●	●	●	○	○	
2016	GMC	Yukon	Assist Step Control Module	●	●	●	●	●	●	
2016	GMC	Yukon	Media Disc Player	●	●	●	●	●	○	
2016	GMC	Yukon	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	GMC	Yukon	HVAC Controls	●	●	●	●	●	●	S065
2016	GMC	Yukon	Radio Controls	●	●	●	●	○	●	S065
2016	GMC	Yukon	Radio	●	●	●	●	●	●	S063 S064
2016	GMC	Yukon	Electronic Brake Control Module	●	●	●	●	●	●	S036

2016	GMC	Yukon	Power Steering Control Module	●	●	●	●	●	●	S064
2016	GMC	Yukon	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2016	GMC	Yukon	Suspension Control Module	●	●	●	●	●	●	
2016	GMC	Yukon	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	GMC	Yukon	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2016	GMC	Yukon	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	GMC	Yukon	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	GMC	Yukon	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	GMC	Yukon	Seat Memory Control Module - Passenger	●	●	●	●	●	○	
2016	GMC	Yukon XL	Steering Column Lock Control Module	●	●	●	●	○	●	
2016	GMC	Yukon XL	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2016	GMC	Yukon XL	Instrument Cluster	●	●	●	●	●	●	S022
2016	GMC	Yukon XL	Liftgate Control Module	●	●	●	●	●	●	S049 S062
2016	GMC	Yukon XL	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2016	GMC	Yukon XL	Transmission Control Module	●	●	●	●	●	●	S048
2016	GMC	Yukon XL	Parking Assist Control Module	●	●	●	●	●	●	S081

2016	GMC	Yukon XL	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	GMC	Yukon XL	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	GMC	Yukon XL	Seat Memory Control Module – Driver	●	●	●	●	●	●	S031
2016	GMC	Yukon XL	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036
2016	GMC	Yukon XL	Keyless Entry Control Module	●	●	●	●	●	○	
2016	GMC	Yukon XL	Passenger Presence Module	●	●	●	●	●	●	S043
2016	GMC	Yukon XL	Amplifier	●	●	●	●	○	○	
2016	GMC	Yukon XL	Assist Step Control Module	●	●	●	●	●	●	
2016	GMC	Yukon XL	Media Disc Player	●	●	●	●	●	○	
2016	GMC	Yukon XL	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	GMC	Yukon XL	HVAC Controls	●	●	●	●	●	●	S065
2016	GMC	Yukon XL	Radio Controls	●	●	●	●	○	●	S065
2016	GMC	Yukon XL	Radio	●	●	●	●	●	●	S063 S064
2016	GMC	Yukon XL	Electronic Brake Control Module	●	●	●	●	●	●	S036
2016	GMC	Yukon XL	Power Steering Control Module	●	●	●	●	●	●	S064
2016	GMC	Yukon XL	Suspension Control Module	●	●	●	●	●	●	
2016	GMC	Yukon XL	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2016	GMC	Yukon XL	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	GMC	Yukon XL	Transfer Case Control Module	●	●	●	●	●	●	S080

2016	GMC	Yukon XL	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2016	GMC	Yukon XL	HVAC Control Module	●	●	●	●	●	●	S032 S033
2016	GMC	Yukon XL	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2016	GMC	Yukon XL	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	GMC	Yukon XL	Seat Memory Control Module - Passenger	●	●	●	●	●	○	
2016	Holden	Astra-J	Parking Assist Control Module	●	●	●	●	●	●	
2016	Holden	Astra-J	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Holden	Astra-J	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2016	Holden	Astra-J	Instrument Cluster	●	●	●	●	●	●	
2016	Holden	Astra-J	Radio	●	●	●	●	●	○	
2016	Holden	Astra-J	Headlamp Control Module	●	●	●	●	●	●	
2016	Holden	Astra-J	HVAC Control Module	●	●	●	●	●	●	
2016	Holden	Astra-J	Trailer Interface Control Module	●	●	●	●	●	●	
2016	Holden	Astra-J	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2016	Holden	Astra-J	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Holden	Astra-J	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Holden	Astra-J	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022

2016	Holden	Astra-J	Electronic Brake Control Module	●	●	●	●	●	●	
2016	Holden	Astra-J	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2016	Holden	Astra-J	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Holden	Astra-J	Body Control Module	●	●	●	●	●	●	S001 S014 S016 S015 S017 S018 S019 S021 S021
2016	Holden	Astra-J	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S108 S029 S025 S030
2016	Holden	Astra-J	Suspension Control Module	●	●	●	●	●	○	
2016	Holden	Astra-J	Transmission Control Module	●	●	●	●	●	●	S166
2016	Holden	Barina	Instrument Cluster	●	●	●	●	●	●	
2016	Holden	Barina	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S162 S025 S029 S167
2016	Holden	Barina	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Holden	Barina	Electronic Brake Control Module	●	●	●	●	●	●	S035
2016	Holden	Barina	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036
2016	Holden	Barina	HVAC Control Module	●	●	●	●	●	●	S033
2016	Holden	Barina	Power Steering Control Module	●	●	●	●	○	●	
2016	Holden	Barina	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Holden	Barina	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019

2016	Holden	Barina	Transmission Control Module	●	●	●	●	●	●	S166
2016	Holden	Barina	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Holden	Barina	Radio	●	●	●	●	●	○	
2016	Holden	Barina	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2016	Holden	Caprice	Transmission Control Module	●	●	●	●	●	●	S048
2016	Holden	Caprice	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S094
2016	Holden	Caprice	Seat Memory Control Module - Driver	●	●	●	●	●	○	
2016	Holden	Caprice	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Holden	Caprice	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019
2016	Holden	Caprice	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Holden	Caprice	Instrument Cluster	●	●	●	●	●	●	
2016	Holden	Caprice	Radio Controls	●	●	●	●	●	●	S065 S022
2016	Holden	Caprice	HVAC Controls	●	●	●	●	●	●	
2016	Holden	Caprice	Trailer Interface Control Module	●	●	●	●	●	●	
2016	Holden	Caprice	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2016	Holden	Caprice	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2016	Holden	Caprice	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Holden	Caprice	Power Steering Control Module	●	●	●	●	○	●	
2016	Holden	Caprice	Suspension Control Module	●	●	●	●	●	●	

2016	Holden	Caprice	Head-Up Display Module	●	●	●	●	●	○	
2016	Holden	Caprice	Radio	●	●	●	●	●	○	
2016	Holden	Caprice	Steering Column Lock Control Module	●	●	●	●	○	○	
2016	Holden	Caprice	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2016	Holden	Caprice	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Holden	Caprice	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Holden	Caprice	HVAC Control Module	●	●	●	●	●	●	S033
2016	Holden	Caprice	Headlamp Control Module	●	●	●	●	●	●	S002
2016	Holden	Caprice	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Holden	Caprice	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Holden	Captiva	Engine Control Module	●	●	●	●	●	●	S044 S026 S105 S108 S169 S170 S109 S110 S171 S111 S045 S172 S173 S112 S122 S113 S029 S115 S116 S174 S175 S176 S177
2016	Holden	Captiva	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2016	Holden	Captiva	Transmission Control Module	●	●	●	●	●	●	S166
2016	Holden	Captiva	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S053
2016	Holden	Captiva	Radio	●	●	●	●	●	○	
2016	Holden	Captiva	Electronic Brake Control Module	●	●	●	●	●	●	S035

2016	Holden	Captiva	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Holden	Captiva	Instrument Cluster	●	●	●	●	●	○	
2016	Holden	Captiva	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2016	Holden	Captiva	Remote Control Door Lock Receiver	●	●	●	●	●	●	S019 S020
2016	Holden	Captiva	Body Control Module	●	●	●	●	●	●	S013 S001
2016	Holden	Captiva	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Holden	Captiva	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Holden	Captiva	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2016	Holden	Captiva	Headlamp Control Module	●	●	●	●	●	●	S002 S179
2016	Holden	Cascada	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036
2016	Holden	Cascada	Parking Assist Control Module	●	●	●	●	●	●	
2016	Holden	Cascada	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Holden	Cascada	Instrument Cluster	●	●	●	●	●	●	
2016	Holden	Cascada	Radio	●	●	●	●	●	○	
2016	Holden	Cascada	Headlamp Control Module	●	●	●	●	●	●	
2016	Holden	Cascada	HVAC Control Module	●	●	●	●	●	●	
2016	Holden	Cascada	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2016	Holden	Cascada	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	

2016	Holden	Cascada	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Holden	Cascada	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022
2016	Holden	Cascada	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Holden	Cascada	Electronic Brake Control Module	●	●	●	●	●	●	
2016	Holden	Cascada	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2016	Holden	Cascada	Body Control Module	●	●	●	●	●	●	S001 S014 S016 S015 S017 S018 S019 S021 S021
2016	Holden	Cascada	Folding Top Control Module	●	●	●	●	●	●	
2016	Holden	Cascada	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S108 S027 S028 S045 S162 S119 S029 S180 S025 S094
2016	Holden	Cascada	Transmission Control Module	●	●	●	●	●	●	S166
2016	Holden	Cascada	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2016	Holden	Colorado	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2016	Holden	Colorado	Engine Control Module	●	●	●	●	●	●	S001 S103 S169 S109 S181 S182 S122 S113 S029 S183 S184 S082 S115 S118
2016	Holden	Colorado	Electronic Brake Control Module	●	●	●	●	●	●	S035 S070
2016	Holden	Colorado	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Holden	Colorado	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019

2016	Holden	Colorado	Transmission Control Module	●	●	●	●	●	●	S048
2016	Holden	Colorado	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2016	Holden	Colorado	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Holden	Colorado	Instrument Cluster	●	●	●	●	●	●	S022
2016	Holden	Colorado	Trailer Interface Control Module	●	●	●	●	●	●	S022
2016	Holden	Colorado	Radio	●	●	●	●	●	○	
2016	Holden	Colorado 7	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2016	Holden	Colorado 7	Engine Control Module	●	●	●	●	●	●	S001 S103 S169 S109 S181 S182 S122 S113 S029 S183 S184 S082 S115 S118
2016	Holden	Colorado 7	Electronic Brake Control Module	●	●	●	●	●	●	S035 S070
2016	Holden	Colorado 7	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Holden	Colorado 7	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019
2016	Holden	Colorado 7	Transmission Control Module	●	●	●	●	●	●	S048
2016	Holden	Colorado 7	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Holden	Colorado 7	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2016	Holden	Colorado 7	Instrument Cluster	●	●	●	●	●	●	S022
2016	Holden	Colorado 7	Trailer Interface Control Module	●	●	●	●	●	●	S022
2016	Holden	Colorado 7	Radio	●	●	●	●	●	○	

2016	Holden	Commodore	Steering Column Lock Control Module	●	●	●	●	○	○	
2016	Holden	Commodore	Liftgate Control Module	●	●	●	●	○	○	
2016	Holden	Commodore	Transmission Control Module	●	●	●	●	●	●	S048
2016	Holden	Commodore	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2016	Holden	Commodore	Seat Memory Control Module - Driver	●	●	●	●	●	○	
2016	Holden	Commodore	Parking Assist Control Module	●	●	●	●	●	●	S022
2016	Holden	Commodore	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019
2016	Holden	Commodore	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Holden	Commodore	Instrument Cluster	●	●	●	●	●	●	
2016	Holden	Commodore	HVAC Controls	●	●	●	●	●	●	
2016	Holden	Commodore	Radio Controls	●	●	●	●	●	●	S065 S022
2016	Holden	Commodore	Trailer Interface Control Module	●	●	●	●	●	●	
2016	Holden	Commodore	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2016	Holden	Commodore	Power Steering Control Module	●	●	●	●	○	●	
2016	Holden	Commodore	Suspension Control Module	●	●	●	●	●	●	
2016	Holden	Commodore	Head-Up Display Module	●	●	●	●	●	○	
2016	Holden	Commodore	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Holden	Commodore	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2016	Holden	Commodore	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	

2016	Holden	Commodore	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Holden	Commodore	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2016	Holden	Commodore	Radio	●	●	●	●	●	○	
2016	Holden	Commodore	HVAC Control Module	●	●	●	●	●	●	S033
2016	Holden	Commodore	Headlamp Control Module	●	●	●	●	●	●	S002
2016	Holden	Commodore	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2016	Holden	Commodore	Right Side Object Detection Control Module	●	●	●	○	●	○	
2016	Holden	Cruze	Fuel Injector Control Module	○	○	●	●	●	○	
2016	Holden	Insignia	Front Seat Heating/Venting/Cooling/Memory Control Module	●	●	●	●	●	○	
2016	Holden	Insignia	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036
2016	Holden	Insignia	Parking Assist Control Module	●	●	●	●	●	●	
2016	Holden	Insignia	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2016	Holden	Insignia	Headlamp Control Module	●	●	●	●	●	●	
2016	Holden	Insignia	HVAC Control Module	●	●	●	●	●	●	S033
2016	Holden	Insignia	Radio	●	●	●	●	●	●	S063
2016	Holden	Insignia	Instrument Cluster	●	●	●	●	●	●	
2016	Holden	Insignia	Trailer Interface Control Module	●	●	●	●	●	●	

2016	Holden	Insignia	Left Side Object Detection Control Module	●	●	●	○	●	○	
2016	Holden	Insignia	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2016	Holden	Insignia	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2016	Holden	Insignia	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Holden	Insignia	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2016	Holden	Insignia	Amplifier	●	●	●	●	○	○	
2016	Holden	Insignia	Electronic Brake Control Module	●	●	●	●	●	●	
2016	Holden	Insignia	Engine Control Module	●	●	●	●	●	●	S044 S028 S029 S025
2016	Holden	Insignia	Power Steering Control Module	●	●	●	●	●	○	
2016	Holden	Insignia	Parking Brake Control Module	●	●	●	●	●	●	S037
2016	Holden	Insignia	Body Control Module	●	●	●	●	●	●	S001 S014 S016 S015 S017 S018 S019
2016	Holden	Insignia	Steering Column Lock Control Module	●	●	●	●	○	●	
2016	Holden	Insignia	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Holden	Insignia	HVAC Controls	●	●	●	●	●	●	
2016	Holden	Insignia	Radio Controls	●	●	●	●	●	●	S064
2016	Holden	Insignia	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2016	Holden	Insignia	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2016	Holden	Insignia	Suspension Control Module	●	●	●	●	●	○	
2016	Holden	Insignia	Transmission Control Module	●	●	●	●	●	●	

2016	Holden	Spark	Transmission Control Module	●	●	●	●	●	●	
2016	Holden	Spark	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S162 S029 S025 S185
2016	Holden	Spark	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036
2016	Holden	Spark	Parking Assist Control Module	●	●	●	●	●	○	
2016	Holden	Spark	Electronic Brake Control Module	●	●	●	●	●	●	
2016	Holden	Spark	Power Steering Control Module	●	●	●	●	○	●	
2016	Holden	Spark	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019
2016	Holden	Spark	Radio	●	●	●	●	●	○	
2016	Holden	Spark	Instrument Cluster	●	●	●	●	●	●	
2016	Holden	Spark	Keyless Entry Control Module	●	●	●	●	●	○	
2016	Holden	Trax	Instrument Cluster	●	●	●	●	●	●	
2016	Holden	Trax	Electronic Brake Control Module	●	●	●	●	●	●	S035
2016	Holden	Trax	Power Steering Control Module	●	●	●	●	○	●	
2016	Holden	Trax	Parking Assist Control Module	●	●	●	●	●	●	
2016	Holden	Trax	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019
2016	Holden	Trax	Transmission Control Module	●	●	●	●	●	●	S166
2016	Holden	Trax	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S162 S025 S029 S167

2016	Holden	Trax	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2016	Holden	Trax	Front Seat Heating Control Module	●	●	●	●	●	○	
2016	Holden	Trax	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2016	Holden	Trax	Radio	●	●	●	●	●	○	
2016	Holden	Trax	HVAC Control Module	●	●	●	●	●	●	S033
2016	Holden	Trax	Rear Differential Clutch Control Module	●	●	●	●	●	●	
2016	Holden	Trax	Trailer Interface Control Module	●	●	●	●	●	●	
2016	Ravon	Gentra	Transmission Control Module	●	●	●	●	●	●	S023
2016	Ravon	Gentra	Fuel Injector Control Module	●	●	●	●	●	○	
2016	Ravon	Gentra	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	○	
2016	Ravon	Gentra	Engine Control Module	●	●	●	●	●	●	S026 S044 S045 S025
2016	Ravon	Gentra	Electronic Brake Control Module	●	●	●	●	●	○	
2016	Ravon	Matiz	Engine Control Module	●	●	●	●	●	●	S095 S096
2016	Ravon	Matiz	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	○	
2016	Ravon	Matiz	Electronic Brake Control Module	●	●	●	●	●	○	
2015	Buick	Enclave	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034 S036
2015	Buick	Enclave	Headlamp Control Module	●	●	●	○	○	○	
2015	Buick	Enclave	Liftgate Control Module	●	●	●	●	○	●	S049

2015	Buick	Enclave	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2015	Buick	Enclave	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2015	Buick	Enclave	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S029 S025 S030
2015	Buick	Enclave	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2015	Buick	Enclave	Front Seat Heating Control Module	●	●	●	●	○	○	
2015	Buick	Enclave	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2015	Buick	Enclave	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Buick	Enclave	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Buick	Enclave	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	Buick	Enclave	Seat Memory Control Module	●	●	●	●	●	○	
2015	Buick	Enclave	Transmission Control Module	●	●	●	●	●	●	S048
2015	Buick	Enclave	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2015	Buick	Enclave	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2015	Buick	Enclave	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Buick	Enclave	Radio	●	●	●	●	●	●	

2015	Buick	Enclave	Rear Audio Control Module	●	●	●	●	●	○	
2015	Buick	Enclave	Personal Audio Link Control Module	●	●	●	○	○	●	S056
2015	Buick	Enclave	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2015	Buick	Enclave	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2015	Buick	Enclave	HVAC Control Module	●	●	●	●	●	●	S052 S032 S033
2015	Buick	Enclave	Instrument Cluster	●	●	●	●	●	○	
2015	Buick	Enclave	Theft Deterrent Module	●	●	●	●	○	○	
2015	Buick	Enclave	Head-Up Display Module	●	●	●	●	●	○	
2015	Buick	Enclave	Body Control Module	●	●	●	●	●	●	S001 S053
2015	Buick	Encore	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Buick	Encore	Instrument Cluster	●	●	●	●	●	●	S022
2015	Buick	Encore	Transmission Control Module	●	●	●	●	●	●	S023
2015	Buick	Encore	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2015	Buick	Encore	Electronic Brake Control Module	●	●	●	●	●	●	S035
2015	Buick	Encore	Power Steering Control Module	●	●	●	●	○	●	
2015	Buick	Encore	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Buick	Encore	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Buick	Encore	Frontview Camera Module	●	●	●	●	●	●	S050 S051

2015	Buick	Encore	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Buick	Encore	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Buick	Encore	Seat Memory Control Module	●	●	●	●	●	●	S031
2015	Buick	Encore	Rear Differential Clutch Control Module	●	●	●	●	●	●	
2015	Buick	Encore	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Buick	Encore	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Buick	Encore	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Buick	Encore	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Buick	Encore	Chassis Control Module	●	●	●	●	●	●	S025
2015	Buick	Encore	Radio	●	●	●	●	●	○	
2015	Buick	LaCrosse	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Buick	LaCrosse	Headlamp Control Module	●	●	●	●	●	○	
2015	Buick	LaCrosse	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2015	Buick	LaCrosse	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	Buick	LaCrosse	Instrument Cluster	●	●	●	●	●	●	S022
2015	Buick	LaCrosse	Transmission Control Module	●	●	●	●	●	●	S048

2015	Buick	LaCrosse	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Buick	LaCrosse	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Buick	LaCrosse	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Buick	LaCrosse	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Buick	LaCrosse	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2015	Buick	LaCrosse	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2015	Buick	LaCrosse	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Buick	LaCrosse	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Buick	LaCrosse	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S030
2015	Buick	LaCrosse	Drive Motor Control Module	●	●	●	●	○	○	
2015	Buick	LaCrosse	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2015	Buick	LaCrosse	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Buick	LaCrosse	Head-Up Display Module	●	●	●	●	●	○	
2015	Buick	LaCrosse	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2015	Buick	LaCrosse	Parking Brake Control Module	●	●	●	●	●	●	S037

2015	Buick	LaCrosse	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Buick	LaCrosse	Suspension Control Module	●	●	●	●	●	○	
2015	Buick	LaCrosse	Power Steering Control Module	●	●	●	●	○	●	S047
2015	Buick	LaCrosse	Battery Energy Control Module	○	○	●	●	○	○	
2015	Buick	LaCrosse	Radio	●	●	●	●	●	●	S063 S064
2015	Buick	LaCrosse	Radio Controls	●	●	●	●	○	●	S065
2015	Buick	LaCrosse	HVAC Controls	●	●	●	●	●	●	S065
2015	Buick	LaCrosse	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	Buick	LaCrosse	Amplifier	●	●	●	●	○	○	
2015	Buick	Regal	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Buick	Regal	Battery Energy Control Module	○	○	●	●	○	○	
2015	Buick	Regal	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2015	Buick	Regal	Chassis Control Module	●	●	●	●	●	●	S025
2015	Buick	Regal	Instrument Cluster	●	●	●	●	●	●	S022
2015	Buick	Regal	Transmission Control Module	●	●	●	●	●	●	S048
2015	Buick	Regal	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Buick	Regal	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Buick	Regal	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036 S036
2015	Buick	Regal	Amplifier	●	●	●	●	○	○	

2015	Buick	Regal	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	Buick	Regal	HVAC Controls	●	●	●	●	●	●	S065
2015	Buick	Regal	Radio Controls	●	●	●	●	○	●	S065
2015	Buick	Regal	Radio	●	●	●	●	●	●	S063 S064
2015	Buick	Regal	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Buick	Regal	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2015	Buick	Regal	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Buick	Regal	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2015	Buick	Regal	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Buick	Regal	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Buick	Regal	Seat Memory Control Module	●	●	●	●	●	●	S031
2015	Buick	Regal	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S030
2015	Buick	Regal	Drive Motor Control Module	●	●	●	●	○	○	
2015	Buick	Regal	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2015	Buick	Regal	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Buick	Regal	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069

2015	Buick	Regal	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Buick	Regal	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Buick	Regal	Suspension Control Module	●	●	●	●	●	○	
2015	Buick	Regal	Power Steering Control Module	●	●	●	●	○	●	S047
2015	Buick	Verano	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Buick	Verano	Transmission Control Module	●	●	●	●	●	●	S023
2015	Buick	Verano	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Buick	Verano	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2015	Buick	Verano	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Buick	Verano	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Buick	Verano	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	Buick	Verano	Instrument Cluster	●	●	●	●	●	●	S022
2015	Buick	Verano	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Buick	Verano	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2015	Buick	Verano	Passenger Presence Module	●	●	●	●	○	●	S043

2015	Buick	Verano	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S029 S025 S030
2015	Buick	Verano	Chassis Control Module	●	●	●	●	●	●	S025
2015	Buick	Verano	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Buick	Verano	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2015	Buick	Verano	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Buick	Verano	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S070 S036
2015	Buick	Verano	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Buick	Verano	Power Steering Control Module	●	●	●	●	○	●	S047
2015	Buick	Verano	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Buick	Verano	Radio	●	●	●	●	●	○	
2015	Buick	Verano	Multimedia Player Interface Module	●	●	●	●	○	●	
2015	Cadillac	ATS	Headlamp Control Module	●	●	●	●	●	●	S002
2015	Cadillac	ATS	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Cadillac	ATS	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Cadillac	ATS	Transmission Control Module	●	●	●	●	●	●	S048
2015	Cadillac	ATS	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Cadillac	ATS	Long Range Radar Sensor Module	●	●	●	●	○	●	S061

2015	Cadillac	ATS	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2015	Cadillac	ATS	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2015	Cadillac	ATS	Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2015	Cadillac	ATS	Active Safety Control Module	●	●	●	●	●	○	
2015	Cadillac	ATS	Frontview Camera Module	●	●	●	●	○	●	S051
2015	Cadillac	ATS	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Cadillac	ATS	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Cadillac	ATS	Pedestrian Impact Detection Module	●	●	●	●	○	●	
2015	Cadillac	ATS	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	Cadillac	ATS	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2015	Cadillac	ATS	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2015	Cadillac	ATS	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Cadillac	ATS	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Cadillac	ATS	Seat Belt Retractor Motor Module - Left	●	●	●	●	●	●	S078
2015	Cadillac	ATS	Seat Belt Retractor Motor Module - Right	●	●	●	●	●	●	S078
2015	Cadillac	ATS	Instrument Cluster	●	●	●	●	●	●	S022

2015	Cadillac	ATS	Trailer Interface Control Module	●	●	●	●	●	●	S022
2015	Cadillac	ATS	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2015	Cadillac	ATS	Suspension Control Module	●	●	●	●	●	●	S076 S077 S077 S038
2015	Cadillac	ATS	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Cadillac	ATS	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2015	Cadillac	ATS	Power Steering Control Module	●	●	●	●	○	●	S075
2015	Cadillac	ATS	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Cadillac	ATS	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S029 S025 S030
2015	Cadillac	ATS	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	Cadillac	ATS	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Cadillac	ATS	Transfer Case Control Module	●	●	●	●	●	●	S072 S073 S074
2015	Cadillac	ATS	Radio	●	●	●	●	●	●	S063 S064
2015	Cadillac	ATS	Radio/HVAC Controls	●	●	●	●	●	○	
2015	Cadillac	ATS	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	Cadillac	ATS	Media Disc Player	●	●	●	●	●	○	
2015	Cadillac	ATS	Amplifier	●	●	●	●	○	○	
2015	Cadillac	ATS	Navigation Control Module	●	●	●	●	●	●	

2015	Cadillac	ELR	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2015	Cadillac	ELR	Battery Energy Control Module	○	○	●	●	○	○	
2015	Cadillac	ELR	Coolant Heater Control Module	●	●	●	●	○	○	
2015	Cadillac	ELR	Battery Charger Control Module	○	○	●	●	○	○	
2015	Cadillac	ELR	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S083 S084 S085 S086 S087 S088 S089
2015	Cadillac	ELR	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Cadillac	ELR	Headlamp Control Module	●	●	●	●	●	●	
2015	Cadillac	ELR	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Cadillac	ELR	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	Cadillac	ELR	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2015	Cadillac	ELR	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Cadillac	ELR	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Cadillac	ELR	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	Cadillac	ELR	Instrument Cluster	●	●	●	●	●	●	S022
2015	Cadillac	ELR	Transmission Control Module	●	●	●	●	●	○	
2015	Cadillac	ELR	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S091

2015	Cadillac	ELR	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Cadillac	ELR	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2015	Cadillac	ELR	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2015	Cadillac	ELR	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Cadillac	ELR	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Cadillac	ELR	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	Cadillac	ELR	Amplifier	●	●	●	●	○	○	
2015	Cadillac	ELR	Radio	●	●	●	●	●	●	S063 S064
2015	Cadillac	ELR	Radio/HVAC Controls	●	●	●	●	●	○	
2015	Cadillac	ELR	Pedestrian Alert Sound Control Module	●	●	●	●	●	○	
2015	Cadillac	ELR	Electronic Brake Control Module	●	●	●	●	●	●	S092 S036 S036 S036
2015	Cadillac	ELR	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Cadillac	ELR	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2015	Cadillac	ELR	Hybrid Powertrain Control Module	●	●	●	●	●	○	
2015	Cadillac	ELR	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Cadillac	ELR	Drive Motor Control Module 1	●	●	●	●	○	○	
2015	Cadillac	ELR	Drive Motor Control Module 2	●	●	●	●	○	○	
2015	Cadillac	ELR	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	

2015	Cadillac	ELR	Suspension Control Module	●	●	●	●	●	○	
2015	Cadillac	ELR	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Cadillac	Escalade	Hybrid Powertrain Control Module	●	●	●	●	●	○	
2015	Cadillac	Escalade	Transfer Case Control Module	●	●	●	●	●	●	S080
2015	Cadillac	Escalade	Drive Motor Control Module 1	○	○	●	●	○	○	
2015	Cadillac	Escalade	Drive Motor Control Module 2	○	○	●	●	○	○	
2015	Cadillac	Escalade	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	
2015	Cadillac	Escalade	Battery Energy Control Module	○	○	●	●	○	○	
2015	Cadillac	Escalade	Transmission Control Module	●	●	●	●	●	●	S048
2015	Cadillac	Escalade	Parking Assist Control Module	●	●	●	●	●	●	S081
2015	Cadillac	Escalade	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Cadillac	Escalade	Instrument Cluster	●	●	●	●	●	●	S022
2015	Cadillac	Escalade	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2015	Cadillac	Escalade	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036

2015	Cadillac	Escalade	Passenger Presence Module	●	●	●	●	●	●	S043
2015	Cadillac	Escalade	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Cadillac	Escalade	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2015	Cadillac	Escalade	Power Steering Control Module	●	●	●	●	●	●	S064
2015	Cadillac	Escalade	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2015	Cadillac	Escalade	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2015	Cadillac	Escalade	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2015	Cadillac	Escalade	Suspension Control Module	●	●	●	●	●	●	
2015	Cadillac	Escalade	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	Cadillac	Escalade	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Cadillac	Escalade	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Cadillac	Escalade	Frontview Camera Module	●	●	●	●	○	●	S051
2015	Cadillac	Escalade	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2015	Cadillac	Escalade	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Cadillac	Escalade	Liftgate Control Module	●	●	●	●	●	●	S049 S062
2015	Cadillac	Escalade	Seat Belt Retractor Motor Module - Left	●	●	●	●	●	●	S078

2015	Cadillac	Escalade ESV	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Cadillac	Escalade ESV	Passenger Presence Module	●	●	●	●	●	●	S043
2015	Cadillac	Escalade ESV	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Cadillac	Escalade ESV	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2015	Cadillac	Escalade ESV	Transfer Case Control Module	●	●	●	●	●	●	S080
2015	Cadillac	Escalade ESV	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Cadillac	Escalade ESV	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Cadillac	Escalade ESV	Frontview Camera Module	●	●	●	●	○	●	S051
2015	Cadillac	Escalade ESV	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Cadillac	Escalade ESV	Parking Assist Control Module	●	●	●	●	●	●	S081
2015	Cadillac	Escalade ESV	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2015	Cadillac	Escalade ESV	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Cadillac	Escalade ESV	Liftgate Control Module	●	●	●	●	●	●	
2015	Cadillac	Escalade ESV	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039

2015	Cadillac	SRX	Liftgate Control Module	●	●	●	●	●	●	S049
2015	Cadillac	SRX	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Cadillac	SRX	Headlamp Control Module	●	●	●	●	●	●	
2015	Cadillac	SRX	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2015	Cadillac	SRX	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2015	Cadillac	SRX	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2015	Cadillac	SRX	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Cadillac	SRX	Suspension Control Module	●	●	●	●	●	○	
2015	Cadillac	SRX	Instrument Cluster	●	●	●	●	●	●	S022
2015	Cadillac	SRX	Trailer Interface Control Module	●	●	●	●	●	●	S022
2015	Cadillac	SRX	Transmission Control Module	●	●	●	●	●	●	S048
2015	Cadillac	SRX	Amplifier	●	●	●	●	○	○	
2015	Cadillac	SRX	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	Cadillac	SRX	Media Disc Player	●	●	●	●	●	○	
2015	Cadillac	SRX	Rear Audio Control Module	●	●	●	●	●	○	
2015	Cadillac	SRX	Radio	●	●	●	●	●	●	S063 S064
2015	Cadillac	SRX	Navigation Control Module	●	●	●	●	●	●	
2015	Cadillac	SRX	Radio/HVAC Controls	●	●	●	●	●	○	
2015	Cadillac	SRX	HVAC Control Module	●	●	●	●	●	●	S032 S033

2015	Cadillac	SRX	Long Range Radar Sensor Module	●	●	●	●	○	●	S061
2015	Cadillac	SRX	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2015	Cadillac	SRX	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2015	Cadillac	SRX	Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2015	Cadillac	SRX	Active Safety Control Module	●	●	●	●	●	○	
2015	Cadillac	SRX	Frontview Camera Module	●	●	●	●	○	●	S051
2015	Cadillac	SRX	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Cadillac	SRX	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Cadillac	SRX	Rear Seat Heating Control Module	●	●	●	●	●	○	
2015	Cadillac	SRX	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	Cadillac	SRX	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2015	Cadillac	SRX	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2015	Cadillac	SRX	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Cadillac	SRX	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Cadillac	SRX	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S094 S046

2015	Cadillac	XTS	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Cadillac	XTS	Suspension Control Module	●	●	●	●	●	●	S076 S077 S077 S038
2015	Cadillac	XTS	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Cadillac	XTS	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2015	Cadillac	XTS	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Cadillac	XTS	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2015	Cadillac	XTS	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Cadillac	XTS	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2015	Cadillac	XTS	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Cadillac	XTS	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2015	Cadillac	XTS	Long Range Radar Sensor Module	●	●	●	●	○	●	S061
2015	Cadillac	XTS	Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2015	Cadillac	XTS	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2015	Cadillac	XTS	Chassis Control Module	●	●	●	●	●	●	S025
2015	Cadillac	XTS	Power Steering Control Module	●	●	●	●	●	○	

2015	Cadillac	XTS	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Cadillac	XTS	Radio/HVAC Controls	●	●	●	●	●	○	
2015	Cadillac	XTS	Radio	●	●	●	●	●	●	S063 S064
2015	Cadillac	XTS	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	Chevrolet	Beat	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	Beat	Engine Control Module	●	●	●	●	●	●	S095 S096
2015	Chevrolet	Beat	Transmission Control Module	●	●	●	●	●	○	
2015	Chevrolet	Beat	Fuel Injector Control Module	●	●	●	●	●	○	
2015	Chevrolet	Beat	Instrument Cluster	●	●	●	●	●	○	
2015	Chevrolet	Beat	Electronic Brake Control Module	●	●	●	●	●	●	
2015	Chevrolet	Beat	Power Steering Control Module	●	●	●	●	○	●	
2015	Chevrolet	Beat	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2015	Chevrolet	Beat	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Beat	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2015	Chevrolet	Beat	Radio	●	●	●	●	●	○	

2015	Chevrolet	Camaro	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	Camaro	Headlamp Control Module	●	●	●	●	●	●	S002
2015	Chevrolet	Camaro	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2015	Chevrolet	Camaro	Mobile Telephone Control Module	●	●	●	●	●	●	
2015	Chevrolet	Camaro	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Camaro	Auxiliary Gage Module	●	●	●	●	●	○	
2015	Chevrolet	Camaro	Head-Up Display Module	●	●	●	●	●	○	
2015	Chevrolet	Camaro	Transmission Control Module	●	●	●	●	●	●	S048
2015	Chevrolet	Camaro	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Chevrolet	Camaro	Folding Top Control Module	●	●	●	●	●	○	
2015	Chevrolet	Camaro	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Chevrolet	Camaro	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	Camaro	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2015	Chevrolet	Camaro	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Chevrolet	Camaro	Radio	●	●	●	●	●	○	
2015	Chevrolet	Camaro	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	Chevrolet	Camaro	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034 S036
2015	Chevrolet	Camaro	Power Steering Control Module	●	●	●	●	○	●	S047
2015	Chevrolet	Camaro	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	

2015	Chevrolet	Camaro	Suspension Control Module	●	●	●	●	●	●	S038
2015	Chevrolet	Camaro	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2015	Chevrolet	Camaro	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Chevrolet	Caprice	Transmission Control Module	●	●	●	●	●	●	S048
2015	Chevrolet	Caprice	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2015	Chevrolet	Caprice	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	Caprice	Headlamp Control Module	●	●	●	●	●	●	S002
2015	Chevrolet	Caprice	Suspension Control Module	●	●	●	●	●	●	S076 S077 S038
2015	Chevrolet	Caprice	Trailer Interface Control Module	●	●	●	●	●	●	
2015	Chevrolet	Caprice	Fuel Injector Control Module	○	○	●	●	●	○	
2015	Chevrolet	Caprice	Instrument Cluster	●	●	●	●	●	●	S022 S097
2015	Chevrolet	Caprice	Head-Up Display Module	●	●	●	●	●	○	
2015	Chevrolet	Caprice	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Chevrolet	Caprice	Passenger Presence Module	●	●	●	●	○	●	S043

2015	Chevrolet	Cheyenne	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Chevrolet	Cheyenne	Passenger Presence Module	●	●	●	●	●	●	S043
2015	Chevrolet	Cheyenne	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S029 S025 S030
2015	Chevrolet	Cheyenne	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2015	Chevrolet	Cheyenne	Power Steering Control Module	●	●	●	●	●	●	S064
2015	Chevrolet	Cheyenne	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2015	Chevrolet	Cheyenne	Suspension Control Module	●	●	●	●	●	●	
2015	Chevrolet	Cheyenne	Fuel Injector Control Module	●	●	●	●	●	○	
2015	Chevrolet	Cheyenne	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Chevrolet	Cheyenne	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	Chevrolet	Cheyenne	Transfer Case Control Module	●	●	●	●	●	●	S080
2015	Chevrolet	Cheyenne	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Cheyenne	Transmission Control Module	●	●	●	●	●	●	S048
2015	Chevrolet	Cheyenne	Amplifier	●	●	●	●	○	○	
2015	Chevrolet	Cheyenne	Radio Controls	●	●	●	●	○	●	S065
2015	Chevrolet	Cheyenne	HVAC Controls	●	●	●	●	●	●	S065
2015	Chevrolet	Cheyenne	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	Chevrolet	Cheyenne	Radio	●	●	●	●	●	●	S063 S064

2015	Chevrolet	Cheyenne	Media Disc Player	●	●	●	●	●	○	
2015	Chevrolet	Cheyenne	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2015	Chevrolet	Cheyenne	Parking Assist Control Module	●	●	●	●	●	●	S081
2015	Chevrolet	Cheyenne	Seat Memory Control Module – Driver	●	●	●	●	●	●	S031
2015	Chevrolet	City Express	Engine Control Module	●	●	●	●	●	●	S025 S028 S099
2015	Chevrolet	City Express	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	○	
2015	Chevrolet	City Express	Passenger Presence Module	○	○	○	●	○	●	
2015	Chevrolet	City Express	Instrument Cluster	●	●	○	●	○	●	
2015	Chevrolet	City Express	Transmission Control Module	●	●	●	●	○	●	S100 S101
2015	Chevrolet	City Express	Radio	●	●	●	●	○	○	
2015	Chevrolet	City Express	Electronic Brake Control Module	●	●	●	●	●	●	
2015	Chevrolet	City Express	Power Steering Control Module	●	●	●	●	○	○	
2015	Chevrolet	City Express	Tire Pressure Indicator Module	●	●	●	●	●	●	S019
2015	Chevrolet	City Express	Underhood Fuse Block	●	●	●	●	●	○	
2015	Chevrolet	City Express	Body Control Module	●	●	●	●	●	●	S098
2015	Chevrolet	Cobalt	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	Cobalt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2015	Chevrolet	Cobalt	Transmission Control Module	●	●	●	●	●	●	S023

2015	Chevrolet	Cobalt	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2015	Chevrolet	Cobalt	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Chevrolet	Cobalt	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Chevrolet	Cobalt	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	Cobalt	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Cobalt	HVAC Control Module	●	●	●	●	●	○	
2015	Chevrolet	Cobalt	Radio	●	●	●	●	●	○	
2015	Chevrolet	Cobalt	Electronic Brake Control Module	●	●	●	●	●	●	S035
2015	Chevrolet	Cobalt	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Corvette	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	Corvette	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2015	Chevrolet	Corvette	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	Chevrolet	Corvette	Rear Differential Clutch Control Module	●	●	●	●	●	●	S079
2015	Chevrolet	Corvette	Vehicle Performance Data Recorder	●	●	●	●	●	○	
2015	Chevrolet	Corvette	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Chevrolet	Corvette	Transmission Control Module	●	●	●	●	●	●	S023

2015	Chevrolet	Corvette	Folding Top Control Module	●	●	●	●	●	○	
2015	Chevrolet	Corvette	Inside Rearview Mirror	●	●	●	●	●	○	
2015	Chevrolet	Corvette	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2015	Chevrolet	Corvette	Seat Memory Control Module - Passenger	●	●	●	●	●	○	
2015	Chevrolet	Corvette	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Corvette	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Chevrolet	Corvette	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Chevrolet	Corvette	Passenger Presence Module	●	●	●	●	●	●	S043
2015	Chevrolet	Corvette	Amplifier	●	●	●	●	○	○	
2015	Chevrolet	Corvette	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	Chevrolet	Corvette	Radio/HVAC Controls	●	●	●	●	●	○	
2015	Chevrolet	Corvette	Radio	●	●	●	●	●	●	S063 S064
2015	Chevrolet	Corvette	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Chevrolet	Corvette	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034 S036
2015	Chevrolet	Corvette	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Chevrolet	Corvette	Power Steering Control Module	●	●	●	●	○	●	S075
2015	Chevrolet	Corvette	Suspension Control Module	●	●	●	●	●	●	S038
2015	Chevrolet	Corvette	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	

2015	Chevrolet	Corvette	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Chevrolet	Cruze	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	Cruze	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2015	Chevrolet	Cruze	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141
2015	Chevrolet	Cruze	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Chevrolet	Cruze	Transmission Control Module	●	●	●	●	●	●	S023
2015	Chevrolet	Cruze	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Chevrolet	Cruze	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Chevrolet	Cruze	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Chevrolet	Cruze	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	Cruze	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	Chevrolet	Cruze	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Chevrolet	Cruze	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2015	Chevrolet	Cruze	Keyless Entry Control Module	●	●	●	●	●	○	

2015	Chevrolet	Cruze	Fuel Injector Control Module	○	○	●	●	●	○	
2015	Chevrolet	Cruze	Trailer Interface Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	Cruze	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2015	Chevrolet	Cruze	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	Cruze	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2015	Chevrolet	Cruze	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2015	Chevrolet	Cruze	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Cruze	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Chevrolet	Cruze	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2015	Chevrolet	Cruze	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Cruze	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	Chevrolet	Cruze	Radio	●	●	●	●	●	○	
2015	Chevrolet	Cruze	Multimedia Player Interface Module	●	●	●	●	○	●	
2015	Chevrolet	Enjoy	Electronic Brake Control Module	●	●	●	●	●	○	
2015	Chevrolet	Enjoy	Engine Control Module	●	●	●	●	●	●	S026 S044 S045 S025
2015	Chevrolet	Enjoy	Instrument Cluster	●	●	○	○	○	○	
2015	Chevrolet	Enjoy	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	

2015	Chevrolet	Equinox	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	Equinox	Liftgate Control Module	●	●	●	●	●	●	S049
2015	Chevrolet	Equinox	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2015	Chevrolet	Equinox	Transmission Control Module	●	●	●	●	●	●	S023
2015	Chevrolet	Equinox	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2015	Chevrolet	Equinox	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Equinox	Power Steering Control Module	●	●	●	●	○	●	
2015	Chevrolet	Equinox	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Equinox	Radio	●	●	●	●	●	○	
2015	Chevrolet	Equinox	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2015	Chevrolet	Equinox	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Chevrolet	Equinox	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Chevrolet	Equinox	Frontview Camera Module	●	●	●	●	○	●	S051
2015	Chevrolet	Equinox	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Chevrolet	Equinox	Parking Assist Control Module	●	●	●	●	●	●	S022

2015	Chevrolet	Equinox	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	Chevrolet	Equinox	Seat Memory Control Module	●	●	●	●	●	●	S031
2015	Chevrolet	Equinox	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Express	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2015	Chevrolet	Express	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2015	Chevrolet	Express	Engine Control Module	●	●	●	●	●	●	S112 S103 S119 S120 S121 S122 S029 S123 S124 S125 S126 S127 S128 S129 S130 S131 S132 S030 S133 S134 S135 S136 S137 S138 S139 S140 S141 S142 S143 S144 S145 S146 S147 S148 S149 S150 S151 S152 S153
2015	Chevrolet	Express	Auxiliary Heater Control Module	●	●	●	●	●	●	S025
2015	Chevrolet	Express	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141 S154
2015	Chevrolet	Express	Transmission Control Module	●	●	●	●	●	●	S048
2015	Chevrolet	Express	Electronic Brake Control Module	●	●	●	●	●	●	S036
2015	Chevrolet	Express	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	Express	Instrument Cluster	●	●	●	●	●	○	
2015	Chevrolet	Express	Rollover Sensor Module	●	●	●	●	○	●	

2015	Chevrolet	Express	Theft Deterrent Module	●	●	●	●	○	○	
2015	Chevrolet	Express	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	S024 S053
2015	Chevrolet	Express	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2015	Chevrolet	Express	Body Control Module	●	●	●	●	●	●	S001 S053
2015	Chevrolet	Express	Radio	●	●	●	●	●	●	
2015	Chevrolet	Express	Fuel Injector Control Module	●	●	●	●	●	○	
2015	Chevrolet	Lacetti	Engine Control Module	●	●	●	●	●	●	S026 S044 S045 S025
2015	Chevrolet	Lacetti	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	○	
2015	Chevrolet	Lacetti	Electronic Brake Control Module	●	●	●	●	●	○	
2015	Chevrolet	Lacetti	Transmission Control Module	●	●	●	●	●	●	S023
2015	Chevrolet	Lacetti	Fuel Injector Control Module	●	●	●	●	●	○	
2015	Chevrolet	Matiz	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	○	
2015	Chevrolet	Matiz	Electronic Brake Control Module	●	●	●	●	●	○	
2015	Chevrolet	Matiz	Engine Control Module	●	●	●	●	●	●	S095 S096 S155
2015	Chevrolet	Max	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	○	
2015	Chevrolet	Max	Electronic Brake Control Module	●	●	●	●	●	○	
2015	Chevrolet	Max	Engine Control Module	●	●	○	●	●	○	

2015	Chevrolet	Move	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	○	
2015	Chevrolet	Move	Electronic Brake Control Module	●	●	●	●	●	○	
2015	Chevrolet	Move	Engine Control Module	●	●	●	●	●	●	S095 S096 S155
2015	Chevrolet	Onix	Transmission Control Module	●	●	●	●	●	●	S023
2015	Chevrolet	Onix	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2015	Chevrolet	Onix	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2015	Chevrolet	Onix	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Chevrolet	Onix	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	Onix	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Onix	Radio	●	●	●	●	●	○	
2015	Chevrolet	Onix	Electronic Brake Control Module	●	●	●	●	●	●	S035
2015	Chevrolet	Onix	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Optra	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2015	Chevrolet	Optra	Body Control Module	●	●	●	●	●	○	
2015	Chevrolet	Optra	Transmission Control Module	●	●	●	●	●	●	S023
2015	Chevrolet	Optra	Instrument Cluster	●	●	●	●	●	○	

2015	Chevrolet	Optra	Electronic Brake Control Module	●	●	●	●	●	○	
2015	Chevrolet	Optra	Engine Control Module	●	●	●	●	●	●	S026 S044 S045 S025
2015	Chevrolet	Orlando	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	Orlando	Transmission Control Module	●	●	●	●	●	●	S023
2015	Chevrolet	Orlando	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2015	Chevrolet	Orlando	Fuel Injector Control Module	●	●	●	●	●	○	
2015	Chevrolet	Orlando	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Chevrolet	Orlando	Parking Assist Control Module	●	●	●	●	●	●	
2015	Chevrolet	Orlando	Rear Seat Heating Control Module	●	●	●	●	●	○	
2015	Chevrolet	Orlando	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Orlando	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2015	Chevrolet	Orlando	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Chevrolet	Orlando	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2015	Chevrolet	Orlando	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2015	Chevrolet	Orlando	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Orlando	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022

2015	Chevrolet	Orlando	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2015	Chevrolet	Orlando	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2015	Chevrolet	Orlando	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Chevrolet	Orlando	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Chevrolet	Orlando	Radio	●	●	●	●	●	○	
2015	Chevrolet	Prisma	Transmission Control Module	●	●	●	●	●	●	S023
2015	Chevrolet	Prisma	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2015	Chevrolet	Prisma	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2015	Chevrolet	Prisma	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Chevrolet	Prisma	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	Prisma	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Prisma	Radio	●	●	●	●	●	○	
2015	Chevrolet	Prisma	Electronic Brake Control Module	●	●	●	●	●	●	S035
2015	Chevrolet	Prisma	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	S10	Telematics Communication Interface Control Module	●	●	●	●	●	●	

2015	Chevrolet	S10	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2015	Chevrolet	S10	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S045 S029 S025 S030
2015	Chevrolet	S10	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	S10	Trailer Interface Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	S10	Electronic Brake Control Module	●	●	●	●	●	●	S035 S070
2015	Chevrolet	S10	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	S10	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2015	Chevrolet	S10	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	S10	Transfer Case Control Module	●	●	●	●	●	●	S080
2015	Chevrolet	S10	Transmission Control Module	●	●	●	●	●	●	S048
2015	Chevrolet	S10	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Chevrolet	S10	Radio	●	●	●	●	●	○	
2015	Chevrolet	Savana	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2015	Chevrolet	Savana	Digital Radio Receiver Control Module	●	●	●	●	●	○	

2015	Chevrolet	Savana	Transmission Control Module	●	●	●	●	●	●	S048
2015	Chevrolet	Savana	Electronic Brake Control Module	●	●	●	●	●	●	S036
2015	Chevrolet	Savana	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	Savana	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2015	Chevrolet	Savana	Instrument Cluster	●	●	●	●	●	○	
2015	Chevrolet	Savana	Rollover Sensor Module	●	●	●	●	○	●	
2015	Chevrolet	Savana	Theft Deterrent Module	●	●	●	●	○	○	
2015	Chevrolet	Savana	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	S024 S053
2015	Chevrolet	Savana	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2015	Chevrolet	Savana	Body Control Module	●	●	●	●	●	●	S001 S053
2015	Chevrolet	Savana	Auxiliary Heater Control Module	●	●	●	●	●	●	S025
2015	Chevrolet	Savana	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141 S154
2015	Chevrolet	Savana	Radio	●	●	●	●	●	●	
2015	Chevrolet	Silverado	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2015	Chevrolet	Silverado	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2015	Chevrolet	Silverado	Power Steering Control Module	●	●	●	●	●	●	S064
2015	Chevrolet	Silverado	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2015	Chevrolet	Silverado	Suspension Control Module	●	●	●	●	●	●	

2015	Chevrolet	Silverado	Transmission Control Module	●	●	●	●	●	●	S048
2015	Chevrolet	Silverado	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	Chevrolet	Silverado	Transfer Case Control Module	●	●	●	●	●	●	S080
2015	Chevrolet	Silverado	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Chevrolet	Silverado	Passenger Presence Module	●	●	●	●	●	●	S043
2015	Chevrolet	Silverado	Fuel Injector Control Module	●	●	●	●	●	○	
2015	Chevrolet	Silverado	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Chevrolet	Silverado	Frontview Camera Module	●	●	●	●	○	●	S051
2015	Chevrolet	Silverado	Parking Assist Control Module	●	●	●	●	●	●	S081
2015	Chevrolet	Silverado	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2015	Chevrolet	Silverado	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2015	Chevrolet	Silverado	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2015	Chevrolet	Silverado	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Chevrolet	Silverado	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Silverado	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141 S154

2015	Chevrolet	Silverado	Power Take-Off Control Module	●	●	●	●	●	●	S158 S159
2015	Chevrolet	Silverado	Radio	●	●	●	●	●	●	S063 S064
2015	Chevrolet	Silverado	Amplifier	●	●	●	●	○	○	
2015	Chevrolet	Silverado	Media Disc Player	●	●	●	●	●	○	
2015	Chevrolet	Silverado	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	Chevrolet	Silverado	Radio Controls	●	●	●	●	○	●	S065
2015	Chevrolet	Sonic	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	Sonic	Transmission Control Module	●	●	●	●	●	●	S023
2015	Chevrolet	Sonic	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2015	Chevrolet	Sonic	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036 S036
2015	Chevrolet	Sonic	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Chevrolet	Sonic	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Sonic	Radio	●	●	●	●	●	○	
2015	Chevrolet	Sonic	Electronic Brake Control Module	●	●	●	●	●	●	S035
2015	Chevrolet	Sonic	HVAC Control Module	●	●	●	●	●	○	
2015	Chevrolet	Sonic	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	Sonic	Power Steering Control Module	●	●	●	●	○	●	
2015	Chevrolet	Sonic	Fuel Injector Control Module	○	○	●	●	●	○	
2015	Chevrolet	Sonic	Front Seat Heating Control Module	●	●	●	●	●	○	

2015	Chevrolet	Sonic	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2015	Chevrolet	Sonic	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Sonic	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Chevrolet	Spark EV	Battery Charger Control Module	○	○	●	●	○	○	
2015	Chevrolet	Spark EV	Battery Energy Control Module	○	○	●	●	○	○	
2015	Chevrolet	Spark EV	Coolant Heater Control Module	●	●	●	○	○	○	
2015	Chevrolet	Spark EV	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2015	Chevrolet	Spark EV	DC Charging Control Module	○	○	●	●	○	○	
2015	Chevrolet	Spark EV	Passenger Presence Module	●	●	●	●	●	●	S043
2015	Chevrolet	Spark EV	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S084 S083 S160 S161 S087 S088 S089
2015	Chevrolet	Spark EV	Hybrid Powertrain Control Module	●	●	●	●	●	●	
2015	Chevrolet	Spark EV	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	
2015	Chevrolet	Spark EV	Drive Motor Control Module	●	●	●	●	○	○	
2015	Chevrolet	Spark EV	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039

2015	Chevrolet	Spark EV	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Chevrolet	Spark EV	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Chevrolet	Spark EV	Engine Control Module	●	●	●	●	●	●	S030
2015	Chevrolet	Spark EV	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Chevrolet	Spark EV	Electronic Brake Control Module	●	●	●	●	●	●	S092 S036 S036 S036
2015	Chevrolet	Spark EV	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Chevrolet	Spark EV	Instrument Cluster	●	●	●	●	●	●	S022 S022
2015	Chevrolet	Spark EV	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Chevrolet	Spark EV	Radio	●	●	●	●	●	○	
2015	Chevrolet	Spark EV	Pedestrian Alert Sound Control Module	●	●	●	●	●	○	
2015	Chevrolet	Spark EV	Power Steering Control Module	●	●	●	●	○	●	
2015	Chevrolet	Spin	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2015	Chevrolet	Spin	Transmission Control Module	●	●	●	●	●	●	S023
2015	Chevrolet	Spin	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2015	Chevrolet	Spin	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021

2015	Chevrolet	Spin	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Spin	HVAC Control Module	●	●	●	●	●	○	
2015	Chevrolet	Spin	Radio	●	●	●	●	●	○	
2015	Chevrolet	Spin	Electronic Brake Control Module	●	●	●	●	●	●	S035
2015	Chevrolet	Spin	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	Spin	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Spin	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	Spin	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Chevrolet	SS	Transmission Control Module	●	●	●	●	●	●	S048
2015	Chevrolet	SS	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	SS	Headlamp Control Module	●	●	●	●	●	●	S002
2015	Chevrolet	SS	Suspension Control Module	●	●	●	●	●	●	S076 S077 S038
2015	Chevrolet	SS	Trailer Interface Control Module	●	●	●	●	●	●	
2015	Chevrolet	SS	Fuel Injector Control Module	○	○	●	●	●	○	
2015	Chevrolet	SS	Head-Up Display Module	●	●	●	●	●	○	
2015	Chevrolet	SS	Instrument Cluster	●	●	●	●	●	●	S022 S097
2015	Chevrolet	SS	Keyless Entry Control Module	●	●	●	●	●	○	

2015	Chevrolet	SS	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Chevrolet	SS	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Chevrolet	SS	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2015	Chevrolet	SS	Power Steering Control Module	●	●	●	●	○	●	
2015	Chevrolet	SS	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	SS	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2015	Chevrolet	SS	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	SS	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Chevrolet	SS	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Chevrolet	SS	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Chevrolet	SS	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	Chevrolet	SS	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2015	Chevrolet	SS	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2015	Chevrolet	SS	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	Chevrolet	SS	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021

2015	Chevrolet	SS	Radio Controls	●	●	●	●	●	●	S022
2015	Chevrolet	SS	HVAC Controls	●	●	●	●	●	●	
2015	Chevrolet	SS	Radio	●	●	●	●	●	○	
2015	Chevrolet	Suburban	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2015	Chevrolet	Suburban	Passenger Presence Module	●	●	●	●	●	●	S043
2015	Chevrolet	Suburban	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Suburban	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	Chevrolet	Suburban	Transmission Control Module	●	●	●	●	●	●	S048
2015	Chevrolet	Suburban	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Suburban	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Chevrolet	Suburban	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Chevrolet	Suburban	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2015	Chevrolet	Suburban	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2015	Chevrolet	Suburban	Power Steering Control Module	●	●	●	●	●	●	S064
2015	Chevrolet	Suburban	Suspension Control Module	●	●	●	●	●	●	
2015	Chevrolet	Suburban	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2015	Chevrolet	Suburban	Transfer Case Control Module	●	●	●	●	●	●	S080

2015	Chevrolet	Suburban	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Chevrolet	Suburban	Liftgate Control Module	●	●	●	●	●	●	
2015	Chevrolet	Suburban	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Chevrolet	Suburban	Frontview Camera Module	●	●	●	●	○	●	S051
2015	Chevrolet	Suburban	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Chevrolet	Suburban	Parking Assist Control Module	●	●	●	●	●	●	S081
2015	Chevrolet	Suburban	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2015	Chevrolet	Suburban	Amplifier	●	●	●	●	○	○	
2015	Chevrolet	Suburban	Radio Controls	●	●	●	●	○	●	S065
2015	Chevrolet	Suburban	HVAC Controls	●	●	●	●	●	●	S065
2015	Chevrolet	Suburban	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	Chevrolet	Suburban	Media Disc Player	●	●	●	●	●	○	
2015	Chevrolet	Suburban	Radio	●	●	●	●	●	●	S063 S064
2015	Chevrolet	Suburban	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Chevrolet	Suburban	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2015	Chevrolet	Suburban	Assist Step Control Module	●	●	●	●	●	●	
2015	Chevrolet	Suburban	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Chevrolet	Tahoe	Hybrid Powertrain Control Module	●	●	●	●	●	○	

2015	Chevrolet	Tahoe	Transfer Case Control Module	●	●	●	●	●	●	S080
2015	Chevrolet	Tahoe	Drive Motor Control Module 1	○	○	●	●	○	○	
2015	Chevrolet	Tahoe	Drive Motor Control Module 2	○	○	●	●	○	○	
2015	Chevrolet	Tahoe	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	
2015	Chevrolet	Tahoe	Battery Energy Control Module	○	○	●	●	○	○	
2015	Chevrolet	Tahoe	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	Tahoe	Passenger Presence Module	●	●	●	●	●	●	S043
2015	Chevrolet	Tahoe	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Chevrolet	Tahoe	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	Chevrolet	Tahoe	Transmission Control Module	●	●	●	●	●	●	S048
2015	Chevrolet	Tahoe	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Tahoe	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Chevrolet	Tahoe	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2015	Chevrolet	Tahoe	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2015	Chevrolet	Tahoe	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Tahoe	Power Steering Control Module	●	●	●	●	●	●	S064

2015	Chevrolet	Tahoe	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2015	Chevrolet	Tahoe	Suspension Control Module	●	●	●	●	●	●	
2015	Chevrolet	Tahoe	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Chevrolet	Tahoe	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Chevrolet	Tahoe	Amplifier	●	●	●	●	○	○	
2015	Chevrolet	Tahoe	Radio Controls	●	●	●	●	○	●	S065
2015	Chevrolet	Tahoe	HVAC Controls	●	●	●	●	●	●	S065
2015	Chevrolet	Tahoe	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	Chevrolet	Tahoe	Media Disc Player	●	●	●	●	●	○	
2015	Chevrolet	Tahoe	Radio	●	●	●	●	●	●	S063 S064
2015	Chevrolet	Tahoe	Frontview Camera Module	●	●	●	●	○	●	S051
2015	Chevrolet	Tahoe	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Chevrolet	Tahoe	Parking Assist Control Module	●	●	●	●	●	●	S081
2015	Chevrolet	Tahoe	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2015	Chevrolet	Tahoe	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Chevrolet	Tahoe	Liftgate Control Module	●	●	●	●	●	●	
2015	Chevrolet	Tahoe	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2015	Chevrolet	Tahoe	Assist Step Control Module	●	●	●	●	●	●	

2015	Chevrolet	Tahoe	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Chevrolet	Tavera	Engine Control Module	●	●	●	●	●	○	
2015	Chevrolet	Tracker	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	Tracker	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Chevrolet	Tracker	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Tracker	Transmission Control Module	●	●	●	●	●	●	S023
2015	Chevrolet	Tracker	Electronic Brake Control Module	●	●	●	●	●	●	S035
2015	Chevrolet	Tracker	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2015	Chevrolet	Tracker	Rear Differential Clutch Control Module	●	●	●	●	●	●	
2015	Chevrolet	Tracker	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Tracker	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2015	Chevrolet	Tracker	Power Steering Control Module	●	●	●	●	○	●	
2015	Chevrolet	Tracker	Parking Assist Control Module	●	●	●	●	●	●	
2015	Chevrolet	Tracker	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Chevrolet	Tracker	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021

2015	Chevrolet	Traverse	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2015	Chevrolet	Traverse	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2015	Chevrolet	Traverse	Liftgate Control Module	●	●	●	●	○	●	S049
2015	Chevrolet	Traverse	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S029 S025 S030
2015	Chevrolet	Traverse	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2015	Chevrolet	Traverse	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034 S036
2015	Chevrolet	Traverse	Transmission Control Module	●	●	●	●	●	●	S048
2015	Chevrolet	Traverse	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2015	Chevrolet	Traverse	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Chevrolet	Traverse	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2015	Chevrolet	Traverse	Body Control Module	●	●	●	●	●	●	S001 S053
2015	Chevrolet	Traverse	Theft Deterrent Module	●	●	●	●	○	○	
2015	Chevrolet	Traverse	Instrument Cluster	●	●	●	●	●	○	
2015	Chevrolet	Traverse	Front Seat Heating Control Module	●	●	●	●	○	○	
2015	Chevrolet	Traverse	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2015	Chevrolet	Traverse	Left Side Object Detection Control Module	●	●	●	○	●	○	

2015	Chevrolet	Traverse	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	Traverse	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	Chevrolet	Traverse	Seat Memory Control Module	●	●	●	●	●	○	
2015	Chevrolet	Traverse	Radio	●	●	●	●	●	●	
2015	Chevrolet	Traverse	HVAC Control Module	●	●	●	●	●	●	S052 S032 S033
2015	Chevrolet	Traverse	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2015	Chevrolet	Traverse	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2015	Chevrolet	Traverse	Rear Audio Control Module	●	●	●	●	●	○	
2015	Chevrolet	Trax	Telematics Communication Interface Control Module	●	●	●	●	●	●	
2015	Chevrolet	Trax	Transmission Control Module	●	●	●	●	●	●	S023
2015	Chevrolet	Trax	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2015	Chevrolet	Trax	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Chevrolet	Trax	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Chevrolet	Trax	Instrument Cluster	●	●	●	●	●	●	S022
2015	Chevrolet	Trax	HVAC Control Module	●	●	●	●	●	○	
2015	Chevrolet	Trax	Electronic Brake Control Module	●	●	●	●	●	●	S035
2015	Chevrolet	Trax	Front Seat Heating Control Module	●	●	●	●	●	○	

2015	Chevrolet	Trax	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2015	Chevrolet	Trax	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Chevrolet	Trax	Parking Assist Control Module	●	●	●	●	●	●	
2015	Chevrolet	Trax	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	Chevrolet	Trax	Seat Memory Control Module	●	●	●	●	●	●	S031
2015	Chevrolet	Trax	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Chevrolet	Trax	Fuel Injector Control Module	○	○	●	●	●	○	
2015	Chevrolet	Trax	Rear Differential Clutch Control Module	●	●	●	●	●	●	
2015	Chevrolet	Trax	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Trax	Power Steering Control Module	●	●	●	●	○	●	
2015	Chevrolet	Trax	Radio	●	●	●	●	●	○	
2015	Chevrolet	Trax	Chassis Control Module	●	●	●	●	●	●	S025
2015	Chevrolet	Volt	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2015	Chevrolet	Volt	Battery Energy Control Module	○	○	●	●	○	○	
2015	Chevrolet	Volt	Coolant Heater Control Module	●	●	●	●	○	○	

2015	Chevrolet	Volt	Battery Charger Control Module	○	○	●	●	○	○	
2015	Chevrolet	Volt	Hybrid Powertrain Control Module	●	●	●	●	●	○	
2015	Chevrolet	Volt	Drive Motor Control Module 1	●	●	●	●	○	○	
2015	Chevrolet	Volt	Drive Motor Control Module 2	●	●	●	●	○	○	
2015	Chevrolet	Volt	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	
2015	Chevrolet	Volt	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S083 S084 S085 S086 S087 S088 S089
2015	Chevrolet	Volt	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	Chevrolet	Volt	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Chevrolet	Volt	Chassis Control Module	●	●	●	●	●	●	S025
2015	Chevrolet	Volt	Instrument Cluster	●	●	●	●	●	●	S022 S022
2015	Chevrolet	Volt	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Chevrolet	Volt	Parking Assist Control Module	●	●	●	●	●	●	
2015	Chevrolet	Volt	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S091
2015	Chevrolet	Volt	Transmission Control Module	●	●	●	●	●	○	
2015	Chevrolet	Volt	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Chevrolet	Volt	Electronic Brake Control Module	●	●	●	●	●	●	S092 S036 S036 S036
2015	Chevrolet	Volt	Parking Brake Control Module	●	●	●	●	●	●	S037

2015	Chevrolet	Volt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2015	Chevrolet	Volt	Passenger Presence Module	●	●	●	●	○	●	S043
2015	Chevrolet	Volt	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Chevrolet	Volt	Radio	●	●	●	●	●	○	
2015	Chevrolet	Volt	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022
2015	Chevrolet	Volt	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Chevrolet	Volt	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2015	Chevrolet	Volt	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Chevrolet	Volt	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2015	Chevrolet	Work	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	○	
2015	Chevrolet	Work	Electronic Brake Control Module	●	●	●	●	●	○	
2015	Chevrolet	Work	Engine Control Module	●	●	●	●	●	●	S095 S096 S155
2015	Daewoo	Alpheon	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2015	Daewoo	Alpheon	Drive Motor Control Module	●	●	●	●	○	○	
2015	Daewoo	Alpheon	Battery Energy Control Module	○	○	●	●	○	○	

2015	Daewoo	Alpheon	Transmission Control Module	●	●	●	●	●	●	S023
2015	Daewoo	Alpheon	Headlamp Control Module	●	●	●	●	●	●	S002
2015	Daewoo	Alpheon	Mobile Telephone Control Module	●	●	●	●	●	●	
2015	Daewoo	Alpheon	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Daewoo	Alpheon	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Daewoo	Alpheon	Rear Seat Heating Control Module	●	●	●	●	●	○	
2015	Daewoo	Alpheon	Seat Memory Control Module	●	●	●	●	●	●	S031
2015	Daewoo	Alpheon	Instrument Cluster	●	●	●	●	●	●	S022
2015	Daewoo	Alpheon	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Daewoo	Alpheon	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2015	Daewoo	Alpheon	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Daewoo	Alpheon	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S046
2015	Daewoo	Alpheon	Chassis Control Module	●	●	●	●	●	●	S025
2015	Daewoo	Alpheon	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2015	Daewoo	Alpheon	Parking Brake Control Module	●	●	●	●	●	●	S037

2015	GMC	Acadia	Front Seat Heating Control Module	●	●	●	●	○	○	
2015	GMC	Acadia	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2015	GMC	Acadia	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	GMC	Acadia	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	GMC	Acadia	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	GMC	Acadia	Seat Memory Control Module	●	●	●	●	●	○	
2015	GMC	Acadia	Transmission Control Module	●	●	●	●	●	●	S048
2015	GMC	Acadia	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2015	GMC	Acadia	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2015	GMC	Acadia	Passenger Presence Module	●	●	●	●	○	●	S043
2015	GMC	Acadia	Radio	●	●	●	●	●	●	
2015	GMC	Acadia	Rear Audio Control Module	●	●	●	●	●	○	
2015	GMC	Acadia	Personal Audio Link Control Module	●	●	●	○	○	●	S056
2015	GMC	Acadia	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2015	GMC	Acadia	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2015	GMC	Acadia	HVAC Control Module	●	●	●	●	●	●	S052 S032 S033
2015	GMC	Acadia	Instrument Cluster	●	●	●	●	●	○	

2015	GMC	Acadia	Head-Up Display Module	●	●	●	●	●	○	
2015	GMC	Acadia	Theft Deterrent Module	●	●	●	●	○	○	
2015	GMC	Acadia	Body Control Module	●	●	●	●	●	●	S001 S053
2015	GMC	Canyon	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	GMC	Canyon	Passenger Presence Module	●	●	●	●	●	●	S043
2015	GMC	Canyon	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	GMC	Canyon	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2015	GMC	Canyon	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S094 S046
2015	GMC	Canyon	Power Steering Control Module	●	●	●	●	●	●	S093 S035
2015	GMC	Canyon	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	GMC	Canyon	Electronic Brake Control Module	●	●	●	●	●	●	S036
2015	GMC	Canyon	Instrument Cluster	●	●	●	●	●	●	
2015	GMC	Canyon	Transmission Control Module	●	●	●	●	●	●	S048
2015	GMC	Canyon	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	GMC	Canyon	Transfer Case Control Module	●	●	●	●	●	●	S080
2015	GMC	Canyon	HVAC Control Module	●	●	●	●	●	●	S033
2015	GMC	Canyon	Frontview Camera Module	●	●	●	●	●	●	S050 S051

2015	GMC	Canyon	Amplifier	●	●	●	●	○	○	
2015	GMC	Canyon	Radio	●	●	●	●	●	●	S063 S064
2015	GMC	Canyon	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	GMC	Savana	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2015	GMC	Savana	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2015	GMC	Savana	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141 S154
2015	GMC	Savana	Auxiliary Heater Control Module	●	●	●	●	●	●	S025
2015	GMC	Savana	Engine Control Module	●	●	●	●	●	●	S112 S103 S119 S120 S121 S122 S029 S123 S124 S125 S126 S127 S128 S129 S130 S131 S132 S030 S133 S134 S135 S136 S137 S138 S139 S140 S141 S142 S143 S144 S145 S146 S147 S148 S149 S150 S151 S152 S153
2015	GMC	Savana	Transmission Control Module	●	●	●	●	●	●	S048
2015	GMC	Savana	Electronic Brake Control Module	●	●	●	●	●	●	S036
2015	GMC	Savana	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	GMC	Savana	Instrument Cluster	●	●	●	●	●	○	
2015	GMC	Savana	Rollover Sensor Module	●	●	●	●	○	●	
2015	GMC	Savana	Theft Deterrent Module	●	●	●	●	○	○	

2015	GMC	Savana	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	S024 S053
2015	GMC	Savana	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2015	GMC	Savana	Body Control Module	●	●	●	●	●	●	S001 S053
2015	GMC	Savana	Radio	●	●	●	●	●	●	
2015	GMC	Sierra	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	GMC	Sierra	Transfer Case Control Module	●	●	●	●	●	●	S080
2015	GMC	Sierra	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2015	GMC	Sierra	Instrument Cluster	●	●	●	●	●	●	S022
2015	GMC	Sierra	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2015	GMC	Sierra	Transmission Control Module	●	●	●	●	●	●	S048
2015	GMC	Sierra	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2015	GMC	Sierra	Power Steering Control Module	●	●	●	●	●	●	S064
2015	GMC	Sierra	Suspension Control Module	●	●	●	●	●	●	
2015	GMC	Sierra	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2015	GMC	Sierra	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	GMC	Sierra	Passenger Presence Module	●	●	●	●	●	●	S043

2015	GMC	Terrain	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2015	GMC	Terrain	Instrument Cluster	●	●	●	●	●	●	S022
2015	GMC	Terrain	Transmission Control Module	●	●	●	●	●	●	S048
2015	GMC	Terrain	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2015	GMC	Terrain	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2015	GMC	Terrain	Power Steering Control Module	●	●	●	●	○	●	
2015	GMC	Terrain	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	GMC	Terrain	Radio	●	●	●	●	●	○	
2015	GMC	Terrain	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2015	GMC	Terrain	Passenger Presence Module	●	●	●	●	○	●	S043
2015	GMC	Terrain	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	GMC	Terrain	Frontview Camera Module	●	●	●	●	○	●	S051
2015	GMC	Terrain	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	GMC	Terrain	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	GMC	Terrain	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	GMC	Terrain	Seat Memory Control Module	●	●	●	●	●	●	S031

2015	GMC	Terrain	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S046
2015	GMC	Terrain	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	GMC	Terrain	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	GMC	Yukon	Hybrid Powertrain Control Module	●	●	●	●	●	○	
2015	GMC	Yukon	Transfer Case Control Module	●	●	●	●	●	●	S080
2015	GMC	Yukon	Drive Motor Control Module 1	○	○	●	●	○	○	
2015	GMC	Yukon	Drive Motor Control Module 2	○	○	●	●	○	○	
2015	GMC	Yukon	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	
2015	GMC	Yukon	Battery Energy Control Module	○	○	●	●	○	○	
2015	GMC	Yukon	Transmission Control Module	●	●	●	●	●	●	S048
2015	GMC	Yukon	Telematics Communication Interface Control Module	●	●	●	●	●	●	S039 S040 S041 S042
2015	GMC	Yukon	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	GMC	Yukon	Instrument Cluster	●	●	●	●	●	●	S022
2015	GMC	Yukon	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	GMC	Yukon	Passenger Presence Module	●	●	●	●	●	●	S043
2015	GMC	Yukon	Keyless Entry Control Module	●	●	●	●	●	○	

2015	GMC	Yukon	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2015	GMC	Yukon	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2015	GMC	Yukon	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2015	GMC	Yukon	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2015	GMC	Yukon	Power Steering Control Module	●	●	●	●	●	●	S064
2015	GMC	Yukon	Suspension Control Module	●	●	●	●	●	●	
2015	GMC	Yukon	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	GMC	Yukon	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	GMC	Yukon	Amplifier	●	●	●	●	○	○	
2015	GMC	Yukon	Radio Controls	●	●	●	●	○	●	S065
2015	GMC	Yukon	HVAC Controls	●	●	●	●	●	●	S065
2015	GMC	Yukon	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	GMC	Yukon	Media Disc Player	●	●	●	●	●	○	
2015	GMC	Yukon	Radio	●	●	●	●	●	●	S063 S064
2015	GMC	Yukon	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	GMC	Yukon	Frontview Camera Module	●	●	●	●	○	●	S051
2015	GMC	Yukon	Left Side Object Detection Control Module	●	●	●	○	●	○	

2015	GMC	Yukon	Parking Assist Control Module	●	●	●	●	●	●	S081
2015	GMC	Yukon	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2015	GMC	Yukon	Liftgate Control Module	●	●	●	●	●	●	
2015	GMC	Yukon	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2015	GMC	Yukon	Assist Step Control Module	●	●	●	●	●	●	
2015	GMC	Yukon	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	GMC	Yukon XL	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	GMC	Yukon XL	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2015	GMC	Yukon XL	Transmission Control Module	●	●	●	●	●	●	S048
2015	GMC	Yukon XL	Instrument Cluster	●	●	●	●	●	●	S022
2015	GMC	Yukon XL	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	GMC	Yukon XL	Passenger Presence Module	●	●	●	●	●	●	S043
2015	GMC	Yukon XL	Keyless Entry Control Module	●	●	●	●	●	○	
2015	GMC	Yukon XL	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2015	GMC	Yukon XL	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2015	GMC	Yukon XL	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	

2015	GMC	Yukon XL	Power Steering Control Module	●	●	●	●	●	●	S064
2015	GMC	Yukon XL	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2015	GMC	Yukon XL	Suspension Control Module	●	●	●	●	●	●	
2015	GMC	Yukon XL	Transfer Case Control Module	●	●	●	●	●	●	S080
2015	GMC	Yukon XL	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	GMC	Yukon XL	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	GMC	Yukon XL	Amplifier	●	●	●	●	○	○	
2015	GMC	Yukon XL	Radio Controls	●	●	●	●	○	●	S065
2015	GMC	Yukon XL	HVAC Controls	●	●	●	●	●	●	S065
2015	GMC	Yukon XL	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	GMC	Yukon XL	Media Disc Player	●	●	●	●	●	○	
2015	GMC	Yukon XL	Radio	●	●	●	●	●	●	S063 S064
2015	GMC	Yukon XL	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	GMC	Yukon XL	Frontview Camera Module	●	●	●	●	○	●	S051
2015	GMC	Yukon XL	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	GMC	Yukon XL	Parking Assist Control Module	●	●	●	●	●	●	S081
2015	GMC	Yukon XL	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2015	GMC	Yukon XL	Liftgate Control Module	●	●	●	●	●	●	

2015	GMC	Yukon XL	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2015	GMC	Yukon XL	Assist Step Control Module	●	●	●	●	●	●	
2015	GMC	Yukon XL	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Holden	Astra-J	Instrument Cluster	●	●	●	●	●	●	
2015	Holden	Astra-J	Trailer Interface Control Module	●	●	●	●	●	●	
2015	Holden	Astra-J	Electronic Brake Control Module	●	●	●	●	●	●	
2015	Holden	Astra-J	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Holden	Astra-J	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2015	Holden	Astra-J	Body Control Module	●	●	●	●	●	●	S001 S014 S016 S015 S017 S018 S019 S021 S021
2015	Holden	Astra-J	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2015	Holden	Astra-J	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Holden	Astra-J	Frontview Camera Module	●	●	●	●	●	●	
2015	Holden	Astra-J	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2015	Holden	Astra-J	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Holden	Astra-J	Parking Assist Control Module	●	●	●	●	●	●	
2015	Holden	Astra-J	Radio	●	●	●	●	●	○	
2015	Holden	Astra-J	Suspension Control Module	●	●	●	●	●	○	

2015	Holden	Astra-J	HVAC Control Module	●	●	●	●	●	●	
2015	Holden	Astra-J	Transmission Control Module	●	●	●	●	●	●	S166
2015	Holden	Astra-J	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2015	Holden	Astra-J	Headlamp Control Module	●	●	●	●	●	●	
2015	Holden	Astra-J	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S108 S029 S025 S030
2015	Holden	Astra-J	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022
2015	Holden	Barina	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067 S038
2015	Holden	Barina	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2015	Holden	Barina	Transmission Control Module	●	●	●	●	●	●	S023
2015	Holden	Barina	Instrument Cluster	●	●	●	●	●	●	S022
2015	Holden	Barina	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036 S036
2015	Holden	Barina	Radio	●	●	●	●	●	○	
2015	Holden	Barina	Electronic Brake Control Module	●	●	●	●	●	●	S035
2015	Holden	Barina	HVAC Control Module	●	●	●	●	●	○	
2015	Holden	Barina	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Holden	Barina	Power Steering Control Module	●	●	●	●	○	●	
2015	Holden	Barina Spark	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2015	Holden	Barina Spark		●	●	●	●	●	●	S024
2015	Holden	Barina Spark	Radio	●	●	●	●	●	○	
2015	Holden	Barina Spark	Instrument Cluster	●	●	●	●	●	○	

2015	Holden	Barina Spark	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2015	Holden	Barina Spark	Electronic Brake Control Module	●	●	●	●	●	●	S035
2015	Holden	Barina Spark	Power Steering Control Module	●	●	●	●	○	●	
2015	Holden	Barina Spark	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Holden	Barina Spark	Transmission Control Module	●	●	●	●	●	●	S048
2015	Holden	Caprice	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Holden	Caprice	Transmission Control Module	●	●	●	●	●	●	S048
2015	Holden	Caprice	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2015	Holden	Caprice	Head-Up Display Module	●	●	●	●	●	○	
2015	Holden	Caprice	Instrument Cluster	●	●	●	●	●	●	S022 S097
2015	Holden	Caprice	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Holden	Caprice	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	Holden	Caprice	Seat Memory Control Module - Driver	●	●	●	●	●	○	
2015	Holden	Caprice	Headlamp Control Module	●	●	●	●	●	●	S002
2015	Holden	Caprice	Suspension Control Module	●	●	●	●	●	●	S076 S077 S038
2015	Holden	Caprice	Trailer Interface Control Module	●	●	●	●	●	●	

2015	Holden	Caprice	Fuel Injector Control Module	○	○	●	●	●	○	
2015	Holden	Caprice	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Holden	Caprice	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Holden	Caprice	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2015	Holden	Caprice	Power Steering Control Module	●	●	●	●	○	●	
2015	Holden	Caprice	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Holden	Caprice	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Holden	Caprice	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Holden	Caprice	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2015	Holden	Caprice	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Holden	Caprice	HVAC Control Module	●	●	●	●	●	●	S033
2015	Holden	Caprice	Chassis Control Module	●	●	●	●	●	●	S025
2015	Holden	Caprice	Radio Controls	●	●	●	●	●	●	S022
2015	Holden	Caprice	HVAC Controls	●	●	●	●	●	●	
2015	Holden	Caprice	Radio	●	●	●	●	●	○	
2015	Holden	Captiva 5	Transmission Control Module	●	●	●	●	●	●	S023
2015	Holden	Captiva 5	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S044 S029 S025 S058

2015	Holden	Captiva 5	Mobile Telephone Control Module	●	●	●	○	●	●	
2015	Holden	Captiva 5	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2015	Holden	Captiva 5	HVAC Control Module	●	●	●	○	●	○	
2015	Holden	Captiva 5	Headlamp Control Module	●	●	●	●	●	●	S002 S179
2015	Holden	Captiva 5	Electronic Brake Control Module	●	●	●	●	●	●	S035
2015	Holden	Captiva 5	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S053
2015	Holden	Captiva 5	Info Display Module	●	●	●	●	●	●	S187 S187 S187 S187 S188 S189 S022 S022 S190 S190 S190 S190 S179 S179 S179
2015	Holden	Captiva 5	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Holden	Captiva 5	Parking Assist Control Module	●	●	●	●	●	●	
2015	Holden	Captiva 5	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2015	Holden	Captiva 5	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2015	Holden	Captiva 5	Theft Deterrent Module	●	●	●	●	○	○	
2015	Holden	Captiva 5	Body Control Module	●	●	●	●	●	●	S013 S001
2015	Holden	Captiva 5	Instrument Cluster	●	●	●	●	●	○	
2015	Holden	Captiva 5	Radio	●	●	●	●	●	●	S187 S187 S187 S187 S179 S179 S179 S179 S191 S191
2015	Holden	Captiva 7	Mobile Telephone Control Module	●	●	●	●	●	●	S022
2015	Holden	Captiva 7	Transmission Control Module	●	●	●	●	●	●	S023

2015	Holden	Captiva 7	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S044 S029 S025 S058
2015	Holden	Captiva 7	HVAC Control Module	●	●	●	○	●	○	
2015	Holden	Captiva 7	Electronic Brake Control Module	●	●	●	●	●	●	S035 S036
2015	Holden	Captiva 7	Instrument Cluster	●	●	●	●	●	○	
2015	Holden	Captiva 7	Theft Deterrent Module	●	●	●	●	○	○	
2015	Holden	Captiva 7	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2015	Holden	Captiva 7	Headlamp Control Module	●	●	●	●	●	●	S002 S179
2015	Holden	Captiva 7	Body Control Module	●	●	●	●	●	●	S013 S001 S053
2015	Holden	Captiva 7	Remote Control Door Lock Receiver	●	●	●	●	●	●	S192 S019 S021 S020
2015	Holden	Captiva 7	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2015	Holden	Captiva 7	Chassis Control Module	●	●	●	●	●	●	S025
2015	Holden	Captiva 7	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Holden	Captiva 7	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2015	Holden	Cascade	Instrument Cluster	●	●	●	●	●	●	
2015	Holden	Cascade	Body Control Module	●	●	●	●	●	●	S001 S014 S016 S015 S017 S018 S019 S021 S021
2015	Holden	Cascade	Folding Top Control Module	●	●	●	●	●	●	
2015	Holden	Cascade	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2015	Holden	Cascade	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Holden	Cascade	Frontview Camera Module	●	●	●	●	●	●	

2015	Holden	Cascada	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036
2015	Holden	Cascada	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Holden	Cascada	Parking Assist Control Module	●	●	●	●	●	●	
2015	Holden	Cascada	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Holden	Cascada	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2015	Holden	Cascada	Electronic Brake Control Module	●	●	●	●	●	●	
2015	Holden	Cascada	Radio	●	●	●	●	●	○	
2015	Holden	Cascada	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S108 S027 S028 S045 S162 S119 S029 S180 S025 S094
2015	Holden	Cascada	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2015	Holden	Cascada	Transmission Control Module	●	●	●	●	●	●	S166
2015	Holden	Cascada	Headlamp Control Module	●	●	●	●	●	●	
2015	Holden	Cascada	HVAC Control Module	●	●	●	●	●	●	
2015	Holden	Colorado	Transmission Control Module	●	●	●	●	●	●	S048
2015	Holden	Colorado	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Holden	Colorado	Instrument Cluster	●	●	●	●	●	●	S022
2015	Holden	Colorado	Trailer Interface Control Module	●	●	●	●	●	●	S022
2015	Holden	Colorado	Engine Control Module	●	●	●	●	●	●	S001 S103 S169 S109 S181 S182 S122 S113 S029 S183 S184 S082 S115 S118

2015	Holden	Colorado	Electronic Brake Control Module	●	●	●	●	●	●	S035 S070
2015	Holden	Colorado	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2015	Holden	Colorado	Transfer Case Control Module	●	●	●	●	●	●	S080
2015	Holden	Colorado	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2015	Holden	Colorado	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Holden	Colorado	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Holden	Colorado 7	Transmission Control Module	●	●	●	●	●	●	S048
2015	Holden	Colorado 7	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Holden	Colorado 7	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2015	Holden	Colorado 7	Instrument Cluster	●	●	●	●	●	●	S022
2015	Holden	Colorado 7	Trailer Interface Control Module	●	●	●	●	●	●	S022
2015	Holden	Colorado 7	Engine Control Module	●	●	●	●	●	●	S001 S103 S169 S109 S181 S182 S122 S113 S029 S183 S184 S082 S115 S118
2015	Holden	Colorado 7	Electronic Brake Control Module	●	●	●	●	●	●	S035 S070

2015	Holden	Colorado 7	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2015	Holden	Colorado 7	Transfer Case Control Module	●	●	●	●	●	●	S080
2015	Holden	Colorado 7	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Holden	Colorado 7	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2015	Holden	Colorado 7	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Holden	Commodore	Liftgate Control Module	●	●	●	●	○	○	
2015	Holden	Commodore	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Holden	Commodore	Transmission Control Module	●	●	●	●	●	●	S048
2015	Holden	Commodore	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2015	Holden	Commodore	Head-Up Display Module	●	●	●	●	●	○	
2015	Holden	Commodore	Instrument Cluster	●	●	●	●	●	●	S022 S097
2015	Holden	Commodore	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Holden	Commodore	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	Holden	Commodore	Seat Memory Control Module - Driver	●	●	●	●	●	○	
2015	Holden	Commodore	Headlamp Control Module	●	●	●	●	●	●	S002

2015	Holden	Commodore	Suspension Control Module	●	●	●	●	●	●	S076 S077 S038
2015	Holden	Commodore	Trailer Interface Control Module	●	●	●	●	●	●	
2015	Holden	Commodore	Fuel Injector Control Module	○	○	●	●	●	○	
2015	Holden	Commodore	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Holden	Commodore	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Holden	Commodore	Power Steering Control Module	●	●	●	●	○	●	
2015	Holden	Commodore	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2015	Holden	Commodore	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Holden	Commodore	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Holden	Commodore	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2015	Holden	Commodore	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Holden	Commodore	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Holden	Commodore	HVAC Control Module	●	●	●	●	●	●	S033
2015	Holden	Commodore	Chassis Control Module	●	●	●	●	●	●	S025
2015	Holden	Commodore	Radio Controls	●	●	●	●	●	●	S022
2015	Holden	Commodore	HVAC Controls	●	●	●	●	●	●	
2015	Holden	Commodore	Radio	●	●	●	●	●	○	

2015	Holden	Cruze	Transmission Control Module	●	●	●	●	●	●	S023
2015	Holden	Cruze	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Holden	Cruze	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2015	Holden	Cruze	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Holden	Cruze	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Holden	Cruze	Parking Assist Control Module	●	●	●	●	●	●	S022
2015	Holden	Cruze	Right Side Object Detection Control Module	●	●	●	○	●	○	
2015	Holden	Cruze	Instrument Cluster	●	●	●	●	●	●	S022
2015	Holden	Cruze	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2015	Holden	Cruze	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2015	Holden	Cruze	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2015	Holden	Cruze	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Holden	Cruze	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Holden	Cruze	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2015	Holden	Cruze	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2015	Holden	Cruze	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	

2015	Holden	Insignia	Front Seat Heating/Venting/Cooling/Memory Control Module	●	●	●	●	●	●	
2015	Holden	Insignia	Parking Assist Control Module	●	●	●	●	●	●	
2015	Holden	Insignia	Engine Control Module	●	●	●	●	●	●	S044 S028 S029 S025
2015	Holden	Insignia	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2015	Holden	Insignia	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Holden	Insignia	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2015	Holden	Insignia	Suspension Control Module	●	●	●	●	●	○	
2015	Holden	Insignia	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2015	Holden	Insignia	HVAC Controls	●	●	●	●	●	●	
2015	Holden	Insignia	Radio Controls	●	●	●	●	●	●	S064
2015	Holden	Insignia	Transmission Control Module	●	●	●	●	●	●	
2015	Holden	Insignia	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2015	Holden	Insignia	HVAC Control Module	●	●	●	●	●	●	S033
2015	Holden	Insignia	Headlamp Control Module	●	●	●	●	●	●	
2015	Holden	Malibu	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Holden	Malibu	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Holden	Malibu	Transmission Control Module	●	●	●	●	●	●	S023

2015	Holden	Malibu	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2015	Holden	Malibu	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Holden	Malibu	Headlamp Control Module	●	●	●	●	●	●	S002
2015	Holden	Malibu	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2015	Holden	Malibu	Instrument Cluster	●	●	●	●	●	●	S022
2015	Holden	Malibu	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036 S036
2015	Holden	Malibu	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Holden	Malibu	Parking Assist Control Module	●	●	●	●	●	●	
2015	Holden	Malibu	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Holden	Malibu	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2015	Holden	Malibu	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2015	Holden	Malibu	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2015	Holden	Malibu	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2015	Holden	Malibu	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Holden	Malibu	Front Seat Heating Control Module	●	●	●	●	●	○	

2015	Holden	Malibu	Left Side Object Detection Control Module	●	●	●	○	●	○	
2015	Holden	Malibu	Rear Seat Heating Control Module	●	●	●	●	●	○	
2015	Holden	Malibu	Seat Memory Control Module	●	●	●	●	●	●	S031
2015	Holden	Malibu	Radio	●	●	●	●	●	○	
2015	Holden	Malibu	Multimedia Player Interface Module	●	●	●	●	○	●	
2015	Holden	Malibu	Trailer Interface Control Module	●	●	●	●	●	●	
2015	Holden	Trax	Transmission Control Module	●	●	●	●	●	●	S023
2015	Holden	Trax	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2015	Holden	Trax	Instrument Cluster	●	●	●	●	●	●	S022
2015	Holden	Trax	HVAC Control Module	●	●	●	●	●	○	
2015	Holden	Trax	Electronic Brake Control Module	●	●	●	●	●	●	S035
2015	Holden	Trax	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2015	Holden	Trax	Rear Differential Clutch Control Module	●	●	●	●	●	●	
2015	Holden	Trax	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Holden	Trax	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2015	Holden	Trax	Power Steering Control Module	●	●	●	●	○	●	

2015	Holden	Trax	Parking Assist Control Module	●	●	●	●	●	●	
2015	Holden	Trax	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Holden	Trax	Seat Memory Control Module	●	●	●	●	●	●	S031
2015	Holden	Trax	Radio	●	●	●	●	●	○	
2015	Holden	Trax	Trailer Interface Control Module	●	●	●	●	●	●	
2015	Holden	Volt	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2015	Holden	Volt	Battery Energy Control Module	○	○	●	●	○	○	
2015	Holden	Volt	Coolant Heater Control Module	●	●	●	●	○	○	
2015	Holden	Volt	Battery Charger Control Module	○	○	●	●	○	○	
2015	Holden	Volt	Hybrid Powertrain Control Module	●	●	●	●	●	○	
2015	Holden	Volt	Drive Motor Control Module 1	●	●	●	●	○	○	
2015	Holden	Volt	Drive Motor Control Module 2	●	●	●	●	○	○	
2015	Holden	Volt	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	
2015	Holden	Volt	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S083 S084 S085 S086 S087 S088 S089
2015	Holden	Volt	Telematics Communication Interface Control Module	●	●	●	●	○	○	
2015	Holden	Volt	Steering Column Lock Control Module	●	●	●	●	○	●	
2015	Holden	Volt	Chassis Control Module	●	●	●	●	●	●	S025

2015	Holden	Volt	Instrument Cluster	●	●	●	●	●	●	S022 S022
2015	Holden	Volt	Front Seat Heating Control Module	●	●	●	●	●	○	
2015	Holden	Volt	Parking Assist Control Module	●	●	●	●	●	●	
2015	Holden	Volt	Transmission Control Module	●	●	●	●	●	○	
2015	Holden	Volt	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S091
2015	Holden	Volt	HVAC Control Module	●	●	●	●	●	●	S032 S033
2015	Holden	Volt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2015	Holden	Volt	Keyless Entry Control Module	●	●	●	●	●	○	
2015	Holden	Volt	Radio	●	●	●	●	●	○	
2015	Holden	Volt	Electronic Brake Control Module	●	●	●	●	●	●	S092 S036 S036 S036
2015	Holden	Volt	Parking Brake Control Module	●	●	●	●	●	●	S037
2015	Holden	Volt	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2015	Holden	Volt	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2015	Holden	Volt	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2015	Holden	Volt	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2014	Buick	Enclave	Transmission Control Module	●	●	●	●	●	●	S048

2014	Buick	Enclave	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Buick	Enclave	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Buick	Enclave	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S094 S030
2014	Buick	Enclave	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2014	Buick	Enclave	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2014	Buick	Enclave	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034 S036
2014	Buick	Enclave	Front Seat Heating Control Module	●	●	●	●	○	○	
2014	Buick	Enclave	Personal Audio Link Control Module	●	●	●	○	○	●	S056
2014	Buick	Encore	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Buick	Encore	Electronic Brake Control Module	●	●	●	●	●	●	S035
2014	Buick	Encore	Power Steering Control Module	●	●	●	●	○	●	
2014	Buick	Encore	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Buick	Encore	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2014	Buick	Encore	Transmission Control Module	●	●	●	●	●	●	S023
2014	Buick	Encore	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Buick	Encore	Rear Differential Clutch Control Module	●	●	●	●	●	●	

2014	Buick	Encore	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2014	Buick	Encore	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Buick	Encore	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2014	Buick	Encore	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Buick	Encore	Instrument Cluster	●	●	●	●	●	●	S022
2014	Buick	Encore	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Buick	Encore	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2014	Buick	Encore	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Buick	Encore	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Buick	Encore	Seat Memory Control Module	●	●	●	●	●	●	S031
2014	Buick	LaCrosse	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Buick	LaCrosse	Headlamp Control Module	●	●	●	●	●	○	
2014	Buick	LaCrosse	Battery Energy Control Module	○	○	●	●	○	○	
2014	Buick	LaCrosse	Drive Motor Control Module	●	●	●	●	○	○	
2014	Buick	LaCrosse	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2014	Buick	LaCrosse	Transmission Control Module	●	●	●	●	●	●	S023

2014	Buick	LaCrosse	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2014	Buick	LaCrosse	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Buick	LaCrosse	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Buick	LaCrosse	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2014	Buick	LaCrosse	Suspension Control Module	●	●	●	●	●	○	
2014	Buick	LaCrosse	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Buick	LaCrosse	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2014	Buick	LaCrosse	Power Steering Control Module	●	●	●	●	○	●	S047
2014	Buick	LaCrosse	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S030
2014	Buick	LaCrosse	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2014	Buick	LaCrosse	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Buick	LaCrosse	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Buick	LaCrosse	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Buick	LaCrosse	Radio Controls	●	●	●	●	○	●	S065
2014	Buick	LaCrosse	HVAC Controls	●	●	●	●	●	●	S065
2014	Buick	LaCrosse	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031

2014	Buick	LaCrosse	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Buick	LaCrosse	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Buick	LaCrosse	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2014	Buick	LaCrosse	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2014	Buick	LaCrosse	Radio	●	●	●	●	●	●	S063 S064
2014	Buick	LaCrosse	Amplifier	●	●	●	●	○	○	
2014	Buick	LaCrosse	Media Disc Player	●	●	●	●	●	○	
2014	Buick	LaCrosse	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2014	Buick	LaCrosse	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Buick	LaCrosse	Instrument Cluster	●	●	●	●	●	●	S022
2014	Buick	LaCrosse	Head-Up Display Module	●	●	●	●	●	○	
2014	Buick	Regal	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Buick	Regal	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2014	Buick	Regal	Drive Motor Control Module	●	●	●	●	○	○	
2014	Buick	Regal	Battery Energy Control Module	○	○	●	●	○	○	
2014	Buick	Regal	Transmission Control Module	●	●	●	●	●	●	S048
2014	Buick	Regal	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Buick	Regal	Radio	●	●	●	●	●	●	S063 S064

2014	Buick	Regal	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2014	Buick	Regal	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2014	Buick	Regal	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Buick	Regal	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Buick	Regal	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Buick	Regal	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036 S036
2014	Buick	Regal	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2014	Buick	Regal	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Buick	Regal	Instrument Cluster	●	●	●	●	●	●	S022
2014	Buick	Regal	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Buick	Regal	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2014	Buick	Regal	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Buick	Regal	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Buick	Regal	Seat Memory Control Module	●	●	●	●	●	●	S031

2014	Buick	Regal	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Buick	Regal	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Buick	Regal	Distance Sensing Cruise Control Module	●	●	●	●	○	●	S068
2014	Buick	Regal	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2014	Buick	Regal	Radio Controls	●	●	●	●	○	●	S065
2014	Buick	Regal	HVAC Controls	●	●	●	●	●	●	S065
2014	Buick	Regal	Amplifier	●	●	●	●	○	○	
2014	Buick	Regal	Suspension Control Module	●	●	●	●	●	○	
2014	Buick	Verano	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Buick	Verano	Transmission Control Module	●	●	●	●	●	●	S023
2014	Buick	Verano	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Buick	Verano	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S162 S029 S025 S030 S001
2014	Buick	Verano	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Buick	Verano	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2014	Buick	Verano	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Buick	Verano	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021

2014	Buick	Verano	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Buick	Verano	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2014	Buick	Verano	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Buick	Verano	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Buick	Verano	Instrument Cluster	●	●	●	●	●	●	S022
2014	Buick	Verano	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Buick	Verano	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Buick	Verano	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Buick	Verano	Power Steering Control Module	●	●	●	●	○	●	
2014	Buick	Verano	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2014	Buick	Verano	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S070 S036
2014	Buick	Verano	Radio	●	●	●	●	●	○	
2014	Buick	Verano	Multimedia Player Interface Module	●	●	●	●	○	●	
2014	Cadillac	ATS	Headlamp Control Module	●	●	●	●	●	●	S002
2014	Cadillac	ATS	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Cadillac	ATS	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Cadillac	ATS	Instrument Cluster	●	●	●	●	●	●	S022
2014	Cadillac	ATS	Transmission Control Module	●	●	●	●	●	●	S048

2014	Cadillac	ATS	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Cadillac	ATS	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2014	Cadillac	ATS	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Cadillac	ATS	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Cadillac	ATS	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Cadillac	ATS	Transfer Case Control Module	●	●	●	●	●	●	S072 S073 S074
2014	Cadillac	ATS	Active Safety Control Module	●	●	●	●	●	○	
2014	Cadillac	ATS	Frontview Camera Module	●	●	●	●	○	●	S051
2014	Cadillac	ATS	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Cadillac	ATS	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Cadillac	ATS	Pedestrian Impact Detection Module	●	●	●	●	○	●	
2014	Cadillac	ATS	Right Side Object Detection Control Module	●	●	●	○	●	○	
2014	Cadillac	ATS	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2014	Cadillac	ATS	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S029 S025 S030

2014	Cadillac	ATS	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2014	Cadillac	ATS	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Cadillac	ATS	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Cadillac	ATS	Power Steering Control Module	●	●	●	●	○	●	S075
2014	Cadillac	ATS	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Cadillac	ATS	Suspension Control Module	●	●	●	●	●	●	S076 S077 S077 S038
2014	Cadillac	ATS	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Cadillac	ATS	Long Range Radar Sensor Module	●	●	●	●	○	●	S061
2014	Cadillac	ATS	Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2014	Cadillac	ATS	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2014	Cadillac	ATS	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2014	Cadillac	ATS	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2014	Cadillac	ATS	Media Disc Player	●	●	●	●	●	○	
2014	Cadillac	ATS	Radio/HVAC Controls	●	●	●	●	○	○	
2014	Cadillac	ATS	Radio	●	●	●	●	●	●	S063 S064
2014	Cadillac	ATS	Amplifier	●	●	●	●	○	○	
2014	Cadillac	ELR	Hybrid Powertrain Control Module	●	●	●	●	●	○	
2014	Cadillac	ELR	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	

2014	Cadillac	ELR	Drive Motor Control Module 1	●	●	●	●	○	○	
2014	Cadillac	ELR	Drive Motor Control Module 2	●	●	●	●	○	○	
2014	Cadillac	ELR	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Cadillac	ELR	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2014	Cadillac	ELR	Battery Energy Control Module	○	○	●	●	○	○	
2014	Cadillac	ELR	Battery Charger Control Module	○	○	●	●	○	○	
2014	Cadillac	ELR	Coolant Heater Control Module	●	●	●	○	○	○	
2014	Cadillac	ELR	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S083 S084 S085 S086 S087 S088 S089
2014	Cadillac	ELR	Transmission Control Module	●	●	●	●	●	○	
2014	Cadillac	ELR	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Cadillac	ELR	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S091
2014	Cadillac	ELR	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Cadillac	ELR	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036
2014	Cadillac	ELR	Passenger Presence Module	●	●	●	●	○	●	S043

2014	Cadillac	ELR	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Cadillac	ELR	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Cadillac	ELR	Instrument Cluster	●	●	●	●	●	●	S022
2014	Cadillac	ELR	Electronic Brake Control Module	●	●	●	●	●	●	S092 S036 S036 S036
2014	Cadillac	ELR	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Cadillac	ELR	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2014	Cadillac	ELR	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Cadillac	ELR	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Cadillac	ELR	Right Side Object Detection Control Module	●	●	●	○	●	○	
2014	Cadillac	ELR	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2014	Cadillac	ELR	Suspension Control Module	●	●	●	●	●	○	
2014	Cadillac	ELR	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Cadillac	ELR	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Cadillac	ELR	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Cadillac	ELR	Pedestrian Alert Sound Control Module	●	●	●	●	●	○	

2014	Cadillac	Escalade ESV	Passenger Presence Module	●	●	●	●	○	○	
2014	Cadillac	Escalade ESV	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2014	Cadillac	Escalade ESV	Body Control Module	●	●	●	●	●	●	S001 S053
2014	Cadillac	Escalade ESV	Theft Deterrent Module	●	●	●	●	○	○	
2014	Cadillac	Escalade ESV	Instrument Cluster	●	●	●	●	●	○	
2014	Cadillac	Escalade ESV	HVAC Control Module	●	●	●	●	●	●	S052 S032 S033
2014	Cadillac	Escalade ESV	Left Side Object Detection Control Module	●	●	●	●	●	○	
2014	Cadillac	Escalade ESV	Parking Assist Control Module	●	●	●	●	●	○	
2014	Cadillac	Escalade ESV	Rear Seat Heating Control Module	●	●	●	●	●	○	
2014	Cadillac	Escalade ESV	Right Side Object Detection Control Module	●	●	●	●	●	○	
2014	Cadillac	Escalade ESV	Seat Memory Control Module	●	●	●	●	●	○	
2014	Cadillac	Escalade ESV	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2014	Cadillac	Escalade ESV	Chassis Control Module	●	●	●	●	●	●	S025
2014	Cadillac	Escalade ESV	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2014	Cadillac	Escalade ESV	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2014	Cadillac	Escalade ESV	Radio	●	●	●	●	●	●	
2014	Cadillac	Escalade ESV	Personal Audio Link Control Module	●	●	●	○	○	●	S056
2014	Cadillac	Escalade ESV	Amplifier	●	●	●	●	○	○	
2014	Cadillac	Escalade ESV	Digital Radio Receiver Control Module	●	●	●	●	●	○	

2014	Cadillac	Escalade ESV	Liftgate Control Module	●	●	●	●	○	●	S049
2014	Cadillac	Escalade ESV	Rear Audio Control Module	●	●	●	●	●	○	
2014	Cadillac	Escalade ESV	Suspension Control Module	●	●	●	●	●	●	
2014	Cadillac	Escalade ESV	Electronic Brake Control Module	●	●	●	●	●	●	S034 S036
2014	Cadillac	Escalade ESV	Transmission Control Module	●	●	●	●	●	●	S048
2014	Cadillac	Escalade ESV	Assist Step Control Module	●	●	●	●	●	○	
2014	Cadillac	Escalade ESV	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2014	Cadillac	SRX	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Cadillac	SRX	Headlamp Control Module	●	●	●	●	●	●	
2014	Cadillac	SRX	Liftgate Control Module	●	●	●	●	●	●	S049
2014	Cadillac	SRX	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2014	Cadillac	SRX	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2014	Cadillac	SRX	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Cadillac	SRX	Suspension Control Module	●	●	●	●	●	○	
2014	Cadillac	SRX	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024

2014	Cadillac	SRX	Transmission Control Module	●	●	●	●	●	●	S048
2014	Cadillac	SRX	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Cadillac	SRX	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2014	Cadillac	SRX	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Cadillac	SRX	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Cadillac	SRX	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Cadillac	SRX	Trailer Interface Control Module	●	●	●	●	●	●	S022
2014	Cadillac	SRX	Instrument Cluster	●	●	●	●	●	●	S022
2014	Cadillac	SRX	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S094 S046
2014	Cadillac	SRX	Rear Seat Heating Control Module	●	●	●	●	●	○	
2014	Cadillac	SRX	Frontview Camera Module	●	●	●	●	○	●	S051
2014	Cadillac	SRX	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Cadillac	SRX	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Cadillac	SRX	Active Safety Control Module	●	●	●	●	●	○	

2014	Cadillac	SRX	Right Side Object Detection Control Module	●	●	●	○	●	○	
2014	Cadillac	SRX	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2014	Cadillac	SRX	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Cadillac	SRX	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Cadillac	SRX	Long Range Radar Sensor Module	●	●	●	●	○	●	S061
2014	Cadillac	SRX	Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2014	Cadillac	SRX	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2014	Cadillac	SRX	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2014	Cadillac	SRX	Radio	●	●	●	●	●	●	S063 S064
2014	Cadillac	SRX	Media Disc Player	●	●	●	●	●	○	
2014	Cadillac	SRX	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2014	Cadillac	SRX	Amplifier	●	●	●	●	○	○	
2014	Cadillac	XTS	Active Safety Control Module	●	●	●	●	●	○	
2014	Cadillac	XTS	Frontview Camera Module	●	●	●	●	○	●	S051
2014	Cadillac	XTS	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Cadillac	XTS	Parking Assist Control Module	●	●	●	●	●	●	S081
2014	Cadillac	XTS	Right Side Object Detection Control Module	●	●	●	○	●	○	

2014	Cadillac	XTS	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Cadillac	XTS	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2014	Cadillac	XTS	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Cadillac	XTS	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Cadillac	XTS	Transmission Control Module	●	●	●	●	●	●	S048
2014	Cadillac	XTS	Headlamp Control Module	●	●	●	●	●	●	S002
2014	Cadillac	XTS	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Cadillac	XTS	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Cadillac	XTS	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2014	Cadillac	XTS	Seat Memory Control Module - Passenger	●	●	●	●	●	○	
2014	Cadillac	XTS	Instrument Cluster	●	●	●	●	●	●	S022
2014	Cadillac	XTS	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2014	Cadillac	XTS	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Cadillac	XTS	Suspension Control Module	●	●	●	●	●	●	S076 S077 S077 S038
2014	Cadillac	XTS	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030

2014	Cadillac	XTS	Radio	●	●	●	●	●	●	S063 S064
2014	Cadillac	XTS	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Cadillac	XTS	Long Range Radar Sensor Module	●	●	●	●	○	●	S061
2014	Cadillac	XTS	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2014	Cadillac	XTS	Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2014	Cadillac	XTS	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2014	Cadillac	XTS	Amplifier	●	●	●	●	○	○	
2014	Cadillac	XTS	Radio/HVAC Controls	●	●	●	●	○	○	
2014	Cadillac	XTS	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2014	Cadillac	XTS	Media Disc Player	●	●	●	●	●	○	
2014	Cadillac	XTS	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2014	Cadillac	XTS	Power Steering Control Module	●	●	●	●	●	○	
2014	Cadillac	XTS	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Chevrolet	Beat	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Beat	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2014	Chevrolet	Beat	Engine Control Module	●	●	●	●	●	●	S026 S044 S045 S025
2014	Chevrolet	Beat	Instrument Cluster	●	●	●	●	●	○	

2014	Chevrolet	Beat	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Chevrolet	Beat	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Beat	Electronic Brake Control Module	●	●	●	●	●	●	S035
2014	Chevrolet	Beat	Power Steering Control Module	●	●	●	●	○	●	
2014	Chevrolet	Beat	Fuel Injector Control Module	●	●	●	●	●	○	
2014	Chevrolet	Camaro	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2014	Chevrolet	Camaro	Head-Up Display Module	●	●	●	●	●	○	
2014	Chevrolet	Camaro	Instrument Cluster	●	●	●	●	●	●	S022
2014	Chevrolet	Camaro	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Camaro	Headlamp Control Module	●	●	●	●	●	●	S002
2014	Chevrolet	Camaro	Transmission Control Module	●	●	●	●	●	●	S048
2014	Chevrolet	Camaro	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Chevrolet	Camaro	Auxiliary Gage Module	●	●	●	●	●	○	
2014	Chevrolet	Camaro	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2014	Chevrolet	Camaro	Passenger Presence Module	●	●	●	●	○	●	S043

2014	Chevrolet	Camaro	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Chevrolet	Camaro	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Chevrolet	Camaro	Folding Top Control Module	●	●	●	●	●	○	
2014	Chevrolet	Camaro	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Chevrolet	Camaro	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Camaro	Radio	●	●	●	●	●	○	
2014	Chevrolet	Camaro	Mobile Telephone Control Module	●	●	●	●	●	●	
2014	Chevrolet	Camaro	Power Steering Control Module	●	●	●	●	○	●	S047
2014	Chevrolet	Camaro	Suspension Control Module	●	●	●	●	●	●	S038
2014	Chevrolet	Camaro	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034 S036
2014	Chevrolet	Camaro	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Camaro	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Chevrolet	Caprice	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Chevrolet	Caprice	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Chevrolet	Caprice	Transmission Control Module	●	●	●	●	●	●	S048
2014	Chevrolet	Caprice	Instrument Cluster	●	●	●	●	●	●	S022 S097
2014	Chevrolet	Caprice	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030

2014	Chevrolet	Caprice	Headlamp Control Module	●	●	●	●	●	●	S002
2014	Chevrolet	Caprice	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Chevrolet	Caprice	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2014	Chevrolet	Caprice	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Chevrolet	Caprice	Trailer Interface Control Module	●	●	●	●	●	●	
2014	Chevrolet	Caprice	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2014	Chevrolet	Caprice	Power Steering Control Module	●	●	●	●	○	●	
2014	Chevrolet	Caprice	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Chevrolet	Caprice	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2014	Chevrolet	Caprice	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Caprice	Radio Controls	●	●	●	●	●	●	S022
2014	Chevrolet	Caprice	HVAC Controls	●	●	●	●	●	●	
2014	Chevrolet	Caprice	Radio	●	●	●	●	●	○	
2014	Chevrolet	Cheyenne	Transfer Case Control Module	●	●	●	●	●	●	S080
2014	Chevrolet	Cheyenne	Transmission Control Module	●	●	●	●	●	●	S048
2014	Chevrolet	Cheyenne	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030

2014	Chevrolet	Cheyenne	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Chevrolet	Cheyenne	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Cheyenne	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2014	Chevrolet	Cheyenne	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Chevrolet	Cheyenne	Instrument Cluster	●	●	●	●	●	●	S022
2014	Chevrolet	Cheyenne	Passenger Presence Module	●	●	●	●	●	●	S043
2014	Chevrolet	Cheyenne	Power Steering Control Module	●	●	●	●	●	●	S064
2014	Chevrolet	Cheyenne	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2014	Chevrolet	Cheyenne	Frontview Camera Module	●	●	●	●	○	●	S051
2014	Chevrolet	Cheyenne	Left Side Object Detection Control Module	●	●	●	●	●	○	
2014	Chevrolet	Cheyenne	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Cheyenne	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2014	Chevrolet	Cheyenne	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Chevrolet	Cheyenne	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S035
2014	Chevrolet	Cheyenne	Radio	●	●	●	●	●	●	S063 S064

2014	Chevrolet	Cheyenne	HVAC Controls	●	●	●	●	●	●	S065
2014	Chevrolet	Cheyenne	Radio Controls	●	●	●	●	○	●	S065
2014	Chevrolet	Cheyenne	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2014	Chevrolet	Cheyenne	Media Disc Player	●	●	●	●	●	○	
2014	Chevrolet	Cheyenne	Amplifier	●	●	●	●	○	○	
2014	Chevrolet	Cobalt	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2014	Chevrolet	Cobalt	Transmission Control Module	●	●	●	●	●	●	S023
2014	Chevrolet	Cobalt	Instrument Cluster	●	●	●	●	●	●	S022
2014	Chevrolet	Cobalt	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2014	Chevrolet	Cobalt	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2014	Chevrolet	Cobalt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2014	Chevrolet	Cobalt	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Chevrolet	Cobalt	HVAC Control Module	●	●	●	●	●	○	
2014	Chevrolet	Cobalt	Electronic Brake Control Module	●	●	●	●	●	●	S035
2014	Chevrolet	Cobalt	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Chevrolet	Cobalt	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Cobalt	Radio	●	●	●	●	●	○	

2014	Chevrolet	Corvette	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Corvette	Rear Differential Clutch Control Module	●	●	●	●	●	●	S079
2014	Chevrolet	Corvette	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2014	Chevrolet	Corvette	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Chevrolet	Corvette	Transmission Control Module	●	●	●	●	●	●	S048
2014	Chevrolet	Corvette	Instrument Cluster	●	●	●	●	●	●	S022
2014	Chevrolet	Corvette	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2014	Chevrolet	Corvette	Passenger Presence Module	●	●	●	●	●	●	S043
2014	Chevrolet	Corvette	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Chevrolet	Corvette	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Chevrolet	Corvette	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2014	Chevrolet	Corvette	Radio	●	●	●	●	●	●	S063 S064
2014	Chevrolet	Corvette	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Chevrolet	Corvette	Amplifier	●	●	●	●	○	○	
2014	Chevrolet	Corvette	Radio/HVAC Controls	●	●	●	●	●	○	

2014	Chevrolet	Corvette	Folding Top Control Module	●	●	●	●	●	○	
2014	Chevrolet	Corvette	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2014	Chevrolet	Corvette	Seat Memory Control Module - Passenger	●	●	●	●	●	○	
2014	Chevrolet	Corvette	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Chevrolet	Corvette	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034 S036
2014	Chevrolet	Corvette	Suspension Control Module	●	●	●	●	●	●	S038
2014	Chevrolet	Corvette	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Corvette	Power Steering Control Module	●	●	●	●	○	●	S075
2014	Chevrolet	Cruze	Engine Control Module	●	●	●	●	●	●	S112 S103 S182 S113 S122 S029 S183 S124 S125 S126 S127 S128 S129 S130 S131 S132 S030 S193 S134 S135 S136 S137 S144 S145 S146 S147 S152 S153
2014	Chevrolet	Cruze	Transmission Control Module	●	●	●	●	●	●	S023
2014	Chevrolet	Cruze	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2014	Chevrolet	Cruze	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141
2014	Chevrolet	Cruze	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Chevrolet	Cruze	Left Side Object Detection Control Module	●	●	●	○	●	○	

2014	Chevrolet	Cruze	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Cruze	Right Side Object Detection Control Module	●	●	●	○	●	○	
2014	Chevrolet	Cruze	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2014	Chevrolet	Cruze	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Chevrolet	Cruze	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Chevrolet	Cruze	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Cruze	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Chevrolet	Cruze	Instrument Cluster	●	●	●	●	●	●	S022
2014	Chevrolet	Cruze	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2014	Chevrolet	Cruze	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Cruze	Trailer Interface Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Cruze	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2014	Chevrolet	Cruze	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2014	Chevrolet	Cruze	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Chevrolet	Cruze	Radio	●	●	●	●	●	○	
2014	Chevrolet	Cruze	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Cruze	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036

2014	Chevrolet	Cruze	Multimedia Player Interface Module	●	●	●	●	○	●	
2014	Chevrolet	Cruze	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Chevrolet	Cruze	Fuel Injector Control Module	○	○	●	●	●	○	
2014	Chevrolet	Enjoy	Instrument Cluster	●	●	○	○	○	○	
2014	Chevrolet	Enjoy	Engine Control Module	●	●	●	●	●	○	
2014	Chevrolet	Enjoy	Electronic Brake Control Module	●	●	●	●	●	○	
2014	Chevrolet	Enjoy	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	
2014	Chevrolet	Equinox	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2014	Chevrolet	Equinox	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Equinox	Power Steering Control Module	●	●	●	●	○	●	
2014	Chevrolet	Equinox	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Equinox	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Equinox	Liftgate Control Module	●	●	●	●	●	●	S049
2014	Chevrolet	Equinox	Transmission Control Module	●	●	●	●	●	●	S023
2014	Chevrolet	Equinox	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2014	Chevrolet	Equinox	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024

2014	Chevrolet	Equinox	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Chevrolet	Equinox	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S046
2014	Chevrolet	Equinox	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2014	Chevrolet	Equinox	Frontview Camera Module	●	●	●	●	○	●	S051
2014	Chevrolet	Equinox	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Chevrolet	Equinox	Right Side Object Detection Control Module	●	●	●	○	●	○	
2014	Chevrolet	Equinox	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Equinox	Seat Memory Control Module	●	●	●	●	●	●	S031
2014	Chevrolet	Equinox	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Chevrolet	Equinox	Instrument Cluster	●	●	●	●	●	●	S022
2014	Chevrolet	Equinox	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Chevrolet	Equinox	Radio	●	●	●	●	●	○	
2014	Chevrolet	Express	Engine Control Module	●	●	●	●	●	●	S112 S103 S119 S120 S121 S122 S029 S123 S124 S125 S126 S127 S128 S129 S130 S131 S132 S030 S133 S134 S135 S136 S137 S138 S139 S140 S141 S142 S143 S144 S145 S146 S147 S148 S149 S150 S151 S152 S153

2014	Chevrolet	Express	Transmission Control Module	●	●	●	●	●	●	S048
2014	Chevrolet	Express	Electronic Brake Control Module	●	●	●	●	●	●	S036
2014	Chevrolet	Express	Body Control Module	●	●	●	●	●	●	S001 S053
2014	Chevrolet	Express	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	S024 S053
2014	Chevrolet	Express	Passenger Presence Module	●	●	●	●	○	●	
2014	Chevrolet	Express	Rollover Sensor Module	●	●	●	●	○	●	
2014	Chevrolet	Express	Instrument Cluster	●	●	●	●	●	○	
2014	Chevrolet	Express	Chime Alarm Control Module	●	●	●	○	●	○	
2014	Chevrolet	Express	Radio	●	●	●	●	●	●	
2014	Chevrolet	Express	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2014	Chevrolet	Express	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Express	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2014	Chevrolet	Express	Theft Deterrent Module	●	●	●	●	○	○	
2014	Chevrolet	Express	Auxiliary Heater Control Module	●	●	●	●	●	●	S025
2014	Chevrolet	Express	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141
2014	Chevrolet	Express	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Lacetti	Electronic Brake Control Module	●	●	●	●	●	○	

2014	Chevrolet	Lacetti	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	○	
2014	Chevrolet	Lacetti	Transmission Control Module	●	●	●	●	●	●	S023
2014	Chevrolet	Lacetti	Engine Control Module	●	●	●	●	●	●	S026 S044 S045 S025
2014	Chevrolet	Lacetti	Fuel Injector Control Module	●	●	●	●	●	○	
2014	Chevrolet	Lumina	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Chevrolet	Lumina	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Chevrolet	Lumina	Head-Up Display Module	●	●	●	●	●	○	
2014	Chevrolet	Lumina	Instrument Cluster	●	●	●	●	●	●	S022 S097
2014	Chevrolet	Lumina	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2014	Chevrolet	Lumina	Transmission Control Module	●	●	●	●	●	●	S048
2014	Chevrolet	Lumina	Headlamp Control Module	●	●	●	●	●	●	S002
2014	Chevrolet	Lumina	Suspension Control Module	●	●	●	●	●	●	S076 S077 S038
2014	Chevrolet	Lumina	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Chevrolet	Lumina	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Chevrolet	Lumina	Trailer Interface Control Module	●	●	●	●	●	●	
2014	Chevrolet	Lumina	Fuel Injector Control Module	○	○	●	●	●	○	

2014	Chevrolet	Malibu	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Chevrolet	Malibu	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Malibu	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Chevrolet	Malibu	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Malibu	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2014	Chevrolet	Malibu	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Chevrolet	Malibu	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2014	Chevrolet	Malibu	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Chevrolet	Malibu	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Chevrolet	Malibu	Headlamp Control Module	●	●	●	●	●	●	S002
2014	Chevrolet	Malibu	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2014	Chevrolet	Malibu	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Malibu	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Chevrolet	Malibu	Instrument Cluster	●	●	●	●	●	●	S022

2014	Chevrolet	Malibu	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Chevrolet	Malibu	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Chevrolet	Malibu	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Malibu	Seat Memory Control Module	●	●	●	●	●	●	S031
2014	Chevrolet	Malibu	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2014	Chevrolet	Malibu	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2014	Chevrolet	Malibu	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Chevrolet	Malibu	Radio	●	●	●	●	●	○	
2014	Chevrolet	Malibu	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2014	Chevrolet	Malibu	Drive Motor Control Module	●	●	●	●	○	○	
2014	Chevrolet	Malibu	Rear Seat Heating Control Module	●	●	●	●	●	○	
2014	Chevrolet	Malibu	Fuel Injector Control Module	●	●	●	●	●	○	
2014	Chevrolet	Malibu	Multimedia Player Interface Module	●	●	●	●	○	●	
2014	Chevrolet	N300	Electronic Brake Control Module	●	●	●	●	●	○	
2014	Chevrolet	N300	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	○	
2014	Chevrolet	N300	Engine Control Module	●	●	●	●	●	●	S095 S096 S155
2014	Chevrolet	Onix	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021

2014	Chevrolet	Onix	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2014	Chevrolet	Onix	Transmission Control Module	●	●	●	●	●	●	S023
2014	Chevrolet	Onix	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2014	Chevrolet	Onix	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2014	Chevrolet	Onix	Electronic Brake Control Module	●	●	●	●	●	●	S035
2014	Chevrolet	Onix	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Chevrolet	Onix	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Onix	Radio	●	●	●	●	●	○	
2014	Chevrolet	Onix	Instrument Cluster	●	●	●	●	●	●	S022
2014	Chevrolet	Onix	Parking Assist Control Module	●	●	●	●	●	●	
2014	Chevrolet	Optra	Transmission Control Module	●	●	●	●	●	●	S023
2014	Chevrolet	Optra	Engine Control Module	●	●	●	●	●	●	S026 S044 S045 S025
2014	Chevrolet	Optra	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2014	Chevrolet	Optra	Electronic Brake Control Module	●	●	●	●	●	○	
2014	Chevrolet	Optra	Instrument Cluster	●	●	●	●	●	○	
2014	Chevrolet	Optra	Body Control Module	●	●	●	●	●	○	
2014	Chevrolet	Orlando	Instrument Cluster	●	●	●	●	●	●	S022

2014	Chevrolet	Orlando	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Orlando	Engine Control Module	●	●	●	●	●	●	S029 S025
2014	Chevrolet	Orlando	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2014	Chevrolet	Orlando	Transmission Control Module	●	●	●	●	●	●	S023
2014	Chevrolet	Orlando	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Chevrolet	Orlando	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2014	Chevrolet	Orlando	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Chevrolet	Orlando	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Orlando	Rear Seat Heating Control Module	●	●	●	●	●	○	
2014	Chevrolet	Orlando	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Chevrolet	Orlando	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Chevrolet	Orlando	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Orlando	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2014	Chevrolet	Orlando	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2014	Chevrolet	Orlando	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Orlando	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022

2014	Chevrolet	Orlando	Radio	●	●	●	●	●	○	
2014	Chevrolet	Orlando	Multimedia Player Interface Module	●	●	●	●	○	●	
2014	Chevrolet	Orlando	Fuel Injector Control Module	●	●	●	●	●	○	
2014	Chevrolet	Prisma	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2014	Chevrolet	Prisma	Transmission Control Module	●	●	●	●	●	●	S023
2014	Chevrolet	Prisma	Electronic Brake Control Module	●	●	●	●	●	●	S035
2014	Chevrolet	Prisma	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Chevrolet	Prisma	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Prisma	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2014	Chevrolet	Prisma	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2014	Chevrolet	Prisma	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2014	Chevrolet	Prisma	Radio	●	●	●	●	●	○	
2014	Chevrolet	Prisma	Instrument Cluster	●	●	●	●	●	●	S022
2014	Chevrolet	Prisma	Parking Assist Control Module	●	●	●	●	●	●	
2014	Chevrolet	S10	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2014	Chevrolet	S10	Transfer Case Control Module	●	●	●	●	●	●	S080
2014	Chevrolet	S10	Instrument Cluster	●	●	●	●	●	●	S022

2014	Chevrolet	S10	Trailer Interface Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	S10	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2014	Chevrolet	S10	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2014	Chevrolet	S10	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Chevrolet	S10	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	S10	Electronic Brake Control Module	●	●	●	●	●	●	S035 S070
2014	Chevrolet	S10	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Chevrolet	S10	Transmission Control Module	●	●	●	●	●	●	S048
2014	Chevrolet	S10	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	S10	Radio	●	●	●	●	●	○	
2014	Chevrolet	Sail	Electronic Brake Control Module	●	●	●	●	●	○	
2014	Chevrolet	Sail	Keyless Entry Control Module	○	○	○	●	○	●	
2014	Chevrolet	Sail	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	S194 S195 S196 S197 S198 S194 S195 S196 S197 S024 S199
2014	Chevrolet	Sail	Engine Control Module	●	●	●	●	●	○	

2014	Chevrolet	Sail	Transmission Control Module	●	●	●	●	●	●	S200 S201 S202 S203 S204
2014	Chevrolet	Savana	Engine Control Module	●	●	●	●	●	●	S112 S103 S119 S120 S121 S122 S029 S123 S124 S125 S126 S127 S128 S129 S130 S131 S132 S030 S133 S134 S135 S136 S137 S138 S139 S140 S141 S142 S143 S144 S145 S146 S147 S148 S149 S150 S151 S152 S153
2014	Chevrolet	Savana	Transmission Control Module	●	●	●	●	●	●	S048
2014	Chevrolet	Savana	Electronic Brake Control Module	●	●	●	●	●	●	S036
2014	Chevrolet	Savana	Body Control Module	●	●	●	●	●	●	S001 S053
2014	Chevrolet	Savana	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	S024 S053
2014	Chevrolet	Savana	Passenger Presence Module	●	●	●	●	○	●	
2014	Chevrolet	Savana	Rollover Sensor Module	●	●	●	●	○	●	
2014	Chevrolet	Savana	Instrument Cluster	●	●	●	●	●	○	
2014	Chevrolet	Savana	Chime Alarm Control Module	●	●	●	○	●	○	
2014	Chevrolet	Savana	Radio	●	●	●	●	●	●	
2014	Chevrolet	Savana	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2014	Chevrolet	Savana	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039

2014	Chevrolet	Savana	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2014	Chevrolet	Savana	Theft Deterrent Module	●	●	●	●	○	○	
2014	Chevrolet	Savana	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Savana	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Chevrolet	Savana	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141
2014	Chevrolet	Sonic	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Chevrolet	Sonic	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Sonic	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Chevrolet	Sonic	Fuel Injector Control Module	○	○	●	●	●	○	
2014	Chevrolet	Sonic	Instrument Cluster	●	●	●	●	●	●	S022
2014	Chevrolet	Sonic	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2014	Chevrolet	Sonic	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2014	Chevrolet	Sonic	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2014	Chevrolet	Sonic	Transmission Control Module	●	●	●	●	●	●	S023
2014	Chevrolet	Sonic	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2014	Chevrolet	Sonic	Parking Assist Control Module	●	●	●	●	●	●	S022

2014	Chevrolet	Sonic	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2014	Chevrolet	Sonic	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Chevrolet	Sonic	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Sonic	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Chevrolet	Sonic	Electronic Brake Control Module	●	●	●	●	●	●	S035
2014	Chevrolet	Sonic	Power Steering Control Module	●	●	●	●	○	●	
2014	Chevrolet	Sonic	HVAC Control Module	●	●	●	●	●	○	
2014	Chevrolet	Sonic	Radio	●	●	●	●	●	○	
2014	Chevrolet	Spark EV	Engine Control Module	●	●	●	●	●	●	S030
2014	Chevrolet	Spark EV	Hybrid Powertrain Control Module	●	●	●	●	●	●	
2014	Chevrolet	Spark EV	Drive Motor Control Module	●	●	●	●	○	○	
2014	Chevrolet	Spark EV	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2014	Chevrolet	Spark EV	Battery Charger Control Module	○	○	●	●	○	○	
2014	Chevrolet	Spark EV	Coolant Heater Control Module	●	●	●	○	○	○	
2014	Chevrolet	Spark EV	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S084 S083 S160 S161 S087 S088 S089
2014	Chevrolet	Spark EV	Battery Energy Control Module	○	○	●	●	○	○	
2014	Chevrolet	Spark EV	DC Charging Control Module	○	○	●	●	○	○	
2014	Chevrolet	Spark EV	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	

2014	Chevrolet	Spark EV	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Chevrolet	Spark EV	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Chevrolet	Spark EV	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2014	Chevrolet	Spark EV	Passenger Presence Module	●	●	●	●	●	●	S043
2014	Chevrolet	Spark EV	Pedestrian Alert Sound Control Module	●	●	●	●	●	○	
2014	Chevrolet	Spark EV	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Spark EV	Power Steering Control Module	●	●	●	●	○	●	
2014	Chevrolet	Spark EV	Instrument Cluster	●	●	●	●	●	●	S022 S022
2014	Chevrolet	Spark EV	Radio	●	●	●	●	●	○	
2014	Chevrolet	Spark EV	Electronic Brake Control Module	●	●	●	●	●	●	S092 S036 S036 S036
2014	Chevrolet	Spin	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2014	Chevrolet	Spin	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2014	Chevrolet	Spin	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025

2014	Chevrolet	Spin	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2014	Chevrolet	Spin	Instrument Cluster	●	●	●	●	●	●	S022
2014	Chevrolet	Spin	Transmission Control Module	●	●	●	●	●	●	S023
2014	Chevrolet	Spin	Electronic Brake Control Module	●	●	●	●	●	●	S035
2014	Chevrolet	Spin	HVAC Control Module	●	●	●	●	●	○	
2014	Chevrolet	Spin	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Chevrolet	Spin	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Spin	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Spin	Radio	●	●	●	●	●	○	
2014	Chevrolet	SS	Instrument Cluster	●	●	●	●	●	●	S022 S097
2014	Chevrolet	SS	Head-Up Display Module	●	●	●	●	●	○	
2014	Chevrolet	SS	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	SS	Headlamp Control Module	●	●	●	●	●	●	S002
2014	Chevrolet	SS	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Chevrolet	SS	Transmission Control Module	●	●	●	●	●	●	S048

2014	Chevrolet	SS	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2014	Chevrolet	SS	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Chevrolet	SS	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Chevrolet	SS	Trailer Interface Control Module	●	●	●	●	●	●	
2014	Chevrolet	SS	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2014	Chevrolet	SS	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Chevrolet	SS	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2014	Chevrolet	SS	Power Steering Control Module	●	●	●	●	○	●	
2014	Chevrolet	SS	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2014	Chevrolet	SS	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	SS	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2014	Chevrolet	SS	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Chevrolet	SS	Right Side Object Detection Control Module	●	●	●	○	●	○	
2014	Chevrolet	SS	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	SS	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Chevrolet	SS	Radio	●	●	●	●	●	○	
2014	Chevrolet	SS	Radio Controls	●	●	●	●	●	●	S022
2014	Chevrolet	Suburban	Liftgate Control Module	●	●	●	●	○	●	S049

2014	Chevrolet	Suburban	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Suburban	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2014	Chevrolet	Suburban	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2014	Chevrolet	Suburban	Passenger Presence Module	●	●	●	●	○	○	
2014	Chevrolet	Suburban	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2014	Chevrolet	Suburban	Transfer Case Control Module	●	●	●	●	●	●	S080
2014	Chevrolet	Suburban	Transmission Control Module	●	●	●	●	●	●	S048
2014	Chevrolet	Suburban	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2014	Chevrolet	Suburban	Chassis Control Module	●	●	●	●	●	●	S025
2014	Chevrolet	Suburban	Body Control Module	●	●	●	●	●	●	S001 S053
2014	Chevrolet	Suburban	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2014	Chevrolet	Suburban	Instrument Cluster	●	●	●	●	●	○	
2014	Chevrolet	Suburban	Theft Deterrent Module	●	●	●	●	○	○	
2014	Chevrolet	Suburban	HVAC Control Module	●	●	●	●	●	●	S052 S032 S033
2014	Chevrolet	Suburban	Left Side Object Detection Control Module	●	●	●	●	●	○	
2014	Chevrolet	Suburban	Parking Assist Control Module	●	●	●	●	●	○	
2014	Chevrolet	Suburban	Rear Seat Heating Control Module	●	●	●	●	●	○	

2014	Chevrolet	Suburban	Right Side Object Detection Control Module	●	●	●	●	●	○	
2014	Chevrolet	Suburban	Seat Memory Control Module	●	●	●	●	●	○	
2014	Chevrolet	Suburban	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2014	Chevrolet	Suburban	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2014	Chevrolet	Suburban	Radio	●	●	●	●	●	●	
2014	Chevrolet	Suburban	Personal Audio Link Control Module	●	●	●	○	○	●	S056
2014	Chevrolet	Suburban	Amplifier	●	●	●	●	○	○	
2014	Chevrolet	Suburban	Rear Audio Control Module	●	●	●	●	●	○	
2014	Chevrolet	Suburban	Suspension Control Module	●	●	●	●	●	●	
2014	Chevrolet	Suburban	Assist Step Control Module	●	●	●	●	●	○	
2014	Chevrolet	Suburban	Electronic Brake Control Module	●	●	●	●	●	●	S034 S036
2014	Chevrolet	Tahoe	Instrument Cluster	●	●	●	●	●	○	
2014	Chevrolet	Tahoe	Theft Deterrent Module	●	●	●	●	○	○	
2014	Chevrolet	Tahoe	Transfer Case Control Module	●	●	●	●	●	●	S080
2014	Chevrolet	Tahoe	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2014	Chevrolet	Tahoe	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2014	Chevrolet	Tahoe	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030

2014	Chevrolet	Tahoe	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Tahoe	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tahoe	Passenger Presence Module	●	●	●	●	○	○	
2014	Chevrolet	Tahoe	Transmission Control Module	●	●	●	●	●	●	S048
2014	Chevrolet	Tahoe	Chassis Control Module	●	●	●	●	●	●	S025
2014	Chevrolet	Tahoe	Radio	●	●	●	●	●	●	
2014	Chevrolet	Tahoe	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tahoe	Body Control Module	●	●	●	●	●	●	S001 S053
2014	Chevrolet	Tahoe	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2014	Chevrolet	Tahoe	HVAC Control Module	●	●	●	●	●	●	S052 S032 S033
2014	Chevrolet	Tahoe	Left Side Object Detection Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tahoe	Parking Assist Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tahoe	Rear Seat Heating Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tahoe	Right Side Object Detection Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tahoe	Seat Memory Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tahoe	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tahoe	Personal Audio Link Control Module	●	●	●	○	○	●	S056
2014	Chevrolet	Tahoe	Amplifier	●	●	●	●	○	○	

2014	Chevrolet	Tahoe	Rear Audio Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tahoe	Liftgate Control Module	●	●	●	●	○	●	S049
2014	Chevrolet	Tahoe	Suspension Control Module	●	●	●	●	●	●	
2014	Chevrolet	Tahoe	Assist Step Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tahoe	Electronic Brake Control Module	●	●	●	●	●	●	S034 S036
2014	Chevrolet	Tahoe	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Chevrolet	Tavera	Engine Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tracker	Instrument Cluster	●	●	●	●	●	●	S022
2014	Chevrolet	Tracker	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2014	Chevrolet	Tracker	Transmission Control Module	●	●	●	●	●	●	S023
2014	Chevrolet	Tracker	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Tracker	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tracker	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Chevrolet	Tracker	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2014	Chevrolet	Tracker	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2014	Chevrolet	Tracker	Passenger Presence Module	●	●	●	●	○	●	S043

2014	Chevrolet	Tracker	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tracker	HVAC Control Module	●	●	●	●	●	○	
2014	Chevrolet	Tracker	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Tracker	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Tracker	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2014	Chevrolet	Tracker	Electronic Brake Control Module	●	●	●	●	●	●	S035
2014	Chevrolet	Tracker	Power Steering Control Module	●	●	●	●	○	●	
2014	Chevrolet	Tracker	Rear Differential Clutch Control Module	●	●	●	●	●	●	
2014	Chevrolet	Tracker	Radio	●	●	●	●	●	○	
2014	Chevrolet	Trailblazer	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2014	Chevrolet	Trailblazer	Transmission Control Module	●	●	●	●	●	●	S048
2014	Chevrolet	Trailblazer	Transfer Case Control Module	●	●	●	●	●	●	S080
2014	Chevrolet	Trailblazer	Instrument Cluster	●	●	●	●	●	●	S022
2014	Chevrolet	Trailblazer	Trailer Interface Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Trailblazer	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S044 S001 S029 S025 S030
2014	Chevrolet	Trailblazer	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2014	Chevrolet	Trailblazer	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036

2014	Chevrolet	Traverse	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Chevrolet	Traverse	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Chevrolet	Traverse	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Traverse	Right Side Object Detection Control Module	●	●	●	○	●	○	
2014	Chevrolet	Traverse	Seat Memory Control Module	●	●	●	●	●	○	
2014	Chevrolet	Traverse	Rear Audio Control Module	●	●	●	●	●	○	
2014	Chevrolet	Traverse	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S094 S030
2014	Chevrolet	Traverse	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034 S036
2014	Chevrolet	Traverse	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2014	Chevrolet	Traverse	HVAC Control Module	●	●	●	●	●	●	S052 S032 S033
2014	Chevrolet	Traverse	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2014	Chevrolet	Traverse	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Chevrolet	Traverse	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2014	Chevrolet	Traverse	Personal Audio Link Control Module	●	●	●	○	○	●	S056
2014	Chevrolet	Trax	Instrument Cluster	●	●	●	●	●	●	S022
2014	Chevrolet	Trax	Transmission Control Module	●	●	●	●	●	●	S023

2014	Chevrolet	Trax	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	Chevrolet	Trax	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2014	Chevrolet	Trax	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2014	Chevrolet	Trax	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Chevrolet	Trax	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2014	Chevrolet	Trax	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2014	Chevrolet	Trax	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Chevrolet	Trax	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Trax	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2014	Chevrolet	Trax	Rear Differential Clutch Control Module	●	●	●	●	●	●	
2014	Chevrolet	Trax	Electronic Brake Control Module	●	●	●	●	●	●	S035
2014	Chevrolet	Trax	Power Steering Control Module	●	●	●	●	○	●	
2014	Chevrolet	Trax	Radio	●	●	●	●	●	○	
2014	Chevrolet	Trax	HVAC Control Module	●	●	●	●	●	○	
2014	Chevrolet	Trax	Front Seat Heating Control Module	●	●	●	●	●	○	

2014	Chevrolet	Volt	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Chevrolet	Volt	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Chevrolet	Volt	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Chevrolet	Volt	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Chevrolet	Volt	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Chevrolet	Volt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2014	Chevrolet	Volt	Passenger Presence Module	●	●	●	●	○	●	S043
2014	Chevrolet	Volt	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Chevrolet	Volt	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2014	Chevrolet	Volt	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2014	Chevrolet	Volt	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022
2014	Chevrolet	Volt	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Chevrolet	Volt	Radio	●	●	●	●	●	○	
2014	Chevrolet	Volt	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Chevrolet	Volt	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Daewoo	Alpheon	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001

2014	Daewoo	Alpheon	Drive Motor Control Module	●	●	●	●	○	○	
2014	Daewoo	Alpheon	Battery Energy Control Module	○	○	●	●	○	○	
2014	Daewoo	Alpheon	Transmission Control Module	●	●	●	●	●	●	S023
2014	Daewoo	Alpheon	Headlamp Control Module	●	●	●	●	●	●	S002
2014	Daewoo	Alpheon	Instrument Cluster	●	●	●	●	●	●	S022
2014	Daewoo	Alpheon	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Daewoo	Alpheon	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Daewoo	Alpheon	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2014	Daewoo	Alpheon	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S030
2014	Daewoo	Alpheon	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Daewoo	Alpheon	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Daewoo	Alpheon	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Daewoo	Alpheon	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2014	Daewoo	Alpheon	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Daewoo	Alpheon	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Daewoo	Alpheon	Suspension Control Module	●	●	●	●	●	●	S038

2014	Daewoo	Alpheon	Power Steering Control Module	●	●	●	●	○	●	S047
2014	Daewoo	Alpheon	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Daewoo	Alpheon	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Daewoo	Alpheon	Rear Seat Heating Control Module	●	●	●	●	●	○	
2014	Daewoo	Alpheon	Seat Memory Control Module	●	●	●	●	●	●	S031
2014	Daewoo	Alpheon	Radio	●	●	●	●	●	○	
2014	Daewoo	Alpheon	Rear Audio Control Module	●	●	●	●	●	○	
2014	Daewoo	Alpheon	Mobile Telephone Control Module	●	●	●	●	●	●	
2014	Daewoo	Gentra	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	○	
2014	Daewoo	Gentra	Transmission Control Module	●	●	●	●	●	●	S023
2014	Daewoo	Gentra	Engine Control Module	●	●	●	●	●	●	S026 S044 S045 S025
2014	Daewoo	Gentra	Fuel Injector Control Module	●	●	●	●	●	○	
2014	Daewoo	Gentra	Electronic Brake Control Module	●	●	●	●	●	○	
2014	GMC	Acadia	Transmission Control Module	●	●	●	●	●	●	S048
2014	GMC	Acadia	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2014	GMC	Acadia	Body Control Module	●	●	●	●	●	●	S001 S053
2014	GMC	Acadia	Instrument Cluster	●	●	●	●	●	○	
2014	GMC	Acadia	Head-Up Display Module	●	●	●	●	●	○	
2014	GMC	Acadia	Digital Radio Receiver Control Module	●	●	●	●	●	○	

2014	GMC	Acadia	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2014	GMC	Acadia	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2014	GMC	Acadia	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	GMC	Acadia	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2014	GMC	Acadia	Personal Audio Link Control Module	●	●	●	○	○	●	S056
2014	GMC	Savana	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S030
2014	GMC	Savana	Transmission Control Module	●	●	●	●	●	●	S048
2014	GMC	Savana	Electronic Brake Control Module	●	●	●	●	●	●	S036
2014	GMC	Savana	Body Control Module	●	●	●	●	●	●	S001 S053
2014	GMC	Savana	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	S024 S053
2014	GMC	Savana	Passenger Presence Module	●	●	●	●	○	●	
2014	GMC	Savana	Rollover Sensor Module	●	●	●	●	○	●	
2014	GMC	Savana	Instrument Cluster	●	●	●	●	●	○	
2014	GMC	Savana	Chime Alarm Control Module	●	●	●	○	●	○	
2014	GMC	Savana	Radio	●	●	●	●	●	●	
2014	GMC	Savana	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2014	GMC	Savana	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	GMC	Savana	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020

2014	GMC	Savana	Theft Deterrent Module	●	●	●	●	○	○	
2014	GMC	Savana	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	GMC	Savana	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	GMC	Savana	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141
2014	GMC	Sierra	Transfer Case Control Module	●	●	●	●	●	●	S080
2014	GMC	Sierra	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	GMC	Sierra	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S071 S057 S027 S028 S029 S025 S030
2014	GMC	Sierra	Transmission Control Module	●	●	●	●	●	●	S048
2014	GMC	Sierra	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	GMC	Sierra	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2014	GMC	Sierra	Instrument Cluster	●	●	●	●	●	●	S022
2014	GMC	Sierra	Passenger Presence Module	●	●	●	●	●	●	S043
2014	GMC	Sierra	Power Steering Control Module	●	●	●	●	●	●	S064
2014	GMC	Sierra	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036 S069
2014	GMC	Sierra	Frontview Camera Module	●	●	●	●	○	●	S051

2014	GMC	Sierra	Parking Assist Control Module	●	●	●	●	●	●	S081
2014	GMC	Sierra	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2014	GMC	Sierra	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	GMC	Sierra	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	GMC	Sierra	Radio	●	●	●	●	●	●	S063 S064
2014	GMC	Sierra HD	Transfer Case Control Module	●	●	●	●	●	●	S080
2014	GMC	Sierra HD	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2014	GMC	Sierra HD	Transmission Control Module	●	●	●	●	●	●	S048
2014	GMC	Sierra HD	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	GMC	Sierra HD	Trailer Brake Control Module	●	●	●	●	●	○	
2014	GMC	Sierra HD	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2014	GMC	Sierra HD	Radio	●	●	●	●	●	○	
2014	GMC	Sierra HD	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2014	GMC	Sierra HD	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2014	GMC	Sierra HD	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141
2014	GMC	Sierra HD	Parking Assist Control Module	●	●	●	●	●	○	
2014	GMC	Sierra HD	Seat Memory Control Module	●	●	●	●	●	○	

2014	GMC	Sierra HD	Theft Deterrent Module	●	●	●	●	○	○	
2014	GMC	Sierra HD	Instrument Cluster	●	●	●	●	●	○	
2014	GMC	Sierra HD	HVAC Control Module	●	●	●	●	●	●	S052 S032 S033
2014	GMC	Sierra HD	Personal Audio Link Control Module	●	●	●	○	○	●	S056
2014	GMC	Sierra HD	Amplifier	●	●	●	●	○	○	
2014	GMC	Sierra HD	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2014	GMC	Sierra HD	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2014	GMC	Sierra HD	Rear Audio Control Module	●	●	●	●	●	○	
2014	GMC	Sierra HD	Electronic Brake Control Module	●	●	●	●	●	●	S036
2014	GMC	Sierra HD	Suspension Control Module	●	●	●	●	●	●	
2014	GMC	Sierra HD	Body Control Module	●	●	●	●	●	●	S001 S053
2014	GMC	Sierra HD	Fuel Injector Control Module	●	●	●	●	●	○	
2014	GMC	Sierra HD	Power Take-Off Control Module	●	●	●	●	●	●	S158 S159
2014	GMC	Terrain	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2014	GMC	Terrain	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2014	GMC	Terrain	Power Steering Control Module	●	●	●	●	○	●	
2014	GMC	Terrain	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	GMC	Terrain	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039

2014	GMC	Terrain	Liftgate Control Module	●	●	●	●	●	●	S049
2014	GMC	Terrain	Transmission Control Module	●	●	●	●	●	●	S048
2014	GMC	Terrain	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2014	GMC	Terrain	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2014	GMC	Terrain	Passenger Presence Module	●	●	●	●	○	●	S043
2014	GMC	Terrain	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S046
2014	GMC	Terrain	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2014	GMC	Terrain	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	GMC	Terrain	Frontview Camera Module	●	●	●	●	○	●	S051
2014	GMC	Terrain	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	GMC	Terrain	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	GMC	Terrain	Right Side Object Detection Control Module	●	●	●	○	●	○	
2014	GMC	Terrain	Seat Memory Control Module	●	●	●	●	●	●	S031
2014	GMC	Terrain	Instrument Cluster	●	●	●	●	●	●	S022
2014	GMC	Terrain	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	GMC	Terrain	Radio	●	●	●	●	●	○	
2014	GMC	Yukon	Instrument Cluster	●	●	●	●	●	○	

2014	GMC	Yukon	Theft Deterrent Module	●	●	●	●	○	○	
2014	GMC	Yukon	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2014	GMC	Yukon	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2014	GMC	Yukon	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2014	GMC	Yukon	Transfer Case Control Module	●	●	●	●	●	●	S080
2014	GMC	Yukon	Liftgate Control Module	●	●	●	●	○	●	S049
2014	GMC	Yukon	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	GMC	Yukon	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2014	GMC	Yukon	Passenger Presence Module	●	●	●	●	○	○	
2014	GMC	Yukon	Transmission Control Module	●	●	●	●	●	●	S048
2014	GMC	Yukon	Chassis Control Module	●	●	●	●	●	●	S025
2014	GMC	Yukon	Body Control Module	●	●	●	●	●	●	S001 S053
2014	GMC	Yukon	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2014	GMC	Yukon	HVAC Control Module	●	●	●	●	●	●	S052 S032 S033
2014	GMC	Yukon	Left Side Object Detection Control Module	●	●	●	●	●	○	
2014	GMC	Yukon	Parking Assist Control Module	●	●	●	●	●	○	
2014	GMC	Yukon	Rear Seat Heating Control Module	●	●	●	●	●	○	

2014	GMC	Yukon	Right Side Object Detection Control Module	●	●	●	●	●	○	
2014	GMC	Yukon	Seat Memory Control Module	●	●	●	●	●	○	
2014	GMC	Yukon	Radio	●	●	●	●	●	●	
2014	GMC	Yukon	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2014	GMC	Yukon	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2014	GMC	Yukon	Amplifier	●	●	●	●	○	○	
2014	GMC	Yukon	Personal Audio Link Control Module	●	●	●	○	○	●	S056
2014	GMC	Yukon	Rear Audio Control Module	●	●	●	●	●	○	
2014	GMC	Yukon	Suspension Control Module	●	●	●	●	●	●	
2014	GMC	Yukon	Assist Step Control Module	●	●	●	●	●	○	
2014	GMC	Yukon	Electronic Brake Control Module	●	●	●	●	●	●	S034 S036
2014	GMC	Yukon	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	GMC	Yukon XL	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2014	GMC	Yukon XL	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2014	GMC	Yukon XL	Passenger Presence Module	●	●	●	●	○	○	
2014	GMC	Yukon XL	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020

2014	GMC	Yukon XL	Body Control Module	●	●	●	●	●	●	S001 S053
2014	GMC	Yukon XL	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2014	GMC	Yukon XL	Transfer Case Control Module	●	●	●	●	●	●	S080
2014	GMC	Yukon XL	Instrument Cluster	●	●	●	●	●	○	
2014	GMC	Yukon XL	Theft Deterrent Module	●	●	●	●	○	○	
2014	GMC	Yukon XL	Chassis Control Module	●	●	●	●	●	●	S025
2014	GMC	Yukon XL	HVAC Control Module	●	●	●	●	●	●	S052 S032 S033
2014	GMC	Yukon XL	Left Side Object Detection Control Module	●	●	●	●	●	○	
2014	GMC	Yukon XL	Parking Assist Control Module	●	●	●	●	●	○	
2014	GMC	Yukon XL	Rear Seat Heating Control Module	●	●	●	●	●	○	
2014	GMC	Yukon XL	Right Side Object Detection Control Module	●	●	●	●	●	○	
2014	GMC	Yukon XL	Seat Memory Control Module	●	●	●	●	●	○	
2014	GMC	Yukon XL	Driver Door Switch Panel Control Module	●	●	●	●	●	○	
2014	GMC	Yukon XL	Passenger Door Switch Panel Control Module	●	●	●	●	●	○	
2014	GMC	Yukon XL	Radio	●	●	●	●	●	●	
2014	GMC	Yukon XL	Personal Audio Link Control Module	●	●	●	○	○	●	S056
2014	GMC	Yukon XL	Amplifier	●	●	●	●	○	○	
2014	GMC	Yukon XL	Rear Audio Control Module	●	●	●	●	●	○	
2014	GMC	Yukon XL	Digital Radio Receiver Control Module	●	●	●	●	●	○	
2014	GMC	Yukon XL	Liftgate Control Module	●	●	●	●	○	●	S049

2014	GMC	Yukon XL	Transmission Control Module	●	●	●	●	●	●	S048
2014	GMC	Yukon XL	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2014	GMC	Yukon XL	Suspension Control Module	●	●	●	●	●	●	
2014	GMC	Yukon XL	Assist Step Control Module	●	●	●	●	●	○	
2014	GMC	Yukon XL	Electronic Brake Control Module	●	●	●	●	●	●	S034 S036
2014	GMC	Yukon XL	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Holden	Barina	Transmission Control Module	●	●	●	●	●	●	S023
2014	Holden	Barina	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Holden	Barina	Instrument Cluster	●	●	●	●	●	●	S022
2014	Holden	Barina	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2014	Holden	Barina	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2014	Holden	Barina	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Holden	Barina	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2014	Holden	Barina	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Holden	Barina	HVAC Control Module	●	●	●	●	●	○	
2014	Holden	Barina	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Holden	Barina	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036

2014	Holden	Barina	Electronic Brake Control Module	●	●	●	●	●	●	S035
2014	Holden	Barina	Power Steering Control Module	●	●	●	●	○	●	
2014	Holden	Barina	Radio	●	●	●	●	●	○	
2014	Holden	Barina Spark	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2014	Holden	Barina Spark	Transmission Control Module	●	●	●	●	●	●	S048
2014	Holden	Barina Spark	Instrument Cluster	●	●	●	●	●	●	S022
2014	Holden	Barina Spark	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2014	Holden	Barina Spark	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2014	Holden	Barina Spark	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Holden	Barina Spark	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Holden	Barina Spark	Electronic Brake Control Module	●	●	●	●	●	●	S035
2014	Holden	Barina Spark	Power Steering Control Module	●	●	●	●	○	●	
2014	Holden	Barina Spark	Radio	●	●	●	●	●	○	
2014	Holden	Caprice	Transmission Control Module	●	●	●	●	●	●	S048
2014	Holden	Caprice	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Holden	Caprice	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Holden	Caprice	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Holden	Caprice	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030

2014	Holden	Caprice	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2014	Holden	Caprice	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Holden	Caprice	Instrument Cluster	●	●	●	●	●	●	S022 S097
2014	Holden	Caprice	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Holden	Caprice	Right Side Object Detection Control Module	●	●	●	○	●	○	
2014	Holden	Caprice	Seat Memory Control Module - Driver	●	●	●	●	●	○	
2014	Holden	Caprice	Radio	●	●	●	●	●	○	
2014	Holden	Caprice	Radio Controls	●	●	●	●	●	●	S022
2014	Holden	Caprice	Head-Up Display Module	●	●	●	●	●	○	
2014	Holden	Caprice	HVAC Controls	●	●	●	●	●	●	
2014	Holden	Caprice	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Holden	Caprice	HVAC Control Module	●	●	●	●	●	●	S033
2014	Holden	Caprice	Headlamp Control Module	●	●	●	●	●	●	S002
2014	Holden	Caprice	Suspension Control Module	●	●	●	●	●	●	S076 S077 S038
2014	Holden	Caprice	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2014	Holden	Caprice	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Holden	Caprice	Trailer Interface Control Module	●	●	●	●	●	●	

2014	Holden	Caprice	Fuel Injector Control Module	○	○	●	●	●	○	
2014	Holden	Caprice	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2014	Holden	Caprice	Power Steering Control Module	●	●	●	●	○	●	
2014	Holden	Caprice	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Holden	Captiva 5	Body Control Module	●	●	●	●	●	●	S013 S001
2014	Holden	Captiva 5	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S044 S029 S025 S058
2014	Holden	Captiva 5	Transmission Control Module	●	●	●	●	●	●	S023
2014	Holden	Captiva 5	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Holden	Captiva 5	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2014	Holden	Captiva 5	Mobile Telephone Control Module	●	●	●	○	●	●	
2014	Holden	Captiva 5	Radio	●	●	●	●	●	●	S187 S187 S187 S187 S179 S179 S179 S179 S191 S191
2014	Holden	Captiva 5	HVAC Control Module	●	●	●	○	●	○	
2014	Holden	Captiva 5	Headlamp Control Module	●	●	●	●	●	●	S002 S179
2014	Holden	Captiva 5	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2014	Holden	Captiva 5	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2014	Holden	Captiva 5	Theft Deterrent Module	●	●	●	●	○	○	
2014	Holden	Captiva 5	Instrument Cluster	●	●	●	●	●	○	
2014	Holden	Captiva 5	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Holden	Captiva 5	Parking Assist Control Module	●	●	●	●	●	●	

2014	Holden	Captiva 5	Electronic Brake Control Module	●	●	●	●	●	●	S035
2014	Holden	Captiva 5	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S053
2014	Holden	Captiva 5	Info Display Module	●	●	●	●	●	●	S187 S187 S187 S187 S188 S189 S022 S022 S190 S190 S190 S190 S179 S179 S179
2014	Holden	Captiva 7	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2014	Holden	Captiva 7	Transmission Control Module	●	●	●	●	●	●	S023
2014	Holden	Captiva 7	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Holden	Captiva 7	HVAC Control Module	●	●	●	○	●	○	
2014	Holden	Captiva 7	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2014	Holden	Captiva 7	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2014	Holden	Captiva 7	Body Control Module	●	●	●	●	●	●	S013 S001 S053
2014	Holden	Captiva 7	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2014	Holden	Captiva 7	Remote Control Door Lock Receiver	●	●	●	●	●	●	S192 S019 S021 S020
2014	Holden	Captiva 7	Theft Deterrent Module	●	●	●	●	○	○	
2014	Holden	Captiva 7	Headlamp Control Module	●	●	●	●	●	●	S002 S179
2014	Holden	Captiva 7	Instrument Cluster	●	●	●	●	●	○	
2014	Holden	Captiva 7	Electronic Brake Control Module	●	●	●	●	●	●	S035 S036
2014	Holden	Colorado	Transmission Control Module	●	●	●	●	●	●	S048
2014	Holden	Colorado	Transfer Case Control Module	●	●	●	●	●	●	S080

2014	Holden	Colorado	Instrument Cluster	●	●	●	●	●	●	S022
2014	Holden	Colorado	Trailer Interface Control Module	●	●	●	●	●	●	S022
2014	Holden	Colorado	Engine Control Module	●	●	●	●	●	●	S001 S103 S169 S109 S181 S182 S122 S113 S029 S183 S184 S082 S115 S118
2014	Holden	Colorado	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2014	Holden	Colorado	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Holden	Colorado	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Holden	Colorado	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2014	Holden	Colorado	Electronic Brake Control Module	●	●	●	●	●	●	S035 S070
2014	Holden	Colorado	Radio	●	●	●	●	●	○	
2014	Holden	Colorado	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Holden	Colorado 7	Transfer Case Control Module	●	●	●	●	●	●	S080
2014	Holden	Colorado 7	Instrument Cluster	●	●	●	●	●	●	S022
2014	Holden	Colorado 7	Trailer Interface Control Module	●	●	●	●	●	●	S022
2014	Holden	Colorado 7	Engine Control Module	●	●	●	●	●	●	S001 S103 S169 S109 S181 S182 S122 S113 S029 S183 S184 S082 S115 S118
2014	Holden	Colorado 7	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024

2014	Holden	Colorado 7	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Holden	Colorado 7	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Holden	Colorado 7	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Holden	Colorado 7	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Holden	Colorado 7	Electronic Brake Control Module	●	●	●	●	●	●	S035 S070
2014	Holden	Colorado 7	Transmission Control Module	●	●	●	●	●	●	S048
2014	Holden	Colorado 7	Radio	●	●	●	●	●	○	
2014	Holden	Commodore	Transmission Control Module	●	●	●	●	●	●	S048
2014	Holden	Commodore	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Holden	Commodore	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Holden	Commodore	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Holden	Commodore	Trailer Interface Control Module	●	●	●	●	●	●	
2014	Holden	Commodore	Power Steering Control Module	●	●	●	●	○	●	
2014	Holden	Commodore	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2014	Holden	Commodore	Headlamp Control Module	●	●	●	●	●	●	S002
2014	Holden	Commodore	Fuel Injector Control Module	○	○	●	●	●	○	

2014	Holden	Commodore	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Holden	Cruze	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Holden	Cruze	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Holden	Cruze	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Holden	Cruze	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2014	Holden	Cruze	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2014	Holden	Cruze	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Holden	Cruze	Transmission Control Module	●	●	●	●	●	●	S023
2014	Holden	Cruze	Engine Control Module	●	●	●	●	●	●	S044 S026 S105 S108 S169 S170 S109 S110 S171 S111 S045 S172 S173 S112 S122 S113 S029 S115 S116 S174 S175 S176 S177
2014	Holden	Cruze	Instrument Cluster	●	●	●	●	●	●	S022
2014	Holden	Cruze	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Holden	Cruze	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2014	Holden	Cruze	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2014	Holden	Cruze	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Holden	Cruze	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036

2014	Holden	Cruze	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2014	Holden	Cruze	Trailer Interface Control Module	●	●	●	●	●	●	S022
2014	Holden	Cruze	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Holden	Cruze	Radio	●	●	●	●	●	○	
2014	Holden	Cruze	Multimedia Player Interface Module	●	●	●	●	○	●	
2014	Holden	Malibu	Suspension Control Module	●	●	●	●	●	○	
2014	Holden	Malibu	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2014	Holden	Malibu	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2014	Holden	Malibu	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2014	Holden	Malibu	Transmission Control Module	●	●	●	●	●	●	S023
2014	Holden	Malibu	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Holden	Malibu	Headlamp Control Module	●	●	●	●	●	●	S002
2014	Holden	Malibu	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2014	Holden	Malibu	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Holden	Malibu	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Holden	Malibu	Instrument Cluster	●	●	●	●	●	●	S022

2014	Holden	Malibu	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Holden	Malibu	Radio	●	●	●	●	●	○	
2014	Holden	Malibu	Multimedia Player Interface Module	●	●	●	●	○	●	
2014	Holden	Malibu	Parking Brake Control Module	●	●	●	●	●	●	S037
2014	Holden	Malibu	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Holden	Malibu	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Holden	Malibu	Rear Seat Heating Control Module	●	●	●	●	●	○	
2014	Holden	Malibu	Seat Memory Control Module	●	●	●	●	●	●	S031
2014	Holden	Malibu	Left Side Object Detection Control Module	●	●	●	○	●	○	
2014	Holden	Malibu	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2014	Holden	Malibu	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2014	Holden	Malibu	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Holden	Malibu	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2014	Holden	Malibu	Trailer Interface Control Module	●	●	●	●	●	●	
2014	Holden	Trax	Transmission Control Module	●	●	●	●	●	●	S023
2014	Holden	Trax	Instrument Cluster	●	●	●	●	●	●	S022
2014	Holden	Trax	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025

2014	Holden	Trax	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2014	Holden	Trax	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Holden	Trax	Rear Differential Clutch Control Module	●	●	●	●	●	●	
2014	Holden	Trax	Electronic Brake Control Module	●	●	●	●	●	●	S035
2014	Holden	Trax	Power Steering Control Module	●	●	●	●	○	●	
2014	Holden	Trax	Radio	●	●	●	●	●	○	
2014	Holden	Trax	HVAC Control Module	●	●	●	●	●	○	
2014	Holden	Trax	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Holden	Trax	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Holden	Trax	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S036 S036 S036
2014	Holden	Volt	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2014	Holden	Volt	Battery Charger Control Module	○	○	●	●	○	○	
2014	Holden	Volt	Battery Energy Control Module	○	○	●	●	○	○	
2014	Holden	Volt	Coolant Heater Control Module	●	●	●	○	○	○	
2014	Holden	Volt	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S083 S084 S085 S086 S087 S088 S089
2014	Holden	Volt	Hybrid Powertrain Control Module	●	●	●	●	●	○	
2014	Holden	Volt	Drive Motor Control Module 1	●	●	●	●	○	○	

2014	Holden	Volt	Drive Motor Control Module 2	●	●	●	●	○	○	
2014	Holden	Volt	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	
2014	Holden	Volt	Transmission Control Module	●	●	●	●	●	○	
2014	Holden	Volt	Instrument Cluster	●	●	●	●	●	●	S022 S022
2014	Holden	Volt	Telematics Communication Interface Control Module	●	●	●	●	○	○	
2014	Holden	Volt	Chassis Control Module	●	●	●	●	●	●	S025 S066 S067
2014	Holden	Volt	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S091
2014	Holden	Volt	Steering Column Lock Control Module	●	●	●	●	○	●	
2014	Holden	Volt	Body Control Module	●	●	●	●	●	●	S003 S004 S005 S006 S007 S008 S009 S010 S011 S012 S013 S001 S014 S015 S016 S017 S018 S019 S020 S021 S021
2014	Holden	Volt	Keyless Entry Control Module	●	●	●	●	●	○	
2014	Holden	Volt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2014	Holden	Volt	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2014	Holden	Volt	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2014	Holden	Volt	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2014	Holden	Volt	HVAC Control Module	●	●	●	●	●	●	S032 S033
2014	Holden	Volt	Radio	●	●	●	●	●	○	

2014	Holden	Volt	Front Seat Heating Control Module	●	●	●	●	●	○	
2014	Holden	Volt	Parking Assist Control Module	●	●	●	●	●	●	S022
2014	Holden	Volt	Electronic Brake Control Module	●	●	●	●	●	●	S092 S036 S036 S036
2014	Holden	Volt	Parking Brake Control Module	●	●	●	●	●	●	S037
2013	Buick	Encore	Transmission Control Module	●	●	●	●	●	●	S023
2013	Buick	Encore	Instrument Cluster	●	●	●	●	●	●	S022
2013	Buick	Encore	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Buick	Encore	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Buick	Encore	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Buick	Encore	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2013	Buick	Encore	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Buick	Encore	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2013	Buick	Encore	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Buick	Encore	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Buick	Encore	Electronic Brake Control Module	●	●	●	●	●	●	S035

2013	Buick	Encore	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2013	Buick	Encore	Power Steering Control Module	●	●	●	●	○	●	
2013	Buick	Encore	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Buick	Encore	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Buick	Encore	Rear Differential Clutch Control Module	●	●	●	●	●	●	
2013	Buick	Encore	Radio	●	●	●	●	●	○	
2013	Buick	Encore	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2013	Buick	Encore	Seat Memory Control Module	●	●	●	●	●	●	S031
2013	Buick	LaCrosse	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S030
2013	Buick	LaCrosse	Fuel Injector Control Module	●	●	●	●	●	○	
2013	Buick	LaCrosse	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Buick	LaCrosse	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2013	Buick	LaCrosse	Transmission Control Module	●	●	●	●	●	●	S057 S082
2013	Buick	LaCrosse	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2013	Buick	LaCrosse	Drive Motor Control Module	●	●	●	●	○	○	
2013	Buick	LaCrosse	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2013	Buick	LaCrosse	Parking Brake Control Module	●	●	●	●	●	●	S037

2013	Buick	LaCrosse	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S070 S036
2013	Buick	LaCrosse	Power Steering Control Module	●	●	●	●	○	●	
2013	Buick	LaCrosse	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Buick	LaCrosse	Suspension Control Module	●	●	●	●	●	○	
2013	Buick	LaCrosse	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Buick	LaCrosse	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2013	Buick	LaCrosse	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Buick	LaCrosse	Instrument Cluster	●	●	●	●	●	●	S022
2013	Buick	LaCrosse	Head-Up Display Module	●	●	●	●	●	○	
2013	Buick	LaCrosse	Headlamp Control Module	●	●	●	●	●	○	
2013	Buick	LaCrosse	Radio	●	●	●	●	●	○	
2013	Buick	LaCrosse	Multimedia Player Interface Module	●	●	●	●	○	●	
2013	Buick	LaCrosse	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Buick	LaCrosse	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Buick	LaCrosse	Seat Memory Control Module	●	●	●	●	●	●	S031
2013	Buick	LaCrosse	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Buick	LaCrosse	Keyless Entry Control Module	●	●	●	●	●	○	

2013	Buick	LaCrosse	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Buick	LaCrosse	Steering Column Lock Control Module	●	●	●	●	○	●	
2013	Buick	Regal	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S030
2013	Buick	Regal	Fuel Injector Control Module	●	●	●	●	●	○	
2013	Buick	Regal	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Buick	Regal	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2013	Buick	Regal	Transmission Control Module	●	●	●	●	●	●	S048
2013	Buick	Regal	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2013	Buick	Regal	Drive Motor Control Module	●	●	●	●	○	○	
2013	Buick	Regal	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2013	Buick	Regal	Parking Brake Control Module	●	●	●	●	●	●	S037
2013	Buick	Regal	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Buick	Regal	Power Steering Control Module	●	●	●	●	○	●	
2013	Buick	Regal	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Buick	Regal	Suspension Control Module	●	●	●	●	●	○	
2013	Buick	Regal	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021

2013	Buick	Regal	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2013	Buick	Regal	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Buick	Regal	Instrument Cluster	●	●	●	●	●	●	S022
2013	Buick	Regal	Radio	●	●	●	●	●	○	
2013	Buick	Regal	Multimedia Player Interface Module	●	●	●	●	○	●	
2013	Buick	Regal	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Buick	Regal	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Buick	Verano	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Buick	Verano	Transmission Control Module	●	●	●	●	●	●	S057 S082
2013	Buick	Verano	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2013	Buick	Verano	Power Steering Control Module	●	●	●	●	○	●	
2013	Buick	Verano	Instrument Cluster	●	●	●	●	●	●	S022
2013	Buick	Verano	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Buick	Verano	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Buick	Verano	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Buick	Verano	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Buick	Verano	Left Side Object Detection Control Module	●	●	●	○	●	○	

2013	Buick	Verano	Right Side Object Detection Control Module	●	●	●	○	●	○	
2013	Buick	Verano	Parking Brake Control Module	●	●	●	●	●	●	S037
2013	Buick	Verano	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Buick	Verano	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Buick	Verano	Keyless Entry Control Module	●	●	●	●	●	○	
2013	Buick	Verano	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Buick	Verano	Radio	●	●	●	●	●	○	
2013	Buick	Verano	Multimedia Player Interface Module	●	●	●	●	○	●	
2013	Buick	Verano	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S162 S029 S025 S030 S001
2013	Buick	Verano	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Buick	Verano	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Cadillac	ATS	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S029 S025 S030
2013	Cadillac	ATS	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Cadillac	ATS	Transmission Control Module	●	●	●	●	●	●	S048
2013	Cadillac	ATS	Transfer Case Control Module	●	●	●	●	●	●	S072 S073

2013	Cadillac	ATS	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2013	Cadillac	ATS	Parking Brake Control Module	●	●	●	●	●	●	S037
2013	Cadillac	ATS	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Cadillac	ATS	Power Steering Control Module	●	●	●	●	○	●	S075
2013	Cadillac	ATS	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Cadillac	ATS	Suspension Control Module	●	●	●	●	●	●	S076 S077 S077 S038
2013	Cadillac	ATS	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Cadillac	ATS	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2013	Cadillac	ATS	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Cadillac	ATS	Instrument Cluster	●	●	●	●	●	●	S022
2013	Cadillac	ATS	Headlamp Control Module	●	●	●	●	●	●	S002
2013	Cadillac	ATS	Radio	●	●	●	●	●	●	S063 S064
2013	Cadillac	ATS	Amplifier	●	●	●	●	○	○	
2013	Cadillac	ATS	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2013	Cadillac	ATS	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Cadillac	ATS	HVAC Control Module	●	●	●	●	●	●	S032 S033

2013	Cadillac	ATS	Seat Memory Control Module	●	●	●	●	●	●	S031
2013	Cadillac	ATS	Keyless Entry Control Module	●	●	●	●	●	○	
2013	Cadillac	ATS	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Cadillac	ATS	Steering Column Lock Control Module	●	●	●	●	○	●	
2013	Cadillac	ATS	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2013	Cadillac	ATS	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2013	Cadillac	ATS	Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2013	Cadillac	ATS	Left Side Object Detection Control Module	●	●	●	○	●	○	
2013	Cadillac	ATS	Right Side Object Detection Control Module	●	●	●	○	●	○	
2013	Cadillac	ATS	Trailer Interface Control Module	●	●	●	●	●	●	S022
2013	Cadillac	ATS	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2013	Cadillac	ATS	Long Range Radar Sensor Module	●	●	●	●	○	●	S061
2013	Cadillac	ATS	Active Safety Control Module	●	●	●	●	●	○	
2013	Cadillac	SRX	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S094 S046
2013	Cadillac	SRX	Transmission Control Module	●	●	●	●	●	●	S048

2013	Cadillac	SRX	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2013	Cadillac	SRX	Parking Brake Control Module	●	●	●	●	●	●	S037
2013	Cadillac	SRX	Instrument Cluster	●	●	●	●	●	●	S022
2013	Cadillac	SRX	Headlamp Control Module	●	●	●	●	●	●	
2013	Cadillac	SRX	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Cadillac	SRX	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Cadillac	SRX	Seat Memory Control Module	●	●	●	●	●	●	S031
2013	Cadillac	SRX	Rear Seat Heating Control Module	●	●	●	●	●	○	
2013	Cadillac	SRX	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Cadillac	SRX	Steering Column Lock Control Module	●	●	●	●	○	●	
2013	Cadillac	SRX	Left Side Object Detection Control Module	●	●	●	○	●	○	
2013	Cadillac	SRX	Right Side Object Detection Control Module	●	●	●	○	●	○	
2013	Cadillac	SRX	Trailer Interface Control Module	●	●	●	●	●	●	S022
2013	Cadillac	SRX	Liftgate Control Module	●	●	●	●	●	●	S049
2013	Cadillac	SRX	Radio	●	●	●	●	●	●	S063 S064
2013	Cadillac	SRX	Amplifier	●	●	●	●	○	○	
2013	Cadillac	SRX	Human Machine Interface Control Module	●	●	●	●	●	●	S064

2013	Cadillac	SRX	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Cadillac	SRX	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Cadillac	SRX	Keyless Entry Control Module	●	●	●	●	●	○	
2013	Cadillac	SRX	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2013	Cadillac	SRX	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Cadillac	SRX	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2013	Cadillac	SRX	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2013	Cadillac	SRX	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Cadillac	SRX	Suspension Control Module	●	●	●	●	●	○	
2013	Cadillac	SRX	Long Range Radar Sensor Module	●	●	●	●	○	●	S061
2013	Cadillac	SRX	Media Disc Player	●	●	●	●	●	○	
2013	Cadillac	SRX	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2013	Cadillac	SRX	Right Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2013	Cadillac	SRX	Rear Short Range Radar Sensor Module	●	●	●	●	○	○	
2013	Cadillac	XTS	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2013	Cadillac	XTS	Fuel Pump Control Module	●	●	●	●	●	●	S025

2013	Cadillac	XTS	Transmission Control Module	●	●	●	●	●	●	S048
2013	Cadillac	XTS	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2013	Cadillac	XTS	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2013	Cadillac	XTS	Parking Brake Control Module	●	●	●	●	●	●	S037
2013	Cadillac	XTS	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Cadillac	XTS	Power Steering Control Module	●	●	●	●	○	●	
2013	Cadillac	XTS	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Cadillac	XTS	Suspension Control Module	●	●	●	●	●	●	S076 S077 S077 S038
2013	Cadillac	XTS	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Cadillac	XTS	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2013	Cadillac	XTS	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Cadillac	XTS	Instrument Cluster	●	●	●	●	●	●	S022
2013	Cadillac	XTS	Headlamp Control Module	●	●	●	●	●	●	S002
2013	Cadillac	XTS	Radio	●	●	●	●	●	●	S063 S064
2013	Cadillac	XTS	Amplifier	●	●	●	●	○	○	
2013	Cadillac	XTS	Human Machine Interface Control Module	●	●	●	●	●	●	S064

2013	Cadillac	XTS	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Cadillac	XTS	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Cadillac	XTS	Seat Memory Control Module	●	●	●	●	●	●	S031
2013	Cadillac	XTS	Keyless Entry Control Module	●	●	●	●	●	○	
2013	Cadillac	XTS	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Cadillac	XTS	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2013	Cadillac	XTS	Long Range Radar Sensor Module	●	●	●	●	○	●	S061
2013	Cadillac	XTS	Left Front Short Range Radar Sensor Module	●	●	●	●	○	○	
2013	Chevrolet	Beat	Engine Control Module	●	●	●	●	●	●	S026 S044 S045 S025
2013	Chevrolet	Beat	Fuel Injector Control Module	●	●	●	●	●	○	
2013	Chevrolet	Beat	Transmission Control Module	●	●	●	●	●	○	
2013	Chevrolet	Beat	Electronic Brake Control Module	●	●	●	●	●	●	S035
2013	Chevrolet	Beat	Instrument Cluster	●	●	●	●	●	○	
2013	Chevrolet	Beat	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2013	Chevrolet	Beat	Power Steering Control Module	●	●	●	●	○	●	
2013	Chevrolet	Beat	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Beat	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036

2013	Chevrolet	Camaro	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025 S030
2013	Chevrolet	Camaro	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Chevrolet	Camaro	Transmission Control Module	●	●	●	●	●	●	S048
2013	Chevrolet	Camaro	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034
2013	Chevrolet	Camaro	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Chevrolet	Camaro	Power Steering Control Module	●	●	●	●	○	●	S047
2013	Chevrolet	Camaro	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Camaro	Suspension Control Module	●	●	●	●	●	●	S038
2013	Chevrolet	Camaro	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2013	Chevrolet	Camaro	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2013	Chevrolet	Camaro	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Chevrolet	Camaro	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Camaro	Head-Up Display Module	●	●	●	●	●	○	
2013	Chevrolet	Camaro	Auxiliary Gage Module	●	●	●	●	●	○	
2013	Chevrolet	Camaro	Headlamp Control Module	●	●	●	●	●	●	S002
2013	Chevrolet	Camaro	Radio	●	●	●	●	●	○	
2013	Chevrolet	Camaro	Multimedia Player Interface Module	●	●	●	●	○	●	
2013	Chevrolet	Camaro	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022

2013	Chevrolet	Camaro	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Chevrolet	Camaro	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Chevrolet	Camaro	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Chevrolet	Camaro	Folding Top Control Module	●	●	●	●	●	○	
2013	Chevrolet	Caprice	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S094 S046
2013	Chevrolet	Caprice	Transmission Control Module	●	●	●	●	●	●	S048
2013	Chevrolet	Cobalt	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2013	Chevrolet	Cobalt	Transmission Control Module	●	●	●	●	●	●	S023
2013	Chevrolet	Cobalt	Electronic Brake Control Module	●	●	●	●	●	●	S035
2013	Chevrolet	Cobalt	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Chevrolet	Cobalt	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Cobalt	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2013	Chevrolet	Cobalt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2013	Chevrolet	Cobalt	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Cobalt	Radio	●	●	●	●	●	○	

2013	Chevrolet	Cobalt	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Chevrolet	Cobalt	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Chevrolet	Colorado	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S044 S001 S029 S025 S030
2013	Chevrolet	Colorado	Transmission Control Module	●	●	●	●	●	●	S048
2013	Chevrolet	Colorado	Transfer Case Control Module	●	●	●	●	●	●	S080
2013	Chevrolet	Colorado	Electronic Brake Control Module	●	●	●	●	●	●	S035 S070
2013	Chevrolet	Colorado	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Chevrolet	Colorado	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Colorado	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2013	Chevrolet	Colorado	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Chevrolet	Colorado	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Colorado	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Chevrolet	Cruze	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029

2013	Chevrolet	Cruze	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Chevrolet	Cruze	Transmission Control Module	●	●	●	●	●	●	S023
2013	Chevrolet	Cruze	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2013	Chevrolet	Cruze	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Chevrolet	Cruze	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2013	Chevrolet	Cruze	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Cruze	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Chevrolet	Cruze	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Chevrolet	Cruze	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Chevrolet	Cruze	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Cruze	Trailer Interface Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Cruze	Radio	●	●	●	●	●	○	
2013	Chevrolet	Cruze	Multimedia Player Interface Module	●	●	●	●	○	●	
2013	Chevrolet	Cruze	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Chevrolet	Cruze	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022

2013	Chevrolet	Cruze	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Chevrolet	Cruze	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Chevrolet	Cruze	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Chevrolet	Cruze	Keyless Entry Control Module	●	●	●	●	●	○	
2013	Chevrolet	Cruze	Parking Assist Control Module	●	●	●	●	●	●	
2013	Chevrolet	Cruze	Steering Column Lock Control Module	●	●	●	●	○	●	
2013	Chevrolet	Cruze	Left Side Object Detection Control Module	●	●	●	○	●	○	
2013	Chevrolet	Cruze	Right Side Object Detection Control Module	●	●	●	○	●	○	
2013	Chevrolet	Cruze	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Enjoy	Engine Control Module	●	●	●	●	●	●	S103 S118 S162 S182 S029 S082
2013	Chevrolet	Enjoy	Electronic Brake Control Module	●	●	●	●	●	○	
2013	Chevrolet	Enjoy	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	
2013	Chevrolet	Enjoy	Instrument Cluster	●	●	○	○	○	○	
2013	Chevrolet	Equinox	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S046
2013	Chevrolet	Equinox	Transmission Control Module	●	●	●	●	●	●	S048

2013	Chevrolet	Equinox	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2013	Chevrolet	Equinox	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2013	Chevrolet	Equinox	Power Steering Control Module	●	●	●	●	○	●	
2013	Chevrolet	Equinox	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Chevrolet	Equinox	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Chevrolet	Equinox	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Equinox	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Chevrolet	Equinox	Liftgate Control Module	●	●	●	●	●	●	S049
2013	Chevrolet	Equinox	Radio	●	●	●	●	●	○	
2013	Chevrolet	Equinox	Seat Memory Control Module	●	●	●	●	●	●	S031
2013	Chevrolet	Equinox	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Chevrolet	Equinox	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Equinox	Left Side Object Detection Control Module	●	●	●	○	●	○	
2013	Chevrolet	Equinox	Right Side Object Detection Control Module	●	●	●	○	●	○	
2013	Chevrolet	Equinox	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Chevrolet	Equinox	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021

2013	Chevrolet	Equinox	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2013	Chevrolet	Equinox	Rear Audio Control Module	●	●	●	●	●	○	
2013	Chevrolet	Equinox	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Malibu	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S030
2013	Chevrolet	Malibu	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Chevrolet	Malibu	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2013	Chevrolet	Malibu	Transmission Control Module	●	●	●	●	●	●	S057 S082
2013	Chevrolet	Malibu	Drive Motor Control Module	●	●	●	●	○	○	
2013	Chevrolet	Malibu	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2013	Chevrolet	Malibu	Parking Brake Control Module	●	●	●	●	●	●	S037
2013	Chevrolet	Malibu	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Chevrolet	Malibu	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2013	Chevrolet	Malibu	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2013	Chevrolet	Malibu	Suspension Control Module	●	●	●	●	●	○	
2013	Chevrolet	Malibu	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021

2013	Chevrolet	Malibu	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Chevrolet	Malibu	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Chevrolet	Malibu	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Malibu	Headlamp Control Module	●	●	●	●	●	●	
2013	Chevrolet	Malibu	Radio	●	●	●	●	●	○	
2013	Chevrolet	Malibu	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Malibu	Multimedia Player Interface Module	●	●	●	●	○	●	
2013	Chevrolet	Malibu	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2013	Chevrolet	Malibu	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Chevrolet	Malibu	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Chevrolet	Malibu	Seat Memory Control Module	●	●	●	●	●	●	S031
2013	Chevrolet	Malibu	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Chevrolet	Malibu	Rear Seat Heating Control Module	●	●	●	●	●	○	
2013	Chevrolet	Malibu	Keyless Entry Control Module	●	●	●	●	●	○	
2013	Chevrolet	Malibu	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Malibu	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168
2013	Chevrolet	Malibu	Steering Column Lock Control Module	●	●	●	●	○	●	

2013	Chevrolet	Malibu	Battery Energy Control Module	○	○	●	●	○	○	
2013	Chevrolet	Malibu	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Chevrolet	Malibu	Fuel Injector Control Module	●	●	●	●	●	○	
2013	Chevrolet	N300	Engine Control Module	●	●	●	●	●	●	S095 S096 S155
2013	Chevrolet	N300	Electronic Brake Control Module	●	●	●	●	●	○	
2013	Chevrolet	N300	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	○	
2013	Chevrolet	Onix	Transmission Control Module	●	●	●	●	●	●	S023
2013	Chevrolet	Onix	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Onix	Parking Assist Control Module	●	●	●	●	●	●	
2013	Chevrolet	Onix	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2013	Chevrolet	Onix	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2013	Chevrolet	Onix	Radio	●	●	●	●	●	○	
2013	Chevrolet	Onix	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Chevrolet	Onix	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Chevrolet	Onix	Electronic Brake Control Module	●	●	●	●	●	●	S035

2013	Chevrolet	Onix	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Chevrolet	Onix	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Orlando	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2013	Chevrolet	Orlando	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Chevrolet	Orlando	Transmission Control Module	●	●	●	●	●	●	S023
2013	Chevrolet	Orlando	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2013	Chevrolet	Orlando	Parking Brake Control Module	●	●	●	●	●	●	S037
2013	Chevrolet	Orlando	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2013	Chevrolet	Orlando	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Chevrolet	Orlando	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Orlando	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Chevrolet	Orlando	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Chevrolet	Orlando	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Orlando	Keyless Entry Control Module	●	●	●	●	●	○	
2013	Chevrolet	Orlando	Radio	●	●	●	●	●	○	
2013	Chevrolet	Orlando	Multimedia Player Interface Module	●	●	●	●	○	●	

2013	Chevrolet	Orlando	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2013	Chevrolet	Orlando	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Chevrolet	Orlando	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Chevrolet	Orlando	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Orlando	Fuel Injector Control Module	●	●	●	●	●	○	
2013	Chevrolet	Orlando	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Chevrolet	Orlando	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Prisma	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2013	Chevrolet	Prisma	Transmission Control Module	●	●	●	●	●	●	S023
2013	Chevrolet	Prisma	Electronic Brake Control Module	●	●	●	●	●	●	S035
2013	Chevrolet	Prisma	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Chevrolet	Prisma	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Prisma	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Chevrolet	Prisma	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S024 S036 S036 S036 S036 S036 S036
2013	Chevrolet	Prisma	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Prisma	Radio	●	●	●	●	●	○	

2013	Chevrolet	Prisma	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Chevrolet	Prisma	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	S10	Engine Control Module	●	●	●	●	●	●	S205 S108
2013	Chevrolet	S10	Transmission Control Module	●	●	●	●	●	●	S048
2013	Chevrolet	S10	Transfer Case Control Module	●	●	●	●	●	●	S080
2013	Chevrolet	S10	Electronic Brake Control Module	●	●	●	●	●	●	S035
2013	Chevrolet	S10	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S070 S070 S036 S036
2013	Chevrolet	S10	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	S10	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2013	Chevrolet	S10	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Chevrolet	S10	Instrument Cluster	●	●	●	●	●	●	
2013	Chevrolet	S10	Trailer Interface Control Module	●	●	●	●	●	●	
2013	Chevrolet	S10	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Chevrolet	Sail	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	S194 S195 S196 S197 S198 S194 S195 S196 S197 S024 S199

2013	Chevrolet	Sail	Keyless Entry Control Module	○	○	○	●	○	●	
2013	Chevrolet	Sail	Engine Control Module	●	●	●	●	●	●	S102 S103 S105 S106 S107 S108 S110 S111 S118
2013	Chevrolet	Sail	Transmission Control Module	●	●	●	●	●	●	S200 S201 S202 S203 S204
2013	Chevrolet	Sail	Electronic Brake Control Module	●	●	●	●	●	○	
2013	Chevrolet	Sonic	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2013	Chevrolet	Sonic	Fuel Injector Control Module	○	○	●	●	●	○	
2013	Chevrolet	Sonic	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Chevrolet	Sonic	Transmission Control Module	●	●	●	●	●	●	S023
2013	Chevrolet	Sonic	Electronic Brake Control Module	●	●	●	●	●	●	S035
2013	Chevrolet	Sonic	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Chevrolet	Sonic	Power Steering Control Module	●	●	●	●	○	●	
2013	Chevrolet	Sonic	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Sonic	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Chevrolet	Sonic	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2013	Chevrolet	Sonic	Passenger Presence Module	●	●	●	●	○	●	S043

2013	Chevrolet	Sonic	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Sonic	Radio	●	●	●	●	●	○	
2013	Chevrolet	Sonic	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Chevrolet	Sonic	HVAC Control Module	●	●	●	●	●	○	
2013	Chevrolet	Sonic	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Chevrolet	Sonic	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Sonic	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Chevrolet	Spin	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S103 S103 S104 S105 S105 S106 S106 S107 S107 S108 S108 S109 S110 S111 S111 S045 S045 S112 S112 S113 S029 S114 S114 S115 S116 S117 S118 S118
2013	Chevrolet	Spin	Transmission Control Module	●	●	●	●	●	●	S023
2013	Chevrolet	Spin	Electronic Brake Control Module	●	●	●	●	●	●	S035
2013	Chevrolet	Spin	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Chevrolet	Spin	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Spin	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021

2013	Chevrolet	Spin	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2013	Chevrolet	Spin	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Spin	Radio	●	●	●	●	●	○	
2013	Chevrolet	Spin	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Chevrolet	Spin	HVAC Control Module	●	●	●	●	●	○	
2013	Chevrolet	Spin	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Tavera	Engine Control Module	●	●	●	●	●	○	
2013	Chevrolet	Tracker	Transmission Control Module	●	●	●	●	●	●	S023
2013	Chevrolet	Tracker	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Tracker	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Chevrolet	Tracker	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Chevrolet	Tracker	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Tracker	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2013	Chevrolet	Tracker	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Chevrolet	Tracker	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021

2013	Chevrolet	Tracker	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Chevrolet	Tracker	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2013	Chevrolet	Tracker	Radio	●	●	●	●	●	○	
2013	Chevrolet	Tracker	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Chevrolet	Tracker	Rear Differential Clutch Control Module	●	●	●	●	●	●	
2013	Chevrolet	Tracker	HVAC Control Module	●	●	●	●	●	○	
2013	Chevrolet	Tracker	Electronic Brake Control Module	●	●	●	●	●	●	S035
2013	Chevrolet	Tracker	Power Steering Control Module	●	●	●	●	○	●	
2013	Chevrolet	Tracker	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Tracker	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2013	Chevrolet	Trailblazer	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2013	Chevrolet	Trailblazer	Transmission Control Module	●	●	●	●	●	●	S048
2013	Chevrolet	Trailblazer	Transfer Case Control Module	●	●	●	●	●	●	S080
2013	Chevrolet	Trailblazer	Electronic Brake Control Module	●	●	●	●	●	●	S035 S070
2013	Chevrolet	Trailblazer	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Chevrolet	Trailblazer	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	

2013	Chevrolet	Trailblazer	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2013	Chevrolet	Trailblazer	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Chevrolet	Trailblazer	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Trailblazer	Trailer Interface Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Trailblazer	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Chevrolet	Trailblazer	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Trax	Transmission Control Module	●	●	●	●	●	●	S023
2013	Chevrolet	Trax	Instrument Cluster	●	●	●	●	●	●	S022
2013	Chevrolet	Trax	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	Chevrolet	Trax	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Chevrolet	Trax	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Trax	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2013	Chevrolet	Trax	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Chevrolet	Trax	Fuel Pump Control Module	●	●	●	●	●	●	S025

2013	Chevrolet	Trax	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Chevrolet	Trax	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Chevrolet	Trax	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2013	Chevrolet	Trax	Radio	●	●	●	●	●	○	
2013	Chevrolet	Trax	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Chevrolet	Trax	Rear Differential Clutch Control Module	●	●	●	●	●	●	
2013	Chevrolet	Trax	HVAC Control Module	●	●	●	●	●	○	
2013	Chevrolet	Trax	Electronic Brake Control Module	●	●	●	●	●	●	S035
2013	Chevrolet	Trax	Power Steering Control Module	●	●	●	●	○	●	
2013	Chevrolet	Trax	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Trax	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2013	Chevrolet	Volt	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S091
2013	Chevrolet	Volt	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Chevrolet	Volt	Hybrid Powertrain Control Module	●	●	●	●	●	○	
2013	Chevrolet	Volt	Transmission Control Module	●	●	●	●	●	○	
2013	Chevrolet	Volt	Drive Motor Control Module 1	●	●	●	●	○	○	

2013	Chevrolet	Volt	Drive Motor Control Module 2	●	●	●	●	○	○	
2013	Chevrolet	Volt	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	
2013	Chevrolet	Volt	Electronic Brake Control Module	●	●	●	●	●	●	S092 S036 S036 S036
2013	Chevrolet	Volt	Parking Brake Control Module	●	●	●	●	●	●	S037
2013	Chevrolet	Volt	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Volt	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2013	Chevrolet	Volt	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Chevrolet	Volt	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Chevrolet	Volt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Chevrolet	Volt	Passenger Presence Module	●	●	●	●	○	●	S043
2013	Chevrolet	Volt	Instrument Cluster	●	●	●	●	●	●	S022 S022
2013	Chevrolet	Volt	Radio	●	●	●	●	●	○	
2013	Chevrolet	Volt	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Volt	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2013	Chevrolet	Volt	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039

2013	Chevrolet	Volt	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2013	Chevrolet	Volt	Coolant Heater Control Module	●	●	●	○	○	○	
2013	Chevrolet	Volt	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Chevrolet	Volt	Keyless Entry Control Module	●	●	●	●	●	○	
2013	Chevrolet	Volt	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Chevrolet	Volt	Steering Column Lock Control Module	●	●	●	●	○	●	
2013	Chevrolet	Volt	Battery Charger Control Module	○	○	●	●	○	○	
2013	Chevrolet	Volt	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S083 S084 S085 S086 S087 S088 S089
2013	Chevrolet	Volt	Battery Energy Control Module	○	○	●	●	○	○	
2013	Chevrolet	Volt	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Chevrolet	Volt	Multimedia Player Interface Module	●	●	●	●	○	●	
2013	Chevrolet	Volt	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2013	Daewoo	Alpheon	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2013	Daewoo	Alpheon	Transmission Control Module	●	●	●	●	●	●	S023
2013	Daewoo	Alpheon	Drive Motor Control Module	●	●	●	●	○	○	
2013	Daewoo	Alpheon	Instrument Cluster	●	●	●	●	●	●	S022
2013	Daewoo	Alpheon	Seat Memory Control Module	●	●	●	●	●	●	S031
2013	Daewoo	Alpheon	Front Seat Heating Control Module	●	●	●	●	●	○	

2013	Daewoo	Alpheon	Rear Seat Heating Control Module	●	●	●	●	●	○	
2013	Daewoo	Alpheon	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Daewoo	Alpheon	Battery Energy Control Module	○	○	●	●	○	○	
2013	Daewoo	Alpheon	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Daewoo	Alpheon	Keyless Entry Control Module	●	●	●	●	●	○	
2013	Daewoo	Alpheon	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2013	Daewoo	Alpheon	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2013	Daewoo	Alpheon	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Daewoo	Alpheon	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Daewoo	Alpheon	Suspension Control Module	●	●	●	●	●	○	
2013	Daewoo	Alpheon	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2013	Daewoo	Alpheon	Radio	●	●	●	●	●	○	
2013	Daewoo	Alpheon	Rear Audio Control Module	●	●	●	●	●	○	
2013	Daewoo	Alpheon	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Daewoo	Alpheon	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S046
2013	Daewoo	Alpheon	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Daewoo	Alpheon	Frontview Camera Module	●	●	●	●	●	●	S050 S168

2013	Daewoo	Alpheon	Parking Brake Control Module	●	●	●	●	●	●	S037
2013	Daewoo	Alpheon	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Daewoo	Alpheon	Headlamp Control Module	●	●	●	●	●	●	S002
2013	GMC	Terrain	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S046
2013	GMC	Terrain	Transmission Control Module	●	●	●	●	●	●	S048
2013	GMC	Terrain	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2013	GMC	Terrain	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2013	GMC	Terrain	Power Steering Control Module	●	●	●	●	○	●	
2013	GMC	Terrain	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	GMC	Terrain	Passenger Presence Module	●	●	●	●	○	●	S043
2013	GMC	Terrain	Instrument Cluster	●	●	●	●	●	●	S022
2013	GMC	Terrain	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2013	GMC	Terrain	Liftgate Control Module	●	●	●	●	●	●	S049
2013	GMC	Terrain	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	GMC	Terrain	Parking Assist Control Module	●	●	●	●	●	●	S022

2013	GMC	Terrain	Left Side Object Detection Control Module	●	●	●	○	●	○	
2013	GMC	Terrain	Right Side Object Detection Control Module	●	●	●	○	●	○	
2013	GMC	Terrain	Radio	●	●	●	●	●	○	
2013	GMC	Terrain	Seat Memory Control Module	●	●	●	●	●	●	S031
2013	GMC	Terrain	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	GMC	Terrain	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	GMC	Terrain	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2013	GMC	Terrain	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2013	Holden	Barina	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2013	Holden	Barina	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Holden	Barina	Transmission Control Module	●	●	●	●	●	●	S023
2013	Holden	Barina	Electronic Brake Control Module	●	●	●	●	●	●	S035
2013	Holden	Barina	Instrument Cluster	●	●	●	●	●	●	S022
2013	Holden	Barina	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Holden	Barina	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2013	Holden	Barina	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021

2013	Holden	Barina	Power Steering Control Module	●	●	●	●	○	●	
2013	Holden	Barina	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Holden	Barina	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Holden	Barina	Radio	●	●	●	●	●	○	
2013	Holden	Barina	HVAC Control Module	●	●	●	●	●	○	
2013	Holden	Barina	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Holden	Barina Spark	Electronic Brake Control Module	●	●	●	●	●	●	S035
2013	Holden	Barina Spark	Instrument Cluster	●	●	●	●	●	○	
2013	Holden	Barina Spark	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2013	Holden	Barina Spark	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2013	Holden	Barina Spark	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Holden	Barina Spark	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2013	Holden	Barina Spark	Transmission Control Module	●	●	●	●	●	●	S048
2013	Holden	Barina Spark	Power Steering Control Module	●	●	●	●	○	●	
2013	Holden	Barina Spark	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Holden	Barina Spark	Radio	●	●	●	●	●	○	
2013	Holden	Captiva 5	Transmission Control Module	●	●	●	●	●	●	S023

2013	Holden	Captiva 5	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2013	Holden	Captiva 5	Instrument Cluster	●	●	●	●	●	○	
2013	Holden	Captiva 5	HVAC Control Module	●	●	●	○	●	○	
2013	Holden	Captiva 5	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S094 S046
2013	Holden	Captiva 5	Electronic Brake Control Module	●	●	●	●	●	●	S035
2013	Holden	Captiva 5	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S053
2013	Holden	Captiva 5	Info Display Module	●	●	●	●	●	●	S187 S187 S187 S187 S188 S189 S022 S022 S190 S190 S190 S190 S179 S179 S179
2013	Holden	Captiva 5	Radio	●	●	●	●	●	●	S187 S187 S187 S187 S179 S179 S179 S179 S191 S191
2013	Holden	Captiva 5	Body Control Module	●	●	●	●	●	●	S013 S001
2013	Holden	Captiva 5	Mobile Telephone Control Module	●	●	●	○	●	●	
2013	Holden	Captiva 5	Headlamp Control Module	●	●	●	●	●	●	S002 S179
2013	Holden	Captiva 5	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2013	Holden	Captiva 5	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2013	Holden	Captiva 5	Theft Deterrent Module	●	●	●	●	○	○	
2013	Holden	Captiva 5	Parking Brake Control Module	●	●	●	●	●	●	S037
2013	Holden	Captiva 5	Parking Assist Control Module	●	●	●	●	●	●	

2013	Holden	Captiva 5	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Holden	Captiva 7	Transmission Control Module	●	●	●	●	●	●	S023
2013	Holden	Captiva 7	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2013	Holden	Captiva 7	Instrument Cluster	●	●	●	●	●	○	
2013	Holden	Captiva 7	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2013	Holden	Captiva 7	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2013	Holden	Captiva 7	Body Control Module	●	●	●	●	●	●	S013 S001 S053
2013	Holden	Captiva 7	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2013	Holden	Captiva 7	Theft Deterrent Module	●	●	●	●	○	○	
2013	Holden	Captiva 7	Engine Control Module	●	●	●	●	●	●	S044 S026 S105 S108 S169 S170 S109 S110 S171 S111 S045 S172 S173 S112 S122 S113 S029 S115 S116 S174 S175 S176 S177
2013	Holden	Captiva 7	Electronic Brake Control Module	●	●	●	●	●	●	S035 S036
2013	Holden	Captiva 7	HVAC Control Module	●	●	●	○	●	○	
2013	Holden	Captiva 7	Mobile Telephone Control Module	●	●	●	●	●	●	S022
2013	Holden	Captiva 7	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Holden	Captiva 7	Headlamp Control Module	●	●	●	●	●	●	S002 S179
2013	Holden	Captiva 7	Parking Brake Control Module	●	●	●	●	●	●	S037

2013	Holden	Colorado	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S044 S001 S029 S025 S030
2013	Holden	Colorado	Transmission Control Module	●	●	●	●	●	●	S048
2013	Holden	Colorado	Transfer Case Control Module	●	●	●	●	●	●	S080
2013	Holden	Colorado	Electronic Brake Control Module	●	●	●	●	●	●	S035 S070
2013	Holden	Colorado	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Holden	Colorado	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Holden	Colorado	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2013	Holden	Colorado	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Holden	Colorado	Instrument Cluster	●	●	●	●	●	●	S022
2013	Holden	Colorado	Trailer Interface Control Module	●	●	●	●	●	●	S022
2013	Holden	Colorado	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Holden	Colorado 7	Transmission Control Module	●	●	●	●	●	●	S048
2013	Holden	Colorado 7	Transfer Case Control Module	●	●	●	●	●	●	S080
2013	Holden	Colorado 7	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021

2013	Holden	Colorado 7	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Holden	Colorado 7	Electronic Brake Control Module	●	●	●	●	●	●	S035 S070
2013	Holden	Colorado 7	Engine Control Module	●	●	●	●	●	●	S205 S108
2013	Holden	Colorado 7	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Holden	Colorado 7	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Holden	Colorado 7	Instrument Cluster	●	●	●	●	●	●	S022
2013	Holden	Colorado 7	Trailer Interface Control Module	●	●	●	●	●	●	S022
2013	Holden	Colorado 7	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Holden	Cruze	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S057 S027 S028 S025 S058 S029
2013	Holden	Cruze	Transmission Control Module	●	●	●	●	●	●	S023
2013	Holden	Cruze	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2013	Holden	Cruze	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2013	Holden	Cruze	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2013	Holden	Cruze	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Holden	Cruze	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021

2013	Holden	Cruze	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Holden	Cruze	Instrument Cluster	●	●	●	●	●	●	S022
2013	Holden	Cruze	Trailer Interface Control Module	●	●	●	●	●	●	S022
2013	Holden	Cruze	Radio	●	●	●	●	●	○	
2013	Holden	Cruze	Multimedia Player Interface Module	●	●	●	●	○	●	
2013	Holden	Cruze	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2013	Holden	Cruze	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Holden	Cruze	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Holden	Cruze	Keyless Entry Control Module	●	●	●	●	●	○	
2013	Holden	Cruze	Parking Assist Control Module	●	●	●	●	●	●	
2013	Holden	Cruze	Steering Column Lock Control Module	●	●	●	●	○	●	
2013	Holden	Cruze	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Holden	Malibu	Transmission Control Module	●	●	●	●	●	●	S023
2013	Holden	Malibu	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Holden	Malibu	Instrument Cluster	●	●	●	●	●	●	S022
2013	Holden	Malibu	Seat Memory Control Module	●	●	●	●	●	●	S031
2013	Holden	Malibu	Front Seat Heating Control Module	●	●	●	●	●	○	

2013	Holden	Malibu	Rear Seat Heating Control Module	●	●	●	●	●	○	
2013	Holden	Malibu	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Holden	Malibu	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Holden	Malibu	Keyless Entry Control Module	●	●	●	●	●	○	
2013	Holden	Malibu	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Holden	Malibu	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S103 S103 S104 S105 S105 S106 S106 S107 S107 S108 S108 S109 S110 S111 S111 S045 S045 S112 S112 S113 S029 S114 S114 S115 S116 S117 S118 S118
2013	Holden	Malibu	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2013	Holden	Malibu	Steering Column Lock Control Module	●	●	●	●	○	●	
2013	Holden	Malibu	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036 S036
2013	Holden	Malibu	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2013	Holden	Malibu	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Holden	Malibu	Frontview Camera Module	●	●	●	●	●	●	S050 S168
2013	Holden	Malibu	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036

2013	Holden	Malibu	Headlamp Control Module	●	●	●	●	●	●	S002
2013	Holden	Malibu	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2013	Holden	Malibu	Suspension Control Module	●	●	●	●	●	○	
2013	Holden	Volt	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S091
2013	Holden	Volt	Fuel Pump Control Module	●	●	●	●	●	●	S025
2013	Holden	Volt	Hybrid Powertrain Control Module	●	●	●	●	●	○	
2013	Holden	Volt	Transmission Control Module	●	●	●	●	●	○	
2013	Holden	Volt	Drive Motor Control Module 1	●	●	●	●	○	○	
2013	Holden	Volt	Drive Motor Control Module 2	●	●	●	●	○	○	
2013	Holden	Volt	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	
2013	Holden	Volt	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	
2013	Holden	Volt	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2013	Holden	Volt	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2013	Holden	Volt	Instrument Cluster	●	●	●	●	●	●	S022
2013	Holden	Volt	Telematics Communication Interface Control Module	●	●	●	●	○	○	
2013	Holden	Volt	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022

2013	Holden	Volt	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2013	Holden	Volt	Coolant Heater Control Module	●	●	●	○	○	○	
2013	Holden	Volt	Steering Column Lock Control Module	●	●	●	●	○	●	
2013	Holden	Volt	Battery Charger Control Module	○	○	●	●	○	○	
2013	Holden	Volt	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S083 S084 S085 S086 S087 S088 S089
2013	Holden	Volt	Battery Energy Control Module	○	○	●	●	○	○	
2013	Holden	Volt	Keyless Entry Control Module	●	●	●	●	●	○	
2013	Holden	Volt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2013	Holden	Volt	HVAC Control Module	●	●	●	●	●	●	S032 S033
2013	Holden	Volt	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S020 S021
2013	Holden	Volt	Parking Assist Control Module	●	●	●	●	●	●	S022
2013	Holden	Volt	Front Seat Heating Control Module	●	●	●	●	●	○	
2013	Holden	Volt	Radio	●	●	●	●	●	○	
2013	Holden	Volt	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2013	Holden	Volt	Electronic Brake Control Module	●	●	●	●	●	●	S092 S036 S036 S036
2013	Cadillac	CTS	Engine control module	●	●	●	●	●	●	T001
2013	Cadillac	CTS	Fuel pump control module	●	●	●	●	●	○	

2013	Cadillac	CTS	Transmission control module	●	●	○	●	●	○	
2013	Cadillac	CTS	Transfer case control module	●	●	●	●	●	●	T001
2013	Cadillac	CTS	Headlamp control module	●	●	●	●	●	○	
2013	Cadillac	CTS	Liftgate module	●	●	●	●	●	○	
2013	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2013	Cadillac	CTS	Passenger presence system	●	●	●	●	●	○	
2013	Cadillac	CTS	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Cadillac	CTS	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Cadillac	CTS	Body control module	●	●	●	●	●	●	T007 T005
2013	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2013	Cadillac	CTS	Park assist module	●	●	●	●	●	○	
2013	Cadillac	CTS	HVAC control module	●	●	●	●	●	●	T008
2013	Cadillac	CTS	Pedestrian impact detection module	●	●	●	●	●	●	T009
2013	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	●	T010
2013	Cadillac	CTS	Driver door switch	●	●	●	●	●	○	
2013	Cadillac	CTS	Passenger door switch	●	●	●	●	●	○	
2013	Cadillac	CTS	Radio	●	●	●	●	●	●	T011
2013	Cadillac	CTS	TV antenna module	●	●	●	●	○	●	T012 T013
2013	Cadillac	CTS	Right side object detection module	●	●	●	●	○	○	
2013	Cadillac	CTS	Left side object detection module	●	●	●	●	●	●	T002 T003 T004
2013	Cadillac	CTS	Electronic brake control module	●	●	●	●	●	●	T014

2013	Cadillac	CTS	Parking brake control module	●	●	●	●	●	○	
2013	Cadillac	CTS	Electronic suspension control	●	●	○	●	●	○	
2013	Chevrolet	Aveo classic	Engine control module	●	●	●	●	●	●	T015
2013	Chevrolet	Aveo classic	Transmission control module	●	●	●	●	●	●	T001
2013	Chevrolet	Aveo classic	Supplemental inflatable restraint	●	●	●	●	●	○	
2013	Chevrolet	Aveo classic	Immobilizer	●	●	●	●	●	●	T016
2013	Chevrolet	Aveo classic	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Sonic	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Sonic	Transmission control module	●	●	●	●	●	●	T015
2013	Chevrolet	Sonic	Immobilizer	○	○	○	○	○	●	T016
2013	Chevrolet	Sonic	Supplemental inflatable restraint	●	●	●	●	●	○	
2013	Chevrolet	Sonic	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2013	Chevrolet	Sonic	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Caprice PPV	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Caprice PPV	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Caprice PPV	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Caprice PPV	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Caprice PPV	HVAC control module	●	●	●	●	●	○	
2013	Chevrolet	Caprice PPV	Radio	●	●	●	●	●	○	
2013	Chevrolet	Caprice PPV	Passenger presence system	●	●	●	●	○	●	T020
2013	Chevrolet	Caprice PPV	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2013	Chevrolet	Caprice PPV	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Caprice PPV	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Caprice PPV	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Caprice PPV	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Corvette	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Corvette	Exhaust flow control module	●	●	●	●	●	○	
2013	Chevrolet	Corvette	Transmission control module	●	●	●	●	●	●	T001
2013	Chevrolet	Corvette	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Corvette	Body control module	●	●	●	●	●	●	T023
2013	Chevrolet	Corvette	Digital radio receiver	●	●	●	●	○	●	T024
2013	Chevrolet	Corvette	Vehicle comm. interface module	●	●	●	●	●	●	T003
2013	Chevrolet	Corvette	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Corvette	Head up display	●	●	●	●	●	○	
2013	Chevrolet	Corvette	Steering column lock module	●	●	●	●	●	○	
2013	Chevrolet	Corvette	Passenger presence system	●	●	○	○	○	●	T025
2013	Chevrolet	Corvette	Remote control door lock receiver	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2013	Chevrolet	Corvette	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2013	Chevrolet	Corvette	Driver position module	●	●	●	●	●	●	T030
2013	Chevrolet	Corvette	Folding top module	●	●	●	●	●	○	
2013	Chevrolet	Corvette	HVAC control module	●	●	●	●	●	●	T008 T031
2013	Chevrolet	Corvette	CD changer	●	●	●	●	○	○	
2013	Chevrolet	Corvette	Driver door switch	●	●	●	●	○	○	
2013	Chevrolet	Corvette	Driver door module	●	●	●	●	●	○	

2013	Chevrolet	Corvette	Passenger door module	●	●	●	●	●	○	
2013	Chevrolet	Corvette	Radio	●	●	●	●	○	●	T032 T033
2013	Chevrolet	Corvette	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Corvette	Electronic suspension control	●	●	●	●	●	○	
2013	Chevrolet	Impala	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Impala	Fuel pump control module	●	●	●	●	●	○	
2013	Chevrolet	Impala	Transmission control module	●	●	●	●	●	●	T001
2013	Chevrolet	Impala	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Impala	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Impala	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Impala	Passenger presence system	●	●	●	●	●	○	
2013	Chevrolet	Impala	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Impala	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Impala	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Impala	Heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Impala	Radio	●	●	●	●	●	○	
2013	Chevrolet	Impala	HVAC control module	●	●	●	●	●	●	T008
2013	Chevrolet	Impala	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Others	Immobilizer	○	○	○	○	○	●	T016
2013	Chevrolet	Others	Supplemental inflatable restraint	●	●	●	●	●	●	T016
2013	Chevrolet	Others	Electronic brake control module	●	●	●	●	●	●	T014

2013	Chevrolet	Others	Transmission control module	●	●	●	●	●	○	
2013	Chevrolet	Others	Engine control module	●	●	●	●	●	●	T015
2013	Buick	Enclave - AWD	Engine control module	●	●	●	●	●	●	T001
2013	Buick	Enclave - AWD	Transmission control module	●	●	○	●	●	○	
2013	Buick	Enclave - AWD	Fuel pump control module	●	●	●	●	●	○	
2013	Buick	Enclave - AWD	Digital radio receiver	●	●	●	●	●	○	
2013	Buick	Enclave - AWD	Liftgate module	●	●	●	●	●	○	
2013	Buick	Enclave - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	Buick	Enclave - AWD	Instrument panel cluster	●	●	●	●	●	○	
2013	Buick	Enclave - AWD	Memory seat module	●	●	●	●	●	○	
2013	Buick	Enclave - AWD	Park assist module	●	●	●	●	○	○	
2013	Buick	Enclave - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Buick	Enclave - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Buick	Enclave - AWD	Headlamp control module	●	●	●	○	○	○	
2013	Buick	Enclave - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Buick	Enclave - AWD	Driver door switch	●	●	●	●	●	●	T035
2013	Buick	Enclave - AWD	Passenger door switch	●	●	●	●	●	●	T035
2013	Buick	Enclave - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2013	Buick	Enclave - AWD	Radio	●	●	●	●	●	○	
2013	Buick	Enclave - AWD	Passenger presence system	●	●	●	●	●	○	
2013	Buick	Enclave - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Buick	Enclave - AWD	Theft deterrent module	●	●	●	●	○	○	
2013	Buick	Enclave - AWD	Body control module	●	●	●	●	●	●	T007 T005
2013	Buick	Enclave - AWD	Left side object detection module	●	●	●	○	●	○	

2013	Buick	Enclave - AWD	Right side object detection module	●	●	●	○	●	○	
2013	Buick	Enclave - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Buick	Enclave - AWD	Rear drive system	●	●	●	●	●	●	T038
2013	Buick	Enclave - FWD	Engine control module	●	●	●	●	●	●	T001
2013	Buick	Enclave - FWD	Transmission control module	●	●	○	●	●	○	
2013	Buick	Enclave - FWD	Fuel pump control module	●	●	●	●	●	○	
2013	Buick	Enclave - FWD	Digital radio receiver	●	●	●	●	●	○	
2013	Buick	Enclave - FWD	Liftgate module	●	●	●	●	●	○	
2013	Buick	Enclave - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	Buick	Enclave - FWD	Instrument panel cluster	●	●	●	●	●	○	
2013	Buick	Enclave - FWD	Memory seat module	●	●	●	●	●	○	
2013	Buick	Enclave - FWD	Park assist module	●	●	●	●	○	○	
2013	Buick	Enclave - FWD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Buick	Enclave - FWD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Buick	Enclave - FWD	Headlamp control module	●	●	●	○	○	○	
2013	Buick	Enclave - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Buick	Enclave - FWD	Driver door switch	●	●	●	●	●	●	T035
2013	Buick	Enclave - FWD	Passenger door switch	●	●	●	●	●	●	T035
2013	Buick	Enclave - FWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2013	Buick	Enclave - FWD	Radio	●	●	●	●	●	○	
2013	Buick	Enclave - FWD	Passenger presence system	●	●	●	●	●	○	
2013	Buick	Enclave - FWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Buick	Enclave - FWD	Theft deterrent module	●	●	●	●	○	○	
2013	Buick	Enclave - FWD	Body control module	●	●	●	●	●	●	T007 T005

2013	Buick	Enclave - FWD	Left side object detection module	●	●	●	○	●	○	
2013	Buick	Enclave - FWD	Right side object detection module	●	●	●	○	●	○	
2013	Buick	Enclave - FWD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Buick	Enclave - FWD	Rear drive system	●	●	●	●	●	●	T038
2013	Cadillac	Escalade	Engine control module	●	●	●	●	●	●	T001
2013	Cadillac	Escalade	Transmission control module	●	●	○	●	●	○	
2013	Cadillac	Escalade	Fuel pump control module	●	●	●	●	●	○	
2013	Cadillac	Escalade	Liftgate module	●	●	●	●	●	○	
2013	Cadillac	Escalade	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2013	Cadillac	Escalade	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Cadillac	Escalade	Passenger presence system	●	●	●	●	○	○	
2013	Cadillac	Escalade	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Cadillac	Escalade	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Cadillac	Escalade	Theft deterrent module	●	●	●	●	○	○	
2013	Cadillac	Escalade	Assist step controller	●	●	●	●	●	●	T039
2013	Cadillac	Escalade	Memory seat module	●	●	●	●	●	○	
2013	Cadillac	Escalade	Inside rear view mirror module	●	●	●	●	●	○	
2013	Cadillac	Escalade	Rear heated seat module	●	●	●	●	○	○	
2013	Cadillac	Escalade	Park assist module	●	●	●	●	○	○	
2013	Cadillac	Escalade	Left side object detection module	●	●	●	●	●	○	

2013	Cadillac	Escalade	Right side object detection module	●	●	●	●	○	○	
2013	Cadillac	Escalade	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Cadillac	Escalade	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Cadillac	Escalade	Amplifier (bose)	●	●	●	●	●	○	
2013	Cadillac	Escalade	Driver door switch	●	●	●	●	●	○	
2013	Cadillac	Escalade	Passenger door switch	●	●	●	●	●	○	
2013	Cadillac	Escalade	Personal audio link module	○	○	○	○	○	●	T037
2013	Cadillac	Escalade	Body control module	●	●	●	●	●	●	T007 T005
2013	Cadillac	Escalade	Radio	●	●	●	●	●	○	
2013	Cadillac	Escalade	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Cadillac	Escalade	Electronic brake control module	●	●	●	●	●	●	T014
2013	Cadillac	Escalade	Electronic suspension control	●	●	●	●	●	●	T040
2013	Cadillac	Escalade	Engine control module	●	●	●	●	●	●	T001
2013	Cadillac	Escalade	Transmission control module	●	●	○	●	●	○	
2013	Cadillac	Escalade	Fuel pump control module	●	●	●	●	●	○	
2013	Cadillac	Escalade	Liftgate module	●	●	●	●	●	○	
2013	Cadillac	Escalade	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2013	Cadillac	Escalade	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Cadillac	Escalade	Passenger presence system	●	●	●	●	○	○	
2013	Cadillac	Escalade	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Cadillac	Escalade	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2013	Cadillac	Escalade	Theft deterrent module	●	●	●	●	○	○	
2013	Cadillac	Escalade	Assist step controller	●	●	●	●	●	●	T039
2013	Cadillac	Escalade	Memory seat module	●	●	●	●	●	○	
2013	Cadillac	Escalade	Inside rear view mirror module	●	●	●	●	●	○	
2013	Cadillac	Escalade	Rear heated seat module	●	●	●	●	○	○	
2013	Cadillac	Escalade	Park assist module	●	●	●	●	○	○	
2013	Cadillac	Escalade	Left side object detection module	●	●	●	●	●	○	
2013	Cadillac	Escalade	Right side object detection module	●	●	●	●	○	○	
2013	Cadillac	Escalade	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Cadillac	Escalade	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Cadillac	Escalade	Amplifier (bose)	●	●	●	●	●	○	
2013	Cadillac	Escalade	Driver door switch	●	●	●	●	●	○	
2013	Cadillac	Escalade	Passenger door switch	●	●	●	●	●	○	
2013	Cadillac	Escalade	Personal audio link module	○	○	○	○	○	●	T037
2013	Cadillac	Escalade	Body control module	●	●	●	●	●	●	T007 T005
2013	Cadillac	Escalade	Radio	●	●	●	●	●	○	
2013	Cadillac	Escalade	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Cadillac	Escalade	Electronic brake control module	●	●	●	●	●	●	T014
2013	Cadillac	Escalade	Electronic suspension control	●	●	●	●	●	●	T040
2013	Cadillac	Escalade hybrid	Engine control module	●	●	●	●	●	●	T001
2013	Cadillac	Escalade hybrid	Transmission control module	●	●	○	●	●	○	
2013	Cadillac	Escalade hybrid	Fuel pump control module	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Accessory power module	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Liftgate module	●	●	●	●	●	○	

2013	Cadillac	Escalade hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Cadillac	Escalade hybrid	Instrument panel cluster	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Cadillac	Escalade hybrid	Passenger presence system	●	●	●	●	○	○	
2013	Cadillac	Escalade hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Cadillac	Escalade hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Cadillac	Escalade hybrid	Theft deterrent module	●	●	●	●	○	○	
2013	Cadillac	Escalade hybrid	A/C compressor control module	●	●	●	●	○	○	
2013	Cadillac	Escalade hybrid	Serial data gateway module	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Assist step controller	●	●	●	●	●	●	T039
2013	Cadillac	Escalade hybrid	Inside rear view mirror module	●	●	●	○	○	○	
2013	Cadillac	Escalade hybrid	Memory seat module	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Rear heated seat module	●	●	●	●	○	○	
2013	Cadillac	Escalade hybrid	Park assist module	●	●	●	●	○	○	
2013	Cadillac	Escalade hybrid	Left side object detection module	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Right side object detection module	●	●	●	●	○	○	
2013	Cadillac	Escalade hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Cadillac	Escalade hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Amplifier (bose)	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Driver door switch	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Passenger door switch	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Personal audio link module	○	○	○	○	○	●	T037

2013	Cadillac	Escalade hybrid	Body control module	●	●	●	●	●	●	T007 T005
2013	Cadillac	Escalade hybrid	Radio	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2013	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2013	Cadillac	Escalade hybrid	Power steering control module	●	●	●	●	●	●	T044
2013	Cadillac	Escalade hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2013	Cadillac	Escalade hybrid	Engine control module	●	●	●	●	●	●	T001
2013	Cadillac	Escalade hybrid	Transmission control module	●	●	○	●	●	○	
2013	Cadillac	Escalade hybrid	Fuel pump control module	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Accessory power module	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Liftgate module	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Cadillac	Escalade hybrid	Instrument panel cluster	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Cadillac	Escalade hybrid	Passenger presence system	●	●	●	●	○	○	
2013	Cadillac	Escalade hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Cadillac	Escalade hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Cadillac	Escalade hybrid	Theft deterrent module	●	●	●	●	○	○	
2013	Cadillac	Escalade hybrid	A/C compressor control module	●	●	●	●	○	○	

2013	Cadillac	Escalade hybrid	Serial data gateway module	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Assist step controller	●	●	●	●	●	●	T039
2013	Cadillac	Escalade hybrid	Inside rear view mirror module	●	●	●	○	○	○	
2013	Cadillac	Escalade hybrid	Memory seat module	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Rear heated seat module	●	●	●	●	○	○	
2013	Cadillac	Escalade hybrid	Park assist module	●	●	●	●	○	○	
2013	Cadillac	Escalade hybrid	Left side object detection module	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Right side object detection module	●	●	●	●	○	○	
2013	Cadillac	Escalade hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Cadillac	Escalade hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Amplifier (bose)	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Driver door switch	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Passenger door switch	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Personal audio link module	○	○	○	○	○	●	T037
2013	Cadillac	Escalade hybrid	Body control module	●	●	●	●	●	●	T007 T005
2013	Cadillac	Escalade hybrid	Radio	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Cadillac	Escalade hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2013	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2013	Cadillac	Escalade hybrid	Power steering control module	●	●	●	●	●	●	T044
2013	Cadillac	Escalade hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Avalanche - 2WD	Transmission control module	●	●	○	●	●	○	

2013	Chevrolet	Avalanche - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Avalanche - 2WD	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 2WD	Assist step controller	●	●	●	●	●	●	T039
2013	Chevrolet	Avalanche - 2WD	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 2WD	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Avalanche - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Avalanche - 2WD	Radio	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Avalanche - 2WD	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Avalanche - 2WD	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014

2013	Chevrolet	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2013	Chevrolet	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Avalanche - 2WD	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Avalanche - 2WD	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 2WD	Assist step controller	●	●	●	●	●	●	T039
2013	Chevrolet	Avalanche - 2WD	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 2WD	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Avalanche - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Personal audio link module	○	○	○	○	○	●	T037

2013	Chevrolet	Avalanche - 2WD	Radio	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Avalanche - 2WD	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Avalanche - 2WD	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2013	Chevrolet	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Avalanche - 4WD	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Avalanche - 4WD	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 4WD	Assist step controller	●	●	●	●	●	●	T039
2013	Chevrolet	Avalanche - 4WD	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 4WD	Park assist module	●	●	●	●	○	○	

2013	Chevrolet	Avalanche - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Avalanche - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Avalanche - 4WD	Radio	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Avalanche - 4WD	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Avalanche - 4WD	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2013	Chevrolet	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Avalanche - 4WD	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2013	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Avalanche - 4WD	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 4WD	Assist step controller	●	●	●	●	●	●	T039
2013	Chevrolet	Avalanche - 4WD	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 4WD	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Avalanche - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Avalanche - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Avalanche - 4WD	Radio	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Avalanche - 4WD	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Avalanche - 4WD	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Chevrolet	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2013	Chevrolet	Captiva sport	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Captiva sport	Transmission control module	●	●	●	●	●	●	T001
2013	Chevrolet	Captiva sport	Rear drive system	●	●	●	●	●	●	T038
2013	Chevrolet	Captiva sport	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Captiva sport	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	Chevrolet	Captiva sport	Telematic veh. locate and immo.	●	●	●	●	○	○	

2013	Chevrolet	Captiva sport	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Captiva sport	Heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Captiva sport	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Captiva sport	HVAC control module	●	●	●	●	●	●	T008
2013	Chevrolet	Captiva sport	Passenger presence system	●	●	●	●	○	●	T045
2013	Chevrolet	Captiva sport	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Captiva sport	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Captiva sport	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Captiva sport	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Captiva sport	Radio	●	●	●	●	●	○	
2013	Chevrolet	Captiva sport	Electronic brake control module	●	●	●	●	●	○	
2013	Chevrolet	Captiva sport	Parking brake control module	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 2WD	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Cheyenne - 2WD	Transmission control module	●	●	●	●	●	●	T001
2013	Chevrolet	Cheyenne - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Cheyenne - 2WD	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Cheyenne - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Cheyenne - 2WD	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Cheyenne - 2WD	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Cheyenne - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2013	Chevrolet	Cheyenne - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Cheyenne - 2WD	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Cheyenne - 2WD	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Cheyenne - 2WD	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Cheyenne - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 2WD	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 2WD	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 2WD	Personal audio link module	●	●	●	●	●	●	T036
2013	Chevrolet	Cheyenne - 2WD	Trailer brake control module	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Cheyenne - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Cheyenne - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2013	Chevrolet	Cheyenne - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2013	Chevrolet	Cheyenne - 2WD	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Cheyenne - 2WD	Transmission control module	●	●	●	●	●	●	T001
2013	Chevrolet	Cheyenne - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Cheyenne - 2WD	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Cheyenne - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Cheyenne - 2WD	Body control module	●	●	●	●	●	●	T007 T005

2013	Chevrolet	Cheyenne - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Cheyenne - 4WD	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Cheyenne - 4WD	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Cheyenne - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Cheyenne - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Cheyenne - 4WD	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Cheyenne - 4WD	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Cheyenne - 4WD	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Cheyenne - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 4WD	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 4WD	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 4WD	Personal audio link module	●	●	●	●	●	●	T036
2013	Chevrolet	Cheyenne - 4WD	Trailer brake control module	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Cheyenne - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Cheyenne - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2013	Chevrolet	Cheyenne - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2013	Chevrolet	Cheyenne - 4WD	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Cheyenne - 4WD	Transmission control module	●	●	●	●	●	●	T001

2013	Chevrolet	Cheyenne - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Cheyenne - 4WD	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Cheyenne - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Cheyenne - 4WD	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Cheyenne - 4WD	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Cheyenne - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Cheyenne - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Cheyenne - 4WD	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Cheyenne - 4WD	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Cheyenne - 4WD	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Cheyenne - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 4WD	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 4WD	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 4WD	Personal audio link module	●	●	●	●	●	●	T036
2013	Chevrolet	Cheyenne - 4WD	Trailer brake control module	●	●	●	●	●	○	
2013	Chevrolet	Cheyenne - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Cheyenne - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Cheyenne - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014

2013	Chevrolet	Express	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049
2013	Chevrolet	Express	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Express	Radio	●	●	●	●	●	○	
2013	Chevrolet	Express	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T025
2013	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Express	Theft deterrent module	●	●	●	●	●	●	T002 T003
2013	Chevrolet	Express	Navigation radio	●	●	●	●	●	○	
2013	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Express	Transmission control module	●	●	●	●	●	●	T001
2013	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Express	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049
2013	Chevrolet	Express	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Express	Radio	●	●	●	●	●	○	
2013	Chevrolet	Express	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T025

2013	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Express	Theft deterrent module	●	●	●	●	●	●	T002 T003
2013	Chevrolet	Express	Navigation radio	●	●	●	●	●	○	
2013	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Express	Transmission control module	●	●	●	●	●	●	T001
2013	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Express	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049
2013	Chevrolet	Express	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Express	Radio	●	●	●	●	●	○	
2013	Chevrolet	Express	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T025
2013	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Express	Theft deterrent module	●	●	●	●	●	●	T002 T003
2013	Chevrolet	Express	Navigation radio	●	●	●	●	●	○	
2013	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Silverado	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Silverado	Transmission control module	●	●	●	●	●	●	T001

2013	Chevrolet	Silverado	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Silverado	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Silverado	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Silverado	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Silverado	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Silverado	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Silverado	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Silverado	Radio	●	●	●	●	●	●	T036
2013	Chevrolet	Silverado	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Silverado	Trailer brake control module	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Electronic brake control module	●	●	●	●	●	●	T014

2013	Chevrolet	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Silverado	FPCM with trailer brake control	●	●	●	●	●	●	T014
2013	Chevrolet	Silverado	Transfer case control module	●	●	●	●	●	●	T001
2013	Chevrolet	Silverado	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Silverado	Transmission control module	●	●	●	●	●	●	T001
2013	Chevrolet	Silverado	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Silverado	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Silverado	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Silverado	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Silverado	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Silverado	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Silverado	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Passenger door switch	●	●	●	●	●	○	

2013	Chevrolet	Silverado	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Silverado	Radio	●	●	●	●	●	●	T036
2013	Chevrolet	Silverado	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Silverado	Trailer brake control module	●	●	●	●	●	○	
2013	Chevrolet	Silverado	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Silverado	FPCM with trailer brake control	●	●	●	●	●	●	T014
2013	Chevrolet	Silverado	Transfer case control module	●	●	●	●	●	●	T001
2013	Chevrolet	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Silverado hybrid	Fuel pump control module	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Accessory power module	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Silverado hybrid	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Silverado hybrid	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Silverado hybrid	Passenger presence system	●	●	●	●	○	○	

2013	Chevrolet	Silverado hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Silverado hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Silverado hybrid	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Silverado hybrid	A/C compressor control module	●	●	●	●	○	○	
2013	Chevrolet	Silverado hybrid	Serial data gateway module	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Silverado hybrid	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Silverado hybrid	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Silverado hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Silverado hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Silverado hybrid	Radio	●	●	●	●	●	●	T036
2013	Chevrolet	Silverado hybrid	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Silverado hybrid	FPCM with trailer brake control	●	●	●	●	●	○	

2013	Chevrolet	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2013	Chevrolet	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Silverado hybrid	Power steering control module	●	●	●	●	●	●	T044
2013	Chevrolet	Silverado hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Silverado hybrid	Fuel pump control module	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Accessory power module	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Silverado hybrid	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Silverado hybrid	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Silverado hybrid	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Silverado hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Silverado hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Silverado hybrid	Theft deterrent module	●	●	●	●	○	○	

2013	Chevrolet	Silverado hybrid	A/C compressor control module	●	●	●	●	○	○	
2013	Chevrolet	Silverado hybrid	Serial data gateway module	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Silverado hybrid	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Silverado hybrid	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Silverado hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Silverado hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Silverado hybrid	Radio	●	●	●	●	●	●	T036
2013	Chevrolet	Silverado hybrid	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Silverado hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Chevrolet	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2013	Chevrolet	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Silverado hybrid	Power steering control module	●	●	●	●	●	●	T044

2013	Chevrolet	Silverado hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Suburban - 2WD	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Suburban - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Liftgate module	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Suburban - 2WD	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 2WD	Assist step controller	●	●	●	●	●	●	T039
2013	Chevrolet	Suburban - 2WD	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 2WD	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 2WD	Left side object detection module	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Right side object detection module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Suburban - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Driver door switch	●	●	●	●	●	○	

2013	Chevrolet	Suburban - 2WD	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Suburban - 2WD	Radio	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Suburban - 2WD	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Suburban - 2WD	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Suburban - 2WD	Trailer brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2013	Chevrolet	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Suburban - 2WD	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Suburban - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Liftgate module	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2013	Chevrolet	Suburban - 2WD	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 2WD	Assist step controller	●	●	●	●	●	●	T039
2013	Chevrolet	Suburban - 2WD	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 2WD	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 2WD	Left side object detection module	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Right side object detection module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Suburban - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Suburban - 2WD	Radio	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Suburban - 2WD	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Suburban - 2WD	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Suburban - 2WD	Trailer brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2013	Chevrolet	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Suburban - 4WD	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Suburban - 4WD	Fuel pump control module	●	●	●	●	●	●	T001

2013	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Liftgate module	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Suburban - 4WD	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 4WD	Assist step controller	●	●	●	●	●	●	T039
2013	Chevrolet	Suburban - 4WD	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 4WD	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 4WD	Left side object detection module	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Right side object detection module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Suburban - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Suburban - 4WD	Radio	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Suburban - 4WD	Navigation radio	●	●	●	●	●	●	T037

2013	Chevrolet	Suburban - 4WD	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Suburban - 4WD	Trailer brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2013	Chevrolet	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Suburban - 4WD	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Suburban - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Liftgate module	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Suburban - 4WD	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 4WD	Assist step controller	●	●	●	●	●	●	T039
2013	Chevrolet	Suburban - 4WD	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 4WD	Park assist module	●	●	●	●	○	○	

2013	Chevrolet	Suburban - 4WD	Left side object detection module	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Right side object detection module	●	●	●	●	○	○	
2013	Chevrolet	Suburban - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Suburban - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Suburban - 4WD	Radio	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Suburban - 4WD	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Suburban - 4WD	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Chevrolet	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Suburban - 4WD	Trailer brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2013	Chevrolet	Tahoe	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Tahoe	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Tahoe	Fuel pump control module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Liftgate module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Tahoe	Instrument panel cluster	●	●	●	●	●	○	

2013	Chevrolet	Tahoe	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Tahoe	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Tahoe	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Tahoe	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Assist step controller	●	●	●	●	●	●	T039
2013	Chevrolet	Tahoe	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Left side object detection module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Right side object detection module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Tahoe	Radio	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Tahoe	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Tahoe	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Tahoe	Engine control module	●	●	●	●	●	●	T001

2013	Chevrolet	Tahoe	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Tahoe	Fuel pump control module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Accessory power module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Liftgate module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Tahoe	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Tahoe	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Tahoe	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Tahoe	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	A/C compressor control module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Serial data gateway module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Left side object detection module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Right side object detection module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Amplifier (bose)	●	●	●	●	●	○	

2013	Chevrolet	Tahoe	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Tahoe	Radio	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Tahoe	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Tahoe	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2013	Chevrolet	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Tahoe	Power steering control module	●	●	●	●	●	●	T044
2013	Chevrolet	Tahoe	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Tahoe	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Tahoe	Transfer case control module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Tahoe	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Liftgate module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Tahoe	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Tahoe	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2013	Chevrolet	Tahoe	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Tahoe	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Assist step controller	●	●	●	●	●	●	T039
2013	Chevrolet	Tahoe	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Left side object detection module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Right side object detection module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Tahoe	Radio	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Tahoe	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Tahoe	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Tahoe	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Tahoe	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Tahoe	Transfer case control module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Fuel pump control module	●	●	●	●	●	○	

2013	Chevrolet	Tahoe	Accessory power module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Liftgate module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Tahoe	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Tahoe	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Tahoe	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Tahoe	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	A/C compressor control module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Serial data gateway module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	Left side object detection module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Right side object detection module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Personal audio link module	○	○	○	○	○	●	T037

2013	Chevrolet	Tahoe	Radio	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Tahoe	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Tahoe	FPCM with trailer brake control	●	●	●	●	●	○	
2013	Chevrolet	Tahoe	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2013	Chevrolet	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Tahoe	Power steering control module	●	●	●	●	●	●	T044
2013	Chevrolet	Tahoe hybrid	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Tahoe hybrid	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Tahoe hybrid	Transfer case control module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe hybrid	Fuel pump control module	●	●	●	●	●	●	T001
2013	Chevrolet	Tahoe hybrid	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Tahoe hybrid	Liftgate module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	Chevrolet	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Tahoe hybrid	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe hybrid	Assist step controller	●	●	●	●	●	●	T039
2013	Chevrolet	Tahoe hybrid	Memory seat module	●	●	●	●	●	○	

2013	Chevrolet	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2013	Chevrolet	Tahoe hybrid	Passenger presence system	●	●	●	●	○	○	
2013	Chevrolet	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe hybrid	A/C compressor control module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe hybrid	Serial data gateway module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe hybrid	Heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe hybrid	Rear heated seat module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe hybrid	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe hybrid	Left side object detection module	●	●	●	●	●	○	
2013	Chevrolet	Tahoe hybrid	Right side object detection module	●	●	●	●	○	○	
2013	Chevrolet	Tahoe hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Tahoe hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Tahoe hybrid	Amplifier (bose)	●	●	●	●	●	○	
2013	Chevrolet	Tahoe hybrid	Driver door switch	●	●	●	●	●	○	
2013	Chevrolet	Tahoe hybrid	Passenger door switch	●	●	●	●	●	○	
2013	Chevrolet	Tahoe hybrid	Personal audio link module	○	○	○	○	○	●	T037
2013	Chevrolet	Tahoe hybrid	Radio	●	●	●	●	●	○	
2013	Chevrolet	Tahoe hybrid	Body control module	●	●	●	●	●	●	T007 T005
2013	Chevrolet	Tahoe hybrid	Navigation radio	●	●	●	●	●	●	T037
2013	Chevrolet	Tahoe hybrid	FPCM with trailer brake control	●	●	●	●	●	○	

2013	Chevrolet	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2013	Chevrolet	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2013	Chevrolet	Tahoe hybrid	Power steering control module	●	●	●	●	●	●	T044
2013	Chevrolet	Traverse - AWD	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Traverse - AWD	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Traverse - AWD	Fuel pump control module	●	●	●	●	●	○	
2013	Chevrolet	Traverse - AWD	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Traverse - AWD	Liftgate module	●	●	●	●	●	○	
2013	Chevrolet	Traverse - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	Chevrolet	Traverse - AWD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Traverse - AWD	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Traverse - AWD	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Traverse - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Traverse - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Traverse - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Traverse - AWD	Driver door switch	●	●	●	●	●	●	T035
2013	Chevrolet	Traverse - AWD	Passenger door switch	●	●	●	●	●	●	T035
2013	Chevrolet	Traverse - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2013	Chevrolet	Traverse - AWD	Radio	●	●	●	●	●	○	
2013	Chevrolet	Traverse - AWD	Passenger presence system	●	●	●	●	●	○	
2013	Chevrolet	Traverse - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Traverse - AWD	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Traverse - AWD	Body control module	●	●	●	●	●	●	T007 T005

2013	Chevrolet	Traverse - AWD	Left side object detection module	●	●	●	○	●	○	
2013	Chevrolet	Traverse - AWD	Right side object detection module	●	●	●	●	●	●	T002 T003
2013	Chevrolet	Traverse - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Traverse - AWD	Rear drive system	●	●	●	●	●	●	T038
2013	Chevrolet	Traverse - FWD	Engine control module	●	●	●	●	●	●	T001
2013	Chevrolet	Traverse - FWD	Transmission control module	●	●	○	●	●	○	
2013	Chevrolet	Traverse - FWD	Fuel pump control module	●	●	●	●	●	○	
2013	Chevrolet	Traverse - FWD	Digital radio receiver	●	●	●	●	●	○	
2013	Chevrolet	Traverse - FWD	Liftgate module	●	●	●	●	●	○	
2013	Chevrolet	Traverse - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	Chevrolet	Traverse - FWD	Instrument panel cluster	●	●	●	●	●	○	
2013	Chevrolet	Traverse - FWD	Memory seat module	●	●	●	●	●	○	
2013	Chevrolet	Traverse - FWD	Park assist module	●	●	●	●	○	○	
2013	Chevrolet	Traverse - FWD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	Chevrolet	Traverse - FWD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	Chevrolet	Traverse - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	Chevrolet	Traverse - FWD	Driver door switch	●	●	●	●	●	●	T035
2013	Chevrolet	Traverse - FWD	Passenger door switch	●	●	●	●	●	●	T035
2013	Chevrolet	Traverse - FWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2013	Chevrolet	Traverse - FWD	Radio	●	●	●	●	●	○	
2013	Chevrolet	Traverse - FWD	Passenger presence system	●	●	●	●	●	○	
2013	Chevrolet	Traverse - FWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	Chevrolet	Traverse - FWD	Theft deterrent module	●	●	●	●	○	○	
2013	Chevrolet	Traverse - FWD	Body control module	●	●	●	●	●	●	T007 T005

2013	Chevrolet	Traverse - FWD	Left side object detection module	●	●	●	○	●	○	
2013	Chevrolet	Traverse - FWD	Right side object detection module	●	●	●	●	●	●	T002 T003
2013	Chevrolet	Traverse - FWD	Electronic brake control module	●	●	●	●	●	●	T014
2013	Chevrolet	Traverse - FWD	Rear drive system	●	●	●	●	●	●	T038
2013	GMC truck	Acadia - 2WD	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Acadia - 2WD	Transmission control module	●	●	○	●	●	○	
2013	GMC truck	Acadia - 2WD	Fuel pump control module	●	●	●	●	●	○	
2013	GMC truck	Acadia - 2WD	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Acadia - 2WD	Liftgate module	●	●	●	●	●	○	
2013	GMC truck	Acadia - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	GMC truck	Acadia - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Acadia - 2WD	Head up display	●	●	●	●	○	○	
2013	GMC truck	Acadia - 2WD	Memory seat module	●	●	●	●	●	○	
2013	GMC truck	Acadia - 2WD	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Acadia - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	GMC truck	Acadia - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	GMC truck	Acadia - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Acadia - 2WD	Driver door switch	●	●	●	●	●	●	T035
2013	GMC truck	Acadia - 2WD	Passenger door switch	●	●	●	●	●	●	T035
2013	GMC truck	Acadia - 2WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2013	GMC truck	Acadia - 2WD	Radio	●	●	●	●	●	○	
2013	GMC truck	Acadia - 2WD	Passenger presence system	●	●	●	●	●	○	
2013	GMC truck	Acadia - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	GMC truck	Acadia - 2WD	Theft deterrent module	●	●	●	●	○	○	

2013	GMC truck	Acadia - 2WD	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Acadia - 2WD	Left side object detection module	●	●	●	○	●	○	
2013	GMC truck	Acadia - 2WD	Right side object detection module	●	●	●	●	●	●	T002 T003
2013	GMC truck	Acadia - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Acadia - 4WD	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Acadia - 4WD	Transmission control module	●	●	○	●	●	○	
2013	GMC truck	Acadia - 4WD	Fuel pump control module	●	●	●	●	●	○	
2013	GMC truck	Acadia - 4WD	Rear drive system	●	●	●	●	○	●	T038
2013	GMC truck	Acadia - 4WD	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Acadia - 4WD	Liftgate module	●	●	●	●	●	○	
2013	GMC truck	Acadia - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	GMC truck	Acadia - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Acadia - 4WD	Head up display	●	●	●	●	○	○	
2013	GMC truck	Acadia - 4WD	Memory seat module	●	●	●	●	●	○	
2013	GMC truck	Acadia - 4WD	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Acadia - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2013	GMC truck	Acadia - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2013	GMC truck	Acadia - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Acadia - 4WD	Driver door switch	●	●	●	●	●	●	T035
2013	GMC truck	Acadia - 4WD	Passenger door switch	●	●	●	●	●	●	T035
2013	GMC truck	Acadia - 4WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2013	GMC truck	Acadia - 4WD	Radio	●	●	●	●	●	○	
2013	GMC truck	Acadia - 4WD	Passenger presence system	●	●	●	●	●	○	
2013	GMC truck	Acadia - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2013	GMC truck	Acadia - 4WD	Theft deterrent module	●	●	●	●	○	○	
2013	GMC truck	Acadia - 4WD	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Acadia - 4WD	Left side object detection module	●	●	●	○	●	○	
2013	GMC truck	Acadia - 4WD	Right side object detection module	●	●	●	●	●	●	T002 T003
2013	GMC truck	Acadia - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Savana	Transmission control module	●	●	●	●	●	●	T001
2013	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2013	GMC truck	Savana	Auxiliary heater control module	●	●	●	●	●	●	T047 T046 T048 T048
2013	GMC truck	Savana	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2013	GMC truck	Savana	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Savana	Radio	●	●	●	●	●	○	
2013	GMC truck	Savana	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T025
2013	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Savana	Theft deterrent module	●	●	●	●	●	●	T002 T003
2013	GMC truck	Savana	Navigation radio	●	●	●	●	●	○	
2013	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001

2013	GMC truck	Savana	Transmission control module	●	●	●	●	●	●	T001
2013	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2013	GMC truck	Savana	Auxiliary heater control module	●	●	●	●	●	●	T047 T046 T048 T048
2013	GMC truck	Savana	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2013	GMC truck	Savana	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Savana	Radio	●	●	●	●	●	○	
2013	GMC truck	Savana	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T025
2013	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Savana	Theft deterrent module	●	●	●	●	●	●	T002 T003
2013	GMC truck	Savana	Navigation radio	●	●	●	●	●	○	
2013	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Savana	Transmission control module	●	●	●	●	●	●	T001
2013	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2013	GMC truck	Savana	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	

2013	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2013	GMC truck	Savana	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Savana	Radio	●	●	●	●	●	○	
2013	GMC truck	Savana	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T025
2013	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Savana	Theft deterrent module	●	●	●	●	●	●	T002 T003
2013	GMC truck	Savana	Navigation radio	●	●	●	●	●	○	
2013	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Savana	Transmission control module	●	●	●	●	●	●	T001
2013	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2013	GMC truck	Savana	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2013	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2013	GMC truck	Savana	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Savana	Radio	●	●	●	●	●	○	
2013	GMC truck	Savana	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T025
2013	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Savana	Theft deterrent module	●	●	●	●	●	●	T002 T003

2013	GMC truck	Savana	Navigation radio	●	●	●	●	●	○	
2013	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Sierra	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Sierra	Transmission control module	●	●	●	●	●	●	T001
2013	GMC truck	Sierra	Fuel pump control module	●	●	●	●	●	●	T001
2013	GMC truck	Sierra	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Sierra	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Sierra	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Sierra	Body control module (aux.)	●	●	●	●	●	●	T006
2013	GMC truck	Sierra	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Sierra	Passenger presence system	●	●	●	●	○	○	
2013	GMC truck	Sierra	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	GMC truck	Sierra	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Sierra	Theft deterrent module	●	●	●	●	○	○	
2013	GMC truck	Sierra	Memory seat module	●	●	●	●	●	○	
2013	GMC truck	Sierra	Rear heated seat module	●	●	●	●	○	○	
2013	GMC truck	Sierra	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Sierra	HVAC control module	●	●	●	●	●	●	T008 T034
2013	GMC truck	Sierra	Rear HVAC/RSA	●	●	●	●	●	○	
2013	GMC truck	Sierra	Amplifier (bose)	●	●	●	●	●	○	
2013	GMC truck	Sierra	Driver door switch	●	●	●	●	●	○	
2013	GMC truck	Sierra	Passenger door switch	●	●	●	●	●	○	
2013	GMC truck	Sierra	Personal audio link module	○	○	○	○	○	●	T037
2013	GMC truck	Sierra	Radio	●	●	●	●	●	●	T036

2013	GMC truck	Sierra	Navigation radio	●	●	●	●	●	●	T037
2013	GMC truck	Sierra	Trailer brake control module	●	●	●	●	●	○	
2013	GMC truck	Sierra	Electronic brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Sierra	Electronic suspension control	●	●	●	●	●	●	T040
2013	GMC truck	Sierra	FPCM with trailer brake control	●	●	●	●	●	●	T014
2013	GMC truck	Sierra	Transfer case control module	●	●	●	●	●	●	T001
2013	GMC truck	Sierra	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Sierra	Transmission control module	●	●	●	●	●	●	T001
2013	GMC truck	Sierra	Fuel pump control module	●	●	●	●	●	●	T001
2013	GMC truck	Sierra	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Sierra	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Sierra	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Sierra	Body control module (aux.)	●	●	●	●	●	●	T006
2013	GMC truck	Sierra	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Sierra	Passenger presence system	●	●	●	●	○	○	
2013	GMC truck	Sierra	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	GMC truck	Sierra	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Sierra	Theft deterrent module	●	●	●	●	○	○	
2013	GMC truck	Sierra	Memory seat module	●	●	●	●	●	○	
2013	GMC truck	Sierra	Rear heated seat module	●	●	●	●	○	○	
2013	GMC truck	Sierra	Park assist module	●	●	●	●	○	○	

2013	GMC truck	Sierra	HVAC control module	●	●	●	●	●	●	T008 T034
2013	GMC truck	Sierra	Rear HVAC/RSA	●	●	●	●	●	○	
2013	GMC truck	Sierra	Amplifier (bose)	●	●	●	●	●	○	
2013	GMC truck	Sierra	Driver door switch	●	●	●	●	●	○	
2013	GMC truck	Sierra	Passenger door switch	●	●	●	●	●	○	
2013	GMC truck	Sierra	Personal audio link module	○	○	○	○	○	●	T037
2013	GMC truck	Sierra	Radio	●	●	●	●	●	●	T036
2013	GMC truck	Sierra	Navigation radio	●	●	●	●	●	●	T037
2013	GMC truck	Sierra	Trailer brake control module	●	●	●	●	●	○	
2013	GMC truck	Sierra	Electronic brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Sierra	Electronic suspension control	●	●	●	●	●	●	T040
2013	GMC truck	Sierra	FPCM with trailer brake control	●	●	●	●	●	●	T014
2013	GMC truck	Sierra	Transfer case control module	●	●	●	●	●	●	T001
2013	GMC truck	Sierra hybrid	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Sierra hybrid	Transmission control module	●	●	○	●	●	○	
2013	GMC truck	Sierra hybrid	Fuel pump control module	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Accessory power module	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Sierra hybrid	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2013	GMC truck	Sierra hybrid	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Sierra hybrid	Passenger presence system	●	●	●	●	○	○	

2013	GMC truck	Sierra hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	GMC truck	Sierra hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Sierra hybrid	Theft deterrent module	●	●	●	●	○	○	
2013	GMC truck	Sierra hybrid	A/C compressor control module	●	●	●	●	○	○	
2013	GMC truck	Sierra hybrid	Serial data gateway module	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Heated seat module	●	●	●	●	○	○	
2013	GMC truck	Sierra hybrid	Rear heated seat module	●	●	●	●	○	○	
2013	GMC truck	Sierra hybrid	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Sierra hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2013	GMC truck	Sierra hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Amplifier (bose)	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Driver door switch	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Passenger door switch	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Personal audio link module	○	○	○	○	○	●	T037
2013	GMC truck	Sierra hybrid	Radio	●	●	●	●	●	●	T036
2013	GMC truck	Sierra hybrid	Navigation radio	●	●	●	●	●	●	T037
2013	GMC truck	Sierra hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2013	GMC truck	Sierra hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2013	GMC truck	Sierra hybrid	Power steering control module	●	●	●	●	●	●	T044
2013	GMC truck	Sierra hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Sierra hybrid	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Sierra hybrid	Transmission control module	●	●	○	●	●	○	

2013	GMC truck	Sierra hybrid	Fuel pump control module	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Accessory power module	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Sierra hybrid	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2013	GMC truck	Sierra hybrid	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Sierra hybrid	Passenger presence system	●	●	●	●	○	○	
2013	GMC truck	Sierra hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	GMC truck	Sierra hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Sierra hybrid	Theft deterrent module	●	●	●	●	○	○	
2013	GMC truck	Sierra hybrid	A/C compressor control module	●	●	●	●	○	○	
2013	GMC truck	Sierra hybrid	Serial data gateway module	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Heated seat module	●	●	●	●	○	○	
2013	GMC truck	Sierra hybrid	Rear heated seat module	●	●	●	●	○	○	
2013	GMC truck	Sierra hybrid	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Sierra hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2013	GMC truck	Sierra hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Amplifier (bose)	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Driver door switch	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Passenger door switch	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Personal audio link module	○	○	○	○	○	●	T037
2013	GMC truck	Sierra hybrid	Radio	●	●	●	●	●	●	T036
2013	GMC truck	Sierra hybrid	Navigation radio	●	●	●	●	●	●	T037

2013	GMC truck	Sierra hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2013	GMC truck	Sierra hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2013	GMC truck	Sierra hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2013	GMC truck	Sierra hybrid	Power steering control module	●	●	●	●	●	●	T044
2013	GMC truck	Sierra hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Yukon	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Yukon	Liftgate module	●	●	●	●	●	○	
2013	GMC truck	Yukon	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Yukon	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Yukon	Body control module (aux.)	●	●	●	●	●	●	T006
2013	GMC truck	Yukon	Passenger presence system	●	●	●	●	○	○	
2013	GMC truck	Yukon	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	GMC truck	Yukon	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Yukon	Theft deterrent module	●	●	●	●	○	○	
2013	GMC truck	Yukon	Assist step controller	●	●	●	●	●	●	T039
2013	GMC truck	Yukon	Memory seat module	●	●	●	●	●	○	
2013	GMC truck	Yukon	Rear heated seat module	●	●	●	●	○	○	
2013	GMC truck	Yukon	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Yukon	Left side object detection module	●	●	●	●	●	○	
2013	GMC truck	Yukon	Right side object detection module	●	●	●	●	○	○	
2013	GMC truck	Yukon	HVAC control module	●	●	●	●	●	●	T008 T034

2013	GMC truck	Yukon	Rear HVAC/RSA	●	●	●	●	●	○	
2013	GMC truck	Yukon	Amplifier (bose)	●	●	●	●	●	○	
2013	GMC truck	Yukon	Driver door switch	●	●	●	●	●	○	
2013	GMC truck	Yukon	Passenger door switch	●	●	●	●	●	○	
2013	GMC truck	Yukon	Personal audio link module	○	○	○	○	○	●	T037
2013	GMC truck	Yukon	Radio	●	●	●	●	●	○	
2013	GMC truck	Yukon	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Yukon	Navigation radio	●	●	●	●	●	●	T037
2013	GMC truck	Yukon	FPCM with trailer brake control	●	●	●	●	●	○	
2013	GMC truck	Yukon	Electronic brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Yukon	Electronic suspension control	●	●	●	●	●	●	T040
2013	GMC truck	Yukon	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Yukon	Transmission control module	●	●	○	●	●	○	
2013	GMC truck	Yukon	Fuel pump control module	●	●	●	●	●	●	T001
2013	GMC truck	Yukon	Transfer case control module	●	●	●	●	●	●	T001
2013	GMC truck	Yukon	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Yukon	Liftgate module	●	●	●	●	●	○	
2013	GMC truck	Yukon	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Yukon	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Yukon	Body control module (aux.)	●	●	●	●	●	●	T006
2013	GMC truck	Yukon	Passenger presence system	●	●	●	●	○	○	
2013	GMC truck	Yukon	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2013	GMC truck	Yukon	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Yukon	Theft deterrent module	●	●	●	●	○	○	
2013	GMC truck	Yukon	Assist step controller	●	●	●	●	●	●	T039
2013	GMC truck	Yukon	Memory seat module	●	●	●	●	●	○	
2013	GMC truck	Yukon	Rear heated seat module	●	●	●	●	○	○	
2013	GMC truck	Yukon	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Yukon	Left side object detection module	●	●	●	●	●	○	
2013	GMC truck	Yukon	Right side object detection module	●	●	●	●	○	○	
2013	GMC truck	Yukon	HVAC control module	●	●	●	●	●	●	T008 T034
2013	GMC truck	Yukon	Rear HVAC/RSA	●	●	●	●	●	○	
2013	GMC truck	Yukon	Amplifier (bose)	●	●	●	●	●	○	
2013	GMC truck	Yukon	Driver door switch	●	●	●	●	●	○	
2013	GMC truck	Yukon	Passenger door switch	●	●	●	●	●	○	
2013	GMC truck	Yukon	Personal audio link module	○	○	○	○	○	●	T037
2013	GMC truck	Yukon	Radio	●	●	●	●	●	○	
2013	GMC truck	Yukon	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Yukon	Navigation radio	●	●	●	●	●	●	T037
2013	GMC truck	Yukon	FPCM with trailer brake control	●	●	●	●	●	○	
2013	GMC truck	Yukon	Electronic brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Yukon	Electronic suspension control	●	●	●	●	●	●	T040
2013	GMC truck	Yukon	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Yukon	Transmission control module	●	●	○	●	●	○	
2013	GMC truck	Yukon	Fuel pump control module	●	●	●	●	●	●	T001
2013	GMC truck	Yukon	Transfer case control module	●	●	●	●	●	●	T001

2013	GMC truck	Yukon hybrid	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Yukon hybrid	Transmission control module	●	●	○	●	●	○	
2013	GMC truck	Yukon hybrid	Fuel pump control module	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Accessory power module	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Liftgate module	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Yukon hybrid	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2013	GMC truck	Yukon hybrid	Passenger presence system	●	●	●	●	○	○	
2013	GMC truck	Yukon hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	GMC truck	Yukon hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Yukon hybrid	Theft deterrent module	●	●	●	●	○	○	
2013	GMC truck	Yukon hybrid	A/C compressor control module	●	●	●	●	○	○	
2013	GMC truck	Yukon hybrid	Serial data gateway module	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Assist step controller	●	●	●	●	●	●	T039
2013	GMC truck	Yukon hybrid	Heated seat module	●	●	●	●	○	○	
2013	GMC truck	Yukon hybrid	Rear heated seat module	●	●	●	●	○	○	
2013	GMC truck	Yukon hybrid	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Yukon hybrid	Left side object detection module	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Right side object detection module	●	●	●	●	○	○	
2013	GMC truck	Yukon hybrid	HVAC control module	●	●	●	●	●	●	T008 T034

2013	GMC truck	Yukon hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Amplifier (bose)	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Driver door switch	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Passenger door switch	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Personal audio link module	○	○	○	○	○	●	T037
2013	GMC truck	Yukon hybrid	Radio	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Yukon hybrid	Navigation radio	●	●	●	●	●	●	T037
2013	GMC truck	Yukon hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2013	GMC truck	Yukon hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2013	GMC truck	Yukon hybrid	Power steering control module	●	●	●	●	●	●	T044
2013	GMC truck	Yukon hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Yukon hybrid	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Yukon hybrid	Transmission control module	●	●	○	●	●	○	
2013	GMC truck	Yukon hybrid	Fuel pump control module	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Accessory power module	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Liftgate module	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Yukon hybrid	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2013	GMC truck	Yukon hybrid	Passenger presence system	●	●	●	●	○	○	

2013	GMC truck	Yukon hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	GMC truck	Yukon hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Yukon hybrid	Theft deterrent module	●	●	●	●	○	○	
2013	GMC truck	Yukon hybrid	A/C compressor control module	●	●	●	●	○	○	
2013	GMC truck	Yukon hybrid	Serial data gateway module	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Assist step controller	●	●	●	●	●	●	T039
2013	GMC truck	Yukon hybrid	Heated seat module	●	●	●	●	○	○	
2013	GMC truck	Yukon hybrid	Rear heated seat module	●	●	●	●	○	○	
2013	GMC truck	Yukon hybrid	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Yukon hybrid	Left side object detection module	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Right side object detection module	●	●	●	●	○	○	
2013	GMC truck	Yukon hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2013	GMC truck	Yukon hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Amplifier (bose)	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Driver door switch	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Passenger door switch	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Personal audio link module	○	○	○	○	○	●	T037
2013	GMC truck	Yukon hybrid	Radio	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Yukon hybrid	Navigation radio	●	●	●	●	●	●	T037
2013	GMC truck	Yukon hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2013	GMC truck	Yukon hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2013	GMC truck	Yukon hybrid	Electronic suspension control	●	●	●	●	●	●	T040

2013	GMC truck	Yukon hybrid	Power steering control module	●	●	●	●	●	●	T044
2013	GMC truck	Yukon hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Yukon XL	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Yukon XL	Transmission control module	●	●	○	●	●	○	
2013	GMC truck	Yukon XL	Fuel pump control module	●	●	●	●	●	●	T001
2013	GMC truck	Yukon XL	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Liftgate module	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Yukon XL	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Body control module (aux.)	●	●	●	●	●	●	T006
2013	GMC truck	Yukon XL	Passenger presence system	●	●	●	●	○	○	
2013	GMC truck	Yukon XL	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2013	GMC truck	Yukon XL	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Yukon XL	Theft deterrent module	●	●	●	●	○	○	
2013	GMC truck	Yukon XL	Assist step controller	●	●	●	●	●	●	T039
2013	GMC truck	Yukon XL	Memory seat module	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Rear heated seat module	●	●	●	●	○	○	
2013	GMC truck	Yukon XL	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Yukon XL	Left side object detection module	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Right side object detection module	●	●	●	●	○	○	
2013	GMC truck	Yukon XL	HVAC control module	●	●	●	●	●	●	T008 T034
2013	GMC truck	Yukon XL	Rear HVAC/RSA	●	●	●	●	●	○	

2013	GMC truck	Yukon XL	Amplifier (bose)	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Driver door switch	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Passenger door switch	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Personal audio link module	○	○	○	○	○	●	T037
2013	GMC truck	Yukon XL	Radio	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Yukon XL	Navigation radio	●	●	●	●	●	●	T037
2013	GMC truck	Yukon XL	FPCM with trailer brake control	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Electronic brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Yukon XL	Electronic suspension control	●	●	●	●	●	●	T040
2013	GMC truck	Yukon XL	Trailer brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Yukon XL	Transfer case control module	●	●	●	●	●	●	T001
2013	GMC truck	Yukon XL	Engine control module	●	●	●	●	●	●	T001
2013	GMC truck	Yukon XL	Transmission control module	●	●	○	●	●	○	
2013	GMC truck	Yukon XL	Fuel pump control module	●	●	●	●	●	●	T001
2013	GMC truck	Yukon XL	Digital radio receiver	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Liftgate module	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2013	GMC truck	Yukon XL	Instrument panel cluster	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Body control module (aux.)	●	●	●	●	●	●	T006
2013	GMC truck	Yukon XL	Passenger presence system	●	●	●	●	○	○	
2013	GMC truck	Yukon XL	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2013	GMC truck	Yukon XL	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2013	GMC truck	Yukon XL	Theft deterrent module	●	●	●	●	○	○	
2013	GMC truck	Yukon XL	Assist step controller	●	●	●	●	●	●	T039
2013	GMC truck	Yukon XL	Memory seat module	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Rear heated seat module	●	●	●	●	○	○	
2013	GMC truck	Yukon XL	Park assist module	●	●	●	●	○	○	
2013	GMC truck	Yukon XL	Left side object detection module	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Right side object detection module	●	●	●	●	○	○	
2013	GMC truck	Yukon XL	HVAC control module	●	●	●	●	●	●	T008 T034
2013	GMC truck	Yukon XL	Rear HVAC/RSA	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Amplifier (bose)	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Driver door switch	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Passenger door switch	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Personal audio link module	○	○	○	○	○	●	T037
2013	GMC truck	Yukon XL	Radio	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Body control module	●	●	●	●	●	●	T007 T005
2013	GMC truck	Yukon XL	Navigation radio	●	●	●	●	●	●	T037
2013	GMC truck	Yukon XL	FPCM with trailer brake control	●	●	●	●	●	○	
2013	GMC truck	Yukon XL	Electronic brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Yukon XL	Electronic suspension control	●	●	●	●	●	●	T040
2013	GMC truck	Yukon XL	Trailer brake control module	●	●	●	●	●	●	T014
2013	GMC truck	Yukon XL	Transfer case control module	●	●	●	●	●	●	T001
2012	Buick	LaCrosse	Engine Control Module	●	●	●	●	●	●	S044 S029 S025 S030
2012	Buick	LaCrosse	Fuel Injector Control Module	●	●	●	●	●	○	

2012	Buick	LaCrosse	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Buick	LaCrosse	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2012	Buick	LaCrosse	Transmission Control Module	●	●	●	●	●	●	S048
2012	Buick	LaCrosse	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2012	Buick	LaCrosse	Drive Motor Control Module	●	●	●	●	○	○	
2012	Buick	LaCrosse	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2012	Buick	LaCrosse	Parking Brake Control Module	●	●	●	●	●	●	S037
2012	Buick	LaCrosse	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Buick	LaCrosse	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2012	Buick	LaCrosse	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Buick	LaCrosse	Suspension Control Module	●	●	●	●	●	○	
2012	Buick	LaCrosse	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2012	Buick	LaCrosse	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2012	Buick	LaCrosse	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Buick	LaCrosse	Instrument Cluster	●	●	●	●	●	●	S022
2012	Buick	LaCrosse	Head-Up Display Module	●	●	●	●	●	○	
2012	Buick	LaCrosse	Headlamp Control Module	●	●	●	●	●	●	

2012	Buick	LaCrosse	Radio	●	●	●	●	●	○	
2012	Buick	LaCrosse	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022 S022
2012	Buick	LaCrosse	Multimedia Player Interface Module	●	●	●	●	○	●	
2012	Buick	LaCrosse	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2012	Buick	LaCrosse	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Buick	LaCrosse	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2012	Buick	LaCrosse	Seat Memory Control Module	●	●	●	●	●	●	S031
2012	Buick	LaCrosse	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Buick	LaCrosse	Rear Seat Heating Control Module	●	●	●	●	●	○	
2012	Buick	LaCrosse	Keyless Entry Control Module	●	●	●	●	●	○	
2012	Buick	LaCrosse	Parking Assist Control Module	●	●	●	●	●	●	S022
2012	Buick	LaCrosse	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168
2012	Buick	LaCrosse	Steering Column Lock Control Module	●	●	●	●	○	●	
2012	Buick	LaCrosse	Battery Energy Control Module	○	○	●	●	○	○	
2012	Buick	LaCrosse	Left Side Object Detection Control Module	●	●	●	●	●	○	

2012	Buick	LaCrosse	Right Side Object Detection Control Module	●	●	●	●	●	○	
2012	Buick	Regal	Engine Control Module	●	●	●	●	●	●	S044 S029 S025 S030
2012	Buick	Regal	Fuel Injector Control Module	●	●	●	●	●	○	
2012	Buick	Regal	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Buick	Regal	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2012	Buick	Regal	Transmission Control Module	●	●	●	●	●	●	S048
2012	Buick	Regal	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2012	Buick	Regal	Drive Motor Control Module	●	●	●	●	○	○	
2012	Buick	Regal	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2012	Buick	Regal	Parking Brake Control Module	●	●	●	●	●	●	S037
2012	Buick	Regal	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Buick	Regal	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2012	Buick	Regal	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Buick	Regal	Suspension Control Module	●	●	●	●	●	○	
2012	Buick	Regal	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2012	Buick	Regal	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024

2012	Buick	Regal	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Buick	Regal	Instrument Cluster	●	●	●	●	●	●	S022
2012	Buick	Regal	Head-Up Display Module	●	●	●	●	●	○	
2012	Buick	Regal	Headlamp Control Module	●	●	●	●	●	●	
2012	Buick	Regal	Radio	●	●	●	●	●	○	
2012	Buick	Regal	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022 S022
2012	Buick	Regal	Multimedia Player Interface Module	●	●	●	●	○	●	
2012	Buick	Regal	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2012	Buick	Regal	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Buick	Regal	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2012	Buick	Regal	Seat Memory Control Module	●	●	●	●	●	●	S031
2012	Buick	Regal	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Buick	Regal	Rear Seat Heating Control Module	●	●	●	●	●	○	
2012	Buick	Regal	Keyless Entry Control Module	●	●	●	●	●	○	
2012	Buick	Regal	Parking Assist Control Module	●	●	●	●	●	●	S022
2012	Buick	Regal	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168
2012	Buick	Regal	Steering Column Lock Control Module	●	●	●	●	○	●	

2012	Buick	Regal	Battery Energy Control Module	○	○	●	●	○	○	
2012	Buick	Regal	Left Side Object Detection Control Module	●	●	●	●	●	○	
2012	Buick	Regal	Right Side Object Detection Control Module	●	●	●	●	●	○	
2012	Buick	Verano	Engine Control Module	●	●	●	●	●	●	S044 S026 S027 S028 S001 S029 S025
2012	Buick	Verano	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Buick	Verano	Transmission Control Module	●	●	●	●	●	●	S023
2012	Buick	Verano	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2012	Buick	Verano	Parking Brake Control Module	●	●	●	●	●	●	S037
2012	Buick	Verano	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Buick	Verano	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2012	Buick	Verano	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Buick	Verano	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2012	Buick	Verano	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2012	Buick	Verano	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Buick	Verano	Instrument Cluster	●	●	●	●	●	●	
2012	Buick	Verano	Headlamp Control Module	●	●	●	●	●	●	

2012	Buick	Verano	Radio	●	●	●	●	●	○	
2012	Buick	Verano	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Buick	Verano	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2012	Buick	Verano	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Buick	Verano	Keyless Entry Control Module	●	●	●	●	●	○	
2012	Buick	Verano	Parking Assist Control Module	●	●	●	●	●	●	S022
2012	Cadillac	SRX	Engine Control Module	●	●	●	●	●	●	S028 S029 S025 S030
2012	Cadillac	SRX	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Cadillac	SRX	Transmission Control Module	●	●	●	●	●	●	S057 S082
2012	Cadillac	SRX	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2012	Cadillac	SRX	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2012	Cadillac	SRX	Parking Brake Control Module	●	●	●	●	●	●	S037
2012	Cadillac	SRX	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Cadillac	SRX	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Cadillac	SRX	Suspension Control Module	●	●	●	●	●	○	
2012	Cadillac	SRX	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021

2012	Cadillac	SRX	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2012	Cadillac	SRX	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Cadillac	SRX	Instrument Cluster	●	●	●	●	●	●	S022
2012	Cadillac	SRX	Headlamp Control Module	●	●	●	●	●	●	
2012	Cadillac	SRX	Trailer Interface Control Module	●	●	●	●	●	●	S022
2012	Cadillac	SRX	Radio	●	●	●	●	●	○	
2012	Cadillac	SRX	Rear Audio Control Module	●	●	●	●	●	○	
2012	Cadillac	SRX	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022 S022
2012	Cadillac	SRX	Multimedia Player Interface Module	●	●	●	●	○	●	
2012	Cadillac	SRX	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2012	Cadillac	SRX	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Cadillac	SRX	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2012	Cadillac	SRX	Liftgate Control Module	●	●	●	●	●	●	S049
2012	Cadillac	SRX	Seat Memory Control Module	●	●	●	●	●	●	S031
2012	Cadillac	SRX	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Cadillac	SRX	Rear Seat Heating Control Module	●	●	●	●	●	○	

2012	Cadillac	SRX	Keyless Entry Control Module	●	●	●	●	●	○	
2012	Cadillac	SRX	Parking Assist Control Module	●	●	●	●	●	●	S022
2012	Cadillac	SRX	Steering Column Lock Control Module	●	●	●	●	○	●	
2012	Cadillac	XTS	Radio	●	●	●	●	●	●	S063 S064
2012	Cadillac	XTS	Glow Plug Control Module	●	●	●	●	●	●	S134 S135 S136 S137 S138 S139 S140 S141
2012	Cadillac	XTS	Transmission Control Module	●	●	●	●	●	●	
2012	Cadillac	XTS	Human Machine Interface Control Module	●	●	●	●	●	●	S064
2012	Cadillac	XTS	Parking Assist Control Module	●	●	●	●	●	●	S081
2012	Cadillac	XTS	Video Processing Control Module	●	●	●	●	●	○	
2012	Cadillac	XTS	Seat Memory Control Module - Left Rear	●	●	●	●	●	○	
2012	Cadillac	XTS	Seat Memory Control Module - Right Rear	●	●	●	●	●	○	
2012	Cadillac	XTS	Seat Memory Control Module - Driver	●	●	●	●	●	●	S031
2012	Cadillac	XTS	Engine Control Module	●	●	●	●	●	●	S112 S103 S119 S120 S121 S122 S029 S123 S124 S125 S126 S127 S128 S129 S130 S131 S132 S030 S133 S134 S135 S136 S137 S138 S139 S140 S141 S142 S143 S144 S145 S146 S147 S148 S149 S150 S151 S152 S153
2012	Cadillac	XTS	Instrument Cluster	●	●	●	●	●	●	

2012	Cadillac	XTS	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018
2012	Cadillac	XTS	HVAC Control Module	●	●	●	●	●	●	S033
2012	Cadillac	XTS	HVAC Controls	●	●	●	●	●	●	S065
2012	Cadillac	XTS	Keyless Entry Control Module	●	●	●	●	●	○	
2012	Cadillac	XTS	Rear Blower Module	●	●	●	●	●	●	S206 S207 S208 S209 S210 S211 S212
2012	Cadillac	XTS	Radio Controls	●	●	●	●	○	●	S065
2012	Cadillac	XTS	Left Side Object Detection Control Module	●	●	●	○	●	○	
2012	Cadillac	XTS	Right Side Object Detection Control Module	●	●	●	○	●	○	
2012	Cadillac	XTS	Suspension Control Module	●	●	●	●	●	●	
2012	Cadillac	XTS	Amplifier	●	●	●	●	○	○	
2012	Chevrolet	Aveo	Engine Control Module	●	●	●	●	●	●	S044 S026
2012	Chevrolet	Aveo	Fuel Injector Control Module	○	○	●	●	●	○	
2012	Chevrolet	Aveo	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Chevrolet	Aveo	Transmission Control Module	●	●	●	●	●	●	S023
2012	Chevrolet	Aveo	Electronic Brake Control Module	●	●	●	●	●	●	S035
2012	Chevrolet	Aveo	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Chevrolet	Aveo	Electric Power Steering Control Module	●	●	●	●	○	●	
2012	Chevrolet	Aveo	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	

2012	Chevrolet	Aveo	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2012	Chevrolet	Aveo	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2012	Chevrolet	Aveo	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Chevrolet	Aveo	Instrument Cluster	●	●	●	●	●	●	S022
2012	Chevrolet	Aveo	Radio	●	●	●	●	●	○	
2012	Chevrolet	Aveo	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2012	Chevrolet	Aveo	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Chevrolet	Aveo	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Chevrolet	Aveo	Parking Assist Control Module	●	●	●	●	●	●	S022
2012	Chevrolet	Beat	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S104 S106 S106 S109 S110 S111 S111 S045 S045 S105 S105 S108 S108 S103 S103 S112 S112 S107 S107 S113 S029 S114 S114 S115 S115 S116 S117 S118 S118
2012	Chevrolet	Beat	Fuel Injector Control Module	●	●	●	●	●	○	
2012	Chevrolet	Beat	Transmission Control Module	●	●	●	●	●	○	

2012	Chevrolet	Beat	Electronic Brake Control Module	●	●	●	●	●	●	S035
2012	Chevrolet	Beat	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Chevrolet	Beat	Electric Power Steering Control Module	●	●	●	●	○	●	
2012	Chevrolet	Beat	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Chevrolet	Beat	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2012	Chevrolet	Beat	Passenger Presence Module	●	●	●	●	●	●	S043
2012	Chevrolet	Beat	Instrument Cluster	●	●	●	●	●	○	
2012	Chevrolet	Camaro	Engine Control Module	●	●	●	●	●	●	S044 S029 S025 S030
2012	Chevrolet	Camaro	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Chevrolet	Camaro	Transmission Control Module	●	●	●	●	●	●	S048
2012	Chevrolet	Camaro	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034
2012	Chevrolet	Camaro	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Chevrolet	Camaro	Power Steering Control Module	●	●	●	●	○	●	
2012	Chevrolet	Camaro	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Chevrolet	Camaro	Suspension Control Module	●	●	●	●	●	●	
2012	Chevrolet	Camaro	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2012	Chevrolet	Camaro	Auxiliary Gage Module	●	●	●	●	●	○	

2012	Chevrolet	Camaro	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2012	Chevrolet	Camaro	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Chevrolet	Camaro	Instrument Cluster	●	●	●	●	●	●	S022
2012	Chevrolet	Camaro	Head-Up Display Module	●	●	●	●	●	○	
2012	Chevrolet	Camaro	Headlamp Control Module	●	●	●	●	●	●	S002
2012	Chevrolet	Camaro	Radio	●	●	●	●	●	○	
2012	Chevrolet	Camaro	Multimedia Player Interface Module	●	●	●	●	○	●	
2012	Chevrolet	Camaro	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2012	Chevrolet	Camaro	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2012	Chevrolet	Camaro	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Chevrolet	Camaro	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2012	Chevrolet	Camaro	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Chevrolet	Camaro	Folding Top Control Module	●	●	●	●	●	○	
2012	Chevrolet	Camaro	Parking Assist Control Module	●	●	●	●	●	●	
2012	Chevrolet	Caprice	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030 S094 S046

2012	Chevrolet	Caprice	Transmission Control Module	●	●	●	●	●	●	S048
2012	Chevrolet	Captiva	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S044 S029 S025 S058
2012	Chevrolet	Captiva	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Chevrolet	Captiva	Transmission Control Module	●	●	●	●	●	●	S023
2012	Chevrolet	Captiva	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2012	Chevrolet	Captiva	Electronic Brake Control Module	●	●	●	●	●	●	S035 S036
2012	Chevrolet	Captiva	Parking Brake Control Module	●	●	●	●	●	●	S037
2012	Chevrolet	Captiva	Body Control Module	●	●	●	●	●	●	S013 S001 S053
2012	Chevrolet	Captiva	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2012	Chevrolet	Captiva	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2012	Chevrolet	Captiva	Instrument Cluster	●	●	●	●	●	○	
2012	Chevrolet	Captiva	Headlamp Control Module	●	●	●	●	●	●	S002 S179
2012	Chevrolet	Captiva	Radio	●	●	●	●	●	●	S187 S213 S189 S188
2012	Chevrolet	Captiva	Mobile Telephone Control Module	●	●	●	●	●	●	S022
2012	Chevrolet	Captiva	HVAC Control Module	●	●	●	○	●	○	
2012	Chevrolet	Captiva	Info Display Module	●	●	●	○	○	●	
2012	Chevrolet	Captiva	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2012	Chevrolet	Captiva	Parking Assist Control Module	●	●	●	●	●	○	
2012	Chevrolet	Captiva	Theft Deterrent Module	●	●	●	●	○	○	
2012	Chevrolet	Cobalt	Engine Control Module	●	●	●	●	●	●	S044 S026

2012	Chevrolet	Cobalt	Fuel Injector Control Module	○	○	●	●	●	○	
2012	Chevrolet	Cobalt	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Chevrolet	Cobalt	Transmission Control Module	●	●	●	●	●	●	S023
2012	Chevrolet	Cobalt	Electronic Brake Control Module	●	●	●	●	●	●	S035
2012	Chevrolet	Cobalt	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Chevrolet	Cobalt	Electric Power Steering Control Module	●	●	●	●	○	●	
2012	Chevrolet	Cobalt	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2012	Chevrolet	Cobalt	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2012	Chevrolet	Cobalt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2012	Chevrolet	Cobalt	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Chevrolet	Cobalt	Instrument Cluster	●	●	●	●	●	●	S022
2012	Chevrolet	Cobalt	Radio	●	●	●	●	●	○	
2012	Chevrolet	Cobalt	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2012	Chevrolet	Cobalt	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039

2012	Chevrolet	Cobalt	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Chevrolet	Cobalt	Parking Assist Control Module	●	●	●	●	●	●	S022
2012	Chevrolet	Colorado	Engine Control Module	●	●	●	●	●	●	S205 S108
2012	Chevrolet	Colorado	Transmission Control Module	●	●	●	●	●	●	S048
2012	Chevrolet	Colorado	Transfer Case Control Module	●	●	●	●	●	●	S080
2012	Chevrolet	Colorado	Electronic Brake Control Module	●	●	●	●	●	●	S035
2012	Chevrolet	Colorado	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S070 S070 S036 S036
2012	Chevrolet	Colorado	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2012	Chevrolet	Colorado	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2012	Chevrolet	Colorado	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2012	Chevrolet	Colorado	Instrument Cluster	●	●	●	●	●	●	
2012	Chevrolet	Colorado	Trailer Interface Control Module	●	●	●	●	●	●	
2012	Chevrolet	Colorado	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2012	Chevrolet	Cruze	Engine Control Module	●	●	●	●	●	●	S029 S025
2012	Chevrolet	Cruze	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Chevrolet	Cruze	Transmission Control Module	●	●	●	●	●	●	S023

2012	Chevrolet	Cruze	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2012	Chevrolet	Cruze	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Chevrolet	Cruze	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2012	Chevrolet	Cruze	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Chevrolet	Cruze	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2012	Chevrolet	Cruze	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2012	Chevrolet	Cruze	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Chevrolet	Cruze	Instrument Cluster	●	●	●	●	●	●	S022
2012	Chevrolet	Cruze	Trailer Interface Control Module	●	●	●	●	●	●	S022
2012	Chevrolet	Cruze	Radio	●	●	●	●	●	○	
2012	Chevrolet	Cruze	Multimedia Player Interface Module	●	●	●	●	○	●	
2012	Chevrolet	Cruze	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2012	Chevrolet	Cruze	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Chevrolet	Cruze	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2012	Chevrolet	Cruze	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Chevrolet	Cruze	Keyless Entry Control Module	●	●	●	●	●	○	

2012	Chevrolet	Cruze	Parking Assist Control Module	●	●	●	●	●	●	
2012	Chevrolet	Cruze	Steering Column Lock Control Module	●	●	●	●	○	●	
2012	Chevrolet	Enjoy	Engine Control Module	●	●	●	●	●	○	
2012	Chevrolet	Enjoy	Electronic Brake Control Module	●	●	●	●	●	○	
2012	Chevrolet	Enjoy	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	
2012	Chevrolet	Equinox	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2012	Chevrolet	Equinox	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Chevrolet	Equinox	Transmission Control Module	●	●	●	●	●	●	S048
2012	Chevrolet	Equinox	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2012	Chevrolet	Equinox	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2012	Chevrolet	Equinox	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Chevrolet	Equinox	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2012	Chevrolet	Equinox	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Chevrolet	Equinox	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2012	Chevrolet	Equinox	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2012	Chevrolet	Equinox	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Chevrolet	Equinox	Instrument Cluster	●	●	●	●	●	●	S022

2012	Chevrolet	Equinox	Radio	●	●	●	●	●	○	
2012	Chevrolet	Equinox	Multimedia Player Interface Module	●	●	●	●	○	●	
2012	Chevrolet	Equinox	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Chevrolet	Equinox	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2012	Chevrolet	Equinox	Liftgate Control Module	●	●	●	●	●	●	S049
2012	Chevrolet	Equinox	Seat Memory Control Module	●	●	●	●	●	●	S031
2012	Chevrolet	Equinox	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Chevrolet	Equinox	Parking Assist Control Module	●	●	●	●	●	●	S022
2012	Chevrolet	Equinox	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168
2012	Chevrolet	Equinox	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2012	Chevrolet	Malibu	Engine Control Module	●	●	●	●	●	●	S044 S029 S025 S030
2012	Chevrolet	Malibu	Fuel Injector Control Module	●	●	●	●	●	○	
2012	Chevrolet	Malibu	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Chevrolet	Malibu	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2012	Chevrolet	Malibu	Transmission Control Module	●	●	●	●	●	●	S048
2012	Chevrolet	Malibu	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2012	Chevrolet	Malibu	Drive Motor Control Module	●	●	●	●	○	○	

2012	Chevrolet	Malibu	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2012	Chevrolet	Malibu	Parking Brake Control Module	●	●	●	●	●	●	S037
2012	Chevrolet	Malibu	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Chevrolet	Malibu	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2012	Chevrolet	Malibu	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Chevrolet	Malibu	Suspension Control Module	●	●	●	●	●	○	
2012	Chevrolet	Malibu	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2012	Chevrolet	Malibu	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2012	Chevrolet	Malibu	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Chevrolet	Malibu	Instrument Cluster	●	●	●	●	●	●	S022
2012	Chevrolet	Malibu	Head-Up Display Module	●	●	●	●	●	○	
2012	Chevrolet	Malibu	Headlamp Control Module	●	●	●	●	●	●	
2012	Chevrolet	Malibu	Radio	●	●	●	●	●	○	
2012	Chevrolet	Malibu	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022 S022
2012	Chevrolet	Malibu	Multimedia Player Interface Module	●	●	●	●	○	●	
2012	Chevrolet	Malibu	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022

2012	Chevrolet	Malibu	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Chevrolet	Malibu	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2012	Chevrolet	Malibu	Seat Memory Control Module	●	●	●	●	●	●	S031
2012	Chevrolet	Malibu	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Chevrolet	Malibu	Rear Seat Heating Control Module	●	●	●	●	●	○	
2012	Chevrolet	Malibu	Keyless Entry Control Module	●	●	●	●	●	○	
2012	Chevrolet	Malibu	Parking Assist Control Module	●	●	●	●	●	●	S022
2012	Chevrolet	Malibu	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168
2012	Chevrolet	Malibu	Steering Column Lock Control Module	●	●	●	●	○	●	
2012	Chevrolet	Malibu	Battery Energy Control Module	○	○	●	●	○	○	
2012	Chevrolet	Malibu	Left Side Object Detection Control Module	●	●	●	●	●	○	
2012	Chevrolet	Malibu	Right Side Object Detection Control Module	●	●	●	●	●	○	
2012	Chevrolet	Orlando	Engine Control Module	●	●	●	●	●	●	S029 S025
2012	Chevrolet	Orlando	Fuel Injector Control Module	●	●	●	●	●	○	
2012	Chevrolet	Orlando	Fuel Pump Control Module	●	●	●	●	●	●	S025

2012	Chevrolet	Orlando	Transmission Control Module	●	●	●	●	●	●	S023
2012	Chevrolet	Orlando	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2012	Chevrolet	Orlando	Parking Brake Control Module	●	●	●	●	●	●	S037
2012	Chevrolet	Orlando	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Chevrolet	Orlando	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2012	Chevrolet	Orlando	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Chevrolet	Orlando	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2012	Chevrolet	Orlando	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2012	Chevrolet	Orlando	Instrument Cluster	●	●	●	●	●	●	S022
2012	Chevrolet	Orlando	Trailer Interface Control Module	●	●	●	●	●	●	S022
2012	Chevrolet	Orlando	Radio	●	●	●	●	●	○	
2012	Chevrolet	Orlando	Multimedia Player Interface Module	●	●	●	●	○	●	
2012	Chevrolet	Orlando	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Chevrolet	Orlando	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2012	Chevrolet	Orlando	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Chevrolet	Orlando	Keyless Entry Control Module	●	●	●	●	●	○	

2012	Chevrolet	Orlando	Parking Assist Control Module	●	●	●	●	●	●	S022
2012	Chevrolet	Orlando	Steering Column Lock Control Module	●	●	●	●	○	●	
2012	Chevrolet	S10	Engine Control Module	●	●	●	●	●	●	S205 S108
2012	Chevrolet	S10	Transmission Control Module	●	●	●	●	●	●	S048
2012	Chevrolet	S10	Transfer Case Control Module	●	●	●	●	●	●	S080
2012	Chevrolet	S10	Electronic Brake Control Module	●	●	●	●	●	●	S035
2012	Chevrolet	S10	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S070 S070 S036 S036
2012	Chevrolet	S10	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2012	Chevrolet	S10	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2012	Chevrolet	S10	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2012	Chevrolet	S10	Instrument Cluster	●	●	●	●	●	●	
2012	Chevrolet	S10	Trailer Interface Control Module	●	●	●	●	●	●	
2012	Chevrolet	S10	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2012	Chevrolet	Sail	Engine Control Module	●	●	●	●	●	○	
2012	Chevrolet	Sail	Transmission Control Module	●	●	●	●	●	●	S200 S201 S202 S203 S204
2012	Chevrolet	Sail	Electronic Brake Control Module	●	●	●	●	●	○	

2012	Chevrolet	Sail	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	S194 S195 S196 S197 S198 S194 S195 S196 S197 S024 S199
2012	Chevrolet	Sail	Keyless Entry Control Module	○	○	○	●	○	●	
2012	Chevrolet	Sonic	Engine Control Module	●	●	●	●	●	●	S044 S026
2012	Chevrolet	Sonic	Fuel Injector Control Module	○	○	●	●	●	○	
2012	Chevrolet	Sonic	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Chevrolet	Sonic	Transmission Control Module	●	●	●	●	●	●	S023
2012	Chevrolet	Sonic	Electronic Brake Control Module	●	●	●	●	●	●	S035
2012	Chevrolet	Sonic	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Chevrolet	Sonic	Electric Power Steering Control Module	●	●	●	●	○	●	
2012	Chevrolet	Sonic	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2012	Chevrolet	Sonic	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2012	Chevrolet	Sonic	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2012	Chevrolet	Sonic	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Chevrolet	Sonic	Instrument Cluster	●	●	●	●	●	●	S022
2012	Chevrolet	Sonic	Radio	●	●	●	●	●	○	

2012	Chevrolet	Sonic	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2012	Chevrolet	Sonic	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Chevrolet	Sonic	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Chevrolet	Sonic	Parking Assist Control Module	●	●	●	●	●	●	S022
2012	Chevrolet	Spark	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S104 S106 S106 S109 S110 S111 S111 S045 S045 S105 S105 S108 S108 S103 S103 S112 S112 S107 S107 S113 S029 S114 S114 S115 S115 S116 S117 S118 S118
2012	Chevrolet	Spark	Fuel Injector Control Module	●	●	●	●	●	○	
2012	Chevrolet	Spark	Transmission Control Module	●	●	●	●	●	○	
2012	Chevrolet	Spark	Electronic Brake Control Module	●	●	●	●	●	●	S035
2012	Chevrolet	Spark	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Chevrolet	Spark	Electric Power Steering Control Module	●	●	●	●	○	●	
2012	Chevrolet	Spark	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035

2012	Chevrolet	Spark	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2012	Chevrolet	Spark	Passenger Presence Module	●	●	●	●	●	●	S043
2012	Chevrolet	Spark	Instrument Cluster	●	●	●	●	●	○	
2012	Chevrolet	Tavera	Engine Control Module	●	●	●	●	●	○	
2012	Chevrolet	Volt	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S091
2012	Chevrolet	Volt	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Chevrolet	Volt	Hybrid Powertrain Control Module	●	●	●	●	●	○	
2012	Chevrolet	Volt	Transmission Control Module	●	●	●	●	●	○	
2012	Chevrolet	Volt	Drive Motor Control Module 1	●	●	●	●	○	○	
2012	Chevrolet	Volt	Drive Motor Control Module 2	●	●	●	●	○	○	
2012	Chevrolet	Volt	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	
2012	Chevrolet	Volt	Electronic Brake Control Module	●	●	●	●	●	●	S092 S036 S036 S036
2012	Chevrolet	Volt	Parking Brake Control Module	●	●	●	●	●	●	S037
2012	Chevrolet	Volt	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Chevrolet	Volt	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2012	Chevrolet	Volt	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Chevrolet	Volt	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021

2012	Chevrolet	Volt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2012	Chevrolet	Volt	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Chevrolet	Volt	Instrument Cluster	●	●	●	●	●	●	S022
2012	Chevrolet	Volt	Radio	●	●	●	●	●	○	
2012	Chevrolet	Volt	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022 S022
2012	Chevrolet	Volt	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2012	Chevrolet	Volt	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Chevrolet	Volt	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2012	Chevrolet	Volt	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2012	Chevrolet	Volt	Coolant Heater Control Module	●	●	●	○	○	○	
2012	Chevrolet	Volt	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Chevrolet	Volt	Keyless Entry Control Module	●	●	●	●	●	○	
2012	Chevrolet	Volt	Parking Assist Control Module	●	●	●	●	●	●	S022
2012	Chevrolet	Volt	Steering Column Lock Control Module	●	●	●	●	○	●	
2012	Chevrolet	Volt	Battery Charger Control Module	○	○	●	●	○	○	
2012	Chevrolet	Volt	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S083 S084 S085 S086 S087 S088 S089

2012	Chevrolet	Volt	Battery Energy Control Module	○	○	●	●	○	○	
2012	Daewoo	Alpheon	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2012	Daewoo	Alpheon	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Daewoo	Alpheon	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2012	Daewoo	Alpheon	Transmission Control Module	●	●	●	●	●	●	S023
2012	Daewoo	Alpheon	Drive Motor Control Module	●	●	●	●	○	○	
2012	Daewoo	Alpheon	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2012	Daewoo	Alpheon	Parking Brake Control Module	●	●	●	●	●	●	S037
2012	Daewoo	Alpheon	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Daewoo	Alpheon	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2012	Daewoo	Alpheon	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Daewoo	Alpheon	Suspension Control Module	●	●	●	●	●	○	
2012	Daewoo	Alpheon	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2012	Daewoo	Alpheon	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2012	Daewoo	Alpheon	Instrument Cluster	●	●	●	●	●	●	S022
2012	Daewoo	Alpheon	Headlamp Control Module	●	●	●	●	●	●	S002
2012	Daewoo	Alpheon	Radio	●	●	●	●	●	○	

2012	GMC	Terrain	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	GMC	Terrain	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2012	GMC	Terrain	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	GMC	Terrain	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2012	GMC	Terrain	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2012	GMC	Terrain	Passenger Presence Module	●	●	●	●	○	●	S043
2012	GMC	Terrain	Instrument Cluster	●	●	●	●	●	●	S022
2012	GMC	Terrain	Radio	●	●	●	●	●	○	
2012	GMC	Terrain	Multimedia Player Interface Module	●	●	●	●	○	●	
2012	GMC	Terrain	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	GMC	Terrain	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2012	GMC	Terrain	Liftgate Control Module	●	●	●	●	●	●	S049
2012	GMC	Terrain	Seat Memory Control Module	●	●	●	●	●	●	S031
2012	GMC	Terrain	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	GMC	Terrain	Parking Assist Control Module	●	●	●	●	●	●	S022
2012	GMC	Terrain	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168

2012	GMC	Terrain	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2012	Holden	Barina	Engine Control Module	●	●	●	●	●	●	S044 S026
2012	Holden	Barina	Fuel Injector Control Module	○	○	●	●	●	○	
2012	Holden	Barina	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Holden	Barina	Transmission Control Module	●	●	●	●	●	●	S023
2012	Holden	Barina	Electronic Brake Control Module	●	●	●	●	●	●	S035
2012	Holden	Barina	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Holden	Barina	Electric Power Steering Control Module	●	●	●	●	○	●	
2012	Holden	Barina	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	
2012	Holden	Barina	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2012	Holden	Barina	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2012	Holden	Barina	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Holden	Barina	Instrument Cluster	●	●	●	●	●	●	S022
2012	Holden	Barina	Radio	●	●	●	●	●	○	
2012	Holden	Barina	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	

2012	Holden	Barina	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Holden	Barina	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Holden	Barina	Parking Assist Control Module	●	●	●	●	●	●	S022
2012	Holden	Barina Spark	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S104 S106 S106 S109 S110 S111 S111 S045 S045 S105 S105 S108 S108 S103 S103 S112 S112 S107 S107 S113 S029 S114 S114 S115 S115 S116 S117 S118 S118
2012	Holden	Barina Spark	Fuel Injector Control Module	●	●	●	●	●	○	
2012	Holden	Barina Spark	Transmission Control Module	●	●	●	●	●	○	
2012	Holden	Barina Spark	Electronic Brake Control Module	●	●	●	●	●	●	S035
2012	Holden	Barina Spark	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Holden	Barina Spark	Electric Power Steering Control Module	●	●	●	●	○	●	
2012	Holden	Barina Spark	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Holden	Barina Spark	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2012	Holden	Barina Spark	Passenger Presence Module	●	●	●	●	●	●	S043

2012	Holden	Barina Spark	Instrument Cluster	●	●	●	●	●	○	
2012	Holden	Captiva 5	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2012	Holden	Captiva 5	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Holden	Captiva 5	Transmission Control Module	●	●	●	●	●	●	S166
2012	Holden	Captiva 5	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2012	Holden	Captiva 5	Electronic Brake Control Module	●	●	●	●	●	●	S035
2012	Holden	Captiva 5	Parking Brake Control Module	●	●	●	●	●	●	S037
2012	Holden	Captiva 5	Body Control Module	●	●	●	●	●	●	S013 S001
2012	Holden	Captiva 5	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2012	Holden	Captiva 5	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S053
2012	Holden	Captiva 5	Headlamp Control Module	●	●	●	●	●	●	S002 S179
2012	Holden	Captiva 5	Radio	●	●	●	●	●	●	S187 S187 S187 S187 S179 S179 S179 S179 S191 S191
2012	Holden	Captiva 5	Mobile Telephone Control Module	●	●	●	○	●	●	
2012	Holden	Captiva 5	HVAC Control Module	●	●	●	○	●	○	
2012	Holden	Captiva 5	Info Display Module	●	●	●	●	●	●	S187 S187 S187 S187 S188 S189 S022 S022 S190 S190 S190 S190 S179 S179 S179
2012	Holden	Captiva 5	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020

2012	Holden	Captiva 5	Parking Assist Control Module	●	●	●	●	●	●	
2012	Holden	Captiva 5	Theft Deterrent Module	●	●	●	●	○	○	
2012	Holden	Captiva 5	Instrument Cluster	●	●	●	●	●	○	
2012	Holden	Captiva 7	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S044 S029 S025 S058
2012	Holden	Captiva 7	Fuel Pump Control Module	●	●	●	●	●	●	S025
2012	Holden	Captiva 7	Transmission Control Module	●	●	●	●	●	●	S023
2012	Holden	Captiva 7	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2012	Holden	Captiva 7	Electronic Brake Control Module	●	●	●	●	●	●	S035 S036
2012	Holden	Captiva 7	Parking Brake Control Module	●	●	●	●	●	●	S037
2012	Holden	Captiva 7	Body Control Module	●	●	●	●	●	●	S013 S001 S053
2012	Holden	Captiva 7	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2012	Holden	Captiva 7	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2012	Holden	Captiva 7	Instrument Cluster	●	●	●	●	●	○	
2012	Holden	Captiva 7	Headlamp Control Module	●	●	●	●	●	●	S002 S179
2012	Holden	Captiva 7	Radio	●	●	●	●	●	●	S187 S213 S189 S188
2012	Holden	Captiva 7	Mobile Telephone Control Module	●	●	●	●	●	●	S022
2012	Holden	Captiva 7	HVAC Control Module	●	●	●	○	●	○	
2012	Holden	Captiva 7	Info Display Module	●	●	●	○	○	●	
2012	Holden	Captiva 7	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2012	Holden	Captiva 7	Parking Assist Control Module	●	●	●	●	●	○	

2012	Holden	Cruze	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2012	Holden	Cruze	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2012	Holden	Cruze	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2012	Holden	Cruze	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2012	Holden	Cruze	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2012	Holden	Cruze	Passenger Presence Module	●	●	●	●	○	●	S043
2012	Holden	Cruze	Instrument Cluster	●	●	●	●	●	●	S022
2012	Holden	Cruze	Trailer Interface Control Module	●	●	●	●	●	●	S022
2012	Holden	Cruze	Radio	●	●	●	●	●	○	
2012	Holden	Cruze	Multimedia Player Interface Module	●	●	●	●	○	●	
2012	Holden	Cruze	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2012	Holden	Cruze	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2012	Holden	Cruze	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2012	Holden	Cruze	Front Seat Heating Control Module	●	●	●	●	●	○	
2012	Holden	Cruze	Keyless Entry Control Module	●	●	●	●	●	○	
2012	Holden	Cruze	Parking Assist Control Module	●	●	●	●	●	●	

2012	Holden	Cruze	Steering Column Lock Control Module	●	●	●	●	○	●	
2012	Cadillac	CTS	Fuel pump control module	●	●	●	●	●	○	
2012	Cadillac	CTS	Engine control module	●	●	●	●	●	●	T001
2012	Cadillac	CTS	Transmission control module	●	●	○	●	●	○	
2012	Cadillac	CTS	Transfer case control module	●	●	●	●	●	●	T001
2012	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	●	T010
2012	Cadillac	CTS	Headlamp control module	●	●	●	●	●	○	
2012	Cadillac	CTS	Liftgate module	●	●	●	●	●	○	
2012	Cadillac	CTS	TV antenna module	●	●	●	●	○	●	T012 T013
2012	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2012	Cadillac	CTS	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Cadillac	CTS	Passenger presence system	●	●	●	●	●	○	
2012	Cadillac	CTS	HVAC control module	●	●	●	●	●	●	T008
2012	Cadillac	CTS	Body control module (aux.)	●	●	●	●	●	●	T006
2012	Cadillac	CTS	Body control module	●	●	●	●	●	●	T007 T005
2012	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2012	Cadillac	CTS	Park assist module	●	●	●	●	●	○	
2012	Cadillac	CTS	Pedestrian impact detection module	●	●	●	●	●	●	T009
2012	Cadillac	CTS	Driver door switch	●	●	●	●	●	○	
2012	Cadillac	CTS	Passenger door switch	●	●	●	●	●	○	
2012	Cadillac	CTS	Radio	●	●	●	●	●	●	T011
2012	Cadillac	CTS	Left side object detection module	●	●	●	●	●	○	

2012	Cadillac	CTS	Right side object detection module	●	●	●	●	●	●	T010
2012	Cadillac	CTS	Parking brake control module	●	●	●	●	●	○	
2012	Cadillac	CTS	Electronic brake control module	●	●	●	●	●	●	T014
2012	Cadillac	CTS	Electronic suspension control	●	●	○	●	●	○	
2012	Chevrolet	Aveo classic	Engine control module	●	●	●	●	●	●	T015
2012	Chevrolet	Aveo classic	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet	Aveo classic	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Chevrolet	Aveo classic	Immobilizer	○	○	○	○	○	●	T016
2012	Chevrolet	Aveo classic	Supplemental inflatable restraint	●	●	●	●	●	●	T002 T003 T004
2012	Chevrolet	Aveo classic	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2012	Chevrolet	Aveo classic	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet	(1)Aveo	Transmission control module	●	●	●	●	●	○	
2012	Chevrolet	(1)Aveo	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet	(1)Aveo	Immobilizer	○	○	○	○	○	●	T016
2012	Chevrolet	(1)Aveo	Supplemental inflatable restraint	●	●	●	●	●	●	T016
2012	Chevrolet	(1)Aveo	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2012	Chevrolet	(1)Aveo	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet	Chevy	Transmission control module	●	●	●	●	●	○	
2012	Chevrolet	Chevy	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet	Chevy	Immobilizer	●	●	●	●	○	●	T052 T053
2012	Chevrolet	Corvette	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet	Corvette	Transmission control module	●	●	○	●	●	○	

2012	Chevrolet	Corvette	Exhaust flow control module	●	●	●	●	●	●	T001
2012	Chevrolet	Corvette	Fuel pump control module	●	●	●	●	●	●	T001
2012	Chevrolet	Corvette	CD changer	●	●	●	●	○	○	
2012	Chevrolet	Corvette	Digital radio receiver	●	●	●	●	○	●	T024
2012	Chevrolet	Corvette	Vehicle comm. interface module	●	●	●	●	●	●	T003
2012	Chevrolet	Corvette	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet	Corvette	Head up display	●	●	●	●	●	○	
2012	Chevrolet	Corvette	Passenger presence system	●	●	○	○	○	●	T025
2012	Chevrolet	Corvette	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2012	Chevrolet	Corvette	Driver door switch	●	●	●	●	○	○	
2012	Chevrolet	Corvette	Driver door module	●	●	●	●	●	○	
2012	Chevrolet	Corvette	Passenger door module	●	●	●	●	●	○	
2012	Chevrolet	Corvette	Remote control door lock receiver	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2012	Chevrolet	Corvette	HVAC control module	●	●	●	●	●	●	T008 T031
2012	Chevrolet	Corvette	Steering column lock module	●	●	●	●	●	○	
2012	Chevrolet	Corvette	Body control module	●	●	●	●	●	●	T023
2012	Chevrolet	Corvette	Radio	●	●	●	●	○	●	T032 T033
2012	Chevrolet	Corvette	Driver position module	●	●	●	●	●	●	T030
2012	Chevrolet	Corvette	Folding top module	●	●	●	●	●	●	T054
2012	Chevrolet	Corvette	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet	Corvette	Electronic suspension control	●	●	●	●	●	○	
2012	Chevrolet	Impala	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet	Impala	Engine control module	●	●	●	●	●	●	T001

2012	Chevrolet	Impala	Fuel pump control module	●	●	●	●	●	●	T001
2012	Chevrolet	Impala	Digital radio receiver	●	●	●	●	●	○	
2012	Chevrolet	Impala	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Chevrolet	Impala	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Chevrolet	Impala	Passenger presence system	●	●	●	●	●	○	
2012	Chevrolet	Impala	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Chevrolet	Impala	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet	Impala	Body control module	●	●	●	●	●	●	T007 T005
2012	Chevrolet	Impala	Radio	●	●	●	●	●	○	
2012	Chevrolet	Impala	Heated seat module	●	●	●	●	○	○	
2012	Chevrolet	Impala	HVAC control module	●	●	●	●	●	●	T008
2012	Chevrolet	Impala	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet	(1)Malibu	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet	(1)Malibu	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet	(1)Malibu	Digital radio receiver	●	●	●	●	●	○	
2012	Chevrolet	(1)Malibu	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	Chevrolet	(1)Malibu	Instrument panel cluster	●	●	●	●	●	●	T055
2012	Chevrolet	(1)Malibu	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2012	Chevrolet	(1)Malibu	Passenger presence system	●	●	○	○	○	○	
2012	Chevrolet	(1)Malibu	Body control module	●	●	●	●	●	●	T008 T023 T056
2012	Chevrolet	(1)Malibu	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2012	Chevrolet	(1)Malibu	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet	(1)Malibu	HVAC control module	●	●	●	●	●	○	
2012	Chevrolet	(1)Malibu	Radio	●	●	●	●	●	●	T033
2012	Chevrolet	(1)Malibu	Personal audio link module	●	●	●	○	○	●	T036
2012	Chevrolet	(1)Malibu	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet	(1)Malibu	Power steering control module	●	●	●	●	●	●	T014
2012	Chevrolet	Matiz classic	Transmission control module	●	●	●	●	●	○	
2012	Chevrolet	Matiz classic	Engine control module	●	●	●	●	●	●	T015
2012	Chevrolet	Matiz classic	Supplemental inflatable restraint	●	●	●	●	○	○	
2012	Chevrolet	Matiz classic	Immobilizer	○	○	○	○	○	●	T016
2012	Chevrolet	Matiz classic	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet	Optra	Engine control module	●	●	●	●	●	●	T017
2012	Chevrolet	Optra	Transmission control module	●	●	●	●	●	●	T017
2012	Chevrolet	Optra	Supplemental inflatable restraint	●	●	●	●	●	○	
2012	Chevrolet	Optra	Immobilizer	○	○	○	○	○	●	T016
2012	Chevrolet	Optra	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2012	Chevrolet	Optra	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet	Matiz	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet	Matiz	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet	Matiz	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet	Matiz	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet	Matiz	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2012	Chevrolet	Matiz	Passenger presence system	●	●	●	●	○	●	T020
2012	Chevrolet	Matiz	HVAC control module	●	●	●	●	●	○	
2012	Chevrolet	Matiz	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Chevrolet	Matiz	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet	Matiz	Body control module	●	●	●	●	●	●	T007 T005
2012	Chevrolet	Matiz	Radio	●	●	●	●	●	○	
2012	Chevrolet	Matiz	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet	Caprice police	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet	Caprice police	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet	Caprice police	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet	Caprice police	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet	Caprice police	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Chevrolet	Caprice police	Passenger presence system	●	●	●	●	○	●	T020
2012	Chevrolet	Caprice police	HVAC control module	●	●	●	●	●	○	
2012	Chevrolet	Caprice police	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Chevrolet	Caprice police	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet	Caprice police	Body control module	●	●	●	●	●	●	T007 T005
2012	Chevrolet	Caprice police	Radio	●	●	●	●	●	○	
2012	Chevrolet	Caprice police	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet	Spark classic	Transmission control module	●	●	●	●	●	○	
2012	Chevrolet	Spark classic	Engine control module	●	●	●	●	●	●	T015
2012	Chevrolet	Spark classic	Supplemental inflatable restraint	●	●	●	●	○	○	
2012	Chevrolet	Spark classic	Immobilizer	○	○	○	○	○	●	T016

2012	Chevrolet	Spark classic	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet	Others	Supplemental inflatable restraint	●	●	●	●	●	○	
2012	Chevrolet	Others	Immobilizer	○	○	○	○	○	●	T016
2012	Chevrolet	Others	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet	Others	Power steering control module	●	●	●	●	●	○	
2012	Chevrolet	Others	Tire pressure monitor	●	●	●	●	●	●	T018 T019
2012	Chevrolet	Others	Engine control module	●	●	○	●	●	●	T001
2012	Chevrolet	Others	Transmission control module	●	●	●	●	●	○	
2012	Holden	Others	Supplemental inflatable restraint	●	●	●	●	●	○	
2012	Holden	Others	Immobilizer	○	○	○	○	○	●	T016
2012	Holden	Others	Electronic brake control module	●	●	●	●	●	●	T014
2012	Holden	Others	Power steering control module	●	●	●	●	●	○	
2012	Holden	Others	Tire pressure monitor	●	●	●	●	●	●	T018 T019
2012	Holden	Others	Engine control module	●	●	○	●	●	●	T001
2012	Holden	Others	Transmission control module	●	●	●	●	●	○	
2012	Buick	Enclave - AWD	Engine control module	●	●	●	●	●	●	T001
2012	Buick	Enclave - AWD	Fuel pump control module	●	●	●	●	●	○	
2012	Buick	Enclave - AWD	Transmission control module	●	●	○	●	●	○	
2012	Buick	Enclave - AWD	Digital radio receiver	●	●	●	●	●	○	
2012	Buick	Enclave - AWD	Headlamp control module	●	●	●	○	○	○	
2012	Buick	Enclave - AWD	Liftgate module	●	●	●	●	●	○	
2012	Buick	Enclave - AWD	Rear HVAC/RSA	●	●	●	●	●	○	

2012	Buick	Enclave - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	Buick	Enclave - AWD	Instrument panel cluster	●	●	●	●	●	○	
2012	Buick	Enclave - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Buick	Enclave - AWD	Passenger presence system	●	●	●	●	●	○	
2012	Buick	Enclave - AWD	Driver door switch	●	●	●	●	●	●	T035
2012	Buick	Enclave - AWD	Passenger door switch	●	●	●	●	●	●	T035
2012	Buick	Enclave - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Buick	Enclave - AWD	Theft deterrent module	●	●	●	●	○	○	
2012	Buick	Enclave - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2012	Buick	Enclave - AWD	Body control module	●	●	●	●	●	●	T007 T005
2012	Buick	Enclave - AWD	Radio	●	●	●	●	●	○	
2012	Buick	Enclave - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2012	Buick	Enclave - AWD	Memory seat module	●	●	●	●	●	○	
2012	Buick	Enclave - AWD	Park assist module	●	●	●	●	○	○	
2012	Buick	Enclave - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Buick	Enclave - AWD	Rear drive system	●	●	●	●	●	●	T038
2012	Buick	Enclave - FWD	Engine control module	●	●	●	●	●	●	T001
2012	Buick	Enclave - FWD	Fuel pump control module	●	●	●	●	●	○	
2012	Buick	Enclave - FWD	Transmission control module	●	●	○	●	●	○	
2012	Buick	Enclave - FWD	Digital radio receiver	●	●	●	●	●	○	
2012	Buick	Enclave - FWD	Headlamp control module	●	●	●	○	○	○	
2012	Buick	Enclave - FWD	Liftgate module	●	●	●	●	●	○	
2012	Buick	Enclave - FWD	Rear HVAC/RSA	●	●	●	●	●	○	
2012	Buick	Enclave - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003

2012	Buick	Enclave - FWD	Instrument panel cluster	●	●	●	●	●	○	
2012	Buick	Enclave - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Buick	Enclave - FWD	Passenger presence system	●	●	●	●	●	○	
2012	Buick	Enclave - FWD	Driver door switch	●	●	●	●	●	●	T035
2012	Buick	Enclave - FWD	Passenger door switch	●	●	●	●	●	●	T035
2012	Buick	Enclave - FWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Buick	Enclave - FWD	Theft deterrent module	●	●	●	●	○	○	
2012	Buick	Enclave - FWD	HVAC control module	●	●	●	●	●	●	T008 T034
2012	Buick	Enclave - FWD	Body control module	●	●	●	●	●	●	T007 T005
2012	Buick	Enclave - FWD	Radio	●	●	●	●	●	○	
2012	Buick	Enclave - FWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2012	Buick	Enclave - FWD	Memory seat module	●	●	●	●	●	○	
2012	Buick	Enclave - FWD	Park assist module	●	●	●	●	○	○	
2012	Buick	Enclave - FWD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Buick	Enclave - FWD	Rear drive system	●	●	●	●	●	●	T038
2012	Cadillac	Escalade	Engine control module	●	●	●	●	●	●	T001
2012	Cadillac	Escalade	Fuel pump control module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Transmission control module	●	●	●	●	●	●	T001
2012	Cadillac	Escalade	Amplifier (bose)	●	●	●	●	●	○	
2012	Cadillac	Escalade	Liftgate module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Rear HVAC/RSA	●	●	●	●	●	○	
2012	Cadillac	Escalade	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2012	Cadillac	Escalade	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2012	Cadillac	Escalade	Passenger presence system	●	●	●	●	○	○	
2012	Cadillac	Escalade	Driver door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade	Passenger door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade	HVAC control module	●	●	●	●	●	●	T008 T034
2012	Cadillac	Escalade	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Cadillac	Escalade	Theft deterrent module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Memory seat module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Inside rear view mirror module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Rear heated seat module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Park assist module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Left side object detection module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Right side object detection module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Body control module	●	●	●	●	●	●	T007 T005
2012	Cadillac	Escalade	Body control module (aux.)	●	●	●	●	●	●	T006
2012	Cadillac	Escalade	Personal audio link module	●	●	●	○	○	●	T036
2012	Cadillac	Escalade	Assist step controller	●	●	●	●	●	●	T039
2012	Cadillac	Escalade	Radio	●	●	●	●	●	○	
2012	Cadillac	Escalade	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Cadillac	Escalade	Electronic brake control module	●	●	●	●	●	●	T014
2012	Cadillac	Escalade	Electronic suspension control	●	●	●	●	●	●	T040
2012	Cadillac	Escalade	Engine control module	●	●	●	●	●	●	T001
2012	Cadillac	Escalade	Fuel pump control module	●	●	●	●	●	○	

2012	Cadillac	Escalade	Transmission control module	●	●	○	●	●	○	
2012	Cadillac	Escalade	Accessory power module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Amplifier (bose)	●	●	●	●	●	○	
2012	Cadillac	Escalade	Liftgate module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Rear HVAC/RSA	●	●	●	●	●	○	
2012	Cadillac	Escalade	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2012	Cadillac	Escalade	A/C compressor control module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Cadillac	Escalade	Passenger presence system	●	●	●	●	○	○	
2012	Cadillac	Escalade	Driver door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade	Passenger door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade	HVAC control module	●	●	●	●	●	●	T008 T034
2012	Cadillac	Escalade	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Cadillac	Escalade	Theft deterrent module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Inside rear view mirror module	●	●	●	○	○	○	
2012	Cadillac	Escalade	Memory seat module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Rear heated seat module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Park assist module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Left side object detection module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Right side object detection module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Body control module	●	●	●	●	●	●	T007 T005
2012	Cadillac	Escalade	Body control module (aux.)	●	●	●	●	●	●	T006

2012	Cadillac	Escalade	Serial data gateway module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Personal audio link module	●	●	●	○	○	●	T036
2012	Cadillac	Escalade	Assist step controller	●	●	●	●	●	●	T039
2012	Cadillac	Escalade	Radio	●	●	●	●	●	○	
2012	Cadillac	Escalade	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Cadillac	Escalade	Electronic suspension control	●	●	●	●	●	●	T040
2012	Cadillac	Escalade	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	Cadillac	Escalade	Power steering control module	●	●	●	●	●	●	T044
2012	Cadillac	Escalade	Engine control module	●	●	●	●	●	●	T001
2012	Cadillac	Escalade	Fuel pump control module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Transmission control module	●	●	●	●	●	●	T001
2012	Cadillac	Escalade	Amplifier (bose)	●	●	●	●	●	○	
2012	Cadillac	Escalade	Liftgate module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Rear HVAC/RSA	●	●	●	●	●	○	
2012	Cadillac	Escalade	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2012	Cadillac	Escalade	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Cadillac	Escalade	Passenger presence system	●	●	●	●	○	○	
2012	Cadillac	Escalade	Driver door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade	Passenger door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade	HVAC control module	●	●	●	●	●	●	T008 T034
2012	Cadillac	Escalade	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2012	Cadillac	Escalade	Theft deterrent module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Memory seat module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Inside rear view mirror module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Rear heated seat module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Park assist module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Left side object detection module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Right side object detection module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Body control module	●	●	●	●	●	●	T007 T005
2012	Cadillac	Escalade	Body control module (aux.)	●	●	●	●	●	●	T006
2012	Cadillac	Escalade	Personal audio link module	●	●	●	○	○	●	T036
2012	Cadillac	Escalade	Assist step controller	●	●	●	●	●	●	T039
2012	Cadillac	Escalade	Radio	●	●	●	●	●	○	
2012	Cadillac	Escalade	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Cadillac	Escalade	Electronic brake control module	●	●	●	●	●	●	T014
2012	Cadillac	Escalade	Electronic suspension control	●	●	●	●	●	●	T040
2012	Cadillac	Escalade	Engine control module	●	●	●	●	●	●	T001
2012	Cadillac	Escalade	Transfer case control module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Fuel pump control module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Transmission control module	●	●	○	●	●	○	
2012	Cadillac	Escalade	Accessory power module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Amplifier (bose)	●	●	●	●	●	○	
2012	Cadillac	Escalade	Liftgate module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Rear HVAC/RSA	●	●	●	●	●	○	

2012	Cadillac	Escalade	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2012	Cadillac	Escalade	A/C compressor control module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Cadillac	Escalade	Passenger presence system	●	●	●	●	○	○	
2012	Cadillac	Escalade	Driver door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade	Passenger door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade	HVAC control module	●	●	●	●	●	●	T008 T034
2012	Cadillac	Escalade	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Cadillac	Escalade	Theft deterrent module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Inside rear view mirror module	●	●	●	○	○	○	
2012	Cadillac	Escalade	Memory seat module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Rear heated seat module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Park assist module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Left side object detection module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Right side object detection module	●	●	●	●	○	○	
2012	Cadillac	Escalade	Body control module	●	●	●	●	●	●	T007 T005
2012	Cadillac	Escalade	Body control module (aux.)	●	●	●	●	●	●	T006
2012	Cadillac	Escalade	Serial data gateway module	●	●	●	●	●	○	
2012	Cadillac	Escalade	Personal audio link module	●	●	●	○	○	●	T036
2012	Cadillac	Escalade	Assist step controller	●	●	●	●	●	●	T039
2012	Cadillac	Escalade	Radio	●	●	●	●	●	○	

2012	Cadillac	Escalade	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Cadillac	Escalade	Electronic suspension control	●	●	●	●	●	●	T040
2012	Cadillac	Escalade	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	Cadillac	Escalade	Power steering control module	●	●	●	●	●	●	T044
2012	Cadillac	Escalade hybrid	Engine control module	●	●	●	●	●	●	T001
2012	Cadillac	Escalade hybrid	Fuel pump control module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Transmission control module	●	●	●	●	●	●	T001
2012	Cadillac	Escalade hybrid	Amplifier (bose)	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Liftgate module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Cadillac	Escalade hybrid	Instrument panel cluster	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Cadillac	Escalade hybrid	Passenger presence system	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Driver door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Passenger door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2012	Cadillac	Escalade hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Cadillac	Escalade hybrid	Theft deterrent module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Memory seat module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Inside rear view mirror module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Rear heated seat module	●	●	●	●	○	○	

2012	Cadillac	Escalade hybrid	Park assist module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Left side object detection module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Right side object detection module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Body control module	●	●	●	●	●	●	T007 T005
2012	Cadillac	Escalade hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2012	Cadillac	Escalade hybrid	Personal audio link module	●	●	●	○	○	●	T036
2012	Cadillac	Escalade hybrid	Assist step controller	●	●	●	●	●	●	T039
2012	Cadillac	Escalade hybrid	Radio	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2012	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	Cadillac	Escalade hybrid	Engine control module	●	●	●	●	●	●	T001
2012	Cadillac	Escalade hybrid	Fuel pump control module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Transmission control module	●	●	○	●	●	○	
2012	Cadillac	Escalade hybrid	Accessory power module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Amplifier (bose)	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Liftgate module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Cadillac	Escalade hybrid	Instrument panel cluster	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	A/C compressor control module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2012	Cadillac	Escalade hybrid	Passenger presence system	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Driver door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Passenger door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2012	Cadillac	Escalade hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Cadillac	Escalade hybrid	Theft deterrent module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Inside rear view mirror module	●	●	●	○	○	○	
2012	Cadillac	Escalade hybrid	Memory seat module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Rear heated seat module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Park assist module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Left side object detection module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Right side object detection module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Body control module	●	●	●	●	●	●	T007 T005
2012	Cadillac	Escalade hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2012	Cadillac	Escalade hybrid	Serial data gateway module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Personal audio link module	●	●	●	○	○	●	T036
2012	Cadillac	Escalade hybrid	Assist step controller	●	●	●	●	●	●	T039
2012	Cadillac	Escalade hybrid	Radio	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	Cadillac	Escalade hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	Cadillac	Escalade hybrid	Power steering control module	●	●	●	●	●	●	T044

2012	Cadillac	Escalade hybrid	Engine control module	●	●	●	●	●	●	T001
2012	Cadillac	Escalade hybrid	Fuel pump control module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Transmission control module	●	●	●	●	●	●	T001
2012	Cadillac	Escalade hybrid	Amplifier (bose)	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Liftgate module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Cadillac	Escalade hybrid	Instrument panel cluster	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Cadillac	Escalade hybrid	Passenger presence system	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Driver door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Passenger door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2012	Cadillac	Escalade hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Cadillac	Escalade hybrid	Theft deterrent module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Memory seat module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Inside rear view mirror module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Rear heated seat module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Park assist module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Left side object detection module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Right side object detection module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Body control module	●	●	●	●	●	●	T007 T005
2012	Cadillac	Escalade hybrid	Body control module (aux.)	●	●	●	●	●	●	T006

2012	Cadillac	Escalade hybrid	Personal audio link module	●	●	●	○	○	●	T036
2012	Cadillac	Escalade hybrid	Assist step controller	●	●	●	●	●	●	T039
2012	Cadillac	Escalade hybrid	Radio	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2012	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	Cadillac	Escalade hybrid	Engine control module	●	●	●	●	●	●	T001
2012	Cadillac	Escalade hybrid	Transfer case control module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Fuel pump control module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Transmission control module	●	●	○	●	●	○	
2012	Cadillac	Escalade hybrid	Accessory power module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Amplifier (bose)	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Liftgate module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Cadillac	Escalade hybrid	Instrument panel cluster	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	A/C compressor control module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Cadillac	Escalade hybrid	Passenger presence system	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Driver door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Passenger door switch	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	HVAC control module	●	●	●	●	●	●	T008 T034

2012	Cadillac	Escalade hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Cadillac	Escalade hybrid	Theft deterrent module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Inside rear view mirror module	●	●	●	○	○	○	
2012	Cadillac	Escalade hybrid	Memory seat module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Rear heated seat module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Park assist module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Left side object detection module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Right side object detection module	●	●	●	●	○	○	
2012	Cadillac	Escalade hybrid	Body control module	●	●	●	●	●	●	T007 T005
2012	Cadillac	Escalade hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2012	Cadillac	Escalade hybrid	Serial data gateway module	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Personal audio link module	●	●	●	○	○	●	T036
2012	Cadillac	Escalade hybrid	Assist step controller	●	●	●	●	●	●	T039
2012	Cadillac	Escalade hybrid	Radio	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	Cadillac	Escalade hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	Cadillac	Escalade hybrid	Power steering control module	●	●	●	●	●	●	T044
2012	Chevrolet truck	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Avalanche - 2WD	Fuel pump control module	●	●	●	●	●	○	

2012	Chevrolet truck	Avalanche - 2WD	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Avalanche - 2WD	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Avalanche - 2WD	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Avalanche - 2WD	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Avalanche - 2WD	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Avalanche - 4WD	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Avalanche - 4WD	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Avalanche - 4WD	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014

2012	Chevrolet truck	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Avalanche - 4WD	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Avalanche - 4WD	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Avalanche - 4WD	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	N200	Engine control module	●	●	●	●	●	●	T015
2012	Chevrolet truck	N200	Supplemental inflatable restraint	●	●	●	●	○	○	
2012	Chevrolet truck	N200	Electronic brake control module	●	●	○	●	●	●	T014
2012	Chevrolet truck	N300	Engine control module	●	●	●	●	●	●	T015
2012	Chevrolet truck	N300	Supplemental inflatable restraint	●	●	●	●	○	○	
2012	Chevrolet truck	N300	Electronic brake control module	●	●	○	●	●	●	T014
2012	Chevrolet truck	Captiva sport (vin L)	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Captiva sport (vin L)	Engine control module	●	●	●	●	●	●	T001

2012	Chevrolet truck	Captiva sport(vin L)	Fuel pump control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Captiva sport(vin L)	Rear drive system	●	●	●	●	●	●	T038
2012	Chevrolet truck	Captiva sport(vin L)	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet truck	Captiva sport(vin L)	Passenger presence system	●	●	●	●	○	●	T045
2012	Chevrolet truck	Captiva sport(vin L)	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Chevrolet truck	Captiva sport(vin L)	Digital radio receiver	●	●	●	●	●	○	
2012	Chevrolet truck	Captiva sport(vin L)	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	Chevrolet truck	Captiva sport(vin L)	HVAC control module	●	●	●	●	●	●	T008
2012	Chevrolet truck	Captiva sport(vin L)	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Chevrolet truck	Captiva sport(vin L)	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet truck	Captiva sport(vin L)	Body control module	●	●	●	●	●	●	T007 T005
2012	Chevrolet truck	Captiva sport(vin L)	Radio	●	●	●	●	●	○	
2012	Chevrolet truck	Captiva sport(vin L)	Electronic brake control module	●	●	●	●	●	○	
2012	Chevrolet truck	Captiva sport(vin L)	Parking brake control module	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Cheyenne - 2WD	Fuel pump control module	●	●	●	●	●	●	T001

2012	Chevrolet truck	Cheyenne - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Digital radio receiver	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Chevrolet truck	Cheyenne - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Chevrolet truck	Cheyenne - 2WD	Passenger presence system	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 2WD	Driver door switch	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Passenger door switch	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Chevrolet truck	Cheyenne - 2WD	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 2WD	Rear heated seat module	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 2WD	Park assist module	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 2WD	Body control module	●	●	●	●	●	●	T007 T005
2012	Chevrolet truck	Cheyenne - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2012	Chevrolet truck	Cheyenne - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2012	Chevrolet truck	Cheyenne - 2WD	Trailer brake control module	●	●	●	●	●	○	

2012	Chevrolet truck	Cheyenne - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Cheyenne - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Cheyenne - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Cheyenne - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Cheyenne - 2WD	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Cheyenne - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Cheyenne - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Digital radio receiver	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Chevrolet truck	Cheyenne - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Chevrolet truck	Cheyenne - 2WD	Passenger presence system	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 2WD	Driver door switch	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Passenger door switch	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2012	Chevrolet truck	Cheyenne - 2WD	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 2WD	Rear heated seat module	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 2WD	Park assist module	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 2WD	Body control module	●	●	●	●	●	●	T007 T005
2012	Chevrolet truck	Cheyenne - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2012	Chevrolet truck	Cheyenne - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2012	Chevrolet truck	Cheyenne - 2WD	Trailer brake control module	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Cheyenne - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Cheyenne - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Cheyenne - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Cheyenne - 4WD	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Cheyenne - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Cheyenne - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Digital radio receiver	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	

2012	Chevrolet truck	Cheyenne - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Chevrolet truck	Cheyenne - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Chevrolet truck	Cheyenne - 4WD	Passenger presence system	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 4WD	Driver door switch	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Passenger door switch	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Chevrolet truck	Cheyenne - 4WD	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 4WD	Rear heated seat module	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 4WD	Park assist module	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 4WD	Body control module	●	●	●	●	●	●	T007 T005
2012	Chevrolet truck	Cheyenne - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2012	Chevrolet truck	Cheyenne - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2012	Chevrolet truck	Cheyenne - 4WD	Trailer brake control module	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Cheyenne - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Cheyenne - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T040

2012	Chevrolet truck	Cheyenne - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Cheyenne - 4WD	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Cheyenne - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Cheyenne - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Digital radio receiver	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2012	Chevrolet truck	Cheyenne - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Chevrolet truck	Cheyenne - 4WD	Passenger presence system	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 4WD	Driver door switch	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Passenger door switch	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Chevrolet truck	Cheyenne - 4WD	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 4WD	Rear heated seat module	●	●	●	●	○	○	
2012	Chevrolet truck	Cheyenne - 4WD	Park assist module	●	●	●	●	○	○	

2012	Chevrolet truck	Cheyenne - 4WD	Body control module	●	●	●	●	●	●	T007 T005
2012	Chevrolet truck	Cheyenne - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2012	Chevrolet truck	Cheyenne - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2012	Chevrolet truck	Cheyenne - 4WD	Trailer brake control module	●	●	●	●	●	○	
2012	Chevrolet truck	Cheyenne - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Cheyenne - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Cheyenne - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Cheyenne - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Colorado pickup - 2WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Colorado pickup - 2WD	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Colorado pickup - 2WD	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Colorado pickup - 2WD	Digital radio receiver	●	●	●	●	●	●	T024
2012	Chevrolet truck	Colorado pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T003
2012	Chevrolet truck	Colorado pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet truck	Colorado pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2012	Chevrolet truck	Colorado pickup - 2WD	Passenger presence system	●	●	○	○	○	●	T025
2012	Chevrolet truck	Colorado pickup - 2WD	Theft deterrent module	●	●	●	●	○	●	T057

2012	Chevrolet truck	Colorado pickup - 2WD	Generator battery control module	●	●	●	●	●	○	
2012	Chevrolet truck	Colorado pickup - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2012	Chevrolet truck	Colorado pickup - 2WD	Radio	●	●	●	●	○	○	
2012	Chevrolet truck	Colorado pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022
2012	Chevrolet truck	Colorado pickup - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Colorado pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Colorado pickup - 4WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Colorado pickup - 4WD	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Colorado pickup - 4WD	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Colorado pickup - 4WD	Digital radio receiver	●	●	●	●	●	●	T024
2012	Chevrolet truck	Colorado pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T003
2012	Chevrolet truck	Colorado pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet truck	Colorado pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2012	Chevrolet truck	Colorado pickup - 4WD	Passenger presence system	●	●	○	○	○	●	T025
2012	Chevrolet truck	Colorado pickup - 4WD	Theft deterrent module	●	●	●	●	○	●	T057
2012	Chevrolet truck	Colorado pickup - 4WD	Generator battery control module	●	●	●	●	●	○	
2012	Chevrolet truck	Colorado pickup - 4WD	Personal audio link module	●	●	●	○	○	●	T036

2012	Chevrolet truck	Colorado pickup - 4WD	Radio	●	●	●	●	○	○	
2012	Chevrolet truck	Colorado pickup - 4WD	Body control module	●	●	●	●	●	●	T058 T022
2012	Chevrolet truck	Colorado pickup - 4WD	Electronic brake control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Colorado pickup - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Express	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Express	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Express	Fuel pump control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Express	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2012	Chevrolet truck	Express	Digital radio receiver	●	●	●	●	●	○	
2012	Chevrolet truck	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	Chevrolet truck	Express	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet truck	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Chevrolet truck	Express	Passenger presence system	●	●	●	●	○	●	T025
2012	Chevrolet truck	Express	Rollover sensor	●	●	●	●	○	●	T049
2012	Chevrolet truck	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Chevrolet truck	Express	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet truck	Express	Body control module	●	●	●	●	●	●	T007 T005

2012	Chevrolet truck	Express	Radio	●	●	●	●	●	○	
2012	Chevrolet truck	Express	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Express	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Express	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Express	Fuel pump control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Express	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2012	Chevrolet truck	Express	Digital radio receiver	●	●	●	●	●	○	
2012	Chevrolet truck	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	Chevrolet truck	Express	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet truck	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Chevrolet truck	Express	Passenger presence system	●	●	●	●	○	●	T025
2012	Chevrolet truck	Express	Rollover sensor	●	●	●	●	○	●	T049
2012	Chevrolet truck	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Chevrolet truck	Express	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet truck	Express	Body control module	●	●	●	●	●	●	T007 T005
2012	Chevrolet truck	Express	Radio	●	●	●	●	●	○	
2012	Chevrolet truck	Express	Electronic brake control module	●	●	●	●	●	●	T014

2012	Chevrolet truck	Express	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Express	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Express	Fuel pump control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Express	Digital radio receiver	●	●	●	●	●	○	
2012	Chevrolet truck	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	Chevrolet truck	Express	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet truck	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Chevrolet truck	Express	Passenger presence system	●	●	●	●	○	●	T025
2012	Chevrolet truck	Express	Rollover sensor	●	●	●	●	○	●	T049
2012	Chevrolet truck	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Chevrolet truck	Express	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet truck	Express	Body control module	●	●	●	●	●	●	T007 T005
2012	Chevrolet truck	Express	Radio	●	●	●	●	●	○	
2012	Chevrolet truck	Express	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Express	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Express	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Express	Fuel pump control module	●	●	●	●	●	●	T001

2012	Chevrolet truck	Express	Digital radio receiver	●	●	●	●	●	○	
2012	Chevrolet truck	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	Chevrolet truck	Express	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet truck	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Chevrolet truck	Express	Passenger presence system	●	●	●	●	○	●	T025
2012	Chevrolet truck	Express	Rollover sensor	●	●	●	●	○	●	T049
2012	Chevrolet truck	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Chevrolet truck	Express	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet truck	Express	Body control module	●	●	●	●	●	●	T007 T005
2012	Chevrolet truck	Express	Radio	●	●	●	●	●	○	
2012	Chevrolet truck	Express	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Silverado	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Silverado	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Silverado	Fuel pump control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Silverado	Trailer brake control module	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Silverado	Electronic brake control module	●	●	●	●	●	●	T014

2012	Chevrolet truck	Silverado	FPCM with trailer brake control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Silverado	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Silverado	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Silverado	Accessory power module	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Silverado	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	Chevrolet truck	Silverado	Power steering control module	●	●	●	●	●	●	T044
2012	Chevrolet truck	Silverado	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Silverado	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Silverado	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Silverado	Fuel pump control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Silverado	Trailer brake control module	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Silverado	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Silverado	FPCM with trailer brake control	●	●	●	●	●	●	T040

2012	Chevrolet truck	Silverado	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Silverado	Transfer case control module	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Silverado	Accessory power module	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Silverado	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	Chevrolet truck	Silverado	Power steering control module	●	●	●	●	●	●	T044
2012	Chevrolet truck	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Silverado hybrid	Fuel pump control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Silverado hybrid	Trailer brake control module	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Silverado hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001

2012	Chevrolet truck	Silverado hybrid	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Silverado hybrid	Accessory power module	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	Chevrolet truck	Silverado hybrid	Power steering control module	●	●	●	●	●	●	T044
2012	Chevrolet truck	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Silverado hybrid	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Silverado hybrid	Fuel pump control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Silverado hybrid	Trailer brake control module	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Silverado hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Silverado hybrid	Transfer case control module	●	●	●	●	●	○	

2012	Chevrolet truck	Silverado hybrid	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Silverado hybrid	Accessory power module	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	Chevrolet truck	Silverado hybrid	Power steering control module	●	●	●	●	●	●	T044
2012	Chevrolet truck	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Suburban - 2WD	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Suburban - 2WD	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Suburban - 2WD	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Suburban - 2WD	Trailer brake control module	●	●	●	●	●	●	T040
2012	Chevrolet truck	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Suburban - 2WD	Fuel pump control module	●	●	●	●	●	○	

2012	Chevrolet truck	Suburban - 2WD	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Suburban - 2WD	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Suburban - 2WD	Trailer brake control module	●	●	●	●	●	●	T040
2012	Chevrolet truck	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Suburban - 4WD	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Suburban - 4WD	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Suburban - 4WD	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Suburban - 4WD	Trailer brake control module	●	●	●	●	●	●	T040
2012	Chevrolet truck	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Suburban - 4WD	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Suburban - 4WD	Transmission control module	●	●	●	●	●	●	T001

2012	Chevrolet truck	Suburban - 4WD	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Suburban - 4WD	Trailer brake control module	●	●	●	●	●	●	T040
2012	Chevrolet truck	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Tahoe	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Tahoe	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Tahoe	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Tahoe	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Tahoe	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Tahoe	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Tahoe	Accessory power module	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040

2012	Chevrolet truck	Tahoe	Power steering control module	●	●	●	●	●	●	T044
2012	Chevrolet truck	Tahoe hybrid	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Tahoe hybrid	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Tahoe hybrid	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Tahoe hybrid	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	Accessory power module	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	Chevrolet truck	Tahoe hybrid	Power steering control module	●	●	●	●	●	●	T044
2012	Chevrolet truck	Tahoe hybrid	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Tahoe hybrid	Transfer case control module	●	●	●	●	●	○	

2012	Chevrolet truck	Tahoe hybrid	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	Transmission control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Tahoe hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Tahoe hybrid	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Tahoe hybrid	Transfer case control module	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	Accessory power module	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	Chevrolet truck	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	Chevrolet truck	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	Chevrolet truck	Tahoe hybrid	Power steering control module	●	●	●	●	●	●	T044
2012	Chevrolet truck	Traverse - AWD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Traverse - AWD	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - AWD	Transmission control module	●	●	○	●	●	○	

2012	Chevrolet truck	Traverse - AWD	Digital radio receiver	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - AWD	Liftgate module	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	Chevrolet truck	Traverse - AWD	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Chevrolet truck	Traverse - AWD	Passenger presence system	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - AWD	Driver door switch	●	●	●	●	●	●	T035
2012	Chevrolet truck	Traverse - AWD	Passenger door switch	●	●	●	●	●	●	T035
2012	Chevrolet truck	Traverse - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Chevrolet truck	Traverse - AWD	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet truck	Traverse - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2012	Chevrolet truck	Traverse - AWD	Body control module	●	●	●	●	●	●	T007 T005
2012	Chevrolet truck	Traverse - AWD	Radio	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2012	Chevrolet truck	Traverse - AWD	Memory seat module	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - AWD	Park assist module	●	●	●	●	●	●	T002 T003

2012	Chevrolet truck	Traverse - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Traverse - AWD	Rear drive system	●	●	●	●	●	●	T038
2012	Chevrolet truck	Traverse - FWD	Engine control module	●	●	●	●	●	●	T001
2012	Chevrolet truck	Traverse - FWD	Fuel pump control module	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - FWD	Transmission control module	●	●	○	●	●	○	
2012	Chevrolet truck	Traverse - FWD	Digital radio receiver	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - FWD	Liftgate module	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - FWD	Rear HVAC/RSA	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	Chevrolet truck	Traverse - FWD	Instrument panel cluster	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	Chevrolet truck	Traverse - FWD	Passenger presence system	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - FWD	Driver door switch	●	●	●	●	●	●	T035
2012	Chevrolet truck	Traverse - FWD	Passenger door switch	●	●	●	●	●	●	T035
2012	Chevrolet truck	Traverse - FWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	Chevrolet truck	Traverse - FWD	Theft deterrent module	●	●	●	●	○	○	
2012	Chevrolet truck	Traverse - FWD	HVAC control module	●	●	●	●	●	●	T008 T034

2012	Chevrolet truck	Traverse - FWD	Body control module	●	●	●	●	●	●	T007 T005
2012	Chevrolet truck	Traverse - FWD	Radio	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - FWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2012	Chevrolet truck	Traverse - FWD	Memory seat module	●	●	●	●	●	○	
2012	Chevrolet truck	Traverse - FWD	Park assist module	●	●	●	●	●	●	T002 T003
2012	Chevrolet truck	Traverse - FWD	Electronic brake control module	●	●	●	●	●	●	T014
2012	Chevrolet truck	Traverse - FWD	Rear drive system	●	●	●	●	●	●	T038
2012	GMC truck	Acadia - 2WD	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Acadia - 2WD	Fuel pump control module	●	●	●	●	●	○	
2012	GMC truck	Acadia - 2WD	Transmission control module	●	●	○	●	●	○	
2012	GMC truck	Acadia - 2WD	Digital radio receiver	●	●	●	●	●	○	
2012	GMC truck	Acadia - 2WD	Liftgate module	●	●	●	●	●	○	
2012	GMC truck	Acadia - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2012	GMC truck	Acadia - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	GMC truck	Acadia - 2WD	Head up display	●	●	●	●	○	○	
2012	GMC truck	Acadia - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2012	GMC truck	Acadia - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	GMC truck	Acadia - 2WD	Passenger presence system	●	●	●	●	●	○	
2012	GMC truck	Acadia - 2WD	Driver door switch	●	●	●	●	●	●	T035
2012	GMC truck	Acadia - 2WD	Passenger door switch	●	●	●	●	●	●	T035
2012	GMC truck	Acadia - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2012	GMC truck	Acadia - 2WD	Theft deterrent module	●	●	●	●	○	○	
2012	GMC truck	Acadia - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2012	GMC truck	Acadia - 2WD	Body control module	●	●	●	●	●	●	T007 T005
2012	GMC truck	Acadia - 2WD	Radio	●	●	●	●	●	○	
2012	GMC truck	Acadia - 2WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2012	GMC truck	Acadia - 2WD	Memory seat module	●	●	●	●	●	○	
2012	GMC truck	Acadia - 2WD	Park assist module	●	●	●	●	●	●	T002 T003
2012	GMC truck	Acadia - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2012	GMC truck	Acadia - 2WD	Rear drive system	●	●	●	●	●	●	T038
2012	GMC truck	Acadia - 4WD	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Acadia - 4WD	Fuel pump control module	●	●	●	●	●	○	
2012	GMC truck	Acadia - 4WD	Transmission control module	●	●	○	●	●	○	
2012	GMC truck	Acadia - 4WD	Digital radio receiver	●	●	●	●	●	○	
2012	GMC truck	Acadia - 4WD	Liftgate module	●	●	●	●	●	○	
2012	GMC truck	Acadia - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2012	GMC truck	Acadia - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	GMC truck	Acadia - 4WD	Head up display	●	●	●	●	○	○	
2012	GMC truck	Acadia - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2012	GMC truck	Acadia - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	GMC truck	Acadia - 4WD	Passenger presence system	●	●	●	●	●	○	
2012	GMC truck	Acadia - 4WD	Driver door switch	●	●	●	●	●	●	T035
2012	GMC truck	Acadia - 4WD	Passenger door switch	●	●	●	●	●	●	T035
2012	GMC truck	Acadia - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	GMC truck	Acadia - 4WD	Theft deterrent module	●	●	●	●	○	○	
2012	GMC truck	Acadia - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2012	GMC truck	Acadia - 4WD	Body control module	●	●	●	●	●	●	T007 T005

2012	GMC truck	Acadia - 4WD	Radio	●	●	●	●	●	○	
2012	GMC truck	Acadia - 4WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2012	GMC truck	Acadia - 4WD	Memory seat module	●	●	●	●	●	○	
2012	GMC truck	Acadia - 4WD	Park assist module	●	●	●	●	●	●	T002 T003
2012	GMC truck	Acadia - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2012	GMC truck	Acadia - 4WD	Rear drive system	●	●	●	●	●	●	T038
2012	GMC truck	Canyon pickup - 2WD	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Canyon pickup - 2WD	Fuel pump control module	●	●	●	●	●	○	
2012	GMC truck	Canyon pickup - 2WD	Transmission control module	●	●	●	●	●	●	T001
2012	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	●	●	T024
2012	GMC truck	Canyon pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T003
2012	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2012	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2012	GMC truck	Canyon pickup - 2WD	Passenger presence system	●	●	○	○	○	●	T025
2012	GMC truck	Canyon pickup - 2WD	Theft deterrent module	●	●	●	●	○	●	T057
2012	GMC truck	Canyon pickup - 2WD	Generator battery control module	●	●	●	●	●	○	
2012	GMC truck	Canyon pickup - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2012	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	
2012	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022

2012	GMC truck	Canyon pickup - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2012	GMC truck	Canyon pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2012	GMC truck	Canyon pickup - 4WD	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Canyon pickup - 4WD	Fuel pump control module	●	●	●	●	●	○	
2012	GMC truck	Canyon pickup - 4WD	Transmission control module	●	●	●	●	●	●	T001
2012	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	●	●	T024
2012	GMC truck	Canyon pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T003
2012	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2012	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2012	GMC truck	Canyon pickup - 4WD	Passenger presence system	●	●	○	○	○	●	T025
2012	GMC truck	Canyon pickup - 4WD	Theft deterrent module	●	●	●	●	○	●	T057
2012	GMC truck	Canyon pickup - 4WD	Generator battery control module	●	●	●	●	●	○	
2012	GMC truck	Canyon pickup - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2012	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	
2012	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058 T022
2012	GMC truck	Canyon pickup - 4WD	Electronic brake control module	●	●	●	●	●	●	T001
2012	GMC truck	Canyon pickup - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2012	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001

2012	GMC truck	Savana	Transmission control module	●	●	●	●	●	●	T001
2012	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2012	GMC truck	Savana	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2012	GMC truck	Savana	Digital radio receiver	●	●	●	●	●	○	
2012	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2012	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T025
2012	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2012	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2012	GMC truck	Savana	Body control module	●	●	●	●	●	●	T007 T005
2012	GMC truck	Savana	Radio	●	●	●	●	●	○	
2012	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2012	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Savana	Transmission control module	●	●	●	●	●	●	T001
2012	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2012	GMC truck	Savana	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2012	GMC truck	Savana	Digital radio receiver	●	●	●	●	●	○	
2012	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	

2012	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T025
2012	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2012	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2012	GMC truck	Savana	Body control module	●	●	●	●	●	●	T007 T005
2012	GMC truck	Savana	Radio	●	●	●	●	●	○	
2012	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2012	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Savana	Transmission control module	●	●	●	●	●	●	T001
2012	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2012	GMC truck	Savana	Digital radio receiver	●	●	●	●	●	○	
2012	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2012	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T025
2012	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2012	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2012	GMC truck	Savana	Body control module	●	●	●	●	●	●	T007 T005
2012	GMC truck	Savana	Radio	●	●	●	●	●	○	
2012	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2012	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001

2012	GMC truck	Savana	Transmission control module	●	●	●	●	●	●	T001
2012	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2012	GMC truck	Savana	Digital radio receiver	●	●	●	●	●	○	
2012	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2012	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2012	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2012	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T025
2012	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2012	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2012	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2012	GMC truck	Savana	Body control module	●	●	●	●	●	●	T007 T005
2012	GMC truck	Savana	Radio	●	●	●	●	●	○	
2012	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2012	GMC truck	Sierra	Transmission control module	●	●	○	●	●	○	
2012	GMC truck	Sierra	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Sierra	Fuel pump control module	●	●	●	●	●	●	T001
2012	GMC truck	Sierra	Trailer brake control module	●	●	●	●	●	○	
2012	GMC truck	Sierra	Electronic suspension control	●	●	●	●	●	●	T040
2012	GMC truck	Sierra	Electronic brake control module	●	●	●	●	●	●	T014
2012	GMC truck	Sierra	FPCM with trailer brake control	●	●	●	●	●	●	T040

2012	GMC truck	Sierra	Transfer case control module	●	●	●	●	●	●	T001
2012	GMC truck	Sierra	Transmission control module	●	●	○	●	●	○	
2012	GMC truck	Sierra	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Sierra	Fuel pump control module	●	●	●	●	●	●	T001
2012	GMC truck	Sierra	Trailer brake control module	●	●	●	●	●	○	
2012	GMC truck	Sierra	Electronic suspension control	●	●	●	●	●	●	T040
2012	GMC truck	Sierra	Electronic brake control module	●	●	●	●	●	●	T014
2012	GMC truck	Sierra	FPCM with trailer brake control	●	●	●	●	●	●	T040
2012	GMC truck	Sierra	Transfer case control module	●	●	●	●	●	●	T001
2012	GMC truck	Sierra hybrid	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Sierra hybrid	Fuel pump control module	●	●	●	●	●	○	
2012	GMC truck	Sierra hybrid	Transmission control module	●	●	○	●	●	○	
2012	GMC truck	Sierra hybrid	Accessory power module	●	●	●	●	●	○	
2012	GMC truck	Sierra hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	GMC truck	Sierra hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	GMC truck	Sierra hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	GMC truck	Sierra hybrid	Power steering control module	●	●	●	●	●	●	T044
2012	GMC truck	Sierra hybrid	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Sierra hybrid	Fuel pump control module	●	●	●	●	●	○	

2012	GMC truck	Sierra hybrid	Transmission control module	●	●	○	●	●	○	
2012	GMC truck	Sierra hybrid	Accessory power module	●	●	●	●	●	○	
2012	GMC truck	Sierra hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	GMC truck	Sierra hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	GMC truck	Sierra hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	GMC truck	Sierra hybrid	Power steering control module	●	●	●	●	●	●	T044
2012	GMC truck	Yukon	FPCM with trailer brake control	●	●	●	●	●	○	
2012	GMC truck	Yukon	Electronic suspension control	●	●	●	●	●	●	T040
2012	GMC truck	Yukon	Electronic brake control module	●	●	●	●	●	●	T014
2012	GMC truck	Yukon	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Yukon	Fuel pump control module	●	●	●	●	●	○	
2012	GMC truck	Yukon	Transmission control module	●	●	●	●	●	●	T001
2012	GMC truck	Yukon	Transfer case control module	●	●	●	●	●	●	T001
2012	GMC truck	Yukon	FPCM with trailer brake control	●	●	●	●	●	○	
2012	GMC truck	Yukon	Electronic suspension control	●	●	●	●	●	●	T040
2012	GMC truck	Yukon	Electronic brake control module	●	●	●	●	●	●	T014
2012	GMC truck	Yukon	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Yukon	Fuel pump control module	●	●	●	●	●	○	
2012	GMC truck	Yukon	Transmission control module	●	●	●	●	●	●	T001

2012	GMC truck	Yukon	Transfer case control module	●	●	●	●	●	●	T001
2012	GMC truck	Yukon hybrid	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Yukon hybrid	Fuel pump control module	●	●	●	●	●	○	
2012	GMC truck	Yukon hybrid	Transmission control module	●	●	○	●	●	○	
2012	GMC truck	Yukon hybrid	Accessory power module	●	●	●	●	●	○	
2012	GMC truck	Yukon hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	GMC truck	Yukon hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	GMC truck	Yukon hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	GMC truck	Yukon hybrid	Power steering control module	●	●	●	●	●	●	T044
2012	GMC truck	Yukon hybrid	Transfer case control module	●	●	●	●	●	●	T040
2012	GMC truck	Yukon hybrid	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Yukon hybrid	Fuel pump control module	●	●	●	●	●	○	
2012	GMC truck	Yukon hybrid	Transmission control module	●	●	○	●	●	○	
2012	GMC truck	Yukon hybrid	Accessory power module	●	●	●	●	●	○	
2012	GMC truck	Yukon hybrid	FPCM with trailer brake control	●	●	●	●	●	○	
2012	GMC truck	Yukon hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2012	GMC truck	Yukon hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2012	GMC truck	Yukon hybrid	Power steering control module	●	●	●	●	●	●	T044
2012	GMC truck	Yukon hybrid	Transfer case control module	●	●	●	●	●	●	T040
2012	GMC truck	Yukon XL	Engine control module	●	●	●	●	●	●	T001

2012	GMC truck	Yukon XL	Fuel pump control module	●	●	●	●	●	○	
2012	GMC truck	Yukon XL	Transmission control module	●	●	●	●	●	●	T001
2012	GMC truck	Yukon XL	FPCM with trailer brake control	●	●	●	●	●	○	
2012	GMC truck	Yukon XL	Electronic suspension control	●	●	●	●	●	●	T040
2012	GMC truck	Yukon XL	Electronic brake control module	●	●	●	●	●	●	T014
2012	GMC truck	Yukon XL	Trailer brake control module	●	●	●	●	●	●	T040
2012	GMC truck	Yukon XL	Transfer case control module	●	●	●	●	●	●	T001
2012	GMC truck	Yukon XL	Engine control module	●	●	●	●	●	●	T001
2012	GMC truck	Yukon XL	Fuel pump control module	●	●	●	●	●	○	
2012	GMC truck	Yukon XL	Transmission control module	●	●	●	●	●	●	T001
2012	GMC truck	Yukon XL	FPCM with trailer brake control	●	●	●	●	●	○	
2012	GMC truck	Yukon XL	Electronic suspension control	●	●	●	●	●	●	T040
2012	GMC truck	Yukon XL	Electronic brake control module	●	●	●	●	●	●	T014
2012	GMC truck	Yukon XL	Trailer brake control module	●	●	●	●	●	●	T040
2012	GMC truck	Yukon XL	Transfer case control module	●	●	●	●	●	●	T001
2011	Buick	LaCrosse	Engine Control Module	●	●	●	●	●	●	S044 S029 S025 S030
2011	Buick	LaCrosse	Fuel Injector Control Module	●	●	●	●	●	○	
2011	Buick	LaCrosse	Fuel Pump Control Module	●	●	●	●	●	●	S025

2011	Buick	LaCrosse	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2011	Buick	LaCrosse	Transmission Control Module	●	●	●	●	●	●	S048
2011	Buick	LaCrosse	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2011	Buick	LaCrosse	Drive Motor Control Module	●	●	●	●	○	○	
2011	Buick	LaCrosse	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2011	Buick	LaCrosse	Parking Brake Control Module	●	●	●	●	●	●	S037
2011	Buick	LaCrosse	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	Buick	LaCrosse	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2011	Buick	LaCrosse	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2011	Buick	LaCrosse	Suspension Control Module	●	●	●	●	●	○	
2011	Buick	LaCrosse	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2011	Buick	LaCrosse	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2011	Buick	LaCrosse	Passenger Presence Module	●	●	●	●	○	●	S043
2011	Buick	LaCrosse	Instrument Cluster	●	●	●	●	●	●	S022
2011	Buick	LaCrosse	Head-Up Display Module	●	●	●	●	●	○	
2011	Buick	LaCrosse	Headlamp Control Module	●	●	●	●	●	●	
2011	Buick	LaCrosse	Radio	●	●	●	●	●	○	

2011	Buick	LaCrosse	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022 S022
2011	Buick	LaCrosse	Multimedia Player Interface Module	●	●	●	●	○	●	
2011	Buick	LaCrosse	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2011	Buick	LaCrosse	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2011	Buick	LaCrosse	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2011	Buick	LaCrosse	Seat Memory Control Module	●	●	●	●	●	●	S031
2011	Buick	LaCrosse	Front Seat Heating Control Module	●	●	●	●	●	○	
2011	Buick	LaCrosse	Rear Seat Heating Control Module	●	●	●	●	●	○	
2011	Buick	LaCrosse	Keyless Entry Control Module	●	●	●	●	●	○	
2011	Buick	LaCrosse	Parking Assist Control Module	●	●	●	●	●	●	S022
2011	Buick	LaCrosse	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168
2011	Buick	LaCrosse	Steering Column Lock Control Module	●	●	●	●	○	●	
2011	Buick	LaCrosse	Battery Energy Control Module	○	○	●	●	○	○	
2011	Buick	LaCrosse	Left Side Object Detection Control Module	●	●	●	●	●	○	
2011	Buick	LaCrosse	Right Side Object Detection Control Module	●	●	●	●	●	○	

2011	Buick	Regal	Engine Control Module	●	●	●	●	●	●	S044 S029 S025 S030
2011	Buick	Regal	Fuel Injector Control Module	●	●	●	●	●	○	
2011	Buick	Regal	Fuel Pump Control Module	●	●	●	●	●	●	S025
2011	Buick	Regal	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2011	Buick	Regal	Transmission Control Module	●	●	●	●	●	●	S048
2011	Buick	Regal	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2011	Buick	Regal	Drive Motor Control Module	●	●	●	●	○	○	
2011	Buick	Regal	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2011	Buick	Regal	Parking Brake Control Module	●	●	●	●	●	●	S037
2011	Buick	Regal	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	Buick	Regal	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2011	Buick	Regal	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2011	Buick	Regal	Suspension Control Module	●	●	●	●	●	○	
2011	Buick	Regal	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2011	Buick	Regal	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2011	Buick	Regal	Passenger Presence Module	●	●	●	●	○	●	S043
2011	Buick	Regal	Instrument Cluster	●	●	●	●	●	●	S022

2011	Buick	Regal	Head-Up Display Module	●	●	●	●	●	○	
2011	Buick	Regal	Headlamp Control Module	●	●	●	●	●	●	
2011	Buick	Regal	Radio	●	●	●	●	●	○	
2011	Buick	Regal	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022 S022
2011	Buick	Regal	Multimedia Player Interface Module	●	●	●	●	○	●	
2011	Buick	Regal	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2011	Buick	Regal	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2011	Buick	Regal	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2011	Buick	Regal	Seat Memory Control Module	●	●	●	●	●	●	S031
2011	Buick	Regal	Front Seat Heating Control Module	●	●	●	●	●	○	
2011	Buick	Regal	Rear Seat Heating Control Module	●	●	●	●	●	○	
2011	Buick	Regal	Keyless Entry Control Module	●	●	●	●	●	○	
2011	Buick	Regal	Parking Assist Control Module	●	●	●	●	●	●	S022
2011	Buick	Regal	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168
2011	Buick	Regal	Steering Column Lock Control Module	●	●	●	●	○	●	
2011	Buick	Regal	Battery Energy Control Module	○	○	●	●	○	○	

2011	Buick	Regal	Left Side Object Detection Control Module	●	●	●	●	●	○	
2011	Buick	Regal	Right Side Object Detection Control Module	●	●	●	●	●	○	
2011	Cadillac	SRX	Engine Control Module	●	●	●	●	●	●	S028 S029 S025 S030
2011	Cadillac	SRX	Fuel Pump Control Module	●	●	●	●	●	●	S025
2011	Cadillac	SRX	Transmission Control Module	●	●	●	●	●	●	S057 S082
2011	Cadillac	SRX	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2011	Cadillac	SRX	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2011	Cadillac	SRX	Parking Brake Control Module	●	●	●	●	●	●	S037
2011	Cadillac	SRX	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	Cadillac	SRX	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2011	Cadillac	SRX	Suspension Control Module	●	●	●	●	●	○	
2011	Cadillac	SRX	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2011	Cadillac	SRX	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2011	Cadillac	SRX	Passenger Presence Module	●	●	●	●	○	●	S043
2011	Cadillac	SRX	Instrument Cluster	●	●	●	●	●	●	S022
2011	Cadillac	SRX	Headlamp Control Module	●	●	●	●	●	●	

2011	Cadillac	SRX	Trailer Interface Control Module	●	●	●	●	●	●	S022
2011	Cadillac	SRX	Radio	●	●	●	●	●	○	
2011	Cadillac	SRX	Rear Audio Control Module	●	●	●	●	●	○	
2011	Cadillac	SRX	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022 S022
2011	Cadillac	SRX	Multimedia Player Interface Module	●	●	●	●	○	●	
2011	Cadillac	SRX	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2011	Cadillac	SRX	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2011	Cadillac	SRX	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2011	Cadillac	SRX	Liftgate Control Module	●	●	●	●	●	●	S049
2011	Cadillac	SRX	Seat Memory Control Module	●	●	●	●	●	●	S031
2011	Cadillac	SRX	Front Seat Heating Control Module	●	●	●	●	●	○	
2011	Cadillac	SRX	Rear Seat Heating Control Module	●	●	●	●	●	○	
2011	Cadillac	SRX	Keyless Entry Control Module	●	●	●	●	●	○	
2011	Cadillac	SRX	Parking Assist Control Module	●	●	●	●	●	●	S022
2011	Cadillac	SRX	Steering Column Lock Control Module	●	●	●	●	○	●	

2011	Chevrolet	Beat	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S104 S106 S106 S109 S110 S111 S111 S045 S045 S105 S105 S108 S108 S103 S103 S112 S112 S107 S107 S113 S029 S114 S114 S115 S115 S116 S117 S118 S118
2011	Chevrolet	Beat	Fuel Injector Control Module	●	●	●	●	●	○	
2011	Chevrolet	Beat	Transmission Control Module	●	●	●	●	●	○	
2011	Chevrolet	Beat	Electronic Brake Control Module	●	●	●	●	●	●	S035
2011	Chevrolet	Beat	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	Chevrolet	Beat	Electric Power Steering Control Module	●	●	●	●	○	●	
2011	Chevrolet	Beat	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2011	Chevrolet	Beat	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2011	Chevrolet	Beat	Passenger Presence Module	●	●	●	●	●	●	S043
2011	Chevrolet	Beat	Instrument Cluster	●	●	●	●	●	○	
2011	Chevrolet	Camaro	Engine Control Module	●	●	●	●	●	●	S044 S029 S025 S030
2011	Chevrolet	Camaro	Fuel Pump Control Module	●	●	●	●	●	●	S025
2011	Chevrolet	Camaro	Transmission Control Module	●	●	●	●	●	●	S048
2011	Chevrolet	Camaro	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034

2011	Chevrolet	Camaro	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	Chevrolet	Camaro	Power Steering Control Module	●	●	●	●	○	●	
2011	Chevrolet	Camaro	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2011	Chevrolet	Camaro	Suspension Control Module	●	●	●	●	●	●	
2011	Chevrolet	Camaro	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2011	Chevrolet	Camaro	Auxiliary Gage Module	●	●	●	●	●	○	
2011	Chevrolet	Camaro	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2011	Chevrolet	Camaro	Passenger Presence Module	●	●	●	●	○	●	S043
2011	Chevrolet	Camaro	Instrument Cluster	●	●	●	●	●	●	S022
2011	Chevrolet	Camaro	Head-Up Display Module	●	●	●	●	●	○	
2011	Chevrolet	Camaro	Headlamp Control Module	●	●	●	●	●	●	S002
2011	Chevrolet	Camaro	Radio	●	●	●	●	●	○	
2011	Chevrolet	Camaro	Multimedia Player Interface Module	●	●	●	●	○	●	
2011	Chevrolet	Camaro	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2011	Chevrolet	Camaro	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2011	Chevrolet	Camaro	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039

2011	Chevrolet	Camaro	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2011	Chevrolet	Camaro	Front Seat Heating Control Module	●	●	●	●	●	○	
2011	Chevrolet	Camaro	Folding Top Control Module	●	●	●	●	●	○	
2011	Chevrolet	Camaro	Parking Assist Control Module	●	●	●	●	●	●	
2011	Chevrolet	Captiva	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S044 S029 S025 S058
2011	Chevrolet	Captiva	Fuel Pump Control Module	●	●	●	●	●	●	S025
2011	Chevrolet	Captiva	Transmission Control Module	●	●	●	●	●	●	S023
2011	Chevrolet	Captiva	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2011	Chevrolet	Captiva	Electronic Brake Control Module	●	●	●	●	●	●	S035 S036
2011	Chevrolet	Captiva	Parking Brake Control Module	●	●	●	●	●	●	S037
2011	Chevrolet	Captiva	Body Control Module	●	●	●	●	●	●	S013 S001 S053
2011	Chevrolet	Captiva	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2011	Chevrolet	Captiva	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2011	Chevrolet	Captiva	Instrument Cluster	●	●	●	●	●	○	
2011	Chevrolet	Captiva	Headlamp Control Module	●	●	●	●	●	●	S002 S179
2011	Chevrolet	Captiva	Radio	●	●	●	●	●	●	S187 S213 S189 S188
2011	Chevrolet	Captiva	Mobile Telephone Control Module	●	●	●	●	●	●	S022
2011	Chevrolet	Captiva	HVAC Control Module	●	●	●	○	●	○	
2011	Chevrolet	Captiva	Info Display Module	●	●	●	○	○	●	

2011	Chevrolet	Captiva	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2011	Chevrolet	Captiva	Parking Assist Control Module	●	●	●	●	●	○	
2011	Chevrolet	Captiva	Theft Deterrent Module	●	●	●	●	○	○	
2011	Chevrolet	Cruze	Engine Control Module	●	●	●	●	●	●	S029 S025
2011	Chevrolet	Cruze	Fuel Pump Control Module	●	●	●	●	●	●	S025
2011	Chevrolet	Cruze	Transmission Control Module	●	●	●	●	●	●	S023
2011	Chevrolet	Cruze	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2011	Chevrolet	Cruze	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	Chevrolet	Cruze	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2011	Chevrolet	Cruze	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2011	Chevrolet	Cruze	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2011	Chevrolet	Cruze	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2011	Chevrolet	Cruze	Passenger Presence Module	●	●	●	●	○	●	S043
2011	Chevrolet	Cruze	Instrument Cluster	●	●	●	●	●	●	S022
2011	Chevrolet	Cruze	Trailer Interface Control Module	●	●	●	●	●	●	S022
2011	Chevrolet	Cruze	Radio	●	●	●	●	●	○	
2011	Chevrolet	Cruze	Multimedia Player Interface Module	●	●	●	●	○	●	
2011	Chevrolet	Cruze	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022

2011	Chevrolet	Cruze	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2011	Chevrolet	Cruze	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2011	Chevrolet	Cruze	Front Seat Heating Control Module	●	●	●	●	●	○	
2011	Chevrolet	Cruze	Keyless Entry Control Module	●	●	●	●	●	○	
2011	Chevrolet	Cruze	Parking Assist Control Module	●	●	●	●	●	●	
2011	Chevrolet	Cruze	Steering Column Lock Control Module	●	●	●	●	○	●	
2011	Chevrolet	Equinox	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2011	Chevrolet	Equinox	Fuel Pump Control Module	●	●	●	●	●	●	S025
2011	Chevrolet	Equinox	Transmission Control Module	●	●	●	●	●	●	S048
2011	Chevrolet	Equinox	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2011	Chevrolet	Equinox	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2011	Chevrolet	Equinox	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	Chevrolet	Equinox	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2011	Chevrolet	Equinox	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2011	Chevrolet	Equinox	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021

2011	Chevrolet	Equinox	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2011	Chevrolet	Equinox	Passenger Presence Module	●	●	●	●	○	●	S043
2011	Chevrolet	Equinox	Instrument Cluster	●	●	●	●	●	●	S022
2011	Chevrolet	Equinox	Radio	●	●	●	●	●	○	
2011	Chevrolet	Equinox	Multimedia Player Interface Module	●	●	●	●	○	●	
2011	Chevrolet	Equinox	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2011	Chevrolet	Equinox	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2011	Chevrolet	Equinox	Liftgate Control Module	●	●	●	●	●	●	S049
2011	Chevrolet	Equinox	Seat Memory Control Module	●	●	●	●	●	●	S031
2011	Chevrolet	Equinox	Front Seat Heating Control Module	●	●	●	●	●	○	
2011	Chevrolet	Equinox	Parking Assist Control Module	●	●	●	●	●	●	S022
2011	Chevrolet	Equinox	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168
2011	Chevrolet	Equinox	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2011	Chevrolet	Orlando	Engine Control Module	●	●	●	●	●	●	S029 S025
2011	Chevrolet	Orlando	Fuel Injector Control Module	●	●	●	●	●	○	
2011	Chevrolet	Orlando	Fuel Pump Control Module	●	●	●	●	●	●	S025
2011	Chevrolet	Orlando	Transmission Control Module	●	●	●	●	●	●	S023

2011	Chevrolet	Orlando	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2011	Chevrolet	Orlando	Parking Brake Control Module	●	●	●	●	●	●	S037
2011	Chevrolet	Orlando	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	Chevrolet	Orlando	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2011	Chevrolet	Orlando	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2011	Chevrolet	Orlando	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2011	Chevrolet	Orlando	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2011	Chevrolet	Orlando	Instrument Cluster	●	●	●	●	●	●	S022
2011	Chevrolet	Orlando	Trailer Interface Control Module	●	●	●	●	●	●	S022
2011	Chevrolet	Orlando	Radio	●	●	●	●	●	○	
2011	Chevrolet	Orlando	Multimedia Player Interface Module	●	●	●	●	○	●	
2011	Chevrolet	Orlando	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2011	Chevrolet	Orlando	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2011	Chevrolet	Orlando	Front Seat Heating Control Module	●	●	●	●	●	○	
2011	Chevrolet	Orlando	Keyless Entry Control Module	●	●	●	●	●	○	
2011	Chevrolet	Orlando	Parking Assist Control Module	●	●	●	●	●	●	S022

2011	Chevrolet	Orlando	Steering Column Lock Control Module	●	●	●	●	○	●	
2011	Chevrolet	Sail	Engine Control Module	●	●	●	●	●	○	
2011	Chevrolet	Sail	Transmission Control Module	●	●	●	●	●	●	S200 S201 S202 S203 S204
2011	Chevrolet	Sail	Electronic Brake Control Module	●	●	●	●	●	○	
2011	Chevrolet	Sail	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	S194 S195 S196 S197 S198 S194 S195 S196 S197 S024 S199
2011	Chevrolet	Sail	Keyless Entry Control Module	○	○	○	●	○	●	
2011	Chevrolet	Spark	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S104 S106 S106 S109 S110 S111 S111 S045 S045 S105 S105 S108 S108 S103 S103 S112 S112 S107 S107 S113 S029 S114 S114 S115 S115 S116 S117 S118 S118
2011	Chevrolet	Spark	Fuel Injector Control Module	●	●	●	●	●	○	
2011	Chevrolet	Spark	Transmission Control Module	●	●	●	●	●	○	
2011	Chevrolet	Spark	Electronic Brake Control Module	●	●	●	●	●	●	S035
2011	Chevrolet	Spark	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	Chevrolet	Spark	Electric Power Steering Control Module	●	●	●	●	○	●	
2011	Chevrolet	Spark	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035

2011	Chevrolet	Spark	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2011	Chevrolet	Spark	Passenger Presence Module	●	●	●	●	●	●	S043
2011	Chevrolet	Spark	Instrument Cluster	●	●	●	●	●	○	
2011	Chevrolet	Tavera	Engine Control Module	●	●	●	●	●	○	
2011	Chevrolet	Volt	Engine Control Module	●	●	●	●	●	●	S026 S027 S028 S029 S025 S091
2011	Chevrolet	Volt	Fuel Pump Control Module	●	●	●	●	●	●	S025
2011	Chevrolet	Volt	Hybrid Powertrain Control Module	●	●	●	●	●	○	
2011	Chevrolet	Volt	Transmission Control Module	●	●	●	●	●	○	
2011	Chevrolet	Volt	Drive Motor Control Module 1	●	●	●	●	○	○	
2011	Chevrolet	Volt	Drive Motor Control Module 2	●	●	●	●	○	○	
2011	Chevrolet	Volt	Auxiliary Transmission Fluid Pump	●	●	●	●	○	○	
2011	Chevrolet	Volt	Electronic Brake Control Module	●	●	●	●	●	●	S092 S036 S036 S036
2011	Chevrolet	Volt	Parking Brake Control Module	●	●	●	●	●	●	S037
2011	Chevrolet	Volt	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	Chevrolet	Volt	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2011	Chevrolet	Volt	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2011	Chevrolet	Volt	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021

2011	Chevrolet	Volt	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2011	Chevrolet	Volt	Passenger Presence Module	●	●	●	●	○	●	S043
2011	Chevrolet	Volt	Instrument Cluster	●	●	●	●	●	●	S022
2011	Chevrolet	Volt	Radio	●	●	●	●	●	○	
2011	Chevrolet	Volt	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022 S022
2011	Chevrolet	Volt	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2011	Chevrolet	Volt	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2011	Chevrolet	Volt	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2011	Chevrolet	Volt	Electric A/C Compressor Control Module	○	○	●	○	○	○	
2011	Chevrolet	Volt	Coolant Heater Control Module	●	●	●	○	○	○	
2011	Chevrolet	Volt	Front Seat Heating Control Module	●	●	●	●	●	○	
2011	Chevrolet	Volt	Keyless Entry Control Module	●	●	●	●	●	○	
2011	Chevrolet	Volt	Parking Assist Control Module	●	●	●	●	●	●	S022
2011	Chevrolet	Volt	Steering Column Lock Control Module	●	●	●	●	○	●	
2011	Chevrolet	Volt	Battery Charger Control Module	○	○	●	●	○	○	
2011	Chevrolet	Volt	Hybrid Powertrain Control Module 2	●	●	●	●	●	●	S083 S084 S085 S086 S087 S088 S089

2011	Chevrolet	Volt	Battery Energy Control Module	○	○	●	●	○	○	
2011	Daewoo	Alpheon	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2011	Daewoo	Alpheon	Fuel Pump Control Module	●	●	●	●	●	●	S025
2011	Daewoo	Alpheon	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2011	Daewoo	Alpheon	Transmission Control Module	●	●	●	●	●	●	S023
2011	Daewoo	Alpheon	Drive Motor Control Module	●	●	●	●	○	○	
2011	Daewoo	Alpheon	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2011	Daewoo	Alpheon	Parking Brake Control Module	●	●	●	●	●	●	S037
2011	Daewoo	Alpheon	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	Daewoo	Alpheon	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2011	Daewoo	Alpheon	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2011	Daewoo	Alpheon	Suspension Control Module	●	●	●	●	●	○	
2011	Daewoo	Alpheon	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2011	Daewoo	Alpheon	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2011	Daewoo	Alpheon	Instrument Cluster	●	●	●	●	●	●	S022
2011	Daewoo	Alpheon	Headlamp Control Module	●	●	●	●	●	●	S002
2011	Daewoo	Alpheon	Radio	●	●	●	●	●	○	

2011	GMC	Terrain	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	GMC	Terrain	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2011	GMC	Terrain	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2011	GMC	Terrain	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2011	GMC	Terrain	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2011	GMC	Terrain	Passenger Presence Module	●	●	●	●	○	●	S043
2011	GMC	Terrain	Instrument Cluster	●	●	●	●	●	●	S022
2011	GMC	Terrain	Radio	●	●	●	●	●	○	
2011	GMC	Terrain	Multimedia Player Interface Module	●	●	●	●	○	●	
2011	GMC	Terrain	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2011	GMC	Terrain	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2011	GMC	Terrain	Liftgate Control Module	●	●	●	●	●	●	S049
2011	GMC	Terrain	Seat Memory Control Module	●	●	●	●	●	●	S031
2011	GMC	Terrain	Front Seat Heating Control Module	●	●	●	●	●	○	
2011	GMC	Terrain	Parking Assist Control Module	●	●	●	●	●	●	S022
2011	GMC	Terrain	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168

2011	GMC	Terrain	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2011	Holden	Barina Spark	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S104 S106 S106 S109 S110 S111 S111 S045 S045 S105 S105 S108 S108 S103 S103 S112 S112 S107 S107 S113 S029 S114 S114 S115 S115 S116 S117 S118 S118
2011	Holden	Barina Spark	Fuel Injector Control Module	●	●	●	●	●	○	
2011	Holden	Barina Spark	Transmission Control Module	●	●	●	●	●	○	
2011	Holden	Barina Spark	Electronic Brake Control Module	●	●	●	●	●	●	S035
2011	Holden	Barina Spark	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	Holden	Barina Spark	Electric Power Steering Control Module	●	●	●	●	○	●	
2011	Holden	Barina Spark	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2011	Holden	Barina Spark	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2011	Holden	Barina Spark	Passenger Presence Module	●	●	●	●	●	●	S043
2011	Holden	Barina Spark	Instrument Cluster	●	●	●	●	●	○	
2011	Holden	Captiva 5	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S044 S029 S025 S058
2011	Holden	Captiva 5	Fuel Pump Control Module	●	●	●	●	●	●	S025

2011	Holden	Captiva 5	Transmission Control Module	●	●	●	●	●	●	S023
2011	Holden	Captiva 5	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2011	Holden	Captiva 5	Electronic Brake Control Module	●	●	●	●	●	●	S035 S036
2011	Holden	Captiva 5	Parking Brake Control Module	●	●	●	●	●	●	S037
2011	Holden	Captiva 5	Body Control Module	●	●	●	●	●	●	S013 S001 S053
2011	Holden	Captiva 5	Auxiliary Body Control Module	●	●	●	●	●	●	S178
2011	Holden	Captiva 5	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024 S053
2011	Holden	Captiva 5	Instrument Cluster	●	●	●	●	●	○	
2011	Holden	Captiva 5	Headlamp Control Module	●	●	●	●	●	●	S002 S179
2011	Holden	Captiva 5	Radio	●	●	●	●	●	●	S187 S213 S189 S188
2011	Holden	Captiva 5	Mobile Telephone Control Module	●	●	●	●	●	●	S022
2011	Holden	Captiva 5	HVAC Control Module	●	●	●	○	●	○	
2011	Holden	Captiva 5	Info Display Module	●	●	●	○	○	●	
2011	Holden	Captiva 5	Remote Control Door Lock Receiver	●	●	●	●	●	●	S054 S004 S005 S006 S007 S008 S021 S019 S020
2011	Holden	Captiva 5	Parking Assist Control Module	●	●	●	●	●	○	
2011	Holden	Captiva 5	Theft Deterrent Module	●	●	●	●	○	○	
2011	Holden	Captiva 7	Engine Control Module	●	●	●	●	●	●	S001 S026 S027 S028 S044 S029 S025 S058
2011	Holden	Captiva 7	Fuel Pump Control Module	●	●	●	●	●	●	S025
2011	Holden	Captiva 7	Transmission Control Module	●	●	●	●	●	●	S023

2011	Holden	Cruze	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2011	Holden	Cruze	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2011	Holden	Cruze	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2011	Holden	Cruze	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2011	Holden	Cruze	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2011	Holden	Cruze	Passenger Presence Module	●	●	●	●	○	●	S043
2011	Holden	Cruze	Instrument Cluster	●	●	●	●	●	●	S022
2011	Holden	Cruze	Trailer Interface Control Module	●	●	●	●	●	●	S022
2011	Holden	Cruze	Radio	●	●	●	●	●	○	
2011	Holden	Cruze	Multimedia Player Interface Module	●	●	●	●	○	●	
2011	Holden	Cruze	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2011	Holden	Cruze	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2011	Holden	Cruze	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2011	Holden	Cruze	Front Seat Heating Control Module	●	●	●	●	●	○	
2011	Holden	Cruze	Keyless Entry Control Module	●	●	●	●	●	○	
2011	Holden	Cruze	Parking Assist Control Module	●	●	●	●	●	●	

2011	Holden	Cruze	Steering Column Lock Control Module	●	●	●	●	○	●	
2011	Buick	Lucerne	Transmission control module	●	●	○	●	●	○	
2011	Buick	Lucerne	Engine control module	●	●	●	●	●	●	T001
2011	Buick	Lucerne	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Buick	Lucerne	Radio	●	●	●	●	●	○	
2011	Buick	Lucerne	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Buick	Lucerne	Theft deterrent module	●	●	●	●	○	○	
2011	Buick	Lucerne	Left side object detection module	●	●	●	●	●	○	
2011	Buick	Lucerne	Memory seat module	●	●	●	●	●	○	
2011	Buick	Lucerne	Park assist module	●	●	●	●	○	○	
2011	Buick	Lucerne	Right side object detection module	●	●	●	●	○	○	
2011	Buick	Lucerne	Veh direction alert alarm warn mod	●	●	●	●	●	○	
2011	Buick	Lucerne	Passenger presence system	●	●	●	●	○	●	T025
2011	Buick	Lucerne	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Buick	Lucerne	HVAC control module	●	●	●	●	●	○	
2011	Buick	Lucerne	Digital radio receiver	●	●	●	●	●	○	
2011	Buick	Lucerne	Driver door switch	●	●	●	●	●	○	
2011	Buick	Lucerne	Passenger door switch	●	●	●	●	●	○	
2011	Buick	Lucerne	Body control module	●	●	●	●	●	●	T007 T005
2011	Buick	Lucerne	Instrument panel cluster	●	●	●	●	●	●	T002 T003 T004
2011	Buick	Lucerne	Electronic brake control module	●	●	●	●	●	●	T014
2011	Buick	Lucerne	Electronic suspension control	●	●	●	●	●	○	
2011	Cadillac	CTS	Engine control module	●	●	●	●	●	○	

2011	Cadillac	CTS	Fuel pump control module	●	●	●	●	●	○	
2011	Cadillac	CTS	Transmission control module	●	●	○	●	●	○	
2011	Cadillac	CTS	Transfer case control module	●	●	●	●	●	●	T001
2011	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Cadillac	CTS	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Cadillac	CTS	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2011	Cadillac	CTS	Pedestrian impact detection module	●	●	●	●	●	●	T009
2011	Cadillac	CTS	Passenger presence system	●	●	●	●	●	○	
2011	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2011	Cadillac	CTS	Park assist module	●	●	●	●	●	○	
2011	Cadillac	CTS	HVAC control module	●	●	●	●	●	●	T008
2011	Cadillac	CTS	Driver door switch	●	●	●	●	●	○	
2011	Cadillac	CTS	Passenger door switch	●	●	●	●	●	○	
2011	Cadillac	CTS	Radio	●	●	●	●	●	●	T011
2011	Cadillac	CTS	TV antenna module	●	●	●	●	○	●	T012 T013
2011	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	●	T010
2011	Cadillac	CTS	Liftgate module	●	●	●	●	●	○	
2011	Cadillac	CTS	Body control module	●	●	●	●	●	●	T007 T005
2011	Cadillac	CTS	Headlamp control module	●	●	●	●	●	●	T002 T003 T004
2011	Cadillac	CTS	Parking brake control module	●	●	●	●	●	○	
2011	Cadillac	CTS	Electronic brake control module	●	●	●	●	●	●	T014

2011	Cadillac	CTS	Electronic suspension control	●	●	○	●	●	○	
2011	Cadillac	DTS	Transmission control module	●	●	○	●	●	○	
2011	Cadillac	DTS	Engine control module	●	●	●	●	●	●	T001
2011	Cadillac	DTS	Instrument panel cluster	●	●	●	●	●	○	
2011	Cadillac	DTS	Amplifier (bose)	●	●	●	●	●	○	
2011	Cadillac	DTS	Digital radio receiver	●	●	●	●	●	○	
2011	Cadillac	DTS	Body control module	●	●	●	●	●	●	T007 T005
2011	Cadillac	DTS	Radio	●	●	●	●	●	○	
2011	Cadillac	DTS	TV antenna module	●	●	●	●	○	●	T012 T013
2011	Cadillac	DTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Cadillac	DTS	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Cadillac	DTS	Theft deterrent module	●	●	●	●	○	○	
2011	Cadillac	DTS	Passenger presence system	●	●	●	●	○	●	T025
2011	Cadillac	DTS	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Cadillac	DTS	Driver position module	●	●	●	●	●	○	
2011	Cadillac	DTS	Inside rear view mirror module	●	●	●	○	○	○	
2011	Cadillac	DTS	Left side object detection module	●	●	●	●	●	○	
2011	Cadillac	DTS	Rear heated seat module	●	●	●	●	○	○	
2011	Cadillac	DTS	Right side object detection module	●	●	●	●	○	○	
2011	Cadillac	DTS	Park assist module	●	●	●	●	●	○	
2011	Cadillac	DTS	Veh direction alert alarm warn mod	●	●	●	●	●	○	
2011	Cadillac	DTS	HVAC control module	●	●	●	●	●	○	

2011	Cadillac	DTS	Distance sensing cruise control	●	●	●	●	●	○	
2011	Cadillac	DTS	Driver door switch	●	●	●	●	●	●	T035
2011	Cadillac	DTS	Passenger door switch	●	●	●	●	●	●	T035
2011	Cadillac	DTS	Aux. HVAC control module	●	●	●	●	●	●	T035
2011	Cadillac	DTS	Electronic brake control module	●	●	●	●	●	●	T014
2011	Cadillac	DTS	Electronic suspension control	●	●	●	●	●	○	
2011	Cadillac	STS	Engine control module	●	●	●	●	●	○	
2011	Cadillac	STS	Transmission control module	●	●	○	●	●	○	
2011	Cadillac	STS	Amplifier (bose)	●	●	○	●	●	○	
2011	Cadillac	STS	Digital radio receiver	●	●	●	●	●	●	T024
2011	Cadillac	STS	Headlamp control module	●	●	●	●	●	○	
2011	Cadillac	STS	Instrument panel module	●	●	●	●	●	●	T059
2011	Cadillac	STS	Radio	●	●	●	●	○	●	T060 T033
2011	Cadillac	STS	Rear integration module	●	●	●	●	●	○	
2011	Cadillac	STS	Head up display	●	●	●	●	●	○	
2011	Cadillac	STS	Instrument panel cluster	●	●	●	●	●	●	T061 T062
2011	Cadillac	STS	Remote control door lock receiver	●	●	●	●	●	●	T021 T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T022
2011	Cadillac	STS	Passenger presence system	●	●	○	○	○	○	
2011	Cadillac	STS	Supplemental inflatable restraint	●	●	●	●	●	●	T067
2011	Cadillac	STS	Driver position module	●	●	●	●	●	○	

2011	Cadillac	STS	Left side object detection module	●	●	●	●	●	○	
2011	Cadillac	STS	Right side object detection module	●	●	●	●	○	○	
2011	Cadillac	STS	Veh direction alert alarm warn mod	●	●	●	●	●	○	
2011	Cadillac	STS	Distance sensing cruise control	●	●	●	●	●	○	
2011	Cadillac	STS	HVAC control module	●	●	●	●	●	○	
2011	Cadillac	STS	Driver door module	●	●	●	●	●	●	T068
2011	Cadillac	STS	Driver door switch	●	●	●	●	○	○	
2011	Cadillac	STS	Left rear door module	●	●	●	●	●	●	T068
2011	Cadillac	STS	Passenger door module	●	●	●	●	●	●	T068
2011	Cadillac	STS	Right rear door module	●	●	●	●	●	●	T068
2011	Cadillac	STS	TV antenna module	●	●	●	●	○	○	
2011	Cadillac	STS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	Cadillac	STS	Navigation radio	●	●	●	●	●	●	T069
2011	Cadillac	STS	Electronic brake control module	●	●	●	●	●	●	T014
2011	Cadillac	STS	Electronic suspension control	●	●	●	●	●	○	
2011	Chevrolet	Aveo	Engine control module	●	●	●	●	●	●	T015
2011	Chevrolet	Aveo	Transmission control module	●	●	●	●	●	●	T001
2011	Chevrolet	Aveo	Immobilizer	○	○	○	○	○	●	T016
2011	Chevrolet	Aveo	Supplemental inflatable restraint	●	●	●	●	●	●	T016
2011	Chevrolet	Aveo	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2011	Chevrolet	Aveo	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Aveo	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Aveo	Radio	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Aveo	Theft deterrent module	●	●	●	●	○	○	

2011	Chevrolet	Aveo	Passenger presence system	●	●	●	●	○	●	T025
2011	Chevrolet	Aveo	Instrument panel cluster	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Aveo	Engine control module	●	●	●	●	●	●	T015
2011	Chevrolet	Aveo	Transmission control module	●	●	●	●	●	●	T001
2011	Chevrolet	Aveo	Immobilizer	○	○	○	○	○	●	T016
2011	Chevrolet	Aveo	Supplemental inflatable restraint	●	●	●	●	●	●	T016
2011	Chevrolet	Aveo	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2011	Chevrolet	Aveo	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Aveo	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Aveo	Radio	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Aveo	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Aveo	Passenger presence system	●	●	●	●	○	●	T025
2011	Chevrolet	Aveo	Instrument panel cluster	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Caprice police	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Caprice police	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Caprice police	Fuel pump control module	●	●	●	●	●	○	
2011	Chevrolet	Caprice police	Passenger presence system	●	●	●	●	○	●	T020
2011	Chevrolet	Caprice police	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Caprice police	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Caprice police	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Caprice police	Instrument panel cluster	●	●	●	●	●	○	

2011	Chevrolet	Caprice police	Body control module	●	●	●	●	●	●	T007 T005
2011	Chevrolet	Caprice police	Radio	●	●	●	●	●	○	
2011	Chevrolet	Caprice police	HVAC control module	●	●	●	●	●	○	
2011	Chevrolet	Caprice police	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Chevy	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Chevy	Transmission control module	●	●	●	●	●	●	T001
2011	Chevrolet	Chevy	Immobilizer	●	●	●	●	○	●	T052 T053
2011	Chevrolet	Corvette	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Corvette	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Corvette	Exhaust flow control module	●	●	●	●	●	●	T001
2011	Chevrolet	Corvette	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Corvette	CD changer	●	●	●	●	○	○	
2011	Chevrolet	Corvette	Digital radio receiver	●	●	●	●	○	●	T024
2011	Chevrolet	Corvette	Radio	●	●	●	●	○	●	T032 T033
2011	Chevrolet	Corvette	Head up display	●	●	●	●	●	○	
2011	Chevrolet	Corvette	Remote control door lock receiver	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2011	Chevrolet	Corvette	Vehicle comm. interface module	●	●	●	●	●	●	T003
2011	Chevrolet	Corvette	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Corvette	Passenger presence system	●	●	○	○	○	●	T025
2011	Chevrolet	Corvette	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2011	Chevrolet	Corvette	Steering column lock module	●	●	●	●	●	○	
2011	Chevrolet	Corvette	Driver position module	●	●	●	●	●	●	T030
2011	Chevrolet	Corvette	Folding top module	●	●	●	●	●	○	

2011	Chevrolet	Corvette	HVAC control module	●	●	●	●	●	●	T008 T031
2011	Chevrolet	Corvette	Driver door module	●	●	●	●	●	○	
2011	Chevrolet	Corvette	Driver door switch	●	●	●	●	○	○	
2011	Chevrolet	Corvette	Passenger door module	●	●	●	●	●	○	
2011	Chevrolet	Corvette	Body control module	●	●	●	●	●	●	T023
2011	Chevrolet	Corvette	Navigation radio	●	●	●	●	○	●	T033
2011	Chevrolet	Corvette	Personal audio link module	●	●	●	●	●	●	T036
2011	Chevrolet	Corvette	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Corvette	Electronic suspension control	●	●	●	●	●	○	
2011	Chevrolet	Epica	Transmission control module	●	●	●	●	●	○	
2011	Chevrolet	Epica	Engine control module	●	●	●	●	●	●	T017
2011	Chevrolet	Epica	Supplemental inflatable restraint	●	●	●	●	●	○	
2011	Chevrolet	Epica	ISU	●	●	●	●	●	○	
2011	Chevrolet	Epica	Electronic brake control module	●	●	●	●	●	●	T017
2011	Chevrolet	Impala	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Impala	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Impala	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Impala	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Impala	Radio	●	●	●	●	●	○	
2011	Chevrolet	Impala	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Impala	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Impala	Passenger presence system	●	●	●	●	●	○	
2011	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Impala	Heated seat module	●	●	●	●	○	○	

2011	Chevrolet	Impala	Body control module	●	●	●	●	●	●	T007 T005
2011	Chevrolet	Impala	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Impala	HVAC control module	●	●	●	●	●	●	T008
2011	Chevrolet	Impala	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Malibu	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Malibu	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Malibu	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	Chevrolet	Malibu	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Malibu	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Malibu	Body control module	●	●	●	●	●	●	T008 T023 T056
2011	Chevrolet	Malibu	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Malibu	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Malibu	Passenger presence system	●	●	○	○	○	○	
2011	Chevrolet	Malibu	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2011	Chevrolet	Malibu	HVAC control module	●	●	●	●	●	○	
2011	Chevrolet	Malibu	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Malibu	Radio	●	●	●	●	●	●	T033
2011	Chevrolet	Malibu	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Malibu	Power steering control module	●	●	●	●	●	●	T014
2011	Chevrolet	Optra	Engine control module	●	●	●	●	●	●	T015
2011	Chevrolet	Optra	Transmission control module	●	●	●	●	●	●	T001
2011	Chevrolet	Optra	Immobilizer	○	○	○	○	○	●	T016

2011	Chevrolet	Optra	Supplemental inflatable restraint	●	●	●	●	●	○	
2011	Chevrolet	Optra	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2011	Chevrolet	Optra	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Spark classic	Transmission control module	●	●	●	●	●	○	
2011	Chevrolet	Spark classic	Engine control module	●	●	●	●	●	●	T015
2011	Chevrolet	Spark classic	Immobilizer	○	○	○	○	○	●	T016
2011	Chevrolet	Spark classic	Supplemental inflatable restraint	●	●	●	●	○	○	
2011	Chevrolet	Spark classic	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Others	Immobilizer	○	○	○	○	○	●	T016
2011	Chevrolet	Others	Supplemental inflatable restraint	●	●	●	●	●	○	
2011	Chevrolet	Others	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Others	Power steering control module	●	●	●	●	●	○	
2011	Chevrolet	Others	Transmission control module	●	●	●	●	●	○	
2011	Chevrolet	Others	Engine control module	●	●	○	●	●	●	T001
2011	Daewoo	Damas	Transmission control module	●	●	●	●	●	○	
2011	Daewoo	Damas	Engine control module	●	●	●	●	●	●	T015
2011	Daewoo	Labo	Transmission control module	●	●	●	●	●	○	
2011	Daewoo	Labo	Engine control module	●	●	●	●	●	●	T015
2011	Daewoo	Others	Engine control module	●	●	●	●	●	○	
2011	Daewoo	Others	Transmission control module	●	●	●	●	●	●	T001
2011	Daewoo	Others	Supplemental inflatable restraint	●	●	●	●	●	○	
2011	Daewoo	Others	ISU	●	●	●	●	●	●	T001

2011	Daewoo	Others	Immobilizer	●	●	●	●	●	●	T016
2011	Daewoo	Others	Electronic brake control module	●	●	●	●	●	●	T001
2011	Daewoo	Others	Tire pressure monitor	●	●	●	●	●	●	T018 T019
2011	Holden	Others	Engine control module	●	●	●	●	●	○	
2011	Holden	Others	Transmission control module	●	●	●	●	●	●	T001
2011	Holden	Others	Supplemental inflatable restraint	●	●	●	●	●	○	
2011	Holden	Others	ISU	●	●	●	●	●	●	T001
2011	Holden	Others	Immobilizer	●	●	●	●	●	●	T016
2011	Holden	Others	Electronic brake control module	●	●	●	●	●	●	T001
2011	Holden	Others	Tire pressure monitor	●	●	●	●	●	●	T018 T019
2011	Buick	Enclave - AWD	Transmission control module	●	●	○	●	●	○	
2011	Buick	Enclave - AWD	Engine control module	●	●	●	●	●	○	
2011	Buick	Enclave - AWD	Fuel pump control module	●	●	●	●	●	○	
2011	Buick	Enclave - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	Buick	Enclave - AWD	Digital radio receiver	●	●	●	●	●	○	
2011	Buick	Enclave - AWD	Body control module	○	○	○	○	○	●	T007 T005
2011	Buick	Enclave - AWD	Headlamp control module	●	●	●	○	○	○	
2011	Buick	Enclave - AWD	Liftgate module	●	●	●	●	●	○	
2011	Buick	Enclave - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2011	Buick	Enclave - AWD	Radio	●	●	●	●	●	○	
2011	Buick	Enclave - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Buick	Enclave - AWD	Theft deterrent module	●	●	●	●	○	○	
2011	Buick	Enclave - AWD	Instrument panel cluster	●	●	●	●	●	○	
2011	Buick	Enclave - AWD	Memory seat module	●	●	●	●	●	○	

2011	Buick	Enclave - AWD	Park assist module	●	●	●	●	○	○	
2011	Buick	Enclave - AWD	Passenger presence system	●	●	●	●	●	○	
2011	Buick	Enclave - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Buick	Enclave - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Buick	Enclave - AWD	Driver door switch	●	●	●	●	●	●	T035
2011	Buick	Enclave - AWD	Passenger door switch	●	●	●	●	●	●	T035
2011	Buick	Enclave - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Buick	Enclave - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Buick	Enclave - AWD	Rear drive system	●	●	●	●	●	●	T038
2011	Buick	Enclave - FWD	Transmission control module	●	●	○	●	●	○	
2011	Buick	Enclave - FWD	Engine control module	●	●	●	●	●	○	
2011	Buick	Enclave - FWD	Fuel pump control module	●	●	●	●	●	○	
2011	Buick	Enclave - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	Buick	Enclave - FWD	Digital radio receiver	●	●	●	●	●	○	
2011	Buick	Enclave - FWD	Body control module	○	○	○	○	○	●	T007 T005
2011	Buick	Enclave - FWD	Headlamp control module	●	●	●	○	○	○	
2011	Buick	Enclave - FWD	Liftgate module	●	●	●	●	●	○	
2011	Buick	Enclave - FWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2011	Buick	Enclave - FWD	Radio	●	●	●	●	●	○	
2011	Buick	Enclave - FWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Buick	Enclave - FWD	Theft deterrent module	●	●	●	●	○	○	
2011	Buick	Enclave - FWD	Instrument panel cluster	●	●	●	●	●	○	
2011	Buick	Enclave - FWD	Memory seat module	●	●	●	●	●	○	
2011	Buick	Enclave - FWD	Park assist module	●	●	●	●	○	○	

2011	Buick	Enclave - FWD	Passenger presence system	●	●	●	●	●	○	
2011	Buick	Enclave - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Buick	Enclave - FWD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Buick	Enclave - FWD	Driver door switch	●	●	●	●	●	●	T035
2011	Buick	Enclave - FWD	Passenger door switch	●	●	●	●	●	●	T035
2011	Buick	Enclave - FWD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Buick	Enclave - FWD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Buick	Enclave - FWD	Rear drive system	●	●	●	●	●	●	T038
2011	Cadillac	Escalade	Transmission control module	●	●	○	●	●	○	
2011	Cadillac	Escalade	Engine control module	●	●	●	●	●	●	T001
2011	Cadillac	Escalade	Fuel pump control module	●	●	●	●	●	●	T001
2011	Cadillac	Escalade	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Cadillac	Escalade	Digital radio receiver	●	●	●	●	●	○	
2011	Cadillac	Escalade	Amplifier (bose)	●	●	●	●	●	○	
2011	Cadillac	Escalade	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Cadillac	Escalade	Personal audio link module	●	●	●	○	○	●	T036
2011	Cadillac	Escalade	Radio	●	●	●	●	●	○	
2011	Cadillac	Escalade	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Cadillac	Escalade	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Cadillac	Escalade	Theft deterrent module	●	●	●	●	○	○	
2011	Cadillac	Escalade	Passenger presence system	●	●	●	●	○	○	
2011	Cadillac	Escalade	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Cadillac	Escalade	Memory seat module	●	●	●	●	●	○	

2011	Cadillac	Escalade	Inside rear view mirror module	●	●	●	●	●	○	
2011	Cadillac	Escalade	Rear heated seat module	●	●	●	●	○	○	
2011	Cadillac	Escalade	Park assist module	●	●	●	●	○	○	
2011	Cadillac	Escalade	Left side object detection module	●	●	●	●	●	○	
2011	Cadillac	Escalade	Right side object detection module	●	●	●	●	○	○	
2011	Cadillac	Escalade	Assist step controller	●	●	●	●	●	●	T039
2011	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2011	Cadillac	Escalade	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Cadillac	Escalade	Liftgate module	●	●	●	●	●	○	
2011	Cadillac	Escalade	Body control module	●	●	●	●	●	●	T005
2011	Cadillac	Escalade	Driver door switch	●	●	●	●	●	○	
2011	Cadillac	Escalade	Passenger door switch	●	●	●	●	●	○	
2011	Cadillac	Escalade	Electronic brake control module	●	●	●	●	●	●	T014
2011	Cadillac	Escalade	Electronic suspension control	●	●	●	●	●	●	T040
2011	Cadillac	Escalade	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Cadillac	Escalade	Transmission control module	●	●	○	●	●	○	
2011	Cadillac	Escalade	Engine control module	●	●	●	●	●	●	T001
2011	Cadillac	Escalade	Fuel pump control module	●	●	●	●	●	●	T001
2011	Cadillac	Escalade	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Cadillac	Escalade	Digital radio receiver	●	●	●	●	●	○	
2011	Cadillac	Escalade	Amplifier (bose)	●	●	●	●	●	○	
2011	Cadillac	Escalade	Body control module (aux.)	●	●	●	●	●	●	T006

2011	Cadillac	Escalade	Personal audio link module	●	●	●	○	○	●	T036
2011	Cadillac	Escalade	Radio	●	●	●	●	●	○	
2011	Cadillac	Escalade	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Cadillac	Escalade	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Cadillac	Escalade	Theft deterrent module	●	●	●	●	○	○	
2011	Cadillac	Escalade	Passenger presence system	●	●	●	●	○	○	
2011	Cadillac	Escalade	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Cadillac	Escalade	Memory seat module	●	●	●	●	●	○	
2011	Cadillac	Escalade	Inside rear view mirror module	●	●	●	●	●	○	
2011	Cadillac	Escalade	Rear heated seat module	●	●	●	●	○	○	
2011	Cadillac	Escalade	Park assist module	●	●	●	●	○	○	
2011	Cadillac	Escalade	Left side object detection module	●	●	●	●	●	○	
2011	Cadillac	Escalade	Right side object detection module	●	●	●	●	○	○	
2011	Cadillac	Escalade	Assist step controller	●	●	●	●	●	●	T039
2011	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2011	Cadillac	Escalade	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Cadillac	Escalade	Liftgate module	●	●	●	●	●	○	
2011	Cadillac	Escalade	Body control module	●	●	●	●	●	●	T005
2011	Cadillac	Escalade	Driver door switch	●	●	●	●	●	○	
2011	Cadillac	Escalade	Passenger door switch	●	●	●	●	●	○	
2011	Cadillac	Escalade	Electronic brake control module	●	●	●	●	●	●	T014
2011	Cadillac	Escalade	Electronic suspension control	●	●	●	●	●	●	T040
2011	Cadillac	Escalade	FPCM with trailer brake control	●	●	●	●	●	●	T014

2011	Cadillac	Escalade hybrid	Engine control module	●	●	●	●	●	●	T001
2011	Cadillac	Escalade hybrid	Accessory power module	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Transmission control module	●	●	○	●	●	○	
2011	Cadillac	Escalade hybrid	Fuel pump control module	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Cadillac	Escalade hybrid	Digital radio receiver	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Amplifier (bose)	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Cadillac	Escalade hybrid	Personal audio link module	●	●	●	○	○	●	T036
2011	Cadillac	Escalade hybrid	Radio	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Cadillac	Escalade hybrid	Theft deterrent module	●	●	●	●	○	○	
2011	Cadillac	Escalade hybrid	Passenger presence system	●	●	●	●	○	○	
2011	Cadillac	Escalade hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Cadillac	Escalade hybrid	Inside rear view mirror module	●	●	●	○	○	○	
2011	Cadillac	Escalade hybrid	Memory seat module	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Rear heated seat module	●	●	●	●	○	○	
2011	Cadillac	Escalade hybrid	Park assist module	●	●	●	●	○	○	
2011	Cadillac	Escalade hybrid	Left side object detection module	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Right side object detection module	●	●	●	●	○	○	
2011	Cadillac	Escalade hybrid	Assist step controller	●	●	●	●	●	●	T039

2011	Cadillac	Escalade hybrid	Instrument panel cluster	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Cadillac	Escalade hybrid	Serial data gateway module	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Liftgate module	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Body control module	●	●	●	●	●	●	T005
2011	Cadillac	Escalade hybrid	Driver door switch	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Passenger door switch	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	A/C compressor control module	●	●	●	●	○	○	
2011	Cadillac	Escalade hybrid	Power steering control module	●	●	○	●	○	●	T044
2011	Cadillac	Escalade hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2011	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2011	Cadillac	Escalade hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T044
2011	Cadillac	Escalade hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2011	Cadillac	Escalade hybrid	Engine control module	●	●	●	●	●	●	T001
2011	Cadillac	Escalade hybrid	Accessory power module	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Transmission control module	●	●	○	●	●	○	
2011	Cadillac	Escalade hybrid	Fuel pump control module	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Cadillac	Escalade hybrid	Digital radio receiver	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Amplifier (bose)	●	●	●	●	●	○	
2011	Cadillac	Escalade hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Cadillac	Escalade hybrid	Personal audio link module	●	●	●	○	○	●	T036

2011	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2011	Cadillac	Escalade hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T044
2011	Cadillac	Escalade hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2011	Cadillac	Hearse	Engine control module	●	●	●	●	●	●	T001
2011	Cadillac	Hearse	Transmission control module	●	●	○	●	●	○	
2011	Cadillac	Hearse	Digital radio receiver	●	●	●	●	●	○	
2011	Cadillac	Hearse	Driver door switch	●	●	●	●	●	○	
2011	Cadillac	Hearse	Passenger door switch	●	●	●	●	●	○	
2011	Cadillac	Hearse	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Cadillac	Hearse	Theft deterrent module	●	●	●	●	○	○	
2011	Cadillac	Hearse	Instrument panel cluster	●	●	●	●	●	○	
2011	Cadillac	Hearse	Driver position module	●	●	●	●	●	○	
2011	Cadillac	Hearse	Rear heated seat module	●	●	●	●	○	○	
2011	Cadillac	Hearse	Passenger presence system	●	●	●	●	○	●	T020
2011	Cadillac	Hearse	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Cadillac	Hearse	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Cadillac	Hearse	HVAC control module	●	●	●	●	●	○	
2011	Cadillac	Hearse	Body control module	●	●	●	●	●	●	T007 T005
2011	Cadillac	Hearse	Amplifier (bose)	●	●	●	●	●	○	
2011	Cadillac	Hearse	Radio	●	●	●	●	●	○	
2011	Cadillac	Hearse	Air suspension control module	●	●	●	●	●	○	
2011	Cadillac	Hearse	Electronic brake control module	●	●	●	●	○	●	T014
2011	Cadillac	Limousine	Engine control module	●	●	●	●	●	●	T001

2011	Cadillac	Limousine	Transmission control module	●	●	○	●	●	○	
2011	Cadillac	Limousine	Digital radio receiver	●	●	●	●	●	○	
2011	Cadillac	Limousine	Driver door switch	●	●	●	●	●	○	
2011	Cadillac	Limousine	Passenger door switch	●	●	●	●	●	○	
2011	Cadillac	Limousine	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Cadillac	Limousine	Theft deterrent module	●	●	●	●	○	○	
2011	Cadillac	Limousine	Instrument panel cluster	●	●	●	●	●	○	
2011	Cadillac	Limousine	Driver position module	●	●	●	●	●	○	
2011	Cadillac	Limousine	Rear heated seat module	●	●	●	●	○	○	
2011	Cadillac	Limousine	Passenger presence system	●	●	●	●	○	●	T020
2011	Cadillac	Limousine	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Cadillac	Limousine	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Cadillac	Limousine	HVAC control module	●	●	●	●	●	○	
2011	Cadillac	Limousine	Aux. HVAC control module	○	○	●	●	●	○	
2011	Cadillac	Limousine	Body control module	●	●	●	●	●	●	T007 T005
2011	Cadillac	Limousine	Amplifier (bose)	●	●	●	●	●	○	
2011	Cadillac	Limousine	Radio	●	●	●	●	●	○	
2011	Cadillac	Limousine	Air suspension control module	●	●	●	●	●	○	
2011	Cadillac	Limousine	Electronic brake control module	●	●	●	●	○	●	T014
2011	Chevrolet	Avalanche - 2WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Avalanche - 2WD	Fuel pump control module	●	●	●	●	●	●	T001

2011	Chevrolet	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Avalanche - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Avalanche - 2WD	Radio	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Avalanche - 2WD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Avalanche - 2WD	Memory seat module	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 2WD	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 2WD	Assist step controller	●	●	●	●	●	●	T039
2011	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Avalanche - 2WD	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Avalanche - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T014

2011	Chevrolet	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Avalanche - 2WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Avalanche - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Avalanche - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Avalanche - 2WD	Radio	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Avalanche - 2WD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Avalanche - 2WD	Memory seat module	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 2WD	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 2WD	Assist step controller	●	●	●	●	●	●	T039
2011	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Avalanche - 2WD	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	●	T005

2011	Chevrolet	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Avalanche - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Avalanche - 4WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Avalanche - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Avalanche - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Avalanche - 4WD	Radio	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Avalanche - 4WD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Avalanche - 4WD	Memory seat module	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 4WD	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 4WD	Assist step controller	●	●	●	●	●	●	T039

2011	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Avalanche - 4WD	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Avalanche - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Avalanche - 4WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Avalanche - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Avalanche - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Avalanche - 4WD	Radio	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Avalanche - 4WD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	●	●	○	○	

2011	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Avalanche - 4WD	Memory seat module	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 4WD	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Avalanche - 4WD	Assist step controller	●	●	●	●	●	●	T039
2011	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Avalanche - 4WD	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Avalanche - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	N200	Engine control module	●	●	●	●	●	●	T015
2011	Chevrolet	N200	Supplemental inflatable restraint	●	●	●	●	○	○	
2011	Chevrolet	N200	Electronic brake control module	●	●	○	●	●	●	T014
2011	Chevrolet	N300	Engine control module	●	●	●	●	●	●	T015
2011	Chevrolet	N300	Supplemental inflatable restraint	●	●	●	●	○	○	
2011	Chevrolet	N300	Electronic brake control module	●	●	○	●	●	●	T014
2011	Chevrolet	Captiva	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Captiva	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Captiva	Rear drive system	●	●	●	●	●	●	T038

2011	Chevrolet	Captiva	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Captiva	Body control module (aux.)	●	●	●	●	●	○	
2011	Chevrolet	Captiva	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Captiva	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Captiva	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Captiva	HVAC control module	●	●	●	○	●	○	
2011	Chevrolet	Captiva	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Captiva	Electronic brake control module	●	●	●	●	●	○	
2011	Chevrolet	Captiva sport	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Captiva sport	Engine control module	●	●	●	●	●	○	
2011	Chevrolet	Captiva sport	Fuel pump control module	●	●	●	●	●	○	
2011	Chevrolet	Captiva sport	Rear drive system	●	●	●	●	●	●	T038
2011	Chevrolet	Captiva sport	Body control module	●	●	●	●	●	●	T007 T005
2011	Chevrolet	Captiva sport	Radio	●	●	●	●	●	○	
2011	Chevrolet	Captiva sport	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Captiva sport	HVAC control module	●	●	●	●	●	●	T008
2011	Chevrolet	Captiva sport	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Captiva sport	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Captiva sport	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Captiva sport	Passenger presence system	●	●	●	●	○	●	T045
2011	Chevrolet	Captiva sport	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	Chevrolet	Captiva sport	Digital radio receiver	●	●	●	●	●	○	

2011	Chevrolet	Captiva sport	Electronic brake control module	●	●	●	●	●	○	
2011	Chevrolet	Captiva sport	Parking brake control module	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Cheyenne - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Cheyenne - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Cheyenne - 2WD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Cheyenne - 2WD	Chime	●	●	●	○	●	○	
2011	Chevrolet	Cheyenne - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Cheyenne - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Cheyenne - 2WD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 2WD	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Cheyenne - 2WD	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 2WD	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Body control module	●	●	●	●	●	●	T005

2011	Chevrolet	Cheyenne - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Cheyenne - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Cheyenne - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Cheyenne - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Cheyenne - 2WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Cheyenne - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Cheyenne - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Cheyenne - 2WD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Cheyenne - 2WD	Chime	●	●	●	○	●	○	
2011	Chevrolet	Cheyenne - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Cheyenne - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Cheyenne - 2WD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 2WD	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Cheyenne - 2WD	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 2WD	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 2WD	Instrument panel cluster	●	●	●	●	●	○	

2011	Chevrolet	Cheyenne - 2WD	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 2WD	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Cheyenne - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Cheyenne - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Cheyenne - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Cheyenne - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Cheyenne - 4WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Cheyenne - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Cheyenne - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Cheyenne - 4WD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Cheyenne - 4WD	Chime	●	●	●	○	●	○	
2011	Chevrolet	Cheyenne - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Cheyenne - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Cheyenne - 4WD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 4WD	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Cheyenne - 4WD	Rear heated seat module	●	●	●	●	○	○	

2011	Chevrolet	Cheyenne - 4WD	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Cheyenne - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Cheyenne - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Cheyenne - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Cheyenne - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Cheyenne - 4WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Cheyenne - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Cheyenne - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Cheyenne - 4WD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Cheyenne - 4WD	Chime	●	●	●	○	●	○	
2011	Chevrolet	Cheyenne - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Cheyenne - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Cheyenne - 4WD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 4WD	Passenger presence system	●	●	●	●	○	○	

2011	Chevrolet	Cheyenne - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Cheyenne - 4WD	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 4WD	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Cheyenne - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Cheyenne - 4WD	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Cheyenne - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Cheyenne - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Cheyenne - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Cheyenne - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Colorado pickup - 2WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Colorado pickup - 2WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Colorado pickup - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Colorado pickup - 2WD	Digital radio receiver	●	●	●	●	●	●	T024
2011	Chevrolet	Colorado pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022
2011	Chevrolet	Colorado pickup - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Colorado pickup - 2WD	Radio	●	●	●	●	○	○	
2011	Chevrolet	Colorado pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T003

2011	Chevrolet	Colorado pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Colorado pickup - 2WD	Theft deterrent module	●	●	●	●	○	●	T057
2011	Chevrolet	Colorado pickup - 2WD	Passenger presence system	●	●	○	○	○	●	T025
2011	Chevrolet	Colorado pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2011	Chevrolet	Colorado pickup - 2WD	Generator battery control module	●	●	●	●	●	●	T024
2011	Chevrolet	Colorado pickup - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2011	Chevrolet	Colorado pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Colorado pickup - 4WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Colorado pickup - 4WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Colorado pickup - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Colorado pickup - 4WD	Digital radio receiver	●	●	●	●	●	●	T024
2011	Chevrolet	Colorado pickup - 4WD	Body control module	●	●	●	●	●	●	T058 T022
2011	Chevrolet	Colorado pickup - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Colorado pickup - 4WD	Radio	●	●	●	●	○	○	
2011	Chevrolet	Colorado pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T003
2011	Chevrolet	Colorado pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Colorado pickup - 4WD	Theft deterrent module	●	●	●	●	○	●	T057

2011	Chevrolet	Colorado pickup - 4WD	Passenger presence system	●	●	○	○	○	●	T025
2011	Chevrolet	Colorado pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2011	Chevrolet	Colorado pickup - 4WD	Generator battery control module	●	●	●	●	●	●	T024
2011	Chevrolet	Colorado pickup - 4WD	Electronic brake control module	●	●	●	●	●	●	T001
2011	Chevrolet	Colorado pickup - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Express	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Express	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2011	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	Chevrolet	Express	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Express	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Express	Radio	●	●	●	●	●	○	
2011	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T025
2011	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049
2011	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Express	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014

2011	Chevrolet	Express	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Express	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2011	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	Chevrolet	Express	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Express	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Express	Radio	●	●	●	●	●	○	
2011	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T025
2011	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049
2011	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Express	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Express	Transmission control module	●	●	●	●	●	●	T001
2011	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	Chevrolet	Express	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Express	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Express	Radio	●	●	●	●	●	○	

2011	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T025
2011	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049
2011	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Express	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Express	Transmission control module	●	●	●	●	●	●	T001
2011	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	Chevrolet	Express	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Express	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Express	Radio	●	●	●	●	●	○	
2011	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T025
2011	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049
2011	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Express	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014

2011	Chevrolet	HHR	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	HHR	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	HHR	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	Chevrolet	HHR	Body control module	●	●	●	●	●	●	T023
2011	Chevrolet	HHR	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	HHR	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	HHR	Radio	●	●	●	●	●	○	
2011	Chevrolet	HHR	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	HHR	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	HHR	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	HHR	Passenger presence system	●	●	○	○	○	○	
2011	Chevrolet	HHR	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2011	Chevrolet	HHR	Electronic brake control module	●	●	●	●	●	○	
2011	Chevrolet	HHR	Power steering control module	●	●	●	●	●	○	
2011	Chevrolet	HHR panel	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	HHR panel	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	HHR panel	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	Chevrolet	HHR panel	Body control module	●	●	●	●	●	●	T023
2011	Chevrolet	HHR panel	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	HHR panel	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	HHR panel	Radio	●	●	●	●	●	○	
2011	Chevrolet	HHR panel	Instrument panel cluster	●	●	●	●	●	○	

2011	Chevrolet	HHR panel	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	HHR panel	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	HHR panel	Passenger presence system	●	●	○	○	○	○	
2011	Chevrolet	HHR panel	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2011	Chevrolet	HHR panel	Electronic brake control module	●	●	●	●	●	○	
2011	Chevrolet	HHR panel	Power steering control module	●	●	●	●	●	○	
2011	Chevrolet	Silverado	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Silverado	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Silverado	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Silverado	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Silverado	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Silverado	Radio	●	●	●	●	●	○	
2011	Chevrolet	Silverado	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Silverado	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Silverado	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Silverado	Memory seat module	●	●	●	●	●	○	

2011	Chevrolet	Silverado	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Silverado	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Silverado	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Silverado	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Silverado	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Silverado	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Silverado	Trailer brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Silverado	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Silverado	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Silverado	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Silverado	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Silverado	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Silverado	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Silverado	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Silverado	Radio	●	●	●	●	●	○	
2011	Chevrolet	Silverado	Rear HVAC/RSA	●	●	●	●	●	○	

2011	Chevrolet	Silverado	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Silverado	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Silverado	Memory seat module	●	●	●	●	●	○	
2011	Chevrolet	Silverado	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Silverado	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Silverado	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Silverado	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Silverado	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Silverado	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Silverado	Trailer brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Silverado	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Silverado	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Silverado hybrid	Accessory power module	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Silverado hybrid	Fuel pump control module	●	●	●	●	●	○	

2011	Chevrolet	Silverado hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Silverado hybrid	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Silverado hybrid	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Silverado hybrid	Radio	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Silverado hybrid	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Silverado hybrid	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Silverado hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Silverado hybrid	Heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Silverado hybrid	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Silverado hybrid	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Silverado hybrid	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Silverado hybrid	Serial data gateway module	●	●	●	●	●	○	

2011	Chevrolet	Silverado hybrid	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Silverado hybrid	A/C compressor control module	●	●	●	●	○	○	
2011	Chevrolet	Silverado hybrid	Power steering control module	●	●	○	●	○	●	T044
2011	Chevrolet	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2011	Chevrolet	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Silverado hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T044
2011	Chevrolet	Silverado hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Silverado hybrid	Accessory power module	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Silverado hybrid	Fuel pump control module	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Silverado hybrid	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Body control module (aux.)	●	●	●	●	●	●	T006

2011	Chevrolet	Silverado hybrid	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Silverado hybrid	Radio	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Silverado hybrid	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Silverado hybrid	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Silverado hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Silverado hybrid	Heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Silverado hybrid	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Silverado hybrid	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Silverado hybrid	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Silverado hybrid	Serial data gateway module	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Silverado hybrid	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Silverado hybrid	A/C compressor control module	●	●	●	●	○	○	

2011	Chevrolet	Silverado hybrid	Power steering control module	●	●	○	●	○	●	T044
2011	Chevrolet	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2011	Chevrolet	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Silverado hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T044
2011	Chevrolet	Silverado hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Suburban - 2WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Suburban - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Suburban - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Suburban - 2WD	Radio	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Suburban - 2WD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Suburban - 2WD	Memory seat module	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Rear heated seat module	●	●	●	●	○	○	

2011	Chevrolet	Suburban - 2WD	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 2WD	Left side object detection module	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Right side object detection module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 2WD	Assist step controller	●	●	●	●	●	●	T039
2011	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Suburban - 2WD	Liftgate module	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Suburban - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Suburban - 2WD	Trailer brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Suburban - 2WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Suburban - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006

2011	Chevrolet	Suburban - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Suburban - 2WD	Radio	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Suburban - 2WD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Suburban - 2WD	Memory seat module	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 2WD	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 2WD	Left side object detection module	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Right side object detection module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 2WD	Assist step controller	●	●	●	●	●	●	T039
2011	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Suburban - 2WD	Liftgate module	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Suburban - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Suburban - 2WD	Trailer brake control module	●	●	●	●	●	●	T014

2011	Chevrolet	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Suburban - 4WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Suburban - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Suburban - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Suburban - 4WD	Radio	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Suburban - 4WD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Suburban - 4WD	Memory seat module	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 4WD	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 4WD	Left side object detection module	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Right side object detection module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 4WD	Assist step controller	●	●	●	●	●	●	T039
2011	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	

2011	Chevrolet	Suburban - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Suburban - 4WD	Liftgate module	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Suburban - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Suburban - 4WD	Trailer brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Suburban - 4WD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Suburban - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	Chevrolet	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Suburban - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Suburban - 4WD	Radio	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Suburban - 4WD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	●	●	○	○	

2011	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Suburban - 4WD	Memory seat module	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 4WD	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 4WD	Left side object detection module	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Right side object detection module	●	●	●	●	○	○	
2011	Chevrolet	Suburban - 4WD	Assist step controller	●	●	●	●	●	●	T039
2011	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Suburban - 4WD	Liftgate module	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Suburban - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Suburban - 4WD	Trailer brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Tahoe	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Tahoe	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Body control module (aux.)	●	●	●	●	●	●	T006

2011	Chevrolet	Tahoe	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Tahoe	Radio	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Tahoe	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Tahoe	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Tahoe	Memory seat module	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe	Left side object detection module	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Right side object detection module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe	Assist step controller	●	●	●	●	●	●	T039
2011	Chevrolet	Tahoe	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Tahoe	Liftgate module	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Tahoe	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Tahoe	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Tahoe	Transmission control module	●	●	○	●	●	○	

2011	Chevrolet	Tahoe	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Tahoe	Fuel pump control module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Tahoe	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Tahoe	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Tahoe	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Tahoe	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Tahoe	Radio	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Tahoe	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Tahoe	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Tahoe	Memory seat module	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe	Left side object detection module	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Right side object detection module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe	Assist step controller	●	●	●	●	●	●	T039
2011	Chevrolet	Tahoe	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Tahoe	Liftgate module	●	●	●	●	●	○	

2011	Chevrolet	Tahoe	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Tahoe	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Tahoe	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Tahoe	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	Chevrolet	Tahoe	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Tahoe	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Tahoe	Fuel pump control module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Tahoe	Transfer case control module	●	●	●	●	●	●	T001
2011	Chevrolet	Tahoe hybrid	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Tahoe hybrid	Accessory power module	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Tahoe hybrid	Fuel pump control module	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Tahoe hybrid	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Tahoe hybrid	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Tahoe hybrid	Radio	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	

2011	Chevrolet	Tahoe hybrid	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Tahoe hybrid	Heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe hybrid	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe hybrid	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe hybrid	Left side object detection module	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Right side object detection module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Tahoe hybrid	Serial data gateway module	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Liftgate module	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Tahoe hybrid	A/C compressor control module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe hybrid	Power steering control module	●	●	○	●	○	●	T044
2011	Chevrolet	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2011	Chevrolet	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Tahoe hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T044
2011	Chevrolet	Tahoe hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Tahoe hybrid	Engine control module	●	●	●	●	●	●	T001
2011	Chevrolet	Tahoe hybrid	Accessory power module	●	●	●	●	●	○	

2011	Chevrolet	Tahoe hybrid	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Tahoe hybrid	Fuel pump control module	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Tahoe hybrid	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Amplifier (bose)	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2011	Chevrolet	Tahoe hybrid	Personal audio link module	●	●	●	○	○	●	T036
2011	Chevrolet	Tahoe hybrid	Radio	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe hybrid	Passenger presence system	●	●	●	●	○	○	
2011	Chevrolet	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Tahoe hybrid	Heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe hybrid	Rear heated seat module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe hybrid	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe hybrid	Left side object detection module	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Right side object detection module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Tahoe hybrid	Serial data gateway module	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Liftgate module	●	●	●	●	●	○	

2011	Chevrolet	Tahoe hybrid	Driver door switch	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Passenger door switch	●	●	●	●	●	○	
2011	Chevrolet	Tahoe hybrid	Body control module	●	●	●	●	●	●	T005
2011	Chevrolet	Tahoe hybrid	A/C compressor control module	●	●	●	●	○	○	
2011	Chevrolet	Tahoe hybrid	Power steering control module	●	●	○	●	○	●	T044
2011	Chevrolet	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2011	Chevrolet	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2011	Chevrolet	Tahoe hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T044
2011	Chevrolet	Tahoe hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2011	Chevrolet	Traverse - AWD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Traverse - AWD	Engine control module	●	●	●	●	●	○	
2011	Chevrolet	Traverse - AWD	Fuel pump control module	●	●	●	●	●	○	
2011	Chevrolet	Traverse - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	Chevrolet	Traverse - AWD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Traverse - AWD	Body control module	○	○	○	○	○	●	T007 T005
2011	Chevrolet	Traverse - AWD	Liftgate module	●	●	●	●	●	○	
2011	Chevrolet	Traverse - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2011	Chevrolet	Traverse - AWD	Radio	●	●	●	●	●	○	
2011	Chevrolet	Traverse - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Traverse - AWD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Traverse - AWD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Traverse - AWD	Memory seat module	●	●	●	●	●	○	
2011	Chevrolet	Traverse - AWD	Park assist module	●	●	●	●	○	○	

2011	Chevrolet	Traverse - AWD	Passenger presence system	●	●	●	●	●	○	
2011	Chevrolet	Traverse - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	Chevrolet	Traverse - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Traverse - AWD	Driver door switch	●	●	●	●	●	●	T035
2011	Chevrolet	Traverse - AWD	Passenger door switch	●	●	●	●	●	●	T035
2011	Chevrolet	Traverse - AWD	Rear HVAC/RSA	●	●	●	●	●	●	T002 T003
2011	Chevrolet	Traverse - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Traverse - AWD	Rear drive system	●	●	●	●	●	●	T038
2011	Chevrolet	Traverse - FWD	Transmission control module	●	●	○	●	●	○	
2011	Chevrolet	Traverse - FWD	Engine control module	●	●	●	●	●	○	
2011	Chevrolet	Traverse - FWD	Fuel pump control module	●	●	●	●	●	○	
2011	Chevrolet	Traverse - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	Chevrolet	Traverse - FWD	Digital radio receiver	●	●	●	●	●	○	
2011	Chevrolet	Traverse - FWD	Body control module	○	○	○	○	○	●	T007 T005
2011	Chevrolet	Traverse - FWD	Liftgate module	●	●	●	●	●	○	
2011	Chevrolet	Traverse - FWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2011	Chevrolet	Traverse - FWD	Radio	●	●	●	●	●	○	
2011	Chevrolet	Traverse - FWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	Chevrolet	Traverse - FWD	Theft deterrent module	●	●	●	●	○	○	
2011	Chevrolet	Traverse - FWD	Instrument panel cluster	●	●	●	●	●	○	
2011	Chevrolet	Traverse - FWD	Memory seat module	●	●	●	●	●	○	
2011	Chevrolet	Traverse - FWD	Park assist module	●	●	●	●	○	○	
2011	Chevrolet	Traverse - FWD	Passenger presence system	●	●	●	●	●	○	
2011	Chevrolet	Traverse - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2011	Chevrolet	Traverse - FWD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	Chevrolet	Traverse - FWD	Driver door switch	●	●	●	●	●	●	T035
2011	Chevrolet	Traverse - FWD	Passenger door switch	●	●	●	●	●	●	T035
2011	Chevrolet	Traverse - FWD	Rear HVAC/RSA	●	●	●	●	●	●	T002 T003
2011	Chevrolet	Traverse - FWD	Electronic brake control module	●	●	●	●	●	●	T014
2011	Chevrolet	Traverse - FWD	Rear drive system	●	●	●	●	●	●	T038
2011	GMC truck	Acadia - 2WD	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Acadia - 2WD	Engine control module	●	●	●	●	●	○	
2011	GMC truck	Acadia - 2WD	Fuel pump control module	●	●	●	●	●	○	
2011	GMC truck	Acadia - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	GMC truck	Acadia - 2WD	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Acadia - 2WD	Body control module	○	○	○	○	○	●	T007 T005
2011	GMC truck	Acadia - 2WD	Liftgate module	●	●	●	●	●	○	
2011	GMC truck	Acadia - 2WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2011	GMC truck	Acadia - 2WD	Radio	●	●	●	●	●	○	
2011	GMC truck	Acadia - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Acadia - 2WD	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Acadia - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Acadia - 2WD	Memory seat module	●	●	●	●	●	○	
2011	GMC truck	Acadia - 2WD	Park assist module	●	●	●	●	○	○	
2011	GMC truck	Acadia - 2WD	Passenger presence system	●	●	●	●	●	○	
2011	GMC truck	Acadia - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	GMC truck	Acadia - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	GMC truck	Acadia - 2WD	Driver door switch	●	●	●	●	●	●	T035
2011	GMC truck	Acadia - 2WD	Passenger door switch	●	●	●	●	●	●	T035
2011	GMC truck	Acadia - 2WD	Head up display	●	●	●	●	○	○	

2011	GMC truck	Acadia - 2WD	Rear HVAC/RSA	●	●	●	●	●	●	T002 T003
2011	GMC truck	Acadia - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Acadia - 2WD	Rear drive system	●	●	●	●	●	●	T038
2011	GMC truck	Acadia - 4WD	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Acadia - 4WD	Engine control module	●	●	●	●	●	○	
2011	GMC truck	Acadia - 4WD	Fuel pump control module	●	●	●	●	●	○	
2011	GMC truck	Acadia - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	GMC truck	Acadia - 4WD	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Acadia - 4WD	Body control module	○	○	○	○	○	●	T007 T005
2011	GMC truck	Acadia - 4WD	Liftgate module	●	●	●	●	●	○	
2011	GMC truck	Acadia - 4WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2011	GMC truck	Acadia - 4WD	Radio	●	●	●	●	●	○	
2011	GMC truck	Acadia - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Acadia - 4WD	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Acadia - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Acadia - 4WD	Memory seat module	●	●	●	●	●	○	
2011	GMC truck	Acadia - 4WD	Park assist module	●	●	●	●	○	○	
2011	GMC truck	Acadia - 4WD	Passenger presence system	●	●	●	●	●	○	
2011	GMC truck	Acadia - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	GMC truck	Acadia - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2011	GMC truck	Acadia - 4WD	Driver door switch	●	●	●	●	●	●	T035
2011	GMC truck	Acadia - 4WD	Passenger door switch	●	●	●	●	●	●	T035
2011	GMC truck	Acadia - 4WD	Head up display	●	●	●	●	○	○	
2011	GMC truck	Acadia - 4WD	Rear HVAC/RSA	●	●	●	●	●	●	T002 T003
2011	GMC truck	Acadia - 4WD	Electronic brake control module	●	●	●	●	●	●	T014

2011	GMC truck	Acadia - 4WD	Rear drive system	●	●	●	●	●	●	T038
2011	GMC truck	Canyon pickup - 2WD	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Canyon pickup - 2WD	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Canyon pickup - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	●	●	T024
2011	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022
2011	GMC truck	Canyon pickup - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2011	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	
2011	GMC truck	Canyon pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T003
2011	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Canyon pickup - 2WD	Theft deterrent module	●	●	●	●	○	●	T057
2011	GMC truck	Canyon pickup - 2WD	Passenger presence system	●	●	○	○	○	●	T025
2011	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2011	GMC truck	Canyon pickup - 2WD	Generator battery control module	●	●	●	●	●	●	T024
2011	GMC truck	Canyon pickup - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2011	GMC truck	Canyon pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2011	GMC truck	Canyon pickup - 4WD	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Canyon pickup - 4WD	Engine control module	●	●	●	●	●	●	T001

2011	GMC truck	Canyon pickup - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2011	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	●	●	T024
2011	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058 T022
2011	GMC truck	Canyon pickup - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2011	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	
2011	GMC truck	Canyon pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T003
2011	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Canyon pickup - 4WD	Theft deterrent module	●	●	●	●	○	●	T057
2011	GMC truck	Canyon pickup - 4WD	Passenger presence system	●	●	○	○	○	●	T025
2011	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2011	GMC truck	Canyon pickup - 4WD	Generator battery control module	●	●	●	●	●	●	T024
2011	GMC truck	Canyon pickup - 4WD	Electronic brake control module	●	●	●	●	●	●	T001
2011	GMC truck	Canyon pickup - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2011	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2011	GMC truck	Savana	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2011	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003

2011	GMC truck	Savana	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2011	GMC truck	Savana	Radio	●	●	●	●	●	○	
2011	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T025
2011	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2011	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2011	GMC truck	Savana	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2011	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	GMC truck	Savana	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2011	GMC truck	Savana	Radio	●	●	●	●	●	○	
2011	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T025
2011	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2011	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2011	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Savana	Transmission control module	●	●	●	●	●	●	T001
2011	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2011	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	GMC truck	Savana	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2011	GMC truck	Savana	Radio	●	●	●	●	●	○	
2011	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T025
2011	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2011	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Savana	Transmission control module	●	●	●	●	●	●	T001
2011	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2011	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2011	GMC truck	Savana	Digital radio receiver	●	●	●	●	●	○	

2011	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2011	GMC truck	Savana	Radio	●	●	●	●	●	○	
2011	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T025
2011	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2011	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Sierra	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Sierra	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Sierra	Fuel pump control module	●	●	●	●	●	●	T001
2011	GMC truck	Sierra	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	GMC truck	Sierra	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Sierra	Amplifier (bose)	●	●	●	●	●	○	
2011	GMC truck	Sierra	Body control module (aux.)	●	●	●	●	●	●	T006
2011	GMC truck	Sierra	Personal audio link module	●	●	●	○	○	●	T036
2011	GMC truck	Sierra	Radio	●	●	●	●	●	○	
2011	GMC truck	Sierra	Rear HVAC/RSA	●	●	●	●	●	○	
2011	GMC truck	Sierra	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Sierra	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Sierra	Passenger presence system	●	●	●	●	○	○	

2011	GMC truck	Sierra	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	GMC truck	Sierra	Memory seat module	●	●	●	●	●	○	
2011	GMC truck	Sierra	Rear heated seat module	●	●	●	●	○	○	
2011	GMC truck	Sierra	Park assist module	●	●	●	●	○	○	
2011	GMC truck	Sierra	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Sierra	HVAC control module	●	●	●	●	●	●	T008 T034
2011	GMC truck	Sierra	Driver door switch	●	●	●	●	●	○	
2011	GMC truck	Sierra	Passenger door switch	●	●	●	●	●	○	
2011	GMC truck	Sierra	Body control module	●	●	●	●	●	●	T005
2011	GMC truck	Sierra	Electronic brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Sierra	Electronic suspension control	●	●	●	●	●	●	T040
2011	GMC truck	Sierra	Trailer brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Sierra	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	GMC truck	Sierra	Transfer case control module	●	●	●	●	●	●	T001
2011	GMC truck	Sierra	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Sierra	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Sierra	Fuel pump control module	●	●	●	●	●	●	T001
2011	GMC truck	Sierra	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	GMC truck	Sierra	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Sierra	Amplifier (bose)	●	●	●	●	●	○	
2011	GMC truck	Sierra	Body control module (aux.)	●	●	●	●	●	●	T006
2011	GMC truck	Sierra	Personal audio link module	●	●	●	○	○	●	T036

2011	GMC truck	Sierra	Radio	●	●	●	●	●	○	
2011	GMC truck	Sierra	Rear HVAC/RSA	●	●	●	●	●	○	
2011	GMC truck	Sierra	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Sierra	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Sierra	Passenger presence system	●	●	●	●	○	○	
2011	GMC truck	Sierra	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	GMC truck	Sierra	Memory seat module	●	●	●	●	●	○	
2011	GMC truck	Sierra	Rear heated seat module	●	●	●	●	○	○	
2011	GMC truck	Sierra	Park assist module	●	●	●	●	○	○	
2011	GMC truck	Sierra	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Sierra	HVAC control module	●	●	●	●	●	●	T008 T034
2011	GMC truck	Sierra	Driver door switch	●	●	●	●	●	○	
2011	GMC truck	Sierra	Passenger door switch	●	●	●	●	●	○	
2011	GMC truck	Sierra	Body control module	●	●	●	●	●	●	T005
2011	GMC truck	Sierra	Electronic brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Sierra	Electronic suspension control	●	●	●	●	●	●	T040
2011	GMC truck	Sierra	Trailer brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Sierra	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	GMC truck	Sierra	Transfer case control module	●	●	●	●	●	●	T001
2011	GMC truck	Sierra hybrid	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Sierra hybrid	Accessory power module	●	●	●	●	●	○	
2011	GMC truck	Sierra hybrid	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Sierra hybrid	Fuel pump control module	●	●	●	●	●	○	

2011	GMC truck	Sierra hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2011	GMC truck	Sierra hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T044
2011	GMC truck	Sierra hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2011	GMC truck	Sierra hybrid	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Sierra hybrid	Accessory power module	●	●	●	●	●	○	
2011	GMC truck	Sierra hybrid	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Sierra hybrid	Fuel pump control module	●	●	●	●	●	○	
2011	GMC truck	Sierra hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	GMC truck	Sierra hybrid	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Sierra hybrid	Amplifier (bose)	●	●	●	●	●	○	
2011	GMC truck	Sierra hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2011	GMC truck	Sierra hybrid	Personal audio link module	●	●	●	○	○	●	T036
2011	GMC truck	Sierra hybrid	Radio	●	●	●	●	●	○	
2011	GMC truck	Sierra hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2011	GMC truck	Sierra hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Sierra hybrid	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Sierra hybrid	Passenger presence system	●	●	●	●	○	○	
2011	GMC truck	Sierra hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	GMC truck	Sierra hybrid	Heated seat module	●	●	●	●	○	○	
2011	GMC truck	Sierra hybrid	Rear heated seat module	●	●	●	●	○	○	
2011	GMC truck	Sierra hybrid	Park assist module	●	●	●	●	○	○	
2011	GMC truck	Sierra hybrid	Instrument panel cluster	●	●	●	●	●	○	

2011	GMC truck	Sierra hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2011	GMC truck	Sierra hybrid	Serial data gateway module	●	●	●	●	●	○	
2011	GMC truck	Sierra hybrid	Driver door switch	●	●	●	●	●	○	
2011	GMC truck	Sierra hybrid	Passenger door switch	●	●	●	●	●	○	
2011	GMC truck	Sierra hybrid	Body control module	●	●	●	●	●	●	T005
2011	GMC truck	Sierra hybrid	A/C compressor control module	●	●	●	●	○	○	
2011	GMC truck	Sierra hybrid	Power steering control module	●	●	○	●	○	●	T044
2011	GMC truck	Sierra hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2011	GMC truck	Sierra hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2011	GMC truck	Sierra hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T044
2011	GMC truck	Sierra hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2011	GMC truck	Yukon	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	GMC truck	Yukon	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Yukon	Amplifier (bose)	●	●	●	●	●	○	
2011	GMC truck	Yukon	Body control module (aux.)	●	●	●	●	●	●	T006
2011	GMC truck	Yukon	Personal audio link module	●	●	●	○	○	●	T036
2011	GMC truck	Yukon	Radio	●	●	●	●	●	○	
2011	GMC truck	Yukon	Rear HVAC/RSA	●	●	●	●	●	○	
2011	GMC truck	Yukon	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Yukon	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Yukon	Passenger presence system	●	●	●	●	○	○	
2011	GMC truck	Yukon	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2011	GMC truck	Yukon	Memory seat module	●	●	●	●	●	○	
2011	GMC truck	Yukon	Rear heated seat module	●	●	●	●	○	○	
2011	GMC truck	Yukon	Park assist module	●	●	●	●	○	○	
2011	GMC truck	Yukon	Left side object detection module	●	●	●	●	●	○	
2011	GMC truck	Yukon	Right side object detection module	●	●	●	●	○	○	
2011	GMC truck	Yukon	Assist step controller	●	●	●	●	●	●	T039
2011	GMC truck	Yukon	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Yukon	HVAC control module	●	●	●	●	●	●	T008 T034
2011	GMC truck	Yukon	Liftgate module	●	●	●	●	●	○	
2011	GMC truck	Yukon	Driver door switch	●	●	●	●	●	○	
2011	GMC truck	Yukon	Passenger door switch	●	●	●	●	●	○	
2011	GMC truck	Yukon	Body control module	●	●	●	●	●	●	T005
2011	GMC truck	Yukon	Electronic brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Yukon	Electronic suspension control	●	●	●	●	●	●	T040
2011	GMC truck	Yukon	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	GMC truck	Yukon	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Yukon	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Yukon	Fuel pump control module	●	●	●	●	●	●	T001
2011	GMC truck	Yukon	Transfer case control module	●	●	●	●	●	●	T001
2011	GMC truck	Yukon	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	GMC truck	Yukon	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Yukon	Amplifier (bose)	●	●	●	●	●	○	
2011	GMC truck	Yukon	Body control module (aux.)	●	●	●	●	●	●	T006

2011	GMC truck	Yukon	Personal audio link module	●	●	●	○	○	●	T036
2011	GMC truck	Yukon	Radio	●	●	●	●	●	○	
2011	GMC truck	Yukon	Rear HVAC/RSA	●	●	●	●	●	○	
2011	GMC truck	Yukon	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Yukon	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Yukon	Passenger presence system	●	●	●	●	○	○	
2011	GMC truck	Yukon	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	GMC truck	Yukon	Memory seat module	●	●	●	●	●	○	
2011	GMC truck	Yukon	Rear heated seat module	●	●	●	●	○	○	
2011	GMC truck	Yukon	Park assist module	●	●	●	●	○	○	
2011	GMC truck	Yukon	Left side object detection module	●	●	●	●	●	○	
2011	GMC truck	Yukon	Right side object detection module	●	●	●	●	○	○	
2011	GMC truck	Yukon	Assist step controller	●	●	●	●	●	●	T039
2011	GMC truck	Yukon	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Yukon	HVAC control module	●	●	●	●	●	●	T008 T034
2011	GMC truck	Yukon	Liftgate module	●	●	●	●	●	○	
2011	GMC truck	Yukon	Driver door switch	●	●	●	●	●	○	
2011	GMC truck	Yukon	Passenger door switch	●	●	●	●	●	○	
2011	GMC truck	Yukon	Body control module	●	●	●	●	●	●	T005
2011	GMC truck	Yukon	Electronic brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Yukon	Electronic suspension control	●	●	●	●	●	●	T040
2011	GMC truck	Yukon	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	GMC truck	Yukon	Transmission control module	●	●	○	●	●	○	

2011	GMC truck	Yukon	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Yukon	Fuel pump control module	●	●	●	●	●	●	T001
2011	GMC truck	Yukon	Transfer case control module	●	●	●	●	●	●	T001
2011	GMC truck	Yukon hybrid	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Yukon hybrid	Accessory power module	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Yukon hybrid	Fuel pump control module	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	GMC truck	Yukon hybrid	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Amplifier (bose)	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2011	GMC truck	Yukon hybrid	Personal audio link module	●	●	●	○	○	●	T036
2011	GMC truck	Yukon hybrid	Radio	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Yukon hybrid	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Passenger presence system	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	GMC truck	Yukon hybrid	Heated seat module	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Rear heated seat module	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Park assist module	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Left side object detection module	●	●	●	●	●	○	

2011	GMC truck	Yukon hybrid	Right side object detection module	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Assist step controller	●	●	●	●	●	●	T039
2011	GMC truck	Yukon hybrid	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2011	GMC truck	Yukon hybrid	Serial data gateway module	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Liftgate module	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Driver door switch	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Passenger door switch	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Body control module	●	●	●	●	●	●	T005
2011	GMC truck	Yukon hybrid	A/C compressor control module	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Power steering control module	●	●	○	●	○	●	T044
2011	GMC truck	Yukon hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2011	GMC truck	Yukon hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2011	GMC truck	Yukon hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T044
2011	GMC truck	Yukon hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2011	GMC truck	Yukon hybrid	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Yukon hybrid	Accessory power module	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Yukon hybrid	Fuel pump control module	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	GMC truck	Yukon hybrid	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Amplifier (bose)	●	●	●	●	●	○	

2011	GMC truck	Yukon hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2011	GMC truck	Yukon hybrid	Personal audio link module	●	●	●	○	○	●	T036
2011	GMC truck	Yukon hybrid	Radio	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Yukon hybrid	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Passenger presence system	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	GMC truck	Yukon hybrid	Heated seat module	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Rear heated seat module	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Park assist module	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Left side object detection module	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Right side object detection module	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Assist step controller	●	●	●	●	●	●	T039
2011	GMC truck	Yukon hybrid	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2011	GMC truck	Yukon hybrid	Serial data gateway module	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Liftgate module	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Driver door switch	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Passenger door switch	●	●	●	●	●	○	
2011	GMC truck	Yukon hybrid	Body control module	●	●	●	●	●	●	T005
2011	GMC truck	Yukon hybrid	A/C compressor control module	●	●	●	●	○	○	
2011	GMC truck	Yukon hybrid	Power steering control module	●	●	○	●	○	●	T044

2011	GMC truck	Yukon hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2011	GMC truck	Yukon hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2011	GMC truck	Yukon hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T044
2011	GMC truck	Yukon hybrid	Transfer case control module	●	●	●	●	●	●	T002 T003 T004
2011	GMC truck	Yukon XL	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Yukon XL	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Yukon XL	Fuel pump control module	●	●	●	●	●	●	T001
2011	GMC truck	Yukon XL	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	GMC truck	Yukon XL	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Amplifier (bose)	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Body control module (aux.)	●	●	●	●	●	●	T006
2011	GMC truck	Yukon XL	Personal audio link module	●	●	●	○	○	●	T036
2011	GMC truck	Yukon XL	Radio	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Rear HVAC/RSA	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Yukon XL	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Yukon XL	Passenger presence system	●	●	●	●	○	○	
2011	GMC truck	Yukon XL	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	GMC truck	Yukon XL	Memory seat module	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Rear heated seat module	●	●	●	●	○	○	
2011	GMC truck	Yukon XL	Park assist module	●	●	●	●	○	○	

2011	GMC truck	Yukon XL	Left side object detection module	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Right side object detection module	●	●	●	●	○	○	
2011	GMC truck	Yukon XL	Assist step controller	●	●	●	●	●	●	T039
2011	GMC truck	Yukon XL	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	HVAC control module	●	●	●	●	●	●	T008 T034
2011	GMC truck	Yukon XL	Liftgate module	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Driver door switch	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Passenger door switch	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Body control module	●	●	●	●	●	●	T005
2011	GMC truck	Yukon XL	Electronic brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Yukon XL	Electronic suspension control	●	●	●	●	●	●	T040
2011	GMC truck	Yukon XL	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	GMC truck	Yukon XL	Trailer brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Yukon XL	Transfer case control module	●	●	●	●	●	●	T001
2011	GMC truck	Yukon XL	Transmission control module	●	●	○	●	●	○	
2011	GMC truck	Yukon XL	Engine control module	●	●	●	●	●	●	T001
2011	GMC truck	Yukon XL	Fuel pump control module	●	●	●	●	●	●	T001
2011	GMC truck	Yukon XL	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2011	GMC truck	Yukon XL	Digital radio receiver	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Amplifier (bose)	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Body control module (aux.)	●	●	●	●	●	●	T006
2011	GMC truck	Yukon XL	Personal audio link module	●	●	●	○	○	●	T036

2011	GMC truck	Yukon XL	Radio	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Rear HVAC/RSA	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2011	GMC truck	Yukon XL	Theft deterrent module	●	●	●	●	○	○	
2011	GMC truck	Yukon XL	Passenger presence system	●	●	●	●	○	○	
2011	GMC truck	Yukon XL	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2011	GMC truck	Yukon XL	Memory seat module	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Rear heated seat module	●	●	●	●	○	○	
2011	GMC truck	Yukon XL	Park assist module	●	●	●	●	○	○	
2011	GMC truck	Yukon XL	Left side object detection module	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Right side object detection module	●	●	●	●	○	○	
2011	GMC truck	Yukon XL	Assist step controller	●	●	●	●	●	●	T039
2011	GMC truck	Yukon XL	Instrument panel cluster	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	HVAC control module	●	●	●	●	●	●	T008 T034
2011	GMC truck	Yukon XL	Liftgate module	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Driver door switch	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Passenger door switch	●	●	●	●	●	○	
2011	GMC truck	Yukon XL	Body control module	●	●	●	●	●	●	T005
2011	GMC truck	Yukon XL	Electronic brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Yukon XL	Electronic suspension control	●	●	●	●	●	●	T040
2011	GMC truck	Yukon XL	FPCM with trailer brake control	●	●	●	●	●	●	T014
2011	GMC truck	Yukon XL	Trailer brake control module	●	●	●	●	●	●	T014
2011	GMC truck	Yukon XL	Transfer case control module	●	●	●	●	●	●	T001

2010	Buick	Allure	Engine Control Module	●	●	●	●	●	●	S044 S029 S025 S030
2010	Buick	Allure	Fuel Injector Control Module	●	●	●	●	●	○	
2010	Buick	Allure	Fuel Pump Control Module	●	●	●	●	●	●	S025
2010	Buick	Allure	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2010	Buick	Allure	Transmission Control Module	●	●	●	●	●	●	S048
2010	Buick	Allure	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2010	Buick	Allure	Drive Motor Control Module	●	●	●	●	○	○	
2010	Buick	Allure	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2010	Buick	Allure	Parking Brake Control Module	●	●	●	●	●	●	S037
2010	Buick	Allure	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2010	Buick	Allure	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2010	Buick	Allure	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2010	Buick	Allure	Suspension Control Module	●	●	●	●	●	○	
2010	Buick	Allure	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021
2010	Buick	Allure	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2010	Buick	Allure	Passenger Presence Module	●	●	●	●	○	●	S043
2010	Buick	Allure	Instrument Cluster	●	●	●	●	●	●	S022

2010	Buick	Allure	Head-Up Display Module	●	●	●	●	●	○	
2010	Buick	Allure	Headlamp Control Module	●	●	●	●	●	●	
2010	Buick	Allure	Radio	●	●	●	●	●	○	
2010	Buick	Allure	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022 S022
2010	Buick	Allure	Multimedia Player Interface Module	●	●	●	●	○	●	
2010	Buick	Allure	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2010	Buick	Allure	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2010	Buick	Allure	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2010	Buick	Allure	Seat Memory Control Module	●	●	●	●	●	●	S031
2010	Buick	Allure	Front Seat Heating Control Module	●	●	●	●	●	○	
2010	Buick	Allure	Rear Seat Heating Control Module	●	●	●	●	●	○	
2010	Buick	Allure	Keyless Entry Control Module	●	●	●	●	●	○	
2010	Buick	Allure	Parking Assist Control Module	●	●	●	●	●	●	S022
2010	Buick	Allure	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168
2010	Buick	Allure	Steering Column Lock Control Module	●	●	●	●	○	●	
2010	Buick	Allure	Battery Energy Control Module	○	○	●	●	○	○	

2010	Buick	Allure	Left Side Object Detection Control Module	●	●	●	●	●	○	
2010	Buick	Allure	Right Side Object Detection Control Module	●	●	●	●	●	○	
2010	Buick	LaCrosse	Engine Control Module	●	●	●	●	●	●	S044 S029 S025 S030
2010	Buick	LaCrosse	Fuel Injector Control Module	●	●	●	●	●	○	
2010	Buick	LaCrosse	Fuel Pump Control Module	●	●	●	●	●	●	S025
2010	Buick	LaCrosse	Hybrid Powertrain Control Module	●	●	●	●	●	●	S001
2010	Buick	LaCrosse	Transmission Control Module	●	●	●	●	●	●	S048
2010	Buick	LaCrosse	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2010	Buick	LaCrosse	Drive Motor Control Module	●	●	●	●	○	○	
2010	Buick	LaCrosse	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2010	Buick	LaCrosse	Parking Brake Control Module	●	●	●	●	●	●	S037
2010	Buick	LaCrosse	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2010	Buick	LaCrosse	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2010	Buick	LaCrosse	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2010	Buick	LaCrosse	Suspension Control Module	●	●	●	●	●	○	
2010	Buick	LaCrosse	Body Control Module	●	●	●	●	●	●	S013 S001 S014 S015 S016 S017 S018 S019 S021

2010	Buick	LaCrosse	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2010	Buick	LaCrosse	Passenger Presence Module	●	●	●	●	○	●	S043
2010	Buick	LaCrosse	Instrument Cluster	●	●	●	●	●	●	S022
2010	Buick	LaCrosse	Head-Up Display Module	●	●	●	●	●	○	
2010	Buick	LaCrosse	Headlamp Control Module	●	●	●	●	●	●	
2010	Buick	LaCrosse	Radio	●	●	●	●	●	○	
2010	Buick	LaCrosse	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022 S022
2010	Buick	LaCrosse	Multimedia Player Interface Module	●	●	●	●	○	●	
2010	Buick	LaCrosse	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2010	Buick	LaCrosse	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2010	Buick	LaCrosse	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2010	Buick	LaCrosse	Seat Memory Control Module	●	●	●	●	●	●	S031
2010	Buick	LaCrosse	Front Seat Heating Control Module	●	●	●	●	●	○	
2010	Buick	LaCrosse	Rear Seat Heating Control Module	●	●	●	●	●	○	
2010	Buick	LaCrosse	Keyless Entry Control Module	●	●	●	●	●	○	
2010	Buick	LaCrosse	Parking Assist Control Module	●	●	●	●	●	●	S022
2010	Buick	LaCrosse	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168

2010	Buick	LaCrosse	Steering Column Lock Control Module	●	●	●	●	○	●	
2010	Buick	LaCrosse	Battery Energy Control Module	○	○	●	●	○	○	
2010	Buick	LaCrosse	Left Side Object Detection Control Module	●	●	●	●	●	○	
2010	Buick	LaCrosse	Right Side Object Detection Control Module	●	●	●	●	●	○	
2010	Cadillac	SRX	Engine Control Module	●	●	●	●	●	●	S028 S029 S025 S030
2010	Cadillac	SRX	Fuel Pump Control Module	●	●	●	●	●	●	S025
2010	Cadillac	SRX	Transmission Control Module	●	●	●	●	●	●	S057 S082
2010	Cadillac	SRX	Rear Differential Clutch Control Module	●	●	●	●	●	○	
2010	Cadillac	SRX	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2010	Cadillac	SRX	Parking Brake Control Module	●	●	●	●	●	●	S037
2010	Cadillac	SRX	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2010	Cadillac	SRX	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2010	Cadillac	SRX	Suspension Control Module	●	●	●	●	●	○	
2010	Cadillac	SRX	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2010	Cadillac	SRX	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2010	Cadillac	SRX	Passenger Presence Module	●	●	●	●	○	●	S043

2010	Cadillac	SRX	Instrument Cluster	●	●	●	●	●	●	S022
2010	Cadillac	SRX	Headlamp Control Module	●	●	●	●	●	●	
2010	Cadillac	SRX	Trailer Interface Control Module	●	●	●	●	●	●	S022
2010	Cadillac	SRX	Radio	●	●	●	●	●	○	
2010	Cadillac	SRX	Rear Audio Control Module	●	●	●	●	●	○	
2010	Cadillac	SRX	Digital Radio Receiver Control Module	●	●	●	●	●	●	S022 S022
2010	Cadillac	SRX	Multimedia Player Interface Module	●	●	●	●	○	●	
2010	Cadillac	SRX	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2010	Cadillac	SRX	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2010	Cadillac	SRX	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2010	Cadillac	SRX	Liftgate Control Module	●	●	●	●	●	●	S049
2010	Cadillac	SRX	Seat Memory Control Module	●	●	●	●	●	●	S031
2010	Cadillac	SRX	Front Seat Heating Control Module	●	●	●	●	●	○	
2010	Cadillac	SRX	Rear Seat Heating Control Module	●	●	●	●	●	○	
2010	Cadillac	SRX	Keyless Entry Control Module	●	●	●	●	●	○	
2010	Cadillac	SRX	Parking Assist Control Module	●	●	●	●	●	●	S022
2010	Cadillac	SRX	Steering Column Lock Control Module	●	●	●	●	○	●	

2010	Chevrolet	Beat	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S104 S106 S106 S109 S110 S111 S111 S045 S045 S105 S105 S108 S108 S103 S103 S112 S112 S107 S107 S113 S029 S114 S114 S115 S115 S116 S117 S118 S118
2010	Chevrolet	Beat	Fuel Injector Control Module	●	●	●	●	●	○	
2010	Chevrolet	Beat	Transmission Control Module	●	●	●	●	●	○	
2010	Chevrolet	Beat	Electronic Brake Control Module	●	●	●	●	●	●	S035
2010	Chevrolet	Beat	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2010	Chevrolet	Beat	Electric Power Steering Control Module	●	●	●	●	○	●	
2010	Chevrolet	Beat	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2010	Chevrolet	Beat	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2010	Chevrolet	Beat	Passenger Presence Module	●	●	●	●	●	●	S043
2010	Chevrolet	Beat	Instrument Cluster	●	●	●	●	●	○	
2010	Chevrolet	Camaro	Engine Control Module	●	●	●	●	●	●	S044 S029 S025 S030
2010	Chevrolet	Camaro	Fuel Pump Control Module	●	●	●	●	●	●	S025
2010	Chevrolet	Camaro	Transmission Control Module	●	●	●	●	●	●	S048
2010	Chevrolet	Camaro	Electronic Brake Control Module	●	●	●	●	●	●	S035 S034

2010	Chevrolet	Camaro	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2010	Chevrolet	Camaro	Power Steering Control Module	●	●	●	●	○	●	
2010	Chevrolet	Camaro	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2010	Chevrolet	Camaro	Suspension Control Module	●	●	●	●	●	●	
2010	Chevrolet	Camaro	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2010	Chevrolet	Camaro	Auxiliary Gage Module	●	●	●	●	●	○	
2010	Chevrolet	Camaro	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024
2010	Chevrolet	Camaro	Passenger Presence Module	●	●	●	●	○	●	S043
2010	Chevrolet	Camaro	Instrument Cluster	●	●	●	●	●	●	S022
2010	Chevrolet	Camaro	Head-Up Display Module	●	●	●	●	●	○	
2010	Chevrolet	Camaro	Headlamp Control Module	●	●	●	●	●	●	S002
2010	Chevrolet	Camaro	Radio	●	●	●	●	●	○	
2010	Chevrolet	Camaro	Multimedia Player Interface Module	●	●	●	●	○	●	
2010	Chevrolet	Camaro	Telematic Vehicle Localization and Immobilization Control Module	●	●	●	●	●	○	
2010	Chevrolet	Camaro	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2010	Chevrolet	Camaro	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039

2010	Chevrolet	Camaro	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2010	Chevrolet	Camaro	Front Seat Heating Control Module	●	●	●	●	●	○	
2010	Chevrolet	Camaro	Folding Top Control Module	●	●	●	●	●	○	
2010	Chevrolet	Camaro	Parking Assist Control Module	●	●	●	●	●	●	
2010	Chevrolet	Cruze	Engine Control Module	●	●	●	●	●	●	S029 S025
2010	Chevrolet	Cruze	Fuel Pump Control Module	●	●	●	●	●	●	S025
2010	Chevrolet	Cruze	Transmission Control Module	●	●	●	●	●	●	S023
2010	Chevrolet	Cruze	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2010	Chevrolet	Cruze	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2010	Chevrolet	Cruze	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2010	Chevrolet	Cruze	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2010	Chevrolet	Cruze	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2010	Chevrolet	Cruze	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2010	Chevrolet	Cruze	Passenger Presence Module	●	●	●	●	○	●	S043
2010	Chevrolet	Cruze	Instrument Cluster	●	●	●	●	●	●	S022
2010	Chevrolet	Cruze	Trailer Interface Control Module	●	●	●	●	●	●	S022
2010	Chevrolet	Cruze	Radio	●	●	●	●	●	○	

2010	Chevrolet	Cruze	Multimedia Player Interface Module	●	●	●	●	○	●	
2010	Chevrolet	Cruze	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2010	Chevrolet	Cruze	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2010	Chevrolet	Cruze	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2010	Chevrolet	Cruze	Front Seat Heating Control Module	●	●	●	●	●	○	
2010	Chevrolet	Cruze	Keyless Entry Control Module	●	●	●	●	●	○	
2010	Chevrolet	Cruze	Parking Assist Control Module	●	●	●	●	●	●	
2010	Chevrolet	Cruze	Steering Column Lock Control Module	●	●	●	●	○	●	
2010	Chevrolet	Equinox	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2010	Chevrolet	Equinox	Fuel Pump Control Module	●	●	●	●	●	●	S025
2010	Chevrolet	Equinox	Transmission Control Module	●	●	●	●	●	●	S048
2010	Chevrolet	Equinox	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2010	Chevrolet	Equinox	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2010	Chevrolet	Equinox	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2010	Chevrolet	Equinox	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075

2010	Chevrolet	Equinox	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2010	Chevrolet	Equinox	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2010	Chevrolet	Equinox	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2010	Chevrolet	Equinox	Passenger Presence Module	●	●	●	●	○	●	S043
2010	Chevrolet	Equinox	Instrument Cluster	●	●	●	●	●	●	S022
2010	Chevrolet	Equinox	Radio	●	●	●	●	●	○	
2010	Chevrolet	Equinox	Multimedia Player Interface Module	●	●	●	●	○	●	
2010	Chevrolet	Equinox	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2010	Chevrolet	Equinox	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2010	Chevrolet	Equinox	Liftgate Control Module	●	●	●	●	●	●	S049
2010	Chevrolet	Equinox	Seat Memory Control Module	●	●	●	●	●	●	S031
2010	Chevrolet	Equinox	Front Seat Heating Control Module	●	●	●	●	●	○	
2010	Chevrolet	Equinox	Parking Assist Control Module	●	●	●	●	●	●	S022
2010	Chevrolet	Equinox	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168
2010	Chevrolet	Equinox	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2010	Chevrolet	Sail	Engine Control Module	●	●	●	●	●	○	
2010	Chevrolet	Sail	Transmission Control Module	●	●	●	●	●	●	S200 S201 S202 S203 S204

2010	Chevrolet	Sail	Electronic Brake Control Module	●	●	●	●	●	○	
2010	Chevrolet	Sail	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	○	●	S194 S195 S196 S197 S198 S194 S195 S196 S197 S024 S199
2010	Chevrolet	Sail	Keyless Entry Control Module	○	○	○	●	○	●	
2010	Chevrolet	Spark	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S104 S106 S106 S109 S110 S111 S111 S045 S045 S105 S105 S108 S108 S103 S103 S112 S112 S107 S107 S113 S029 S114 S114 S115 S115 S116 S117 S118 S118
2010	Chevrolet	Spark	Fuel Injector Control Module	●	●	●	●	●	○	
2010	Chevrolet	Spark	Transmission Control Module	●	●	●	●	●	○	
2010	Chevrolet	Spark	Electronic Brake Control Module	●	●	●	●	●	●	S035
2010	Chevrolet	Spark	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2010	Chevrolet	Spark	Electric Power Steering Control Module	●	●	●	●	○	●	
2010	Chevrolet	Spark	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2010	Chevrolet	Spark	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2010	Chevrolet	Spark	Passenger Presence Module	●	●	●	●	●	●	S043
2010	Chevrolet	Spark	Instrument Cluster	●	●	●	●	●	○	

2010	Daewoo	Lacetti	Engine Control Module	●	●	●	●	●	●	S029 S025
2010	Daewoo	Lacetti	Fuel Pump Control Module	●	●	●	●	●	●	S025
2010	Daewoo	Lacetti	Transmission Control Module	●	●	●	●	●	●	S023
2010	Daewoo	Lacetti	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2010	Daewoo	Lacetti	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2010	Daewoo	Lacetti	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2010	Daewoo	Lacetti	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2010	Daewoo	Lacetti	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2010	Daewoo	Lacetti	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2010	Daewoo	Lacetti	Passenger Presence Module	●	●	●	●	○	●	S043
2010	Daewoo	Lacetti	Instrument Cluster	●	●	●	●	●	●	S022
2010	Daewoo	Lacetti	Trailer Interface Control Module	●	●	●	●	●	●	S022
2010	Daewoo	Lacetti	Radio	●	●	●	●	●	○	
2010	Daewoo	Lacetti	Multimedia Player Interface Module	●	●	●	●	○	●	
2010	Daewoo	Lacetti	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2010	Daewoo	Lacetti	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039

2010	Daewoo	Lacetti	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2010	Daewoo	Lacetti	Front Seat Heating Control Module	●	●	●	●	●	○	
2010	Daewoo	Lacetti	Keyless Entry Control Module	●	●	●	●	●	○	
2010	Daewoo	Lacetti	Parking Assist Control Module	●	●	●	●	●	●	
2010	Daewoo	Lacetti	Steering Column Lock Control Module	●	●	●	●	○	●	
2010	Daewoo	Matiz	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S104 S106 S106 S109 S110 S111 S111 S045 S045 S105 S105 S108 S108 S103 S103 S112 S112 S107 S107 S113 S029 S114 S114 S115 S115 S116 S117 S118 S118
2010	Daewoo	Matiz	Fuel Injector Control Module	●	●	●	●	●	○	
2010	Daewoo	Matiz	Transmission Control Module	●	●	●	●	●	○	
2010	Daewoo	Matiz	Electronic Brake Control Module	●	●	●	●	●	●	S035
2010	Daewoo	Matiz	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2010	Daewoo	Matiz	Electric Power Steering Control Module	●	●	●	●	○	●	
2010	Daewoo	Matiz	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035

2010	Daewoo	Matiz	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2010	Daewoo	Matiz	Passenger Presence Module	●	●	●	●	●	●	S043
2010	Daewoo	Matiz	Instrument Cluster	●	●	●	●	●	○	
2010	GMC	Terrain	Engine Control Module	●	●	●	●	●	●	S001 S044 S026 S027 S028 S029 S025 S030
2010	GMC	Terrain	Fuel Pump Control Module	●	●	●	●	●	●	S025
2010	GMC	Terrain	Transmission Control Module	●	●	●	●	●	●	S048
2010	GMC	Terrain	Rear Differential Clutch Control Module	●	●	●	●	●	●	S055
2010	GMC	Terrain	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2010	GMC	Terrain	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2010	GMC	Terrain	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2010	GMC	Terrain	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2010	GMC	Terrain	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2010	GMC	Terrain	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2010	GMC	Terrain	Passenger Presence Module	●	●	●	●	○	●	S043
2010	GMC	Terrain	Instrument Cluster	●	●	●	●	●	●	S022
2010	GMC	Terrain	Radio	●	●	●	●	●	○	
2010	GMC	Terrain	Multimedia Player Interface Module	●	●	●	●	○	●	

2010	GMC	Terrain	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2010	GMC	Terrain	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2010	GMC	Terrain	Liftgate Control Module	●	●	●	●	●	●	S049
2010	GMC	Terrain	Seat Memory Control Module	●	●	●	●	●	●	S031
2010	GMC	Terrain	Front Seat Heating Control Module	●	●	●	●	●	○	
2010	GMC	Terrain	Parking Assist Control Module	●	●	●	●	●	●	S022
2010	GMC	Terrain	Vehicle Direction Camera Control Module	●	●	●	●	●	●	S050 S168
2010	GMC	Terrain	Frontview Camera Module	●	●	●	●	●	●	S050 S051
2010	Holden	Barina Spark	Engine Control Module	●	●	●	●	●	●	S102 S102 S044 S104 S106 S106 S109 S110 S111 S111 S045 S045 S105 S105 S108 S108 S103 S103 S112 S112 S107 S107 S113 S029 S114 S114 S115 S115 S116 S117 S118 S118
2010	Holden	Barina Spark	Fuel Injector Control Module	●	●	●	●	●	○	
2010	Holden	Barina Spark	Transmission Control Module	●	●	●	●	●	○	
2010	Holden	Barina Spark	Electronic Brake Control Module	●	●	●	●	●	●	S035

2010	Holden	Barina Spark	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2010	Holden	Barina Spark	Electric Power Steering Control Module	●	●	●	●	○	●	
2010	Holden	Barina Spark	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2010	Holden	Barina Spark	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	
2010	Holden	Barina Spark	Passenger Presence Module	●	●	●	●	●	●	S043
2010	Holden	Barina Spark	Instrument Cluster	●	●	●	●	●	○	
2010	Holden	Cruze	Engine Control Module	●	●	●	●	●	●	S029 S025
2010	Holden	Cruze	Fuel Pump Control Module	●	●	●	●	●	●	S025
2010	Holden	Cruze	Transmission Control Module	●	●	●	●	●	●	S023
2010	Holden	Cruze	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2010	Holden	Cruze	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2010	Holden	Cruze	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2010	Holden	Cruze	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2010	Holden	Cruze	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2010	Holden	Cruze	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2010	Holden	Cruze	Passenger Presence Module	●	●	●	●	○	●	S043

2010	Holden	Cruze	Instrument Cluster	●	●	●	●	●	●	S022
2010	Holden	Cruze	Trailer Interface Control Module	●	●	●	●	●	●	S022
2010	Holden	Cruze	Radio	●	●	●	●	●	○	
2010	Holden	Cruze	Multimedia Player Interface Module	●	●	●	●	○	●	
2010	Holden	Cruze	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022
2010	Holden	Cruze	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2010	Holden	Cruze	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2010	Holden	Cruze	Front Seat Heating Control Module	●	●	●	●	●	○	
2010	Holden	Cruze	Keyless Entry Control Module	●	●	●	●	●	○	
2010	Holden	Cruze	Parking Assist Control Module	●	●	●	●	●	●	
2010	Holden	Cruze	Steering Column Lock Control Module	●	●	●	●	○	●	
2010	Buick	Lucerne	Transmission control module	●	●	○	●	●	○	
2010	Buick	Lucerne	Engine control module	●	●	●	●	●	●	T001
2010	Buick	Lucerne	Digital radio receiver	●	●	●	●	●	○	
2010	Buick	Lucerne	Radio	●	●	●	●	●	○	
2010	Buick	Lucerne	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Buick	Lucerne	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Buick	Lucerne	Veh direction alert alarm warn mod	●	●	●	●	●	○	

2010	Buick	Lucerne	Passenger presence system	●	●	●	●	○	●	T020
2010	Buick	Lucerne	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Buick	Lucerne	Left side object detection module	●	●	●	●	●	○	
2010	Buick	Lucerne	Memory seat module	●	●	●	●	●	○	
2010	Buick	Lucerne	Park assist module	●	●	●	●	●	○	
2010	Buick	Lucerne	Right side object detection module	●	●	●	●	○	○	
2010	Buick	Lucerne	Theft deterrent module	●	●	●	●	○	○	
2010	Buick	Lucerne	Instrument panel cluster	●	●	●	●	●	○	
2010	Buick	Lucerne	HVAC control module	●	●	●	●	●	○	
2010	Buick	Lucerne	Driver door switch	●	●	●	●	●	○	
2010	Buick	Lucerne	Passenger door switch	●	●	●	●	●	○	
2010	Buick	Lucerne	Body control module	●	●	●	●	●	●	T007 T005
2010	Buick	Lucerne	Electronic brake control module	●	●	●	●	●	●	T014
2010	Buick	Lucerne	Electronic suspension control	●	●	●	●	●	○	
2010	Cadillac	CTS	Transmission control module	●	●	○	●	●	○	
2010	Cadillac	CTS	Fuel pump control module	●	●	●	●	●	○	
2010	Cadillac	CTS	Engine control module	●	●	●	●	●	●	T001
2010	Cadillac	CTS	Transfer case control module	●	●	●	●	●	●	T001
2010	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	●	T010
2010	Cadillac	CTS	Radio	●	●	●	●	●	●	T011
2010	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Cadillac	CTS	TV antenna module	●	●	●	●	○	●	T012 T013
2010	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	

2010	Cadillac	CTS	Headlamp control module	●	●	●	●	●	○	
2010	Cadillac	CTS	Pedestrian impact detection module	●	●	●	●	●	●	T009
2010	Cadillac	CTS	Passenger presence system	●	●	●	●	●	○	
2010	Cadillac	CTS	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2010	Cadillac	CTS	HVAC control module	●	●	●	●	●	●	T008
2010	Cadillac	CTS	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Cadillac	CTS	Driver door switch	●	●	●	●	●	○	
2010	Cadillac	CTS	Passenger door switch	●	●	●	●	●	○	
2010	Cadillac	CTS	Liftgate module	●	●	●	●	●	○	
2010	Cadillac	CTS	Body control module	●	●	●	●	●	●	T007 T005
2010	Cadillac	CTS	Park assist module	●	●	●	●	●	●	T010
2010	Cadillac	CTS	Parking brake control module	●	●	●	●	●	○	
2010	Cadillac	CTS	Electronic brake control module	●	●	●	●	●	●	T014
2010	Cadillac	CTS	Electronic suspension control	●	●	○	●	●	○	
2010	Cadillac	DTS	Engine control module	●	●	●	●	●	●	T001
2010	Cadillac	DTS	Transmission control module	●	●	○	●	●	○	
2010	Cadillac	DTS	Amplifier (bose)	●	●	●	●	●	○	
2010	Cadillac	DTS	Digital radio receiver	●	●	●	●	●	○	
2010	Cadillac	DTS	Radio	●	●	●	●	●	○	
2010	Cadillac	DTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Cadillac	DTS	TV antenna module	●	●	●	●	○	●	T012 T013
2010	Cadillac	DTS	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2010	Cadillac	DTS	Veh direction alert alarm warn mod	●	●	●	●	●	○	
2010	Cadillac	DTS	Passenger presence system	●	●	●	●	○	●	T020
2010	Cadillac	DTS	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Cadillac	DTS	Distance sensing cruise control	●	●	●	●	●	○	
2010	Cadillac	DTS	Driver position module	●	●	●	●	●	○	
2010	Cadillac	DTS	Inside rear view mirror module	●	●	●	○	○	○	
2010	Cadillac	DTS	Left side object detection module	●	●	●	●	●	○	
2010	Cadillac	DTS	Rear heated seat module	●	●	●	●	○	○	
2010	Cadillac	DTS	Right side object detection module	●	●	●	●	○	○	
2010	Cadillac	DTS	Park assist module	●	●	●	●	●	○	
2010	Cadillac	DTS	Theft deterrent module	●	●	●	●	○	○	
2010	Cadillac	DTS	Instrument panel cluster	●	●	●	●	●	○	
2010	Cadillac	DTS	HVAC control module	●	●	●	●	●	○	
2010	Cadillac	DTS	Driver door switch	●	●	●	●	●	●	T035
2010	Cadillac	DTS	Passenger door switch	●	●	●	●	●	●	T035
2010	Cadillac	DTS	Body control module	●	●	●	●	●	●	T007 T005
2010	Cadillac	DTS	Electronic brake control module	●	●	●	●	●	●	T014
2010	Cadillac	DTS	Electronic suspension control	●	●	●	●	●	○	
2010	Cadillac	STS	Engine control module	●	●	●	●	●	●	T001
2010	Cadillac	STS	Transmission control module	●	●	●	●	●	○	
2010	Cadillac	STS	Amplifier (bose)	●	●	○	●	●	○	
2010	Cadillac	STS	Digital radio receiver	●	●	●	●	●	●	T024
2010	Cadillac	STS	Radio	●	●	●	●	○	●	T060 T033

2010	Cadillac	STS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Cadillac	STS	TV antenna module	●	●	●	●	○	○	
2010	Cadillac	STS	Remote control door lock receiver	●	●	●	●	●	●	T021 T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T022
2010	Cadillac	STS	Veh direction alert alarm warn mod	●	●	●	●	●	○	
2010	Cadillac	STS	Passenger presence system	●	●	○	○	○	○	
2010	Cadillac	STS	Supplemental inflatable restraint	●	●	●	●	●	●	T067
2010	Cadillac	STS	Head up display	●	●	●	●	●	○	
2010	Cadillac	STS	Headlamp control module	●	●	●	●	●	○	
2010	Cadillac	STS	Driver position module	●	●	●	●	●	○	
2010	Cadillac	STS	Left side object detection module	●	●	●	●	●	○	
2010	Cadillac	STS	Right side object detection module	●	●	●	●	○	○	
2010	Cadillac	STS	Instrument panel cluster	●	●	●	●	●	●	T061 T062
2010	Cadillac	STS	Driver door module	●	●	●	●	●	●	T068
2010	Cadillac	STS	Driver door switch	●	●	●	●	○	○	
2010	Cadillac	STS	Instrument panel module	●	●	●	●	●	●	T059
2010	Cadillac	STS	Left rear door module	●	●	●	●	●	●	T068
2010	Cadillac	STS	Passenger door module	●	●	●	●	●	●	T068
2010	Cadillac	STS	Right rear door module	●	●	●	●	●	●	T068
2010	Cadillac	STS	Rear integration module	●	●	●	●	●	○	
2010	Cadillac	STS	Distance sensing cruise control	●	●	●	●	●	○	
2010	Cadillac	STS	HVAC control module	●	●	●	●	●	○	

2010	Cadillac	STS	Steering column lock module	●	●	●	●	●	●	T024
2010	Cadillac	STS	Navigation radio	●	●	●	●	●	●	T069
2010	Cadillac	STS	Electronic brake control module	●	●	●	●	●	●	T014
2010	Cadillac	STS	Electronic suspension control	●	●	●	●	●	○	
2010	Cadillac	STS	Power steering control module	●	●	○	●	○	●	T071 T072
2010	Cadillac	STS	Vehicle stability control module	●	●	●	●	●	●	T014
2010	Chevrolet	Aveo	Engine control module	●	●	●	●	●	●	T015
2010	Chevrolet	Aveo	Transmission control module	●	●	●	●	●	●	T001
2010	Chevrolet	Aveo	Supplemental inflatable restraint	●	●	●	●	●	○	
2010	Chevrolet	Aveo	Immobilizer	●	●	●	●	●	●	T016
2010	Chevrolet	Aveo	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Aveo	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2010	Chevrolet	Aveo	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Aveo	Transmission control module	●	●	●	●	●	●	T001
2010	Chevrolet	Aveo	Supplemental inflatable restraint	●	●	●	●	●	○	
2010	Chevrolet	Aveo	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Aveo	Immobilizer	●	●	●	●	●	●	T016
2010	Chevrolet	Aveo	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Aveo	Radio	●	●	●	○	○	○	
2010	Chevrolet	Aveo	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Aveo	Passenger presence system	●	●	●	●	●	●	T045

2010	Chevrolet	Aveo	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Aveo	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2010	Chevrolet	Cobalt	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Cobalt	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Cobalt	Body control module	●	●	●	●	●	●	T023
2010	Chevrolet	Cobalt	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Cobalt	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Cobalt	Radio	●	●	●	●	●	○	
2010	Chevrolet	Cobalt	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Cobalt	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Cobalt	Passenger presence system	●	●	○	○	○	○	
2010	Chevrolet	Cobalt	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Chevrolet	Cobalt	Driver information center	●	●	●	●	●	○	
2010	Chevrolet	Cobalt	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Chevrolet	Cobalt	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Cobalt	Electronic brake control module	●	●	●	●	●	○	
2010	Chevrolet	Cobalt	Power steering control module	●	●	●	●	●	○	
2010	Chevrolet	Chevy	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Chevy	Transmission control module	●	●	●	●	●	●	T001
2010	Chevrolet	Chevy	Immobilizer	●	●	●	●	○	●	T052 T053
2010	Chevrolet	Corvette	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Corvette	Engine control module	●	●	●	●	●	●	T001

2010	Chevrolet	Corvette	Exhaust flow control module	●	●	●	●	●	●	T001
2010	Chevrolet	Corvette	Fuel pump control module	●	●	●	●	●	○	
2010	Chevrolet	Corvette	CD changer	●	●	●	●	○	○	
2010	Chevrolet	Corvette	Digital radio receiver	●	●	●	●	○	●	T024
2010	Chevrolet	Corvette	Radio	●	●	●	●	○	●	T032 T033
2010	Chevrolet	Corvette	Vehicle comm. interface module	●	●	●	●	●	●	T002 T073 T003
2010	Chevrolet	Corvette	Remote control door lock receiver	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2010	Chevrolet	Corvette	Head up display	●	●	●	●	●	○	
2010	Chevrolet	Corvette	Passenger presence system	●	●	○	○	○	●	T020
2010	Chevrolet	Corvette	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Chevrolet	Corvette	Steering column lock module	●	●	●	●	●	○	
2010	Chevrolet	Corvette	Driver position module	●	●	●	●	●	●	T030
2010	Chevrolet	Corvette	Folding top module	●	●	●	●	●	○	
2010	Chevrolet	Corvette	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Corvette	HVAC control module	●	●	●	●	●	●	T008 T031
2010	Chevrolet	Corvette	Body control module	●	●	●	●	●	●	T023
2010	Chevrolet	Corvette	Driver door module	●	●	●	●	●	○	
2010	Chevrolet	Corvette	Driver door switch	●	●	●	●	○	○	
2010	Chevrolet	Corvette	Passenger door module	●	●	●	●	●	●	T024
2010	Chevrolet	Corvette	Navigation radio	●	●	●	●	○	●	T033
2010	Chevrolet	Corvette	Personal audio link module	●	●	●	●	●	●	T036
2010	Chevrolet	Corvette	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Corvette	Electronic suspension control	●	●	●	●	●	○	

2010	Chevrolet	Epica	Engine control module	●	●	●	●	●	●	T017
2010	Chevrolet	Epica	Transmission control module	●	●	●	●	●	●	T017
2010	Chevrolet	Epica	Supplemental inflatable restraint	●	●	●	●	●	○	
2010	Chevrolet	Epica	ISU	●	●	●	●	●	○	
2010	Chevrolet	Epica	Electronic brake control module	●	●	●	●	●	●	T017
2010	Chevrolet	Impala	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Impala	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Impala	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Impala	Radio	●	●	●	●	●	○	
2010	Chevrolet	Impala	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Impala	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Impala	Passenger presence system	●	●	●	●	●	○	
2010	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Impala	Heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Impala	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Impala	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Impala	Body control module	●	●	●	●	●	●	T007 T005
2010	Chevrolet	Impala	HVAC control module	●	●	●	●	●	●	T008
2010	Chevrolet	Impala	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Malibu	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Malibu	Transmission control module	●	●	●	●	●	●	T001
2010	Chevrolet	Malibu	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Malibu	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003

2010	Chevrolet	Malibu	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Malibu	Radio	●	●	●	●	●	●	T033
2010	Chevrolet	Malibu	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Malibu	Passenger presence system	●	●	○	○	○	○	
2010	Chevrolet	Malibu	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Chevrolet	Malibu	Body control module	●	●	●	●	●	●	T008 T023 T056
2010	Chevrolet	Malibu	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Malibu	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Malibu	HVAC control module	●	●	●	●	●	●	T055
2010	Chevrolet	Malibu	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Malibu	Power steering control module	●	●	●	●	●	●	T014
2010	Chevrolet	Malibu hybrid	Starter/generator control module	○	○	○	●	●	○	
2010	Chevrolet	Malibu hybrid	Battery energy control module	○	○	○	●	●	○	
2010	Chevrolet	Malibu hybrid	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Malibu hybrid	Engine control module	●	●	●	●	●	●	T074 T075 T001
2010	Chevrolet	Malibu hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Malibu hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Chevrolet	Malibu hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Malibu hybrid	Radio	●	●	●	●	●	●	T033
2010	Chevrolet	Malibu hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Malibu hybrid	Passenger presence system	●	●	○	○	○	○	

2010	Chevrolet	Malibu hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Chevrolet	Malibu hybrid	Body control module	●	●	●	●	●	●	T008 T023 T056
2010	Chevrolet	Malibu hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Malibu hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Malibu hybrid	HVAC control module	●	●	●	●	●	●	T055
2010	Chevrolet	Malibu hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Malibu hybrid	Power steering control module	●	●	●	●	●	○	
2010	Chevrolet	Optra	Engine control module	●	●	●	●	●	●	T015
2010	Chevrolet	Optra	Transmission control module	●	●	●	●	●	●	T001
2010	Chevrolet	Optra	Supplemental inflatable restraint	●	●	●	●	●	○	
2010	Chevrolet	Optra	Immobilizer	○	○	○	○	○	●	T016
2010	Chevrolet	Optra	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2010	Chevrolet	Optra	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Spark classic	Transmission control module	●	●	●	●	●	○	
2010	Chevrolet	Spark classic	Engine control module	●	●	●	●	●	●	T015
2010	Chevrolet	Spark classic	Supplemental inflatable restraint	●	●	●	●	○	○	
2010	Chevrolet	Spark classic	Immobilizer	○	○	○	○	○	●	T016
2010	Chevrolet	Spark classic	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Others	Supplemental inflatable restraint	●	●	●	●	●	○	
2010	Chevrolet	Others	Immobilizer	○	○	○	○	○	●	T016
2010	Pontiac	G3	Transmission control module	●	●	●	●	●	○	
2010	Pontiac	G3	Engine control module	●	●	●	●	●	●	T001

2010	Pontiac	G3	Supplemental inflatable restraint	●	●	●	●	●	○	
2010	Pontiac	G3	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Pontiac	G3	Immobilizer	●	●	●	●	●	●	T016
2010	Pontiac	G3	Instrument panel cluster	●	●	●	●	●	○	
2010	Pontiac	G3	Radio	●	●	●	○	○	○	
2010	Pontiac	G3	Theft deterrent module	●	●	●	●	○	○	
2010	Pontiac	G3	Passenger presence system	●	●	●	●	●	●	T045
2010	Pontiac	G3	Electronic brake control module	●	●	●	●	●	●	T014
2010	Pontiac	G3	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2010	Pontiac	G5	Engine control module	●	●	●	●	●	○	
2010	Pontiac	G5	Transmission control module	●	●	●	●	●	●	T001
2010	Pontiac	G5	Body control module	●	●	●	●	●	●	T023
2010	Pontiac	G5	Digital radio receiver	●	●	●	●	●	○	
2010	Pontiac	G5	Personal audio link module	●	●	●	○	○	●	T036
2010	Pontiac	G5	Radio	●	●	●	●	●	○	
2010	Pontiac	G5	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Pontiac	G5	Theft deterrent module	●	●	●	●	○	○	
2010	Pontiac	G5	Passenger presence system	●	●	○	○	○	○	
2010	Pontiac	G5	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Pontiac	G5	Driver information center	●	●	●	●	●	○	
2010	Pontiac	G5	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Pontiac	G5	Instrument panel cluster	●	●	●	●	●	○	

2010	Pontiac	G5	Electronic brake control module	●	●	●	●	●	○	
2010	Pontiac	G5	Power steering control module	●	●	●	●	●	○	
2010	Pontiac	G6	Engine control module	●	●	●	●	●	●	T001
2010	Pontiac	G6	Transmission control module	●	●	●	●	●	●	T001
2010	Pontiac	G6	Digital radio receiver	●	●	●	●	●	○	
2010	Pontiac	G6	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Pontiac	G6	Personal audio link module	●	●	●	○	○	●	T036
2010	Pontiac	G6	Radio	●	●	●	●	●	●	T033
2010	Pontiac	G6	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Pontiac	G6	Passenger presence system	●	●	○	○	○	○	
2010	Pontiac	G6	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Pontiac	G6	Body control module	●	●	●	●	●	●	T008 T023
2010	Pontiac	G6	Folding top module	●	●	●	●	●	○	
2010	Pontiac	G6	Theft deterrent module	●	●	●	●	○	○	
2010	Pontiac	G6	Instrument panel cluster	●	●	●	●	●	○	
2010	Pontiac	G6	HVAC control module	●	●	●	●	●	○	
2010	Pontiac	G6	Electronic brake control module	●	●	●	●	●	●	T014
2010	Pontiac	G6	Power steering control module	●	●	●	●	●	○	
2010	Pontiac	Solstice	Engine control module	●	●	●	●	●	○	
2010	Pontiac	Solstice	Transmission control module	●	●	●	●	●	●	T001
2010	Pontiac	Solstice	Digital radio receiver	●	●	●	●	●	○	
2010	Pontiac	Solstice	Personal audio link module	●	●	●	○	○	●	T036

2010	Pontiac	Solstice	Radio	●	●	●	●	●	●	T033
2010	Pontiac	Solstice	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Pontiac	Solstice	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Pontiac	Solstice	Body control module	●	●	●	●	●	●	T023
2010	Pontiac	Solstice	Theft deterrent module	●	●	●	●	○	○	
2010	Pontiac	Solstice	Passenger presence system	●	●	○	○	○	○	
2010	Pontiac	Solstice	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Pontiac	Solstice	Instrument panel cluster	●	●	●	●	●	○	
2010	Pontiac	Solstice	Electronic brake control module	●	●	●	●	●	○	
2010	Pontiac	Vibe - AWD	Powertrain control module	●	●	●	●	●	○	
2010	Pontiac	Vibe - AWD	Engine control module	●	●	●	●	●	○	
2010	Pontiac	Vibe - AWD	Serial data gateway (if equipped)	○	○	○	●	○	○	
2010	Pontiac	Vibe - AWD	Body control module	●	●	○	●	●	○	
2010	Pontiac	Vibe - AWD	Theft deterrent module	○	○	○	●	●	○	
2010	Pontiac	Vibe - AWD	Immobilizer	●	●	○	●	○	●	T076
2010	Pontiac	Vibe - AWD	Digital radio receiver	●	●	●	●	○	○	
2010	Pontiac	Vibe - AWD	Radio	●	●	●	●	●	○	
2010	Pontiac	Vibe - AWD	Veh. interface module	●	●	●	●	●	○	
2010	Pontiac	Vibe - AWD	Instrument panel cluster	●	●	○	●	●	●	T077
2010	Pontiac	Vibe - AWD	HVAC control module	●	●	○	●	●	○	
2010	Pontiac	Vibe - AWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2010	Pontiac	Vibe - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Pontiac	Vibe - AWD	Tire pressure monitor	○	○	●	●	○	●	T078

2010	Pontiac	Vibe - AWD	Electronic brake control module	●	●	○	●	●	●	T014
2010	Pontiac	Vibe - AWD	Power steering control module	●	●	○	●	○	●	T044
2010	Pontiac	Vibe - FWD	Powertrain control module	●	●	●	●	●	○	
2010	Pontiac	Vibe - FWD	Engine control module	●	●	●	●	●	○	
2010	Pontiac	Vibe - FWD	Serial data gateway (if equipped)	○	○	○	●	○	○	
2010	Pontiac	Vibe - FWD	Body control module	●	●	○	●	●	○	
2010	Pontiac	Vibe - FWD	Theft deterrent module	○	○	○	●	●	○	
2010	Pontiac	Vibe - FWD	Immobilizer	●	●	○	●	○	●	T076
2010	Pontiac	Vibe - FWD	Digital radio receiver	●	●	●	●	○	○	
2010	Pontiac	Vibe - FWD	Radio	●	●	●	●	●	○	
2010	Pontiac	Vibe - FWD	Veh. interface module	●	●	●	●	●	○	
2010	Pontiac	Vibe - FWD	Instrument panel cluster	●	●	○	●	●	●	T077
2010	Pontiac	Vibe - FWD	HVAC control module	●	●	○	●	●	○	
2010	Pontiac	Vibe - FWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2010	Pontiac	Vibe - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Pontiac	Vibe - FWD	Tire pressure monitor	○	○	●	●	○	●	T078
2010	Pontiac	Vibe - FWD	Electronic brake control module	●	●	○	●	●	●	T014
2010	Pontiac	Vibe - FWD	Power steering control module	●	●	○	●	○	●	T044
2010	Pontiac	Others	Supplemental inflatable restraint	●	●	●	●	○	○	
2010	Pontiac	Others	Immobilizer	○	○	○	○	○	●	T016
2010	Pontiac	Others	Engine control module	●	●	●	●	●	●	T015
2010	Saturn	SKY	Engine control module	●	●	●	●	●	○	
2010	Saturn	SKY	Transmission control module	●	●	●	●	●	●	T001
2010	Saturn	SKY	Digital radio receiver	●	●	●	●	●	○	

2010	Saturn	SKY	Personal audio link module	●	●	●	○	○	●	T036
2010	Saturn	SKY	Radio	●	●	●	●	●	●	T033
2010	Saturn	SKY	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Saturn	SKY	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Saturn	SKY	Body control module	●	●	●	●	●	●	T023
2010	Saturn	SKY	Theft deterrent module	●	●	●	●	○	○	
2010	Saturn	SKY	Passenger presence system	●	●	○	○	○	○	
2010	Saturn	SKY	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Saturn	SKY	Instrument panel cluster	●	●	●	●	●	○	
2010	Saturn	SKY	Electronic brake control module	●	●	●	●	●	○	
2010	Saturn	Aura	Engine control module	●	●	●	●	●	●	T001
2010	Saturn	Aura	Transmission control module	●	●	●	●	●	●	T001
2010	Saturn	Aura	Digital radio receiver	●	●	●	●	●	○	
2010	Saturn	Aura	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Saturn	Aura	Personal audio link module	●	●	●	○	○	●	T036
2010	Saturn	Aura	Radio	●	●	●	●	●	●	T033
2010	Saturn	Aura	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Saturn	Aura	Passenger presence system	●	●	○	○	○	○	
2010	Saturn	Aura	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Saturn	Aura	Body control module	●	●	●	●	●	●	T008 T023
2010	Saturn	Aura	Theft deterrent module	●	●	●	●	○	○	

2010	Saturn	Aura	Instrument panel cluster	●	●	●	●	●	○	
2010	Saturn	Aura	HVAC control module	●	●	●	●	●	●	T055
2010	Saturn	Aura	Electronic brake control module	●	●	●	●	●	●	T014
2010	Saturn	Aura	Power steering control module	●	●	●	●	●	○	
2010	Saturn	Aura hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	Saturn	Aura hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Saturn	Aura hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	Saturn	Aura hybrid	Radio	●	●	●	●	●	●	T033
2010	Saturn	Aura hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Saturn	Aura hybrid	Passenger presence system	●	●	○	○	○	○	
2010	Saturn	Aura hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Saturn	Aura hybrid	Body control module	●	●	●	●	●	●	T008 T023
2010	Saturn	Aura hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	Saturn	Aura hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	Saturn	Aura hybrid	HVAC control module	●	●	●	●	●	●	T055
2010	Saturn	Aura hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2010	Saturn	Aura hybrid	Power steering control module	●	●	●	●	●	○	
2010	Daewoo	Damas	Transmission control module	●	●	●	●	●	○	
2010	Daewoo	Damas	Engine control module	●	●	●	●	●	●	T015
2010	Daewoo	Damas	Transmission control module	●	●	●	●	●	○	
2010	Daewoo	Damas	Engine control module	●	●	●	●	●	●	T015

2010	Daewoo	Labo	Transmission control module	●	●	●	●	●	○	
2010	Daewoo	Labo	Engine control module	●	●	●	●	●	●	T015
2010	Daewoo	Labo	Transmission control module	●	●	●	●	●	○	
2010	Daewoo	Labo	Engine control module	●	●	●	●	●	●	T015
2010	Daewoo	Others	Transmission control module	●	●	●	●	●	○	
2010	Daewoo	Others	Engine control module	●	●	●	●	●	●	T015
2010	Daewoo	Others	Supplemental inflatable restraint	●	●	●	●	○	○	
2010	Daewoo	Others	Immobilizer	●	●	●	●	●	●	T016
2010	Daewoo	Others	ISU	●	●	●	●	●	○	
2010	Daewoo	Kalos	Engine control module	●	●	●	●	●	●	T015
2010	Daewoo	Kalos	Transmission control module	●	●	●	●	●	●	T015
2010	Daewoo	Kalos	Supplemental inflatable restraint	●	●	●	●	●	○	
2010	Daewoo	Kalos	Immobilizer	●	●	●	●	●	●	T016
2010	Daewoo	Gentra	Engine control module	●	●	●	●	●	●	T001
2010	Daewoo	Gentra	Transmission control module	●	●	●	●	●	●	T001
2010	Daewoo	Gentra	Supplemental inflatable restraint	●	●	●	●	●	○	
2010	Daewoo	Gentra	Immobilizer	●	●	●	●	●	●	T016
2010	Holden	Others	Engine control module	●	●	●	●	●	●	T017
2010	Holden	Others	Transmission control module	●	●	●	●	●	●	T017
2010	Holden	Others	Supplemental inflatable restraint	●	●	●	●	●	○	
2010	Holden	Others	ISU	●	●	●	●	●	○	
2010	Holden	Others	Electronic brake control module	●	●	●	●	●	●	T001
2010	Holden	Others	Immobilizer	○	○	○	○	○	●	T016
2010	Holden	Others	Tire pressure monitor	●	●	●	●	●	●	T018 T019

2010	Buick	Enclave - AWD	Transmission control module	●	●	○	●	●	○	
2010	Buick	Enclave - AWD	Fuel pump control module	●	●	●	●	●	○	
2010	Buick	Enclave - AWD	Engine control module	●	●	●	●	●	○	
2010	Buick	Enclave - AWD	Digital radio receiver	●	●	●	●	●	○	
2010	Buick	Enclave - AWD	Radio	●	●	●	●	●	○	
2010	Buick	Enclave - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Buick	Enclave - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Buick	Enclave - AWD	Headlamp control module	●	●	●	○	○	○	
2010	Buick	Enclave - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2010	Buick	Enclave - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Buick	Enclave - AWD	Passenger presence system	●	●	●	●	●	○	
2010	Buick	Enclave - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Buick	Enclave - AWD	Memory seat module	●	●	●	●	●	○	
2010	Buick	Enclave - AWD	Park assist module	●	●	●	●	○	○	
2010	Buick	Enclave - AWD	Theft deterrent module	●	●	●	●	○	○	
2010	Buick	Enclave - AWD	Instrument panel cluster	●	●	●	●	●	○	
2010	Buick	Enclave - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Buick	Enclave - AWD	Driver door switch	●	●	●	●	●	●	T035
2010	Buick	Enclave - AWD	Passenger door switch	●	●	●	●	●	●	T035
2010	Buick	Enclave - AWD	Body control module	●	●	●	●	●	●	T007 T005
2010	Buick	Enclave - AWD	Liftgate module	●	●	●	●	●	○	
2010	Buick	Enclave - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Buick	Enclave - AWD	Rear drive system	●	●	●	●	●	●	T038
2010	Buick	Enclave - FWD	Transmission control module	●	●	○	●	●	○	

2010	Buick	Enclave - FWD	Fuel pump control module	●	●	●	●	●	○	
2010	Buick	Enclave - FWD	Engine control module	●	●	●	●	●	○	
2010	Buick	Enclave - FWD	Digital radio receiver	●	●	●	●	●	○	
2010	Buick	Enclave - FWD	Radio	●	●	●	●	●	○	
2010	Buick	Enclave - FWD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Buick	Enclave - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Buick	Enclave - FWD	Headlamp control module	●	●	●	○	○	○	
2010	Buick	Enclave - FWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2010	Buick	Enclave - FWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Buick	Enclave - FWD	Passenger presence system	●	●	●	●	●	○	
2010	Buick	Enclave - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Buick	Enclave - FWD	Memory seat module	●	●	●	●	●	○	
2010	Buick	Enclave - FWD	Park assist module	●	●	●	●	○	○	
2010	Buick	Enclave - FWD	Theft deterrent module	●	●	●	●	○	○	
2010	Buick	Enclave - FWD	Instrument panel cluster	●	●	●	●	●	○	
2010	Buick	Enclave - FWD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Buick	Enclave - FWD	Driver door switch	●	●	●	●	●	●	T035
2010	Buick	Enclave - FWD	Passenger door switch	●	●	●	●	●	●	T035
2010	Buick	Enclave - FWD	Body control module	●	●	●	●	●	●	T007 T005
2010	Buick	Enclave - FWD	Liftgate module	●	●	●	●	●	○	
2010	Buick	Enclave - FWD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Buick	Enclave - FWD	Rear drive system	●	●	●	●	●	●	T038
2010	Cadillac	Escalade	Transmission control module	●	●	○	●	●	○	
2010	Cadillac	Escalade	Engine control module	●	●	●	●	●	●	T001

2010	Cadillac	Escalade	Driver door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade	Passenger door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade	Electronic suspension control	●	●	●	●	●	●	T040
2010	Cadillac	Escalade	Electronic brake control module	●	●	●	●	●	●	T014
2010	Cadillac	Escalade	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Cadillac	Escalade	Accessory power module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Transmission control module	●	●	○	●	●	○	
2010	Cadillac	Escalade	Engine control module	●	●	●	●	●	●	T001
2010	Cadillac	Escalade	Fuel pump control module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Digital radio receiver	●	●	●	●	●	○	
2010	Cadillac	Escalade	Personal audio link module	●	●	●	○	○	●	T036
2010	Cadillac	Escalade	Radio	●	●	●	●	●	○	
2010	Cadillac	Escalade	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Cadillac	Escalade	Amplifier (bose)	●	●	●	●	●	○	
2010	Cadillac	Escalade	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Cadillac	Escalade	A/C compressor control module	●	●	●	●	○	○	
2010	Cadillac	Escalade	Theft deterrent module	●	●	●	●	○	○	
2010	Cadillac	Escalade	Passenger presence system	●	●	●	●	○	○	
2010	Cadillac	Escalade	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Cadillac	Escalade	Park assist module	●	●	●	●	○	○	
2010	Cadillac	Escalade	Inside rear view mirror module	●	●	●	○	○	○	
2010	Cadillac	Escalade	Memory seat module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Rear heated seat module	●	●	●	●	○	○	

2010	Cadillac	Escalade	Left side object detection module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Right side object detection module	●	●	●	●	○	●	T037
2010	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2010	Cadillac	Escalade	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Cadillac	Escalade	Liftgate module	●	●	●	●	●	○	
2010	Cadillac	Escalade	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Cadillac	Escalade	Body control module	●	●	●	●	●	●	T005
2010	Cadillac	Escalade	Serial data gateway module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Cadillac	Escalade	Driver door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade	Passenger door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade	Electronic suspension control	●	●	●	●	●	●	T040
2010	Cadillac	Escalade	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	Cadillac	Escalade	Power steering control module	●	●	○	●	○	●	T044
2010	Cadillac	Escalade	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	Cadillac	Escalade	Transmission control module	●	●	○	●	●	○	
2010	Cadillac	Escalade	Engine control module	●	●	●	●	●	●	T001
2010	Cadillac	Escalade	Fuel pump control module	●	●	●	●	●	●	T001
2010	Cadillac	Escalade	Digital radio receiver	●	●	●	●	●	○	
2010	Cadillac	Escalade	Personal audio link module	●	●	●	○	○	●	T036
2010	Cadillac	Escalade	Radio	●	●	●	●	●	○	
2010	Cadillac	Escalade	Rear HVAC/RSA	●	●	●	●	●	○	

2010	Cadillac	Escalade	Amplifier (bose)	●	●	●	●	●	○	
2010	Cadillac	Escalade	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Cadillac	Escalade	Theft deterrent module	●	●	●	●	○	○	
2010	Cadillac	Escalade	Passenger presence system	●	●	●	●	○	○	
2010	Cadillac	Escalade	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Cadillac	Escalade	Park assist module	●	●	●	●	○	○	
2010	Cadillac	Escalade	Memory seat module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Inside rear view mirror module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Rear heated seat module	●	●	●	●	○	○	
2010	Cadillac	Escalade	Left side object detection module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Right side object detection module	●	●	●	●	○	●	T037
2010	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2010	Cadillac	Escalade	Assist step controller	●	●	●	●	●	●	T039
2010	Cadillac	Escalade	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Cadillac	Escalade	Liftgate module	●	●	●	●	●	○	
2010	Cadillac	Escalade	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Cadillac	Escalade	Body control module	●	●	●	●	●	●	T005
2010	Cadillac	Escalade	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Cadillac	Escalade	Driver door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade	Passenger door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade	Electronic suspension control	●	●	●	●	●	●	T040
2010	Cadillac	Escalade	Electronic brake control module	●	●	●	●	●	●	T014

2010	Cadillac	Escalade	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Cadillac	Escalade	Accessory power module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Transfer case control module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Transmission control module	●	●	○	●	●	○	
2010	Cadillac	Escalade	Engine control module	●	●	●	●	●	●	T001
2010	Cadillac	Escalade	Fuel pump control module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Digital radio receiver	●	●	●	●	●	○	
2010	Cadillac	Escalade	Personal audio link module	●	●	●	○	○	●	T036
2010	Cadillac	Escalade	Radio	●	●	●	●	●	○	
2010	Cadillac	Escalade	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Cadillac	Escalade	Amplifier (bose)	●	●	●	●	●	○	
2010	Cadillac	Escalade	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Cadillac	Escalade	A/C compressor control module	●	●	●	●	○	○	
2010	Cadillac	Escalade	Theft deterrent module	●	●	●	●	○	○	
2010	Cadillac	Escalade	Passenger presence system	●	●	●	●	○	○	
2010	Cadillac	Escalade	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Cadillac	Escalade	Park assist module	●	●	●	●	○	○	
2010	Cadillac	Escalade	Inside rear view mirror module	●	●	●	○	○	○	
2010	Cadillac	Escalade	Memory seat module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Rear heated seat module	●	●	●	●	○	○	
2010	Cadillac	Escalade	Left side object detection module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Right side object detection module	●	●	●	●	○	●	T037

2010	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2010	Cadillac	Escalade	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Cadillac	Escalade	Liftgate module	●	●	●	●	●	○	
2010	Cadillac	Escalade	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Cadillac	Escalade	Body control module	●	●	●	●	●	●	T005
2010	Cadillac	Escalade	Serial data gateway module	●	●	●	●	●	○	
2010	Cadillac	Escalade	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Cadillac	Escalade	Driver door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade	Passenger door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade	Electronic suspension control	●	●	●	●	●	●	T040
2010	Cadillac	Escalade	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	Cadillac	Escalade	Power steering control module	●	●	○	●	○	●	T044
2010	Cadillac	Escalade	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	Cadillac	Escalade hybrid	Transmission control module	●	●	○	●	●	○	
2010	Cadillac	Escalade hybrid	Engine control module	●	●	●	●	●	●	T001
2010	Cadillac	Escalade hybrid	Fuel pump control module	●	●	●	●	●	●	T001
2010	Cadillac	Escalade hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	Cadillac	Escalade hybrid	Radio	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Amplifier (bose)	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Cadillac	Escalade hybrid	Theft deterrent module	●	●	●	●	○	○	

2010	Cadillac	Escalade hybrid	Passenger presence system	●	●	●	●	○	○	
2010	Cadillac	Escalade hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Cadillac	Escalade hybrid	Park assist module	●	●	●	●	○	○	
2010	Cadillac	Escalade hybrid	Memory seat module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Inside rear view mirror module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Rear heated seat module	●	●	●	●	○	○	
2010	Cadillac	Escalade hybrid	Left side object detection module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Right side object detection module	●	●	●	●	○	●	T037
2010	Cadillac	Escalade hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Assist step controller	●	●	●	●	●	●	T039
2010	Cadillac	Escalade hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Cadillac	Escalade hybrid	Liftgate module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Cadillac	Escalade hybrid	Body control module	●	●	●	●	●	●	T005
2010	Cadillac	Escalade hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Cadillac	Escalade hybrid	Driver door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Passenger door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2010	Cadillac	Escalade hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2010	Cadillac	Escalade hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Cadillac	Escalade hybrid	Accessory power module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Transmission control module	●	●	○	●	●	○	

2010	Cadillac	Escalade hybrid	Engine control module	●	●	●	●	●	●	T001
2010	Cadillac	Escalade hybrid	Fuel pump control module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	Cadillac	Escalade hybrid	Radio	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Amplifier (bose)	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Cadillac	Escalade hybrid	A/C compressor control module	●	●	●	●	○	○	
2010	Cadillac	Escalade hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	Cadillac	Escalade hybrid	Passenger presence system	●	●	●	●	○	○	
2010	Cadillac	Escalade hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Cadillac	Escalade hybrid	Park assist module	●	●	●	●	○	○	
2010	Cadillac	Escalade hybrid	Inside rear view mirror module	●	●	●	○	○	○	
2010	Cadillac	Escalade hybrid	Memory seat module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Rear heated seat module	●	●	●	●	○	○	
2010	Cadillac	Escalade hybrid	Left side object detection module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Right side object detection module	●	●	●	●	○	●	T037
2010	Cadillac	Escalade hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Cadillac	Escalade hybrid	Liftgate module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Cadillac	Escalade hybrid	Body control module	●	●	●	●	●	●	T005

2010	Cadillac	Escalade hybrid	Serial data gateway module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Cadillac	Escalade hybrid	Driver door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Passenger door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2010	Cadillac	Escalade hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	Cadillac	Escalade hybrid	Power steering control module	●	●	○	●	○	●	T044
2010	Cadillac	Escalade hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	Cadillac	Escalade hybrid	Transmission control module	●	●	○	●	●	○	
2010	Cadillac	Escalade hybrid	Engine control module	●	●	●	●	●	●	T001
2010	Cadillac	Escalade hybrid	Fuel pump control module	●	●	●	●	●	●	T001
2010	Cadillac	Escalade hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	Cadillac	Escalade hybrid	Radio	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Amplifier (bose)	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Cadillac	Escalade hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	Cadillac	Escalade hybrid	Passenger presence system	●	●	●	●	○	○	
2010	Cadillac	Escalade hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Cadillac	Escalade hybrid	Park assist module	●	●	●	●	○	○	
2010	Cadillac	Escalade hybrid	Memory seat module	●	●	●	●	●	○	

2010	Cadillac	Escalade hybrid	Inside rear view mirror module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Rear heated seat module	●	●	●	●	○	○	
2010	Cadillac	Escalade hybrid	Left side object detection module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Right side object detection module	●	●	●	●	○	●	T037
2010	Cadillac	Escalade hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Assist step controller	●	●	●	●	●	●	T039
2010	Cadillac	Escalade hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Cadillac	Escalade hybrid	Liftgate module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Cadillac	Escalade hybrid	Body control module	●	●	●	●	●	●	T005
2010	Cadillac	Escalade hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Cadillac	Escalade hybrid	Driver door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Passenger door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2010	Cadillac	Escalade hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2010	Cadillac	Escalade hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Cadillac	Escalade hybrid	Accessory power module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Transfer case control module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Transmission control module	●	●	○	●	●	○	
2010	Cadillac	Escalade hybrid	Engine control module	●	●	●	●	●	●	T001
2010	Cadillac	Escalade hybrid	Fuel pump control module	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Digital radio receiver	●	●	●	●	●	○	

2010	Cadillac	Escalade hybrid	Driver door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Passenger door switch	●	●	●	●	●	○	
2010	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2010	Cadillac	Escalade hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	Cadillac	Escalade hybrid	Power steering control module	●	●	○	●	○	●	T044
2010	Cadillac	Escalade hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	Cadillac	Hearse	Amplifier (bose)	●	●	●	●	●	○	
2010	Cadillac	Hearse	Digital radio receiver	●	●	●	●	●	○	
2010	Cadillac	Hearse	Radio	●	●	●	●	●	○	
2010	Cadillac	Hearse	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Cadillac	Hearse	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Cadillac	Hearse	Passenger presence system	●	●	●	●	○	●	T020
2010	Cadillac	Hearse	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Cadillac	Hearse	Driver position module	●	●	●	●	●	○	
2010	Cadillac	Hearse	Rear heated seat module	●	●	●	●	○	○	
2010	Cadillac	Hearse	Theft deterrent module	●	●	●	●	○	○	
2010	Cadillac	Hearse	Instrument panel cluster	●	●	●	●	●	○	
2010	Cadillac	Hearse	HVAC control module	●	●	●	●	●	○	
2010	Cadillac	Hearse	Body control module	●	●	●	●	●	●	T007 T005
2010	Cadillac	Hearse	Driver door switch	●	●	●	●	●	○	
2010	Cadillac	Hearse	Passenger door switch	●	●	●	●	●	○	
2010	Cadillac	Hearse	Air suspension control module	●	●	●	●	●	○	
2010	Cadillac	Hearse	Electronic brake control module	●	●	●	●	○	●	T014

2010	Cadillac	Hearse	Engine control module	●	●	●	●	●	●	T001
2010	Cadillac	Hearse	Transmission control module	●	●	○	●	●	○	
2010	Cadillac	Limousine	Amplifier (bose)	●	●	●	●	●	○	
2010	Cadillac	Limousine	Digital radio receiver	●	●	●	●	●	○	
2010	Cadillac	Limousine	Radio	●	●	●	●	●	○	
2010	Cadillac	Limousine	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Cadillac	Limousine	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Cadillac	Limousine	Passenger presence system	●	●	●	●	○	●	T020
2010	Cadillac	Limousine	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Cadillac	Limousine	Driver position module	●	●	●	●	●	○	
2010	Cadillac	Limousine	Rear heated seat module	●	●	●	●	○	○	
2010	Cadillac	Limousine	Theft deterrent module	●	●	●	●	○	○	
2010	Cadillac	Limousine	Instrument panel cluster	●	●	●	●	●	○	
2010	Cadillac	Limousine	HVAC control module	●	●	●	●	●	○	
2010	Cadillac	Limousine	Aux. HVAC control module	○	○	●	●	●	○	
2010	Cadillac	Limousine	Body control module	●	●	●	●	●	●	T007 T005
2010	Cadillac	Limousine	Driver door switch	●	●	●	●	●	○	
2010	Cadillac	Limousine	Passenger door switch	●	●	●	●	●	○	
2010	Cadillac	Limousine	Air suspension control module	●	●	●	●	●	○	
2010	Cadillac	Limousine	Electronic brake control module	●	●	●	●	○	●	T014
2010	Cadillac	Limousine	Engine control module	●	●	●	●	●	●	T001
2010	Cadillac	Limousine	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Transmission control module	●	●	○	●	●	○	

2010	Chevrolet	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Avalanche - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Avalanche - 2WD	Radio	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Avalanche - 2WD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Avalanche - 2WD	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 2WD	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Assist step controller	●	●	●	●	●	●	T039
2010	Chevrolet	Avalanche - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Avalanche - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014

2010	Chevrolet	Avalanche - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Avalanche - 2WD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Avalanche - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Avalanche - 2WD	Radio	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Avalanche - 2WD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Avalanche - 2WD	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 2WD	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 2WD	Assist step controller	●	●	●	●	●	●	T039
2010	Chevrolet	Avalanche - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Avalanche - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	●	T005

2010	Chevrolet	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Avalanche - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Avalanche - 4WD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Avalanche - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Avalanche - 4WD	Radio	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Avalanche - 4WD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Avalanche - 4WD	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 4WD	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Driver door switch	●	●	●	●	●	○	

2010	Chevrolet	Avalanche - 4WD	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Assist step controller	●	●	●	●	●	●	T039
2010	Chevrolet	Avalanche - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Avalanche - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Avalanche - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Avalanche - 4WD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Avalanche - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Avalanche - 4WD	Radio	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Avalanche - 4WD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Avalanche - 4WD	Park assist module	●	●	●	●	○	○	

2010	Chevrolet	Avalanche - 4WD	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Avalanche - 4WD	Assist step controller	●	●	●	●	●	●	T039
2010	Chevrolet	Avalanche - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Avalanche - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Avalanche - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Captiva	Engine control module	●	●	●	●	●	●	T017
2010	Chevrolet	Captiva	Transmission control module	●	●	●	●	●	●	T017
2010	Chevrolet	Captiva	Rear drive system	●	●	●	●	●	●	T038
2010	Chevrolet	Captiva	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Captiva	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Captiva	Body control module (aux.)	●	●	●	●	●	○	
2010	Chevrolet	Captiva	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Captiva	Instrument panel cluster	●	●	●	●	●	○	

2010	Chevrolet	Captiva	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Captiva	HVAC control module	●	●	●	○	●	○	
2010	Chevrolet	Captiva	Electronic brake control module	●	●	●	●	●	○	
2010	Chevrolet	Captiva sport	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Captiva sport	Fuel pump control module	●	●	●	●	●	○	
2010	Chevrolet	Captiva sport	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Captiva sport	Rear drive system	●	●	●	●	●	●	T038
2010	Chevrolet	Captiva sport	Radio	●	●	●	●	●	○	
2010	Chevrolet	Captiva sport	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Captiva sport	Rollover sensor	●	●	●	●	○	●	T049
2010	Chevrolet	Captiva sport	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Captiva sport	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Captiva sport	Passenger presence system	●	●	●	●	○	●	T045
2010	Chevrolet	Captiva sport	HVAC control module	●	●	●	●	●	●	T008
2010	Chevrolet	Captiva sport	Body control module	●	●	●	●	●	●	T007 T005
2010	Chevrolet	Captiva sport	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Captiva sport	Electronic brake control module	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 2WD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Cheyenne - 2WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Cheyenne - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Cheyenne - 2WD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Cheyenne - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	

2010	Chevrolet	Cheyenne - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Cheyenne - 2WD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 2WD	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Cheyenne - 2WD	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 2WD	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 2WD	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 2WD	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Cheyenne - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Cheyenne - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Cheyenne - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Cheyenne - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Cheyenne - 2WD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Cheyenne - 2WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Cheyenne - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Cheyenne - 2WD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Cheyenne - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 2WD	Amplifier (bose)	●	●	●	●	●	○	

2010	Chevrolet	Cheyenne - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Cheyenne - 2WD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 2WD	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Cheyenne - 2WD	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 2WD	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 2WD	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 2WD	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Cheyenne - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Cheyenne - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Cheyenne - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Cheyenne - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Cheyenne - 4WD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Cheyenne - 4WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Cheyenne - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Cheyenne - 4WD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Cheyenne - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 4WD	Amplifier (bose)	●	●	●	●	●	○	

2010	Chevrolet	Cheyenne - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Cheyenne - 4WD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 4WD	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Cheyenne - 4WD	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 4WD	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 4WD	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 4WD	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Cheyenne - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Cheyenne - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Cheyenne - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Cheyenne - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Cheyenne - 4WD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Cheyenne - 4WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Cheyenne - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Cheyenne - 4WD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Cheyenne - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 4WD	Amplifier (bose)	●	●	●	●	●	○	

2010	Chevrolet	Cheyenne - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Cheyenne - 4WD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 4WD	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Cheyenne - 4WD	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 4WD	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Cheyenne - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 4WD	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 4WD	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Cheyenne - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Cheyenne - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Cheyenne - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Cheyenne - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Cheyenne - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Colorado pickup - 2WD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Colorado pickup - 2WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Colorado pickup - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Colorado pickup - 2WD	Digital radio receiver	●	●	●	●	●	●	T024
2010	Chevrolet	Colorado pickup - 2WD	Radio	●	●	●	●	○	○	

2010	Chevrolet	Colorado pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2010	Chevrolet	Colorado pickup - 2WD	Generator battery control module	●	●	●	●	●	○	
2010	Chevrolet	Colorado pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Chevrolet	Colorado pickup - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2010	Chevrolet	Colorado pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022
2010	Chevrolet	Colorado pickup - 2WD	Theft deterrent module	●	●	●	●	○	●	T057
2010	Chevrolet	Colorado pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Colorado pickup - 2WD	Personal audio link module	●	●	●	●	●	●	T036
2010	Chevrolet	Colorado pickup - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2010	Chevrolet	Colorado pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Colorado pickup - 4WD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Colorado pickup - 4WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Colorado pickup - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Colorado pickup - 4WD	Digital radio receiver	●	●	●	●	●	●	T024
2010	Chevrolet	Colorado pickup - 4WD	Radio	●	●	●	●	○	○	
2010	Chevrolet	Colorado pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2010	Chevrolet	Colorado pickup - 4WD	Generator battery control module	●	●	●	●	●	○	

2010	Chevrolet	Colorado pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Chevrolet	Colorado pickup - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2010	Chevrolet	Colorado pickup - 4WD	Body control module	●	●	●	●	●	●	T058 T022
2010	Chevrolet	Colorado pickup - 4WD	Theft deterrent module	●	●	●	●	○	●	T057
2010	Chevrolet	Colorado pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Colorado pickup - 4WD	Personal audio link module	●	●	●	●	●	●	T036
2010	Chevrolet	Colorado pickup - 4WD	Electronic brake control module	●	●	●	●	●	●	T001
2010	Chevrolet	Colorado pickup - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Express	Transmission control module	●	●	●	●	●	●	T001
2010	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Express	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2010	Chevrolet	Express	Radio	●	●	●	●	●	○	
2010	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T045
2010	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049
2010	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Express	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Express	Body control module	●	●	●	●	●	●	T005

2010	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Express	Transmission control module	●	●	●	●	●	●	T001
2010	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Express	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2010	Chevrolet	Express	Radio	●	●	●	●	●	○	
2010	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T045
2010	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049
2010	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Express	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Express	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Express	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Express	Radio	●	●	●	●	●	○	
2010	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T045
2010	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049

2010	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Express	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Express	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Express	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Express	Radio	●	●	●	●	●	○	
2010	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T045
2010	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049
2010	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Express	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Express	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	HHR	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	HHR	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	HHR	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	HHR	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	HHR	Radio	●	●	●	●	●	○	
2010	Chevrolet	HHR	Body control module	●	●	●	●	●	●	T023

2010	Chevrolet	HHR	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	HHR	Passenger presence system	●	●	○	○	○	○	
2010	Chevrolet	HHR	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Chevrolet	HHR	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	HHR	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	HHR	Driver information center	●	●	●	●	●	○	
2010	Chevrolet	HHR	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	HHR	Electronic brake control module	●	●	●	●	●	○	
2010	Chevrolet	HHR	Power steering control module	●	●	●	●	●	○	
2010	Chevrolet	HHR panel	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	HHR panel	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	HHR panel	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	HHR panel	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	HHR panel	Radio	●	●	●	●	●	○	
2010	Chevrolet	HHR panel	Body control module	●	●	●	●	●	●	T023
2010	Chevrolet	HHR panel	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	HHR panel	Passenger presence system	●	●	○	○	○	○	
2010	Chevrolet	HHR panel	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Chevrolet	HHR panel	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	HHR panel	Instrument panel cluster	●	●	●	●	●	○	

2010	Chevrolet	HHR panel	Driver information center	●	●	●	●	●	○	
2010	Chevrolet	HHR panel	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	HHR panel	Electronic brake control module	●	●	●	●	●	○	
2010	Chevrolet	HHR panel	Power steering control module	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Silverado	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Silverado	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Silverado	Radio	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Silverado	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Passenger door switch	●	●	●	●	●	○	

2010	Chevrolet	Silverado	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Silverado	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Silverado	Trailer brake control module	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Silverado	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Silverado	FPCM with trailer brake control	●	●	●	●	●	●	T040
2010	Chevrolet	Silverado	Accessory power module	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Silverado	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Silverado	Fuel pump control module	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Silverado	Radio	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Silverado	A/C compressor control module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2010	Chevrolet	Silverado	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Silverado	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Silverado	Serial data gateway module	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Silverado	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Silverado	Power steering control module	●	●	○	●	○	●	T044
2010	Chevrolet	Silverado	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Silverado	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Silverado	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Silverado	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Silverado	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Silverado	Radio	●	●	●	●	●	○	

2010	Chevrolet	Silverado	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Silverado	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Silverado	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Silverado	Trailer brake control module	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Silverado	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Silverado	FPCM with trailer brake control	●	●	●	●	●	●	T040
2010	Chevrolet	Silverado	Accessory power module	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Transfer case control module	●	●	●	●	●	○	

2010	Chevrolet	Silverado	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Silverado	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Silverado	Fuel pump control module	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Silverado	Radio	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Silverado	A/C compressor control module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Silverado	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Silverado	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Silverado	Serial data gateway module	●	●	●	●	●	○	

2010	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Silverado	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Silverado	Power steering control module	●	●	○	●	○	●	T044
2010	Chevrolet	Silverado	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Silverado hybrid	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Silverado hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Silverado hybrid	Radio	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Silverado hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2010	Chevrolet	Silverado hybrid	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Silverado hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Silverado hybrid	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Silverado hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Silverado hybrid	Trailer brake control module	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Silverado hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T040
2010	Chevrolet	Silverado hybrid	Accessory power module	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001

2010	Chevrolet	Silverado hybrid	Fuel pump control module	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Silverado hybrid	Radio	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Silverado hybrid	A/C compressor control module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Silverado hybrid	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Passenger door switch	●	●	●	●	●	○	

2010	Chevrolet	Silverado hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Silverado hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Silverado hybrid	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Silverado hybrid	Serial data gateway module	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Silverado hybrid	Power steering control module	●	●	○	●	○	●	T044
2010	Chevrolet	Silverado hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Silverado hybrid	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Silverado hybrid	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Silverado hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Silverado hybrid	Radio	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Rear HVAC/RSA	●	●	●	●	●	○	

2010	Chevrolet	Silverado hybrid	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Silverado hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Silverado hybrid	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Silverado hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Silverado hybrid	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Silverado hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Silverado hybrid	Trailer brake control module	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040

2010	Chevrolet	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Silverado hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T040
2010	Chevrolet	Silverado hybrid	Accessory power module	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Transfer case control module	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Silverado hybrid	Fuel pump control module	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Silverado hybrid	Radio	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Silverado hybrid	A/C compressor control module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2010	Chevrolet	Silverado hybrid	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Silverado hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Silverado hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Silverado hybrid	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Silverado hybrid	Serial data gateway module	●	●	●	●	●	○	
2010	Chevrolet	Silverado hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Silverado hybrid	Power steering control module	●	●	○	●	○	●	T044
2010	Chevrolet	Silverado hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Suburban - 2WD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Suburban - 2WD	Fuel pump control module	●	●	●	●	●	●	T001

2010	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Suburban - 2WD	Radio	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Suburban - 2WD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Suburban - 2WD	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 2WD	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 2WD	Left side object detection module	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Right side object detection module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Assist step controller	●	●	●	●	●	●	T039
2010	Chevrolet	Suburban - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Suburban - 2WD	Liftgate module	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	●	T040

2010	Chevrolet	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Suburban - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Suburban - 2WD	Trailer brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Suburban - 2WD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Suburban - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Suburban - 2WD	Radio	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Suburban - 2WD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Suburban - 2WD	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 2WD	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 2WD	Left side object detection module	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Right side object detection module	●	●	●	●	○	○	

2010	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	Assist step controller	●	●	●	●	●	●	T039
2010	Chevrolet	Suburban - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Suburban - 2WD	Liftgate module	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Suburban - 2WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Suburban - 2WD	Trailer brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Suburban - 4WD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Suburban - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Suburban - 4WD	Radio	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2010	Chevrolet	Suburban - 4WD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Suburban - 4WD	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 4WD	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 4WD	Left side object detection module	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Right side object detection module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Assist step controller	●	●	●	●	●	●	T039
2010	Chevrolet	Suburban - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Suburban - 4WD	Liftgate module	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Suburban - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Suburban - 4WD	Trailer brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001

2010	Chevrolet	Suburban - 4WD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Suburban - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Suburban - 4WD	Radio	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Suburban - 4WD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Suburban - 4WD	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 4WD	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 4WD	Left side object detection module	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Right side object detection module	●	●	●	●	○	○	
2010	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	Assist step controller	●	●	●	●	●	●	T039
2010	Chevrolet	Suburban - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Suburban - 4WD	Liftgate module	●	●	●	●	●	○	
2010	Chevrolet	Suburban - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034

2010	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Suburban - 4WD	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Suburban - 4WD	Trailer brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2010	Chevrolet	Tahoe	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Tahoe	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Tahoe	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Tahoe	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Tahoe	Radio	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Tahoe	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Tahoe	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Rear heated seat module	●	●	●	●	○	○	

2010	Chevrolet	Tahoe	Left side object detection module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Right side object detection module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Assist step controller	●	●	●	●	●	●	T039
2010	Chevrolet	Tahoe	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Tahoe	Liftgate module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Tahoe	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Tahoe	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Tahoe	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Tahoe	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Tahoe	Accessory power module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Tahoe	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Tahoe	Fuel pump control module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Tahoe	Radio	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Amplifier (bose)	●	●	●	●	●	○	

2010	Chevrolet	Tahoe	Power steering control module	●	●	○	●	○	●	T044
2010	Chevrolet	Tahoe	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Tahoe	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Tahoe	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Tahoe	Transfer case control module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Tahoe	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Tahoe	Radio	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Tahoe	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Tahoe	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Left side object detection module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Right side object detection module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Driver door switch	●	●	●	●	●	○	

2010	Chevrolet	Tahoe	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Assist step controller	●	●	●	●	●	●	T039
2010	Chevrolet	Tahoe	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Tahoe	Liftgate module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Tahoe	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Tahoe	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Tahoe	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Tahoe	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Tahoe	Accessory power module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Transfer case control module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Tahoe	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Tahoe	Fuel pump control module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Tahoe	Radio	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Tahoe	A/C compressor control module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Theft deterrent module	●	●	●	●	○	○	

2010	Chevrolet	Tahoe	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Tahoe	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Left side object detection module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Right side object detection module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Tahoe	Liftgate module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Tahoe	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Tahoe	Serial data gateway module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Tahoe	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Tahoe	Power steering control module	●	●	○	●	○	●	T044
2010	Chevrolet	Tahoe	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Tahoe hybrid	Transmission control module	●	●	○	●	●	○	

2010	Chevrolet	Tahoe hybrid	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Tahoe hybrid	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Tahoe hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Tahoe hybrid	Radio	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Tahoe hybrid	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Left side object detection module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Right side object detection module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Assist step controller	●	●	●	●	●	●	T039
2010	Chevrolet	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Tahoe hybrid	Liftgate module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Tahoe hybrid	Body control module	●	●	●	●	●	●	T005

2010	Chevrolet	Tahoe hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Tahoe hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Tahoe hybrid	Accessory power module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Tahoe hybrid	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Tahoe hybrid	Fuel pump control module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Tahoe hybrid	Radio	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Tahoe hybrid	A/C compressor control module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Tahoe hybrid	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Left side object detection module	●	●	●	●	●	○	

2010	Chevrolet	Tahoe hybrid	Right side object detection module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Tahoe hybrid	Liftgate module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Tahoe hybrid	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Tahoe hybrid	Serial data gateway module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Tahoe hybrid	Power steering control module	●	●	○	●	○	●	T044
2010	Chevrolet	Tahoe hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Tahoe hybrid	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Tahoe hybrid	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Tahoe hybrid	Transfer case control module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Fuel pump control module	●	●	●	●	●	●	T001
2010	Chevrolet	Tahoe hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Tahoe hybrid	Radio	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Rear HVAC/RSA	●	●	●	●	●	○	

2010	Chevrolet	Tahoe hybrid	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Tahoe hybrid	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Left side object detection module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Right side object detection module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Passenger door switch	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Assist step controller	●	●	●	●	●	●	T039
2010	Chevrolet	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Tahoe hybrid	Liftgate module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Tahoe hybrid	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Tahoe hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Tahoe hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	Chevrolet	Tahoe hybrid	Accessory power module	●	●	●	●	●	○	

2010	Chevrolet	Tahoe hybrid	Transfer case control module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Tahoe hybrid	Engine control module	●	●	●	●	●	●	T001
2010	Chevrolet	Tahoe hybrid	Fuel pump control module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	Chevrolet	Tahoe hybrid	Radio	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Amplifier (bose)	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Tahoe hybrid	A/C compressor control module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Passenger presence system	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Tahoe hybrid	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Rear heated seat module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Left side object detection module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Right side object detection module	●	●	●	●	○	○	
2010	Chevrolet	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Driver door switch	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Passenger door switch	●	●	●	●	●	○	

2010	Chevrolet	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2010	Chevrolet	Tahoe hybrid	Liftgate module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Tahoe hybrid	Body control module	●	●	●	●	●	●	T005
2010	Chevrolet	Tahoe hybrid	Serial data gateway module	●	●	●	●	●	○	
2010	Chevrolet	Tahoe hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Chevrolet	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2010	Chevrolet	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Tahoe hybrid	Power steering control module	●	●	○	●	○	●	T044
2010	Chevrolet	Tahoe hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	Chevrolet	Traverse - AWD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Traverse - AWD	Fuel pump control module	●	●	●	●	●	○	
2010	Chevrolet	Traverse - AWD	Engine control module	●	●	●	●	●	○	
2010	Chevrolet	Traverse - AWD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Traverse - AWD	Radio	●	●	●	●	●	○	
2010	Chevrolet	Traverse - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Traverse - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Chevrolet	Traverse - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2010	Chevrolet	Traverse - AWD	Passenger presence system	●	●	●	●	●	○	
2010	Chevrolet	Traverse - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Traverse - AWD	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Traverse - AWD	Park assist module	●	●	●	●	○	○	

2010	Chevrolet	Traverse - AWD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Traverse - AWD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Traverse - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Chevrolet	Traverse - AWD	Driver door switch	●	●	●	●	●	●	T035
2010	Chevrolet	Traverse - AWD	Passenger door switch	●	●	●	●	●	●	T035
2010	Chevrolet	Traverse - AWD	Body control module	●	●	●	●	●	●	T007 T005
2010	Chevrolet	Traverse - AWD	Liftgate module	●	●	●	●	●	○	
2010	Chevrolet	Traverse - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Traverse - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Traverse - AWD	Rear drive system	●	●	●	●	●	●	T038
2010	Chevrolet	Traverse - FWD	Transmission control module	●	●	○	●	●	○	
2010	Chevrolet	Traverse - FWD	Fuel pump control module	●	●	●	●	●	○	
2010	Chevrolet	Traverse - FWD	Engine control module	●	●	●	●	●	○	
2010	Chevrolet	Traverse - FWD	Digital radio receiver	●	●	●	●	●	○	
2010	Chevrolet	Traverse - FWD	Radio	●	●	●	●	●	○	
2010	Chevrolet	Traverse - FWD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Chevrolet	Traverse - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Chevrolet	Traverse - FWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2010	Chevrolet	Traverse - FWD	Passenger presence system	●	●	●	●	●	○	
2010	Chevrolet	Traverse - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Chevrolet	Traverse - FWD	Memory seat module	●	●	●	●	●	○	
2010	Chevrolet	Traverse - FWD	Park assist module	●	●	●	●	○	○	
2010	Chevrolet	Traverse - FWD	Theft deterrent module	●	●	●	●	○	○	
2010	Chevrolet	Traverse - FWD	Instrument panel cluster	●	●	●	●	●	○	
2010	Chevrolet	Traverse - FWD	HVAC control module	●	●	●	●	●	●	T008 T034

2010	Chevrolet	Traverse - FWD	Driver door switch	●	●	●	●	●	●	T035
2010	Chevrolet	Traverse - FWD	Passenger door switch	●	●	●	●	●	●	T035
2010	Chevrolet	Traverse - FWD	Body control module	●	●	●	●	●	●	T007 T005
2010	Chevrolet	Traverse - FWD	Liftgate module	●	●	●	●	●	○	
2010	Chevrolet	Traverse - FWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Chevrolet	Traverse - FWD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Chevrolet	Traverse - FWD	Rear drive system	●	●	●	●	●	●	T038
2010	GMC truck	Acadia - 2WD	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Acadia - 2WD	Fuel pump control module	●	●	●	●	●	○	
2010	GMC truck	Acadia - 2WD	Engine control module	●	●	●	●	●	○	
2010	GMC truck	Acadia - 2WD	Digital radio receiver	●	●	●	●	●	○	
2010	GMC truck	Acadia - 2WD	Radio	●	●	●	●	●	○	
2010	GMC truck	Acadia - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	GMC truck	Acadia - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	GMC truck	Acadia - 2WD	Head up display	●	●	●	●	○	○	
2010	GMC truck	Acadia - 2WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2010	GMC truck	Acadia - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Acadia - 2WD	Passenger presence system	●	●	●	●	●	○	
2010	GMC truck	Acadia - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Acadia - 2WD	Memory seat module	●	●	●	●	●	○	
2010	GMC truck	Acadia - 2WD	Park assist module	●	●	●	●	○	○	
2010	GMC truck	Acadia - 2WD	Theft deterrent module	●	●	●	●	○	○	
2010	GMC truck	Acadia - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Acadia - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	GMC truck	Acadia - 2WD	Driver door switch	●	●	●	●	●	●	T035

2010	GMC truck	Acadia - 2WD	Passenger door switch	●	●	●	●	●	●	T035
2010	GMC truck	Acadia - 2WD	Body control module	●	●	●	●	●	●	T007 T005
2010	GMC truck	Acadia - 2WD	Liftgate module	●	●	●	●	●	○	
2010	GMC truck	Acadia - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	GMC truck	Acadia - 2WD	Rear drive system	●	●	●	●	●	●	T038
2010	GMC truck	Acadia - 4WD	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Acadia - 4WD	Fuel pump control module	●	●	●	●	●	○	
2010	GMC truck	Acadia - 4WD	Engine control module	●	●	●	●	●	○	
2010	GMC truck	Acadia - 4WD	Digital radio receiver	●	●	●	●	●	○	
2010	GMC truck	Acadia - 4WD	Radio	●	●	●	●	●	○	
2010	GMC truck	Acadia - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	GMC truck	Acadia - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	GMC truck	Acadia - 4WD	Head up display	●	●	●	●	○	○	
2010	GMC truck	Acadia - 4WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2010	GMC truck	Acadia - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Acadia - 4WD	Passenger presence system	●	●	●	●	●	○	
2010	GMC truck	Acadia - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Acadia - 4WD	Memory seat module	●	●	●	●	●	○	
2010	GMC truck	Acadia - 4WD	Park assist module	●	●	●	●	○	○	
2010	GMC truck	Acadia - 4WD	Theft deterrent module	●	●	●	●	○	○	
2010	GMC truck	Acadia - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Acadia - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	GMC truck	Acadia - 4WD	Driver door switch	●	●	●	●	●	●	T035
2010	GMC truck	Acadia - 4WD	Passenger door switch	●	●	●	●	●	●	T035
2010	GMC truck	Acadia - 4WD	Body control module	●	●	●	●	●	●	T007 T005
2010	GMC truck	Acadia - 4WD	Liftgate module	●	●	●	●	●	○	

2010	GMC truck	Acadia - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	GMC truck	Acadia - 4WD	Rear drive system	●	●	●	●	●	●	T038
2010	GMC truck	Canyon pickup - 2WD	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Canyon pickup - 2WD	Engine control module	●	●	●	●	●	●	T001
2010	GMC truck	Canyon pickup - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2010	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	●	●	T024
2010	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	
2010	GMC truck	Canyon pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2010	GMC truck	Canyon pickup - 2WD	Generator battery control module	●	●	●	●	●	○	
2010	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	GMC truck	Canyon pickup - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2010	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022
2010	GMC truck	Canyon pickup - 2WD	Theft deterrent module	●	●	●	●	○	●	T057
2010	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Canyon pickup - 2WD	Personal audio link module	●	●	●	●	●	●	T036
2010	GMC truck	Canyon pickup - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2010	GMC truck	Canyon pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2010	GMC truck	Canyon pickup - 4WD	Transmission control module	●	●	○	●	●	○	

2010	GMC truck	Savana	Radio	●	●	●	●	●	○	
2010	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T045
2010	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2010	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2010	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2010	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2010	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2010	GMC truck	Savana	Transmission control module	●	●	●	●	●	●	T001
2010	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2010	GMC truck	Savana	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2010	GMC truck	Savana	Radio	●	●	●	●	●	○	
2010	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T045
2010	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2010	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2010	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2010	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014

2010	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2010	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2010	GMC truck	Savana	Radio	●	●	●	●	●	○	
2010	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T045
2010	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2010	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2010	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2010	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2010	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2010	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2010	GMC truck	Savana	Radio	●	●	●	●	●	○	
2010	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T045
2010	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2010	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	

2010	GMC truck	Sierra	Trailer brake control module	●	●	●	●	●	○	
2010	GMC truck	Sierra	Electronic suspension control	●	●	●	●	●	●	T040
2010	GMC truck	Sierra	Electronic brake control module	●	●	●	●	●	●	T014
2010	GMC truck	Sierra	FPCM with trailer brake control	●	●	●	●	●	●	T040
2010	GMC truck	Sierra	Accessory power module	●	●	●	●	●	○	
2010	GMC truck	Sierra	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Sierra	Engine control module	●	●	●	●	●	●	T001
2010	GMC truck	Sierra	Fuel pump control module	●	●	●	●	●	○	
2010	GMC truck	Sierra	Digital radio receiver	●	●	●	●	●	○	
2010	GMC truck	Sierra	Personal audio link module	●	●	●	○	○	●	T036
2010	GMC truck	Sierra	Radio	●	●	●	●	●	○	
2010	GMC truck	Sierra	Rear HVAC/RSA	●	●	●	●	●	○	
2010	GMC truck	Sierra	Amplifier (bose)	●	●	●	●	●	○	
2010	GMC truck	Sierra	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Sierra	A/C compressor control module	●	●	●	●	○	○	
2010	GMC truck	Sierra	Theft deterrent module	●	●	●	●	○	○	
2010	GMC truck	Sierra	Passenger presence system	●	●	●	●	○	○	
2010	GMC truck	Sierra	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Sierra	Park assist module	●	●	●	●	○	○	
2010	GMC truck	Sierra	Heated seat module	●	●	●	●	○	○	
2010	GMC truck	Sierra	Rear heated seat module	●	●	●	●	○	○	
2010	GMC truck	Sierra	Instrument panel cluster	●	●	●	●	●	○	

2010	GMC truck	Sierra	Driver door switch	●	●	●	●	●	○	
2010	GMC truck	Sierra	Passenger door switch	●	●	●	●	●	○	
2010	GMC truck	Sierra	Body control module (aux.)	●	●	●	●	●	●	T006
2010	GMC truck	Sierra	HVAC control module	●	●	●	●	●	●	T008 T034
2010	GMC truck	Sierra	Body control module	●	●	●	●	●	●	T005
2010	GMC truck	Sierra	Serial data gateway module	●	●	●	●	●	○	
2010	GMC truck	Sierra	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	GMC truck	Sierra	Electronic suspension control	●	●	●	●	●	●	T040
2010	GMC truck	Sierra	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	GMC truck	Sierra	Power steering control module	●	●	○	●	○	●	T044
2010	GMC truck	Sierra	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	GMC truck	Sierra	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Sierra	Engine control module	●	●	●	●	●	●	T001
2010	GMC truck	Sierra	Transfer case control module	●	●	●	●	●	●	T001
2010	GMC truck	Sierra	Fuel pump control module	●	●	●	●	●	●	T001
2010	GMC truck	Sierra	Digital radio receiver	●	●	●	●	●	○	
2010	GMC truck	Sierra	Personal audio link module	●	●	●	○	○	●	T036
2010	GMC truck	Sierra	Radio	●	●	●	●	●	○	
2010	GMC truck	Sierra	Rear HVAC/RSA	●	●	●	●	●	○	
2010	GMC truck	Sierra	Amplifier (bose)	●	●	●	●	●	○	
2010	GMC truck	Sierra	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Sierra	Theft deterrent module	●	●	●	●	○	○	

2010	GMC truck	Sierra	Passenger presence system	●	●	●	●	○	○	
2010	GMC truck	Sierra	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Sierra	Park assist module	●	●	●	●	○	○	
2010	GMC truck	Sierra	Memory seat module	●	●	●	●	●	○	
2010	GMC truck	Sierra	Rear heated seat module	●	●	●	●	○	○	
2010	GMC truck	Sierra	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Sierra	Driver door switch	●	●	●	●	●	○	
2010	GMC truck	Sierra	Passenger door switch	●	●	●	●	●	○	
2010	GMC truck	Sierra	Body control module (aux.)	●	●	●	●	●	●	T006
2010	GMC truck	Sierra	HVAC control module	●	●	●	●	●	●	T008 T034
2010	GMC truck	Sierra	Body control module	●	●	●	●	●	●	T005
2010	GMC truck	Sierra	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	GMC truck	Sierra	Trailer brake control module	●	●	●	●	●	○	
2010	GMC truck	Sierra	Electronic suspension control	●	●	●	●	●	●	T040
2010	GMC truck	Sierra	Electronic brake control module	●	●	●	●	●	●	T014
2010	GMC truck	Sierra	FPCM with trailer brake control	●	●	●	●	●	●	T040
2010	GMC truck	Sierra	Accessory power module	●	●	●	●	●	○	
2010	GMC truck	Sierra	Transfer case control module	●	●	●	●	●	○	
2010	GMC truck	Sierra	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Sierra	Engine control module	●	●	●	●	●	●	T001
2010	GMC truck	Sierra	Fuel pump control module	●	●	●	●	●	○	
2010	GMC truck	Sierra	Digital radio receiver	●	●	●	●	●	○	

2010	GMC truck	Sierra	Power steering control module	●	●	○	●	○	●	T044
2010	GMC truck	Sierra	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	GMC truck	Yukon	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Yukon	Engine control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon	Fuel pump control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon	Digital radio receiver	●	●	●	●	●	○	
2010	GMC truck	Yukon	Personal audio link module	●	●	●	○	○	●	T036
2010	GMC truck	Yukon	Radio	●	●	●	●	●	○	
2010	GMC truck	Yukon	Rear HVAC/RSA	●	●	●	●	●	○	
2010	GMC truck	Yukon	Amplifier (bose)	●	●	●	●	●	○	
2010	GMC truck	Yukon	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Yukon	Theft deterrent module	●	●	●	●	○	○	
2010	GMC truck	Yukon	Passenger presence system	●	●	●	●	○	○	
2010	GMC truck	Yukon	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Yukon	Park assist module	●	●	●	●	○	○	
2010	GMC truck	Yukon	Memory seat module	●	●	●	●	●	○	
2010	GMC truck	Yukon	Rear heated seat module	●	●	●	●	○	○	
2010	GMC truck	Yukon	Left side object detection module	●	●	●	●	●	○	
2010	GMC truck	Yukon	Right side object detection module	●	●	●	●	○	○	
2010	GMC truck	Yukon	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Yukon	Driver door switch	●	●	●	●	●	○	
2010	GMC truck	Yukon	Passenger door switch	●	●	●	●	●	○	
2010	GMC truck	Yukon	Assist step controller	●	●	●	●	●	●	T039

2010	GMC truck	Yukon	Body control module (aux.)	●	●	●	●	●	●	T006
2010	GMC truck	Yukon	Liftgate module	●	●	●	●	●	○	
2010	GMC truck	Yukon	HVAC control module	●	●	●	●	●	●	T008 T034
2010	GMC truck	Yukon	Body control module	●	●	●	●	●	●	T005
2010	GMC truck	Yukon	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	GMC truck	Yukon	Electronic suspension control	●	●	●	●	●	●	T040
2010	GMC truck	Yukon	Electronic brake control module	●	●	●	●	●	●	T014
2010	GMC truck	Yukon	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	GMC truck	Yukon	Transfer case control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Yukon	Engine control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon	Fuel pump control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon	Digital radio receiver	●	●	●	●	●	○	
2010	GMC truck	Yukon	Personal audio link module	●	●	●	○	○	●	T036
2010	GMC truck	Yukon	Radio	●	●	●	●	●	○	
2010	GMC truck	Yukon	Rear HVAC/RSA	●	●	●	●	●	○	
2010	GMC truck	Yukon	Amplifier (bose)	●	●	●	●	●	○	
2010	GMC truck	Yukon	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Yukon	Theft deterrent module	●	●	●	●	○	○	
2010	GMC truck	Yukon	Passenger presence system	●	●	●	●	○	○	
2010	GMC truck	Yukon	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Yukon	Park assist module	●	●	●	●	○	○	
2010	GMC truck	Yukon	Memory seat module	●	●	●	●	●	○	

2010	GMC truck	Yukon	Rear heated seat module	●	●	●	●	○	○	
2010	GMC truck	Yukon	Left side object detection module	●	●	●	●	●	○	
2010	GMC truck	Yukon	Right side object detection module	●	●	●	●	○	○	
2010	GMC truck	Yukon	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Yukon	Driver door switch	●	●	●	●	●	○	
2010	GMC truck	Yukon	Passenger door switch	●	●	●	●	●	○	
2010	GMC truck	Yukon	Assist step controller	●	●	●	●	●	●	T039
2010	GMC truck	Yukon	Body control module (aux.)	●	●	●	●	●	●	T006
2010	GMC truck	Yukon	Liftgate module	●	●	●	●	●	○	
2010	GMC truck	Yukon	HVAC control module	●	●	●	●	●	●	T008 T034
2010	GMC truck	Yukon	Body control module	●	●	●	●	●	●	T005
2010	GMC truck	Yukon	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	GMC truck	Yukon	Electronic suspension control	●	●	●	●	●	●	T040
2010	GMC truck	Yukon	Electronic brake control module	●	●	●	●	●	●	T014
2010	GMC truck	Yukon	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	GMC truck	Yukon	Transfer case control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon hybrid	Accessory power module	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Yukon hybrid	Engine control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon hybrid	Fuel pump control module	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Personal audio link module	●	●	●	○	○	●	T036

2010	GMC truck	Yukon hybrid	Radio	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Amplifier (bose)	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Yukon hybrid	A/C compressor control module	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Passenger presence system	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Yukon hybrid	Park assist module	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Heated seat module	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Rear heated seat module	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Left side object detection module	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Right side object detection module	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Driver door switch	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Passenger door switch	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2010	GMC truck	Yukon hybrid	Liftgate module	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2010	GMC truck	Yukon hybrid	Body control module	●	●	●	●	●	●	T005
2010	GMC truck	Yukon hybrid	Serial data gateway module	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	GMC truck	Yukon hybrid	Electronic suspension control	●	●	●	●	●	●	T040

2010	GMC truck	Yukon hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	GMC truck	Yukon hybrid	Power steering control module	●	●	○	●	○	●	T044
2010	GMC truck	Yukon hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	GMC truck	Yukon hybrid	Transfer case control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon hybrid	Accessory power module	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Yukon hybrid	Engine control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon hybrid	Fuel pump control module	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Digital radio receiver	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Personal audio link module	●	●	●	○	○	●	T036
2010	GMC truck	Yukon hybrid	Radio	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Amplifier (bose)	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Yukon hybrid	A/C compressor control module	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Theft deterrent module	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Passenger presence system	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Yukon hybrid	Park assist module	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Heated seat module	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Rear heated seat module	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Left side object detection module	●	●	●	●	●	○	

2010	GMC truck	Yukon hybrid	Right side object detection module	●	●	●	●	○	○	
2010	GMC truck	Yukon hybrid	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Driver door switch	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Passenger door switch	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2010	GMC truck	Yukon hybrid	Liftgate module	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2010	GMC truck	Yukon hybrid	Body control module	●	●	●	●	●	●	T005
2010	GMC truck	Yukon hybrid	Serial data gateway module	●	●	●	●	●	○	
2010	GMC truck	Yukon hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	GMC truck	Yukon hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2010	GMC truck	Yukon hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2010	GMC truck	Yukon hybrid	Power steering control module	●	●	○	●	○	●	T044
2010	GMC truck	Yukon hybrid	FPCM with trailer brake control	●	●	●	●	●	●	T041 T041 T042 T043
2010	GMC truck	Yukon hybrid	Transfer case control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon XL	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Yukon XL	Engine control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon XL	Fuel pump control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon XL	Digital radio receiver	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Personal audio link module	●	●	●	○	○	●	T036
2010	GMC truck	Yukon XL	Radio	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Rear HVAC/RSA	●	●	●	●	●	○	

2010	GMC truck	Yukon XL	Amplifier (bose)	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Yukon XL	Theft deterrent module	●	●	●	●	○	○	
2010	GMC truck	Yukon XL	Passenger presence system	●	●	●	●	○	○	
2010	GMC truck	Yukon XL	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Yukon XL	Park assist module	●	●	●	●	○	○	
2010	GMC truck	Yukon XL	Memory seat module	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Rear heated seat module	●	●	●	●	○	○	
2010	GMC truck	Yukon XL	Left side object detection module	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Right side object detection module	●	●	●	●	○	○	
2010	GMC truck	Yukon XL	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Driver door switch	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Passenger door switch	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Assist step controller	●	●	●	●	●	●	T039
2010	GMC truck	Yukon XL	Body control module (aux.)	●	●	●	●	●	●	T006
2010	GMC truck	Yukon XL	Liftgate module	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	HVAC control module	●	●	●	●	●	●	T008 T034
2010	GMC truck	Yukon XL	Body control module	●	●	●	●	●	●	T005
2010	GMC truck	Yukon XL	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	GMC truck	Yukon XL	Electronic suspension control	●	●	●	●	●	●	T040
2010	GMC truck	Yukon XL	Electronic brake control module	●	●	●	●	●	●	T014
2010	GMC truck	Yukon XL	FPCM with trailer brake control	●	●	●	●	●	●	T014

2010	GMC truck	Yukon XL	Trailer brake control module	●	●	●	●	●	●	T014
2010	GMC truck	Yukon XL	Transfer case control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon XL	Transmission control module	●	●	○	●	●	○	
2010	GMC truck	Yukon XL	Engine control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon XL	Fuel pump control module	●	●	●	●	●	●	T001
2010	GMC truck	Yukon XL	Digital radio receiver	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Personal audio link module	●	●	●	○	○	●	T036
2010	GMC truck	Yukon XL	Radio	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Rear HVAC/RSA	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Amplifier (bose)	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Yukon XL	Theft deterrent module	●	●	●	●	○	○	
2010	GMC truck	Yukon XL	Passenger presence system	●	●	●	●	○	○	
2010	GMC truck	Yukon XL	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Yukon XL	Park assist module	●	●	●	●	○	○	
2010	GMC truck	Yukon XL	Memory seat module	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Rear heated seat module	●	●	●	●	○	○	
2010	GMC truck	Yukon XL	Left side object detection module	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Right side object detection module	●	●	●	●	○	○	
2010	GMC truck	Yukon XL	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Driver door switch	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Passenger door switch	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	Assist step controller	●	●	●	●	●	●	T039

2010	GMC truck	Yukon XL	Body control module (aux.)	●	●	●	●	●	●	T006
2010	GMC truck	Yukon XL	Liftgate module	●	●	●	●	●	○	
2010	GMC truck	Yukon XL	HVAC control module	●	●	●	●	●	●	T008 T034
2010	GMC truck	Yukon XL	Body control module	●	●	●	●	●	●	T005
2010	GMC truck	Yukon XL	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	GMC truck	Yukon XL	Electronic suspension control	●	●	●	●	●	●	T040
2010	GMC truck	Yukon XL	Electronic brake control module	●	●	●	●	●	●	T014
2010	GMC truck	Yukon XL	FPCM with trailer brake control	●	●	●	●	●	●	T014
2010	GMC truck	Yukon XL	Trailer brake control module	●	●	●	●	●	●	T014
2010	GMC truck	Yukon XL	Transfer case control module	●	●	●	●	●	●	T001
2010	GMC truck	Others	Park assist module	●	●	●	●	○	○	
2010	GMC truck	Others	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	GMC truck	Others	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	GMC truck	Others	Body control module	●	●	●	●	●	●	T005
2010	GMC truck	Others	Body control module (aux.)	●	●	●	●	●	○	
2010	GMC truck	Others	Headlamp control module	●	●	●	●	●	○	
2010	GMC truck	Others	Instrument panel cluster	●	●	●	●	●	○	
2010	GMC truck	Others	Front display interface module	●	●	●	○	○	○	
2010	GMC truck	Others	Radio	●	●	●	●	●	○	
2010	GMC truck	Others	HVAC control module	●	●	●	●	●	●	T005
2010	GMC truck	Others	Electronic brake control module	●	●	●	●	●	○	

2010	GMC truck	Others	Engine control module	●	●	●	●	●	●	T070
2010	GMC truck	Others	Transmission control module	●	●	●	●	●	●	T070
2010	GMC truck	Others	Rear drive system	●	●	●	●	●	●	T038
2010	Saturn	OUTLOOK - AWD	Transmission control module	●	●	○	●	●	○	
2010	Saturn	OUTLOOK - AWD	Fuel pump control module	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - AWD	Engine control module	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - AWD	Digital radio receiver	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - AWD	Radio	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Saturn	OUTLOOK - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2010	Saturn	OUTLOOK - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Saturn	OUTLOOK - AWD	Passenger presence system	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Saturn	OUTLOOK - AWD	Memory seat module	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - AWD	Park assist module	●	●	●	●	○	○	
2010	Saturn	OUTLOOK - AWD	Theft deterrent module	●	●	●	●	○	○	
2010	Saturn	OUTLOOK - AWD	Instrument panel cluster	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Saturn	OUTLOOK - AWD	Driver door switch	●	●	●	●	●	●	T035
2010	Saturn	OUTLOOK - AWD	Passenger door switch	●	●	●	●	●	●	T035
2010	Saturn	OUTLOOK - AWD	Body control module	●	●	●	●	●	●	T007 T005
2010	Saturn	OUTLOOK - AWD	Liftgate module	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Saturn	OUTLOOK - AWD	Rear drive system	●	●	●	●	●	●	T038

2010	Saturn	OUTLOOK - 2WD	Transmission control module	●	●	○	●	●	○	
2010	Saturn	OUTLOOK - 2WD	Fuel pump control module	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - 2WD	Engine control module	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - 2WD	Digital radio receiver	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - 2WD	Radio	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2010	Saturn	OUTLOOK - 2WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2010	Saturn	OUTLOOK - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Saturn	OUTLOOK - 2WD	Passenger presence system	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Saturn	OUTLOOK - 2WD	Memory seat module	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - 2WD	Park assist module	●	●	●	●	○	○	
2010	Saturn	OUTLOOK - 2WD	Theft deterrent module	●	●	●	●	○	○	
2010	Saturn	OUTLOOK - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Saturn	OUTLOOK - 2WD	Driver door switch	●	●	●	●	●	●	T035
2010	Saturn	OUTLOOK - 2WD	Passenger door switch	●	●	●	●	●	●	T035
2010	Saturn	OUTLOOK - 2WD	Body control module	●	●	●	●	●	●	T007 T005
2010	Saturn	OUTLOOK - 2WD	Liftgate module	●	●	●	●	●	○	
2010	Saturn	OUTLOOK - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2010	Saturn	OUTLOOK - 2WD	Rear drive system	●	●	●	●	●	●	T038
2010	Saturn	VUE - AWD	Transmission control module	●	●	○	●	●	○	
2010	Saturn	VUE - AWD	Fuel pump control module	●	●	●	●	●	○	

2010	Saturn	VUE - AWD	Engine control module	●	●	●	●	●	●	T001
2010	Saturn	VUE - AWD	Rear drive system	●	●	●	●	●	●	T038
2010	Saturn	VUE - AWD	Digital radio receiver	●	●	●	●	●	○	
2010	Saturn	VUE - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Saturn	VUE - AWD	Radio	●	●	●	●	●	○	
2010	Saturn	VUE - AWD	Theft deterrent module	●	●	●	●	○	○	
2010	Saturn	VUE - AWD	Rollover sensor	●	●	●	●	○	●	T049
2010	Saturn	VUE - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Saturn	VUE - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Saturn	VUE - AWD	Passenger presence system	●	●	●	●	○	●	T045
2010	Saturn	VUE - AWD	HVAC control module	●	●	●	●	●	●	T008
2010	Saturn	VUE - AWD	Body control module	●	●	●	●	●	●	T007 T005
2010	Saturn	VUE - AWD	Instrument panel cluster	●	●	●	●	●	○	
2010	Saturn	VUE - AWD	Electronic brake control module	●	●	●	●	●	○	
2010	Saturn	VUE - FWD	Transmission control module	●	●	○	●	●	○	
2010	Saturn	VUE - FWD	Fuel pump control module	●	●	●	●	●	○	
2010	Saturn	VUE - FWD	Engine control module	●	●	●	●	●	●	T001
2010	Saturn	VUE - FWD	Digital radio receiver	●	●	●	●	●	○	
2010	Saturn	VUE - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Saturn	VUE - FWD	Radio	●	●	●	●	●	○	
2010	Saturn	VUE - FWD	Theft deterrent module	●	●	●	●	○	○	
2010	Saturn	VUE - FWD	Rollover sensor	●	●	●	●	○	●	T049
2010	Saturn	VUE - FWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Saturn	VUE - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2010	Saturn	VUE - FWD	Passenger presence system	●	●	●	●	○	●	T045
2010	Saturn	VUE - FWD	HVAC control module	●	●	●	●	●	●	T008
2010	Saturn	VUE - FWD	Body control module	●	●	●	●	●	●	T007 T005
2010	Saturn	VUE - FWD	Instrument panel cluster	●	●	●	●	●	○	
2010	Saturn	VUE - FWD	Electronic brake control module	●	●	●	●	●	○	
2010	Hummer	H2	Transmission control module	●	●	○	●	●	○	
2010	Hummer	H2	Fuel pump control module	●	●	●	●	●	○	
2010	Hummer	H2	Transfer case control module	●	●	●	●	●	○	
2010	Hummer	H2	Engine control module	●	●	●	●	●	●	T001
2010	Hummer	H2	Amplifier (bose)	●	●	●	●	●	●	T010
2010	Hummer	H2	Digital radio receiver	●	●	●	●	●	○	
2010	Hummer	H2	Personal audio link module	●	●	●	○	○	●	T036
2010	Hummer	H2	Radio	●	●	●	●	●	○	
2010	Hummer	H2	Rear HVAC/RSA	●	●	●	●	●	○	
2010	Hummer	H2	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2010	Hummer	H2	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Hummer	H2	Theft deterrent module	●	●	●	●	○	○	
2010	Hummer	H2	Rollover sensor	●	●	●	●	○	●	T049
2010	Hummer	H2	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Hummer	H2	Memory seat module	●	●	●	●	●	○	
2010	Hummer	H2	Rear heated seat module	●	●	●	●	○	○	
2010	Hummer	H2	Instrument panel cluster	●	●	●	●	●	○	
2010	Hummer	H2	Driver door switch	●	●	●	●	●	○	

2010	Hummer	H2	Passenger door switch	●	●	●	●	●	○	
2010	Hummer	H2	HVAC control module	●	●	●	●	●	●	T008 T034
2010	Hummer	H2	Body control module	●	●	●	●	●	●	T005
2010	Hummer	H2	Air suspension control module	●	●	●	●	●	○	
2010	Hummer	H2	Electronic brake control module	●	●	●	●	●	●	T014
2010	Hummer	H3	Transmission control module	●	●	○	●	●	○	
2010	Hummer	H3	Engine control module	●	●	●	●	●	●	T001
2010	Hummer	H3	Fuel pump control module	●	●	●	●	●	○	
2010	Hummer	H3	Transfer case control module	●	●	●	●	●	●	T001
2010	Hummer	H3	Digital radio receiver	●	●	●	●	●	●	T024
2010	Hummer	H3	Personal audio link module	●	●	●	○	○	●	T036
2010	Hummer	H3	Radio	●	●	●	●	●	●	T080 T032
2010	Hummer	H3	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2010	Hummer	H3	Generator battery control module	●	●	●	●	●	○	
2010	Hummer	H3	Passenger presence system	●	●	○	○	○	●	T020
2010	Hummer	H3	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2010	Hummer	H3	Body control module	●	●	●	●	●	●	T058 T022
2010	Hummer	H3	Instrument panel cluster	●	●	●	●	●	○	
2010	Hummer	H3	Theft deterrent module	●	●	●	●	●	●	T057
2010	Hummer	H3	Navigation radio	●	●	●	●	●	●	T033
2010	Hummer	H3	Electronic brake control module	●	●	●	●	●	○	
2010	Holden	Captiva	Engine control module	●	●	●	●	●	●	T017

2010	Holden	Captiva	Transmission control module	●	●	●	●	●	●	T017
2010	Holden	Captiva	Rear drive system	●	●	●	●	●	●	T038
2010	Holden	Captiva	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Holden	Captiva	Body control module	●	●	●	●	●	●	T005
2010	Holden	Captiva	Body control module (aux.)	●	●	●	●	●	○	
2010	Holden	Captiva	Theft deterrent module	●	●	●	●	○	○	
2010	Holden	Captiva	Instrument panel cluster	●	●	●	●	●	○	
2010	Holden	Captiva	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Holden	Captiva	HVAC control module	●	●	●	○	●	○	
2010	Holden	Captiva	Electronic brake control module	●	●	●	●	●	○	
2010	Holden	Captiva maxx	Engine control module	●	●	●	●	●	●	T017
2010	Holden	Captiva maxx	Rear drive system	●	●	●	●	●	●	T038
2010	Holden	Captiva maxx	Transmission control module	●	●	●	●	●	●	T038
2010	Holden	Captiva maxx	Park assist module	●	●	●	●	○	○	
2010	Holden	Captiva maxx	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2010	Holden	Captiva maxx	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2010	Holden	Captiva maxx	Body control module	●	●	●	●	●	●	T005
2010	Holden	Captiva maxx	Body control module (aux.)	●	●	●	●	●	○	
2010	Holden	Captiva maxx	Headlamp control module	●	●	●	●	●	○	
2010	Holden	Captiva maxx	Instrument panel cluster	●	●	●	●	●	○	
2010	Holden	Captiva maxx	Front display interface module	●	●	●	○	○	○	
2010	Holden	Captiva maxx	Radio	●	●	●	●	●	○	

2010	Holden	Captiva maxx	HVAC control module	●	●	●	○	●	○	
2010	Holden	Captiva maxx	Theft deterrent module	●	●	●	●	●	●	T005
2010	Holden	Captiva maxx	Electronic brake control module	●	●	●	●	●	○	
2009	Daewoo	Lacetti	Engine Control Module	●	●	●	●	●	●	S029 S025
2009	Daewoo	Lacetti	Fuel Pump Control Module	●	●	●	●	●	●	S025
2009	Daewoo	Lacetti	Transmission Control Module	●	●	●	●	●	●	S023
2009	Daewoo	Lacetti	Electronic Brake Control Module	●	●	●	●	●	●	S034 S035 S036
2009	Daewoo	Lacetti	Multi-Axis Acceleration Sensor Module	●	●	●	○	○	●	S036 S036
2009	Daewoo	Lacetti	Power Steering Control Module	●	●	●	●	○	●	S165 S165 S075 S075
2009	Daewoo	Lacetti	Steering Wheel Angle Sensor Module	●	●	●	○	○	●	S093 S093 S035 S035
2009	Daewoo	Lacetti	Body Control Module	●	●	●	●	●	●	S001 S014 S015 S016 S017 S018 S019 S021
2009	Daewoo	Lacetti	Inflatable Restraint Sensing and Diagnostic Module	●	●	●	●	●	●	S024 S024
2009	Daewoo	Lacetti	Passenger Presence Module	●	●	●	●	○	●	S043
2009	Daewoo	Lacetti	Instrument Cluster	●	●	●	●	●	●	S022
2009	Daewoo	Lacetti	Trailer Interface Control Module	●	●	●	●	●	●	S022
2009	Daewoo	Lacetti	Radio	●	●	●	●	●	○	
2009	Daewoo	Lacetti	Multimedia Player Interface Module	●	●	●	●	○	●	
2009	Daewoo	Lacetti	Mobile Telephone Control Module	●	●	●	●	●	●	S022 S022

2009	Daewoo	Lacetti	Telematics Communication Interface Control Module	●	●	●	●	●	●	S186 S039
2009	Daewoo	Lacetti	Remote Heater and Air Conditioning Control Module	●	●	●	●	●	●	S032 S033
2009	Daewoo	Lacetti	Front Seat Heating Control Module	●	●	●	●	●	○	
2009	Daewoo	Lacetti	Keyless Entry Control Module	●	●	●	●	●	○	
2009	Daewoo	Lacetti	Parking Assist Control Module	●	●	●	●	●	●	
2009	Daewoo	Lacetti	Steering Column Lock Control Module	●	●	●	●	○	●	
2009	Buick	Lacrosse	Powertrain control module	●	●	●	●	●	●	T001
2009	Buick	Lacrosse	Transmission control module	●	●	○	●	●	○	
2009	Buick	Lacrosse	Engine control module	●	●	●	●	●	●	T001
2009	Buick	Lacrosse	Remote control door lock receiver	●	●	●	●	●	●	T022
2009	Buick	Lacrosse	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Buick	Lacrosse	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T060 T080 T032
2009	Buick	Lacrosse	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	Buick	Lacrosse	Digital radio receiver	●	●	●	●	●	●	T024
2009	Buick	Lacrosse	Body control module	●	●	●	●	●	●	T007
2009	Buick	Lacrosse	HVAC control module	●	●	●	●	●	●	T008
2009	Buick	Lacrosse	Instrument panel cluster	●	●	●	●	●	●	T022

2009	Buick	Lacrosse	Electronic brake control module	●	●	○	●	●	●	T014
2009	Buick	Lacrosse (allure in canada)	Powertrain control module	●	●	●	●	●	●	T001
2009	Buick	Lacrosse (allure in canada)	Transmission control module	●	●	○	●	●	○	
2009	Buick	Lacrosse (allure in canada)	Engine control module	●	●	●	●	●	●	T001
2009	Buick	Lacrosse (allure in canada)	Remote control door lock receiver	●	●	●	●	●	●	T022
2009	Buick	Lacrosse (allure in canada)	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Buick	Lacrosse (allure in canada)	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T060 T080 T032
2009	Buick	Lacrosse (allure in canada)	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	Buick	Lacrosse (allure in canada)	Digital radio receiver	●	●	●	●	●	●	T024
2009	Buick	Lacrosse (allure in canada)	Body control module	●	●	●	●	●	●	T007
2009	Buick	Lacrosse (allure in canada)	HVAC control module	●	●	●	●	●	●	T008
2009	Buick	Lacrosse (allure in canada)	Instrument panel cluster	●	●	●	●	●	●	T022

2009	Buick	Lacrosse (allure in canada)	Electronic brake control module	●	●	○	●	●	●	T014
2009	Buick	Lucerne	Transmission control module	●	●	○	●	●	○	
2009	Buick	Lucerne	Engine control module	●	●	●	●	●	●	T001
2009	Buick	Lucerne	Passenger presence system	●	●	●	●	○	●	T020
2009	Buick	Lucerne	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Buick	Lucerne	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Buick	Lucerne	Theft deterrent module	●	●	●	●	○	○	
2009	Buick	Lucerne	Radio	●	●	●	●	●	○	
2009	Buick	Lucerne	Digital radio receiver	●	●	●	●	●	○	
2009	Buick	Lucerne	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Buick	Lucerne	Veh direction alert alarm warn mod	●	●	●	●	●	○	
2009	Buick	Lucerne	Left side object detection module	●	●	●	●	●	○	
2009	Buick	Lucerne	Memory seat module	●	●	●	●	●	○	
2009	Buick	Lucerne	Park assist module	●	●	●	●	●	○	
2009	Buick	Lucerne	Right side object detection module	●	●	●	●	○	○	
2009	Buick	Lucerne	Instrument panel cluster	●	●	●	●	●	○	
2009	Buick	Lucerne	HVAC control module	●	●	●	●	●	○	
2009	Buick	Lucerne	Driver door switch	●	●	●	●	●	○	
2009	Buick	Lucerne	Passenger door switch	●	●	●	●	●	○	
2009	Buick	Lucerne	Body control module	●	●	●	●	●	●	T007 T005
2009	Buick	Lucerne	Electronic brake control module	●	●	●	●	●	●	T014
2009	Buick	Lucerne	Electronic suspension control	●	●	●	●	●	○	

2009	Buick	Others	Immobilizer	○	○	○	○	○	●	T016
2009	Buick	Others	Engine control module	●	●	●	●	●	○	
2009	Buick	Others	Transmission control module	●	●	●	●	●	○	
2009	Cadillac	CTS	Transmission control module	●	●	○	●	●	○	
2009	Cadillac	CTS	Engine control module	●	●	●	●	●	○	
2009	Cadillac	CTS	Transfer case control module	●	●	●	●	●	●	T001
2009	Cadillac	CTS	Fuel pump control module	●	●	●	●	●	●	T001
2009	Cadillac	CTS	Pedestrian impact detection module	●	●	●	●	●	●	T009
2009	Cadillac	CTS	Passenger presence system	●	●	●	●	●	○	
2009	Cadillac	CTS	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	●	T010
2009	Cadillac	CTS	Radio	●	●	●	●	●	●	T011
2009	Cadillac	CTS	TV antenna module	●	●	●	●	○	●	T012 T013
2009	Cadillac	CTS	Headlamp control module	●	●	●	●	●	○	
2009	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2009	Cadillac	CTS	Park assist module	●	●	●	●	●	○	
2009	Cadillac	CTS	Body control module	●	●	●	●	●	●	T007 T005
2009	Cadillac	CTS	HVAC control module	●	●	●	●	●	●	T008
2009	Cadillac	CTS	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2009	Cadillac	CTS	Driver door switch	●	●	●	●	●	○	
2009	Cadillac	CTS	Passenger door switch	●	●	●	●	●	○	

2009	Cadillac	CTS	Electronic brake control module	●	●	●	●	●	●	T014
2009	Cadillac	CTS	Parking brake control module	●	●	●	●	●	○	
2009	Cadillac	CTS	Electronic suspension control	●	●	○	●	●	○	
2009	Cadillac	DTS	Engine control module	●	●	●	●	●	●	T001
2009	Cadillac	DTS	Transmission control module	●	●	○	●	●	○	
2009	Cadillac	DTS	Passenger presence system	●	●	●	●	○	●	T020
2009	Cadillac	DTS	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Cadillac	DTS	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Cadillac	DTS	Theft deterrent module	●	●	●	●	○	○	
2009	Cadillac	DTS	Radio	●	●	●	●	●	○	
2009	Cadillac	DTS	TV antenna module	●	●	●	●	○	●	T012 T013
2009	Cadillac	DTS	Amplifier (bose)	●	●	●	●	●	○	
2009	Cadillac	DTS	Digital radio receiver	●	●	●	●	●	○	
2009	Cadillac	DTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Cadillac	DTS	Veh direction alert alarm warn mod	●	●	●	●	●	○	
2009	Cadillac	DTS	Driver position module	●	●	●	●	●	○	
2009	Cadillac	DTS	Inside rear view mirror module	●	●	●	○	○	○	
2009	Cadillac	DTS	Left side object detection module	●	●	●	●	●	○	
2009	Cadillac	DTS	Rear heated seat module	●	●	●	●	○	○	
2009	Cadillac	DTS	Right side object detection module	●	●	●	●	○	○	
2009	Cadillac	DTS	Park assist module	●	●	●	●	●	○	

2009	Cadillac	DTS	Instrument panel cluster	●	●	●	●	●	○	
2009	Cadillac	DTS	Body control module	●	●	●	●	●	●	T007 T005
2009	Cadillac	DTS	Distance sensing cruise control	●	●	●	●	●	○	
2009	Cadillac	DTS	HVAC control module	●	●	●	●	●	○	
2009	Cadillac	DTS	Driver door switch	●	●	●	●	●	●	T035
2009	Cadillac	DTS	Passenger door switch	●	●	●	●	●	●	T035
2009	Cadillac	DTS	Aux. HVAC control module	●	●	●	●	●	●	T035
2009	Cadillac	DTS	Electronic brake control module	●	●	●	●	●	●	T014
2009	Cadillac	DTS	Electronic suspension control	●	●	●	●	●	○	
2009	Cadillac	STS	Transmission control module	●	●	○	●	●	○	
2009	Cadillac	STS	Engine control module	●	●	●	●	●	●	T001
2009	Cadillac	STS	Passenger presence system	●	●	○	○	○	○	
2009	Cadillac	STS	Remote control door lock receiver	●	●	●	●	●	●	T021 T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T022
2009	Cadillac	STS	Supplemental inflatable restraint	●	●	●	●	●	●	T067
2009	Cadillac	STS	Amplifier (bose)	●	●	○	●	●	○	
2009	Cadillac	STS	Radio	●	●	●	●	○	●	T060 T033
2009	Cadillac	STS	TV antenna module	●	●	●	●	○	○	
2009	Cadillac	STS	Digital radio receiver	●	●	●	●	●	●	T024
2009	Cadillac	STS	Headlamp control module	●	●	●	●	●	○	
2009	Cadillac	STS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Cadillac	STS	Veh direction alert alarm warn mod	●	●	●	●	●	○	

2009	Cadillac	STS	Driver position module	●	●	●	●	●	○	
2009	Cadillac	STS	Left side object detection module	●	●	●	●	●	○	
2009	Cadillac	STS	Right side object detection module	●	●	●	●	○	○	
2009	Cadillac	STS	Steering column lock module	●	●	●	●	●	○	
2009	Cadillac	STS	Instrument panel cluster	●	●	●	●	●	●	T061 T062
2009	Cadillac	STS	Head up display	●	●	●	●	●	○	
2009	Cadillac	STS	Distance sensing cruise control	●	●	●	●	●	○	
2009	Cadillac	STS	HVAC control module	●	●	●	●	●	○	
2009	Cadillac	STS	Driver door module	●	●	●	●	●	●	T068
2009	Cadillac	STS	Driver door switch	●	●	●	●	○	○	
2009	Cadillac	STS	Instrument panel module	●	●	●	●	●	●	T059
2009	Cadillac	STS	Left rear door module	●	●	●	●	●	●	T068
2009	Cadillac	STS	Passenger door module	●	●	●	●	●	●	T068
2009	Cadillac	STS	Right rear door module	●	●	●	●	●	●	T068
2009	Cadillac	STS	Rear integration module	●	●	●	●	●	●	T021 T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T022
2009	Cadillac	STS	Navigation radio	●	●	●	●	●	●	T069
2009	Cadillac	STS	Electronic brake control module	●	●	●	●	●	●	T014
2009	Cadillac	STS	Electronic suspension control	●	●	●	●	●	○	
2009	Cadillac	STS	Vehicle stability control module	●	●	○	●	●	○	
2009	Cadillac	STS	Power steering control module	●	●	●	●	●	●	T071 T072
2009	Cadillac	XLR	Engine control module	●	●	●	●	●	●	T001

2009	Cadillac	XLR	Transmission control module	●	●	●	●	●	●	T001
2009	Cadillac	XLR	Exhaust flow control module	●	●	●	●	●	○	
2009	Cadillac	XLR	Passenger presence system	●	●	○	○	○	●	T020
2009	Cadillac	XLR	Remote control door lock receiver	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2009	Cadillac	XLR	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Cadillac	XLR	CD changer	●	●	●	○	○	○	
2009	Cadillac	XLR	Navigation radio	●	●	●	●	○	●	T033
2009	Cadillac	XLR	Vehicle comm. interface module	●	●	●	●	●	●	T002 T073 T003
2009	Cadillac	XLR	Amplifier (bose)	●	●	●	●	●	○	
2009	Cadillac	XLR	Digital radio receiver	●	●	●	●	○	●	T024
2009	Cadillac	XLR	Headlamp control module	●	●	●	●	●	○	
2009	Cadillac	XLR	Body control module	●	●	●	●	●	●	T023
2009	Cadillac	XLR	Driver position module	●	●	●	●	●	●	T030
2009	Cadillac	XLR	Folding top module	●	●	●	●	●	○	
2009	Cadillac	XLR	Steering column lock module	●	●	●	●	●	○	
2009	Cadillac	XLR	Instrument panel cluster	●	●	●	●	●	○	
2009	Cadillac	XLR	Head up display	●	●	●	●	●	○	
2009	Cadillac	XLR	Distance sensing cruise control	●	●	●	●	●	○	
2009	Cadillac	XLR	HVAC control module	●	●	●	●	●	●	T008
2009	Cadillac	XLR	Driver door module	●	●	●	●	●	○	
2009	Cadillac	XLR	Driver door switch	●	●	●	●	○	○	
2009	Cadillac	XLR	Passenger door module	●	●	●	●	●	○	
2009	Cadillac	XLR	Electronic brake control module	●	●	●	●	●	●	T014

2009	Cadillac	XLR	Electronic suspension control	●	●	●	●	●	○	
2009	Cadillac	SLS	Vehicle comm. interface module	●	●	●	●	●	●	T002
2009	Cadillac	SLS	Radio	●	●	●	●	●	○	
2009	Cadillac	SLS	Passenger presence system	●	●	○	○	○	○	
2009	Cadillac	SLS	Driver position module	●	●	●	●	●	○	
2009	Cadillac	SLS	Driver door module	●	●	●	●	●	○	
2009	Cadillac	SLS	Driver door switch	●	●	●	●	○	○	
2009	Cadillac	SLS	Headlamp control module	●	●	●	●	○	○	
2009	Cadillac	SLS	Instrument panel module	●	●	●	●	●	●	T059
2009	Cadillac	SLS	Left rear door module	●	●	●	●	●	●	T068
2009	Cadillac	SLS	Passenger door module	●	●	●	●	●	●	T068
2009	Cadillac	SLS	Rear integration module	●	●	●	●	●	○	
2009	Cadillac	SLS	Right rear door module	●	●	●	●	●	●	T068
2009	Cadillac	SLS	Supplemental inflatable restraint	●	●	●	●	●	●	T067
2009	Cadillac	SLS	HVAC control module	●	●	●	●	●	○	
2009	Cadillac	SLS	Instrument panel cluster	●	●	●	●	●	●	T088
2009	Cadillac	SLS	TV antenna module	●	●	●	●	○	○	
2009	Cadillac	SLS	Amplifier (bose)	●	●	○	●	●	○	
2009	Cadillac	SLS	Remote control door lock receiver	●	●	●	●	●	●	T021 T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066
2009	Cadillac	SLS	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Cadillac	SLS	Electronic brake control module	●	●	●	●	●	●	T014
2009	Cadillac	SLS	Electronic suspension control	●	●	●	●	●	○	

2009	Cadillac	SLS	Transmission control module	●	●	●	●	●	○	
2009	Cadillac	SLS	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Aveo	Engine control module	●	●	●	●	●	●	T015
2009	Chevrolet	Aveo	Transmission control module	●	●	●	●	●	●	T015
2009	Chevrolet	Aveo	Immobilizer	○	○	○	○	○	●	T016
2009	Chevrolet	Aveo	Supplemental inflatable restraint	●	●	●	●	●	●	T016
2009	Chevrolet	Aveo	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Aveo	Tire pressure monitor	●	●	●	●	●	●	T018 T019
2009	Chevrolet	Aveo	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Aveo	Instrument panel cluster	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Aveo	Radio	●	●	●	○	○	○	
2009	Chevrolet	Aveo	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Aveo	Passenger presence system	●	●	●	●	●	●	T045
2009	Chevrolet	Aveo	Engine control module	●	●	○	●	●	●	T001
2009	Chevrolet	Aveo	Transmission control module	●	●	●	●	●	●	T001
2009	Chevrolet	Aveo	Supplemental inflatable restraint	●	●	●	●	●	○	
2009	Chevrolet	Aveo	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Aveo	Immobilizer	○	○	○	○	○	●	T016
2009	Chevrolet	Aveo	Instrument panel cluster	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Aveo	Radio	●	●	●	○	○	○	
2009	Chevrolet	Aveo	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Aveo	Passenger presence system	●	●	●	●	●	●	T045

2009	Chevrolet	Aveo	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Aveo	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2009	Chevrolet	Chevy	Transmission control module	●	●	●	●	●	○	
2009	Chevrolet	Chevy	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Chevy	Immobilizer	●	●	●	●	○	●	T052 T053
2009	Chevrolet	Cobalt	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Cobalt	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Cobalt	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Cobalt	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Chevrolet	Cobalt	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Cobalt	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Cobalt	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Cobalt	Body control module	●	●	●	●	●	●	T023
2009	Chevrolet	Cobalt	Radio	●	●	●	●	●	○	
2009	Chevrolet	Cobalt	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Cobalt	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Cobalt	Passenger presence system	●	●	○	○	○	○	
2009	Chevrolet	Cobalt	Driver information center	●	●	●	●	●	○	
2009	Chevrolet	Cobalt	Electronic brake control module	●	●	●	●	●	○	
2009	Chevrolet	Cobalt	Power steering control module	●	●	●	●	●	○	
2009	Chevrolet	Corvette	Fuel pump control module	●	●	●	●	●	○	

2009	Chevrolet	Corvette	Exhaust flow control module	●	●	●	●	●	○	
2009	Chevrolet	Corvette	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Corvette	Transmission control module	●	●	●	●	●	●	T001
2009	Chevrolet	Corvette	Passenger presence system	●	●	○	○	○	●	T020
2009	Chevrolet	Corvette	Remote control door lock receiver	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2009	Chevrolet	Corvette	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Chevrolet	Corvette	CD changer	●	●	●	●	○	○	
2009	Chevrolet	Corvette	Radio	●	●	●	●	○	●	T032 T033
2009	Chevrolet	Corvette	Vehicle comm. interface module	●	●	●	●	●	●	T002 T073 T003
2009	Chevrolet	Corvette	Digital radio receiver	●	●	●	●	○	●	T024
2009	Chevrolet	Corvette	Body control module	●	●	●	●	●	●	T023
2009	Chevrolet	Corvette	Steering column lock module	●	●	●	●	●	○	
2009	Chevrolet	Corvette	Driver position module	●	●	●	●	●	●	T030
2009	Chevrolet	Corvette	Folding top module	●	●	●	●	●	○	
2009	Chevrolet	Corvette	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Corvette	Head up display	●	●	●	●	●	○	
2009	Chevrolet	Corvette	HVAC control module	●	●	●	●	●	●	T008 T031
2009	Chevrolet	Corvette	Driver door module	●	●	●	●	●	○	
2009	Chevrolet	Corvette	Driver door switch	●	●	●	●	○	○	
2009	Chevrolet	Corvette	Passenger door module	●	●	●	●	●	●	T020
2009	Chevrolet	Corvette	Navigation radio	●	●	●	●	●	●	T033
2009	Chevrolet	Corvette	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Corvette	Electronic brake control module	●	●	●	●	●	●	T014

2009	Chevrolet	Corvette	Electronic suspension control	●	●	●	●	●	○	
2009	Chevrolet	Epica	Transmission control module	●	●	●	●	●	○	
2009	Chevrolet	Epica	Engine control module	●	●	●	●	●	●	T017
2009	Chevrolet	Epica	Supplemental inflatable restraint	●	●	●	●	●	○	
2009	Chevrolet	Epica	ISU	●	●	●	●	●	○	
2009	Chevrolet	Epica	Electronic brake control module	●	●	●	●	●	●	T015
2009	Chevrolet	Impala	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Impala	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Impala	Passenger presence system	●	●	●	●	●	○	
2009	Chevrolet	Impala	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Impala	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Impala	Radio	●	●	●	●	●	○	
2009	Chevrolet	Impala	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Impala	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Impala	Heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Impala	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Impala	Body control module	●	●	●	●	●	●	T007 T005
2009	Chevrolet	Impala	HVAC control module	●	●	●	●	●	●	T008
2009	Chevrolet	Impala	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Malibu	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Malibu	Transmission control module	●	●	●	●	●	●	T001

2009	Chevrolet	Malibu	Passenger presence system	●	●	○	○	○	○	
2009	Chevrolet	Malibu	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Malibu	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Chevrolet	Malibu	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Malibu	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Malibu	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Malibu	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Malibu	Body control module	●	●	●	●	●	●	T008 T023
2009	Chevrolet	Malibu	Radio	●	●	●	●	●	●	T033
2009	Chevrolet	Malibu	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Malibu	HVAC control module	●	●	●	●	●	●	T055
2009	Chevrolet	Malibu	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Malibu	Power steering control module	●	●	●	●	●	●	T014
2009	Chevrolet	Malibu hybrid	Passenger presence system	●	●	○	○	○	○	
2009	Chevrolet	Malibu hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Malibu hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Chevrolet	Malibu hybrid	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Malibu hybrid	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Malibu hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Malibu hybrid	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Malibu hybrid	Body control module	●	●	●	●	●	●	T008 T023
2009	Chevrolet	Malibu hybrid	Radio	●	●	●	●	●	●	T033

2009	Chevrolet	Malibu hybrid	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Malibu hybrid	HVAC control module	●	●	●	●	●	●	T055
2009	Chevrolet	Malibu hybrid	Power steering control module	●	●	●	●	●	○	
2009	Chevrolet	Malibu hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Optra	Engine control module	●	●	●	●	●	●	T015
2009	Chevrolet	Optra	Transmission control module	●	●	●	●	●	●	T015
2009	Chevrolet	Optra	Immobilizer	○	○	○	○	○	●	T016
2009	Chevrolet	Optra	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2009	Chevrolet	Optra	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Optra - mexico	Engine control module	●	●	●	●	●	●	T015
2009	Chevrolet	Optra - mexico	Transmission control module	●	●	●	●	●	●	T015
2009	Chevrolet	Optra - mexico	Immobilizer	○	○	○	○	○	●	T016
2009	Chevrolet	Optra - mexico	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2009	Chevrolet	Optra - mexico	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Spark	Transmission control module	●	●	●	●	●	○	
2009	Chevrolet	Spark	Engine control module	●	●	●	●	●	●	T015
2009	Chevrolet	Spark	Supplemental inflatable restraint	●	●	●	●	○	○	
2009	Chevrolet	Spark	Immobilizer	○	○	○	○	○	●	T016
2009	Chevrolet	Spark	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Others	Immobilizer	○	○	○	○	○	●	T016
2009	Chevrolet	Others	Engine control module	●	●	○	●	●	●	T001
2009	Chevrolet	Others	Transmission control module	●	●	●	●	●	●	T001
2009	Chevrolet	Others	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003

2009	Chevrolet	Others	Supplemental inflatable restraint	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Others	Instrument panel cluster	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Others	Radio	●	●	●	○	○	○	
2009	Chevrolet	Others	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Others	Passenger presence system	●	●	●	●	●	●	T045
2009	Pontiac	G3	Engine control module	●	●	●	●	●	●	T001
2009	Pontiac	G3	Transmission control module	●	●	●	●	●	●	T001
2009	Pontiac	G3	Instrument panel cluster	●	●	●	●	●	○	
2009	Pontiac	G3	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Pontiac	G3	Radio	●	●	●	○	○	○	
2009	Pontiac	G3	Theft deterrent module	●	●	●	●	○	○	
2009	Pontiac	G3	Passenger presence system	●	●	●	●	○	●	T045
2009	Pontiac	G3	Supplemental inflatable restraint	●	●	●	●	●	●	T002 T003
2009	Pontiac	G3	Immobilizer	●	●	●	●	●	●	T016
2009	Pontiac	G3	Electronic brake control module	●	●	●	●	●	●	T014
2009	Pontiac	G3	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2009	Pontiac	G5	Transmission control module	●	●	○	●	●	○	
2009	Pontiac	G5	Engine control module	●	●	●	●	●	●	T001
2009	Pontiac	G5	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Pontiac	G5	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Pontiac	G5	Theft deterrent module	●	●	●	●	○	○	
2009	Pontiac	G5	Digital radio receiver	●	●	●	●	●	○	

2009	Pontiac	G5	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Pontiac	G5	Body control module	●	●	●	●	●	●	T023
2009	Pontiac	G5	Radio	●	●	●	●	●	○	
2009	Pontiac	G5	Personal audio link module	●	●	●	○	○	●	T036
2009	Pontiac	G5	Instrument panel cluster	●	●	●	●	●	○	
2009	Pontiac	G5	Passenger presence system	●	●	○	○	○	○	
2009	Pontiac	G5	Driver information center	●	●	●	●	●	○	
2009	Pontiac	G5	Electronic brake control module	●	●	●	●	●	○	
2009	Pontiac	G5	Power steering control module	●	●	●	●	●	○	
2009	Pontiac	G6	Engine control module	●	●	●	●	●	●	T001
2009	Pontiac	G6	Transmission control module	●	●	●	●	●	●	T001
2009	Pontiac	G6	Passenger presence system	●	●	○	○	○	○	
2009	Pontiac	G6	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Pontiac	G6	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Pontiac	G6	Theft deterrent module	●	●	●	●	○	○	
2009	Pontiac	G6	Digital radio receiver	●	●	●	●	●	○	
2009	Pontiac	G6	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Pontiac	G6	Folding top module	●	●	●	●	●	○	
2009	Pontiac	G6	Body control module	●	●	●	●	●	●	T008 T023
2009	Pontiac	G6	HVAC control module	●	●	●	●	●	○	
2009	Pontiac	G6	Radio	●	●	●	●	●	●	T033
2009	Pontiac	G6	Instrument panel cluster	●	●	●	●	●	○	

2009	Pontiac	G6	Personal audio link module	●	●	●	●	●	●	T036
2009	Pontiac	G6	Electronic brake control module	●	●	●	●	●	●	T014
2009	Pontiac	G6	Power steering control module	●	●	●	●	●	○	
2009	Pontiac	G8	Engine control module	●	●	●	●	●	○	
2009	Pontiac	G8	Transmission control module	●	●	●	●	●	●	T001
2009	Pontiac	G8	Digital radio receiver	●	●	●	●	●	○	
2009	Pontiac	G8	Body control module	●	●	●	●	●	●	T007 T005
2009	Pontiac	G8	Passenger presence system	●	●	●	●	○	●	T020
2009	Pontiac	G8	HVAC control module	●	●	●	●	●	○	
2009	Pontiac	G8	Instrument panel cluster	●	●	●	●	●	○	
2009	Pontiac	G8	Personal audio link module	●	●	●	○	○	●	T036
2009	Pontiac	G8	Radio	●	●	●	●	●	○	
2009	Pontiac	G8	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Pontiac	G8	Driver information display	●	●	●	●	●	●	T091
2009	Pontiac	G8	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Pontiac	G8	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Pontiac	G8	Electronic brake control module	●	●	●	●	●	●	T014
2009	Pontiac	Matiz	Transmission control module	●	●	●	●	●	○	
2009	Pontiac	Matiz	Engine control module	●	●	●	●	●	●	T015
2009	Pontiac	Matiz	Supplemental inflatable restraint	●	●	●	●	○	○	
2009	Pontiac	Matiz	Immobilizer	○	○	○	○	○	●	T016

2009	Pontiac	Matiz	Electronic brake control module	●	●	●	●	●	●	T014
2009	Pontiac	Solstice	Transmission control module	●	●	●	●	●	○	
2009	Pontiac	Solstice	Engine control module	●	●	●	●	●	●	T001
2009	Pontiac	Solstice	Passenger presence system	●	●	○	○	○	○	
2009	Pontiac	Solstice	Remote control door lock receiver	●	●	●	●	●	●	T021 T029 T022
2009	Pontiac	Solstice	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Pontiac	Solstice	Theft deterrent module	●	●	●	●	○	○	
2009	Pontiac	Solstice	Radio	●	●	●	●	●	●	T033
2009	Pontiac	Solstice	Personal audio link module	●	●	●	○	○	●	T036
2009	Pontiac	Solstice	Digital radio receiver	●	●	●	●	●	○	
2009	Pontiac	Solstice	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Pontiac	Solstice	Body control module	●	●	●	●	●	●	T023
2009	Pontiac	Solstice	Instrument panel cluster	●	●	●	●	●	○	
2009	Pontiac	Solstice	Electronic brake control module	●	●	●	●	●	○	
2009	Pontiac	Vibe - AWD	Powertrain control module	●	●	●	●	●	○	
2009	Pontiac	Vibe - AWD	Engine control module	●	●	●	●	●	○	
2009	Pontiac	Vibe - AWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2009	Pontiac	Vibe - AWD	Immobilizer	●	●	○	●	○	●	T076
2009	Pontiac	Vibe - AWD	Theft deterrent module	○	○	○	●	●	○	
2009	Pontiac	Vibe - AWD	Body control module	●	●	○	●	●	○	
2009	Pontiac	Vibe - AWD	Serial data gateway (if equipped)	○	○	○	●	○	○	
2009	Pontiac	Vibe - AWD	HVAC control module	●	●	○	●	●	○	

2009	Pontiac	Vibe - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Pontiac	Vibe - AWD	Digital radio receiver	●	●	●	●	○	○	
2009	Pontiac	Vibe - AWD	Radio	●	●	●	●	●	○	
2009	Pontiac	Vibe - AWD	Instrument panel cluster	●	●	○	●	●	●	T077
2009	Pontiac	Vibe - AWD	Veh. interface module	●	●	●	●	●	●	T077
2009	Pontiac	Vibe - AWD	Electronic brake control module	●	●	○	●	●	●	T014
2009	Pontiac	Vibe - AWD	Tire pressure monitor	○	○	●	●	○	●	T078
2009	Pontiac	Vibe - AWD	Power steering control module	●	●	○	●	○	●	T044
2009	Pontiac	Vibe - FWD	Powertrain control module	●	●	●	●	●	○	
2009	Pontiac	Vibe - FWD	Engine control module	●	●	●	●	●	○	
2009	Pontiac	Vibe - FWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2009	Pontiac	Vibe - FWD	Immobilizer	●	●	○	●	○	●	T076
2009	Pontiac	Vibe - FWD	Theft deterrent module	○	○	○	●	●	○	
2009	Pontiac	Vibe - FWD	Body control module	●	●	○	●	●	○	
2009	Pontiac	Vibe - FWD	Serial data gateway (if equipped)	○	○	○	●	○	○	
2009	Pontiac	Vibe - FWD	HVAC control module	●	●	○	●	●	○	
2009	Pontiac	Vibe - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Pontiac	Vibe - FWD	Digital radio receiver	●	●	●	●	○	○	
2009	Pontiac	Vibe - FWD	Radio	●	●	●	●	●	○	
2009	Pontiac	Vibe - FWD	Instrument panel cluster	●	●	○	●	●	●	T077
2009	Pontiac	Vibe - FWD	Veh. interface module	●	●	●	●	●	●	T077
2009	Pontiac	Vibe - FWD	Electronic brake control module	●	●	○	●	●	●	T014
2009	Pontiac	Vibe - FWD	Tire pressure monitor	○	○	●	●	○	●	T078
2009	Pontiac	Vibe - FWD	Power steering control module	●	●	○	●	○	●	T044

2009	Pontiac	Wave	Engine control module	●	●	●	●	●	●	T001
2009	Pontiac	Wave	Transmission control module	●	●	●	●	●	●	T001
2009	Pontiac	Wave	Instrument panel cluster	●	●	●	●	●	○	
2009	Pontiac	Wave	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Pontiac	Wave	Radio	●	●	●	○	○	○	
2009	Pontiac	Wave	Theft deterrent module	●	●	●	●	○	○	
2009	Pontiac	Wave	Passenger presence system	●	●	●	●	○	●	T045
2009	Pontiac	Wave	Supplemental inflatable restraint	●	●	●	●	●	●	T002 T003
2009	Pontiac	Wave	Immobilizer	●	●	●	●	●	●	T016
2009	Pontiac	Wave	Electronic brake control module	●	●	●	●	●	●	T014
2009	Pontiac	Wave	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2009	Saturn	AURA	Engine control module	●	●	●	●	●	●	T001
2009	Saturn	AURA	Transmission control module	●	●	●	●	●	●	T001
2009	Saturn	AURA	Passenger presence system	●	●	○	○	○	○	
2009	Saturn	AURA	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Saturn	AURA	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Saturn	AURA	Theft deterrent module	●	●	●	●	○	○	
2009	Saturn	AURA	Digital radio receiver	●	●	●	●	●	○	
2009	Saturn	AURA	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Saturn	AURA	Instrument panel cluster	●	●	●	●	●	○	
2009	Saturn	AURA	Body control module	●	●	●	●	●	●	T008 T023
2009	Saturn	AURA	Radio	●	●	●	●	●	●	T033

2009	Saturn	Sky	Transmission control module	●	●	●	●	●	○	
2009	Saturn	Sky	Engine control module	●	●	●	●	●	●	T001
2009	Saturn	Sky	Passenger presence system	●	●	○	○	○	○	
2009	Saturn	Sky	Remote control door lock receiver	●	●	●	●	●	●	T021 T029 T022
2009	Saturn	Sky	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Saturn	Sky	Theft deterrent module	●	●	●	●	○	○	
2009	Saturn	Sky	Radio	●	●	●	●	●	●	T033
2009	Saturn	Sky	Personal audio link module	●	●	●	○	○	●	T036
2009	Saturn	Sky	Digital radio receiver	●	●	●	●	●	○	
2009	Saturn	Sky	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Saturn	Sky	Body control module	●	●	●	●	●	●	T023
2009	Saturn	Sky	Instrument panel cluster	●	●	●	●	●	○	
2009	Saturn	Sky	Electronic brake control module	●	●	●	●	●	○	
2009	Daewoo	Damas	Transmission control module	●	●	●	●	●	○	
2009	Daewoo	Damas	Engine control module	●	●	●	●	●	●	T015
2009	Daewoo	Labo	Transmission control module	●	●	●	●	●	○	
2009	Daewoo	Labo	Engine control module	●	●	●	●	●	●	T015
2009	Daewoo	Others	Engine control module	●	●	●	●	●	●	T015
2009	Daewoo	Others	Supplemental inflatable restraint	●	●	●	●	○	○	
2009	Daewoo	Others	Immobilizer	○	○	○	○	○	●	T016
2009	Daewoo	Others	Electronic brake control module	●	●	●	●	●	●	T014
2009	Daewoo	Others	Transmission control module	●	●	●	●	●	●	T001

2009	Daewoo	Others	ISU	●	●	●	●	●	○	
2009	Daewoo	Kalos	Engine control module	●	●	●	●	●	●	T015
2009	Daewoo	Kalos	Transmission control module	●	●	●	●	●	●	T015
2009	Daewoo	Kalos	Immobilizer	○	○	○	○	○	●	T016
2009	Daewoo	Kalos	Supplemental inflatable restraint	●	●	●	●	●	●	T016
2009	Daewoo	Gentra	Engine control module	●	●	●	●	●	●	T001
2009	Daewoo	Gentra	Transmission control module	●	●	●	●	●	●	T001
2009	Daewoo	Gentra	Immobilizer	○	○	○	○	○	●	T016
2009	Daewoo	Gentra	Supplemental inflatable restraint	●	●	●	●	●	●	T016
2009	Buick	Enclave - AWD	Transmission control module	●	●	○	●	●	○	
2009	Buick	Enclave - AWD	Engine control module	●	●	●	●	●	○	
2009	Buick	Enclave - AWD	Passenger presence system	●	●	●	●	●	○	
2009	Buick	Enclave - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Buick	Enclave - AWD	Rollover sensor	●	●	●	●	○	●	T049
2009	Buick	Enclave - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Buick	Enclave - AWD	Theft deterrent module	●	●	●	●	○	○	
2009	Buick	Enclave - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2009	Buick	Enclave - AWD	Radio	●	●	●	●	●	○	
2009	Buick	Enclave - AWD	Digital radio receiver	●	●	●	●	●	○	
2009	Buick	Enclave - AWD	Headlamp control module	●	●	●	○	○	○	
2009	Buick	Enclave - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Buick	Enclave - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Buick	Enclave - AWD	Memory seat module	●	●	●	●	●	○	
2009	Buick	Enclave - AWD	Park assist module	●	●	●	●	●	○	

2009	Buick	Enclave - AWD	Liftgate module	●	●	●	●	●	○	
2009	Buick	Enclave - AWD	Instrument panel cluster	●	●	●	●	●	○	
2009	Buick	Enclave - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Buick	Enclave - AWD	Body control module	●	●	●	●	●	●	T007 T005
2009	Buick	Enclave - AWD	Driver door switch	●	●	●	●	●	●	T035
2009	Buick	Enclave - AWD	Passenger door switch	●	●	●	●	●	●	T035
2009	Buick	Enclave - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Buick	Enclave - AWD	Rear drive system	●	●	●	●	●	●	T038
2009	Buick	Enclave - FWD	Transmission control module	●	●	○	●	●	○	
2009	Buick	Enclave - FWD	Engine control module	●	●	●	●	●	○	
2009	Buick	Enclave - FWD	Passenger presence system	●	●	●	●	●	○	
2009	Buick	Enclave - FWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Buick	Enclave - FWD	Rollover sensor	●	●	●	●	○	●	T049
2009	Buick	Enclave - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Buick	Enclave - FWD	Theft deterrent module	●	●	●	●	○	○	
2009	Buick	Enclave - FWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2009	Buick	Enclave - FWD	Radio	●	●	●	●	●	○	
2009	Buick	Enclave - FWD	Digital radio receiver	●	●	●	●	●	○	
2009	Buick	Enclave - FWD	Headlamp control module	●	●	●	○	○	○	
2009	Buick	Enclave - FWD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Buick	Enclave - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Buick	Enclave - FWD	Memory seat module	●	●	●	●	●	○	
2009	Buick	Enclave - FWD	Park assist module	●	●	●	●	●	○	
2009	Buick	Enclave - FWD	Liftgate module	●	●	●	●	●	○	
2009	Buick	Enclave - FWD	Instrument panel cluster	●	●	●	●	●	○	

2009	Buick	Enclave - FWD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Buick	Enclave - FWD	Body control module	●	●	●	●	●	●	T007 T005
2009	Buick	Enclave - FWD	Driver door switch	●	●	●	●	●	●	T035
2009	Buick	Enclave - FWD	Passenger door switch	●	●	●	●	●	●	T035
2009	Buick	Enclave - FWD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Buick	Enclave - FWD	Rear drive system	●	●	●	●	●	●	T038
2009	Cadillac	Escalade	Transmission control module	●	●	○	●	●	○	
2009	Cadillac	Escalade	Engine control module	●	●	●	●	●	●	T001
2009	Cadillac	Escalade	Fuel pump control module	●	●	●	●	●	○	
2009	Cadillac	Escalade	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Cadillac	Escalade	Rollover sensor	●	●	●	●	○	●	T049
2009	Cadillac	Escalade	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Cadillac	Escalade	Theft deterrent module	●	●	●	●	○	○	
2009	Cadillac	Escalade	Digital radio receiver	●	●	●	●	●	○	
2009	Cadillac	Escalade	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Cadillac	Escalade	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Cadillac	Escalade	Inside rear view mirror module	●	●	●	○	○	○	
2009	Cadillac	Escalade	Rear heated seat module	●	●	●	●	○	○	
2009	Cadillac	Escalade	Park assist module	●	●	●	●	●	○	
2009	Cadillac	Escalade	Personal audio link module	●	●	●	○	○	●	T036
2009	Cadillac	Escalade	Radio	●	●	●	●	●	○	
2009	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2009	Cadillac	Escalade	Left side object detection module	●	●	●	●	●	○	

2009	Cadillac	Escalade	Inside rear view mirror module	●	●	●	○	○	○	
2009	Cadillac	Escalade	Rear heated seat module	●	●	●	●	○	○	
2009	Cadillac	Escalade	Park assist module	●	●	●	●	●	○	
2009	Cadillac	Escalade	Personal audio link module	●	●	●	○	○	●	T036
2009	Cadillac	Escalade	Radio	●	●	●	●	●	○	
2009	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2009	Cadillac	Escalade	Left side object detection module	●	●	●	●	●	○	
2009	Cadillac	Escalade	Right side object detection module	●	●	●	●	○	○	
2009	Cadillac	Escalade	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Cadillac	Escalade	Assist step controller	●	●	●	●	●	●	T039
2009	Cadillac	Escalade	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Cadillac	Escalade	Liftgate module	●	●	●	●	●	○	
2009	Cadillac	Escalade	Body control module	●	●	●	●	●	●	T005
2009	Cadillac	Escalade	Memory seat module	●	●	●	●	●	○	
2009	Cadillac	Escalade	Passenger presence system	●	●	●	●	○	○	
2009	Cadillac	Escalade	Amplifier (bose)	●	●	●	●	●	●	T037
2009	Cadillac	Escalade	Driver door switch	●	●	●	●	●	○	
2009	Cadillac	Escalade	Passenger door switch	●	●	●	●	●	○	
2009	Cadillac	Escalade	Electronic suspension control	●	●	●	●	●	●	T040
2009	Cadillac	Escalade	Trailer brake control module	●	●	●	●	●	○	
2009	Cadillac	Escalade	Electronic brake control module	●	●	●	●	●	●	T014
2009	Cadillac	Escalade hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Cadillac	Escalade hybrid	Rollover sensor	●	●	●	●	○	●	T049

2009	Cadillac	Escalade hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Cadillac	Escalade hybrid	Theft deterrent module	●	●	●	●	○	○	
2009	Cadillac	Escalade hybrid	Digital radio receiver	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Inside rear view mirror module	●	●	●	○	○	○	
2009	Cadillac	Escalade hybrid	Rear heated seat module	●	●	●	●	○	○	
2009	Cadillac	Escalade hybrid	Park assist module	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Personal audio link module	●	●	●	○	○	●	T036
2009	Cadillac	Escalade hybrid	Radio	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Instrument panel cluster	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Left side object detection module	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Right side object detection module	●	●	●	●	○	○	
2009	Cadillac	Escalade hybrid	Serial data gateway module	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	A/C compressor control module	●	●	●	●	○	○	
2009	Cadillac	Escalade hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Cadillac	Escalade hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Cadillac	Escalade hybrid	Liftgate module	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Body control module	●	●	●	●	●	●	T005
2009	Cadillac	Escalade hybrid	Passenger presence system	●	●	●	●	○	○	
2009	Cadillac	Escalade hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Cadillac	Escalade hybrid	Amplifier (bose)	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Memory seat module	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Driver door switch	●	●	●	●	●	○	

2009	Cadillac	Escalade hybrid	Passenger door switch	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2009	Cadillac	Escalade hybrid	Trailer brake control module	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2009	Cadillac	Escalade hybrid	Power steering control module	●	●	●	●	●	●	T044
2009	Cadillac	Escalade hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Cadillac	Escalade hybrid	Rollover sensor	●	●	●	●	○	●	T049
2009	Cadillac	Escalade hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Cadillac	Escalade hybrid	Theft deterrent module	●	●	●	●	○	○	
2009	Cadillac	Escalade hybrid	Digital radio receiver	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Inside rear view mirror module	●	●	●	○	○	○	
2009	Cadillac	Escalade hybrid	Rear heated seat module	●	●	●	●	○	○	
2009	Cadillac	Escalade hybrid	Park assist module	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Personal audio link module	●	●	●	○	○	●	T036
2009	Cadillac	Escalade hybrid	Radio	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Instrument panel cluster	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Left side object detection module	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Right side object detection module	●	●	●	●	○	○	
2009	Cadillac	Escalade hybrid	Serial data gateway module	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	A/C compressor control module	●	●	●	●	○	○	

2009	Cadillac	Escalade hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Cadillac	Escalade hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Cadillac	Escalade hybrid	Liftgate module	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Body control module	●	●	●	●	●	●	T005
2009	Cadillac	Escalade hybrid	Passenger presence system	●	●	●	●	○	○	
2009	Cadillac	Escalade hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Cadillac	Escalade hybrid	Amplifier (bose)	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Memory seat module	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Driver door switch	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Passenger door switch	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2009	Cadillac	Escalade hybrid	Trailer brake control module	●	●	●	●	●	○	
2009	Cadillac	Escalade hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2009	Cadillac	Escalade hybrid	Power steering control module	●	●	●	●	●	●	T044
2009	Cadillac	SRX	Engine control module	●	●	●	●	●	●	T001
2009	Cadillac	SRX	Transmission control module	●	●	●	●	●	○	
2009	Cadillac	SRX	Passenger presence system	●	●	●	●	○	●	T045
2009	Cadillac	SRX	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Cadillac	SRX	Rollover sensor	●	●	●	●	○	●	T049
2009	Cadillac	SRX	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Cadillac	SRX	Theft deterrent module	●	●	●	●	○	○	
2009	Cadillac	SRX	TV antenna module	●	●	●	●	○	●	T012 T013
2009	Cadillac	SRX	Radio	●	●	●	●	●	○	
2009	Cadillac	SRX	Amplifier (bose)	●	●	●	●	●	○	

2009	Cadillac	SRX	Digital radio receiver	●	●	●	●	●	○	
2009	Cadillac	SRX	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2009	Cadillac	SRX	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Cadillac	SRX	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Cadillac	SRX	Memory seat module	●	●	●	●	●	○	
2009	Cadillac	SRX	Rear seat module	●	●	●	●	●	○	
2009	Cadillac	SRX	Park assist module	●	●	●	●	●	○	
2009	Cadillac	SRX	Instrument panel cluster	●	●	●	●	●	○	
2009	Cadillac	SRX	Body control module	●	●	●	●	●	●	T007 T005
2009	Cadillac	SRX	HVAC control module	●	●	●	●	●	○	
2009	Cadillac	SRX	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Cadillac	SRX	Driver door switch	●	●	●	●	●	●	T035
2009	Cadillac	SRX	Passenger door switch	●	●	●	●	●	●	T035
2009	Cadillac	SRX	Liftgate module	●	●	●	●	●	○	
2009	Cadillac	SRX	Electronic brake control module	●	●	●	●	●	●	T014
2009	Cadillac	SRX	Electronic suspension control	●	●	○	●	●	○	
2009	Cadillac	Hearse	Engine control module	●	●	●	●	●	●	T001
2009	Cadillac	Hearse	Transmission control module	●	●	○	●	●	○	
2009	Cadillac	Hearse	Radio	●	●	●	●	●	○	
2009	Cadillac	Hearse	Passenger presence system	●	●	●	●	○	●	T020
2009	Cadillac	Hearse	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Cadillac	Hearse	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Cadillac	Hearse	Theft deterrent module	●	●	●	●	○	○	
2009	Cadillac	Hearse	Amplifier (bose)	●	●	●	●	●	○	
2009	Cadillac	Hearse	Digital radio receiver	●	●	●	●	●	○	

2009	Cadillac	Hearse	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Cadillac	Hearse	Driver position module	●	●	●	●	●	○	
2009	Cadillac	Hearse	Rear heated seat module	●	●	●	●	○	○	
2009	Cadillac	Hearse	Body control module	●	●	●	●	●	●	T007 T005
2009	Cadillac	Hearse	Instrument panel cluster	●	●	●	●	●	○	
2009	Cadillac	Hearse	HVAC control module	●	●	●	●	●	○	
2009	Cadillac	Hearse	Driver door switch	●	●	●	●	●	○	
2009	Cadillac	Hearse	Passenger door switch	●	●	●	●	●	○	
2009	Cadillac	Hearse	Air suspension control module	●	●	●	●	●	○	
2009	Cadillac	Hearse	Electronic brake control module	●	●	●	●	○	●	T014
2009	Cadillac	Limousine	Engine control module	●	●	●	●	●	●	T001
2009	Cadillac	Limousine	Transmission control module	●	●	○	●	●	○	
2009	Cadillac	Limousine	Radio	●	●	●	●	●	○	
2009	Cadillac	Limousine	Passenger presence system	●	●	●	●	○	●	T020
2009	Cadillac	Limousine	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Cadillac	Limousine	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Cadillac	Limousine	Theft deterrent module	●	●	●	●	○	○	
2009	Cadillac	Limousine	Amplifier (bose)	●	●	●	●	●	○	
2009	Cadillac	Limousine	Digital radio receiver	●	●	●	●	●	○	
2009	Cadillac	Limousine	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Cadillac	Limousine	Driver position module	●	●	●	●	●	○	
2009	Cadillac	Limousine	Rear heated seat module	●	●	●	●	○	○	
2009	Cadillac	Limousine	Body control module	●	●	●	●	●	●	T007 T005

2009	Cadillac	Limousine	Instrument panel cluster	●	●	●	●	●	○	
2009	Cadillac	Limousine	HVAC control module	●	●	●	●	●	○	
2009	Cadillac	Limousine	Aux. HVAC control module	○	○	●	●	●	○	
2009	Cadillac	Limousine	Driver door switch	●	●	●	●	●	○	
2009	Cadillac	Limousine	Passenger door switch	●	●	●	●	●	○	
2009	Cadillac	Limousine	Air suspension control module	●	●	●	●	●	○	
2009	Cadillac	Limousine	Electronic brake control module	●	●	●	●	○	●	T014
2009	Chevrolet	Avalanche - 2WD	Fuel pump control module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Avalanche - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Avalanche - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Avalanche - 2WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Avalanche - 2WD	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Avalanche - 2WD	Radio	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	

2009	Chevrolet	Avalanche - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Avalanche - 2WD	Assist step controller	●	●	●	●	●	●	T039
2009	Chevrolet	Avalanche - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Avalanche - 2WD	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Avalanche - 2WD	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Avalanche - 2WD	Fuel pump control module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Avalanche - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Avalanche - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Avalanche - 2WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Memory seat module	●	●	●	●	●	○	

2009	Chevrolet	Avalanche - 2WD	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Avalanche - 2WD	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Avalanche - 2WD	Radio	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Avalanche - 2WD	Assist step controller	●	●	●	●	●	●	T039
2009	Chevrolet	Avalanche - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Avalanche - 2WD	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Avalanche - 2WD	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Avalanche - 4WD	Fuel pump control module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Avalanche - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Avalanche - 4WD	Rollover sensor	●	●	●	●	○	●	T049

2009	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Avalanche - 4WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Avalanche - 4WD	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Avalanche - 4WD	Radio	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Avalanche - 4WD	Assist step controller	●	●	●	●	●	●	T039
2009	Chevrolet	Avalanche - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Avalanche - 4WD	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Avalanche - 4WD	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001

2009	Chevrolet	Avalanche - 4WD	Fuel pump control module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Avalanche - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Avalanche - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Avalanche - 4WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Avalanche - 4WD	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Avalanche - 4WD	Radio	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Avalanche - 4WD	Assist step controller	●	●	●	●	●	●	T039
2009	Chevrolet	Avalanche - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Avalanche - 4WD	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	●	T021 T022

2009	Chevrolet	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Avalanche - 4WD	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Captiva	Transmission control module	●	●	●	●	●	○	
2009	Chevrolet	Captiva	Engine control module	●	●	●	●	●	●	T017
2009	Chevrolet	Captiva	Rear drive system	●	●	●	●	●	●	T038
2009	Chevrolet	Captiva	HVAC control module	●	●	●	○	●	○	
2009	Chevrolet	Captiva	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Captiva	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Captiva	Body control module (aux.)	●	●	●	●	●	○	
2009	Chevrolet	Captiva	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Captiva	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Captiva	Theft deterrent module	●	●	●	●	●	●	T005
2009	Chevrolet	Captiva	Electronic brake control module	●	●	●	●	●	○	
2009	Chevrolet	Captiva sport	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Captiva sport	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Captiva sport	Rear drive system	●	●	●	●	●	●	T038
2009	Chevrolet	Captiva sport	Radio	●	●	●	●	●	○	
2009	Chevrolet	Captiva sport	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Captiva sport	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Captiva sport	Theft deterrent module	●	●	●	●	○	○	

2009	Chevrolet	Captiva sport	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Captiva sport	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Captiva sport	HVAC control module	●	●	●	●	●	●	T008
2009	Chevrolet	Captiva sport	Passenger presence system	●	●	●	●	○	●	T045
2009	Chevrolet	Captiva sport	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Captiva sport	Electronic brake control module	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Cheyenne - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2009	Chevrolet	Cheyenne - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Cheyenne - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Cheyenne - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Cheyenne - 2WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Cheyenne - 2WD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Cheyenne - 2WD	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Cheyenne - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Cheyenne - 2WD	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Passenger presence system	●	●	●	●	○	○	

2009	Chevrolet	Cheyenne - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Cheyenne - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Cheyenne - 2WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Cheyenne - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2009	Chevrolet	Cheyenne - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Cheyenne - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Cheyenne - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Cheyenne - 2WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Cheyenne - 2WD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Cheyenne - 2WD	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Cheyenne - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Cheyenne - 2WD	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Cheyenne - 2WD	Amplifier (bose)	●	●	●	●	●	○	

2009	Chevrolet	Cheyenne - 2WD	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Cheyenne - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Cheyenne - 4WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Cheyenne - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2009	Chevrolet	Cheyenne - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Cheyenne - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Cheyenne - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Cheyenne - 4WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Cheyenne - 4WD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Cheyenne - 4WD	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Cheyenne - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Cheyenne - 4WD	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Cheyenne - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Trailer brake control module	●	●	●	●	●	○	

2009	Chevrolet	Cheyenne - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Cheyenne - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Cheyenne - 4WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Cheyenne - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2009	Chevrolet	Cheyenne - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Cheyenne - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Cheyenne - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Cheyenne - 4WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Cheyenne - 4WD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Cheyenne - 4WD	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Cheyenne - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Cheyenne - 4WD	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Cheyenne - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Cheyenne - 4WD	Electronic brake control module	●	●	●	●	●	●	T014

2009	Chevrolet	Cheyenne - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Colorado	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Colorado	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Colorado	Fuel pump control module	●	●	●	●	●	●	T001
2009	Chevrolet	Colorado	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Chevrolet	Colorado	Theft deterrent module	●	●	●	●	○	●	T057
2009	Chevrolet	Colorado	Radio	●	●	●	●	○	○	
2009	Chevrolet	Colorado	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	Chevrolet	Colorado	Digital radio receiver	●	●	●	●	●	●	T024
2009	Chevrolet	Colorado	Body control module	●	●	●	●	●	●	T058 T022
2009	Chevrolet	Colorado	Generator battery control module	●	●	●	●	●	○	
2009	Chevrolet	Colorado	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Colorado	Passenger presence system	●	●	●	●	●	●	T020
2009	Chevrolet	Colorado	Electronic brake control module	●	●	●	●	●	●	T023
2009	Chevrolet	Colorado	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Colorado	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Colorado	Fuel pump control module	●	●	●	●	●	●	T001
2009	Chevrolet	Colorado	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Chevrolet	Colorado	Theft deterrent module	●	●	●	●	○	●	T057
2009	Chevrolet	Colorado	Radio	●	●	●	●	○	○	
2009	Chevrolet	Colorado	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	Chevrolet	Colorado	Digital radio receiver	●	●	●	●	●	●	T024

2009	Chevrolet	Colorado	Body control module	●	●	●	●	●	●	T058 T022
2009	Chevrolet	Colorado	Generator battery control module	●	●	●	●	●	○	
2009	Chevrolet	Colorado	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Colorado	Passenger presence system	●	●	●	●	●	●	T020
2009	Chevrolet	Colorado	Electronic brake control module	●	●	●	●	●	●	T023
2009	Chevrolet	Equinox	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Equinox	Engine control module	●	●	●	●	●	○	
2009	Chevrolet	Equinox	Rear drive system	●	●	●	●	●	●	T038
2009	Chevrolet	Equinox	Radio	●	●	●	●	●	○	
2009	Chevrolet	Equinox	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Equinox	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T093
2009	Chevrolet	Equinox	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Equinox	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Equinox	Body control module	●	●	●	●	●	●	T007 T005
2009	Chevrolet	Equinox	Passenger presence system	●	●	●	●	○	●	T045
2009	Chevrolet	Equinox	Heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Equinox	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Equinox	HVAC control module	●	●	●	●	●	●	T008
2009	Chevrolet	Equinox	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Equinox	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Equinox	Power steering control module	●	●	○	●	○	○	
2009	Chevrolet	Equinox	Electronic brake control module	●	●	●	●	●	○	

2009	Chevrolet	Express	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2009	Chevrolet	Express	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2009	Chevrolet	Express	Radio	●	●	●	●	●	○	
2009	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Express	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Express	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T045
2009	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Express	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2009	Chevrolet	Express	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2009	Chevrolet	Express	Radio	●	●	●	●	●	○	
2009	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Express	Theft deterrent module	●	●	●	●	○	○	

2009	Chevrolet	Express	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T045
2009	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Express	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2009	Chevrolet	Express	Radio	●	●	●	●	●	○	
2009	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Express	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Express	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T045
2009	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Express	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Express	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Express	Fuel pump control module	●	●	●	●	●	●	T001
2009	Chevrolet	Express	Radio	●	●	●	●	●	○	
2009	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Express	Rollover sensor	●	●	●	●	○	●	T049

2009	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Express	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Express	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Express	Passenger presence system	●	●	●	●	○	●	T045
2009	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	HHR	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	HHR	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	HHR	Radio	●	●	●	●	●	○	
2009	Chevrolet	HHR	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	HHR	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	HHR	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Chevrolet	HHR	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	HHR	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	HHR	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	HHR	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Chevrolet	HHR	Body control module	●	●	●	●	●	●	T023
2009	Chevrolet	HHR	Passenger presence system	●	●	○	○	○	○	
2009	Chevrolet	HHR	Driver information center	●	●	●	●	●	○	
2009	Chevrolet	HHR	Electronic brake control module	●	●	●	●	●	○	
2009	Chevrolet	HHR	Power steering control module	●	●	●	●	●	○	

2009	Chevrolet	HHR panel	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	HHR panel	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	HHR panel	Radio	●	●	●	●	●	○	
2009	Chevrolet	HHR panel	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	HHR panel	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	HHR panel	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Chevrolet	HHR panel	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	HHR panel	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	HHR panel	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Chevrolet	HHR panel	Body control module	●	●	●	●	●	●	T023
2009	Chevrolet	HHR panel	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	HHR panel	Passenger presence system	●	●	○	○	○	○	
2009	Chevrolet	HHR panel	Driver information center	●	●	●	●	●	○	
2009	Chevrolet	HHR panel	Electronic brake control module	●	●	●	●	●	○	
2009	Chevrolet	HHR panel	Power steering control module	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Silverado	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Silverado	Fuel pump control module	●	●	●	●	●	●	T001
2009	Chevrolet	Silverado	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Silverado	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2009	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Silverado	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Silverado	Radio	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Silverado	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Silverado	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Silverado	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Silverado	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Silverado	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Silverado	Engine control module	●	●	●	●	●	●	T001

2009	Chevrolet	Silverado	Fuel pump control module	●	●	●	●	●	●	T001
2009	Chevrolet	Silverado	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Silverado	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Silverado	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Silverado	Radio	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Silverado	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Silverado	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	○	
2009	Chevrolet	Silverado	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Silverado	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Silverado	Trailer brake control module	●	●	●	●	●	○	

2009	Chevrolet	Silverado	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Silverado	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Silverado hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Silverado hybrid	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Silverado hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Silverado hybrid	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Silverado hybrid	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Silverado hybrid	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Silverado hybrid	Radio	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Serial data gateway module	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	A/C compressor control module	●	●	●	●	○	○	
2009	Chevrolet	Silverado hybrid	HVAC control module	●	●	●	●	●	●	T008 T034

2009	Chevrolet	Silverado hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Silverado hybrid	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Silverado hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Silverado hybrid	Amplifier (bose)	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Silverado hybrid	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2009	Chevrolet	Silverado hybrid	Power steering control module	●	●	●	●	●	●	T044
2009	Chevrolet	Silverado hybrid	Fuel pump control module	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Silverado hybrid	Accessory power module	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Silverado hybrid	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Silverado hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2009	Chevrolet	Silverado hybrid	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Silverado hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Silverado hybrid	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Silverado hybrid	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Silverado hybrid	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Silverado hybrid	Radio	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Serial data gateway module	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	A/C compressor control module	●	●	●	●	○	○	
2009	Chevrolet	Silverado hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Silverado hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Silverado hybrid	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Passenger door switch	●	●	●	●	●	○	

2009	Chevrolet	Silverado hybrid	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Silverado hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Silverado hybrid	Amplifier (bose)	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Silverado hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Silverado hybrid	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2009	Chevrolet	Silverado hybrid	Power steering control module	●	●	●	●	●	●	T044
2009	Chevrolet	Silverado hybrid	Fuel pump control module	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Silverado hybrid	Accessory power module	●	●	●	●	●	○	
2009	Chevrolet	Silverado hybrid	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Silverado hybrid	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Suburban - 2WD	Fuel pump control module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Suburban - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Suburban - 2WD	Rollover sensor	●	●	●	●	○	●	T049

2009	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Suburban - 2WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 2WD	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Suburban - 2WD	Radio	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Left side object detection module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Right side object detection module	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Suburban - 2WD	Assist step controller	●	●	●	●	●	●	T039
2009	Chevrolet	Suburban - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Suburban - 2WD	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Liftgate module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Suburban - 2WD	Trailer brake control module	●	●	●	●	●	○	

2009	Chevrolet	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Suburban - 2WD	Fuel pump control module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Suburban - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Suburban - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Suburban - 2WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 2WD	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Suburban - 2WD	Radio	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Left side object detection module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Right side object detection module	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Suburban - 2WD	Assist step controller	●	●	●	●	●	●	T039

2009	Chevrolet	Suburban - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Suburban - 2WD	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Liftgate module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Suburban - 2WD	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Suburban - 4WD	Fuel pump control module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Suburban - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Suburban - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Suburban - 4WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Rear heated seat module	●	●	●	●	○	○	

2009	Chevrolet	Suburban - 4WD	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Suburban - 4WD	Radio	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Left side object detection module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Right side object detection module	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Suburban - 4WD	Assist step controller	●	●	●	●	●	●	T039
2009	Chevrolet	Suburban - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Suburban - 4WD	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Liftgate module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Suburban - 4WD	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Suburban - 4WD	Fuel pump control module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001

2009	Chevrolet	Suburban - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Suburban - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Suburban - 4WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 4WD	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Suburban - 4WD	Radio	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Left side object detection module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Right side object detection module	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Suburban - 4WD	Assist step controller	●	●	●	●	●	●	T039
2009	Chevrolet	Suburban - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Suburban - 4WD	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Liftgate module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	●	T021 T022

2009	Chevrolet	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Suburban - 4WD	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Tahoe	Fuel pump control module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Tahoe	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Tahoe	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Tahoe	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Tahoe	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Tahoe	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Tahoe	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Tahoe	Radio	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Left side object detection module	●	●	●	●	●	○	

2009	Chevrolet	Tahoe	Right side object detection module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Tahoe	Assist step controller	●	●	●	●	●	●	T039
2009	Chevrolet	Tahoe	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Tahoe	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Liftgate module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Tahoe	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Tahoe	Amplifier (bose)	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Tahoe	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Tahoe	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Tahoe	Fuel pump control module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Tahoe	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Tahoe	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Tahoe	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Tahoe	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Tahoe	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Chevrolet	Tahoe	Digital radio receiver	●	●	●	●	●	○	

2009	Chevrolet	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Tahoe	Radio	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Left side object detection module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Right side object detection module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Tahoe	Assist step controller	●	●	●	●	●	●	T039
2009	Chevrolet	Tahoe	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Tahoe	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Liftgate module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Tahoe	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Tahoe	Amplifier (bose)	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Tahoe	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Tahoe	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2009	Chevrolet	Tahoe hybrid	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe hybrid	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe hybrid	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Tahoe hybrid	Radio	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Left side object detection module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Right side object detection module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe hybrid	Serial data gateway module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	A/C compressor control module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2009	Chevrolet	Tahoe hybrid	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Liftgate module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe hybrid	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Tahoe hybrid	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Tahoe hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Tahoe hybrid	Amplifier (bose)	●	●	●	●	●	○	

2009	Chevrolet	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Tahoe hybrid	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2009	Chevrolet	Tahoe hybrid	Power steering control module	●	●	●	●	●	●	T044
2009	Chevrolet	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Tahoe hybrid	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe hybrid	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Rear heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe hybrid	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Personal audio link module	●	●	●	○	○	●	T036
2009	Chevrolet	Tahoe hybrid	Radio	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Left side object detection module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Right side object detection module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe hybrid	Serial data gateway module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	A/C compressor control module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006

2009	Chevrolet	Tahoe hybrid	Driver door switch	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Liftgate module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Passenger door switch	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Heated seat module	●	●	●	●	○	○	
2009	Chevrolet	Tahoe hybrid	Body control module	●	●	●	●	●	●	T005
2009	Chevrolet	Tahoe hybrid	Passenger presence system	●	●	●	●	○	○	
2009	Chevrolet	Tahoe hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Tahoe hybrid	Amplifier (bose)	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2009	Chevrolet	Tahoe hybrid	Trailer brake control module	●	●	●	●	●	○	
2009	Chevrolet	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2009	Chevrolet	Tahoe hybrid	Power steering control module	●	●	●	●	●	●	T044
2009	Chevrolet	Trailblazer - 2WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Trailblazer - 2WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Trailblazer - 2WD	Radio	●	●	●	●	○	○	
2009	Chevrolet	Trailblazer - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	Chevrolet	Trailblazer - 2WD	Digital radio receiver	●	●	●	●	●	●	T024
2009	Chevrolet	Trailblazer - 2WD	Disc player and video display	●	●	●	○	○	○	

2009	Chevrolet	Trailblazer - 2WD	Rear seat audio	●	●	●	●	○	○	
2009	Chevrolet	Trailblazer - 2WD	Generator battery control module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Body control module	●	●	●	●	●	●	T058
2009	Chevrolet	Trailblazer - 2WD	Driver door module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Driver seat module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	HVAC control module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Liftgate module	●	●	●	●	●	●	T022
2009	Chevrolet	Trailblazer - 2WD	Passenger door module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2009	Chevrolet	Trailblazer - 2WD	Navigation radio	●	●	●	●	●	●	T033
2009	Chevrolet	Trailblazer - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2009	Chevrolet	Trailblazer - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Trailblazer - 2WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Trailblazer - 2WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Theft deterrent module	●	●	●	●	○	○	

2009	Chevrolet	Trailblazer - 2WD	Radio	●	●	●	●	○	○	
2009	Chevrolet	Trailblazer - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	Chevrolet	Trailblazer - 2WD	Digital radio receiver	●	●	●	●	●	●	T024
2009	Chevrolet	Trailblazer - 2WD	Disc player and video display	●	●	●	○	○	○	
2009	Chevrolet	Trailblazer - 2WD	Rear seat audio	●	●	●	●	○	○	
2009	Chevrolet	Trailblazer - 2WD	Generator battery control module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Body control module	●	●	●	●	●	●	T058
2009	Chevrolet	Trailblazer - 2WD	Driver door module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Driver seat module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	HVAC control module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Liftgate module	●	●	●	●	●	●	T022
2009	Chevrolet	Trailblazer - 2WD	Passenger door module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2009	Chevrolet	Trailblazer - 2WD	Navigation radio	●	●	●	●	●	●	T033
2009	Chevrolet	Trailblazer - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2009	Chevrolet	Trailblazer - 2WD	Transfer case control module	●	●	●	●	●	●	T001

2009	Chevrolet	Trailblazer - 4WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Trailblazer - 4WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Trailblazer - 4WD	Radio	●	●	●	●	○	○	
2009	Chevrolet	Trailblazer - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	Chevrolet	Trailblazer - 4WD	Digital radio receiver	●	●	●	●	●	●	T024
2009	Chevrolet	Trailblazer - 4WD	Disc player and video display	●	●	●	○	○	○	
2009	Chevrolet	Trailblazer - 4WD	Rear seat audio	●	●	●	●	○	○	
2009	Chevrolet	Trailblazer - 4WD	Generator battery control module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	Body control module	●	●	●	●	●	●	T058
2009	Chevrolet	Trailblazer - 4WD	Driver door module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	Driver seat module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	HVAC control module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	Liftgate module	●	●	●	●	●	●	T022
2009	Chevrolet	Trailblazer - 4WD	Passenger door module	●	●	●	●	●	○	

2009	Chevrolet	Trailblazer - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2009	Chevrolet	Trailblazer - 4WD	Navigation radio	●	●	●	●	●	●	T033
2009	Chevrolet	Trailblazer - 4WD	Electronic brake control module	●	●	●	●	●	●	T001
2009	Chevrolet	Trailblazer - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Trailblazer - 4WD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Trailblazer - 4WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Trailblazer - 4WD	Radio	●	●	●	●	○	○	
2009	Chevrolet	Trailblazer - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	Chevrolet	Trailblazer - 4WD	Digital radio receiver	●	●	●	●	●	●	T024
2009	Chevrolet	Trailblazer - 4WD	Disc player and video display	●	●	●	○	○	○	
2009	Chevrolet	Trailblazer - 4WD	Rear seat audio	●	●	●	●	○	○	
2009	Chevrolet	Trailblazer - 4WD	Generator battery control module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	Body control module	●	●	●	●	●	●	T058
2009	Chevrolet	Trailblazer - 4WD	Driver door module	●	●	●	●	●	○	

2009	Chevrolet	Trailblazer - 4WD	Driver seat module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	HVAC control module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	Liftgate module	●	●	●	●	●	●	T022
2009	Chevrolet	Trailblazer - 4WD	Passenger door module	●	●	●	●	●	○	
2009	Chevrolet	Trailblazer - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2009	Chevrolet	Trailblazer - 4WD	Navigation radio	●	●	●	●	●	●	T033
2009	Chevrolet	Trailblazer - 4WD	Electronic brake control module	●	●	●	●	●	●	T001
2009	Chevrolet	Trailblazer - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2009	Chevrolet	Traverse - AWD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Traverse - AWD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Traverse - AWD	Rear drive system	●	●	●	●	●	●	T038
2009	Chevrolet	Traverse - AWD	Passenger presence system	●	●	●	●	●	○	
2009	Chevrolet	Traverse - AWD	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Traverse - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Traverse - AWD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Traverse - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2009	Chevrolet	Traverse - AWD	Radio	●	●	●	●	●	○	
2009	Chevrolet	Traverse - AWD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Traverse - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Traverse - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Traverse - AWD	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Traverse - AWD	Park assist module	●	●	●	●	●	○	

2009	Chevrolet	Traverse - AWD	Liftgate module	●	●	●	●	●	○	
2009	Chevrolet	Traverse - AWD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Traverse - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Traverse - AWD	Body control module	●	●	●	●	●	●	T007 T005
2009	Chevrolet	Traverse - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Traverse - AWD	Driver door switch	●	●	●	●	●	●	T035
2009	Chevrolet	Traverse - AWD	Passenger door switch	●	●	●	●	●	●	T035
2009	Chevrolet	Traverse - AWD	Disc player and video display	●	●	●	●	●	●	T073 T003
2009	Chevrolet	Traverse - AWD	Left power sliding door module	●	●	●	●	●	○	
2009	Chevrolet	Traverse - AWD	Right power sliding door module	●	●	●	●	●	●	T020
2009	Chevrolet	Traverse - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Traverse - FWD	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Traverse - FWD	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Traverse - FWD	Rear drive system	●	●	●	●	●	●	T038
2009	Chevrolet	Traverse - FWD	Passenger presence system	●	●	●	●	●	○	
2009	Chevrolet	Traverse - FWD	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Traverse - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Traverse - FWD	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Traverse - FWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2009	Chevrolet	Traverse - FWD	Radio	●	●	●	●	●	○	
2009	Chevrolet	Traverse - FWD	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Traverse - FWD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Traverse - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Traverse - FWD	Memory seat module	●	●	●	●	●	○	

2009	Chevrolet	Traverse - FWD	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Traverse - FWD	Liftgate module	●	●	●	●	●	○	
2009	Chevrolet	Traverse - FWD	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Traverse - FWD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Traverse - FWD	Body control module	●	●	●	●	●	●	T007 T005
2009	Chevrolet	Traverse - FWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Traverse - FWD	Driver door switch	●	●	●	●	●	●	T035
2009	Chevrolet	Traverse - FWD	Passenger door switch	●	●	●	●	●	●	T035
2009	Chevrolet	Traverse - FWD	Disc player and video display	●	●	●	●	●	●	T073 T003
2009	Chevrolet	Traverse - FWD	Left power sliding door module	●	●	●	●	●	○	
2009	Chevrolet	Traverse - FWD	Right power sliding door module	●	●	●	●	●	●	T020
2009	Chevrolet	Traverse - FWD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Chevrolet	Uplander	Rear drive system	●	●	●	●	●	●	T038
2009	Chevrolet	Uplander	Engine control module	●	●	●	●	●	○	
2009	Chevrolet	Uplander	Passenger presence system	●	●	●	●	●	○	
2009	Chevrolet	Uplander	Rollover sensor	●	●	●	●	○	●	T049
2009	Chevrolet	Uplander	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Chevrolet	Uplander	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Uplander	Personal audio link module	●	●	●	○	○	●	T036 T037
2009	Chevrolet	Uplander	Radio	●	●	●	●	●	○	
2009	Chevrolet	Uplander	Digital radio receiver	●	●	●	●	●	○	
2009	Chevrolet	Uplander	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Chevrolet	Uplander	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Uplander	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Uplander	Park assist module	●	●	●	●	●	○	

2009	Chevrolet	Uplander	Liftgate module	●	●	●	●	●	○	
2009	Chevrolet	Uplander	Instrument panel cluster	●	●	●	●	●	○	
2009	Chevrolet	Uplander	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Uplander	Body control module	●	●	●	●	●	●	T007 T005
2009	Chevrolet	Uplander	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Chevrolet	Uplander	Driver door switch	●	●	●	●	●	●	T035
2009	Chevrolet	Uplander	Passenger door switch	●	●	●	●	●	●	T035
2009	Chevrolet	Uplander	Disc player and video display	●	●	●	●	●	●	T073 T003
2009	Chevrolet	Uplander	Left power sliding door module	●	●	●	●	●	○	
2009	Chevrolet	Uplander	Right power sliding door module	●	●	●	●	●	●	T020
2009	Chevrolet	Uplander	Electronic brake control module	●	●	○	●	●	●	T014
2009	Chevrolet	Uplander	Transmission control module	●	●	●	●	●	●	T001
2009	Chevrolet	Uplander ext.	Transmission control module	●	●	○	●	●	○	
2009	Chevrolet	Uplander ext.	Engine control module	●	●	●	●	●	●	T001
2009	Chevrolet	Uplander ext.	Passenger presence system	●	●	○	○	○	●	T020
2009	Chevrolet	Uplander ext.	Remote control door lock receiver	●	●	●	●	●	●	T022
2009	Chevrolet	Uplander ext.	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Chevrolet	Uplander ext.	Radio	●	●	●	●	○	●	T094 T095 T033
2009	Chevrolet	Uplander ext.	Digital radio receiver	●	●	●	●	●	●	T024
2009	Chevrolet	Uplander ext.	Disc player and video display	●	●	●	○	○	○	
2009	Chevrolet	Uplander ext.	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	Chevrolet	Uplander ext.	Body control module	●	●	●	●	●	●	T007

2009	Chevrolet	Uplander ext.	HVAC control module	●	●	●	●	●	○	
2009	Chevrolet	Uplander ext.	Left power sliding door module	●	●	●	●	●	○	
2009	Chevrolet	Uplander ext.	Right power sliding door module	●	●	●	●	●	○	
2009	Chevrolet	Uplander ext.	Instrument panel cluster	●	●	●	●	●	●	T020
2009	Chevrolet	Uplander ext.	Electronic brake control module	●	●	○	●	●	●	T014
2009	Chevrolet	Uplander ext.	Rear drive system	●	●	●	●	●	●	T038
2009	Chevrolet	Uplander ext.	Rollover sensor	●	●	●	●	●	●	T049
2009	Chevrolet	Uplander ext.	Theft deterrent module	●	●	●	●	○	○	
2009	Chevrolet	Uplander ext.	Personal audio link module	●	●	●	●	●	●	T036 T037
2009	Chevrolet	Uplander ext.	Rear HVAC/RSA	●	●	●	●	●	●	T002 T003
2009	Chevrolet	Uplander ext.	Memory seat module	●	●	●	●	●	○	
2009	Chevrolet	Uplander ext.	Park assist module	●	●	●	●	●	○	
2009	Chevrolet	Uplander ext.	Liftgate module	●	●	●	●	●	●	T008 T034
2009	Chevrolet	Uplander ext.	Driver door switch	●	●	●	●	●	●	T035
2009	Chevrolet	Uplander ext.	Passenger door switch	●	●	●	●	●	●	T035
2009	GMC truck	Acadia - 2WD	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Acadia - 2WD	Engine control module	●	●	●	●	●	○	
2009	GMC truck	Acadia - 2WD	Passenger presence system	●	●	●	●	●	○	
2009	GMC truck	Acadia - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Acadia - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Acadia - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Acadia - 2WD	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Acadia - 2WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2009	GMC truck	Acadia - 2WD	Radio	●	●	●	●	●	○	
2009	GMC truck	Acadia - 2WD	Digital radio receiver	●	●	●	●	●	○	

2009	GMC truck	Acadia - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	GMC truck	Acadia - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	GMC truck	Acadia - 2WD	Memory seat module	●	●	●	●	●	○	
2009	GMC truck	Acadia - 2WD	Park assist module	●	●	●	●	●	○	
2009	GMC truck	Acadia - 2WD	Liftgate module	●	●	●	●	●	○	
2009	GMC truck	Acadia - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Acadia - 2WD	Head up display	●	●	●	●	○	○	
2009	GMC truck	Acadia - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	GMC truck	Acadia - 2WD	Body control module	●	●	●	●	●	●	T007 T005
2009	GMC truck	Acadia - 2WD	Driver door switch	●	●	●	●	●	●	T035
2009	GMC truck	Acadia - 2WD	Passenger door switch	●	●	●	●	●	●	T035
2009	GMC truck	Acadia - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2009	GMC truck	Acadia - 2WD	Rear drive system	●	●	●	●	●	●	T038
2009	GMC truck	Acadia - 4WD	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Acadia - 4WD	Engine control module	●	●	●	●	●	○	
2009	GMC truck	Acadia - 4WD	Passenger presence system	●	●	●	●	●	○	
2009	GMC truck	Acadia - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Acadia - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Acadia - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Acadia - 4WD	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Acadia - 4WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2009	GMC truck	Acadia - 4WD	Radio	●	●	●	●	●	○	
2009	GMC truck	Acadia - 4WD	Digital radio receiver	●	●	●	●	●	○	
2009	GMC truck	Acadia - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	GMC truck	Acadia - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	GMC truck	Acadia - 4WD	Memory seat module	●	●	●	●	●	○	

2009	GMC truck	Acadia - 4WD	Park assist module	●	●	●	●	●	○	
2009	GMC truck	Acadia - 4WD	Liftgate module	●	●	●	●	●	○	
2009	GMC truck	Acadia - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Acadia - 4WD	Head up display	●	●	●	●	○	○	
2009	GMC truck	Acadia - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	GMC truck	Acadia - 4WD	Body control module	●	●	●	●	●	●	T007 T005
2009	GMC truck	Acadia - 4WD	Driver door switch	●	●	●	●	●	●	T035
2009	GMC truck	Acadia - 4WD	Passenger door switch	●	●	●	●	●	●	T035
2009	GMC truck	Acadia - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2009	GMC truck	Acadia - 4WD	Rear drive system	●	●	●	●	●	●	T038
2009	GMC truck	Canyon pickup - 2WD	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Canyon pickup - 2WD	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Canyon pickup - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2009	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	GMC truck	Canyon pickup - 2WD	Theft deterrent module	●	●	●	●	○	●	T057
2009	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	
2009	GMC truck	Canyon pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	●	●	T024
2009	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022
2009	GMC truck	Canyon pickup - 2WD	Generator battery control module	●	●	●	●	●	○	
2009	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	

2009	GMC truck	Canyon pickup - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2009	GMC truck	Canyon pickup - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2009	GMC truck	Canyon pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Canyon pickup - 2WD	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Canyon pickup - 2WD	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Canyon pickup - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2009	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	GMC truck	Canyon pickup - 2WD	Theft deterrent module	●	●	●	●	○	●	T057
2009	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	
2009	GMC truck	Canyon pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	●	●	T024
2009	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022
2009	GMC truck	Canyon pickup - 2WD	Generator battery control module	●	●	●	●	●	○	
2009	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Canyon pickup - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2009	GMC truck	Canyon pickup - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2009	GMC truck	Canyon pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T001

2009	GMC truck	Canyon pickup - 4WD	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Canyon pickup - 4WD	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Canyon pickup - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2009	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	GMC truck	Canyon pickup - 4WD	Theft deterrent module	●	●	●	●	○	●	T057
2009	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	
2009	GMC truck	Canyon pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	●	●	T024
2009	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058 T022
2009	GMC truck	Canyon pickup - 4WD	Generator battery control module	●	●	●	●	●	○	
2009	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Canyon pickup - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2009	GMC truck	Canyon pickup - 4WD	Electronic brake control module	●	●	●	●	●	●	T001
2009	GMC truck	Canyon pickup - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Canyon pickup - 4WD	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Canyon pickup - 4WD	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Canyon pickup - 4WD	Fuel pump control module	●	●	●	●	●	●	T001

2009	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	GMC truck	Canyon pickup - 4WD	Theft deterrent module	●	●	●	●	○	●	T057
2009	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	
2009	GMC truck	Canyon pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	●	●	T024
2009	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058 T022
2009	GMC truck	Canyon pickup - 4WD	Generator battery control module	●	●	●	●	●	○	
2009	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Canyon pickup - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2009	GMC truck	Canyon pickup - 4WD	Electronic brake control module	●	●	●	●	●	●	T001
2009	GMC truck	Canyon pickup - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Envoy - 2WD	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Envoy - 2WD	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Envoy - 2WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Envoy - 2WD	Radio	●	●	●	●	○	○	
2009	GMC truck	Envoy - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	GMC truck	Envoy - 2WD	Digital radio receiver	●	●	●	●	●	●	T024
2009	GMC truck	Envoy - 2WD	Disc player and video display	●	●	●	○	○	○	
2009	GMC truck	Envoy - 2WD	Rear seat audio	●	●	●	●	○	○	

2009	GMC truck	Envoy - 2WD	Generator battery control module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	Body control module	●	●	●	●	●	●	T058
2009	GMC truck	Envoy - 2WD	Driver door module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	Driver seat module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	HVAC control module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	Liftgate module	●	●	●	●	●	●	T022
2009	GMC truck	Envoy - 2WD	Passenger door module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2009	GMC truck	Envoy - 2WD	Navigation radio	●	●	●	●	●	●	T033
2009	GMC truck	Envoy - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2009	GMC truck	Envoy - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Envoy - 2WD	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Envoy - 2WD	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Envoy - 2WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Envoy - 2WD	Radio	●	●	●	●	○	○	
2009	GMC truck	Envoy - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	GMC truck	Envoy - 2WD	Digital radio receiver	●	●	●	●	●	●	T024
2009	GMC truck	Envoy - 2WD	Disc player and video display	●	●	●	○	○	○	
2009	GMC truck	Envoy - 2WD	Rear seat audio	●	●	●	●	○	○	
2009	GMC truck	Envoy - 2WD	Generator battery control module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	Body control module	●	●	●	●	●	●	T058

2009	GMC truck	Envoy - 2WD	Driver door module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	Driver seat module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	HVAC control module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	Liftgate module	●	●	●	●	●	●	T022
2009	GMC truck	Envoy - 2WD	Passenger door module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2009	GMC truck	Envoy - 2WD	Navigation radio	●	●	●	●	●	●	T033
2009	GMC truck	Envoy - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2009	GMC truck	Envoy - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Envoy - 4WD	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Envoy - 4WD	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Envoy - 4WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2009	GMC truck	Envoy - 4WD	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Envoy - 4WD	Radio	●	●	●	●	○	○	
2009	GMC truck	Envoy - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	GMC truck	Envoy - 4WD	Digital radio receiver	●	●	●	●	●	●	T024
2009	GMC truck	Envoy - 4WD	Disc player and video display	●	●	●	○	○	○	
2009	GMC truck	Envoy - 4WD	Rear seat audio	●	●	●	●	○	○	
2009	GMC truck	Envoy - 4WD	Generator battery control module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Envoy - 4WD	Body control module	●	●	●	●	●	●	T058
2009	GMC truck	Envoy - 4WD	Driver door module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 4WD	Driver seat module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 4WD	HVAC control module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 4WD	Liftgate module	●	●	●	●	●	●	T022
2009	GMC truck	Envoy - 4WD	Passenger door module	●	●	●	●	●	○	

2009	GMC truck	Envoy - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2009	GMC truck	Envoy - 4WD	Navigation radio	●	●	●	●	●	●	T033
2009	GMC truck	Envoy - 4WD	Electronic brake control module	●	●	●	●	●	●	T001
2009	GMC truck	Envoy - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Envoy - 4WD	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Envoy - 4WD	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Envoy - 4WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2009	GMC truck	Envoy - 4WD	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Envoy - 4WD	Radio	●	●	●	●	○	○	
2009	GMC truck	Envoy - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	GMC truck	Envoy - 4WD	Digital radio receiver	●	●	●	●	●	●	T024
2009	GMC truck	Envoy - 4WD	Disc player and video display	●	●	●	○	○	○	
2009	GMC truck	Envoy - 4WD	Rear seat audio	●	●	●	●	○	○	
2009	GMC truck	Envoy - 4WD	Generator battery control module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Envoy - 4WD	Body control module	●	●	●	●	●	●	T058
2009	GMC truck	Envoy - 4WD	Driver door module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 4WD	Driver seat module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 4WD	HVAC control module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 4WD	Liftgate module	●	●	●	●	●	●	T022
2009	GMC truck	Envoy - 4WD	Passenger door module	●	●	●	●	●	○	
2009	GMC truck	Envoy - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2009	GMC truck	Envoy - 4WD	Navigation radio	●	●	●	●	●	●	T033
2009	GMC truck	Envoy - 4WD	Electronic brake control module	●	●	●	●	●	●	T001

2009	GMC truck	Envoy - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2009	GMC truck	Savana	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2009	GMC truck	Savana	Radio	●	●	●	●	●	○	
2009	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2009	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T045
2009	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2009	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2009	GMC truck	Savana	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2009	GMC truck	Savana	Radio	●	●	●	●	●	○	
2009	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049

2009	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2009	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T045
2009	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2009	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2009	GMC truck	Savana	Radio	●	●	●	●	●	○	
2009	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2009	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T045
2009	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2009	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2009	GMC truck	Savana	Radio	●	●	●	●	●	○	

2009	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2009	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T045
2009	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2009	GMC truck	Sierra	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Sierra	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Sierra	Fuel pump control module	●	●	●	●	●	●	T001
2009	GMC truck	Sierra	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Sierra	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Sierra	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Sierra	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Sierra	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	GMC truck	Sierra	Digital radio receiver	●	●	●	●	●	○	
2009	GMC truck	Sierra	Rear HVAC/RSA	●	●	●	●	●	○	
2009	GMC truck	Sierra	Memory seat module	●	●	●	●	●	○	
2009	GMC truck	Sierra	Rear heated seat module	●	●	●	●	○	○	
2009	GMC truck	Sierra	Park assist module	●	●	●	●	●	○	
2009	GMC truck	Sierra	Personal audio link module	●	●	●	○	○	●	T036
2009	GMC truck	Sierra	Radio	●	●	●	●	●	○	

2009	GMC truck	Sierra	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Sierra	HVAC control module	●	●	●	●	●	●	T008 T034
2009	GMC truck	Sierra	Body control module (aux.)	●	●	●	●	●	●	T006
2009	GMC truck	Sierra	Driver door switch	●	●	●	●	●	○	
2009	GMC truck	Sierra	Passenger door switch	●	●	●	●	●	○	
2009	GMC truck	Sierra	Passenger presence system	●	●	●	●	○	○	
2009	GMC truck	Sierra	Amplifier (bose)	●	●	●	●	●	○	
2009	GMC truck	Sierra	Body control module	●	●	●	●	●	●	T005
2009	GMC truck	Sierra	Electronic suspension control	●	●	●	●	●	●	T040
2009	GMC truck	Sierra	Trailer brake control module	●	●	●	●	●	○	
2009	GMC truck	Sierra	Electronic brake control module	●	●	●	●	●	●	T014
2009	GMC truck	Sierra	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Sierra	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Sierra	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Sierra	Fuel pump control module	●	●	●	●	●	●	T001
2009	GMC truck	Sierra	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Sierra	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Sierra	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Sierra	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Sierra	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	GMC truck	Sierra	Digital radio receiver	●	●	●	●	●	○	
2009	GMC truck	Sierra	Rear HVAC/RSA	●	●	●	●	●	○	
2009	GMC truck	Sierra	Memory seat module	●	●	●	●	●	○	

2009	GMC truck	Sierra	Rear heated seat module	●	●	●	●	○	○	
2009	GMC truck	Sierra	Park assist module	●	●	●	●	●	○	
2009	GMC truck	Sierra	Personal audio link module	●	●	●	○	○	●	T036
2009	GMC truck	Sierra	Radio	●	●	●	●	●	○	
2009	GMC truck	Sierra	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Sierra	HVAC control module	●	●	●	●	●	●	T008 T034
2009	GMC truck	Sierra	Body control module (aux.)	●	●	●	●	●	●	T006
2009	GMC truck	Sierra	Driver door switch	●	●	●	●	●	○	
2009	GMC truck	Sierra	Passenger door switch	●	●	●	●	●	○	
2009	GMC truck	Sierra	Passenger presence system	●	●	●	●	○	○	
2009	GMC truck	Sierra	Amplifier (bose)	●	●	●	●	●	○	
2009	GMC truck	Sierra	Body control module	●	●	●	●	●	●	T005
2009	GMC truck	Sierra	Electronic suspension control	●	●	●	●	●	●	T040
2009	GMC truck	Sierra	Trailer brake control module	●	●	●	●	●	○	
2009	GMC truck	Sierra	Electronic brake control module	●	●	●	●	●	●	T014
2009	GMC truck	Sierra	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Sierra hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Sierra hybrid	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Sierra hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Sierra hybrid	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Sierra hybrid	Digital radio receiver	●	●	●	●	●	○	
2009	GMC truck	Sierra hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2009	GMC truck	Sierra hybrid	Memory seat module	●	●	●	●	●	○	

2009	GMC truck	Sierra hybrid	Rear heated seat module	●	●	●	●	○	○	
2009	GMC truck	Sierra hybrid	Park assist module	●	●	●	●	●	○	
2009	GMC truck	Sierra hybrid	Personal audio link module	●	●	●	○	○	●	T036
2009	GMC truck	Sierra hybrid	Radio	●	●	●	●	●	○	
2009	GMC truck	Sierra hybrid	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Sierra hybrid	Serial data gateway module	●	●	●	●	●	○	
2009	GMC truck	Sierra hybrid	A/C compressor control module	●	●	●	●	○	○	
2009	GMC truck	Sierra hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2009	GMC truck	Sierra hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2009	GMC truck	Sierra hybrid	Driver door switch	●	●	●	●	●	○	
2009	GMC truck	Sierra hybrid	Passenger door switch	●	●	●	●	●	○	
2009	GMC truck	Sierra hybrid	Passenger presence system	●	●	●	●	○	○	
2009	GMC truck	Sierra hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	GMC truck	Sierra hybrid	Amplifier (bose)	●	●	●	●	●	○	
2009	GMC truck	Sierra hybrid	Body control module	●	●	●	●	●	●	T005
2009	GMC truck	Sierra hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2009	GMC truck	Sierra hybrid	Trailer brake control module	●	●	●	●	●	○	
2009	GMC truck	Sierra hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2009	GMC truck	Sierra hybrid	Power steering control module	●	●	●	●	●	●	T044
2009	GMC truck	Sierra hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Sierra hybrid	Rollover sensor	●	●	●	●	○	●	T049

2009	GMC truck	Sierra hybrid	Power steering control module	●	●	●	●	●	●	T044
2009	GMC truck	Yukon	Fuel pump control module	●	●	●	●	●	○	
2009	GMC truck	Yukon	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Yukon	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Yukon	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Yukon	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Yukon	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Yukon	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Yukon	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	GMC truck	Yukon	Digital radio receiver	●	●	●	●	●	○	
2009	GMC truck	Yukon	Rear HVAC/RSA	●	●	●	●	●	○	
2009	GMC truck	Yukon	Rear heated seat module	●	●	●	●	○	○	
2009	GMC truck	Yukon	Park assist module	●	●	●	●	●	○	
2009	GMC truck	Yukon	Personal audio link module	●	●	●	○	○	●	T036
2009	GMC truck	Yukon	Radio	●	●	●	●	●	○	
2009	GMC truck	Yukon	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Yukon	Left side object detection module	●	●	●	●	●	○	
2009	GMC truck	Yukon	Right side object detection module	●	●	●	●	○	○	
2009	GMC truck	Yukon	HVAC control module	●	●	●	●	●	●	T008 T034
2009	GMC truck	Yukon	Assist step controller	●	●	●	●	●	●	T039
2009	GMC truck	Yukon	Body control module (aux.)	●	●	●	●	●	●	T006
2009	GMC truck	Yukon	Driver door switch	●	●	●	●	●	○	
2009	GMC truck	Yukon	Liftgate module	●	●	●	●	●	○	

2009	GMC truck	Yukon	Passenger door switch	●	●	●	●	●	○	
2009	GMC truck	Yukon	Body control module	●	●	●	●	●	●	T005
2009	GMC truck	Yukon	Memory seat module	●	●	●	●	●	○	
2009	GMC truck	Yukon	Passenger presence system	●	●	●	●	○	○	
2009	GMC truck	Yukon	Amplifier (bose)	●	●	●	●	●	●	T021 T022
2009	GMC truck	Yukon	Electronic suspension control	●	●	●	●	●	●	T040
2009	GMC truck	Yukon	Trailer brake control module	●	●	●	●	●	○	
2009	GMC truck	Yukon	Electronic brake control module	●	●	●	●	●	●	T014
2009	GMC truck	Yukon	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Yukon	Fuel pump control module	●	●	●	●	●	○	
2009	GMC truck	Yukon	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Yukon	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Yukon	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Yukon	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Yukon	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Yukon	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Yukon	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	GMC truck	Yukon	Digital radio receiver	●	●	●	●	●	○	
2009	GMC truck	Yukon	Rear HVAC/RSA	●	●	●	●	●	○	
2009	GMC truck	Yukon	Rear heated seat module	●	●	●	●	○	○	
2009	GMC truck	Yukon	Park assist module	●	●	●	●	●	○	
2009	GMC truck	Yukon	Personal audio link module	●	●	●	○	○	●	T036
2009	GMC truck	Yukon	Radio	●	●	●	●	●	○	

2009	GMC truck	Yukon	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Yukon	Left side object detection module	●	●	●	●	●	○	
2009	GMC truck	Yukon	Right side object detection module	●	●	●	●	○	○	
2009	GMC truck	Yukon	HVAC control module	●	●	●	●	●	●	T008 T034
2009	GMC truck	Yukon	Assist step controller	●	●	●	●	●	●	T039
2009	GMC truck	Yukon	Body control module (aux.)	●	●	●	●	●	●	T006
2009	GMC truck	Yukon	Driver door switch	●	●	●	●	●	○	
2009	GMC truck	Yukon	Liftgate module	●	●	●	●	●	○	
2009	GMC truck	Yukon	Passenger door switch	●	●	●	●	●	○	
2009	GMC truck	Yukon	Body control module	●	●	●	●	●	●	T005
2009	GMC truck	Yukon	Memory seat module	●	●	●	●	●	○	
2009	GMC truck	Yukon	Passenger presence system	●	●	●	●	○	○	
2009	GMC truck	Yukon	Amplifier (bose)	●	●	●	●	●	●	T021 T022
2009	GMC truck	Yukon	Electronic suspension control	●	●	●	●	●	●	T040
2009	GMC truck	Yukon	Trailer brake control module	●	●	●	●	●	○	
2009	GMC truck	Yukon	Electronic brake control module	●	●	●	●	●	●	T014
2009	GMC truck	Yukon	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Yukon hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Yukon hybrid	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Yukon hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Yukon hybrid	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Yukon hybrid	Digital radio receiver	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Rear HVAC/RSA	●	●	●	●	●	○	

2009	GMC truck	Yukon hybrid	Power steering control module	●	●	●	●	●	●	T044
2009	GMC truck	Yukon hybrid	Fuel pump control module	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Yukon hybrid	Accessory power module	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Yukon hybrid	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Yukon hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Yukon hybrid	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Yukon hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Yukon hybrid	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Yukon hybrid	Digital radio receiver	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Rear heated seat module	●	●	●	●	○	○	
2009	GMC truck	Yukon hybrid	Park assist module	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Personal audio link module	●	●	●	○	○	●	T036
2009	GMC truck	Yukon hybrid	Radio	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Left side object detection module	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Right side object detection module	●	●	●	●	○	○	
2009	GMC truck	Yukon hybrid	Serial data gateway module	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	A/C compressor control module	●	●	●	●	○	○	
2009	GMC truck	Yukon hybrid	HVAC control module	●	●	●	●	●	●	T008 T034

2009	GMC truck	Yukon hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2009	GMC truck	Yukon hybrid	Driver door switch	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Liftgate module	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Passenger door switch	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Heated seat module	●	●	●	●	○	○	
2009	GMC truck	Yukon hybrid	Body control module	●	●	●	●	●	●	T005
2009	GMC truck	Yukon hybrid	Passenger presence system	●	●	●	●	○	○	
2009	GMC truck	Yukon hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	GMC truck	Yukon hybrid	Amplifier (bose)	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2009	GMC truck	Yukon hybrid	Trailer brake control module	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2009	GMC truck	Yukon hybrid	Power steering control module	●	●	●	●	●	●	T044
2009	GMC truck	Yukon hybrid	Fuel pump control module	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Yukon hybrid	Accessory power module	●	●	●	●	●	○	
2009	GMC truck	Yukon hybrid	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Yukon hybrid	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Yukon XL	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Yukon XL	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Yukon XL	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Yukon XL	Theft deterrent module	●	●	●	●	○	○	

2009	GMC truck	Yukon XL	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	GMC truck	Yukon XL	Digital radio receiver	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Rear HVAC/RSA	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Rear heated seat module	●	●	●	●	○	○	
2009	GMC truck	Yukon XL	Park assist module	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Personal audio link module	●	●	●	○	○	●	T036
2009	GMC truck	Yukon XL	Radio	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Left side object detection module	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Right side object detection module	●	●	●	●	○	○	
2009	GMC truck	Yukon XL	HVAC control module	●	●	●	●	●	●	T008 T034
2009	GMC truck	Yukon XL	Assist step controller	●	●	●	●	●	●	T039
2009	GMC truck	Yukon XL	Body control module (aux.)	●	●	●	●	●	●	T006
2009	GMC truck	Yukon XL	Driver door switch	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Liftgate module	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Passenger door switch	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Body control module	●	●	●	●	●	●	T005
2009	GMC truck	Yukon XL	Passenger presence system	●	●	●	●	○	○	
2009	GMC truck	Yukon XL	Amplifier (bose)	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Memory seat module	●	●	●	●	●	●	T021 T022
2009	GMC truck	Yukon XL	Electronic suspension control	●	●	●	●	●	●	T040
2009	GMC truck	Yukon XL	Trailer brake control module	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Electronic brake control module	●	●	●	●	●	●	T014

2009	GMC truck	Yukon XL	Fuel pump control module	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Yukon XL	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Yukon XL	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Yukon XL	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	GMC truck	Yukon XL	Rollover sensor	●	●	●	●	○	●	T049
2009	GMC truck	Yukon XL	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Yukon XL	Theft deterrent module	●	●	●	●	○	○	
2009	GMC truck	Yukon XL	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	GMC truck	Yukon XL	Digital radio receiver	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Rear HVAC/RSA	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Rear heated seat module	●	●	●	●	○	○	
2009	GMC truck	Yukon XL	Park assist module	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Personal audio link module	●	●	●	○	○	●	T036
2009	GMC truck	Yukon XL	Radio	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Left side object detection module	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Right side object detection module	●	●	●	●	○	○	
2009	GMC truck	Yukon XL	HVAC control module	●	●	●	●	●	●	T008 T034
2009	GMC truck	Yukon XL	Assist step controller	●	●	●	●	●	●	T039
2009	GMC truck	Yukon XL	Body control module (aux.)	●	●	●	●	●	●	T006
2009	GMC truck	Yukon XL	Driver door switch	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Liftgate module	●	●	●	●	●	○	

2009	GMC truck	Yukon XL	Passenger door switch	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Body control module	●	●	●	●	●	●	T005
2009	GMC truck	Yukon XL	Passenger presence system	●	●	●	●	○	○	
2009	GMC truck	Yukon XL	Amplifier (bose)	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Memory seat module	●	●	●	●	●	●	T021 T022
2009	GMC truck	Yukon XL	Electronic suspension control	●	●	●	●	●	●	T040
2009	GMC truck	Yukon XL	Trailer brake control module	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Electronic brake control module	●	●	●	●	●	●	T014
2009	GMC truck	Yukon XL	Fuel pump control module	●	●	●	●	●	○	
2009	GMC truck	Yukon XL	Transmission control module	●	●	○	●	●	○	
2009	GMC truck	Yukon XL	Engine control module	●	●	●	●	●	●	T001
2009	GMC truck	Yukon XL	Transfer case control module	●	●	●	●	●	●	T001
2009	GMC truck	Others	Instrument panel cluster	●	●	●	●	●	○	
2009	GMC truck	Others	Front display interface module	●	●	●	○	○	○	
2009	GMC truck	Others	HVAC control module	●	●	●	○	●	○	
2009	GMC truck	Others	Radio	●	●	●	●	●	○	
2009	GMC truck	Others	Body control module (aux.)	●	●	●	●	●	○	
2009	GMC truck	Others	Body control module	●	●	●	●	●	●	T005
2009	GMC truck	Others	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	GMC truck	Others	Headlamp control module	●	●	●	●	●	○	
2009	GMC truck	Others	Park assist module	●	●	●	●	○	○	
2009	GMC truck	Others	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2009	GMC truck	Others	Theft deterrent module	●	●	●	●	●	●	T005
2009	GMC truck	Others	Electronic brake control module	●	●	●	●	●	○	
2009	GMC truck	Others	Transmission control module	●	●	●	●	●	○	
2009	GMC truck	Others	Engine control module	●	●	●	●	●	●	T070
2009	GMC truck	Others	Rear drive system	●	●	●	●	●	●	T038
2009	Pontiac	Montana SV6	Transmission control module	●	●	○	●	●	○	
2009	Pontiac	Montana SV6	Engine control module	●	●	●	●	●	●	T001
2009	Pontiac	Montana SV6	Passenger presence system	●	●	○	○	○	●	T020
2009	Pontiac	Montana SV6	Remote control door lock receiver	●	●	●	●	●	●	T022
2009	Pontiac	Montana SV6	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Pontiac	Montana SV6	Radio	●	●	●	●	○	●	T094 T095 T033
2009	Pontiac	Montana SV6	Digital radio receiver	●	●	●	●	●	●	T024
2009	Pontiac	Montana SV6	Disc player and video display	●	●	●	○	○	○	
2009	Pontiac	Montana SV6	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	Pontiac	Montana SV6	Body control module	●	●	●	●	●	●	T007
2009	Pontiac	Montana SV6	HVAC control module	●	●	●	●	●	○	
2009	Pontiac	Montana SV6	Left power sliding door module	●	●	●	●	●	○	
2009	Pontiac	Montana SV6	Right power sliding door module	●	●	●	●	●	○	
2009	Pontiac	Montana SV6	Instrument panel cluster	●	●	●	●	●	●	T020
2009	Pontiac	Montana SV6	Electronic brake control module	●	●	●	●	●	●	T014
2009	Pontiac	Montana SV6 ext.	Transmission control module	●	●	○	●	●	○	

2009	Pontiac	Montana SV6 ext.	Engine control module	●	●	●	●	●	●	T001
2009	Pontiac	Montana SV6 ext.	Passenger presence system	●	●	○	○	○	●	T020
2009	Pontiac	Montana SV6 ext.	Remote control door lock receiver	●	●	●	●	●	●	T022
2009	Pontiac	Montana SV6 ext.	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Pontiac	Montana SV6 ext.	Radio	●	●	●	●	○	●	T094 T095 T033
2009	Pontiac	Montana SV6 ext.	Digital radio receiver	●	●	●	●	●	●	T024
2009	Pontiac	Montana SV6 ext.	Disc player and video display	●	●	●	○	○	○	
2009	Pontiac	Montana SV6 ext.	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	Pontiac	Montana SV6 ext.	Body control module	●	●	●	●	●	●	T007
2009	Pontiac	Montana SV6 ext.	HVAC control module	●	●	●	●	●	○	
2009	Pontiac	Montana SV6 ext.	Left power sliding door module	●	●	●	●	●	○	
2009	Pontiac	Montana SV6 ext.	Right power sliding door module	●	●	●	●	●	○	
2009	Pontiac	Montana SV6 ext.	Instrument panel cluster	●	●	●	●	●	●	T020
2009	Pontiac	Montana SV6 ext.	Electronic brake control module	●	●	●	●	●	●	T014
2009	Pontiac	Torrent	Transmission control module	●	●	○	●	●	○	
2009	Pontiac	Torrent	Engine control module	●	●	●	●	●	●	T001
2009	Pontiac	Torrent	Rear drive system	●	●	●	●	●	●	T038
2009	Pontiac	Torrent	Radio	●	●	●	●	●	○	
2009	Pontiac	Torrent	Digital radio receiver	●	●	●	●	●	○	

2009	Pontiac	Torrent	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T093
2009	Pontiac	Torrent	Rollover sensor	●	●	●	●	○	●	T049
2009	Pontiac	Torrent	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Pontiac	Torrent	Body control module	●	●	●	●	●	●	T007 T005
2009	Pontiac	Torrent	Passenger presence system	●	●	●	●	○	●	T045
2009	Pontiac	Torrent	Heated seat module	●	●	●	●	○	○	
2009	Pontiac	Torrent	Instrument panel cluster	●	●	●	●	●	○	
2009	Pontiac	Torrent	HVAC control module	●	●	●	●	●	●	T008
2009	Pontiac	Torrent	Theft deterrent module	●	●	●	●	○	○	
2009	Pontiac	Torrent	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Pontiac	Torrent	Power steering control module	●	●	○	●	○	○	
2009	Pontiac	Torrent	Electronic brake control module	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - AWD	Transmission control module	●	●	○	●	●	○	
2009	Saturn	OUTLOOK - AWD	Engine control module	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - AWD	Passenger presence system	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Saturn	OUTLOOK - AWD	Rollover sensor	●	●	●	●	○	●	T049
2009	Saturn	OUTLOOK - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Saturn	OUTLOOK - AWD	Theft deterrent module	●	●	●	●	○	○	
2009	Saturn	OUTLOOK - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2009	Saturn	OUTLOOK - AWD	Radio	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - AWD	Digital radio receiver	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - AWD	Rear HVAC/RSA	●	●	●	●	●	○	

2009	Saturn	OUTLOOK - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Saturn	OUTLOOK - AWD	Memory seat module	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - AWD	Park assist module	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - AWD	Liftgate module	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - AWD	Instrument panel cluster	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Saturn	OUTLOOK - AWD	Body control module	●	●	●	●	●	●	T007 T005
2009	Saturn	OUTLOOK - AWD	Driver door switch	●	●	●	●	●	●	T035
2009	Saturn	OUTLOOK - AWD	Passenger door switch	●	●	●	●	●	●	T035
2009	Saturn	OUTLOOK - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2009	Saturn	OUTLOOK - 2WD	Rear drive system	●	●	●	●	●	●	T038
2009	Saturn	OUTLOOK - 2WD	Engine control module	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - 2WD	Passenger presence system	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Saturn	OUTLOOK - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2009	Saturn	OUTLOOK - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Saturn	OUTLOOK - 2WD	Theft deterrent module	●	●	●	●	○	○	
2009	Saturn	OUTLOOK - 2WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2009	Saturn	OUTLOOK - 2WD	Radio	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - 2WD	Digital radio receiver	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Saturn	OUTLOOK - 2WD	Memory seat module	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - 2WD	Park assist module	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - 2WD	Liftgate module	●	●	●	●	●	○	
2009	Saturn	OUTLOOK - 2WD	Instrument panel cluster	●	●	●	●	●	○	

2009	Saturn	VUE hybrid	Battery energy control module	○	○	○	●	●	○	
2009	Saturn	VUE hybrid	Starter/generator control module	●	●	●	●	●	○	
2009	Saturn	VUE hybrid	Accessory power module	●	●	●	●	●	○	
2009	Saturn	VUE hybrid	Radio	●	●	●	●	●	○	
2009	Saturn	VUE hybrid	Digital radio receiver	●	●	●	●	●	○	
2009	Saturn	VUE hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Saturn	VUE hybrid	Theft deterrent module	●	●	●	●	○	○	
2009	Saturn	VUE hybrid	Rollover sensor	●	●	●	●	○	●	T049
2009	Saturn	VUE hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Saturn	VUE hybrid	HVAC control module	●	●	●	●	●	●	T008
2009	Saturn	VUE hybrid	Passenger presence system	●	●	●	●	○	●	T045
2009	Saturn	VUE hybrid	Instrument panel cluster	●	●	●	●	●	○	
2009	Saturn	VUE hybrid	Body control module	●	●	●	●	●	●	T007 T005
2009	Saturn	VUE hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003
2009	Saturn	VUE hybrid	A/C compressor control module	●	●	●	●	●	●	T045
2009	Saturn	VUE hybrid	Serial data gateway module	●	●	●	●	●	●	T002 T003
2009	Saturn	VUE hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2009	Hummer	H2	Fuel pump control module	●	●	●	●	●	○	
2009	Hummer	H2	Transfer case control module	●	●	●	●	●	○	
2009	Hummer	H2	Transmission control module	●	●	○	●	●	○	
2009	Hummer	H2	Engine control module	●	●	●	●	●	●	T001

2009	Hummer	H2	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Hummer	H2	Rollover sensor	●	●	●	●	○	●	T049
2009	Hummer	H2	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Hummer	H2	Theft deterrent module	●	●	●	●	○	○	
2009	Hummer	H2	Amplifier (bose)	●	●	●	●	●	●	T010
2009	Hummer	H2	Digital radio receiver	●	●	●	●	●	○	
2009	Hummer	H2	Rear HVAC/RSA	●	●	●	●	●	○	
2009	Hummer	H2	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T004
2009	Hummer	H2	Memory seat module	●	●	●	●	●	○	
2009	Hummer	H2	Rear heated seat module	●	●	●	●	○	○	
2009	Hummer	H2	Personal audio link module	●	●	●	○	○	●	T036
2009	Hummer	H2	Radio	●	●	●	●	●	○	
2009	Hummer	H2	Instrument panel cluster	●	●	●	●	●	○	
2009	Hummer	H2	Body control module	●	●	●	●	●	●	T005
2009	Hummer	H2	HVAC control module	●	●	●	●	●	●	T008 T034
2009	Hummer	H2	Driver door switch	●	●	●	●	●	○	
2009	Hummer	H2	Passenger door switch	●	●	●	●	●	○	
2009	Hummer	H2	Electronic brake control module	●	●	●	●	●	●	T014
2009	Hummer	H2	Air suspension control module	●	●	●	●	●	○	
2009	Hummer	H3	Engine control module	●	●	●	●	●	●	T001
2009	Hummer	H3	Fuel pump control module	●	●	●	●	●	○	
2009	Hummer	H3	Transmission control module	●	●	○	●	●	○	
2009	Hummer	H3	Transfer case control module	●	●	●	●	●	●	T001
2009	Hummer	H3	Radio	●	●	●	●	●	●	T080 T032

2009	Hummer	H3	Passenger presence system	●	●	○	○	○	●	T020
2009	Hummer	H3	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2009	Hummer	H3	Theft deterrent module	●	●	●	●	○	●	T057
2009	Hummer	H3	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	Hummer	H3	Digital radio receiver	●	●	●	●	●	●	T024
2009	Hummer	H3	Body control module	●	●	●	●	●	●	T058 T022
2009	Hummer	H3	Instrument panel cluster	●	●	●	●	●	○	
2009	Hummer	H3	Generator battery control module	●	●	●	●	●	○	
2009	Hummer	H3	Personal audio link module	●	●	●	○	○	●	T036
2009	Hummer	H3	Navigation radio	●	●	●	●	●	●	T033
2009	Hummer	H3	Electronic brake control module	●	●	●	●	●	●	T001
2009	SAAB	Saab 9-7x	Transmission control module	●	●	○	●	●	○	
2009	SAAB	Saab 9-7x	Engine control module	●	●	●	●	●	●	T001
2009	SAAB	Saab 9-7x	Transfer case control module	●	●	●	●	●	●	T001
2009	SAAB	Saab 9-7x	Passenger presence system	●	●	○	○	○	●	T020
2009	SAAB	Saab 9-7x	Supplemental inflatable restraint	●	●	●	●	●	○	
2009	SAAB	Saab 9-7x	Theft deterrent module	●	●	●	●	○	○	
2009	SAAB	Saab 9-7x	Radio	●	●	●	●	●	●	T080 T032
2009	SAAB	Saab 9-7x	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003
2009	SAAB	Saab 9-7x	Digital radio receiver	●	●	●	●	●	●	T024
2009	SAAB	Saab 9-7x	Disc player and video display	●	●	●	○	○	○	
2009	SAAB	Saab 9-7x	Rear seat audio	●	●	●	●	○	○	

2009	SAAB	Saab 9-7x	Generator battery control module	●	●	●	●	●	○	
2009	SAAB	Saab 9-7x	Instrument panel cluster	●	●	●	●	●	○	
2009	SAAB	Saab 9-7x	Body control module	●	●	●	●	●	●	T058
2009	SAAB	Saab 9-7x	Driver door module	●	●	●	●	●	○	
2009	SAAB	Saab 9-7x	Driver seat module	●	●	●	●	●	○	
2009	SAAB	Saab 9-7x	HVAC control module	●	●	●	●	●	○	
2009	SAAB	Saab 9-7x	Liftgate module	●	●	●	●	●	●	T022
2009	SAAB	Saab 9-7x	Passenger door module	●	●	●	●	●	●	T020
2009	SAAB	Saab 9-7x	Navigation radio	●	●	●	●	●	●	T033
2009	SAAB	Saab 9-7x	Electronic brake control module	●	●	●	●	●	○	
2009	Holden	Captiva	Engine control module	●	●	●	●	●	●	T070
2009	Holden	Captiva	Transmission control module	●	●	●	●	●	●	T070
2009	Holden	Captiva	Rear drive system	●	●	●	●	●	●	T038
2009	Holden	Captiva	HVAC control module	●	●	●	○	●	○	
2009	Holden	Captiva	Instrument panel cluster	●	●	●	●	●	○	
2009	Holden	Captiva	Body control module	●	●	●	●	●	●	T005
2009	Holden	Captiva	Body control module (aux.)	●	●	●	●	●	○	
2009	Holden	Captiva	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2009	Holden	Captiva	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2009	Holden	Captiva	Theft deterrent module	●	●	●	●	●	●	T005
2009	Holden	Captiva	Electronic brake control module	●	●	●	●	●	○	
2009	Holden	Captiva maxx	Transmission control module	●	●	●	●	●	○	
2009	Holden	Captiva maxx	Engine control module	●	●	●	●	●	○	
2009	Holden	Captiva maxx	Rear drive system	●	●	●	●	●	●	T038

2008	Buick	Lacrosse	HVAC control module	●	●	●	●	●	●	T008
2008	Buick	Lacrosse	Instrument panel cluster	●	●	●	●	●	●	T022
2008	Buick	Lacrosse	Electronic brake control module	●	●	○	●	●	●	T014
2008	Buick	Lacrosse (allure in canada)	Powertrain control module	●	●	●	●	●	●	T001
2008	Buick	Lacrosse (allure in canada)	Engine control module	●	●	●	●	●	○	
2008	Buick	Lacrosse (allure in canada)	Transmission control module	●	●	●	●	●	●	T001
2008	Buick	Lacrosse (allure in canada)	Remote control door lock receiver	●	●	●	●	●	●	T022
2008	Buick	Lacrosse (allure in canada)	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Buick	Lacrosse (allure in canada)	Body control module	●	●	●	●	●	●	T007
2008	Buick	Lacrosse (allure in canada)	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T060 T080 T032
2008	Buick	Lacrosse (allure in canada)	Digital radio receiver	●	●	●	●	○	●	T024
2008	Buick	Lacrosse (allure in canada)	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003 T093
2008	Buick	Lacrosse (allure in canada)	HVAC control module	●	●	●	●	●	●	T008

2008	Buick	Lacrosse (allure in canada)	Instrument panel cluster	●	●	●	●	●	●	T022
2008	Buick	Lacrosse (allure in canada)	Electronic brake control module	●	●	○	●	●	●	T014
2008	Buick	Lucerne	Powertrain control module	●	●	●	●	●	●	T001
2008	Buick	Lucerne	Engine control module	●	●	●	●	●	●	T001
2008	Buick	Lucerne	Transmission control module	●	●	●	●	●	●	T001
2008	Buick	Lucerne	Passenger presence system	●	●	●	●	○	●	T020
2008	Buick	Lucerne	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Buick	Lucerne	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Buick	Lucerne	Theft deterrent module	●	●	●	●	○	○	
2008	Buick	Lucerne	Radio	●	●	●	●	●	○	
2008	Buick	Lucerne	Veh direction alert alarm warn mod	●	●	●	●	●	○	
2008	Buick	Lucerne	Digital radio receiver	●	●	●	●	○	○	
2008	Buick	Lucerne	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Buick	Lucerne	HVAC control module	●	●	●	●	●	○	
2008	Buick	Lucerne	Body control module	●	●	●	●	●	●	T007 T005
2008	Buick	Lucerne	Left side object detection module	●	●	●	●	●	○	
2008	Buick	Lucerne	Right side object detection module	●	●	●	●	○	○	
2008	Buick	Lucerne	Memory seat module	●	●	●	●	●	○	
2008	Buick	Lucerne	Park assist module	●	●	●	●	●	○	
2008	Buick	Lucerne	Instrument panel cluster	●	●	●	●	●	○	
2008	Buick	Lucerne	Driver door switch	●	●	●	●	●	○	

2008	Buick	Lucerne	Passenger door switch	●	●	●	●	●	●	T020
2008	Buick	Lucerne	Electronic brake control module	●	●	●	●	●	●	T014
2008	Buick	Lucerne	Electronic suspension control	●	●	●	●	●	○	
2008	Buick	Others	Immobilizer	○	○	○	○	○	●	T016
2008	Buick	Others	Engine control module	●	●	●	●	●	●	T015
2008	Buick	Others	Transmission control module	●	●	●	●	●	●	T001
2008	Cadillac	SLS	Engine control module	●	●	●	●	●	○	
2008	Cadillac	SLS	Transmission control module	●	●	●	●	●	●	T001
2008	Cadillac	SLS	Radio	●	●	●	●	●	○	
2008	Cadillac	SLS	HVAC control module	●	●	●	●	●	○	
2008	Cadillac	SLS	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Cadillac	SLS	Amplifier (bose)	●	●	○	●	●	○	
2008	Cadillac	SLS	Remote control door lock receiver	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2008	Cadillac	SLS	TV antenna module	●	●	●	●	○	○	
2008	Cadillac	SLS	Passenger presence system	●	●	○	○	○	○	
2008	Cadillac	SLS	Driver position module	●	●	●	●	●	○	
2008	Cadillac	SLS	Driver door module	●	●	●	●	●	○	
2008	Cadillac	SLS	Driver door switch	●	●	●	●	○	○	
2008	Cadillac	SLS	Headlamp control module	●	●	●	●	○	○	
2008	Cadillac	SLS	Instrument panel module	●	●	●	●	●	●	T059
2008	Cadillac	SLS	Left rear door module	●	●	●	●	●	●	T068
2008	Cadillac	SLS	Passenger door module	●	●	●	●	●	●	T068
2008	Cadillac	SLS	Rear integration module	●	●	●	●	●	○	
2008	Cadillac	SLS	Right rear door module	●	●	●	●	●	●	T068

2008	Cadillac	SLS	Supplemental inflatable restraint	●	●	●	●	●	●	T067
2008	Cadillac	SLS	Instrument panel cluster	●	●	●	●	●	●	T088
2008	Cadillac	SLS	Electronic brake control module	●	●	●	●	●	●	T014
2008	Cadillac	SLS	Electronic suspension control	●	●	●	●	●	○	
2008	Cadillac	CTS	Transmission control module	●	●	○	●	●	○	
2008	Cadillac	CTS	Engine control module	●	●	●	●	●	○	
2008	Cadillac	CTS	Transfer case control module	●	●	●	●	●	○	
2008	Cadillac	CTS	Passenger presence system	●	●	●	●	○	●	T045
2008	Cadillac	CTS	Pedestrian impact detection module	●	●	●	●	●	●	T009
2008	Cadillac	CTS	Headlamp control module	●	●	●	●	●	○	
2008	Cadillac	CTS	TV antenna module	●	●	●	●	○	●	T012 T013
2008	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2008	Cadillac	CTS	HVAC control module	●	●	●	●	●	●	T008
2008	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2008	Cadillac	CTS	Radio	●	●	●	●	●	○	
2008	Cadillac	CTS	Body control module	●	●	●	●	●	●	T007 T005
2008	Cadillac	CTS	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Cadillac	CTS	Park assist module	●	●	●	●	●	○	
2008	Cadillac	CTS	Memory seat module	●	●	●	●	●	●	T011
2008	Cadillac	CTS	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Cadillac	CTS	Infotainment faceplate module	○	○	●	○	○	○	

2008	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T003 T093
2008	Cadillac	CTS	Driver door switch	●	●	●	●	●	○	
2008	Cadillac	CTS	Passenger door switch	●	●	●	●	●	○	
2008	Cadillac	CTS	Electronic brake control module	●	●	●	●	●	●	T014
2008	Cadillac	DTS	Engine control module	●	●	●	●	●	●	T001
2008	Cadillac	DTS	Transmission control module	●	●	○	●	●	○	
2008	Cadillac	DTS	Passenger presence system	●	●	●	●	○	●	T020
2008	Cadillac	DTS	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Cadillac	DTS	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Cadillac	DTS	Theft deterrent module	●	●	●	●	○	○	
2008	Cadillac	DTS	Amplifier (bose)	●	●	●	●	●	○	
2008	Cadillac	DTS	Radio	●	●	●	●	●	○	
2008	Cadillac	DTS	TV antenna module	●	●	●	●	○	●	T012 T013
2008	Cadillac	DTS	Veh direction alert alarm warn mod	●	●	●	●	●	○	
2008	Cadillac	DTS	Body control module	●	●	●	●	●	●	T007 T005
2008	Cadillac	DTS	Digital radio receiver	●	●	●	●	○	○	
2008	Cadillac	DTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Cadillac	DTS	HVAC control module	●	●	●	●	●	○	
2008	Cadillac	DTS	Left side object detection module	●	●	●	●	●	○	
2008	Cadillac	DTS	Right side object detection module	●	●	●	●	○	○	
2008	Cadillac	DTS	Driver position module	●	●	●	●	●	○	
2008	Cadillac	DTS	Inside rear view mirror module	●	●	●	○	○	○	
2008	Cadillac	DTS	Rear heated seat module	●	●	●	●	○	○	

2008	Cadillac	DTS	Park assist module	●	●	●	●	●	○	
2008	Cadillac	DTS	Distance sensing cruise control	●	●	●	●	●	○	
2008	Cadillac	DTS	Instrument panel cluster	●	●	●	●	●	○	
2008	Cadillac	DTS	Driver door switch	●	●	●	●	●	●	T035
2008	Cadillac	DTS	Passenger door switch	●	●	●	●	●	●	T035
2008	Cadillac	DTS	Aux. HVAC control module	●	●	●	●	●	●	T035
2008	Cadillac	DTS	Electronic brake control module	●	●	●	●	●	●	T014
2008	Cadillac	DTS	Electronic suspension control	●	●	●	●	●	○	
2008	Cadillac	STS	Transmission control module	●	●	○	●	●	○	
2008	Cadillac	STS	Engine control module	●	●	●	●	●	●	T001
2008	Cadillac	STS	Passenger presence system	●	●	○	○	○	○	
2008	Cadillac	STS	Remote control door lock receiver	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2008	Cadillac	STS	Supplemental inflatable restraint	●	●	●	●	●	●	T067
2008	Cadillac	STS	Amplifier (bose)	●	●	○	●	●	○	
2008	Cadillac	STS	Radio	●	●	●	●	○	●	T060 T033
2008	Cadillac	STS	TV antenna module	●	●	●	●	○	○	
2008	Cadillac	STS	Veh direction alert alarm warn mod	●	●	●	●	●	○	
2008	Cadillac	STS	Digital radio receiver	●	●	●	●	○	●	T024
2008	Cadillac	STS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Cadillac	STS	Head up display	●	●	●	●	●	○	
2008	Cadillac	STS	HVAC control module	●	●	●	●	●	○	

2008	Cadillac	STS	Headlamp control module	●	●	●	●	●	○	
2008	Cadillac	STS	Driver position module	●	●	●	●	●	○	
2008	Cadillac	STS	Steering column lock module	●	●	●	●	●	○	
2008	Cadillac	STS	Distance sensing cruise control	●	●	●	●	●	○	
2008	Cadillac	STS	Left side object detection module	●	●	●	●	●	○	
2008	Cadillac	STS	Right side object detection module	●	●	●	●	○	○	
2008	Cadillac	STS	Instrument panel cluster	●	●	●	●	●	○	
2008	Cadillac	STS	Instrument panel module	●	●	●	●	●	●	T059
2008	Cadillac	STS	Driver door module	●	●	●	●	●	●	T068
2008	Cadillac	STS	Driver door switch	●	●	●	●	○	○	
2008	Cadillac	STS	Left rear door module	●	●	●	●	●	●	T068
2008	Cadillac	STS	Passenger door module	●	●	●	●	●	●	T068
2008	Cadillac	STS	Right rear door module	●	●	●	●	●	●	T068
2008	Cadillac	STS	Rear integration module	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2008	Cadillac	STS	Navigation radio	●	●	●	●	●	●	T069
2008	Cadillac	STS	Power steering control module	●	●	○	●	○	●	T071 T072
2008	Cadillac	STS	Electronic suspension control	●	●	●	●	●	○	
2008	Cadillac	STS	Vehicle stability control module	○	○	○	○	●	○	
2008	Cadillac	STS	Electronic brake control module	●	●	●	●	●	●	T014
2008	Cadillac	XLR	Transmission control module	●	●	○	●	●	○	

2008	Cadillac	XLR	Engine control module	●	●	●	●	●	●	T001
2008	Cadillac	XLR	Exhaust flow control module	●	●	●	●	●	○	
2008	Cadillac	XLR	Passenger presence system	●	●	○	○	○	●	T020
2008	Cadillac	XLR	Remote control door lock receiver	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2008	Cadillac	XLR	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Cadillac	XLR	Amplifier (bose)	●	●	●	●	●	○	
2008	Cadillac	XLR	CD changer	●	●	●	○	○	○	
2008	Cadillac	XLR	Navigation radio	●	●	●	●	○	●	T033
2008	Cadillac	XLR	Body control module	●	●	●	●	●	●	T023
2008	Cadillac	XLR	HVAC control module	●	●	●	●	●	●	T008
2008	Cadillac	XLR	Headlamp control module	●	●	●	●	●	○	
2008	Cadillac	XLR	Digital radio receiver	●	●	●	●	○	●	T024
2008	Cadillac	XLR	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Cadillac	XLR	Head up display	●	●	●	●	●	○	
2008	Cadillac	XLR	Driver position module	●	●	●	●	●	●	T030
2008	Cadillac	XLR	Folding top module	●	●	●	●	●	○	
2008	Cadillac	XLR	Steering column lock module	●	●	●	●	●	○	
2008	Cadillac	XLR	Distance sensing cruise control	●	●	●	●	●	○	
2008	Cadillac	XLR	Instrument panel cluster	●	●	●	●	●	○	
2008	Cadillac	XLR	Driver door module	●	●	●	●	●	○	
2008	Cadillac	XLR	Passenger door module	●	●	●	●	●	○	
2008	Cadillac	XLR	Driver door switch	●	●	●	●	○	○	
2008	Cadillac	XLR	Electronic brake control module	●	●	●	●	●	●	T014

2008	Cadillac	XLR	Electronic suspension control	●	●	●	●	●	○	
2008	Chevrolet	Aveo	Engine control module	●	●	●	●	●	●	T015
2008	Chevrolet	Aveo	Transmission control module	●	●	●	●	●	●	T015
2008	Chevrolet	Aveo	Immobilizer	○	○	○	○	○	●	T016
2008	Chevrolet	Aveo	Supplemental inflatable restraint	●	●	●	●	●	●	T016
2008	Chevrolet	Aveo	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet	Aveo	Tire pressure monitor	●	●	●	●	●	●	T018 T019
2008	Chevrolet	Aveo	Passenger presence system	●	●	●	●	●	●	T045
2008	Chevrolet	Chevy	Transmission control module	●	●	●	●	●	○	
2008	Chevrolet	Chevy	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet	Chevy	Immobilizer	●	●	●	●	○	●	T052 T053
2008	Chevrolet	Cobalt	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet	Cobalt	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet	Cobalt	Passenger presence system	●	●	○	○	○	○	
2008	Chevrolet	Cobalt	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Chevrolet	Cobalt	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet	Cobalt	Body control module	●	●	●	●	●	●	T023
2008	Chevrolet	Cobalt	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet	Cobalt	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet	Cobalt	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet	Cobalt	Radio	●	●	●	●	●	○	
2008	Chevrolet	Cobalt	Instrument panel cluster	●	●	●	●	●	○	

2008	Chevrolet	Cobalt	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet	Cobalt	Power steering control module	●	●	○	●	○	○	
2008	Chevrolet	Cobalt	Electronic brake control module	●	●	●	●	●	○	
2008	Chevrolet	Corvette	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet	Corvette	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet	Corvette	Exhaust flow control module	●	●	●	●	●	●	T001
2008	Chevrolet	Corvette	Passenger presence system	●	●	○	○	○	●	T020
2008	Chevrolet	Corvette	Remote control door lock receiver	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2008	Chevrolet	Corvette	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Chevrolet	Corvette	CD changer	●	●	●	●	○	○	
2008	Chevrolet	Corvette	Body control module	●	●	●	●	●	●	T023
2008	Chevrolet	Corvette	Digital radio receiver	●	●	●	●	○	●	T024
2008	Chevrolet	Corvette	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet	Corvette	Head up display	●	●	●	●	●	○	
2008	Chevrolet	Corvette	HVAC control module	●	●	●	●	●	●	T008 T031
2008	Chevrolet	Corvette	Radio	●	●	●	●	○	●	T032 T033
2008	Chevrolet	Corvette	Steering column lock module	●	●	●	●	●	○	
2008	Chevrolet	Corvette	Driver position module	●	●	●	●	●	●	T030
2008	Chevrolet	Corvette	Folding top module	●	●	●	●	●	○	
2008	Chevrolet	Corvette	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet	Corvette	Driver door module	●	●	●	●	●	○	
2008	Chevrolet	Corvette	Driver door switch	●	●	●	●	○	○	
2008	Chevrolet	Corvette	Passenger door module	●	●	●	●	●	●	T020

2008	Chevrolet	Corvette	Navigation radio	●	●	●	●	●	●	T033
2008	Chevrolet	Corvette	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet	Corvette	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet	Corvette	Electronic suspension control	●	●	●	●	●	○	
2008	Chevrolet	Epica	Engine control module	●	●	●	●	●	●	T017
2008	Chevrolet	Epica	Transmission control module	●	●	●	●	●	●	T017
2008	Chevrolet	Epica	ISU	●	●	●	●	●	○	
2008	Chevrolet	Epica	Supplemental inflatable restraint	●	●	●	●	●	○	
2008	Chevrolet	Epica	Electronic brake control module	●	●	●	●	●	●	T015
2008	Chevrolet	Impala	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet	Impala	Transmission control module	●	●	●	●	●	●	T001
2008	Chevrolet	Impala	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet	Impala	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet	Impala	Radio	●	●	●	●	●	○	
2008	Chevrolet	Impala	Heated seat module	●	●	●	●	○	○	
2008	Chevrolet	Impala	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet	Impala	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet	Impala	Body control module	●	●	●	●	●	●	T007 T005
2008	Chevrolet	Impala	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet	Impala	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet	Impala	HVAC control module	●	●	●	●	●	●	T008

2008	Chevrolet	Impala	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet	Joy	Transmission control module	●	●	●	●	●	○	
2008	Chevrolet	Joy	Engine control module	●	●	●	●	●	●	T015
2008	Chevrolet	Joy	Immobilizer	○	○	○	○	○	●	T016
2008	Chevrolet	Joy	Supplemental inflatable restraint	●	●	●	●	○	○	
2008	Chevrolet	Joy	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet	Malibu	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet	Malibu	Transmission control module	●	●	●	●	●	●	T001
2008	Chevrolet	Malibu	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Chevrolet	Malibu	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet	Malibu	Passenger presence system	●	●	○	○	○	○	
2008	Chevrolet	Malibu	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet	Malibu	Radio	●	●	●	●	●	●	T033
2008	Chevrolet	Malibu	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet	Malibu	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet	Malibu	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet	Malibu	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet	Malibu	HVAC control module	●	●	●	●	●	○	
2008	Chevrolet	Malibu	Body control module	●	●	●	●	●	●	T008 T023
2008	Chevrolet	Malibu	Power steering control module	●	●	●	●	●	○	
2008	Chevrolet	Malibu	Electronic brake control module	●	●	●	●	●	●	T014

2008	Chevrolet	Malibu classic	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet	Malibu classic	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet	Malibu classic	Body control module	●	●	●	●	●	●	T008 T023
2008	Chevrolet	Malibu classic	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Chevrolet	Malibu classic	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet	Malibu classic	Passenger presence system	●	●	○	○	○	○	
2008	Chevrolet	Malibu classic	Disc player and video display	●	●	●	●	○	○	
2008	Chevrolet	Malibu classic	Radio	●	●	●	●	●	●	T102 T103 T033
2008	Chevrolet	Malibu classic	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet	Malibu classic	HVAC control module	●	●	●	●	●	○	
2008	Chevrolet	Malibu classic	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet	Malibu classic	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet	Malibu classic	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet	Malibu classic	Power steering control module	●	●	●	●	●	●	T104
2008	Chevrolet	Malibu hybrid	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet	Malibu hybrid	Engine control module	●	●	●	●	●	●	T074 T075 T001
2008	Chevrolet	Malibu hybrid	Battery energy control module	○	○	○	●	●	○	
2008	Chevrolet	Malibu hybrid	Starter/generator control module	○	○	○	●	●	○	
2008	Chevrolet	Malibu hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Chevrolet	Malibu hybrid	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet	Malibu hybrid	Passenger presence system	●	●	○	○	○	○	

2008	Chevrolet	Malibu hybrid	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet	Malibu hybrid	Radio	●	●	●	●	●	●	T033
2008	Chevrolet	Malibu hybrid	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet	Malibu hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet	Malibu hybrid	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet	Malibu hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet	Malibu hybrid	HVAC control module	●	●	●	●	●	○	
2008	Chevrolet	Malibu hybrid	Body control module	●	●	●	●	●	●	T008 T023
2008	Chevrolet	Malibu hybrid	Power steering control module	●	●	●	●	●	○	
2008	Chevrolet	Malibu hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet	Optra	Engine control module	●	●	●	●	●	●	T015
2008	Chevrolet	Optra	Transmission control module	●	●	●	●	●	●	T015
2008	Chevrolet	Optra	Immobilizer	○	○	○	○	○	●	T016
2008	Chevrolet	Optra	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2008	Chevrolet	Optra	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet	Optra - mexico	Engine control module	●	●	●	●	●	●	T015
2008	Chevrolet	Optra - mexico	Transmission control module	●	●	●	●	●	●	T015
2008	Chevrolet	Optra - mexico	Immobilizer	○	○	○	○	○	●	T016
2008	Chevrolet	Optra - mexico	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2008	Chevrolet	Optra - mexico	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet	Spark	Transmission control module	●	●	●	●	●	○	
2008	Chevrolet	Spark	Engine control module	●	●	●	●	●	●	T015
2008	Chevrolet	Spark	Immobilizer	○	○	○	○	○	●	T016

2008	Chevrolet	Spark	Supplemental inflatable restraint	●	●	●	●	○	○	
2008	Chevrolet	Spark	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet	Vivant	Engine control module	●	●	●	●	●	●	T015
2008	Chevrolet	Vivant	Transmission control module	●	●	●	●	●	●	T001
2008	Chevrolet	Vivant	Immobilizer	○	○	○	○	○	●	T016
2008	Chevrolet	Vivant	Supplemental inflatable restraint	●	●	●	●	○	○	
2008	Chevrolet	Vivant	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet	Others	Immobilizer	○	○	○	○	○	●	T016
2008	Chevrolet	Others	Engine control module	●	●	○	●	●	●	T001
2008	Chevrolet	Others	Transmission control module	●	●	●	●	●	●	T001
2008	Pontiac	G3	Engine control module	●	●	●	●	●	●	T015
2008	Pontiac	G3	Transmission control module	●	●	●	●	●	●	T015
2008	Pontiac	G3	Immobilizer	○	○	○	○	○	●	T016
2008	Pontiac	G3	Supplemental inflatable restraint	●	●	●	●	●	●	T016
2008	Pontiac	G3	Passenger presence system	●	●	●	●	●	●	T045
2008	Pontiac	G3	Electronic brake control module	●	●	●	●	●	●	T014
2008	Pontiac	G3	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2008	Pontiac	G5	Transmission control module	●	●	○	●	●	○	
2008	Pontiac	G5	Engine control module	●	●	●	●	●	●	T001
2008	Pontiac	G5	Passenger presence system	●	●	○	○	○	○	
2008	Pontiac	G5	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Pontiac	G5	Theft deterrent module	●	●	●	●	○	○	

2008	Pontiac	G5	Body control module	●	●	●	●	●	●	T023
2008	Pontiac	G5	Digital radio receiver	●	●	●	●	○	○	
2008	Pontiac	G5	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Pontiac	G5	Personal audio link module	●	●	●	○	○	●	T036
2008	Pontiac	G5	Radio	●	●	●	●	●	○	
2008	Pontiac	G5	Instrument panel cluster	●	●	●	●	●	○	
2008	Pontiac	G5	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Pontiac	G5	Power steering control module	●	●	○	●	○	○	
2008	Pontiac	G5	Electronic brake control module	●	●	●	●	●	○	
2008	Pontiac	G6	Transmission control module	●	●	○	●	●	○	
2008	Pontiac	G6	Engine control module	●	●	●	●	●	●	T001
2008	Pontiac	G6	Body control module	●	●	●	●	●	●	T008 T023
2008	Pontiac	G6	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Pontiac	G6	Theft deterrent module	●	●	●	●	○	○	
2008	Pontiac	G6	Passenger presence system	●	●	○	○	○	○	
2008	Pontiac	G6	Radio	●	●	●	●	●	●	T089 T090 T033
2008	Pontiac	G6	Digital radio receiver	●	●	●	●	○	○	
2008	Pontiac	G6	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Pontiac	G6	HVAC control module	●	●	●	●	●	○	
2008	Pontiac	G6	Instrument panel cluster	●	●	●	●	●	○	
2008	Pontiac	G6	Folding top module	●	●	●	●	●	○	
2008	Pontiac	G6	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2008	Pontiac	G6	Power steering control module	●	●	●	●	●	○	
2008	Pontiac	G6	Electronic brake control module	●	●	●	●	●	●	T014
2008	Pontiac	G8	Engine control module	●	●	●	●	●	○	
2008	Pontiac	G8	Transmission control module	●	●	●	●	●	●	T001
2008	Pontiac	G8	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Pontiac	G8	Body control module	●	●	●	●	●	●	T007 T005
2008	Pontiac	G8	Instrument panel cluster	●	●	●	●	●	○	
2008	Pontiac	G8	Passenger presence system	●	●	●	●	○	●	T020
2008	Pontiac	G8	Radio	●	●	●	●	●	○	
2008	Pontiac	G8	HVAC control module	●	●	●	●	●	○	
2008	Pontiac	G8	Driver information display	●	●	●	●	●	●	T091
2008	Pontiac	G8	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Pontiac	G8	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Pontiac	G8	Electronic brake control module	●	●	●	●	●	●	T014
2008	Pontiac	Grand prix	Engine control module	●	●	●	●	●	●	T001
2008	Pontiac	Grand prix	Transmission control module	●	●	○	●	●	○	
2008	Pontiac	Grand prix	Powertrain control module	●	●	●	●	●	●	T001
2008	Pontiac	Grand prix	Remote control door lock receiver	●	●	●	●	●	●	T022
2008	Pontiac	Grand prix	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Pontiac	Grand prix	Navigation radio	●	●	●	●	●	●	T033 T080 T032
2008	Pontiac	Grand prix	Body control module	●	●	●	●	●	●	T007

2008	Pontiac	Grand prix	Head up display	●	●	○	○	○	○	
2008	Pontiac	Grand prix	Digital radio receiver	●	●	●	●	○	●	T024
2008	Pontiac	Grand prix	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003 T093
2008	Pontiac	Grand prix	HVAC control module	●	●	●	●	●	●	T008
2008	Pontiac	Grand prix	Instrument panel cluster	●	●	●	●	●	○	
2008	Pontiac	Grand prix	Driver information center	●	●	●	●	●	●	T022
2008	Pontiac	Grand prix	Electronic brake control module	●	●	○	●	●	●	T014
2008	Pontiac	Solstice	Transmission control module	●	●	●	●	●	○	
2008	Pontiac	Solstice	Engine control module	●	●	●	●	●	●	T001
2008	Pontiac	Solstice	Passenger presence system	●	●	○	○	○	○	
2008	Pontiac	Solstice	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Pontiac	Solstice	Theft deterrent module	●	●	●	●	○	○	
2008	Pontiac	Solstice	Remote control door lock receiver	●	●	●	●	●	●	T021 T029 T022
2008	Pontiac	Solstice	Body control module	●	●	●	●	●	●	T023
2008	Pontiac	Solstice	Digital radio receiver	●	●	●	●	○	○	
2008	Pontiac	Solstice	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Pontiac	Solstice	Personal audio link module	●	●	●	○	○	●	T036
2008	Pontiac	Solstice	Radio	●	●	●	●	●	●	T033
2008	Pontiac	Solstice	Instrument panel cluster	●	●	●	●	●	○	
2008	Pontiac	Solstice	Electronic brake control module	●	●	●	●	●	○	
2008	Pontiac	Vibe - FWD	Powertrain control module	●	●	●	●	●	○	
2008	Pontiac	Vibe - FWD	Engine control module	●	●	●	●	●	○	

2008	Pontiac	Vibe - FWD	Digital radio receiver	●	●	●	●	○	●	T024
2008	Pontiac	Vibe - FWD	Immobilizer	●	●	○	●	○	●	T076
2008	Pontiac	Vibe - FWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2008	Pontiac	Vibe - FWD	Radio	●	●	○	●	●	●	T080
2008	Pontiac	Vibe - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Pontiac	Vibe - FWD	Tire pressure monitor	○	○	●	●	○	●	T078
2008	Pontiac	Vibe - FWD	Electronic brake control module	●	●	●	●	●	●	T105
2008	Pontiac	Wave	Engine control module	●	●	○	●	●	●	T001
2008	Pontiac	Wave	Transmission control module	●	●	●	●	●	●	T001
2008	Pontiac	Wave	Immobilizer	○	○	○	○	○	●	T016
2008	Pontiac	Wave	Supplemental inflatable restraint	●	●	●	●	●	●	T016
2008	Pontiac	Wave	Electronic brake control module	●	●	●	●	●	●	T014
2008	Pontiac	Wave	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2008	Saturn	AURA	Transmission control module	●	●	○	●	●	○	
2008	Saturn	AURA	Engine control module	●	●	●	●	●	●	T001
2008	Saturn	AURA	Body control module	●	●	●	●	●	●	T008 T023
2008	Saturn	AURA	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Saturn	AURA	Theft deterrent module	●	●	●	●	○	○	
2008	Saturn	AURA	Passenger presence system	●	●	○	○	○	○	
2008	Saturn	AURA	Personal audio link module	●	●	●	○	○	●	T036
2008	Saturn	AURA	Radio	●	●	●	●	●	●	T033
2008	Saturn	AURA	Digital radio receiver	●	●	●	●	○	○	
2008	Saturn	AURA	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Saturn	AURA	HVAC control module	●	●	●	●	●	○	

2008	Saturn	AURA	Instrument panel cluster	●	●	●	●	●	○	
2008	Saturn	AURA	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Saturn	AURA	Power steering control module	●	●	●	●	●	○	
2008	Saturn	AURA	Electronic brake control module	●	●	●	●	●	●	T014
2008	Saturn	AURA	Body control module	●	●	●	●	●	●	T008 T023
2008	Saturn	AURA	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Saturn	AURA	Theft deterrent module	●	●	●	●	○	○	
2008	Saturn	AURA	Passenger presence system	●	●	○	○	○	○	
2008	Saturn	AURA	Personal audio link module	●	●	●	○	○	●	T036
2008	Saturn	AURA	Radio	●	●	●	●	●	●	T033
2008	Saturn	AURA	Digital radio receiver	●	●	●	●	○	○	
2008	Saturn	AURA	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Saturn	AURA	HVAC control module	●	●	●	●	●	○	
2008	Saturn	AURA	Instrument panel cluster	●	●	●	●	●	○	
2008	Saturn	AURA	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Saturn	AURA	Electronic brake control module	●	●	●	●	●	●	T014
2008	Saturn	AURA	Power steering control module	●	●	●	●	●	○	
2008	Saturn	AURA	Engine control module	●	●	●	●	●	●	T074 T075 T001
2008	Saturn	AURA	Starter/generator control module	○	○	○	●	●	○	
2008	Saturn	AURA	Battery energy control module	○	○	○	●	●	○	

2008	Saturn	AURA	Transmission control module	●	●	○	●	●	○	
2008	Saturn	Sky	Transmission control module	●	●	●	●	●	○	
2008	Saturn	Sky	Engine control module	●	●	●	●	●	●	T001
2008	Saturn	Sky	Passenger presence system	●	●	○	○	○	○	
2008	Saturn	Sky	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Saturn	Sky	Theft deterrent module	●	●	●	●	○	○	
2008	Saturn	Sky	Remote control door lock receiver	●	●	●	●	●	●	T021 T029 T022
2008	Saturn	Sky	Body control module	●	●	●	●	●	●	T106 T023
2008	Saturn	Sky	Digital radio receiver	●	●	●	●	○	○	
2008	Saturn	Sky	Personal audio link module	●	●	●	○	○	●	T036
2008	Saturn	Sky	Radio	●	●	●	●	●	●	T033
2008	Saturn	Sky	Instrument panel cluster	●	●	●	●	●	○	
2008	Saturn	Sky	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Saturn	Sky	Electronic brake control module	●	●	●	●	●	○	
2008	Daewoo		4 Transmission control module	●	●	●	●	●	○	
2008	Daewoo		4 Engine control module	●	●	●	●	●	●	T015
2008	Daewoo		4 Transmission control module	●	●	●	●	●	○	
2008	Daewoo		4 Engine control module	●	●	●	●	●	●	T015
2008	Daewoo	B	Transmission control module	●	●	●	●	●	○	
2008	Daewoo	B	Engine control module	●	●	●	●	●	●	T015
2008	Daewoo	B	Transmission control module	●	●	●	●	●	○	
2008	Daewoo	B	Engine control module	●	●	●	●	●	●	T015

2008	Daewoo	M	Transmission control module	●	●	●	●	●	○	
2008	Daewoo	M	Engine control module	●	●	●	●	●	○	
2008	Daewoo	M	Passenger presence system	●	●	○	○	○	○	
2008	Daewoo	M	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Daewoo	M	Theft deterrent module	●	●	●	●	○	○	
2008	Daewoo	M	Remote control door lock receiver	●	●	●	●	●	●	T021 T029 T022
2008	Daewoo	M	Digital radio receiver	●	●	●	●	○	○	
2008	Daewoo	M	Radio	●	●	●	●	●	●	T033
2008	Daewoo	M	Instrument panel cluster	●	●	●	●	●	○	
2008	Daewoo	M	Electronic brake control module	●	●	●	●	●	○	
2008	Daewoo	M	Engine control module	●	●	●	●	●	○	
2008	Daewoo	M	Transmission control module	●	●	○	●	●	○	
2008	Buick	Enclave - AWD	Engine control module	●	●	●	●	●	●	T001
2008	Buick	Enclave - AWD	Transmission control module	●	●	○	●	●	○	
2008	Buick	Enclave - AWD	Passenger presence system	●	●	●	●	○	●	T045
2008	Buick	Enclave - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Buick	Enclave - AWD	Rollover sensor	●	●	●	●	○	●	T049
2008	Buick	Enclave - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Buick	Enclave - AWD	Theft deterrent module	●	●	●	●	○	○	
2008	Buick	Enclave - AWD	Memory seat module	●	●	●	●	●	○	
2008	Buick	Enclave - AWD	Park assist module	●	●	●	●	●	○	
2008	Buick	Enclave - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Buick	Enclave - AWD	Digital radio receiver	●	●	●	●	○	○	
2008	Buick	Enclave - AWD	Radio	●	●	●	●	●	○	

2008	Buick	Enclave - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Buick	Enclave - AWD	Body control module	○	○	○	○	○	●	T007 T005
2008	Buick	Enclave - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Buick	Enclave - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2008	Buick	Enclave - AWD	Driver door switch	●	●	●	●	●	●	T035
2008	Buick	Enclave - AWD	Passenger door switch	●	●	●	●	●	●	T035
2008	Buick	Enclave - AWD	Instrument panel cluster	○	○	○	○	●	○	
2008	Buick	Enclave - AWD	Headlamp control module	●	●	●	●	●	○	
2008	Buick	Enclave - AWD	Liftgate module	●	●	●	●	●	○	
2008	Buick	Enclave - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Buick	Enclave - AWD	Rear drive system	●	●	●	●	●	●	T038
2008	Buick	Enclave - FWD	Engine control module	●	●	●	●	●	●	T001
2008	Buick	Enclave - FWD	Rear drive system	●	●	●	●	●	●	T038
2008	Buick	Enclave - FWD	Passenger presence system	●	●	●	●	○	●	T045
2008	Buick	Enclave - FWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Buick	Enclave - FWD	Rollover sensor	●	●	●	●	○	●	T049
2008	Buick	Enclave - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Buick	Enclave - FWD	Theft deterrent module	●	●	●	●	○	○	
2008	Buick	Enclave - FWD	Memory seat module	●	●	●	●	●	○	
2008	Buick	Enclave - FWD	Park assist module	●	●	●	●	●	○	
2008	Buick	Enclave - FWD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Buick	Enclave - FWD	Digital radio receiver	●	●	●	●	○	○	
2008	Buick	Enclave - FWD	Radio	●	●	●	●	●	○	
2008	Buick	Enclave - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Buick	Enclave - FWD	Body control module	○	○	○	○	○	●	T007 T005
2008	Buick	Enclave - FWD	Rear HVAC/RSA	●	●	●	●	●	○	

2008	Buick	Enclave - FWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2008	Buick	Enclave - FWD	Driver door switch	●	●	●	●	●	●	T035
2008	Buick	Enclave - FWD	Passenger door switch	●	●	●	●	●	●	T035
2008	Buick	Enclave - FWD	Instrument panel cluster	○	○	○	○	●	○	
2008	Buick	Enclave - FWD	Headlamp control module	●	●	●	●	●	○	
2008	Buick	Enclave - FWD	Liftgate module	●	●	●	●	●	○	
2008	Buick	Enclave - FWD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Cadillac	Hearse	Engine control module	●	●	●	●	●	●	T001
2008	Cadillac	Hearse	Transmission control module	●	●	○	●	●	○	
2008	Cadillac	Hearse	Passenger presence system	●	●	●	●	○	●	T020
2008	Cadillac	Hearse	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Cadillac	Hearse	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Cadillac	Hearse	Theft deterrent module	●	●	●	●	○	○	
2008	Cadillac	Hearse	Amplifier (bose)	●	●	●	●	●	○	
2008	Cadillac	Hearse	Radio	●	●	●	●	●	○	
2008	Cadillac	Hearse	Instrument panel cluster	●	●	●	●	●	○	
2008	Cadillac	Hearse	Digital radio receiver	●	●	●	●	○	○	
2008	Cadillac	Hearse	HVAC control module	●	●	●	●	●	○	
2008	Cadillac	Hearse	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Cadillac	Hearse	Driver position module	●	●	●	●	●	○	
2008	Cadillac	Hearse	Rear heated seat module	●	●	●	●	○	○	
2008	Cadillac	Hearse	Body control module	●	●	●	●	●	●	T007 T005
2008	Cadillac	Hearse	Driver door switch	●	●	●	●	●	○	
2008	Cadillac	Hearse	Passenger door switch	●	●	●	●	●	○	

2008	Cadillac	Hearse	Air suspension control module	●	●	●	●	●	○	
2008	Cadillac	Hearse	Electronic brake control module	●	●	●	●	○	●	T014
2008	Cadillac	Limousine	Engine control module	●	●	●	●	●	●	T001
2008	Cadillac	Limousine	Transmission control module	●	●	○	●	●	○	
2008	Cadillac	Limousine	Passenger presence system	●	●	●	●	○	●	T020
2008	Cadillac	Limousine	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Cadillac	Limousine	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Cadillac	Limousine	Theft deterrent module	●	●	●	●	○	○	
2008	Cadillac	Limousine	Amplifier (bose)	●	●	●	●	●	○	
2008	Cadillac	Limousine	Radio	●	●	●	●	●	○	
2008	Cadillac	Limousine	Instrument panel cluster	●	●	●	●	●	○	
2008	Cadillac	Limousine	Digital radio receiver	●	●	●	●	○	○	
2008	Cadillac	Limousine	HVAC control module	●	●	●	●	●	○	
2008	Cadillac	Limousine	Aux. HVAC control module	○	○	●	●	●	○	
2008	Cadillac	Limousine	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Cadillac	Limousine	Driver position module	●	●	●	●	●	○	
2008	Cadillac	Limousine	Rear heated seat module	●	●	●	●	○	○	
2008	Cadillac	Limousine	Body control module	●	●	●	●	●	●	T007 T005
2008	Cadillac	Limousine	Driver door switch	●	●	●	●	●	○	
2008	Cadillac	Limousine	Passenger door switch	●	●	●	●	●	○	
2008	Cadillac	Limousine	Air suspension control module	●	●	●	●	●	○	
2008	Cadillac	Limousine	Electronic brake control module	●	●	●	●	○	●	T014

2008	Cadillac	Escalade - 2WD	Transmission control module	●	●	○	●	●	○	
2008	Cadillac	Escalade - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	Cadillac	Escalade - 2WD	Fuel pump control module	●	●	●	●	●	○	
2008	Cadillac	Escalade - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2008	Cadillac	Escalade - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Cadillac	Escalade - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2008	Cadillac	Escalade - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Cadillac	Escalade - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	Cadillac	Escalade - 2WD	Body control module	●	●	●	●	●	●	T005
2008	Cadillac	Escalade - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Cadillac	Escalade - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2008	Cadillac	Escalade - 2WD	Digital radio receiver	●	●	●	●	○	○	
2008	Cadillac	Escalade - 2WD	Radio	●	●	●	●	●	○	
2008	Cadillac	Escalade - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Cadillac	Escalade - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Cadillac	Escalade - 2WD	Memory seat module	●	●	●	●	●	○	
2008	Cadillac	Escalade - 2WD	Inside rear view mirror module	●	●	●	○	○	○	
2008	Cadillac	Escalade - 2WD	Rear heated seat module	●	●	●	●	○	○	
2008	Cadillac	Escalade - 2WD	Park assist module	●	●	●	●	●	○	
2008	Cadillac	Escalade - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Cadillac	Escalade - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2008	Cadillac	Escalade - 2WD	Passenger door switch	●	●	●	●	●	○	
2008	Cadillac	Escalade - 2WD	Driver door switch	●	●	●	●	●	○	
2008	Cadillac	Escalade - 2WD	Assist step controller	●	●	●	●	●	●	T039

2008	Cadillac	Escalade - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Cadillac	Escalade - 2WD	Liftgate module	●	●	●	●	●	●	T037
2008	Cadillac	Escalade - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Cadillac	Escalade - 2WD	Trailer brake control module	●	●	●	●	○	○	
2008	Cadillac	Escalade - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Cadillac	Escalade - AWD	Transmission control module	●	●	○	●	●	○	
2008	Cadillac	Escalade - AWD	Engine control module	●	●	●	●	●	●	T001
2008	Cadillac	Escalade - AWD	Fuel pump control module	●	●	●	●	●	○	
2008	Cadillac	Escalade - AWD	Passenger presence system	●	●	●	●	○	●	T020
2008	Cadillac	Escalade - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Cadillac	Escalade - AWD	Rollover sensor	●	●	●	●	○	●	T049
2008	Cadillac	Escalade - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Cadillac	Escalade - AWD	Theft deterrent module	●	●	●	●	○	○	
2008	Cadillac	Escalade - AWD	Body control module	●	●	●	●	●	●	T005
2008	Cadillac	Escalade - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Cadillac	Escalade - AWD	Amplifier (bose)	●	●	●	●	●	○	
2008	Cadillac	Escalade - AWD	Digital radio receiver	●	●	●	●	○	○	
2008	Cadillac	Escalade - AWD	Radio	●	●	●	●	●	○	
2008	Cadillac	Escalade - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Cadillac	Escalade - AWD	Instrument panel cluster	●	●	●	●	●	○	
2008	Cadillac	Escalade - AWD	Memory seat module	●	●	●	●	●	○	
2008	Cadillac	Escalade - AWD	Inside rear view mirror module	●	●	●	○	○	○	

2008	Cadillac	Escalade - AWD	Rear heated seat module	●	●	●	●	○	○	
2008	Cadillac	Escalade - AWD	Park assist module	●	●	●	●	●	○	
2008	Cadillac	Escalade - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Cadillac	Escalade - AWD	Personal audio link module	●	●	●	○	○	●	T036
2008	Cadillac	Escalade - AWD	Passenger door switch	●	●	●	●	●	○	
2008	Cadillac	Escalade - AWD	Driver door switch	●	●	●	●	●	○	
2008	Cadillac	Escalade - AWD	Assist step controller	●	●	●	●	●	●	T039
2008	Cadillac	Escalade - AWD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Cadillac	Escalade - AWD	Liftgate module	●	●	●	●	●	●	T037
2008	Cadillac	Escalade - AWD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Cadillac	Escalade - AWD	Trailer brake control module	●	●	●	●	○	○	
2008	Cadillac	Escalade - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Cadillac	Escalade ESV	Transmission control module	●	●	○	●	●	○	
2008	Cadillac	Escalade ESV	Engine control module	●	●	●	●	●	●	T001
2008	Cadillac	Escalade ESV	Fuel pump control module	●	●	●	●	●	○	
2008	Cadillac	Escalade ESV	Passenger presence system	●	●	●	●	○	●	T020
2008	Cadillac	Escalade ESV	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Cadillac	Escalade ESV	Rollover sensor	●	●	●	●	○	●	T049
2008	Cadillac	Escalade ESV	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Cadillac	Escalade ESV	Theft deterrent module	●	●	●	●	○	○	
2008	Cadillac	Escalade ESV	Body control module	●	●	●	●	●	●	T005
2008	Cadillac	Escalade ESV	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Cadillac	Escalade ESV	Amplifier (bose)	●	●	●	●	●	○	
2008	Cadillac	Escalade ESV	Digital radio receiver	●	●	●	●	○	○	

2008	Cadillac	Escalade ESV	Radio	●	●	●	●	●	○	
2008	Cadillac	Escalade ESV	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Cadillac	Escalade ESV	Instrument panel cluster	●	●	●	●	●	○	
2008	Cadillac	Escalade ESV	Memory seat module	●	●	●	●	●	○	
2008	Cadillac	Escalade ESV	Inside rear view mirror module	●	●	●	○	○	○	
2008	Cadillac	Escalade ESV	Rear heated seat module	●	●	●	●	○	○	
2008	Cadillac	Escalade ESV	Park assist module	●	●	●	●	●	○	
2008	Cadillac	Escalade ESV	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Cadillac	Escalade ESV	Personal audio link module	●	●	●	○	○	●	T036
2008	Cadillac	Escalade ESV	Passenger door switch	●	●	●	●	●	○	
2008	Cadillac	Escalade ESV	Driver door switch	●	●	●	●	●	○	
2008	Cadillac	Escalade ESV	Assist step controller	●	●	●	●	●	●	T039
2008	Cadillac	Escalade ESV	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Cadillac	Escalade ESV	Liftgate module	●	●	●	●	●	●	T037
2008	Cadillac	Escalade ESV	Electronic suspension control	●	●	●	●	●	●	T040
2008	Cadillac	Escalade ESV	Trailer brake control module	●	●	●	●	○	○	
2008	Cadillac	Escalade ESV	Electronic brake control module	●	●	●	●	●	●	T014
2008	Cadillac	Escalade EXT	Transmission control module	●	●	○	●	●	○	
2008	Cadillac	Escalade EXT	Engine control module	●	●	●	●	●	●	T001
2008	Cadillac	Escalade EXT	Fuel pump control module	●	●	●	●	●	○	
2008	Cadillac	Escalade EXT	Passenger presence system	●	●	●	●	○	●	T020
2008	Cadillac	Escalade EXT	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2008	Cadillac	Escalade EXT	Rollover sensor	●	●	●	●	○	●	T049
2008	Cadillac	Escalade EXT	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Cadillac	Escalade EXT	Theft deterrent module	●	●	●	●	○	○	
2008	Cadillac	Escalade EXT	Body control module	●	●	●	●	●	●	T005
2008	Cadillac	Escalade EXT	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Cadillac	Escalade EXT	Amplifier (bose)	●	●	●	●	●	○	
2008	Cadillac	Escalade EXT	Digital radio receiver	●	●	●	●	○	○	
2008	Cadillac	Escalade EXT	Radio	●	●	●	●	●	○	
2008	Cadillac	Escalade EXT	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Cadillac	Escalade EXT	Instrument panel cluster	●	●	●	●	●	○	
2008	Cadillac	Escalade EXT	Memory seat module	●	●	●	●	●	○	
2008	Cadillac	Escalade EXT	Inside rear view mirror module	●	●	●	○	○	○	
2008	Cadillac	Escalade EXT	Rear heated seat module	●	●	●	●	○	○	
2008	Cadillac	Escalade EXT	Park assist module	●	●	●	●	●	○	
2008	Cadillac	Escalade EXT	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Cadillac	Escalade EXT	Personal audio link module	●	●	●	○	○	●	T036
2008	Cadillac	Escalade EXT	Passenger door switch	●	●	●	●	●	○	
2008	Cadillac	Escalade EXT	Driver door switch	●	●	●	●	●	○	
2008	Cadillac	Escalade EXT	Assist step controller	●	●	●	●	●	●	T039
2008	Cadillac	Escalade EXT	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Cadillac	Escalade EXT	Liftgate module	●	●	●	●	●	●	T037
2008	Cadillac	Escalade EXT	Electronic suspension control	●	●	●	●	●	●	T040
2008	Cadillac	Escalade EXT	Trailer brake control module	●	●	●	●	○	○	
2008	Cadillac	Escalade EXT	Electronic brake control module	●	●	●	●	●	●	T014

2008	Cadillac	SRX	Transmission control module	●	●	○	●	●	○	
2008	Cadillac	SRX	Engine control module	●	●	●	●	●	●	T001
2008	Cadillac	SRX	Passenger presence system	●	●	●	●	○	●	T045
2008	Cadillac	SRX	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Cadillac	SRX	Rollover sensor	●	●	●	●	○	●	T049
2008	Cadillac	SRX	Theft deterrent module	●	●	●	●	○	○	
2008	Cadillac	SRX	TV antenna module	●	●	●	●	○	●	T012 T013
2008	Cadillac	SRX	Radio	●	●	●	●	●	○	
2008	Cadillac	SRX	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Cadillac	SRX	Amplifier (bose)	●	●	●	●	●	○	
2008	Cadillac	SRX	Digital radio receiver	●	●	●	●	○	○	
2008	Cadillac	SRX	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Cadillac	SRX	Body control module	●	●	●	●	●	●	T007 T005
2008	Cadillac	SRX	HVAC control module	●	●	●	●	●	○	
2008	Cadillac	SRX	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2008	Cadillac	SRX	Memory seat module	●	●	●	●	●	○	
2008	Cadillac	SRX	Rear seat module	●	●	●	●	●	○	
2008	Cadillac	SRX	Park assist module	●	●	●	●	●	○	
2008	Cadillac	SRX	Instrument panel cluster	●	●	●	●	●	○	
2008	Cadillac	SRX	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Cadillac	SRX	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Cadillac	SRX	Driver door switch	●	●	●	●	●	●	T035
2008	Cadillac	SRX	Passenger door switch	●	●	●	●	●	●	T035
2008	Cadillac	SRX	Liftgate module	●	●	●	●	●	○	
2008	Cadillac	SRX	Electronic brake control module	●	●	●	●	●	●	T014

2008	Cadillac	SRX	Electronic suspension control	●	●	○	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Avalanche - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Avalanche - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Avalanche - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Avalanche - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Avalanche - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 2WD	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Avalanche - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 2WD	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Memory seat module	●	●	●	●	●	○	

2008	Chevrolet truck	Avalanche - 2WD	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 2WD	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Avalanche - 2WD	Assist step controller	●	●	●	●	●	●	T039
2008	Chevrolet truck	Avalanche - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Avalanche - 2WD	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Avalanche - 2WD	Trailer brake control module	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Avalanche - 2WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Avalanche - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Avalanche - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Avalanche - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2008	Chevrolet truck	Avalanche - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Avalanche - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 2WD	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Avalanche - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 2WD	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 2WD	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Avalanche - 2WD	Assist step controller	●	●	●	●	●	●	T039
2008	Chevrolet truck	Avalanche - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006

2008	Chevrolet truck	Avalanche - 2WD	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 2WD	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Avalanche - 2WD	Trailer brake control module	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Avalanche - 4WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Avalanche - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Avalanche - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Avalanche - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Avalanche - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Avalanche - 4WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 4WD	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Avalanche - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	○	

2008	Chevrolet truck	Avalanche - 4WD	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 4WD	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 4WD	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Avalanche - 4WD	Assist step controller	●	●	●	●	●	●	T039
2008	Chevrolet truck	Avalanche - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Avalanche - 4WD	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Avalanche - 4WD	Trailer brake control module	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001

2008	Chevrolet truck	Avalanche - 4WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Avalanche - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Avalanche - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Avalanche - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Avalanche - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Avalanche - 4WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 4WD	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Avalanche - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 4WD	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Rear heated seat module	●	●	●	●	○	○	

2008	Chevrolet truck	Avalanche - 4WD	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Avalanche - 4WD	Assist step controller	●	●	●	●	●	●	T039
2008	Chevrolet truck	Avalanche - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Avalanche - 4WD	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Avalanche - 4WD	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Avalanche - 4WD	Trailer brake control module	●	●	●	●	○	○	
2008	Chevrolet truck	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Captiva	Engine control module	●	●	●	●	●	●	T017
2008	Chevrolet truck	Captiva	Transmission control module	●	●	●	●	●	●	T017
2008	Chevrolet truck	Captiva	Rear drive system	●	●	●	●	●	●	T038
2008	Chevrolet truck	Captiva	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Captiva	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Captiva	HVAC control module	●	●	●	○	●	○	

2008	Chevrolet truck	Captiva	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Captiva	Body control module (aux.)	●	●	●	●	●	○	
2008	Chevrolet truck	Captiva	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Captiva	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Captiva	Electronic brake control module	●	●	●	●	●	○	
2008	Chevrolet truck	Captiva sport	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Captiva sport	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Captiva sport	Rear drive system	●	●	●	●	●	●	T038
2008	Chevrolet truck	Captiva sport	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Captiva sport	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Captiva sport	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Captiva sport	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Captiva sport	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Captiva sport	Passenger presence system	●	●	●	●	○	●	T045
2008	Chevrolet truck	Captiva sport	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Captiva sport	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Captiva sport	HVAC control module	●	●	●	●	●	●	T008

2008	Chevrolet truck	Captiva sport	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Captiva sport	Electronic brake control module	●	●	●	●	●	○	
2008	Chevrolet truck	Colorado	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Colorado	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Colorado	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Chevrolet truck	Colorado	Passenger presence system	●	●	○	○	○	●	T020
2008	Chevrolet truck	Colorado	Body control module	●	●	●	●	●	●	T058 T022
2008	Chevrolet truck	Colorado	Digital radio receiver	●	●	●	●	○	●	T024
2008	Chevrolet truck	Colorado	Radio	●	●	●	●	○	○	
2008	Chevrolet truck	Colorado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Colorado	Theft deterrent module	●	●	●	●	○	●	T057
2008	Chevrolet truck	Colorado	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Colorado	Generator battery control module	●	●	●	●	●	●	T023
2008	Chevrolet truck	Colorado	Electronic brake control module	●	●	●	●	●	○	
2008	Chevrolet truck	Colorado	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Colorado	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Colorado	Engine control module	●	●	●	●	●	●	T001

2008	Chevrolet truck	Colorado	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Chevrolet truck	Colorado	Passenger presence system	●	●	○	○	○	●	T020
2008	Chevrolet truck	Colorado	Body control module	●	●	●	●	●	●	T058 T022
2008	Chevrolet truck	Colorado	Digital radio receiver	●	●	●	●	○	●	T024
2008	Chevrolet truck	Colorado	Radio	●	●	●	●	○	○	
2008	Chevrolet truck	Colorado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Colorado	Theft deterrent module	●	●	●	●	○	●	T057
2008	Chevrolet truck	Colorado	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Colorado	Generator battery control module	●	●	●	●	●	●	T023
2008	Chevrolet truck	Colorado	Electronic brake control module	●	●	●	●	●	○	
2008	Chevrolet truck	Colorado	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Colorado	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Colorado	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Colorado	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Chevrolet truck	Colorado	Passenger presence system	●	●	○	○	○	●	T020
2008	Chevrolet truck	Colorado	Body control module	●	●	●	●	●	●	T058 T022
2008	Chevrolet truck	Colorado	Digital radio receiver	●	●	●	●	○	●	T024

2008	Chevrolet truck	Colorado	Radio	●	●	●	●	○	○	
2008	Chevrolet truck	Colorado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Colorado	Theft deterrent module	●	●	●	●	○	●	T057
2008	Chevrolet truck	Colorado	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Colorado	Generator battery control module	●	●	●	●	●	●	T023
2008	Chevrolet truck	Colorado	Electronic brake control module	●	●	●	●	●	○	
2008	Chevrolet truck	Colorado	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Colorado	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Colorado	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Colorado	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Chevrolet truck	Colorado	Passenger presence system	●	●	○	○	○	●	T020
2008	Chevrolet truck	Colorado	Body control module	●	●	●	●	●	●	T058 T022
2008	Chevrolet truck	Colorado	Digital radio receiver	●	●	●	●	○	●	T024
2008	Chevrolet truck	Colorado	Radio	●	●	●	●	○	○	
2008	Chevrolet truck	Colorado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Colorado	Theft deterrent module	●	●	●	●	○	●	T057
2008	Chevrolet truck	Colorado	Instrument panel cluster	●	●	●	●	●	○	

2008	Chevrolet truck	Colorado	Generator battery control module	●	●	●	●	●	●	T023
2008	Chevrolet truck	Colorado	Electronic brake control module	●	●	●	●	●	○	
2008	Chevrolet truck	Colorado	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Equinox	Engine control module	●	●	●	●	●	○	
2008	Chevrolet truck	Equinox	Transmission control module	●	●	●	●	●	○	
2008	Chevrolet truck	Equinox	Rear drive system	●	●	●	●	●	●	T038
2008	Chevrolet truck	Equinox	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Equinox	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Equinox	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Equinox	Body control module	●	●	●	●	●	●	T007 T005
2008	Chevrolet truck	Equinox	Passenger presence system	●	●	●	●	○	●	T045
2008	Chevrolet truck	Equinox	Heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Equinox	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Equinox	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Equinox	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Equinox	HVAC control module	●	●	●	●	●	●	T008
2008	Chevrolet truck	Equinox	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2008	Chevrolet truck	Equinox	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Equinox	Power steering control module	●	●	○	●	○	○	
2008	Chevrolet truck	Equinox	Electronic brake control module	●	●	●	●	●	○	
2008	Chevrolet truck	Express	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Express	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Express	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Express	Auxiliary heater control module	●	●	●	●	●	●	T047 T079 T048 T048
2008	Chevrolet truck	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Express	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Express	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Express	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Express	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Express	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Express	Passenger presence system	●	●	●	●	○	●	T045
2008	Chevrolet truck	Express	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Express	Transmission control module	●	●	○	●	●	○	

2008	Chevrolet truck	Express	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Express	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Express	Auxiliary heater control module	●	●	●	●	●	●	T047 T079 T048 T048
2008	Chevrolet truck	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Express	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Express	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Express	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Express	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Express	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Express	Passenger presence system	●	●	●	●	○	●	T045
2008	Chevrolet truck	Express	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Express	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Express	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Express	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Express	Rollover sensor	●	●	●	●	○	●	T049

2008	Chevrolet truck	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Express	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Express	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Express	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Express	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Express	Passenger presence system	●	●	●	●	○	●	T045
2008	Chevrolet truck	Express	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Express	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Express	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Express	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Express	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Express	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Express	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Express	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Express	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Express	Body control module	●	●	●	●	●	●	T005

2008	Chevrolet truck	Express	Passenger presence system	●	●	●	●	○	●	T045
2008	Chevrolet truck	Express	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Tracker	Powertrain control module	●	●	●	●	●	○	
2008	Chevrolet truck	Tracker	Electronic brake control module	●	●	●	●	○	●	T107
2008	Chevrolet truck	HHR	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	HHR	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	HHR	Passenger presence system	●	●	○	○	○	○	
2008	Chevrolet truck	HHR	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Chevrolet truck	HHR	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	HHR	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	HHR	Body control module	●	●	●	●	●	●	T023
2008	Chevrolet truck	HHR	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	HHR	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	HHR	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	HHR	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	HHR	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	HHR	Electronic brake control module	●	●	●	●	●	○	

2008	Chevrolet truck	HHR	Power steering control module	●	●	●	●	●	○	
2008	Chevrolet truck	HHR panel	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	HHR panel	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	HHR panel	Passenger presence system	●	●	○	○	○	○	
2008	Chevrolet truck	HHR panel	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Chevrolet truck	HHR panel	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	HHR panel	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	HHR panel	Body control module	●	●	●	●	●	●	T023
2008	Chevrolet truck	HHR panel	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	HHR panel	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	HHR panel	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	HHR panel	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	HHR panel	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	HHR panel	Electronic brake control module	●	●	●	●	●	○	
2008	Chevrolet truck	HHR panel	Power steering control module	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Engine control module	●	●	●	●	●	●	T001

2008	Chevrolet truck	Silverado - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Silverado - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Silverado - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Silverado - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Silverado - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Silverado - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Silverado - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Silverado - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Silverado - 2WD	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Silverado - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Silverado - 2WD	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Personal audio link module	●	●	●	○	○	●	T036

2008	Chevrolet truck	Silverado - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Silverado - 2WD	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Silverado - 2WD	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Silverado - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Silverado - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Silverado - 2WD	Trailer brake control module	●	●	●	●	●	●	T040
2008	Chevrolet truck	Silverado - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Silverado - 2WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Silverado - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Silverado - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Silverado - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Silverado - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Silverado - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Silverado - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Silverado - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034

2008	Chevrolet truck	Silverado - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Silverado - 2WD	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Silverado - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Silverado - 2WD	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Silverado - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Silverado - 2WD	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Silverado - 2WD	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 2WD	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Silverado - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Silverado - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Silverado - 2WD	Trailer brake control module	●	●	●	●	●	●	T040

2008	Chevrolet truck	Silverado - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Silverado - 4WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Silverado - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Silverado - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Silverado - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Silverado - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Silverado - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Silverado - 4WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Silverado - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Silverado - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Silverado - 4WD	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Silverado - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Rear heated seat module	●	●	●	●	○	○	

2008	Chevrolet truck	Silverado - 4WD	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Silverado - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Silverado - 4WD	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Silverado - 4WD	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Silverado - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Silverado - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Silverado - 4WD	Trailer brake control module	●	●	●	●	●	●	T040
2008	Chevrolet truck	Silverado - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Silverado - 4WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Silverado - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Silverado - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Silverado - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Silverado - 4WD	Rollover sensor	●	●	●	●	○	●	T049

2008	Chevrolet truck	Silverado - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Silverado - 4WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Silverado - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Silverado - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Silverado - 4WD	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Silverado - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Silverado - 4WD	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Silverado - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Silverado - 4WD	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Silverado - 4WD	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Silverado - 4WD	Passenger door switch	●	●	●	●	●	●	T020

2008	Chevrolet truck	Silverado - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Silverado - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Silverado - 4WD	Trailer brake control module	●	●	●	●	●	●	T040
2008	Chevrolet truck	Silverado - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Suburban - 2WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Suburban - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Suburban - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Suburban - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Suburban - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Suburban - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 2WD	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Suburban - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 2WD	Radio	●	●	●	●	●	○	

2008	Chevrolet truck	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 2WD	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Suburban - 2WD	Assist step controller	●	●	●	●	●	●	T039
2008	Chevrolet truck	Suburban - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Suburban - 2WD	Liftgate module	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Suburban - 2WD	Trailer brake control module	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Suburban - 2WD	Transmission control module	●	●	○	●	●	○	

2008	Chevrolet truck	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Suburban - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Suburban - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Suburban - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Suburban - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Suburban - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 2WD	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Suburban - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 2WD	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 2WD	Park assist module	●	●	●	●	●	○	

2008	Chevrolet truck	Suburban - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Suburban - 2WD	Assist step controller	●	●	●	●	●	●	T039
2008	Chevrolet truck	Suburban - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Suburban - 2WD	Liftgate module	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 2WD	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Suburban - 2WD	Trailer brake control module	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Suburban - 4WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Suburban - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Suburban - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Suburban - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Suburban - 4WD	Rollover sensor	●	●	●	●	○	●	T049

2008	Chevrolet truck	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Suburban - 4WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 4WD	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Suburban - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 4WD	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 4WD	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Suburban - 4WD	Assist step controller	●	●	●	●	●	●	T039
2008	Chevrolet truck	Suburban - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Suburban - 4WD	Liftgate module	●	●	●	●	●	○	

2008	Chevrolet truck	Suburban - 4WD	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Suburban - 4WD	Trailer brake control module	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Suburban - 4WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Suburban - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Suburban - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Suburban - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Suburban - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Suburban - 4WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 4WD	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Suburban - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	○	

2008	Chevrolet truck	Suburban - 4WD	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 4WD	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 4WD	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Suburban - 4WD	Assist step controller	●	●	●	●	●	●	T039
2008	Chevrolet truck	Suburban - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Suburban - 4WD	Liftgate module	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Suburban - 4WD	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Suburban - 4WD	Trailer brake control module	●	●	●	●	○	○	
2008	Chevrolet truck	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014

2008	Chevrolet truck	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Tahoe	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Tahoe	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Tahoe	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Tahoe	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Tahoe	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Tahoe	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Tahoe	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Tahoe	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Tahoe	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Tahoe	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Tahoe	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Memory seat module	●	●	●	●	●	○	

2008	Chevrolet truck	Tahoe	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Tahoe	Assist step controller	●	●	●	●	●	●	T039
2008	Chevrolet truck	Tahoe	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Tahoe	Liftgate module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Tahoe	Trailer brake control module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Tahoe	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Tahoe	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Tahoe	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Tahoe	Fuel pump control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Tahoe	Passenger presence system	●	●	●	●	○	●	T020

2008	Chevrolet truck	Tahoe	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Tahoe	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Tahoe	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Tahoe	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Tahoe	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Tahoe	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Tahoe	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Tahoe	Assist step controller	●	●	●	●	●	●	T039

2008	Chevrolet truck	Tahoe	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Tahoe	Liftgate module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Tahoe	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Tahoe	Trailer brake control module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Tahoe	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Tahoe hybrid	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Tahoe hybrid	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	A/C compressor control module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Serial data gateway module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Tahoe hybrid	Amplifier (bose)	●	●	●	●	●	○	

2008	Chevrolet truck	Tahoe hybrid	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Tahoe hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Tahoe hybrid	Liftgate module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Passenger door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Power steering control module	●	●	○	●	○	●	T044
2008	Chevrolet truck	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Tahoe hybrid	Trailer brake control module	●	●	●	●	○	○	

2008	Chevrolet truck	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2008	Chevrolet truck	Tahoe hybrid	Accessory power module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Fuel pump control module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Tahoe hybrid	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Tahoe hybrid	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Tahoe hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Tahoe hybrid	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	

2008	Chevrolet truck	Tahoe hybrid	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Tahoe hybrid	Assist step controller	●	●	●	●	●	●	T039
2008	Chevrolet truck	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Tahoe hybrid	Liftgate module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Tahoe hybrid	Trailer brake control module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Tahoe hybrid	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Tahoe hybrid	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2008	Chevrolet truck	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	A/C compressor control module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Serial data gateway module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Body control module	●	●	●	●	●	●	T005
2008	Chevrolet truck	Tahoe hybrid	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Tahoe hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Tahoe hybrid	Liftgate module	●	●	●	●	●	○	

2008	Chevrolet truck	Tahoe hybrid	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Passenger door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Power steering control module	●	●	○	●	○	●	T044
2008	Chevrolet truck	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2008	Chevrolet truck	Tahoe hybrid	Trailer brake control module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2008	Chevrolet truck	Tahoe hybrid	Accessory power module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Transfer case control module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Fuel pump control module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Tahoe hybrid	Passenger presence system	●	●	●	●	○	●	T020
2008	Chevrolet truck	Tahoe hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Chevrolet truck	Tahoe hybrid	Rollover sensor	●	●	●	●	○	●	T049
2008	Chevrolet truck	Tahoe hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Chevrolet truck	Tahoe hybrid	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Body control module	●	●	●	●	●	●	T005

2008	Chevrolet truck	Tahoe hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Chevrolet truck	Tahoe hybrid	Amplifier (bose)	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Digital radio receiver	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Radio	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Tahoe hybrid	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Memory seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Rear heated seat module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Park assist module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Personal audio link module	●	●	●	○	○	●	T036
2008	Chevrolet truck	Tahoe hybrid	Assist step controller	●	●	●	●	●	●	T039
2008	Chevrolet truck	Tahoe hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2008	Chevrolet truck	Tahoe hybrid	Liftgate module	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Driver door switch	●	●	●	●	●	○	
2008	Chevrolet truck	Tahoe hybrid	Passenger door switch	●	●	●	●	●	●	T020
2008	Chevrolet truck	Tahoe hybrid	Electronic suspension control	●	●	●	●	●	●	T040

2008	Chevrolet truck	Tahoe hybrid	Trailer brake control module	●	●	●	●	○	○	
2008	Chevrolet truck	Tahoe hybrid	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Trailblazer - 2WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Trailblazer - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Trailblazer - 2WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Trailblazer - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2008	Chevrolet truck	Trailblazer - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2008	Chevrolet truck	Trailblazer - 2WD	Disc player and video display	●	●	●	○	○	○	
2008	Chevrolet truck	Trailblazer - 2WD	Radio	●	●	●	●	○	○	
2008	Chevrolet truck	Trailblazer - 2WD	Rear seat audio	●	●	●	●	○	○	
2008	Chevrolet truck	Trailblazer - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Trailblazer - 2WD	Generator battery control module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 2WD	Body control module	●	●	●	●	●	●	T058
2008	Chevrolet truck	Trailblazer - 2WD	Driver door module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 2WD	Passenger door module	●	●	●	●	●	○	

2008	Chevrolet truck	Trailblazer - 2WD	Liftgate module	●	●	●	●	●	●	T022
2008	Chevrolet truck	Trailblazer - 2WD	Driver seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 2WD	HVAC control module	●	●	●	●	●	●	T020
2008	Chevrolet truck	Trailblazer - 2WD	Navigation radio	●	●	●	●	●	●	T033
2008	Chevrolet truck	Trailblazer - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Trailblazer - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Trailblazer - 2WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Trailblazer - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Trailblazer - 2WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Trailblazer - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2008	Chevrolet truck	Trailblazer - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2008	Chevrolet truck	Trailblazer - 2WD	Disc player and video display	●	●	●	○	○	○	
2008	Chevrolet truck	Trailblazer - 2WD	Radio	●	●	●	●	○	○	
2008	Chevrolet truck	Trailblazer - 2WD	Rear seat audio	●	●	●	●	○	○	
2008	Chevrolet truck	Trailblazer - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Trailblazer - 2WD	Generator battery control module	●	●	●	●	●	○	

2008	Chevrolet truck	Trailblazer - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 2WD	Body control module	●	●	●	●	●	●	T058
2008	Chevrolet truck	Trailblazer - 2WD	Driver door module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 2WD	Passenger door module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 2WD	Liftgate module	●	●	●	●	●	●	T022
2008	Chevrolet truck	Trailblazer - 2WD	Driver seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 2WD	HVAC control module	●	●	●	●	●	●	T020
2008	Chevrolet truck	Trailblazer - 2WD	Navigation radio	●	●	●	●	●	●	T033
2008	Chevrolet truck	Trailblazer - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Trailblazer - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Trailblazer - 4WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Trailblazer - 4WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Trailblazer - 4WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 4WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Trailblazer - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2008	Chevrolet truck	Trailblazer - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2008	Chevrolet truck	Trailblazer - 4WD	Disc player and video display	●	●	●	○	○	○	

2008	Chevrolet truck	Trailblazer - 4WD	Radio	●	●	●	●	○	○	
2008	Chevrolet truck	Trailblazer - 4WD	Rear seat audio	●	●	●	●	○	○	
2008	Chevrolet truck	Trailblazer - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Trailblazer - 4WD	Generator battery control module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 4WD	Body control module	●	●	●	●	●	●	T058
2008	Chevrolet truck	Trailblazer - 4WD	Driver door module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 4WD	Passenger door module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 4WD	Liftgate module	●	●	●	●	●	●	T022
2008	Chevrolet truck	Trailblazer - 4WD	Driver seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 4WD	HVAC control module	●	●	●	●	●	●	T020
2008	Chevrolet truck	Trailblazer - 4WD	Navigation radio	●	●	●	●	●	●	T033
2008	Chevrolet truck	Trailblazer - 4WD	Electronic brake control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Trailblazer - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Trailblazer - 4WD	Transmission control module	●	●	○	●	●	○	
2008	Chevrolet truck	Trailblazer - 4WD	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Trailblazer - 4WD	Supplemental inflatable restraint	●	●	●	●	●	○	

2008	Chevrolet truck	Trailblazer - 4WD	Theft deterrent module	●	●	●	●	○	○	
2008	Chevrolet truck	Trailblazer - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2008	Chevrolet truck	Trailblazer - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2008	Chevrolet truck	Trailblazer - 4WD	Disc player and video display	●	●	●	○	○	○	
2008	Chevrolet truck	Trailblazer - 4WD	Radio	●	●	●	●	○	○	
2008	Chevrolet truck	Trailblazer - 4WD	Rear seat audio	●	●	●	●	○	○	
2008	Chevrolet truck	Trailblazer - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Chevrolet truck	Trailblazer - 4WD	Generator battery control module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 4WD	Body control module	●	●	●	●	●	●	T058
2008	Chevrolet truck	Trailblazer - 4WD	Driver door module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 4WD	Passenger door module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 4WD	Liftgate module	●	●	●	●	●	●	T022
2008	Chevrolet truck	Trailblazer - 4WD	Driver seat module	●	●	●	●	●	○	
2008	Chevrolet truck	Trailblazer - 4WD	HVAC control module	●	●	●	●	●	●	T020
2008	Chevrolet truck	Trailblazer - 4WD	Navigation radio	●	●	●	●	●	●	T033
2008	Chevrolet truck	Trailblazer - 4WD	Electronic brake control module	●	●	●	●	●	●	T001

2008	Chevrolet truck	Trailblazer - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Uplander	Engine control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Uplander	Transmission control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Uplander	Remote control door lock receiver	●	●	●	●	●	●	T022
2008	Chevrolet truck	Uplander	Passenger presence system	●	●	○	○	○	●	T020
2008	Chevrolet truck	Uplander	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Chevrolet truck	Uplander	Body control module	●	●	●	●	●	●	T007
2008	Chevrolet truck	Uplander	Digital radio receiver	●	●	●	●	○	●	T024
2008	Chevrolet truck	Uplander	Disc player and video display	●	●	●	○	○	○	
2008	Chevrolet truck	Uplander	Radio	●	●	●	●	○	●	T094 T095 T033
2008	Chevrolet truck	Uplander	HVAC control module	●	●	●	●	●	○	
2008	Chevrolet truck	Uplander	Left power sliding door module	●	●	●	●	●	○	
2008	Chevrolet truck	Uplander	Right power sliding door module	●	●	●	●	●	○	
2008	Chevrolet truck	Uplander	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003 T093
2008	Chevrolet truck	Uplander	Navigation radio	●	●	●	●	●	●	T033
2008	Chevrolet truck	Uplander	Electronic brake control module	●	●	●	●	●	●	T014
2008	Chevrolet truck	Uplander ext.	Engine control module	●	●	●	●	●	●	T001

2008	Chevrolet truck	Uplander ext.	Transmission control module	●	●	●	●	●	●	T001
2008	Chevrolet truck	Uplander ext.	Remote control door lock receiver	●	●	●	●	●	●	T022
2008	Chevrolet truck	Uplander ext.	Passenger presence system	●	●	○	○	○	●	T020
2008	Chevrolet truck	Uplander ext.	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Chevrolet truck	Uplander ext.	Body control module	●	●	●	●	●	●	T007
2008	Chevrolet truck	Uplander ext.	Digital radio receiver	●	●	●	●	○	●	T024
2008	Chevrolet truck	Uplander ext.	Disc player and video display	●	●	●	○	○	○	
2008	Chevrolet truck	Uplander ext.	Radio	●	●	●	●	○	●	T094 T095 T033
2008	Chevrolet truck	Uplander ext.	HVAC control module	●	●	●	●	●	○	
2008	Chevrolet truck	Uplander ext.	Left power sliding door module	●	●	●	●	●	○	
2008	Chevrolet truck	Uplander ext.	Right power sliding door module	●	●	●	●	●	○	
2008	Chevrolet truck	Uplander ext.	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003 T093
2008	Chevrolet truck	Uplander ext.	Navigation radio	●	●	●	●	●	●	T033
2008	Chevrolet truck	Uplander ext.	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Acadia - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Acadia - 2WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Acadia - 2WD	Passenger presence system	●	●	●	●	○	●	T045
2008	GMC truck	Acadia - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2008	GMC truck	Acadia - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Acadia - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Acadia - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Acadia - 2WD	Head up display	●	●	●	●	○	○	
2008	GMC truck	Acadia - 2WD	Memory seat module	●	●	●	●	●	○	
2008	GMC truck	Acadia - 2WD	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Acadia - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Acadia - 2WD	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Acadia - 2WD	Radio	●	●	●	●	●	○	
2008	GMC truck	Acadia - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Acadia - 2WD	Body control module	○	○	○	○	○	●	T007 T005
2008	GMC truck	Acadia - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Acadia - 2WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2008	GMC truck	Acadia - 2WD	Driver door switch	●	●	●	●	●	●	T035
2008	GMC truck	Acadia - 2WD	Passenger door switch	●	●	●	●	●	●	T035
2008	GMC truck	Acadia - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Acadia - 2WD	Liftgate module	●	●	●	●	●	●	T045
2008	GMC truck	Acadia - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Acadia - 2WD	Rear drive system	●	●	●	●	●	●	T038
2008	GMC truck	Acadia - 4WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Acadia - 4WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Acadia - 4WD	Passenger presence system	●	●	●	●	○	●	T045
2008	GMC truck	Acadia - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Acadia - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Acadia - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Acadia - 4WD	Theft deterrent module	●	●	●	●	○	○	

2008	GMC truck	Acadia - 4WD	Head up display	●	●	●	●	○	○	
2008	GMC truck	Acadia - 4WD	Memory seat module	●	●	●	●	●	○	
2008	GMC truck	Acadia - 4WD	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Acadia - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Acadia - 4WD	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Acadia - 4WD	Radio	●	●	●	●	●	○	
2008	GMC truck	Acadia - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Acadia - 4WD	Body control module	○	○	○	○	○	●	T007 T005
2008	GMC truck	Acadia - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Acadia - 4WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2008	GMC truck	Acadia - 4WD	Driver door switch	●	●	●	●	●	●	T035
2008	GMC truck	Acadia - 4WD	Passenger door switch	●	●	●	●	●	●	T035
2008	GMC truck	Acadia - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Acadia - 4WD	Liftgate module	●	●	●	●	●	●	T045
2008	GMC truck	Acadia - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Acadia - 4WD	Rear drive system	●	●	●	●	●	●	T038
2008	GMC truck	Canyon pickup - 2WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Canyon pickup - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	GMC truck	Canyon pickup - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2008	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022
2008	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2008	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	

2008	GMC truck	Canyon pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Canyon pickup - 2WD	Theft deterrent module	●	●	●	●	○	●	T057
2008	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Canyon pickup - 2WD	Generator battery control module	●	●	●	●	●	●	T023
2008	GMC truck	Canyon pickup - 2WD	Electronic brake control module	●	●	●	●	●	○	
2008	GMC truck	Canyon pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Canyon pickup - 2WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Canyon pickup - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	GMC truck	Canyon pickup - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2008	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022
2008	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2008	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	
2008	GMC truck	Canyon pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Canyon pickup - 2WD	Theft deterrent module	●	●	●	●	○	●	T057
2008	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Canyon pickup - 2WD	Generator battery control module	●	●	●	●	●	●	T023

2008	GMC truck	Canyon pickup - 2WD	Electronic brake control module	●	●	●	●	●	○	
2008	GMC truck	Canyon pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Canyon pickup - 4WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Canyon pickup - 4WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	GMC truck	Canyon pickup - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2008	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058 T022
2008	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2008	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	
2008	GMC truck	Canyon pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Canyon pickup - 4WD	Theft deterrent module	●	●	●	●	○	●	T057
2008	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Canyon pickup - 4WD	Generator battery control module	●	●	●	●	●	●	T023
2008	GMC truck	Canyon pickup - 4WD	Electronic brake control module	●	●	●	●	●	○	
2008	GMC truck	Canyon pickup - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Canyon pickup - 4WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Canyon pickup - 4WD	Engine control module	●	●	●	●	●	●	T001

2008	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	GMC truck	Canyon pickup - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2008	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058 T022
2008	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2008	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	
2008	GMC truck	Canyon pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Canyon pickup - 4WD	Theft deterrent module	●	●	●	●	○	●	T057
2008	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Canyon pickup - 4WD	Generator battery control module	●	●	●	●	●	●	T023
2008	GMC truck	Canyon pickup - 4WD	Electronic brake control module	●	●	●	●	●	○	
2008	GMC truck	Canyon pickup - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Envoy - 2WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Envoy - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Envoy - 2WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2008	GMC truck	Envoy - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Envoy - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2008	GMC truck	Envoy - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2008	GMC truck	Envoy - 2WD	Disc player and video display	●	●	●	○	○	○	
2008	GMC truck	Envoy - 2WD	Radio	●	●	●	●	○	○	
2008	GMC truck	Envoy - 2WD	Rear seat audio	●	●	●	●	○	○	

2008	GMC truck	Envoy - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Envoy - 2WD	Generator battery control module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Envoy - 2WD	Body control module	●	●	●	●	●	●	T058
2008	GMC truck	Envoy - 2WD	Driver door module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 2WD	Passenger door module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 2WD	Liftgate module	●	●	●	●	●	●	T022
2008	GMC truck	Envoy - 2WD	Driver seat module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 2WD	HVAC control module	●	●	●	●	●	●	T020
2008	GMC truck	Envoy - 2WD	Navigation radio	●	●	●	●	●	●	T033
2008	GMC truck	Envoy - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2008	GMC truck	Envoy - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Envoy - 2WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Envoy - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Envoy - 2WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2008	GMC truck	Envoy - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Envoy - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2008	GMC truck	Envoy - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2008	GMC truck	Envoy - 2WD	Disc player and video display	●	●	●	○	○	○	
2008	GMC truck	Envoy - 2WD	Radio	●	●	●	●	○	○	
2008	GMC truck	Envoy - 2WD	Rear seat audio	●	●	●	●	○	○	
2008	GMC truck	Envoy - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Envoy - 2WD	Generator battery control module	●	●	●	●	●	○	

2008	GMC truck	Envoy - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Envoy - 2WD	Body control module	●	●	●	●	●	●	T058
2008	GMC truck	Envoy - 2WD	Driver door module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 2WD	Passenger door module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 2WD	Liftgate module	●	●	●	●	●	●	T022
2008	GMC truck	Envoy - 2WD	Driver seat module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 2WD	HVAC control module	●	●	●	●	●	●	T020
2008	GMC truck	Envoy - 2WD	Navigation radio	●	●	●	●	●	●	T033
2008	GMC truck	Envoy - 2WD	Electronic brake control module	●	●	●	●	●	●	T001
2008	GMC truck	Envoy - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Envoy - 4WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Envoy - 4WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Envoy - 4WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2008	GMC truck	Envoy - 4WD	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Envoy - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2008	GMC truck	Envoy - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2008	GMC truck	Envoy - 4WD	Disc player and video display	●	●	●	○	○	○	
2008	GMC truck	Envoy - 4WD	Radio	●	●	●	●	○	○	
2008	GMC truck	Envoy - 4WD	Rear seat audio	●	●	●	●	○	○	
2008	GMC truck	Envoy - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Envoy - 4WD	Generator battery control module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Envoy - 4WD	Body control module	●	●	●	●	●	●	T058
2008	GMC truck	Envoy - 4WD	Driver door module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 4WD	Passenger door module	●	●	●	●	●	○	

2008	GMC truck	Envoy - 4WD	Liftgate module	●	●	●	●	●	●	T022
2008	GMC truck	Envoy - 4WD	Driver seat module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 4WD	HVAC control module	●	●	●	●	●	●	T020
2008	GMC truck	Envoy - 4WD	Navigation radio	●	●	●	●	●	●	T033
2008	GMC truck	Envoy - 4WD	Electronic brake control module	●	●	●	●	●	●	T001
2008	GMC truck	Envoy - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Envoy - 4WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Envoy - 4WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Envoy - 4WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2008	GMC truck	Envoy - 4WD	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Envoy - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2008	GMC truck	Envoy - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2008	GMC truck	Envoy - 4WD	Disc player and video display	●	●	●	○	○	○	
2008	GMC truck	Envoy - 4WD	Radio	●	●	●	●	○	○	
2008	GMC truck	Envoy - 4WD	Rear seat audio	●	●	●	●	○	○	
2008	GMC truck	Envoy - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Envoy - 4WD	Generator battery control module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Envoy - 4WD	Body control module	●	●	●	●	●	●	T058
2008	GMC truck	Envoy - 4WD	Driver door module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 4WD	Passenger door module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 4WD	Liftgate module	●	●	●	●	●	●	T022
2008	GMC truck	Envoy - 4WD	Driver seat module	●	●	●	●	●	○	
2008	GMC truck	Envoy - 4WD	HVAC control module	●	●	●	●	●	●	T020
2008	GMC truck	Envoy - 4WD	Navigation radio	●	●	●	●	●	●	T033

2008	GMC truck	Envoy - 4WD	Electronic brake control module	●	●	●	●	●	●	T001
2008	GMC truck	Envoy - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2008	GMC truck	Savana	Auxiliary heater control module	●	●	●	●	●	●	T047 T079 T048 T048
2008	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Savana	Radio	●	●	●	●	●	○	
2008	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T045
2008	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2008	GMC truck	Savana	Auxiliary heater control module	●	●	●	●	●	●	T047 T079 T048 T048
2008	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049

2008	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Savana	Radio	●	●	●	●	●	○	
2008	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T045
2008	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001
2008	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Savana	Radio	●	●	●	●	●	○	
2008	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T045
2008	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Savana	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Savana	Fuel pump control module	●	●	●	●	●	●	T001

2008	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Savana	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Savana	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Savana	Radio	●	●	●	●	●	○	
2008	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Savana	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Savana	Passenger presence system	●	●	●	●	○	●	T045
2008	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Sierra - 2WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Sierra - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2008	GMC truck	Sierra - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Sierra - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Sierra - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Sierra - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Sierra - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Sierra - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2008	GMC truck	Sierra - 2WD	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Sierra - 2WD	Radio	●	●	●	●	●	○	
2008	GMC truck	Sierra - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Sierra - 2WD	Instrument panel cluster	●	●	●	●	●	○	

2008	GMC truck	Sierra - 2WD	Memory seat module	●	●	●	●	●	○	
2008	GMC truck	Sierra - 2WD	Rear heated seat module	●	●	●	●	○	○	
2008	GMC truck	Sierra - 2WD	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Sierra - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Sierra - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2008	GMC truck	Sierra - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	GMC truck	Sierra - 2WD	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Sierra - 2WD	Driver door switch	●	●	●	●	●	○	
2008	GMC truck	Sierra - 2WD	Passenger door switch	●	●	●	●	●	●	T020
2008	GMC truck	Sierra - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	GMC truck	Sierra - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Sierra - 2WD	Trailer brake control module	●	●	●	●	●	●	T040
2008	GMC truck	Sierra - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra - 2WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Sierra - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2008	GMC truck	Sierra - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Sierra - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Sierra - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Sierra - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Sierra - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Sierra - 2WD	Amplifier (bose)	●	●	●	●	●	○	

2008	GMC truck	Sierra - 2WD	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Sierra - 2WD	Radio	●	●	●	●	●	○	
2008	GMC truck	Sierra - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Sierra - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Sierra - 2WD	Memory seat module	●	●	●	●	●	○	
2008	GMC truck	Sierra - 2WD	Rear heated seat module	●	●	●	●	○	○	
2008	GMC truck	Sierra - 2WD	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Sierra - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Sierra - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2008	GMC truck	Sierra - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	GMC truck	Sierra - 2WD	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Sierra - 2WD	Driver door switch	●	●	●	●	●	○	
2008	GMC truck	Sierra - 2WD	Passenger door switch	●	●	●	●	●	●	T020
2008	GMC truck	Sierra - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	GMC truck	Sierra - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Sierra - 2WD	Trailer brake control module	●	●	●	●	●	●	T040
2008	GMC truck	Sierra - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra - 4WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Sierra - 4WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2008	GMC truck	Sierra - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2008	GMC truck	Sierra - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Sierra - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Sierra - 4WD	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Sierra - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Sierra - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Sierra - 4WD	Radio	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Sierra - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Memory seat module	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Rear heated seat module	●	●	●	●	○	○	
2008	GMC truck	Sierra - 4WD	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2008	GMC truck	Sierra - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	GMC truck	Sierra - 4WD	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Sierra - 4WD	Driver door switch	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Passenger door switch	●	●	●	●	●	●	T020
2008	GMC truck	Sierra - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	GMC truck	Sierra - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Sierra - 4WD	Trailer brake control module	●	●	●	●	●	●	T040
2008	GMC truck	Sierra - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra - 4WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Sierra - 4WD	Engine control module	●	●	●	●	●	●	T001

2008	GMC truck	Sierra - 4WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2008	GMC truck	Sierra - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Sierra - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Sierra - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Sierra - 4WD	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Sierra - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Sierra - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Sierra - 4WD	Radio	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Sierra - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Memory seat module	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Rear heated seat module	●	●	●	●	○	○	
2008	GMC truck	Sierra - 4WD	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2008	GMC truck	Sierra - 4WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	GMC truck	Sierra - 4WD	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Sierra - 4WD	Driver door switch	●	●	●	●	●	○	
2008	GMC truck	Sierra - 4WD	Passenger door switch	●	●	●	●	●	●	T020
2008	GMC truck	Sierra - 4WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	GMC truck	Sierra - 4WD	Electronic brake control module	●	●	●	●	●	●	T014

2008	GMC truck	Sierra - 4WD	Trailer brake control module	●	●	●	●	●	●	T040
2008	GMC truck	Sierra - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra denali - 2WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra denali - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra denali - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2008	GMC truck	Sierra denali - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Sierra denali - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Sierra denali - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Sierra denali - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Sierra denali - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Sierra denali - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Sierra denali - 2WD	Radio	●	●	●	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Sierra denali - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Memory seat module	●	●	●	●	●	○	

2008	GMC truck	Sierra denali - 2WD	Rear heated seat module	●	●	●	●	○	○	
2008	GMC truck	Sierra denali - 2WD	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2008	GMC truck	Sierra denali - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	GMC truck	Sierra denali - 2WD	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Sierra denali - 2WD	Driver door switch	●	●	●	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Passenger door switch	●	●	●	●	●	●	T020
2008	GMC truck	Sierra denali - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	GMC truck	Sierra denali - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Sierra denali - 2WD	Trailer brake control module	●	●	●	●	●	●	T040
2008	GMC truck	Sierra denali - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra denali - 2WD	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra denali - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2008	GMC truck	Sierra denali - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2008	GMC truck	Sierra denali - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2008	GMC truck	Sierra denali - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Sierra denali - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Sierra denali - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Sierra denali - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Sierra denali - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Sierra denali - 2WD	Radio	●	●	●	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Sierra denali - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Memory seat module	●	●	●	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Rear heated seat module	●	●	●	●	○	○	
2008	GMC truck	Sierra denali - 2WD	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Sierra denali - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2008	GMC truck	Sierra denali - 2WD	Body control module (aux.)	●	●	●	●	●	●	T006
2008	GMC truck	Sierra denali - 2WD	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Sierra denali - 2WD	Driver door switch	●	●	●	●	●	○	

2008	GMC truck	Sierra denali - 2WD	Passenger door switch	●	●	●	●	●	●	T020
2008	GMC truck	Sierra denali - 2WD	Electronic suspension control	●	●	●	●	●	●	T040
2008	GMC truck	Sierra denali - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Sierra denali - 2WD	Trailer brake control module	●	●	●	●	●	●	T040
2008	GMC truck	Sierra denali - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Yukon	Passenger presence system	●	●	●	●	○	●	T020
2008	GMC truck	Yukon	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Yukon	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Yukon	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Yukon	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Yukon	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Yukon	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Yukon	Amplifier (bose)	●	●	●	●	●	○	
2008	GMC truck	Yukon	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Yukon	Radio	●	●	●	●	●	○	
2008	GMC truck	Yukon	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Yukon	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Yukon	Memory seat module	●	●	●	●	●	○	
2008	GMC truck	Yukon	Rear heated seat module	●	●	●	●	○	○	
2008	GMC truck	Yukon	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Yukon	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Yukon	Personal audio link module	●	●	●	○	○	●	T036
2008	GMC truck	Yukon	Assist step controller	●	●	●	●	●	●	T039

2008	GMC truck	Yukon	Body control module (aux.)	●	●	●	●	●	●	T006
2008	GMC truck	Yukon	Liftgate module	●	●	●	●	●	○	
2008	GMC truck	Yukon	Driver door switch	●	●	●	●	●	○	
2008	GMC truck	Yukon	Passenger door switch	●	●	●	●	●	●	T020
2008	GMC truck	Yukon	Electronic suspension control	●	●	●	●	●	●	T040
2008	GMC truck	Yukon	Trailer brake control module	●	●	●	●	○	○	
2008	GMC truck	Yukon	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Yukon	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Yukon	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Yukon	Fuel pump control module	●	●	●	●	●	●	T001
2008	GMC truck	Yukon	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Yukon	Passenger presence system	●	●	●	●	○	●	T020
2008	GMC truck	Yukon	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Yukon	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Yukon	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Yukon	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Yukon	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Yukon	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Yukon	Amplifier (bose)	●	●	●	●	●	○	
2008	GMC truck	Yukon	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Yukon	Radio	●	●	●	●	●	○	
2008	GMC truck	Yukon	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Yukon	Instrument panel cluster	●	●	●	●	●	○	

2008	GMC truck	Yukon	Memory seat module	●	●	●	●	●	○	
2008	GMC truck	Yukon	Rear heated seat module	●	●	●	●	○	○	
2008	GMC truck	Yukon	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Yukon	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Yukon	Personal audio link module	●	●	●	○	○	●	T036
2008	GMC truck	Yukon	Assist step controller	●	●	●	●	●	●	T039
2008	GMC truck	Yukon	Body control module (aux.)	●	●	●	●	●	●	T006
2008	GMC truck	Yukon	Liftgate module	●	●	●	●	●	○	
2008	GMC truck	Yukon	Driver door switch	●	●	●	●	●	○	
2008	GMC truck	Yukon	Passenger door switch	●	●	●	●	●	●	T020
2008	GMC truck	Yukon	Electronic suspension control	●	●	●	●	●	●	T040
2008	GMC truck	Yukon	Trailer brake control module	●	●	●	●	○	○	
2008	GMC truck	Yukon	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Yukon	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Yukon	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Yukon	Fuel pump control module	●	●	●	●	●	●	T001
2008	GMC truck	Yukon	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Yukon hybrid	Passenger presence system	●	●	●	●	○	●	T020
2008	GMC truck	Yukon hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Yukon hybrid	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Yukon hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Yukon hybrid	Theft deterrent module	●	●	●	●	○	○	

2008	GMC truck	Yukon hybrid	A/C compressor control module	●	●	●	●	○	○	
2008	GMC truck	Yukon hybrid	Serial data gateway module	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Yukon hybrid	Amplifier (bose)	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Yukon hybrid	Radio	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Yukon hybrid	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Memory seat module	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Rear heated seat module	●	●	●	●	○	○	
2008	GMC truck	Yukon hybrid	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Personal audio link module	●	●	●	○	○	●	T036
2008	GMC truck	Yukon hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2008	GMC truck	Yukon hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Yukon hybrid	Liftgate module	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Driver door switch	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Passenger door switch	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Power steering control module	●	●	○	●	○	●	T044
2008	GMC truck	Yukon hybrid	Electronic suspension control	●	●	●	●	●	●	T040
2008	GMC truck	Yukon hybrid	Trailer brake control module	●	●	●	●	○	○	
2008	GMC truck	Yukon hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2008	GMC truck	Yukon hybrid	Passenger presence system	●	●	●	●	○	●	T020

2008	GMC truck	Yukon hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Yukon hybrid	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Yukon hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Yukon hybrid	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Yukon hybrid	A/C compressor control module	●	●	●	●	○	○	
2008	GMC truck	Yukon hybrid	Serial data gateway module	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Yukon hybrid	Amplifier (bose)	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Yukon hybrid	Radio	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Yukon hybrid	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Memory seat module	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Rear heated seat module	●	●	●	●	○	○	
2008	GMC truck	Yukon hybrid	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Personal audio link module	●	●	●	○	○	●	T036
2008	GMC truck	Yukon hybrid	Body control module (aux.)	●	●	●	●	●	●	T006
2008	GMC truck	Yukon hybrid	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Yukon hybrid	Liftgate module	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Driver door switch	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Passenger door switch	●	●	●	●	●	○	
2008	GMC truck	Yukon hybrid	Power steering control module	●	●	○	●	○	●	T044
2008	GMC truck	Yukon hybrid	Electronic suspension control	●	●	●	●	●	●	T040

2008	GMC truck	Yukon hybrid	Trailer brake control module	●	●	●	●	○	○	
2008	GMC truck	Yukon hybrid	Electronic brake control module	●	●	●	●	●	●	T041 T041 T042 T043
2008	GMC truck	Yukon XL	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Yukon XL	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Yukon XL	Fuel pump control module	●	●	●	●	●	●	T001
2008	GMC truck	Yukon XL	Passenger presence system	●	●	●	●	○	●	T020
2008	GMC truck	Yukon XL	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Yukon XL	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Yukon XL	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Yukon XL	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Yukon XL	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Yukon XL	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Yukon XL	Amplifier (bose)	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Yukon XL	Radio	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Yukon XL	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Memory seat module	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Rear heated seat module	●	●	●	●	○	○	
2008	GMC truck	Yukon XL	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Personal audio link module	●	●	●	○	○	●	T036
2008	GMC truck	Yukon XL	Assist step controller	●	●	●	●	●	●	T039

2008	GMC truck	Yukon XL	Body control module (aux.)	●	●	●	●	●	●	T006
2008	GMC truck	Yukon XL	Liftgate module	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Driver door switch	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Passenger door switch	●	●	●	●	●	●	T020
2008	GMC truck	Yukon XL	Electronic suspension control	●	●	●	●	●	●	T040
2008	GMC truck	Yukon XL	Trailer brake control module	●	●	●	●	○	○	
2008	GMC truck	Yukon XL	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Yukon XL	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Yukon XL	Transmission control module	●	●	○	●	●	○	
2008	GMC truck	Yukon XL	Engine control module	●	●	●	●	●	●	T001
2008	GMC truck	Yukon XL	Fuel pump control module	●	●	●	●	●	●	T001
2008	GMC truck	Yukon XL	Passenger presence system	●	●	●	●	○	●	T020
2008	GMC truck	Yukon XL	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Yukon XL	Rollover sensor	●	●	●	●	○	●	T049
2008	GMC truck	Yukon XL	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Yukon XL	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Yukon XL	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Yukon XL	HVAC control module	●	●	●	●	●	●	T008 T034
2008	GMC truck	Yukon XL	Amplifier (bose)	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Digital radio receiver	●	●	●	●	○	○	
2008	GMC truck	Yukon XL	Radio	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	GMC truck	Yukon XL	Instrument panel cluster	●	●	●	●	●	○	

2008	GMC truck	Yukon XL	Memory seat module	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Rear heated seat module	●	●	●	●	○	○	
2008	GMC truck	Yukon XL	Park assist module	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Rear HVAC/RSA	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Personal audio link module	●	●	●	○	○	●	T036
2008	GMC truck	Yukon XL	Assist step controller	●	●	●	●	●	●	T039
2008	GMC truck	Yukon XL	Body control module (aux.)	●	●	●	●	●	●	T006
2008	GMC truck	Yukon XL	Liftgate module	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Driver door switch	●	●	●	●	●	○	
2008	GMC truck	Yukon XL	Passenger door switch	●	●	●	●	●	●	T020
2008	GMC truck	Yukon XL	Electronic suspension control	●	●	●	●	●	●	T040
2008	GMC truck	Yukon XL	Trailer brake control module	●	●	●	●	○	○	
2008	GMC truck	Yukon XL	Electronic brake control module	●	●	●	●	●	●	T014
2008	GMC truck	Yukon XL	Transfer case control module	●	●	●	●	●	●	T001
2008	GMC truck	Others	Engine control module	●	●	●	●	●	●	T070
2008	GMC truck	Others	Transmission control module	●	●	●	●	●	●	T070
2008	GMC truck	Others	Rear drive system	●	●	●	●	●	●	T038
2008	GMC truck	Others	Instrument panel cluster	●	●	●	●	●	○	
2008	GMC truck	Others	Body control module	●	●	●	●	●	●	T005
2008	GMC truck	Others	Body control module (aux.)	●	●	●	●	●	○	
2008	GMC truck	Others	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	GMC truck	Others	Headlamp control module	●	●	●	●	●	○	
2008	GMC truck	Others	Park assist module	●	●	●	●	○	○	

2008	GMC truck	Others	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	GMC truck	Others	Theft deterrent module	●	●	●	●	○	○	
2008	GMC truck	Others	HVAC control module	●	●	●	○	●	○	
2008	GMC truck	Others	Radio	●	●	●	●	●	○	
2008	GMC truck	Others	Front display interface module	●	●	●	●	●	●	T005
2008	GMC truck	Others	Electronic brake control module	●	●	●	●	●	○	
2008	Pontiac	Montana SV6	Engine control module	●	●	●	●	●	●	T001
2008	Pontiac	Montana SV6	Transmission control module	●	●	●	●	●	●	T001
2008	Pontiac	Montana SV6	Remote control door lock receiver	●	●	●	●	●	●	T022
2008	Pontiac	Montana SV6	Passenger presence system	●	●	○	○	○	●	T020
2008	Pontiac	Montana SV6	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Pontiac	Montana SV6	Body control module	●	●	●	●	●	●	T007
2008	Pontiac	Montana SV6	Digital radio receiver	●	●	●	●	○	●	T024
2008	Pontiac	Montana SV6	Disc player and video display	●	●	●	○	○	○	
2008	Pontiac	Montana SV6	Radio	●	●	●	●	○	●	T094 T095 T033
2008	Pontiac	Montana SV6	HVAC control module	●	●	●	●	●	○	
2008	Pontiac	Montana SV6	Left power sliding door module	●	●	●	●	●	○	
2008	Pontiac	Montana SV6	Right power sliding door module	●	●	●	●	●	○	
2008	Pontiac	Montana SV6	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003 T093
2008	Pontiac	Montana SV6	Navigation radio	●	●	●	●	●	●	T033
2008	Pontiac	Montana SV6	Electronic brake control module	●	●	●	●	●	●	T014
2008	Pontiac	Montana SV6 ext.	Engine control module	●	●	●	●	●	●	T001

2008	Pontiac	Montana SV6 ext.	Transmission control module	●	●	●	●	●	●	T001
2008	Pontiac	Montana SV6 ext.	Remote control door lock receiver	●	●	●	●	●	●	T022
2008	Pontiac	Montana SV6 ext.	Passenger presence system	●	●	○	○	○	●	T020
2008	Pontiac	Montana SV6 ext.	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Pontiac	Montana SV6 ext.	Body control module	●	●	●	●	●	●	T007
2008	Pontiac	Montana SV6 ext.	Digital radio receiver	●	●	●	●	○	●	T024
2008	Pontiac	Montana SV6 ext.	Disc player and video display	●	●	●	○	○	○	
2008	Pontiac	Montana SV6 ext.	Radio	●	●	●	●	○	●	T094 T095 T033
2008	Pontiac	Montana SV6 ext.	HVAC control module	●	●	●	●	●	○	
2008	Pontiac	Montana SV6 ext.	Left power sliding door module	●	●	●	●	●	○	
2008	Pontiac	Montana SV6 ext.	Right power sliding door module	●	●	●	●	●	○	
2008	Pontiac	Montana SV6 ext.	Vehicle comm. interface module	●	●	●	●	●	●	T073 T003 T093
2008	Pontiac	Montana SV6 ext.	Navigation radio	●	●	●	●	●	●	T033
2008	Pontiac	Montana SV6 ext.	Electronic brake control module	●	●	●	●	●	●	T014
2008	Pontiac	Torrent	Transmission control module	●	●	○	●	●	○	
2008	Pontiac	Torrent	Engine control module	●	●	●	●	●	●	T001
2008	Pontiac	Torrent	Rear drive system	●	●	●	●	●	●	T038
2008	Pontiac	Torrent	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Pontiac	Torrent	Digital radio receiver	●	●	●	●	○	○	

2008	Pontiac	Torrent	Rollover sensor	●	●	●	●	○	●	T049
2008	Pontiac	Torrent	Body control module	●	●	●	●	●	●	T007 T005
2008	Pontiac	Torrent	Instrument panel cluster	●	●	●	●	●	○	
2008	Pontiac	Torrent	Passenger presence system	●	●	●	●	○	●	T045
2008	Pontiac	Torrent	Heated seat module	●	●	●	●	○	○	
2008	Pontiac	Torrent	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Pontiac	Torrent	Radio	●	●	●	●	●	○	
2008	Pontiac	Torrent	HVAC control module	●	●	●	●	●	●	T008
2008	Pontiac	Torrent	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Pontiac	Torrent	Theft deterrent module	●	●	●	●	○	○	
2008	Pontiac	Torrent	Power steering control module	●	●	○	●	○	○	
2008	Pontiac	Torrent	Electronic brake control module	●	●	●	●	●	○	
2008	Saturn	OUTLOOK - AWD	Engine control module	●	●	●	●	●	●	T001
2008	Saturn	OUTLOOK - AWD	Transmission control module	●	●	○	●	●	○	
2008	Saturn	OUTLOOK - AWD	Passenger presence system	●	●	●	●	○	●	T045
2008	Saturn	OUTLOOK - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Saturn	OUTLOOK - AWD	Rollover sensor	●	●	●	●	○	●	T049
2008	Saturn	OUTLOOK - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Saturn	OUTLOOK - AWD	Theft deterrent module	●	●	●	●	○	○	
2008	Saturn	OUTLOOK - AWD	Memory seat module	●	●	●	●	●	○	
2008	Saturn	OUTLOOK - AWD	Park assist module	●	●	●	●	●	○	
2008	Saturn	OUTLOOK - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Saturn	OUTLOOK - AWD	Digital radio receiver	●	●	●	●	○	○	
2008	Saturn	OUTLOOK - AWD	Radio	●	●	●	●	●	○	

2008	Saturn	OUTLOOK - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Saturn	OUTLOOK - AWD	Body control module	○	○	○	○	○	●	T007 T005
2008	Saturn	OUTLOOK - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Saturn	OUTLOOK - AWD	Personal audio link module	●	●	●	○	○	●	T036 T037
2008	Saturn	OUTLOOK - AWD	Driver door switch	●	●	●	●	●	●	T035
2008	Saturn	OUTLOOK - AWD	Passenger door switch	●	●	●	●	●	●	T035
2008	Saturn	OUTLOOK - AWD	Instrument panel cluster	●	●	●	●	●	○	
2008	Saturn	OUTLOOK - AWD	Liftgate module	●	●	●	●	●	●	T045
2008	Saturn	OUTLOOK - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Saturn	OUTLOOK - AWD	Rear drive system	●	●	●	●	●	●	T038
2008	Saturn	OUTLOOK - 2WD	Engine control module	●	●	●	●	●	●	T001
2008	Saturn	OUTLOOK - 2WD	Transmission control module	●	●	○	●	●	○	
2008	Saturn	OUTLOOK - 2WD	Passenger presence system	●	●	●	●	○	●	T045
2008	Saturn	OUTLOOK - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Saturn	OUTLOOK - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2008	Saturn	OUTLOOK - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Saturn	OUTLOOK - 2WD	Theft deterrent module	●	●	●	●	○	○	
2008	Saturn	OUTLOOK - 2WD	Memory seat module	●	●	●	●	●	○	
2008	Saturn	OUTLOOK - 2WD	Park assist module	●	●	●	●	●	○	
2008	Saturn	OUTLOOK - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Saturn	OUTLOOK - 2WD	Digital radio receiver	●	●	●	●	○	○	
2008	Saturn	OUTLOOK - 2WD	Radio	●	●	●	●	●	○	
2008	Saturn	OUTLOOK - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Saturn	OUTLOOK - 2WD	Body control module	○	○	○	○	○	●	T007 T005
2008	Saturn	OUTLOOK - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	

2008	Saturn	OUTLOOK - 2WD	Personal audio link module	●	●	●	○	○	●	T036 T037
2008	Saturn	OUTLOOK - 2WD	Driver door switch	●	●	●	●	●	●	T035
2008	Saturn	OUTLOOK - 2WD	Passenger door switch	●	●	●	●	●	●	T035
2008	Saturn	OUTLOOK - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2008	Saturn	OUTLOOK - 2WD	Liftgate module	●	●	●	●	●	●	T045
2008	Saturn	OUTLOOK - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2008	Saturn	OUTLOOK - 2WD	Rear drive system	●	●	●	●	●	●	T038
2008	Saturn	VUE	Transmission control module	●	●	○	●	●	○	
2008	Saturn	VUE	Fuel pump control module	●	●	●	●	●	○	
2008	Saturn	VUE	Engine control module	●	●	●	●	●	●	T001
2008	Saturn	VUE	Rear drive system	●	●	●	●	●	●	T038
2008	Saturn	VUE	Instrument panel cluster	●	●	●	●	●	○	
2008	Saturn	VUE	Digital radio receiver	●	●	●	●	○	○	
2008	Saturn	VUE	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Saturn	VUE	Theft deterrent module	●	●	●	●	○	○	
2008	Saturn	VUE	Radio	●	●	●	●	●	○	
2008	Saturn	VUE	Rollover sensor	●	●	●	●	○	●	T049
2008	Saturn	VUE	Passenger presence system	●	●	●	●	○	●	T045
2008	Saturn	VUE	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Saturn	VUE	Body control module	●	●	●	●	●	●	T005
2008	Saturn	VUE	HVAC control module	●	●	●	●	●	●	T008
2008	Saturn	VUE	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Saturn	VUE	Power steering control module	●	●	○	●	○	○	

2008	Saturn	VUE	Electronic brake control module	●	●	●	●	●	○	
2008	Saturn	VUE	Engine control module	●	●	●	●	●	●	T074 T075 T001
2008	Saturn	VUE	Battery energy control module	○	○	○	●	●	○	
2008	Saturn	VUE	Starter/generator control module	○	○	○	●	●	○	
2008	Saturn	VUE	Transmission control module	●	●	○	●	●	○	
2008	Saturn	VUE	Fuel pump control module	●	●	●	●	●	○	
2008	Saturn	VUE	Digital radio receiver	●	●	●	●	○	○	
2008	Saturn	VUE	Theft deterrent module	●	●	●	●	○	○	
2008	Saturn	VUE	Radio	●	●	●	●	●	○	
2008	Saturn	VUE	Rollover sensor	●	●	●	●	○	●	T049
2008	Saturn	VUE	Passenger presence system	●	●	●	●	○	●	T045
2008	Saturn	VUE	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Saturn	VUE	Body control module	●	●	●	●	●	●	T005
2008	Saturn	VUE	HVAC control module	●	●	●	●	●	●	T008
2008	Saturn	VUE	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Saturn	VUE	Instrument panel cluster	●	●	●	●	●	○	
2008	Saturn	VUE	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Saturn	VUE	Power steering control module	●	●	○	●	○	○	
2008	Saturn	VUE	Electronic brake control module	●	●	●	●	●	○	
2008	Saturn	VUE hybrid	Transmission control module	●	●	○	●	●	○	
2008	Saturn	VUE hybrid	Fuel pump control module	●	●	●	●	●	○	

2008	Saturn	VUE hybrid	Engine control module	●	●	●	●	●	●	T001
2008	Saturn	VUE hybrid	Rear drive system	●	●	●	●	●	●	T038
2008	Saturn	VUE hybrid	Instrument panel cluster	●	●	●	●	●	○	
2008	Saturn	VUE hybrid	Digital radio receiver	●	●	●	●	○	○	
2008	Saturn	VUE hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Saturn	VUE hybrid	Theft deterrent module	●	●	●	●	○	○	
2008	Saturn	VUE hybrid	Radio	●	●	●	●	●	○	
2008	Saturn	VUE hybrid	Rollover sensor	●	●	●	●	○	●	T049
2008	Saturn	VUE hybrid	Passenger presence system	●	●	●	●	○	●	T045
2008	Saturn	VUE hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Saturn	VUE hybrid	Body control module	●	●	●	●	●	●	T005
2008	Saturn	VUE hybrid	HVAC control module	●	●	●	●	●	●	T008
2008	Saturn	VUE hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Saturn	VUE hybrid	Power steering control module	●	●	○	●	○	○	
2008	Saturn	VUE hybrid	Electronic brake control module	●	●	●	●	●	○	
2008	Saturn	VUE hybrid	Engine control module	●	●	●	●	●	●	T074 T075 T001
2008	Saturn	VUE hybrid	Battery energy control module	○	○	○	●	●	○	
2008	Saturn	VUE hybrid	Starter/generator control module	○	○	○	●	●	○	
2008	Saturn	VUE hybrid	Transmission control module	●	●	○	●	●	○	
2008	Saturn	VUE hybrid	Fuel pump control module	●	●	●	●	●	○	
2008	Saturn	VUE hybrid	Digital radio receiver	●	●	●	●	○	○	
2008	Saturn	VUE hybrid	Theft deterrent module	●	●	●	●	○	○	
2008	Saturn	VUE hybrid	Radio	●	●	●	●	●	○	
2008	Saturn	VUE hybrid	Rollover sensor	●	●	●	●	○	●	T049

2008	Saturn	VUE hybrid	Passenger presence system	●	●	●	●	○	●	T045
2008	Saturn	VUE hybrid	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Saturn	VUE hybrid	Body control module	●	●	●	●	●	●	T005
2008	Saturn	VUE hybrid	HVAC control module	●	●	●	●	●	●	T008
2008	Saturn	VUE hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Saturn	VUE hybrid	Instrument panel cluster	●	●	●	●	●	○	
2008	Saturn	VUE hybrid	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Saturn	VUE hybrid	Power steering control module	●	●	○	●	○	○	
2008	Saturn	VUE hybrid	Electronic brake control module	●	●	●	●	●	○	
2008	Hummer	H2	Transmission control module	●	●	○	●	●	○	
2008	Hummer	H2	Transfer case control module	●	●	●	●	●	○	
2008	Hummer	H2	Engine control module	●	●	●	●	●	●	T001
2008	Hummer	H2	Fuel pump control module	●	●	●	●	●	○	
2008	Hummer	H2	Rollover sensor	●	●	●	●	○	●	T049
2008	Hummer	H2	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Hummer	H2	Theft deterrent module	●	●	●	●	○	○	
2008	Hummer	H2	Amplifier (bose)	●	●	●	●	●	○	
2008	Hummer	H2	Digital radio receiver	●	●	●	●	○	○	
2008	Hummer	H2	Radio	●	●	●	●	●	○	
2008	Hummer	H2	Instrument panel cluster	●	●	●	●	●	○	
2008	Hummer	H2	Vehicle comm. interface module	●	●	●	●	●	●	T002 T073 T003 T093
2008	Hummer	H2	Memory seat module	●	●	●	●	●	○	

2008	Hummer	H2	Rear heated seat module	●	●	●	●	○	○	
2008	Hummer	H2	Rear HVAC/RSA	●	●	●	●	●	○	
2008	Hummer	H2	Personal audio link module	●	●	●	○	○	●	T036
2008	Hummer	H2	HVAC control module	●	●	●	●	●	●	T008 T034
2008	Hummer	H2	Body control module	●	●	●	●	●	●	T005
2008	Hummer	H2	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Hummer	H2	Driver door switch	●	●	●	●	●	○	
2008	Hummer	H2	Passenger door switch	●	●	●	●	●	○	
2008	Hummer	H2	Electronic brake control module	●	●	●	●	●	●	T014
2008	Hummer	H2	Air suspension control module	●	●	●	●	●	○	
2008	Hummer	H3	Transmission control module	●	●	○	●	●	○	
2008	Hummer	H3	Transfer case control module	●	●	●	●	●	○	
2008	Hummer	H3	Engine control module	●	●	●	●	●	●	T001
2008	Hummer	H3	Passenger presence system	●	●	○	○	○	●	T020
2008	Hummer	H3	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2008	Hummer	H3	Theft deterrent module	●	●	●	●	○	●	T057
2008	Hummer	H3	Body control module	●	●	●	●	●	●	T058 T022
2008	Hummer	H3	Digital radio receiver	●	●	●	●	○	●	T024
2008	Hummer	H3	Radio	●	●	●	●	●	●	T080 T032
2008	Hummer	H3	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	Hummer	H3	Instrument panel cluster	●	●	●	●	●	○	
2008	Hummer	H3	Generator battery control module	●	●	●	●	●	○	

2008	Hummer	H3	Personal audio link module	●	●	●	●	●	●	T036
2008	Hummer	H3	Navigation radio	●	●	●	●	●	●	T033
2008	Hummer	H3	Electronic brake control module	●	●	●	●	●	●	T001
2008	SAAB	Saab 9-7x	Transmission control module	●	●	○	●	●	○	
2008	SAAB	Saab 9-7x	Engine control module	●	●	●	●	●	●	T001
2008	SAAB	Saab 9-7x	Transfer case control module	●	●	●	●	●	●	T001
2008	SAAB	Saab 9-7x	Passenger presence system	●	●	○	○	○	●	T020
2008	SAAB	Saab 9-7x	Supplemental inflatable restraint	●	●	●	●	●	○	
2008	SAAB	Saab 9-7x	Theft deterrent module	●	●	●	●	○	○	
2008	SAAB	Saab 9-7x	Digital radio receiver	●	●	●	●	○	●	T024
2008	SAAB	Saab 9-7x	Disc player and video display	●	●	●	○	○	○	
2008	SAAB	Saab 9-7x	Radio	●	●	●	●	●	●	T080 T032
2008	SAAB	Saab 9-7x	Rear seat audio	●	●	●	●	○	○	
2008	SAAB	Saab 9-7x	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2008	SAAB	Saab 9-7x	Generator battery control module	●	●	●	●	●	○	
2008	SAAB	Saab 9-7x	Instrument panel cluster	●	●	●	●	●	○	
2008	SAAB	Saab 9-7x	Body control module	●	●	●	●	●	●	T058
2008	SAAB	Saab 9-7x	Driver door module	●	●	●	●	●	○	
2008	SAAB	Saab 9-7x	Passenger door module	●	●	●	●	●	○	
2008	SAAB	Saab 9-7x	Liftgate module	●	●	●	●	●	●	T022
2008	SAAB	Saab 9-7x	Driver seat module	●	●	●	●	●	○	
2008	SAAB	Saab 9-7x	HVAC control module	●	●	●	●	●	●	T020
2008	SAAB	Saab 9-7x	Navigation radio	●	●	●	●	●	●	T033
2008	SAAB	Saab 9-7x	Electronic brake control module	●	●	●	●	●	○	

2008	Holden	Captiva	Engine control module	●	●	●	●	●	○	
2008	Holden	Captiva	Transmission control module	●	●	●	●	●	○	
2008	Holden	Captiva	Rear drive system	●	●	●	●	●	●	T038
2008	Holden	Captiva	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Holden	Captiva	Theft deterrent module	●	●	●	●	○	○	
2008	Holden	Captiva	HVAC control module	●	●	●	○	●	○	
2008	Holden	Captiva	Body control module	●	●	●	●	●	●	T005
2008	Holden	Captiva	Body control module (aux.)	●	●	●	●	●	○	
2008	Holden	Captiva	Instrument panel cluster	●	●	●	●	●	○	
2008	Holden	Captiva	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Holden	Captiva	Electronic brake control module	●	●	●	●	●	○	
2008	Holden	Captiva maxx	Engine control module	●	●	●	●	●	○	
2008	Holden	Captiva maxx	Transmission control module	●	●	●	●	●	○	
2008	Holden	Captiva maxx	Rear drive system	●	●	●	●	●	●	T038
2008	Holden	Captiva maxx	Instrument panel cluster	●	●	●	●	●	○	
2008	Holden	Captiva maxx	Body control module	●	●	●	●	●	●	T005
2008	Holden	Captiva maxx	Body control module (aux.)	●	●	●	●	●	○	
2008	Holden	Captiva maxx	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2008	Holden	Captiva maxx	Headlamp control module	●	●	●	●	●	○	
2008	Holden	Captiva maxx	Park assist module	●	●	●	●	○	○	
2008	Holden	Captiva maxx	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2008	Holden	Captiva maxx	Theft deterrent module	●	●	●	●	○	○	
2008	Holden	Captiva maxx	HVAC control module	●	●	●	○	●	○	

2008	Holden	Captiva maxx	Radio	●	●	●	●	●	○	
2008	Holden	Captiva maxx	Front display interface module	●	●	●	●	●	●	T005
2008	Holden	Captiva maxx	Electronic brake control module	●	●	●	●	●	○	
2007	Buick	Lacrosse	Powertrain control module	●	●	●	●	●	○	
2007	Buick	Lacrosse	Transmission control module	●	●	○	●	●	○	
2007	Buick	Lacrosse	Engine control module	●	●	●	●	●	○	
2007	Buick	Lacrosse	Remote control door lock receiver	●	●	●	●	●	●	T022
2007	Buick	Lacrosse	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Buick	Lacrosse	Digital radio receiver	●	●	●	●	○	●	T024
2007	Buick	Lacrosse	Body control module	●	●	●	●	●	●	T007
2007	Buick	Lacrosse	Instrument panel cluster	●	●	●	●	●	○	
2007	Buick	Lacrosse	HVAC control module	●	●	●	●	●	●	T008
2007	Buick	Lacrosse	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T060 T080 T032
2007	Buick	Lacrosse	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Buick	Lacrosse	Electronic brake control module	○	○	○	●	○	●	T014
2007	Buick	Lacrosse (allure in canada)	Powertrain control module	●	●	●	●	●	○	
2007	Buick	Lacrosse (allure in canada)	Transmission control module	●	●	○	●	●	○	
2007	Buick	Lacrosse (allure in canada)	Engine control module	●	●	●	●	●	○	

2007	Buick	Lacrosse (allure in canada)	Remote control door lock receiver	●	●	●	●	●	●	T022
2007	Buick	Lacrosse (allure in canada)	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Buick	Lacrosse (allure in canada)	Digital radio receiver	●	●	●	●	○	●	T024
2007	Buick	Lacrosse (allure in canada)	Body control module	●	●	●	●	●	●	T007
2007	Buick	Lacrosse (allure in canada)	Instrument panel cluster	●	●	●	●	●	○	
2007	Buick	Lacrosse (allure in canada)	HVAC control module	●	●	●	●	●	●	T008
2007	Buick	Lacrosse (allure in canada)	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T060 T080 T032
2007	Buick	Lacrosse (allure in canada)	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Buick	Lacrosse (allure in canada)	Electronic brake control module	○	○	○	●	○	●	T014
2007	Buick	Lucerne	Powertrain control module	●	●	●	●	●	●	T001
2007	Buick	Lucerne	Transmission control module	●	●	○	●	●	○	
2007	Buick	Lucerne	Engine control module	●	●	●	●	●	●	T001
2007	Buick	Lucerne	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2007	Buick	Lucerne	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Buick	Lucerne	Theft deterrent module	●	●	●	●	○	○	
2007	Buick	Lucerne	Passenger presence system	●	●	●	●	○	●	T020
2007	Buick	Lucerne	Digital radio receiver	●	●	●	●	○	○	
2007	Buick	Lucerne	Radio	●	●	●	●	●	○	
2007	Buick	Lucerne	Body control module	●	●	●	●	●	●	T007 T005
2007	Buick	Lucerne	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Buick	Lucerne	HVAC control module	●	●	●	●	●	○	
2007	Buick	Lucerne	Driver door switch	●	●	●	●	●	○	
2007	Buick	Lucerne	Passenger door switch	●	●	●	●	●	○	
2007	Buick	Lucerne	Instrument panel cluster	●	●	●	●	●	○	
2007	Buick	Lucerne	Memory seat module	●	●	●	●	●	○	
2007	Buick	Lucerne	Park assist module	●	●	●	●	●	●	T021 T022
2007	Buick	Lucerne	Electronic brake control module	●	●	●	●	●	●	T014
2007	Buick	Lucerne	Electronic suspension control	●	●	●	●	●	○	
2007	Cadillac	DTS	Transmission control module	●	●	○	●	●	○	
2007	Cadillac	DTS	Engine control module	●	●	●	●	●	●	T001
2007	Cadillac	DTS	Passenger presence system	●	●	●	●	○	●	T020
2007	Cadillac	DTS	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Cadillac	DTS	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Cadillac	DTS	Theft deterrent module	●	●	●	●	○	○	
2007	Cadillac	DTS	Digital radio receiver	●	●	●	●	○	○	
2007	Cadillac	DTS	Amplifier (bose)	●	●	●	●	●	●	T111
2007	Cadillac	DTS	Radio	●	●	●	●	●	○	
2007	Cadillac	DTS	TV antenna module	●	●	●	●	○	●	T012 T013

2007	Cadillac	DTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	DTS	HVAC control module	●	●	●	●	●	○	
2007	Cadillac	DTS	Body control module	●	●	●	●	●	●	T007 T005
2007	Cadillac	DTS	Driver door switch	●	●	●	●	●	○	
2007	Cadillac	DTS	Passenger door switch	●	●	●	●	●	○	
2007	Cadillac	DTS	Instrument panel cluster	●	●	●	●	●	○	
2007	Cadillac	DTS	Driver position module	●	●	●	●	●	○	
2007	Cadillac	DTS	Park assist module	●	●	●	●	●	○	
2007	Cadillac	DTS	Rear heated seat module	●	●	●	●	○	○	
2007	Cadillac	DTS	Inside rear view mirror module	●	●	●	○	○	○	
2007	Cadillac	DTS	Distance sensing cruise control	●	●	●	●	●	●	T020
2007	Cadillac	DTS	Aux. HVAC control module	●	●	●	●	●	●	T007 T005
2007	Cadillac	DTS	Electronic brake control module	●	●	●	●	●	●	T014
2007	Cadillac	DTS	Electronic suspension control	●	●	●	●	●	○	
2007	Cadillac	CTS	Transmission control module	●	●	●	●	●	○	
2007	Cadillac	CTS	Engine control module	●	●	●	●	●	○	
2007	Cadillac	CTS	Passenger presence system	●	●	○	○	○	○	
2007	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T112 T113
2007	Cadillac	CTS	Theft deterrent module	●	●	●	●	○	○	
2007	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2007	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092

2007	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2007	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2007	Cadillac	CTS	Radio	●	●	●	●	○	●	T032
2007	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2007	Cadillac	CTS	Climate control panel	●	●	●	●	●	○	
2007	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2007	Cadillac	CTS	Driver door switch	●	●	●	●	○	●	T117 T117 T117 T117
2007	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2007	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2007	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2007	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2007	Cadillac	CTS	Memory seat module	●	●	●	●	●	●	T118 T119 T120 T121
2007	Cadillac	CTS	Remote control door lock receiver	●	●	●	●	●	●	T137
2007	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2007	Cadillac	CTS	Transmission control module	●	●	●	●	●	○	
2007	Cadillac	CTS	Engine control module	●	●	●	●	●	○	
2007	Cadillac	CTS	Passenger presence system	●	●	○	○	○	○	
2007	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T112 T113
2007	Cadillac	CTS	Theft deterrent module	●	●	●	●	○	○	
2007	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2007	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2007	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2007	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2007	Cadillac	CTS	Radio	●	●	●	●	○	●	T032
2007	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2007	Cadillac	CTS	Climate control panel	●	●	●	●	●	○	
2007	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116

2007	Cadillac	CTS	Driver door switch	●	●	●	●	○	○	
2007	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2007	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2007	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2007	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2007	Cadillac	CTS	Memory seat module	●	●	●	●	●	●	T118 T119 T120 T121
2007	Cadillac	CTS	Remote control door lock receiver	●	●	●	●	●	●	T137
2007	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2007	Cadillac	CTS	Transmission control module	●	●	●	●	●	○	
2007	Cadillac	CTS	Engine control module	●	●	●	●	●	○	
2007	Cadillac	CTS	Passenger presence system	●	●	○	○	○	○	
2007	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T112 T113
2007	Cadillac	CTS	Theft deterrent module	●	●	●	●	○	○	
2007	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2007	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2007	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2007	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2007	Cadillac	CTS	Radio	●	●	●	●	○	●	T032
2007	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2007	Cadillac	CTS	Climate control panel	●	●	●	●	●	○	
2007	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2007	Cadillac	CTS	Driver door switch	●	●	●	●	○	○	
2007	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2007	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2007	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2007	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	

2007	Cadillac	CTS	Memory seat module	●	●	●	●	●	●	T118 T119 T120 T121
2007	Cadillac	CTS	Remote control door lock receiver	●	●	●	●	●	●	T137
2007	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2007	Cadillac	CTS	Passenger presence system	●	●	○	○	○	○	
2007	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T112 T113
2007	Cadillac	CTS	Theft deterrent module	●	●	●	●	○	○	
2007	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2007	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2007	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2007	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2007	Cadillac	CTS	Radio	●	●	●	●	○	●	T032
2007	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2007	Cadillac	CTS	Climate control panel	●	●	●	●	●	○	
2007	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2007	Cadillac	CTS	Driver door switch	●	●	●	●	○	○	
2007	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2007	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2007	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2007	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2007	Cadillac	CTS	Memory seat module	●	●	●	●	●	●	T118 T119 T120 T121
2007	Cadillac	CTS	Remote control door lock receiver	●	●	●	●	●	●	T137
2007	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2007	Cadillac	CTS	Engine control module	●	●	●	●	●	●	T001
2007	Cadillac	STS	Transmission control module	●	●	○	●	●	○	
2007	Cadillac	STS	Engine control module	●	●	●	●	●	●	T001

2007	Cadillac	STS	Passenger presence system	●	●	○	○	○	○	
2007	Cadillac	STS	Remote control door lock receiver	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2007	Cadillac	STS	Supplemental inflatable restraint	●	●	●	●	●	●	T067
2007	Cadillac	STS	Digital radio receiver	●	●	●	●	○	●	T024
2007	Cadillac	STS	Headlamp control module	●	●	●	●	●	○	
2007	Cadillac	STS	Instrument panel module	●	●	●	●	●	●	T138 T059
2007	Cadillac	STS	Radio	●	●	●	●	○	●	T060 T033
2007	Cadillac	STS	TV antenna module	●	●	●	●	○	○	
2007	Cadillac	STS	Amplifier (bose)	●	●	○	●	●	○	
2007	Cadillac	STS	Driver door module	●	●	●	●	●	●	T068
2007	Cadillac	STS	Driver door switch	●	●	●	●	○	○	
2007	Cadillac	STS	Passenger door module	●	●	●	●	●	●	T068
2007	Cadillac	STS	Left rear door module	●	●	●	●	●	●	T068
2007	Cadillac	STS	Right rear door module	●	●	●	●	●	●	T068
2007	Cadillac	STS	HVAC control module	●	●	●	●	●	○	
2007	Cadillac	STS	Rear integration module	●	●	●	●	●	○	
2007	Cadillac	STS	Instrument panel cluster	●	●	●	●	●	●	T068
2007	Cadillac	STS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	STS	Driver position module	●	●	●	●	●	○	
2007	Cadillac	STS	Steering column lock module	●	●	●	●	●	○	
2007	Cadillac	STS	Distance sensing cruise control	●	●	●	●	●	○	
2007	Cadillac	STS	Head up display	●	●	●	●	●	○	

2007	Cadillac	STS	Electronic brake control module	●	●	●	●	●	●	T014
2007	Cadillac	STS	Electronic suspension control	●	●	●	●	●	○	
2007	Cadillac	STS	Transmission control module	●	●	●	●	●	○	
2007	Cadillac	STS	Engine control module	●	●	●	●	●	○	
2007	Cadillac	STS	Passenger presence system	●	●	○	○	○	○	
2007	Cadillac	STS	Remote control door lock receiver	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2007	Cadillac	STS	Supplemental inflatable restraint	●	●	●	●	●	●	T067
2007	Cadillac	STS	Digital radio receiver	●	●	●	●	○	●	T024
2007	Cadillac	STS	Headlamp control module	●	●	●	●	●	○	
2007	Cadillac	STS	Instrument panel module	●	●	●	●	●	●	T138 T059
2007	Cadillac	STS	Radio	●	●	●	●	○	●	T060 T033
2007	Cadillac	STS	TV antenna module	●	●	●	●	○	○	
2007	Cadillac	STS	Amplifier (bose)	●	●	○	●	●	○	
2007	Cadillac	STS	Driver door module	●	●	●	●	●	●	T068
2007	Cadillac	STS	Driver door switch	●	●	●	●	○	○	
2007	Cadillac	STS	Passenger door module	●	●	●	●	●	●	T068
2007	Cadillac	STS	Left rear door module	●	●	●	●	●	●	T068
2007	Cadillac	STS	Right rear door module	●	●	●	●	●	●	T068
2007	Cadillac	STS	HVAC control module	●	●	●	●	●	○	
2007	Cadillac	STS	Rear integration module	●	●	●	●	●	○	
2007	Cadillac	STS	Instrument panel cluster	●	●	●	●	●	●	T068
2007	Cadillac	STS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093

2007	Cadillac	STS	Driver position module	●	●	●	●	●	○	
2007	Cadillac	STS	Steering column lock module	●	●	●	●	●	○	
2007	Cadillac	STS	Distance sensing cruise control	●	●	●	●	●	○	
2007	Cadillac	STS	Head up display	●	●	●	●	●	○	
2007	Cadillac	STS	Electronic brake control module	●	●	●	●	●	●	T014
2007	Cadillac	STS	Electronic suspension control	●	●	●	●	●	○	
2007	Cadillac	STS	Engine control module	●	●	●	●	●	●	T001
2007	Cadillac	STS	Transmission control module	●	●	○	●	●	○	
2007	Cadillac	STS	Passenger presence system	●	●	○	○	○	○	
2007	Cadillac	STS	Supplemental inflatable restraint	●	●	●	●	●	●	T067
2007	Cadillac	STS	Remote control door lock receiver	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2007	Cadillac	STS	Digital radio receiver	●	●	●	●	○	●	T024
2007	Cadillac	STS	Headlamp control module	●	●	●	●	●	○	
2007	Cadillac	STS	Instrument panel module	●	●	●	●	●	●	T138 T059
2007	Cadillac	STS	Radio	●	●	●	●	○	●	T060 T033
2007	Cadillac	STS	TV antenna module	●	●	●	●	○	○	
2007	Cadillac	STS	Amplifier (bose)	●	●	○	●	●	○	
2007	Cadillac	STS	HVAC control module	●	●	●	●	●	○	
2007	Cadillac	STS	Driver door module	●	●	●	●	●	●	T068
2007	Cadillac	STS	Driver door switch	●	●	●	●	○	○	
2007	Cadillac	STS	Passenger door module	●	●	●	●	●	●	T068
2007	Cadillac	STS	Left rear door module	●	●	●	●	●	●	T068
2007	Cadillac	STS	Right rear door module	●	●	●	●	●	●	T068

2007	Cadillac	STS	Rear integration module	●	●	●	●	●	○	
2007	Cadillac	STS	Instrument panel cluster	●	●	●	●	●	●	T068
2007	Cadillac	STS	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	STS	Driver position module	●	●	●	●	●	○	
2007	Cadillac	STS	Steering column lock module	●	●	●	●	●	○	
2007	Cadillac	STS	Distance sensing cruise control	●	●	●	●	●	○	
2007	Cadillac	STS	Head up display	●	●	●	●	●	○	
2007	Cadillac	STS	Electronic brake control module	●	●	●	●	●	●	T014
2007	Cadillac	STS	Electronic suspension control	●	●	●	●	●	○	
2007	Cadillac	XLR	Transmission control module	●	●	○	●	●	○	
2007	Cadillac	XLR	Engine control module	●	●	●	●	●	●	T001
2007	Cadillac	XLR	Exhaust flow control module	●	●	●	●	●	○	
2007	Cadillac	XLR	Passenger presence system	●	●	○	○	○	●	T020
2007	Cadillac	XLR	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Cadillac	XLR	Remote control door lock receiver	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T029
2007	Cadillac	XLR	Digital radio receiver	●	●	●	●	○	●	T024
2007	Cadillac	XLR	Headlamp control module	●	●	●	●	●	○	
2007	Cadillac	XLR	Amplifier (bose)	●	●	●	●	●	○	
2007	Cadillac	XLR	HVAC control module	●	●	●	●	●	●	T008
2007	Cadillac	XLR	Driver door module	●	●	●	●	●	○	
2007	Cadillac	XLR	Driver door switch	●	●	●	●	○	○	

2007	Cadillac	XLR	Passenger door module	●	●	●	●	●	○	
2007	Cadillac	XLR	Instrument panel cluster	●	●	●	●	●	○	
2007	Cadillac	XLR	Driver position module	●	●	●	●	●	●	T030
2007	Cadillac	XLR	Folding top module	●	●	●	●	●	○	
2007	Cadillac	XLR	CD changer	●	●	●	○	○	○	
2007	Cadillac	XLR	Navigation radio	●	●	●	●	○	●	T033
2007	Cadillac	XLR	Body control module	●	●	●	●	●	●	T059 T023
2007	Cadillac	XLR	Head up display	●	●	●	●	●	○	
2007	Cadillac	XLR	Distance sensing cruise control	●	●	●	●	●	○	
2007	Cadillac	XLR	Steering column lock module	●	●	●	●	●	○	
2007	Cadillac	XLR	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	XLR	Electronic brake control module	●	●	●	●	●	●	T014
2007	Cadillac	XLR	Electronic suspension control	●	●	●	●	●	○	
2007	Cadillac	XLR	Engine control module	●	●	●	●	●	●	T001
2007	Cadillac	XLR	Transmission control module	●	●	○	●	●	○	
2007	Cadillac	XLR	Exhaust flow control module	●	●	●	●	●	○	
2007	Cadillac	XLR	Passenger presence system	●	●	○	○	○	●	T020
2007	Cadillac	XLR	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Cadillac	XLR	Remote control door lock receiver	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T029
2007	Cadillac	XLR	Digital radio receiver	●	●	●	●	○	●	T024
2007	Cadillac	XLR	Headlamp control module	●	●	●	●	●	○	
2007	Cadillac	XLR	Amplifier (bose)	●	●	●	●	●	○	

2007	Cadillac	XLR	HVAC control module	●	●	●	●	●	●	T008
2007	Cadillac	XLR	Driver door module	●	●	●	●	●	○	
2007	Cadillac	XLR	Driver door switch	●	●	●	●	○	○	
2007	Cadillac	XLR	Passenger door module	●	●	●	●	●	○	
2007	Cadillac	XLR	Instrument panel cluster	●	●	●	●	●	○	
2007	Cadillac	XLR	Driver position module	●	●	●	●	●	●	T030
2007	Cadillac	XLR	Folding top module	●	●	●	●	●	○	
2007	Cadillac	XLR	CD changer	●	●	●	○	○	○	
2007	Cadillac	XLR	Navigation radio	●	●	●	●	○	●	T033
2007	Cadillac	XLR	Body control module	●	●	●	●	●	●	T059 T023
2007	Cadillac	XLR	Head up display	●	●	●	●	●	○	
2007	Cadillac	XLR	Distance sensing cruise control	●	●	●	●	●	○	
2007	Cadillac	XLR	Steering column lock module	●	●	●	●	●	○	
2007	Cadillac	XLR	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	XLR	Electronic brake control module	●	●	●	●	●	●	T014
2007	Cadillac	XLR	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Aveo	Engine control module	●	●	●	●	●	●	T015
2007	Chevrolet	Aveo	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Aveo	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Chevrolet	Aveo	Immobilizer	●	●	●	●	●	●	T016
2007	Chevrolet	Aveo	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Aveo HB	Engine control module	●	●	●	●	●	●	T015
2007	Chevrolet	Aveo HB	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Aveo HB	Supplemental inflatable restraint	●	●	●	●	●	○	

2007	Chevrolet	Aveo HB	Immobilizer	●	●	●	●	●	●	T016
2007	Chevrolet	Aveo HB	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Chevy	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Chevy	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Chevy	Immobilizer	●	●	●	●	○	●	T052 T053
2007	Chevrolet	Cobalt	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Cobalt	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Cobalt	Powertrain control module	●	●	○	●	●	○	
2007	Chevrolet	Cobalt	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Cobalt	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Chevrolet	Cobalt	Passenger presence system	●	●	○	○	○	○	
2007	Chevrolet	Cobalt	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Cobalt	Radio	●	●	●	●	●	○	
2007	Chevrolet	Cobalt	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Cobalt	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Cobalt	Body control module	●	●	●	●	●	●	T023
2007	Chevrolet	Cobalt	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Cobalt	Remote control door lock receiver	●	●	●	●	●	○	
2007	Chevrolet	Cobalt	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Cobalt	Power steering control module	●	●	○	●	○	○	
2007	Chevrolet	Corvette	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Corvette	Engine control module	●	●	●	●	●	●	T001

2007	Chevrolet	Corvette	Exhaust flow control module	●	●	●	●	●	●	T001
2007	Chevrolet	Corvette	Passenger presence system	●	●	○	○	○	●	T020
2007	Chevrolet	Corvette	Remote control door lock receiver	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2007	Chevrolet	Corvette	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Chevrolet	Corvette	Digital radio receiver	●	●	●	●	○	●	T024
2007	Chevrolet	Corvette	HVAC control module	●	●	●	●	●	●	T008 T031
2007	Chevrolet	Corvette	Driver door module	●	●	●	●	●	○	
2007	Chevrolet	Corvette	Driver door switch	●	●	●	●	○	○	
2007	Chevrolet	Corvette	Passenger door module	●	●	●	●	●	○	
2007	Chevrolet	Corvette	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Corvette	Body control module	●	●	●	●	●	●	T023
2007	Chevrolet	Corvette	CD changer	●	●	●	●	○	○	
2007	Chevrolet	Corvette	Radio	●	●	●	●	●	●	T032
2007	Chevrolet	Corvette	Driver position module	●	●	●	●	●	●	T030
2007	Chevrolet	Corvette	Folding top module	●	●	●	●	●	○	
2007	Chevrolet	Corvette	Head up display	●	●	●	●	●	○	
2007	Chevrolet	Corvette	Steering column lock module	●	●	●	●	●	○	
2007	Chevrolet	Corvette	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Corvette	Navigation radio	●	●	●	●	●	●	T033
2007	Chevrolet	Corvette	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Corvette	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Impala	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Impala	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Impala	Theft deterrent module	●	●	●	●	○	○	

2007	Chevrolet	Impala	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Impala	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Impala	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Impala	Radio	●	●	●	●	●	○	
2007	Chevrolet	Impala	Body control module	●	●	●	●	●	●	T007 T005
2007	Chevrolet	Impala	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Impala	Heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Impala	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Impala	HVAC control module	●	●	●	●	●	●	T008
2007	Chevrolet	Impala	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Impala	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Impala	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Impala	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Impala	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Impala	Radio	●	●	●	●	●	○	
2007	Chevrolet	Impala	Body control module	●	●	●	●	●	●	T007 T005
2007	Chevrolet	Impala	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Impala	Heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Impala	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Impala	HVAC control module	●	●	●	●	●	●	T008
2007	Chevrolet	Impala	Electronic brake control module	●	●	●	●	●	●	T014

2007	Chevrolet	Impala	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Impala	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Impala	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Impala	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Impala	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Impala	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Impala	Radio	●	●	●	●	●	○	
2007	Chevrolet	Impala	Body control module	●	●	●	●	●	●	T007 T005
2007	Chevrolet	Impala	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Impala	Heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Impala	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Impala	HVAC control module	●	●	●	●	●	●	T008
2007	Chevrolet	Impala	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Impala	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Impala	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Impala	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Impala	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Impala	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Impala	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Impala	Radio	●	●	●	●	●	○	
2007	Chevrolet	Impala	Body control module	●	●	●	●	●	●	T007 T005

2007	Chevrolet	Impala	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Impala	Heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Impala	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Impala	HVAC control module	●	●	●	●	●	●	T008
2007	Chevrolet	Impala	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Impala	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Impala	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Impala	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Impala	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Impala	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Impala	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Impala	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Impala	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Impala	Radio	●	●	●	●	●	○	
2007	Chevrolet	Impala	Body control module	●	●	●	●	●	●	T007 T005
2007	Chevrolet	Impala	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Impala	Heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Impala	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Impala	HVAC control module	●	●	●	●	●	●	T008
2007	Chevrolet	Impala	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Impala	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Impala	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2007	Chevrolet	Impala	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Impala	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Impala	Radio	●	●	●	●	●	○	
2007	Chevrolet	Impala	Body control module	●	●	●	●	●	●	T007 T005
2007	Chevrolet	Impala	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Impala	Heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Impala	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Impala	HVAC control module	●	●	●	●	●	●	T008
2007	Chevrolet	Impala	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Impala	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Impala	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Malibu	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Malibu	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Malibu	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Chevrolet	Malibu	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Malibu	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Malibu	Disc player and video display	●	●	●	●	○	○	
2007	Chevrolet	Malibu	Radio	●	●	●	●	●	●	T102 T103 T033
2007	Chevrolet	Malibu	Body control module	●	●	●	●	●	●	T008 T023
2007	Chevrolet	Malibu	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Malibu	HVAC control module	●	●	●	●	●	○	
2007	Chevrolet	Malibu	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093

2007	Chevrolet	Malibu	Remote control door lock receiver	●	●	●	●	●	●	T029
2007	Chevrolet	Malibu	Passenger presence system	●	●	●	●	●	●	T023
2007	Chevrolet	Malibu	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Malibu	Power steering control module	●	●	●	●	●	●	T104
2007	Chevrolet	Monte carlo	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Monte carlo	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Monte carlo	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Monte carlo	Radio	●	●	●	●	●	○	
2007	Chevrolet	Monte carlo	Body control module	●	●	●	●	●	●	T007 T005
2007	Chevrolet	Monte carlo	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Monte carlo	Heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Monte carlo	HVAC control module	●	●	●	●	●	●	T008
2007	Chevrolet	Monte carlo	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Monte carlo	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Monte carlo	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Monte carlo	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Monte carlo	Theft deterrent module	●	●	●	●	●	●	T007 T005
2007	Chevrolet	Monte carlo	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Monte carlo	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Monte carlo	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Monte carlo	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Monte carlo	Radio	●	●	●	●	●	○	
2007	Chevrolet	Monte carlo	Body control module	●	●	●	●	●	●	T007 T005

2007	Chevrolet	Monte carlo	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Monte carlo	Heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Monte carlo	HVAC control module	●	●	●	●	●	●	T008
2007	Chevrolet	Monte carlo	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Monte carlo	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Monte carlo	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Monte carlo	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Monte carlo	Theft deterrent module	●	●	●	●	●	●	T007 T005
2007	Chevrolet	Monte carlo	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Monte carlo	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Monte carlo	Radio	●	●	●	●	●	○	
2007	Chevrolet	Monte carlo	Body control module	●	●	●	●	●	●	T007 T005
2007	Chevrolet	Monte carlo	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Monte carlo	Heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Monte carlo	HVAC control module	●	●	●	●	●	●	T008
2007	Chevrolet	Monte carlo	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Monte carlo	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Monte carlo	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Monte carlo	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Monte carlo	Theft deterrent module	●	●	●	●	●	●	T007 T005
2007	Chevrolet	Monte carlo	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Monte carlo	Transmission control module	●	●	○	●	●	○	

2007	Chevrolet	Monte carlo	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Optra	Engine control module	●	●	●	●	●	●	T015
2007	Chevrolet	Optra	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Optra	Immobilizer	○	○	○	○	○	●	T016
2007	Chevrolet	Optra	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2007	Chevrolet	Optra	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Optra - mexico	Engine control module	●	●	●	●	●	●	T015
2007	Chevrolet	Optra - mexico	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Optra - mexico	Immobilizer	○	○	○	○	○	●	T016
2007	Chevrolet	Optra - mexico	Tire pressure monitor	●	●	●	●	○	●	T018 T019
2007	Chevrolet	Optra - mexico	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Spark	Engine control module	●	●	●	●	●	●	T015
2007	Chevrolet	Spark	Transmission control module	●	●	●	●	●	●	T015
2007	Chevrolet	Spark	Immobilizer	○	○	○	○	○	●	T016
2007	Chevrolet	Spark	Supplemental inflatable restraint	●	●	●	●	○	○	
2007	Chevrolet	Spark	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Vivant	Engine control module	●	●	●	●	●	●	T015
2007	Chevrolet	Vivant	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Vivant	Supplemental inflatable restraint	●	●	●	●	○	○	
2007	Chevrolet	Vivant	Immobilizer	○	○	○	○	○	●	T016
2007	Chevrolet	Vivant	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Others	Immobilizer	○	○	○	○	○	●	T016
2007	Chevrolet	Others	ISU	●	●	●	●	●	○	
2007	Chevrolet	Others	Supplemental inflatable restraint	●	●	●	●	●	○	

2007	Chevrolet	Others	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Others	Transmission control module	●	●	●	●	●	○	
2007	Chevrolet	Others	Engine control module	●	●	●	●	●	●	T001
2007	Pontiac	G3	Engine control module	●	●	○	○	○	○	
2007	Pontiac	G3	Transmission control module	●	●	●	●	●	●	T001
2007	Pontiac	G3	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Pontiac	G3	Immobilizer	●	●	●	●	●	●	T016
2007	Pontiac	G3	Electronic brake control module	●	●	●	●	●	●	T014
2007	Pontiac	G5	Transmission control module	●	●	○	●	●	○	
2007	Pontiac	G5	Engine control module	●	●	●	●	●	●	T001
2007	Pontiac	G5	Theft deterrent module	●	●	●	●	○	○	
2007	Pontiac	G5	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Pontiac	G5	Passenger presence system	●	●	○	○	○	○	
2007	Pontiac	G5	Digital radio receiver	●	●	●	●	○	○	
2007	Pontiac	G5	Radio	●	●	●	●	●	○	
2007	Pontiac	G5	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Pontiac	G5	Instrument panel cluster	●	●	●	●	●	○	
2007	Pontiac	G5	Body control module	●	●	●	●	●	●	T023
2007	Pontiac	G5	Personal audio link module	●	●	●	○	○	●	T036
2007	Pontiac	G5	Remote control door lock receiver	●	●	●	●	●	○	
2007	Pontiac	G5	Electronic brake control module	●	●	●	●	●	○	

2007	Pontiac	G5	Power steering control module	●	●	○	●	○	○	
2007	Pontiac	G6	Transmission control module	●	●	○	●	●	○	
2007	Pontiac	G6	Engine control module	●	●	●	●	●	●	T001
2007	Pontiac	G6	Passenger presence system	●	●	○	○	○	○	
2007	Pontiac	G6	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Pontiac	G6	Theft deterrent module	●	●	●	●	○	○	
2007	Pontiac	G6	Digital radio receiver	●	●	●	●	○	○	
2007	Pontiac	G6	Instrument panel cluster	●	●	●	●	●	○	
2007	Pontiac	G6	Body control module	●	●	●	●	●	●	T008 T023
2007	Pontiac	G6	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Pontiac	G6	Radio	●	●	●	●	●	●	T089 T090 T033
2007	Pontiac	G6	Folding top module	●	●	●	●	●	○	
2007	Pontiac	G6	Remote control door lock receiver	●	●	●	●	●	○	
2007	Pontiac	G6	HVAC control module	●	●	●	●	●	●	T023
2007	Pontiac	G6	Electronic brake control module	●	●	●	●	●	●	T014
2007	Pontiac	G6	Power steering control module	●	●	●	●	●	●	T104
2007	Pontiac	Grand prix	Transmission control module	●	●	○	●	●	○	
2007	Pontiac	Grand prix	Engine control module	●	●	●	●	●	●	T001
2007	Pontiac	Grand prix	Powertrain control module	●	●	●	●	●	○	
2007	Pontiac	Grand prix	Digital radio receiver	●	●	●	●	○	●	T024
2007	Pontiac	Grand prix	Remote control door lock receiver	●	●	●	●	●	●	T022
2007	Pontiac	Grand prix	Supplemental inflatable restraint	●	●	●	●	●	●	T023

2007	Pontiac	Grand prix	Body control module	●	●	●	●	●	●	T007
2007	Pontiac	Grand prix	Instrument panel cluster	●	●	●	●	●	○	
2007	Pontiac	Grand prix	HVAC control module	●	●	●	●	●	●	T008
2007	Pontiac	Grand prix	Driver information center	●	●	○	●	●	○	
2007	Pontiac	Grand prix	Navigation radio	●	●	●	●	●	●	T033 T080 T032
2007	Pontiac	Grand prix	Head up display	●	●	○	○	○	○	
2007	Pontiac	Grand prix	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Pontiac	Grand prix	Electronic brake control module	●	●	○	●	●	●	T014
2007	Pontiac	Matiz	Transmission control module	●	●	●	●	●	○	
2007	Pontiac	Matiz	Engine control module	●	●	●	●	●	●	T001
2007	Pontiac	Matiz	Passenger presence system	●	●	○	○	○	○	
2007	Pontiac	Matiz	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Pontiac	Matiz	Theft deterrent module	●	●	●	●	○	○	
2007	Pontiac	Matiz	Digital radio receiver	●	●	●	●	○	○	
2007	Pontiac	Matiz	Remote control door lock receiver	●	●	●	●	●	●	T029
2007	Pontiac	Matiz	Radio	●	●	●	●	●	●	T033
2007	Pontiac	Matiz	Instrument panel cluster	●	●	●	●	●	○	
2007	Pontiac	Matiz	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Pontiac	Matiz	Body control module	●	●	●	●	●	●	T023
2007	Pontiac	Matiz	Personal audio link module	●	●	●	○	○	●	T036
2007	Pontiac	Matiz	Electronic brake control module	●	●	●	●	●	○	
2007	Pontiac	Solstice	Transmission control module	●	●	●	●	●	○	

2007	Pontiac	Solstice	Engine control module	●	●	●	●	●	●	T001
2007	Pontiac	Solstice	Passenger presence system	●	●	○	○	○	○	
2007	Pontiac	Solstice	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Pontiac	Solstice	Theft deterrent module	●	●	●	●	○	○	
2007	Pontiac	Solstice	Digital radio receiver	●	●	●	●	○	○	
2007	Pontiac	Solstice	Remote control door lock receiver	●	●	●	●	●	●	T029
2007	Pontiac	Solstice	Radio	●	●	●	●	●	●	T033
2007	Pontiac	Solstice	Instrument panel cluster	●	●	●	●	●	○	
2007	Pontiac	Solstice	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Pontiac	Solstice	Body control module	●	●	●	●	●	●	T023
2007	Pontiac	Solstice	Personal audio link module	●	●	●	○	○	●	T036
2007	Pontiac	Solstice	Electronic brake control module	●	●	●	●	●	○	
2007	Pontiac	Vibe - FWD	Digital radio receiver	●	●	●	●	○	●	T024
2007	Pontiac	Vibe - FWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2007	Pontiac	Vibe - FWD	Radio	●	●	○	●	●	●	T080
2007	Pontiac	Vibe - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Pontiac	Vibe - FWD	Electronic brake control module	●	●	○	●	●	●	T105
2007	Pontiac	Wave	Engine control module	●	●	○	○	○	○	
2007	Pontiac	Wave	Transmission control module	●	●	●	●	●	●	T001
2007	Pontiac	Wave	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Pontiac	Wave	Immobilizer	●	●	●	●	●	●	T016
2007	Pontiac	Wave	Electronic brake control module	●	●	●	●	●	●	T014

2007	Saturn	AURA	Transmission control module	●	●	○	●	●	○	
2007	Saturn	AURA	Engine control module	●	●	●	●	●	●	T001
2007	Saturn	AURA	Passenger presence system	●	●	○	○	○	○	
2007	Saturn	AURA	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Saturn	AURA	Theft deterrent module	●	●	●	●	○	○	
2007	Saturn	AURA	Digital radio receiver	●	●	●	●	○	○	
2007	Saturn	AURA	Radio	●	●	●	●	●	●	T033
2007	Saturn	AURA	Body control module	●	●	●	●	●	●	T008 T023
2007	Saturn	AURA	HVAC control module	●	●	●	●	●	○	
2007	Saturn	AURA	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Saturn	AURA	Instrument panel cluster	●	●	●	●	●	○	
2007	Saturn	AURA	Personal audio link module	●	●	●	○	○	●	T036
2007	Saturn	AURA	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Saturn	AURA	Electronic brake control module	●	●	●	●	●	●	T014
2007	Saturn	AURA	Passenger presence system	●	●	○	○	○	○	
2007	Saturn	AURA	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Saturn	AURA	Theft deterrent module	●	●	●	●	○	○	
2007	Saturn	AURA	Digital radio receiver	●	●	●	●	○	○	
2007	Saturn	AURA	Radio	●	●	●	●	●	●	T033
2007	Saturn	AURA	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Saturn	AURA	Personal audio link module	●	●	●	○	○	●	T036
2007	Saturn	AURA	HVAC control module	●	●	●	●	●	○	

2007	Saturn	AURA	Instrument panel cluster	●	●	●	●	●	○	
2007	Saturn	AURA	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Saturn	AURA	Body control module	●	●	●	●	●	●	T008 T023
2007	Saturn	AURA	Electronic brake control module	●	●	●	●	●	●	T014
2007	Saturn	AURA	Power steering control module	●	●	●	●	●	○	
2007	Saturn	AURA	Engine control module	●	●	●	●	●	●	T074 T075 T001
2007	Saturn	AURA	Battery energy control module	○	○	○	●	●	○	
2007	Saturn	AURA	Starter/generator control module	○	○	○	●	●	○	
2007	Saturn	AURA	Transmission control module	●	●	○	●	●	○	
2007	Saturn	ION	Transmission control module	●	●	○	●	●	○	
2007	Saturn	ION	Engine control module	●	●	●	●	●	●	T001
2007	Saturn	ION	Powertrain control module	●	●	○	●	●	○	
2007	Saturn	ION	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Saturn	ION	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Saturn	ION	Digital radio receiver	●	●	●	●	○	○	
2007	Saturn	ION	Radio	●	●	●	●	●	●	T059
2007	Saturn	ION	Instrument panel cluster	●	●	●	●	●	○	
2007	Saturn	ION	Body control module	●	●	●	●	●	●	T141 T142 T143
2007	Saturn	ION	Electronic brake control module	●	●	○	●	●	●	T014
2007	Saturn	ION	Power steering control module	●	●	○	●	○	○	

2007	Saturn	SKY	Transmission control module	●	●	●	●	●	○	
2007	Saturn	SKY	Engine control module	●	●	●	●	●	●	T001
2007	Saturn	SKY	Passenger presence system	●	●	○	○	○	○	
2007	Saturn	SKY	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Saturn	SKY	Theft deterrent module	●	●	●	●	○	○	
2007	Saturn	SKY	Digital radio receiver	●	●	●	●	○	○	
2007	Saturn	SKY	Remote control door lock receiver	●	●	●	●	●	●	T029
2007	Saturn	SKY	Radio	●	●	●	●	●	●	T033
2007	Saturn	SKY	Instrument panel cluster	●	●	●	●	●	○	
2007	Saturn	SKY	Body control module	●	●	●	●	●	●	T106 T023
2007	Saturn	SKY	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Saturn	SKY	Personal audio link module	●	●	●	○	○	●	T036
2007	Saturn	SKY	Electronic brake control module	●	●	●	●	●	○	
2007	Buick	Rainier	Powertrain control module	●	●	○	●	●	○	
2007	Buick	Rainier	Transmission control module	●	●	○	●	●	○	
2007	Buick	Rainier	Engine control module	●	●	●	●	●	●	T001
2007	Buick	Rainier	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Buick	Rainier	Disc player and video display	●	●	●	○	○	○	
2007	Buick	Rainier	Radio	●	●	●	●	○	○	
2007	Buick	Rainier	Rear seat audio	●	●	●	●	○	○	
2007	Buick	Rainier	Digital radio receiver	●	●	●	●	○	●	T024
2007	Buick	Rainier	Instrument panel cluster	●	●	●	●	●	○	

2007	Buick	Rainier	Generator battery control module	●	●	●	●	●	○	
2007	Buick	Rainier	Body control module	●	●	●	●	●	●	T058
2007	Buick	Rainier	Driver door module	●	●	●	●	●	○	
2007	Buick	Rainier	Driver seat module	●	●	●	●	●	○	
2007	Buick	Rainier	HVAC control module	●	●	●	●	●	○	
2007	Buick	Rainier	Passenger door module	●	●	●	●	●	○	
2007	Buick	Rainier	Liftgate module	●	●	●	●	●	●	T022
2007	Buick	Rainier	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Buick	Rainier	Passenger presence system	●	●	●	●	●	●	T020
2007	Buick	Rainier	Navigation radio	●	●	●	●	●	●	T033
2007	Buick	Rainier	Electronic brake control module	●	●	●	●	●	○	
2007	Buick	Rainier	Transfer case control module	●	●	●	●	●	●	T001
2007	Buick	Rendezvous - FWD	Powertrain control module	●	●	●	●	●	○	
2007	Buick	Rendezvous - FWD	Passenger presence system	●	●	○	○	○	●	T020
2007	Buick	Rendezvous - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Buick	Rendezvous - FWD	Theft deterrent module	●	●	●	●	○	○	
2007	Buick	Rendezvous - FWD	Digital radio receiver	●	●	●	●	○	●	T024
2007	Buick	Rendezvous - FWD	Disc player and video display	●	●	●	○	○	○	
2007	Buick	Rendezvous - FWD	Radio	●	●	●	●	●	●	T081 T080 T082 T032 T144
2007	Buick	Rendezvous - FWD	HVAC control module	●	●	●	●	●	○	
2007	Buick	Rendezvous - FWD	Instrument panel cluster	●	●	●	●	●	○	

2007	Buick	Rendezvous - FWD	Body control module	●	●	●	●	●	●	T136 T145 T122 T023
2007	Buick	Rendezvous - FWD	Head up display	●	●	●	●	○	○	
2007	Buick	Rendezvous - FWD	Memory seat module	●	●	○	●	●	○	
2007	Buick	Rendezvous - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Buick	Rendezvous - FWD	Electronic brake control module	●	●	○	●	●	●	T014
2007	Buick	Terraza	Transmission control module	●	●	○	●	●	○	
2007	Buick	Terraza	Engine control module	●	●	●	●	●	●	T001
2007	Buick	Terraza	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Buick	Terraza	Mobile digital media	●	●	○	○	○	○	
2007	Buick	Terraza	Radio	●	●	●	●	●	●	T095 T032 T033
2007	Buick	Terraza	Disc player and video display	●	●	●	○	○	○	
2007	Buick	Terraza	Body control module	●	●	●	●	●	●	T007
2007	Buick	Terraza	Left power sliding door module	●	●	●	●	●	○	
2007	Buick	Terraza	Right power sliding door module	●	●	●	●	●	○	
2007	Buick	Terraza	Memory seat module	●	●	●	●	●	○	
2007	Buick	Terraza	HVAC control module	●	●	●	●	●	○	
2007	Buick	Terraza	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Buick	Terraza	Digital radio receiver	●	●	●	●	○	●	T024
2007	Buick	Terraza	Passenger presence system	●	●	●	●	●	●	T020
2007	Buick	Terraza	Navigation radio	●	●	●	●	●	●	T033
2007	Buick	Terraza	Electronic brake control module	●	●	○	●	●	●	T014

2007	Buick	Terraza ext.	Transmission control module	●	●	○	●	●	○	
2007	Buick	Terraza ext.	Engine control module	●	●	●	●	●	●	T001
2007	Buick	Terraza ext.	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Buick	Terraza ext.	Mobile digital media	●	●	○	○	○	○	
2007	Buick	Terraza ext.	Radio	●	●	●	●	●	●	T095 T032 T033
2007	Buick	Terraza ext.	Disc player and video display	●	●	●	○	○	○	
2007	Buick	Terraza ext.	Body control module	●	●	●	●	●	●	T007
2007	Buick	Terraza ext.	Left power sliding door module	●	●	●	●	●	○	
2007	Buick	Terraza ext.	Right power sliding door module	●	●	●	●	●	○	
2007	Buick	Terraza ext.	Memory seat module	●	●	●	●	●	○	
2007	Buick	Terraza ext.	HVAC control module	●	●	●	●	●	○	
2007	Buick	Terraza ext.	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Buick	Terraza ext.	Digital radio receiver	●	●	●	●	○	●	T024
2007	Buick	Terraza ext.	Passenger presence system	●	●	●	●	●	●	T020
2007	Buick	Terraza ext.	Navigation radio	●	●	●	●	●	●	T033
2007	Buick	Terraza ext.	Electronic brake control module	●	●	○	●	●	●	T014
2007	Cadillac	Hearse	Transmission control module	●	●	○	●	●	○	
2007	Cadillac	Hearse	Engine control module	●	●	●	●	●	●	T001
2007	Cadillac	Hearse	Passenger presence system	●	●	●	●	○	●	T020
2007	Cadillac	Hearse	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Cadillac	Hearse	Theft deterrent module	●	●	●	●	○	○	
2007	Cadillac	Hearse	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Cadillac	Hearse	Digital radio receiver	●	●	●	●	○	○	

2007	Cadillac	Hearse	Amplifier (bose)	●	●	●	●	●	○	
2007	Cadillac	Hearse	Radio	●	●	●	●	●	○	
2007	Cadillac	Hearse	Body control module	●	●	●	●	●	●	T007 T005
2007	Cadillac	Hearse	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	Hearse	HVAC control module	●	●	●	●	●	○	
2007	Cadillac	Hearse	Driver door switch	●	●	●	●	●	○	
2007	Cadillac	Hearse	Passenger door switch	●	●	●	●	●	○	
2007	Cadillac	Hearse	Instrument panel cluster	●	●	●	●	●	○	
2007	Cadillac	Hearse	Driver position module	●	●	●	●	●	○	
2007	Cadillac	Hearse	Rear heated seat module	●	●	●	●	○	○	
2007	Cadillac	Hearse	Inside rear view mirror module	●	●	●	○	○	○	
2007	Cadillac	Hearse	Electronic brake control module	●	●	●	●	○	●	T014
2007	Cadillac	Hearse	Air suspension control module	●	●	●	●	●	○	
2007	Cadillac	Limousine	Transmission control module	●	●	○	●	●	○	
2007	Cadillac	Limousine	Engine control module	●	●	●	●	●	●	T001
2007	Cadillac	Limousine	Passenger presence system	●	●	●	●	○	●	T020
2007	Cadillac	Limousine	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Cadillac	Limousine	Theft deterrent module	●	●	●	●	○	○	
2007	Cadillac	Limousine	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Cadillac	Limousine	Digital radio receiver	●	●	●	●	○	○	
2007	Cadillac	Limousine	Amplifier (bose)	●	●	●	●	●	○	
2007	Cadillac	Limousine	Radio	●	●	●	●	●	○	
2007	Cadillac	Limousine	Body control module	●	●	●	●	●	●	T007 T005
2007	Cadillac	Limousine	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093

2007	Cadillac	Limousine	HVAC control module	●	●	●	●	●	○	
2007	Cadillac	Limousine	Aux. HVAC control module	○	○	●	●	●	○	
2007	Cadillac	Limousine	Driver door switch	●	●	●	●	●	○	
2007	Cadillac	Limousine	Passenger door switch	●	●	●	●	●	○	
2007	Cadillac	Limousine	Instrument panel cluster	●	●	●	●	●	○	
2007	Cadillac	Limousine	Driver position module	●	●	●	●	●	○	
2007	Cadillac	Limousine	Rear heated seat module	●	●	●	●	○	○	
2007	Cadillac	Limousine	Inside rear view mirror module	●	●	●	○	○	○	
2007	Cadillac	Limousine	Electronic brake control module	●	●	●	●	○	●	T014
2007	Cadillac	Limousine	Air suspension control module	●	●	●	●	●	○	
2007	Cadillac	Escalade - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	Cadillac	Escalade - 2WD	Transmission control module	●	●	○	●	●	○	
2007	Cadillac	Escalade - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2007	Cadillac	Escalade - 2WD	Driver door switch	●	●	●	●	●	○	
2007	Cadillac	Escalade - 2WD	Passenger door switch	●	●	●	●	●	○	
2007	Cadillac	Escalade - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	Cadillac	Escalade - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Cadillac	Escalade - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Cadillac	Escalade - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	Cadillac	Escalade - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Cadillac	Escalade - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Cadillac	Escalade - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2007	Cadillac	Escalade - 2WD	Inside rear view mirror module	●	●	●	○	○	○	

2007	Cadillac	Escalade - 2WD	Park assist module	●	●	●	●	●	○	
2007	Cadillac	Escalade - 2WD	Memory seat module	●	●	●	●	●	○	
2007	Cadillac	Escalade - 2WD	Rear heated seat module	●	●	●	●	○	○	
2007	Cadillac	Escalade - 2WD	Body control module	●	●	●	●	●	●	T005
2007	Cadillac	Escalade - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Cadillac	Escalade - 2WD	Body control module (aux.)	●	●	●	●	●	○	
2007	Cadillac	Escalade - 2WD	Assist step controller	●	●	●	●	●	●	T039
2007	Cadillac	Escalade - 2WD	Radio	●	●	●	●	●	○	
2007	Cadillac	Escalade - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Cadillac	Escalade - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	Escalade - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2007	Cadillac	Escalade - 2WD	Liftgate module	●	●	●	●	●	○	
2007	Cadillac	Escalade - 2WD	Electronic suspension control	●	●	●	●	●	○	
2007	Cadillac	Escalade - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Cadillac	Escalade - AWD	Engine control module	●	●	●	●	●	●	T001
2007	Cadillac	Escalade - AWD	Transmission control module	●	●	○	●	●	○	
2007	Cadillac	Escalade - AWD	Amplifier (bose)	●	●	●	●	●	○	
2007	Cadillac	Escalade - AWD	Driver door switch	●	●	●	●	●	○	
2007	Cadillac	Escalade - AWD	Passenger door switch	●	●	●	●	●	○	
2007	Cadillac	Escalade - AWD	Digital radio receiver	●	●	●	●	○	○	
2007	Cadillac	Escalade - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Cadillac	Escalade - AWD	Instrument panel cluster	●	●	●	●	●	○	
2007	Cadillac	Escalade - AWD	Theft deterrent module	●	●	●	●	○	○	
2007	Cadillac	Escalade - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Cadillac	Escalade - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2007	Cadillac	Escalade - AWD	Passenger presence system	●	●	●	●	○	●	T020
2007	Cadillac	Escalade - AWD	Inside rear view mirror module	●	●	●	○	○	○	
2007	Cadillac	Escalade - AWD	Park assist module	●	●	●	●	●	○	
2007	Cadillac	Escalade - AWD	Memory seat module	●	●	●	●	●	○	
2007	Cadillac	Escalade - AWD	Rear heated seat module	●	●	●	●	○	○	
2007	Cadillac	Escalade - AWD	Body control module	●	●	●	●	●	●	T005
2007	Cadillac	Escalade - AWD	Rollover sensor	●	●	●	●	○	●	T049
2007	Cadillac	Escalade - AWD	Body control module (aux.)	●	●	●	●	●	○	
2007	Cadillac	Escalade - AWD	Assist step controller	●	●	●	●	●	●	T039
2007	Cadillac	Escalade - AWD	Radio	●	●	●	●	●	○	
2007	Cadillac	Escalade - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Cadillac	Escalade - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	Escalade - AWD	Personal audio link module	●	●	●	○	○	●	T036
2007	Cadillac	Escalade - AWD	Liftgate module	●	●	●	●	●	○	
2007	Cadillac	Escalade - AWD	Electronic suspension control	●	●	●	●	●	○	
2007	Cadillac	Escalade - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Cadillac	Escalade ESV	Engine control module	●	●	●	●	●	●	T001
2007	Cadillac	Escalade ESV	Transmission control module	●	●	○	●	●	○	
2007	Cadillac	Escalade ESV	Amplifier (bose)	●	●	●	●	●	○	
2007	Cadillac	Escalade ESV	Driver door switch	●	●	●	●	●	○	
2007	Cadillac	Escalade ESV	Passenger door switch	●	●	●	●	●	○	
2007	Cadillac	Escalade ESV	Digital radio receiver	●	●	●	●	○	○	
2007	Cadillac	Escalade ESV	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Cadillac	Escalade ESV	Instrument panel cluster	●	●	●	●	●	○	
2007	Cadillac	Escalade ESV	Theft deterrent module	●	●	●	●	○	○	

2007	Cadillac	Escalade ESV	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Cadillac	Escalade ESV	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Cadillac	Escalade ESV	Passenger presence system	●	●	●	●	○	●	T020
2007	Cadillac	Escalade ESV	Inside rear view mirror module	●	●	●	○	○	○	
2007	Cadillac	Escalade ESV	Park assist module	●	●	●	●	●	○	
2007	Cadillac	Escalade ESV	Memory seat module	●	●	●	●	●	○	
2007	Cadillac	Escalade ESV	Rear heated seat module	●	●	●	●	○	○	
2007	Cadillac	Escalade ESV	Body control module	●	●	●	●	●	●	T005
2007	Cadillac	Escalade ESV	Rollover sensor	●	●	●	●	○	●	T049
2007	Cadillac	Escalade ESV	Body control module (aux.)	●	●	●	●	●	○	
2007	Cadillac	Escalade ESV	Assist step controller	●	●	●	●	●	●	T039
2007	Cadillac	Escalade ESV	Radio	●	●	●	●	●	○	
2007	Cadillac	Escalade ESV	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Cadillac	Escalade ESV	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	Escalade ESV	Personal audio link module	●	●	●	○	○	●	T036
2007	Cadillac	Escalade ESV	Liftgate module	●	●	●	●	●	○	
2007	Cadillac	Escalade ESV	Electronic suspension control	●	●	●	●	●	○	
2007	Cadillac	Escalade ESV	Electronic brake control module	●	●	●	●	●	●	T014
2007	Cadillac	Escalade EXT	Engine control module	●	●	●	●	●	●	T001
2007	Cadillac	Escalade EXT	Transmission control module	●	●	○	●	●	○	
2007	Cadillac	Escalade EXT	Amplifier (bose)	●	●	●	●	●	○	
2007	Cadillac	Escalade EXT	Driver door switch	●	●	●	●	●	○	
2007	Cadillac	Escalade EXT	Passenger door switch	●	●	●	●	●	○	
2007	Cadillac	Escalade EXT	Digital radio receiver	●	●	●	●	○	○	

2007	Cadillac	Escalade EXT	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Cadillac	Escalade EXT	Instrument panel cluster	●	●	●	●	●	○	
2007	Cadillac	Escalade EXT	Theft deterrent module	●	●	●	●	○	○	
2007	Cadillac	Escalade EXT	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Cadillac	Escalade EXT	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Cadillac	Escalade EXT	Passenger presence system	●	●	●	●	○	●	T020
2007	Cadillac	Escalade EXT	Inside rear view mirror module	●	●	●	○	○	○	
2007	Cadillac	Escalade EXT	Park assist module	●	●	●	●	●	○	
2007	Cadillac	Escalade EXT	Memory seat module	●	●	●	●	●	○	
2007	Cadillac	Escalade EXT	Rear heated seat module	●	●	●	●	○	○	
2007	Cadillac	Escalade EXT	Body control module	●	●	●	●	●	●	T005
2007	Cadillac	Escalade EXT	Rollover sensor	●	●	●	●	○	●	T049
2007	Cadillac	Escalade EXT	Body control module (aux.)	●	●	●	●	●	○	
2007	Cadillac	Escalade EXT	Assist step controller	●	●	●	●	●	●	T039
2007	Cadillac	Escalade EXT	Radio	●	●	●	●	●	○	
2007	Cadillac	Escalade EXT	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Cadillac	Escalade EXT	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	Escalade EXT	Personal audio link module	●	●	●	○	○	●	T036
2007	Cadillac	Escalade EXT	Liftgate module	●	●	●	●	●	○	
2007	Cadillac	Escalade EXT	Electronic suspension control	●	●	●	●	●	○	
2007	Cadillac	Escalade EXT	Electronic brake control module	●	●	●	●	●	●	T014
2007	Cadillac	SRX	Transmission control module	●	●	●	●	●	○	
2007	Cadillac	SRX	Engine control module	●	●	●	●	●	●	T001

2007	Cadillac	SRX	Passenger presence system	●	●	●	●	○	●	T045
2007	Cadillac	SRX	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Cadillac	SRX	Rollover sensor	●	●	●	●	○	●	T049
2007	Cadillac	SRX	Theft deterrent module	●	●	●	●	○	○	
2007	Cadillac	SRX	Amplifier (bose)	●	●	●	●	●	○	
2007	Cadillac	SRX	Digital radio receiver	●	●	●	●	○	○	
2007	Cadillac	SRX	Radio	●	●	●	●	●	○	
2007	Cadillac	SRX	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2007	Cadillac	SRX	TV antenna module	●	●	●	●	○	●	T012 T013
2007	Cadillac	SRX	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Cadillac	SRX	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Cadillac	SRX	HVAC control module	●	●	●	●	●	○	
2007	Cadillac	SRX	Memory seat module	●	●	●	●	●	○	
2007	Cadillac	SRX	Rear seat module	●	●	●	●	●	○	
2007	Cadillac	SRX	Instrument panel cluster	●	●	●	●	●	○	
2007	Cadillac	SRX	Driver door switch	●	●	●	●	●	○	
2007	Cadillac	SRX	Passenger door switch	●	●	●	●	●	○	
2007	Cadillac	SRX	Body control module	●	●	●	●	●	●	T007 T005
2007	Cadillac	SRX	Park assist module	●	●	●	●	●	○	
2007	Cadillac	SRX	Body control module (aux.)	●	●	●	●	●	●	T006
2007	Cadillac	SRX	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Cadillac	SRX	Liftgate module	●	●	●	●	●	○	
2007	Cadillac	SRX	Electronic suspension control	●	●	○	●	●	○	
2007	Cadillac	SRX	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001

2007	Chevrolet	Avalanche - 2WD	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Avalanche - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Avalanche - 2WD	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Avalanche - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Avalanche - 2WD	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Assist step controller	●	●	●	●	●	●	T039
2007	Chevrolet	Avalanche - 2WD	Radio	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Avalanche - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Avalanche - 2WD	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Trailer brake control module	●	●	●	●	○	○	

2007	Chevrolet	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Avalanche - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Avalanche - 2WD	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Avalanche - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Avalanche - 2WD	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Avalanche - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Avalanche - 2WD	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Assist step controller	●	●	●	●	●	●	T039
2007	Chevrolet	Avalanche - 2WD	Radio	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Avalanche - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Avalanche - 2WD	Driver door switch	●	●	●	●	●	○	

2007	Chevrolet	Avalanche - 2WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Avalanche - 2WD	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 2WD	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Avalanche - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Avalanche - 4WD	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Avalanche - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Avalanche - 4WD	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Avalanche - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Avalanche - 4WD	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Assist step controller	●	●	●	●	●	●	T039
2007	Chevrolet	Avalanche - 4WD	Radio	●	●	●	●	●	○	

2007	Chevrolet	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Avalanche - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Avalanche - 4WD	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Avalanche - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Avalanche - 4WD	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Avalanche - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Avalanche - 4WD	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	●	T005

2007	Chevrolet	Avalanche - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Avalanche - 4WD	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Assist step controller	●	●	●	●	●	●	T039
2007	Chevrolet	Avalanche - 4WD	Radio	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Avalanche - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Avalanche - 4WD	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Avalanche - 4WD	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Avalanche - 4WD	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Avalanche - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Avalanche - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Captiva	Transmission control module	●	●	●	●	●	○	
2007	Chevrolet	Captiva	Engine control module	●	●	●	●	●	●	T017
2007	Chevrolet	Captiva	Rear drive system	●	●	●	●	●	●	T038
2007	Chevrolet	Captiva	HVAC control module	●	●	●	○	●	○	
2007	Chevrolet	Captiva	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Captiva	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Captiva	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Captiva	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Captiva	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Captiva	Theft deterrent module	●	●	●	●	●	●	T005

2007	Chevrolet	Captiva	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Colorado pickup - 2WD	Powertrain control module	●	●	○	●	●	●	T146
2007	Chevrolet	Colorado pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	Chevrolet	Colorado pickup - 2WD	Radio	●	●	●	●	○	○	
2007	Chevrolet	Colorado pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Chevrolet	Colorado pickup - 2WD	Generator battery control module	●	●	●	●	●	○	
2007	Chevrolet	Colorado pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Colorado pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022
2007	Chevrolet	Colorado pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Colorado pickup - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2007	Chevrolet	Colorado pickup - 2WD	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Colorado pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T146
2007	Chevrolet	Colorado pickup - 2WD	Powertrain control module	●	●	○	●	●	●	T146
2007	Chevrolet	Colorado pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	Chevrolet	Colorado pickup - 2WD	Radio	●	●	●	●	○	○	
2007	Chevrolet	Colorado pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Chevrolet	Colorado pickup - 2WD	Generator battery control module	●	●	●	●	●	○	

2007	Chevrolet	Colorado pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Colorado pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022
2007	Chevrolet	Colorado pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Colorado pickup - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2007	Chevrolet	Colorado pickup - 2WD	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Colorado pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T146
2007	Chevrolet	Colorado pickup - 4WD	Powertrain control module	●	●	○	●	●	●	T146
2007	Chevrolet	Colorado pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	Chevrolet	Colorado pickup - 4WD	Radio	●	●	●	●	○	○	
2007	Chevrolet	Colorado pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Chevrolet	Colorado pickup - 4WD	Generator battery control module	●	●	●	●	●	○	
2007	Chevrolet	Colorado pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Colorado pickup - 4WD	Body control module	●	●	●	●	●	●	T058 T022
2007	Chevrolet	Colorado pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Colorado pickup - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2007	Chevrolet	Colorado pickup - 4WD	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Colorado pickup - 4WD	Transfer case control module	●	●	●	●	●	●	T146

2007	Chevrolet	Colorado pickup - 4WD	Powertrain control module	●	●	○	●	●	●	T146
2007	Chevrolet	Colorado pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	Chevrolet	Colorado pickup - 4WD	Radio	●	●	●	●	○	○	
2007	Chevrolet	Colorado pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Chevrolet	Colorado pickup - 4WD	Generator battery control module	●	●	●	●	●	○	
2007	Chevrolet	Colorado pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Colorado pickup - 4WD	Body control module	●	●	●	●	●	●	T058 T022
2007	Chevrolet	Colorado pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Colorado pickup - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2007	Chevrolet	Colorado pickup - 4WD	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Colorado pickup - 4WD	Transfer case control module	●	●	●	●	●	●	T146
2007	Chevrolet	Equinox	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Equinox	Rear drive system	●	●	●	●	○	●	T038
2007	Chevrolet	Equinox	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Equinox	Radio	●	●	●	●	●	○	
2007	Chevrolet	Equinox	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Equinox	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Equinox	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Equinox	Body control module	●	●	●	●	●	●	T007 T005
2007	Chevrolet	Equinox	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Equinox	Heated seat module	●	●	●	●	○	○	

2007	Chevrolet	Equinox	Passenger presence system	●	●	●	●	○	●	T045
2007	Chevrolet	Equinox	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Equinox	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Equinox	HVAC control module	●	●	●	●	●	●	T008
2007	Chevrolet	Equinox	Power steering control module	●	●	○	●	○	○	
2007	Chevrolet	Equinox	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Express	Powertrain control module	●	●	○	●	●	●	T146
2007	Chevrolet	Express	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Express	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2007	Chevrolet	Express	Radio	●	●	●	●	○	○	
2007	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	○	
2007	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Express	Passenger presence system	●	●	○	○	○	○	
2007	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	○	
2007	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Express	Body control module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Express	Powertrain control module	●	●	○	●	●	●	T146

2007	Chevrolet	Express	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Express	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2007	Chevrolet	Express	Radio	●	●	●	●	○	○	
2007	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	○	
2007	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Express	Passenger presence system	●	●	○	○	○	○	
2007	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	○	
2007	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Express	Body control module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Express	Powertrain control module	●	●	○	●	●	○	
2007	Chevrolet	Express	Radio	●	●	●	●	○	○	
2007	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	○	
2007	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Express	Passenger presence system	●	●	○	○	○	○	
2007	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	○	
2007	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	○	

2007	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Express	Body control module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Express	Powertrain control module	●	●	○	●	●	○	
2007	Chevrolet	Express	Radio	●	●	●	●	○	○	
2007	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	○	
2007	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Express	Passenger presence system	●	●	○	○	○	○	
2007	Chevrolet	Express	Remote control door lock receiver	●	●	●	●	●	○	
2007	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Express	Body control module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Express	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	HHR	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	HHR	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	HHR	Passenger presence system	●	●	○	○	○	○	
2007	Chevrolet	HHR	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Chevrolet	HHR	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	HHR	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	HHR	Radio	●	●	●	●	●	○	

2007	Chevrolet	HHR	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	HHR	Body control module	●	●	●	●	●	●	T023
2007	Chevrolet	HHR	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	HHR	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	HHR	Remote control door lock receiver	●	●	●	●	●	○	
2007	Chevrolet	HHR	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	HHR	Power steering control module	●	●	○	●	○	○	
2007	Chevrolet	Silverado	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Silverado	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Silverado	Fuel pump control module	●	●	●	●	●	●	T001
2007	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Radio	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Silverado	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Silverado	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Silverado	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Silverado	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Memory seat module	●	●	●	●	●	○	

2007	Chevrolet	Silverado	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Silverado	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Silverado	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Silverado	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Silverado	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Silverado	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Silverado	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Silverado	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Silverado	Powertrain control module	●	●	○	●	●	●	T146
2007	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	●	T139
2007	Chevrolet	Silverado	CD changer	●	●	●	○	○	○	
2007	Chevrolet	Silverado	Chime	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	○	●	T024
2007	Chevrolet	Silverado	Disc player and video display	●	●	●	○	○	○	
2007	Chevrolet	Silverado	Radio	●	●	●	●	○	○	
2007	Chevrolet	Silverado	Rear seat audio	●	●	●	●	○	○	
2007	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Silverado	Passenger presence system	●	●	○	○	○	●	T020
2007	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2007	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	

2007	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Body control module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Generator battery control module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Driver door module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Driver seat module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Rear aux. climate module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Rear HVAC	●	●	●	●	○	○	
2007	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Passenger door module	●	●	●	●	●	●	T022
2007	Chevrolet	Silverado	Navigation radio	●	●	●	●	●	●	T033
2007	Chevrolet	Silverado	ABS	●	●	●	●	●	○	
2007	Chevrolet	Silverado	EHPS (parallel hybrid)	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Silverado	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Silverado	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Silverado	Fuel pump control module	●	●	●	●	●	●	T001
2007	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Radio	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Silverado	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Silverado	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2007	Chevrolet	Silverado	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Silverado	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Silverado	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Silverado	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Silverado	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Silverado	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Silverado	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Silverado	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Silverado	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Silverado	Powertrain control module	●	●	○	●	●	●	T146
2007	Chevrolet	Silverado	Transfer case control module	●	●	○	●	●	●	T146
2007	Chevrolet	Silverado	Amplifier (bose)	●	●	●	●	●	●	T139
2007	Chevrolet	Silverado	CD changer	●	●	●	○	○	○	
2007	Chevrolet	Silverado	Chime	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Digital radio receiver	●	●	●	●	○	●	T024
2007	Chevrolet	Silverado	Disc player and video display	●	●	●	○	○	○	
2007	Chevrolet	Silverado	Radio	●	●	●	●	○	○	
2007	Chevrolet	Silverado	Rear seat audio	●	●	●	●	○	○	

2007	Chevrolet	Silverado	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Silverado	Passenger presence system	●	●	○	○	○	●	T020
2007	Chevrolet	Silverado	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2007	Chevrolet	Silverado	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Silverado	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Body control module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Generator battery control module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Driver door module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Driver seat module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Rear aux. climate module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Rear HVAC	●	●	●	●	○	○	
2007	Chevrolet	Silverado	HVAC control module	●	●	●	●	●	○	
2007	Chevrolet	Silverado	Passenger door module	●	●	●	●	●	●	T022
2007	Chevrolet	Silverado	Navigation radio	●	●	●	●	●	●	T033
2007	Chevrolet	Silverado	ABS	●	●	●	●	●	○	
2007	Chevrolet	Silverado	EHPS (parallel hybrid)	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Silverado classic	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Silverado classic	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Silverado classic	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Radio	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Digital radio receiver	●	●	●	●	○	○	

2007	Chevrolet	Silverado classic	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Silverado classic	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Silverado classic	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Silverado classic	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Silverado classic	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Silverado classic	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Silverado classic	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Silverado classic	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Silverado classic	Electronic suspension control	●	●	●	●	●	○	

2007	Chevrolet	Silverado classic	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Silverado classic	Powertrain control module	●	●	○	●	●	●	T146
2007	Chevrolet	Silverado classic	Battery energy control module	●	●	○	●	●	○	
2007	Chevrolet	Silverado classic	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Silverado classic	Engine control module	●	●	●	●	●	●	T047 T048 T048
2007	Chevrolet	Silverado classic	Amplifier (bose)	●	●	●	●	●	●	T139
2007	Chevrolet	Silverado classic	CD changer	●	●	●	○	○	○	
2007	Chevrolet	Silverado classic	Chime	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Digital radio receiver	●	●	●	●	○	●	T024
2007	Chevrolet	Silverado classic	Disc player and video display	●	●	●	○	○	○	
2007	Chevrolet	Silverado classic	Radio	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	Rear seat audio	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Silverado classic	Passenger presence system	●	●	○	○	○	●	T020
2007	Chevrolet	Silverado classic	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2007	Chevrolet	Silverado classic	Theft deterrent module	●	●	●	●	○	○	

2007	Chevrolet	Silverado classic	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Body control module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Generator battery control module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Driver door module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Driver seat module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Rear aux. climate module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Rear HVAC	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	HVAC control module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Passenger door module	●	●	●	●	●	●	T022
2007	Chevrolet	Silverado classic	Navigation radio	●	●	●	●	●	●	T033
2007	Chevrolet	Silverado classic	ABS	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	EHPS (parallel hybrid)	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Silverado classic	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Silverado classic	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Silverado classic	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Silverado classic	Amplifier (bose)	●	●	●	●	●	○	

2007	Chevrolet	Silverado classic	Radio	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Silverado classic	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Silverado classic	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Silverado classic	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Silverado classic	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Silverado classic	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Silverado classic	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Silverado classic	Driver door switch	●	●	●	●	●	○	

2007	Chevrolet	Silverado classic	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Silverado classic	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Silverado classic	Powertrain control module	●	●	○	●	●	●	T146
2007	Chevrolet	Silverado classic	Transfer case control module	●	●	○	●	●	●	T146
2007	Chevrolet	Silverado classic	Battery energy control module	●	●	○	●	●	○	
2007	Chevrolet	Silverado classic	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Silverado classic	Engine control module	●	●	●	●	●	●	T047 T048 T048
2007	Chevrolet	Silverado classic	Amplifier (bose)	●	●	●	●	●	●	T139
2007	Chevrolet	Silverado classic	CD changer	●	●	●	○	○	○	
2007	Chevrolet	Silverado classic	Chime	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Digital radio receiver	●	●	●	●	○	●	T024
2007	Chevrolet	Silverado classic	Disc player and video display	●	●	●	○	○	○	
2007	Chevrolet	Silverado classic	Radio	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	Rear seat audio	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093

2007	Chevrolet	Silverado classic	Passenger presence system	●	●	○	○	○	●	T020
2007	Chevrolet	Silverado classic	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2007	Chevrolet	Silverado classic	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Body control module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Generator battery control module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Driver door module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Driver seat module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Rear aux. climate module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Rear HVAC	●	●	●	●	○	○	
2007	Chevrolet	Silverado classic	HVAC control module	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	Passenger door module	●	●	●	●	●	●	T022
2007	Chevrolet	Silverado classic	Navigation radio	●	●	●	●	●	●	T033
2007	Chevrolet	Silverado classic	ABS	●	●	●	●	●	○	
2007	Chevrolet	Silverado classic	EHPS (parallel hybrid)	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Suburban - 2WD	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Suburban - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	○	

2007	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Suburban - 2WD	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Suburban - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Suburban - 2WD	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Assist step controller	●	●	●	●	●	●	T039
2007	Chevrolet	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Suburban - 2WD	Radio	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Suburban - 2WD	Liftgate module	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014

2007	Chevrolet	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Suburban - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Suburban - 2WD	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Suburban - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Suburban - 2WD	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Suburban - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Suburban - 2WD	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Assist step controller	●	●	●	●	●	●	T039
2007	Chevrolet	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Suburban - 2WD	Radio	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Suburban - 2WD	Liftgate module	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Passenger door switch	●	●	●	●	●	●	T021 T022

2007	Chevrolet	Suburban - 2WD	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 2WD	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Suburban - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Suburban - 4WD	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Suburban - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Suburban - 4WD	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Suburban - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Suburban - 4WD	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Assist step controller	●	●	●	●	●	●	T039
2007	Chevrolet	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093

2007	Chevrolet	Suburban - 4WD	Radio	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Suburban - 4WD	Liftgate module	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Suburban - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Suburban - 4WD	Transmission control module	●	●	●	●	●	●	T001
2007	Chevrolet	Suburban - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Suburban - 4WD	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	●	T005

2007	Chevrolet	Suburban - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Suburban - 4WD	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Assist step controller	●	●	●	●	●	●	T039
2007	Chevrolet	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Suburban - 4WD	Radio	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Suburban - 4WD	Liftgate module	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Suburban - 4WD	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Suburban - 4WD	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Suburban - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Suburban - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Tahoe - 2WD	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Tahoe - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Tahoe - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Tahoe - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2007	Chevrolet	Tahoe - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Tahoe - 2WD	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 2WD	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Tahoe - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Tahoe - 2WD	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Assist step controller	●	●	●	●	●	●	T039
2007	Chevrolet	Tahoe - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Tahoe - 2WD	Radio	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Tahoe - 2WD	Liftgate module	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Tahoe - 2WD	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Tahoe - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Tahoe - 2WD	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Tahoe - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Tahoe - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	

2007	Chevrolet	Tahoe - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Tahoe - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Tahoe - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Tahoe - 2WD	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 2WD	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Tahoe - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Tahoe - 2WD	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Assist step controller	●	●	●	●	●	●	T039
2007	Chevrolet	Tahoe - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Tahoe - 2WD	Radio	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Tahoe - 2WD	Liftgate module	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Tahoe - 2WD	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 2WD	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Tahoe - 2WD	Transfer case control module	●	●	●	●	●	●	T001

2007	Chevrolet	Tahoe - 4WD	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Tahoe - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Tahoe - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Tahoe - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Tahoe - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Tahoe - 4WD	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 4WD	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Tahoe - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Tahoe - 4WD	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Assist step controller	●	●	●	●	●	●	T039
2007	Chevrolet	Tahoe - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Tahoe - 4WD	Radio	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Tahoe - 4WD	Liftgate module	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Tahoe - 4WD	Electronic suspension control	●	●	●	●	●	○	

2007	Chevrolet	Tahoe - 4WD	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Tahoe - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Tahoe - 4WD	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Tahoe - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Chevrolet	Tahoe - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Digital radio receiver	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Tahoe - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Chevrolet	Tahoe - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2007	Chevrolet	Tahoe - 4WD	Park assist module	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Memory seat module	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Rear heated seat module	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 4WD	Body control module	●	●	●	●	●	●	T005
2007	Chevrolet	Tahoe - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Chevrolet	Tahoe - 4WD	Body control module (aux.)	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Assist step controller	●	●	●	●	●	●	T039
2007	Chevrolet	Tahoe - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Tahoe - 4WD	Radio	●	●	●	●	●	○	

2007	Chevrolet	Tahoe - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2007	Chevrolet	Tahoe - 4WD	Liftgate module	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Driver door switch	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	Chevrolet	Tahoe - 4WD	Electronic suspension control	●	●	●	●	●	○	
2007	Chevrolet	Tahoe - 4WD	Trailer brake control module	●	●	●	●	○	○	
2007	Chevrolet	Tahoe - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Tahoe - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Trailblazer - 2WD	Powertrain control module	●	●	○	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Trailblazer - 2WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Trailblazer - 2WD	Disc player and video display	●	●	●	○	○	○	
2007	Chevrolet	Trailblazer - 2WD	Radio	●	●	●	●	○	○	
2007	Chevrolet	Trailblazer - 2WD	Rear seat audio	●	●	●	●	○	○	
2007	Chevrolet	Trailblazer - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	Chevrolet	Trailblazer - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Generator battery control module	●	●	●	●	●	○	

2007	Chevrolet	Trailblazer - 2WD	Body control module	●	●	●	●	●	●	T058
2007	Chevrolet	Trailblazer - 2WD	Driver door module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Driver seat module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	HVAC control module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Passenger door module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Liftgate module	●	●	●	●	●	●	T022
2007	Chevrolet	Trailblazer - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Trailblazer - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2007	Chevrolet	Trailblazer - 2WD	Navigation radio	●	●	●	●	●	●	T033
2007	Chevrolet	Trailblazer - 2WD	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Trailblazer - 2WD	Powertrain control module	●	●	○	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Trailblazer - 2WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Trailblazer - 2WD	Disc player and video display	●	●	●	○	○	○	

2007	Chevrolet	Trailblazer - 2WD	Radio	●	●	●	●	○	○	
2007	Chevrolet	Trailblazer - 2WD	Rear seat audio	●	●	●	●	○	○	
2007	Chevrolet	Trailblazer - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	Chevrolet	Trailblazer - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Generator battery control module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Body control module	●	●	●	●	●	●	T058
2007	Chevrolet	Trailblazer - 2WD	Driver door module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Driver seat module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	HVAC control module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Passenger door module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Liftgate module	●	●	●	●	●	●	T022
2007	Chevrolet	Trailblazer - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Trailblazer - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2007	Chevrolet	Trailblazer - 2WD	Navigation radio	●	●	●	●	●	●	T033
2007	Chevrolet	Trailblazer - 2WD	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Trailblazer - 4WD	Powertrain control module	●	●	○	●	●	○	

2007	Chevrolet	Trailblazer - 4WD	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Trailblazer - 4WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Trailblazer - 4WD	Disc player and video display	●	●	●	○	○	○	
2007	Chevrolet	Trailblazer - 4WD	Radio	●	●	●	●	○	○	
2007	Chevrolet	Trailblazer - 4WD	Rear seat audio	●	●	●	●	○	○	
2007	Chevrolet	Trailblazer - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	Chevrolet	Trailblazer - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Generator battery control module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Body control module	●	●	●	●	●	●	T058
2007	Chevrolet	Trailblazer - 4WD	Driver door module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Driver seat module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	HVAC control module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Passenger door module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Liftgate module	●	●	●	●	●	●	T022
2007	Chevrolet	Trailblazer - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093

2007	Chevrolet	Trailblazer - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2007	Chevrolet	Trailblazer - 4WD	Navigation radio	●	●	●	●	●	●	T033
2007	Chevrolet	Trailblazer - 4WD	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Trailblazer - 4WD	Powertrain control module	●	●	○	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Trailblazer - 4WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Theft deterrent module	●	●	●	●	○	○	
2007	Chevrolet	Trailblazer - 4WD	Disc player and video display	●	●	●	○	○	○	
2007	Chevrolet	Trailblazer - 4WD	Radio	●	●	●	●	○	○	
2007	Chevrolet	Trailblazer - 4WD	Rear seat audio	●	●	●	●	○	○	
2007	Chevrolet	Trailblazer - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	Chevrolet	Trailblazer - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Generator battery control module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Body control module	●	●	●	●	●	●	T058
2007	Chevrolet	Trailblazer - 4WD	Driver door module	●	●	●	●	●	○	

2007	Chevrolet	Trailblazer - 4WD	Driver seat module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	HVAC control module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Passenger door module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Liftgate module	●	●	●	●	●	●	T022
2007	Chevrolet	Trailblazer - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Trailblazer - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2007	Chevrolet	Trailblazer - 4WD	Navigation radio	●	●	●	●	●	●	T033
2007	Chevrolet	Trailblazer - 4WD	Electronic brake control module	●	●	●	●	●	○	
2007	Chevrolet	Trailblazer - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2007	Chevrolet	Uplander	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Uplander	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Uplander	Passenger presence system	●	●	○	○	○	●	T020
2007	Chevrolet	Uplander	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Chevrolet	Uplander	Mobile digital media	●	●	○	○	○	○	
2007	Chevrolet	Uplander	Radio	●	●	●	●	●	●	T095 T032 T033
2007	Chevrolet	Uplander	Disc player and video display	●	●	●	○	○	○	
2007	Chevrolet	Uplander	Body control module	●	●	●	●	●	●	T007
2007	Chevrolet	Uplander	Left power sliding door module	●	●	●	●	●	○	
2007	Chevrolet	Uplander	Right power sliding door module	●	●	●	●	●	○	
2007	Chevrolet	Uplander	HVAC control module	●	●	●	●	●	○	

2007	Chevrolet	Uplander	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Uplander	Digital radio receiver	●	●	●	●	●	●	T024
2007	Chevrolet	Uplander	Navigation radio	●	●	●	●	●	●	T033
2007	Chevrolet	Uplander	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Uplander ext.	Transmission control module	●	●	○	●	●	○	
2007	Chevrolet	Uplander ext.	Engine control module	●	●	●	●	●	●	T001
2007	Chevrolet	Uplander ext.	Passenger presence system	●	●	○	○	○	●	T020
2007	Chevrolet	Uplander ext.	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Chevrolet	Uplander ext.	Mobile digital media	●	●	○	○	○	○	
2007	Chevrolet	Uplander ext.	Radio	●	●	●	●	●	●	T095 T032 T033
2007	Chevrolet	Uplander ext.	Disc player and video display	●	●	●	○	○	○	
2007	Chevrolet	Uplander ext.	Body control module	●	●	●	●	●	●	T007
2007	Chevrolet	Uplander ext.	Left power sliding door module	●	●	●	●	●	○	
2007	Chevrolet	Uplander ext.	Right power sliding door module	●	●	●	●	●	○	
2007	Chevrolet	Uplander ext.	HVAC control module	●	●	●	●	●	○	
2007	Chevrolet	Uplander ext.	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Chevrolet	Uplander ext.	Digital radio receiver	●	●	●	●	●	●	T024
2007	Chevrolet	Uplander ext.	Navigation radio	●	●	●	●	●	●	T033
2007	Chevrolet	Uplander ext.	Electronic brake control module	●	●	●	●	●	●	T014
2007	Chevrolet	Others	Electronic brake control module	●	●	●	●	○	●	T107
2007	Chevrolet	Others	Powertrain control module	●	●	●	●	●	●	T107
2007	Chevrolet	Others	Passenger presence system	●	●	○	○	○	●	T020

2007	Chevrolet	Others	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2007	Chevrolet	Others	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Acadia - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Acadia - 2WD	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Acadia - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Acadia - 2WD	Radio	●	●	●	●	●	○	
2007	GMC truck	Acadia - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Acadia - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Acadia - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Acadia - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Acadia - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Acadia - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Acadia - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Acadia - 2WD	Body control module	○	○	○	○	○	●	T007 T005
2007	GMC truck	Acadia - 2WD	Passenger presence system	●	●	●	●	○	●	T045
2007	GMC truck	Acadia - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Acadia - 2WD	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Acadia - 2WD	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Acadia - 2WD	Head up display	●	●	●	●	○	○	
2007	GMC truck	Acadia - 2WD	Driver door switch	●	●	●	●	●	●	T035
2007	GMC truck	Acadia - 2WD	Passenger door switch	●	●	●	●	●	●	T035
2007	GMC truck	Acadia - 2WD	Liftgate module	●	●	●	●	●	●	T049
2007	GMC truck	Acadia - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Acadia - 2WD	Rear drive system	●	●	●	●	●	●	T038
2007	GMC truck	Acadia - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Acadia - 4WD	Transmission control module	●	●	○	●	●	○	

2007	GMC truck	Acadia - 4WD	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Acadia - 4WD	Radio	●	●	●	●	●	○	
2007	GMC truck	Acadia - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Acadia - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Acadia - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Acadia - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Acadia - 4WD	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Acadia - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Acadia - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Acadia - 4WD	Body control module	○	○	○	○	○	●	T007 T005
2007	GMC truck	Acadia - 4WD	Passenger presence system	●	●	●	●	○	●	T045
2007	GMC truck	Acadia - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Acadia - 4WD	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Acadia - 4WD	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Acadia - 4WD	Head up display	●	●	●	●	○	○	
2007	GMC truck	Acadia - 4WD	Driver door switch	●	●	●	●	●	●	T035
2007	GMC truck	Acadia - 4WD	Passenger door switch	●	●	●	●	●	●	T035
2007	GMC truck	Acadia - 4WD	Liftgate module	●	●	●	●	●	●	T049
2007	GMC truck	Acadia - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Acadia - 4WD	Rear drive system	●	●	●	●	●	●	T038
2007	GMC truck	Canyon pickup - 2WD	Powertrain control module	●	●	○	●	●	●	T146
2007	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	
2007	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023

2007	GMC truck	Canyon pickup - 2WD	Generator battery control module	●	●	●	●	●	○	
2007	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022
2007	GMC truck	Canyon pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Canyon pickup - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2007	GMC truck	Canyon pickup - 2WD	Electronic brake control module	●	●	●	●	●	●	T146
2007	GMC truck	Canyon pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T024
2007	GMC truck	Canyon pickup - 2WD	Powertrain control module	●	●	○	●	●	●	T146
2007	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	
2007	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	GMC truck	Canyon pickup - 2WD	Generator battery control module	●	●	●	●	●	○	
2007	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058 T022
2007	GMC truck	Canyon pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Canyon pickup - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2007	GMC truck	Canyon pickup - 2WD	Electronic brake control module	●	●	●	●	●	●	T146

2007	GMC truck	Canyon pickup - 2WD	Transfer case control module	●	●	●	●	●	●	T024
2007	GMC truck	Canyon pickup - 4WD	Powertrain control module	●	●	○	●	●	●	T146
2007	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	
2007	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	GMC truck	Canyon pickup - 4WD	Generator battery control module	●	●	●	●	●	○	
2007	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058 T022
2007	GMC truck	Canyon pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Canyon pickup - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2007	GMC truck	Canyon pickup - 4WD	Electronic brake control module	●	●	●	●	●	●	T146
2007	GMC truck	Canyon pickup - 4WD	Transfer case control module	●	●	●	●	●	●	T024
2007	GMC truck	Canyon pickup - 4WD	Powertrain control module	●	●	○	●	●	●	T146
2007	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	
2007	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	GMC truck	Canyon pickup - 4WD	Generator battery control module	●	●	●	●	●	○	

2007	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058 T022
2007	GMC truck	Canyon pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Canyon pickup - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2007	GMC truck	Canyon pickup - 4WD	Electronic brake control module	●	●	●	●	●	●	T146
2007	GMC truck	Canyon pickup - 4WD	Transfer case control module	●	●	●	●	●	●	T024
2007	GMC truck	Envoy - 2WD	Powertrain control module	●	●	○	●	●	○	
2007	GMC truck	Envoy - 2WD	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Envoy - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Envoy - 2WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Disc player and video display	●	●	●	○	○	○	
2007	GMC truck	Envoy - 2WD	Radio	●	●	●	●	○	○	
2007	GMC truck	Envoy - 2WD	Rear seat audio	●	●	●	●	○	○	
2007	GMC truck	Envoy - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	GMC truck	Envoy - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Generator battery control module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Body control module	●	●	●	●	●	●	T058
2007	GMC truck	Envoy - 2WD	Driver door module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Driver seat module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	HVAC control module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Passenger door module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Liftgate module	●	●	●	●	●	●	T022

2007	GMC truck	Envoy - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Envoy - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2007	GMC truck	Envoy - 2WD	Navigation radio	●	●	●	●	●	●	T033
2007	GMC truck	Envoy - 2WD	Electronic brake control module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Envoy - 2WD	Powertrain control module	●	●	○	●	●	○	
2007	GMC truck	Envoy - 2WD	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Envoy - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Envoy - 2WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Disc player and video display	●	●	●	○	○	○	
2007	GMC truck	Envoy - 2WD	Radio	●	●	●	●	○	○	
2007	GMC truck	Envoy - 2WD	Rear seat audio	●	●	●	●	○	○	
2007	GMC truck	Envoy - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	GMC truck	Envoy - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Generator battery control module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Body control module	●	●	●	●	●	●	T058
2007	GMC truck	Envoy - 2WD	Driver door module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Driver seat module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	HVAC control module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Passenger door module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Liftgate module	●	●	●	●	●	●	T022
2007	GMC truck	Envoy - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Envoy - 2WD	Passenger presence system	●	●	●	●	●	●	T020

2007	GMC truck	Envoy - 2WD	Navigation radio	●	●	●	●	●	●	T033
2007	GMC truck	Envoy - 2WD	Electronic brake control module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Envoy - 4WD	Powertrain control module	●	●	○	●	●	○	
2007	GMC truck	Envoy - 4WD	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Envoy - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Envoy - 4WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	Disc player and video display	●	●	●	○	○	○	
2007	GMC truck	Envoy - 4WD	Radio	●	●	●	●	○	○	
2007	GMC truck	Envoy - 4WD	Rear seat audio	●	●	●	●	○	○	
2007	GMC truck	Envoy - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	GMC truck	Envoy - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	Generator battery control module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	Body control module	●	●	●	●	●	●	T058
2007	GMC truck	Envoy - 4WD	Driver door module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	Driver seat module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	HVAC control module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	Passenger door module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	Liftgate module	●	●	●	●	●	●	T022
2007	GMC truck	Envoy - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Envoy - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2007	GMC truck	Envoy - 4WD	Navigation radio	●	●	●	●	●	●	T033
2007	GMC truck	Envoy - 4WD	Electronic brake control module	●	●	●	●	●	○	

2007	GMC truck	Envoy - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Envoy - 4WD	Powertrain control module	●	●	○	●	●	○	
2007	GMC truck	Envoy - 4WD	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Envoy - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Envoy - 4WD	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	Disc player and video display	●	●	●	○	○	○	
2007	GMC truck	Envoy - 4WD	Radio	●	●	●	●	○	○	
2007	GMC truck	Envoy - 4WD	Rear seat audio	●	●	●	●	○	○	
2007	GMC truck	Envoy - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2007	GMC truck	Envoy - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	Generator battery control module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	Body control module	●	●	●	●	●	●	T058
2007	GMC truck	Envoy - 4WD	Driver door module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	Driver seat module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	HVAC control module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	Passenger door module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	Liftgate module	●	●	●	●	●	●	T022
2007	GMC truck	Envoy - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Envoy - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2007	GMC truck	Envoy - 4WD	Navigation radio	●	●	●	●	●	●	T033
2007	GMC truck	Envoy - 4WD	Electronic brake control module	●	●	●	●	●	○	
2007	GMC truck	Envoy - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Savana	Powertrain control module	●	●	○	●	●	●	T146

2007	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Savana	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2007	GMC truck	Savana	Radio	●	●	●	●	○	○	
2007	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	○	
2007	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Savana	Passenger presence system	●	●	○	○	○	○	
2007	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	○	
2007	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Savana	Body control module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	○	
2007	GMC truck	Savana	Powertrain control module	●	●	○	●	●	●	T146
2007	GMC truck	Savana	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Savana	Auxiliary heater control module	●	●	●	●	●	●	T047 T048 T048
2007	GMC truck	Savana	Radio	●	●	●	●	○	○	
2007	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	○	
2007	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Savana	Passenger presence system	●	●	○	○	○	○	

2007	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	○	
2007	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Savana	Body control module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	○	
2007	GMC truck	Savana	Powertrain control module	●	●	○	●	●	○	
2007	GMC truck	Savana	Radio	●	●	●	●	○	○	
2007	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	○	
2007	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Savana	Passenger presence system	●	●	○	○	○	○	
2007	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	○	
2007	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Savana	Body control module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	○	
2007	GMC truck	Savana	Powertrain control module	●	●	○	●	●	○	
2007	GMC truck	Savana	Radio	●	●	●	●	○	○	
2007	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	○	

2007	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Savana	Passenger presence system	●	●	○	○	○	○	
2007	GMC truck	Savana	Remote control door lock receiver	●	●	●	●	●	○	
2007	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Savana	Body control module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Savana	Electronic brake control module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra	Transmission control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra	Fuel pump control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Sierra	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Sierra	Radio	●	●	●	●	●	○	
2007	GMC truck	Sierra	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Sierra	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Sierra	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Sierra	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Sierra	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Sierra	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Sierra	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Memory seat module	●	●	●	●	●	○	

2007	GMC truck	Sierra	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Sierra	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Sierra	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Sierra	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Sierra	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Sierra	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Sierra	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Sierra	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Sierra	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Sierra	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Sierra	Powertrain control module	●	●	○	●	●	●	T146
2007	GMC truck	Sierra	Amplifier (bose)	●	●	●	●	●	●	T139
2007	GMC truck	Sierra	CD changer	●	●	●	○	○	○	
2007	GMC truck	Sierra	Chime	●	●	●	●	●	○	
2007	GMC truck	Sierra	Digital radio receiver	●	●	●	●	○	●	T024
2007	GMC truck	Sierra	Disc player and video display	●	●	●	○	○	○	
2007	GMC truck	Sierra	Radio	●	●	●	●	○	○	
2007	GMC truck	Sierra	Rear seat audio	●	●	●	●	○	○	
2007	GMC truck	Sierra	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Sierra	Passenger presence system	●	●	○	○	○	●	T020
2007	GMC truck	Sierra	Supplemental inflatable restraint	●	●	●	●	●	●	T147

2007	GMC truck	Sierra	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Sierra	Body control module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Generator battery control module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Driver door module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Driver seat module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Rear aux. climate module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Rear HVAC	●	●	●	●	○	○	
2007	GMC truck	Sierra	HVAC control module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Passenger door module	●	●	●	●	●	●	T022
2007	GMC truck	Sierra	Navigation radio	●	●	●	●	●	●	T033
2007	GMC truck	Sierra	ABS	●	●	●	●	●	○	
2007	GMC truck	Sierra	EHPS (parallel hybrid)	●	●	●	●	●	○	
2007	GMC truck	Sierra	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Sierra	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra	Fuel pump control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Sierra	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Sierra	Radio	●	●	●	●	●	○	
2007	GMC truck	Sierra	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Sierra	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Sierra	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Sierra	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Sierra	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra	Supplemental inflatable restraint	●	●	●	●	●	●	T005

2007	GMC truck	Sierra	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Sierra	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Sierra	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Sierra	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Sierra	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Sierra	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Sierra	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Sierra	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Sierra	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Sierra	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Sierra	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Sierra	Powertrain control module	●	●	○	●	●	●	T146
2007	GMC truck	Sierra	Transfer case control module	●	●	○	●	●	●	T146
2007	GMC truck	Sierra	Amplifier (bose)	●	●	●	●	●	●	T139
2007	GMC truck	Sierra	CD changer	●	●	●	○	○	○	
2007	GMC truck	Sierra	Chime	●	●	●	●	●	○	
2007	GMC truck	Sierra	Digital radio receiver	●	●	●	●	○	●	T024
2007	GMC truck	Sierra	Disc player and video display	●	●	●	○	○	○	
2007	GMC truck	Sierra	Radio	●	●	●	●	○	○	
2007	GMC truck	Sierra	Rear seat audio	●	●	●	●	○	○	

2007	GMC truck	Sierra	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Sierra	Passenger presence system	●	●	○	○	○	●	T020
2007	GMC truck	Sierra	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2007	GMC truck	Sierra	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Sierra	Body control module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Generator battery control module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Driver door module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Driver seat module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Rear aux. climate module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Rear HVAC	●	●	●	●	○	○	
2007	GMC truck	Sierra	HVAC control module	●	●	●	●	●	○	
2007	GMC truck	Sierra	Passenger door module	●	●	●	●	●	●	T022
2007	GMC truck	Sierra	Navigation radio	●	●	●	●	●	●	T033
2007	GMC truck	Sierra	ABS	●	●	●	●	●	○	
2007	GMC truck	Sierra	EHPS (parallel hybrid)	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra classic	Transmission control module	●	●	●	●	●	●	T047 T079 T048 T048
2007	GMC truck	Sierra classic	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Sierra classic	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Radio	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2007	GMC truck	Sierra classic	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Sierra classic	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Sierra classic	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Sierra classic	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Sierra classic	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Sierra classic	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Sierra classic	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra classic	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Sierra classic	Powertrain control module	●	●	○	●	●	●	T146
2007	GMC truck	Sierra classic	Battery energy control module	●	●	○	●	●	○	
2007	GMC truck	Sierra classic	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Sierra classic	Engine control module	●	●	●	●	●	●	T047 T048 T048
2007	GMC truck	Sierra classic	Amplifier (bose)	●	●	●	●	●	●	T139
2007	GMC truck	Sierra classic	CD changer	●	●	●	○	○	○	
2007	GMC truck	Sierra classic	Chime	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Digital radio receiver	●	●	●	●	○	●	T024

2007	GMC truck	Sierra classic	Disc player and video display	●	●	●	○	○	○	
2007	GMC truck	Sierra classic	Radio	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	Rear seat audio	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Sierra classic	Passenger presence system	●	●	○	○	○	●	T020
2007	GMC truck	Sierra classic	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2007	GMC truck	Sierra classic	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Body control module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Generator battery control module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Driver door module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Driver seat module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Rear aux. climate module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Rear HVAC	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	HVAC control module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Passenger door module	●	●	●	●	●	●	T022
2007	GMC truck	Sierra classic	Navigation radio	●	●	●	●	●	●	T033
2007	GMC truck	Sierra classic	ABS	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	EHPS (parallel hybrid)	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra classic	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Sierra classic	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra classic	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Sierra classic	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Radio	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	Rear HVAC/RSA	●	●	●	●	●	○	

2007	GMC truck	Sierra classic	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra classic	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Sierra classic	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Sierra classic	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Sierra classic	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Sierra classic	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Sierra classic	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Sierra classic	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra classic	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Sierra classic	Powertrain control module	●	●	○	●	●	●	T146
2007	GMC truck	Sierra classic	Transfer case control module	●	●	○	●	●	●	T146
2007	GMC truck	Sierra classic	Battery energy control module	●	●	○	●	●	○	

2007	GMC truck	Sierra classic	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Sierra classic	Engine control module	●	●	●	●	●	●	T047 T048 T048
2007	GMC truck	Sierra classic	Amplifier (bose)	●	●	●	●	●	●	T139
2007	GMC truck	Sierra classic	CD changer	●	●	●	○	○	○	
2007	GMC truck	Sierra classic	Chime	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Digital radio receiver	●	●	●	●	○	●	T024
2007	GMC truck	Sierra classic	Disc player and video display	●	●	●	○	○	○	
2007	GMC truck	Sierra classic	Radio	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	Rear seat audio	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Sierra classic	Passenger presence system	●	●	○	○	○	●	T020
2007	GMC truck	Sierra classic	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2007	GMC truck	Sierra classic	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Body control module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Generator battery control module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Driver door module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Driver seat module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Rear aux. climate module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Rear HVAC	●	●	●	●	○	○	
2007	GMC truck	Sierra classic	HVAC control module	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	Passenger door module	●	●	●	●	●	●	T022
2007	GMC truck	Sierra classic	Navigation radio	●	●	●	●	●	●	T033
2007	GMC truck	Sierra classic	ABS	●	●	●	●	●	○	
2007	GMC truck	Sierra classic	EHPS (parallel hybrid)	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Engine control module	●	●	●	●	●	●	T001

2007	GMC truck	Sierra denali - 2WD	Transmission control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Sierra denali - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Radio	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Sierra denali - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Sierra denali - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra denali - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Sierra denali - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Sierra denali - 2WD	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Sierra denali - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Sierra denali - 2WD	Body control module (aux.)	●	●	●	●	●	○	

2007	GMC truck	Sierra denali - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Sierra denali - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Sierra denali - 2WD	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Sierra denali - 2WD	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra denali - 2WD	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Sierra denali - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Sierra denali - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali - 2WD	Transmission control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali - 2WD	Fuel pump control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Sierra denali - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Radio	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Sierra denali - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	

2007	GMC truck	Sierra denali - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Sierra denali - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra denali - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Sierra denali - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Sierra denali - 2WD	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Sierra denali - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Sierra denali - 2WD	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Sierra denali - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Sierra denali - 2WD	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Sierra denali - 2WD	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra denali - 2WD	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Sierra denali - 2WD	Trailer brake control module	●	●	●	●	○	○	

2007	GMC truck	Sierra denali - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Sierra denali - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali classic	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali classic	Transmission control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali classic	Fuel pump control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali classic	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Sierra denali classic	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Radio	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Sierra denali classic	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Sierra denali classic	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra denali classic	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Sierra denali classic	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Sierra denali classic	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Memory seat module	●	●	●	●	●	○	

2007	GMC truck	Sierra denali classic	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Sierra denali classic	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Sierra denali classic	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Sierra denali classic	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Sierra denali classic	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Sierra denali classic	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra denali classic	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Sierra denali classic	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Sierra denali classic	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali classic	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali classic	Transmission control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali classic	Fuel pump control module	●	●	●	●	●	●	T001
2007	GMC truck	Sierra denali classic	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Sierra denali classic	Amplifier (bose)	●	●	●	●	●	○	

2007	GMC truck	Sierra denali classic	Radio	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Sierra denali classic	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Sierra denali classic	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra denali classic	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Sierra denali classic	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Sierra denali classic	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Sierra denali classic	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Sierra denali classic	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Sierra denali classic	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Sierra denali classic	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Sierra denali classic	Driver door switch	●	●	●	●	●	○	

2007	GMC truck	Sierra denali classic	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Sierra denali classic	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Sierra denali classic	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Sierra denali classic	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Sierra denali classic	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon - 2WD	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Yukon - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Yukon - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Yukon - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Yukon - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Yukon - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Yukon - 2WD	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Yukon - 2WD	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Yukon - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Yukon - 2WD	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Assist step controller	●	●	●	●	●	●	T039

2007	GMC truck	Yukon - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Yukon - 2WD	Radio	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Yukon - 2WD	Liftgate module	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon - 2WD	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Yukon - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Yukon - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon - 2WD	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Yukon - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Yukon - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Yukon - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Yukon - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Yukon - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Yukon - 2WD	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Memory seat module	●	●	●	●	●	○	

2007	GMC truck	Yukon - 2WD	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Yukon - 2WD	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Yukon - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Yukon - 2WD	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Assist step controller	●	●	●	●	●	●	T039
2007	GMC truck	Yukon - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Yukon - 2WD	Radio	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Yukon - 2WD	Liftgate module	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon - 2WD	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Yukon - 2WD	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Yukon - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Yukon - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon - 4WD	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Yukon - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Yukon - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Yukon - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Yukon - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022

2007	GMC truck	Yukon - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Yukon - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Yukon - 4WD	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Yukon - 4WD	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Yukon - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Yukon - 4WD	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Assist step controller	●	●	●	●	●	●	T039
2007	GMC truck	Yukon - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Yukon - 4WD	Radio	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Yukon - 4WD	Liftgate module	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon - 4WD	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Yukon - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Yukon - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon - 4WD	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Yukon - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Yukon - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Digital radio receiver	●	●	●	●	○	○	

2007	GMC truck	Yukon - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Yukon - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Yukon - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Yukon - 4WD	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Yukon - 4WD	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Yukon - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Yukon - 4WD	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Assist step controller	●	●	●	●	●	●	T039
2007	GMC truck	Yukon - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Yukon - 4WD	Radio	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Yukon - 4WD	Liftgate module	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon - 4WD	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Yukon - 4WD	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Yukon - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Yukon - 4WD	Transfer case control module	●	●	●	●	●	●	T001

2007	GMC truck	Yukon denali	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Yukon denali	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon denali	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Yukon denali	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Yukon denali	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Yukon denali	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon denali	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Yukon denali	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Yukon denali	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Yukon denali	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Yukon denali	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Yukon denali	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Assist step controller	●	●	●	●	●	●	T039
2007	GMC truck	Yukon denali	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Yukon denali	Radio	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Yukon denali	Liftgate module	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon denali	Electronic suspension control	●	●	●	●	●	○	

2007	GMC truck	Yukon denali	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Yukon denali	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Yukon denali	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon denali	Transmission control module	●	●	○	●	●	○	
2007	GMC truck	Yukon denali	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon denali	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Yukon denali	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Yukon denali	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Yukon denali	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon denali	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Yukon denali	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Yukon denali	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Yukon denali	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Yukon denali	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Yukon denali	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Assist step controller	●	●	●	●	●	●	T039
2007	GMC truck	Yukon denali	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Yukon denali	Radio	●	●	●	●	●	○	

2007	GMC truck	Yukon denali	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Yukon denali	Liftgate module	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon denali	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Yukon denali	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Yukon denali	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Yukon denali	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL - 2WD	Transmission control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Yukon XL - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon XL - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Yukon XL - 2WD	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Yukon XL - 2WD	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 2WD	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Yukon XL - 2WD	Rollover sensor	●	●	●	●	○	●	T049

2007	GMC truck	Yukon XL - 2WD	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Assist step controller	●	●	●	●	●	●	T039
2007	GMC truck	Yukon XL - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Yukon XL - 2WD	Radio	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Yukon XL - 2WD	Liftgate module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon XL - 2WD	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Yukon XL - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL - 2WD	Transmission control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Yukon XL - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon XL - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Yukon XL - 2WD	Passenger presence system	●	●	●	●	○	●	T020

2007	GMC truck	Yukon XL - 2WD	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 2WD	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Yukon XL - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Yukon XL - 2WD	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Assist step controller	●	●	●	●	●	●	T039
2007	GMC truck	Yukon XL - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Yukon XL - 2WD	Radio	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Yukon XL - 2WD	Liftgate module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon XL - 2WD	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 2WD	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 2WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Yukon XL - 2WD	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL - 4WD	Transmission control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Yukon XL - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Theft deterrent module	●	●	●	●	○	○	

2007	GMC truck	Yukon XL - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon XL - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Yukon XL - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Yukon XL - 4WD	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 4WD	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Yukon XL - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Yukon XL - 4WD	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Assist step controller	●	●	●	●	●	●	T039
2007	GMC truck	Yukon XL - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Yukon XL - 4WD	Radio	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Yukon XL - 4WD	Liftgate module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon XL - 4WD	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 4WD	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Yukon XL - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL - 4WD	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL - 4WD	Transmission control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL - 4WD	HVAC control module	●	●	●	●	●	●	T008 T034

2007	GMC truck	Yukon XL - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 4WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 4WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon XL - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Yukon XL - 4WD	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Yukon XL - 4WD	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 4WD	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Yukon XL - 4WD	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Yukon XL - 4WD	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Assist step controller	●	●	●	●	●	●	T039
2007	GMC truck	Yukon XL - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Yukon XL - 4WD	Radio	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Yukon XL - 4WD	Liftgate module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon XL - 4WD	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Yukon XL - 4WD	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL - 4WD	Electronic brake control module	●	●	●	●	●	●	T014

2007	GMC truck	Yukon XL - 4WD	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL denali	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL denali	Transmission control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL denali	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Yukon XL denali	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Yukon XL denali	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL denali	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon XL denali	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Yukon XL denali	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Yukon XL denali	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL denali	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Yukon XL denali	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Yukon XL denali	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Assist step controller	●	●	●	●	●	●	T039
2007	GMC truck	Yukon XL denali	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	GMC truck	Yukon XL denali	Radio	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Yukon XL denali	Liftgate module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Passenger door switch	●	●	●	●	●	●	T021 T022

2007	GMC truck	Yukon XL denali	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL denali	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Yukon XL denali	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL denali	Engine control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL denali	Transmission control module	●	●	●	●	●	●	T001
2007	GMC truck	Yukon XL denali	HVAC control module	●	●	●	●	●	●	T008 T034
2007	GMC truck	Yukon XL denali	Amplifier (bose)	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Digital radio receiver	●	●	●	●	○	○	
2007	GMC truck	Yukon XL denali	Rear HVAC/RSA	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Instrument panel cluster	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Theft deterrent module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL denali	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon XL denali	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	GMC truck	Yukon XL denali	Passenger presence system	●	●	●	●	○	●	T020
2007	GMC truck	Yukon XL denali	Park assist module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Memory seat module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Rear heated seat module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL denali	Body control module	●	●	●	●	●	●	T005
2007	GMC truck	Yukon XL denali	Rollover sensor	●	●	●	●	○	●	T049
2007	GMC truck	Yukon XL denali	Body control module (aux.)	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Assist step controller	●	●	●	●	●	●	T039
2007	GMC truck	Yukon XL denali	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093

2007	GMC truck	Yukon XL denali	Radio	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Personal audio link module	●	●	●	○	○	●	T036
2007	GMC truck	Yukon XL denali	Liftgate module	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Driver door switch	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Passenger door switch	●	●	●	●	●	●	T021 T022
2007	GMC truck	Yukon XL denali	Electronic suspension control	●	●	●	●	●	○	
2007	GMC truck	Yukon XL denali	Trailer brake control module	●	●	●	●	○	○	
2007	GMC truck	Yukon XL denali	Electronic brake control module	●	●	●	●	●	●	T014
2007	GMC truck	Yukon XL denali	Transfer case control module	●	●	●	●	●	●	T001
2007	GMC truck	Others	Passenger presence system	●	●	○	○	○	●	T020
2007	GMC truck	Others	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2007	Pontiac	Montana SV6	Transmission control module	●	●	○	●	●	○	
2007	Pontiac	Montana SV6	Engine control module	●	●	●	●	●	●	T001
2007	Pontiac	Montana SV6	Passenger presence system	●	●	○	○	○	●	T020
2007	Pontiac	Montana SV6	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Pontiac	Montana SV6	Mobile digital media	●	●	○	○	○	○	
2007	Pontiac	Montana SV6	Radio	●	●	●	●	●	●	T095 T032 T033
2007	Pontiac	Montana SV6	Disc player and video display	●	●	●	○	○	○	
2007	Pontiac	Montana SV6	Body control module	●	●	●	●	●	●	T007
2007	Pontiac	Montana SV6	Left power sliding door module	●	●	●	●	●	○	
2007	Pontiac	Montana SV6	Right power sliding door module	●	●	●	●	●	○	
2007	Pontiac	Montana SV6	HVAC control module	●	●	●	●	●	○	

2007	Pontiac	Montana SV6	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Pontiac	Montana SV6	Digital radio receiver	●	●	●	●	●	●	T024
2007	Pontiac	Montana SV6	Navigation radio	●	●	●	●	●	●	T033
2007	Pontiac	Montana SV6	Electronic brake control module	●	●	●	●	●	●	T014
2007	Pontiac	Montana SV6 ext.	Transmission control module	●	●	○	●	●	○	
2007	Pontiac	Montana SV6 ext.	Engine control module	●	●	●	●	●	●	T001
2007	Pontiac	Montana SV6 ext.	Passenger presence system	●	●	○	○	○	●	T020
2007	Pontiac	Montana SV6 ext.	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Pontiac	Montana SV6 ext.	Mobile digital media	●	●	○	○	○	○	
2007	Pontiac	Montana SV6 ext.	Radio	●	●	●	●	●	●	T095 T032 T033
2007	Pontiac	Montana SV6 ext.	Disc player and video display	●	●	●	○	○	○	
2007	Pontiac	Montana SV6 ext.	Body control module	●	●	●	●	●	●	T007
2007	Pontiac	Montana SV6 ext.	Left power sliding door module	●	●	●	●	●	○	
2007	Pontiac	Montana SV6 ext.	Right power sliding door module	●	●	●	●	●	○	
2007	Pontiac	Montana SV6 ext.	HVAC control module	●	●	●	●	●	○	
2007	Pontiac	Montana SV6 ext.	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Pontiac	Montana SV6 ext.	Digital radio receiver	●	●	●	●	●	●	T024
2007	Pontiac	Montana SV6 ext.	Navigation radio	●	●	●	●	●	●	T033

2007	Pontiac	Montana SV6 ext.	Electronic brake control module	●	●	●	●	●	●	T014
2007	Pontiac	Torrent	Engine control module	●	●	●	●	●	●	T001
2007	Pontiac	Torrent	Rear drive system	●	●	●	●	○	●	T038
2007	Pontiac	Torrent	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Pontiac	Torrent	Radio	●	●	●	●	●	○	
2007	Pontiac	Torrent	Digital radio receiver	●	●	●	●	○	○	
2007	Pontiac	Torrent	Theft deterrent module	●	●	●	●	○	○	
2007	Pontiac	Torrent	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Pontiac	Torrent	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Pontiac	Torrent	Heated seat module	●	●	●	●	○	○	
2007	Pontiac	Torrent	Instrument panel cluster	●	●	●	●	●	○	
2007	Pontiac	Torrent	Passenger presence system	●	●	●	●	○	●	T045
2007	Pontiac	Torrent	Rollover sensor	●	●	●	●	○	●	T049
2007	Pontiac	Torrent	Body control module	●	●	●	●	●	●	T007 T005
2007	Pontiac	Torrent	HVAC control module	●	●	●	●	●	●	T008
2007	Pontiac	Torrent	Power steering control module	●	●	○	●	○	○	
2007	Pontiac	Torrent	Electronic brake control module	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - AWD	Engine control module	●	●	●	●	●	●	T001
2007	Saturn	OUTLOOK - AWD	Transmission control module	●	●	○	●	●	○	
2007	Saturn	OUTLOOK - AWD	Digital radio receiver	●	●	●	●	○	○	
2007	Saturn	OUTLOOK - AWD	Radio	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - AWD	Instrument panel cluster	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - AWD	Rollover sensor	●	●	●	●	○	●	T049

2007	Saturn	OUTLOOK - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Saturn	OUTLOOK - AWD	Theft deterrent module	●	●	●	●	○	○	
2007	Saturn	OUTLOOK - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Saturn	OUTLOOK - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Saturn	OUTLOOK - AWD	Body control module	○	○	○	○	○	●	T007 T005
2007	Saturn	OUTLOOK - AWD	Passenger presence system	●	●	●	●	○	●	T045
2007	Saturn	OUTLOOK - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Saturn	OUTLOOK - AWD	Memory seat module	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - AWD	Park assist module	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - AWD	Driver door switch	●	●	●	●	●	●	T035
2007	Saturn	OUTLOOK - AWD	Passenger door switch	●	●	●	●	●	●	T035
2007	Saturn	OUTLOOK - AWD	Liftgate module	●	●	●	●	●	●	T049
2007	Saturn	OUTLOOK - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Saturn	OUTLOOK - AWD	Engine control module	●	●	●	●	●	●	T001
2007	Saturn	OUTLOOK - AWD	Rear drive system	●	●	●	●	●	●	T038
2007	Saturn	OUTLOOK - AWD	Digital radio receiver	●	●	●	●	○	○	
2007	Saturn	OUTLOOK - AWD	Radio	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - AWD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - AWD	Instrument panel cluster	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - AWD	Rollover sensor	●	●	●	●	○	●	T049
2007	Saturn	OUTLOOK - AWD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Saturn	OUTLOOK - AWD	Theft deterrent module	●	●	●	●	○	○	
2007	Saturn	OUTLOOK - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Saturn	OUTLOOK - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Saturn	OUTLOOK - AWD	Body control module	○	○	○	○	○	●	T007 T005

2007	Saturn	OUTLOOK - AWD	Passenger presence system	●	●	●	●	○	●	T045
2007	Saturn	OUTLOOK - AWD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Saturn	OUTLOOK - AWD	Memory seat module	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - AWD	Park assist module	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - AWD	Driver door switch	●	●	●	●	●	●	T035
2007	Saturn	OUTLOOK - AWD	Passenger door switch	●	●	●	●	●	●	T035
2007	Saturn	OUTLOOK - AWD	Liftgate module	●	●	●	●	●	●	T049
2007	Saturn	OUTLOOK - AWD	Electronic brake control module	●	●	●	●	●	●	T014
2007	Saturn	OUTLOOK - 2WD	Engine control module	●	●	●	●	●	●	T001
2007	Saturn	OUTLOOK - 2WD	Transmission control module	●	●	○	●	●	○	
2007	Saturn	OUTLOOK - 2WD	Digital radio receiver	●	●	●	●	○	○	
2007	Saturn	OUTLOOK - 2WD	Radio	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - 2WD	Rear HVAC/RSA	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - 2WD	Rollover sensor	●	●	●	●	○	●	T049
2007	Saturn	OUTLOOK - 2WD	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Saturn	OUTLOOK - 2WD	Theft deterrent module	●	●	●	●	○	○	
2007	Saturn	OUTLOOK - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Saturn	OUTLOOK - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Saturn	OUTLOOK - 2WD	Body control module	○	○	○	○	○	●	T007 T005
2007	Saturn	OUTLOOK - 2WD	Passenger presence system	●	●	●	●	○	●	T045
2007	Saturn	OUTLOOK - 2WD	HVAC control module	●	●	●	●	●	●	T008 T034
2007	Saturn	OUTLOOK - 2WD	Memory seat module	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - 2WD	Park assist module	●	●	●	●	●	○	
2007	Saturn	OUTLOOK - 2WD	Driver door switch	●	●	●	●	●	●	T035
2007	Saturn	OUTLOOK - 2WD	Passenger door switch	●	●	●	●	●	●	T035
2007	Saturn	OUTLOOK - 2WD	Liftgate module	●	●	●	●	●	●	T049

2007	Saturn	Relay	Disc player and video display	●	●	●	○	○	○	
2007	Saturn	Relay	Body control module	●	●	●	●	●	●	T007
2007	Saturn	Relay	Left power sliding door module	●	●	●	●	●	○	
2007	Saturn	Relay	Right power sliding door module	●	●	●	●	●	○	
2007	Saturn	Relay	HVAC control module	●	●	●	●	●	○	
2007	Saturn	Relay	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Saturn	Relay	Digital radio receiver	●	●	●	●	○	●	T024
2007	Saturn	Relay	Passenger presence system	●	●	●	●	●	●	T020
2007	Saturn	Relay	Navigation radio	●	●	●	●	●	●	T033
2007	Saturn	Relay	Electronic brake control module	●	●	○	●	●	●	T014
2007	Saturn	VUE	Engine control module	●	●	●	●	●	●	T001
2007	Saturn	VUE	Transmission control module	●	●	●	●	●	●	T001
2007	Saturn	VUE	Powertrain control module	●	●	●	●	●	○	
2007	Saturn	VUE	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Saturn	VUE	Digital radio receiver	●	●	●	○	○	○	
2007	Saturn	VUE	Radio	●	●	●	●	●	●	T059
2007	Saturn	VUE	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Saturn	VUE	Instrument panel cluster	○	○	●	○	●	○	
2007	Saturn	VUE	Body control module	●	●	●	●	●	●	T141 T148 T142 T143 T008
2007	Saturn	VUE	Electronic brake control module	●	●	○	●	●	○	
2007	Saturn	VUE	Power steering control module	●	●	○	●	○	○	

2007	Saturn	VUE	Engine control module	●	●	●	●	●	●	T074 T075 T001
2007	Saturn	VUE	Battery energy control module	○	○	○	●	●	○	
2007	Saturn	VUE	Starter/generator control module	○	○	○	●	●	○	
2007	Saturn	VUE	Transmission control module	●	●	○	●	●	○	
2007	Saturn	VUE	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Saturn	VUE	Digital radio receiver	●	●	●	○	○	○	
2007	Saturn	VUE	Radio	●	●	●	●	●	●	T059
2007	Saturn	VUE	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Saturn	VUE	Instrument panel cluster	○	○	●	○	●	○	
2007	Saturn	VUE	Body control module	●	●	●	●	●	●	T141 T148 T142 T143 T008
2007	Saturn	VUE	Power steering control module	●	●	○	●	○	○	
2007	Saturn	VUE	Electronic brake control module	●	●	○	●	●	●	T014
2007	Saturn	VUE hybrid	Engine control module	●	●	●	●	●	●	T001
2007	Saturn	VUE hybrid	Transmission control module	●	●	●	●	●	●	T001
2007	Saturn	VUE hybrid	Powertrain control module	●	●	●	●	●	○	
2007	Saturn	VUE hybrid	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Saturn	VUE hybrid	Digital radio receiver	●	●	●	○	○	○	
2007	Saturn	VUE hybrid	Radio	●	●	●	●	●	●	T059
2007	Saturn	VUE hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Saturn	VUE hybrid	Instrument panel cluster	○	○	●	○	●	○	

2007	Saturn	VUE hybrid	Body control module	●	●	●	●	●	●	T141 T148 T142 T143 T008
2007	Saturn	VUE hybrid	Electronic brake control module	●	●	○	●	●	○	
2007	Saturn	VUE hybrid	Power steering control module	●	●	○	●	○	○	
2007	Saturn	VUE hybrid	Engine control module	●	●	●	●	●	●	T074 T075 T001
2007	Saturn	VUE hybrid	Battery energy control module	○	○	○	●	●	○	
2007	Saturn	VUE hybrid	Starter/generator control module	○	○	○	●	●	○	
2007	Saturn	VUE hybrid	Transmission control module	●	●	○	●	●	○	
2007	Saturn	VUE hybrid	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Saturn	VUE hybrid	Digital radio receiver	●	●	●	○	○	○	
2007	Saturn	VUE hybrid	Radio	●	●	●	●	●	●	T059
2007	Saturn	VUE hybrid	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Saturn	VUE hybrid	Instrument panel cluster	○	○	●	○	●	○	
2007	Saturn	VUE hybrid	Body control module	●	●	●	●	●	●	T141 T148 T142 T143 T008
2007	Saturn	VUE hybrid	Power steering control module	●	●	○	●	○	○	
2007	Saturn	VUE hybrid	Electronic brake control module	●	●	○	●	●	●	T014
2007	Hummer	H2	Powertrain control module	○	○	○	●	●	○	
2007	Hummer	H2	Transfer case control module	●	●	○	●	●	○	
2007	Hummer	H2	Amplifier (bose)	●	●	●	●	●	○	
2007	Hummer	H2	Digital radio receiver	●	●	●	●	○	●	T024
2007	Hummer	H2	Radio	●	●	●	●	○	○	
2007	Hummer	H2	Rear seat audio	●	●	●	●	○	○	

2007	Hummer	H2	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Hummer	H2	Instrument panel cluster	●	●	●	●	●	○	
2007	Hummer	H2	Body control module	●	●	●	●	●	○	
2007	Hummer	H2	Driver door module	●	●	●	●	●	○	
2007	Hummer	H2	Driver seat module	●	●	●	●	●	○	
2007	Hummer	H2	HVAC control module	●	●	●	●	●	○	
2007	Hummer	H2	Passenger door module	●	●	●	●	●	●	T022
2007	Hummer	H2	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2007	Hummer	H2	Navigation radio	●	●	●	●	●	●	T033
2007	Hummer	H2	Air suspension	●	●	●	●	●	○	
2007	Hummer	H2	ABS	●	●	○	●	●	●	T149
2007	Hummer	H3	Powertrain control module	○	○	○	●	●	○	
2007	Hummer	H3	Transfer case control module	●	●	○	●	●	●	T146
2007	Hummer	H3	Passenger presence system	●	●	○	○	○	●	T020
2007	Hummer	H3	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2007	Hummer	H3	Radio	●	●	●	●	●	●	T080 T032
2007	Hummer	H3	Digital radio receiver	●	●	●	●	○	●	T024
2007	Hummer	H3	Generator battery control module	●	●	●	●	●	○	
2007	Hummer	H3	Instrument panel cluster	●	●	●	●	●	○	
2007	Hummer	H3	Body control module	●	●	●	●	●	●	T058 T022
2007	Hummer	H3	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Hummer	H3	Personal audio link module	●	●	●	●	●	●	T036
2007	Hummer	H3	Navigation radio	●	●	●	●	●	●	T033

2007	Hummer	H3	Electronic brake control module	●	●	●	●	●	●	T146
2007	Saab	Saab 9-7x	Powertrain control module	●	●	○	●	●	○	
2007	Saab	Saab 9-7x	Transfer case control module	●	●	○	●	●	○	
2007	Saab	Saab 9-7x	Transmission control module	●	●	○	●	●	○	
2007	Saab	Saab 9-7x	Engine control module	●	●	●	●	●	●	T001
2007	Saab	Saab 9-7x	Passenger presence system	●	●	○	○	○	●	T020
2007	Saab	Saab 9-7x	Supplemental inflatable restraint	●	●	●	●	●	○	
2007	Saab	Saab 9-7x	Theft deterrent module	●	●	●	●	○	○	
2007	Saab	Saab 9-7x	Disc player and video display	●	●	●	○	○	○	
2007	Saab	Saab 9-7x	Rear seat audio	●	●	●	●	○	○	
2007	Saab	Saab 9-7x	Digital radio receiver	●	●	●	●	○	●	T024
2007	Saab	Saab 9-7x	Radio	●	●	●	●	●	●	T080 T032
2007	Saab	Saab 9-7x	Instrument panel cluster	●	●	●	●	●	○	
2007	Saab	Saab 9-7x	Generator battery control module	●	●	●	●	●	○	
2007	Saab	Saab 9-7x	Body control module	●	●	●	●	●	●	T058
2007	Saab	Saab 9-7x	Driver door module	●	●	●	●	●	○	
2007	Saab	Saab 9-7x	Driver seat module	●	●	●	●	●	○	
2007	Saab	Saab 9-7x	HVAC control module	●	●	●	●	●	○	
2007	Saab	Saab 9-7x	Passenger door module	●	●	●	●	●	○	
2007	Saab	Saab 9-7x	Liftgate module	●	●	●	●	●	●	T022
2007	Saab	Saab 9-7x	Vehicle comm. interface module	●	●	●	●	●	●	T002 T099 T073 T003 T093
2007	Saab	Saab 9-7x	Navigation radio	●	●	●	●	●	●	T033
2007	Saab	Saab 9-7x	Electronic brake control module	●	●	●	●	●	○	
2007	Holden	Captiva	HVAC control module	●	●	●	○	●	○	

2007	Holden	Captiva	Instrument panel cluster	●	●	●	●	●	○	
2007	Holden	Captiva	Body control module	●	●	●	●	●	●	T005
2007	Holden	Captiva	Body control module (aux.)	●	●	●	●	●	○	
2007	Holden	Captiva	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Holden	Captiva	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Holden	Captiva	Theft deterrent module	●	●	●	●	●	●	T005
2007	Holden	Captiva maxx	HVAC control module	●	●	●	○	●	○	
2007	Holden	Captiva maxx	Remote control door lock receiver	●	●	●	●	●	●	T021 T022
2007	Holden	Captiva maxx	Theft deterrent module	●	●	●	●	○	○	
2007	Holden	Captiva maxx	Front display interface module	●	●	●	○	○	○	
2007	Holden	Captiva maxx	Instrument panel cluster	●	●	○	●	●	○	
2007	Holden	Captiva maxx	Headlamp control module	●	●	●	●	●	○	
2007	Holden	Captiva maxx	Park assist module	●	●	●	●	○	○	
2007	Holden	Captiva maxx	Body control module	●	●	●	●	●	●	T005
2007	Holden	Captiva maxx	Body control module (aux.)	●	●	●	●	●	○	
2007	Holden	Captiva maxx	Supplemental inflatable restraint	●	●	●	●	●	●	T005
2007	Holden	Captiva maxx	Radio	●	●	●	●	●	●	T021 T022
2007	Holden	Captiva maxx	Electronic brake control module	●	●	●	●	●	○	
2007	Holden	Captiva maxx	Engine control module	●	●	●	●	●	○	
2007	Holden	Captiva maxx	Transmission control module	●	●	●	●	●	○	
2007	Holden	Captiva maxx	Rear drive system	●	●	●	●	●	●	T038
2006	Buick	Lacrosse	HVAC systems - manual	●	●	●	●	●	●	T007

2006	Buick	Lacrosse	HVAC systems - automatic	●	●	●	●	●	●	T008
2006	Buick	Lacrosse	Antilock brake system	●	●	●	●	●	●	T014
2006	Buick	Lacrosse	Engine controls	●	●	○	●	●	○	
2006	Buick	Lacrosse	Engine cooling	●	●	○	●	●	○	
2006	Buick	Lacrosse	Engine electrical	●	●	●	●	●	●	T007
2006	Buick	Lacrosse	Shift lock control	●	●	●	●	●	●	T007
2006	Buick	Lacrosse	Automatic transaxle	●	●	●	●	●	●	T007
2006	Buick	Lacrosse	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2006	Buick	Lacrosse	Cruise control	●	●	●	●	●	○	
2006	Buick	Lacrosse	Entertainment	●	●	●	●	●	●	T024
2006	Buick	Lacrosse	Horns	●	●	●	●	●	●	T007
2006	Buick	Lacrosse	Instrument panel	●	●	●	●	●	○	
2006	Buick	Lacrosse	Keyless entry	●	●	●	●	●	●	T007
2006	Buick	Lacrosse	Lighting systems	●	●	●	●	●	●	T007
2006	Buick	Lacrosse	Seats	●	●	●	●	●	●	T007
2006	Buick	Lacrosse	Stationary windows	●	●	●	●	●	●	T007
2006	Buick	Lacrosse	Theft deterrent	●	●	●	●	●	●	T007
2006	Buick	Lacrosse	Wipers/washer systems	●	●	●	●	●	●	T007
2006	Buick	Lacrosse	Seat belts	●	●	●	●	●	●	T147 T023
2006	Buick	Lacrosse	SIR	●	●	●	●	●	●	T147 T023
2006	Buick	Lacrosse (allure in canada)	HVAC systems - manual	●	●	●	●	●	●	T007
2006	Buick	Lacrosse (allure in canada)	HVAC systems - automatic	●	●	●	●	●	●	T008
2006	Buick	Lacrosse (allure in canada)	Antilock brake system	●	●	●	●	●	●	T014
2006	Buick	Lacrosse (allure in canada)	Engine controls	●	●	○	●	●	○	

2006	Buick	Lacrosse (allure in canada)	Engine cooling	●	●	○	●	●	○	
2006	Buick	Lacrosse (allure in canada)	Engine electrical	●	●	●	●	●	●	T007
2006	Buick	Lacrosse (allure in canada)	Shift lock control	●	●	●	●	●	●	T007
2006	Buick	Lacrosse (allure in canada)	Automatic transaxle	●	●	●	●	●	●	T007
2006	Buick	Lacrosse (allure in canada)	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2006	Buick	Lacrosse (allure in canada)	Cruise control	●	●	●	●	●	○	
2006	Buick	Lacrosse (allure in canada)	Entertainment	●	●	●	●	●	●	T024
2006	Buick	Lacrosse (allure in canada)	Horns	●	●	●	●	●	●	T007
2006	Buick	Lacrosse (allure in canada)	Instrument panel	●	●	●	●	●	○	
2006	Buick	Lacrosse (allure in canada)	Keyless entry	●	●	●	●	●	●	T007
2006	Buick	Lacrosse (allure in canada)	Lighting systems	●	●	●	●	●	●	T007

2006	Buick	Lacrosse (allure in canada)	Seats	●	●	●	●	●	●	T007
2006	Buick	Lacrosse (allure in canada)	Stationary windows	●	●	●	●	●	●	T007
2006	Buick	Lacrosse (allure in canada)	Theft deterrent	●	●	●	●	●	●	T007
2006	Buick	Lacrosse (allure in canada)	Wipers/washer systems	●	●	●	●	●	●	T007
2006	Buick	Lacrosse (allure in canada)	Seat belts	●	●	●	●	●	●	T147 T023
2006	Buick	Lacrosse (allure in canada)	SIR	●	●	●	●	●	●	T147 T023
2006	Buick	Lucerne	HVAC systems - automatic	●	●	●	●	●	○	
2006	Buick	Lucerne	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Buick	Lucerne	Steering	●	●	●	●	○	○	
2006	Buick	Lucerne	Suspension	●	●	○	●	●	○	
2006	Buick	Lucerne	Antilock brake system	●	●	●	●	●	●	T001
2006	Buick	Lucerne	Hydraulic brakes	●	●	●	○	○	○	
2006	Buick	Lucerne	Park brake	●	●	●	●	●	●	T014
2006	Buick	Lucerne	Engine controls	●	●	●	●	●	●	T001
2006	Buick	Lucerne	Engine cooling	●	●	●	●	●	●	T001
2006	Buick	Lucerne	Engine electrical	●	●	●	●	●	●	T001
2006	Buick	Lucerne	Shift lock control	●	●	●	●	○	○	
2006	Buick	Lucerne	Automatic transaxle	●	●	●	●	●	○	
2006	Buick	Lucerne	Body rear end	●	●	●	●	○	○	
2006	Buick	Lucerne	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Buick	Lucerne	Cruise control	●	●	●	●	●	●	T001

2006	Buick	Lucerne	Doors	●	●	●	●	●	○	
2006	Buick	Lucerne	Entertainment	●	●	●	●	●	○	
2006	Buick	Lucerne	Horns	●	●	●	●	○	○	
2006	Buick	Lucerne	Instrument panel	●	●	●	●	●	●	T001
2006	Buick	Lucerne	Keyless entry	●	●	●	●	●	●	T001
2006	Buick	Lucerne	Lighting systems	●	●	●	●	○	○	
2006	Buick	Lucerne	Body control module	●	●	●	●	○	○	
2006	Buick	Lucerne	Seats	●	●	●	●	●	○	
2006	Buick	Lucerne	Stationary windows	●	●	●	●	○	○	
2006	Buick	Lucerne	Theft deterrent	●	●	●	●	●	●	T001
2006	Buick	Lucerne	Wipers/washer systems	●	●	●	●	○	○	
2006	Buick	Lucerne	Rear parking assist	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Buick	Lucerne	Seat belts	●	●	●	●	●	●	T005
2006	Buick	Lucerne	SIR	●	●	●	●	●	●	T005
2006	Buick	Others	Powertrain	●	●	●	●	●	●	T001
2006	Buick	Others	Electronic brake control module	●	●	●	●	●	●	T014
2006	Cadillac	CTS	Powertrain	●	●	●	●	●	○	
2006	Cadillac	CTS	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2006	Cadillac	CTS	Driver door switch	●	●	●	●	○	●	T117 T117 T117 T117
2006	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2006	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2006	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2006	Cadillac	CTS	Passenger presence system	●	●	○	○	○	○	
2006	Cadillac	CTS	Remote function actuation	●	●	●	●	●	○	
2006	Cadillac	CTS	Climate control panel	●	●	●	●	●	○	
2006	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T118 T119 T120 T121
2006	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2006	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	

2006	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2006	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2006	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2006	Cadillac	CTS	Radio	●	●	●	●	○	●	T032
2006	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2006	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2006	Cadillac	CTS	Tire pressure monitor	●	●	○	●	●	●	T137
2006	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2006	Cadillac	CTS	Powertrain	●	●	●	●	●	○	
2006	Cadillac	CTS	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2006	Cadillac	CTS	Driver door switch	●	●	●	●	○	○	
2006	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2006	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2006	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2006	Cadillac	CTS	Passenger presence system	●	●	○	○	○	○	
2006	Cadillac	CTS	Remote function actuation	●	●	●	●	●	○	
2006	Cadillac	CTS	Climate control panel	●	●	●	●	●	○	
2006	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T118 T119 T120 T121
2006	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2006	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2006	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2006	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2006	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2006	Cadillac	CTS	Radio	●	●	●	●	○	●	T032
2006	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	

2006	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2006	Cadillac	CTS	Tire pressure monitor	●	●	○	●	●	●	T137
2006	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2006	Cadillac	CTS	Powertrain	●	●	●	●	●	○	
2006	Cadillac	CTS	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2006	Cadillac	CTS	Driver door switch	●	●	●	●	○	○	
2006	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2006	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2006	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2006	Cadillac	CTS	Passenger presence system	●	●	○	○	○	○	
2006	Cadillac	CTS	Remote function actuation	●	●	●	●	●	○	
2006	Cadillac	CTS	Climate control panel	●	●	●	●	●	○	
2006	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T118 T119 T120 T121
2006	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2006	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2006	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2006	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2006	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2006	Cadillac	CTS	Radio	●	●	●	●	○	●	T032
2006	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2006	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2006	Cadillac	CTS	Tire pressure monitor	●	●	○	●	●	●	T137
2006	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014

2006	Cadillac	CTS	Powertrain	●	●	●	●	●	●	T001
2006	Cadillac	CTS	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2006	Cadillac	CTS	Driver door switch	●	●	●	●	○	○	
2006	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2006	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2006	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2006	Cadillac	CTS	Passenger presence system	●	●	○	○	○	○	
2006	Cadillac	CTS	Remote function actuation	●	●	●	●	●	○	
2006	Cadillac	CTS	Climate control panel	●	●	●	●	●	○	
2006	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T118 T119 T120 T121
2006	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2006	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2006	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2006	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2006	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2006	Cadillac	CTS	Radio	●	●	●	●	○	●	T032
2006	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2006	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2006	Cadillac	CTS	Tire pressure monitor	●	●	○	●	●	●	T137
2006	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2006	Cadillac	DTS	HVAC systems - automatic	●	●	●	●	●	●	T001
2006	Cadillac	DTS	Steering wheel and column	●	●	●	●	●	○	
2006	Cadillac	DTS	Tire pressure monitoring	●	●	●	●	●	●	T021 T022

2006	Cadillac	DTS	Electronic suspension control (ESC)	●	●	○	●	●	○	
2006	Cadillac	DTS	Antilock brake system	●	●	●	●	●	●	T001
2006	Cadillac	DTS	Hydraulic brakes	●	●	●	○	○	○	
2006	Cadillac	DTS	Park brake	●	●	●	●	○	○	
2006	Cadillac	DTS	Engine controls	●	●	●	●	●	●	T001
2006	Cadillac	DTS	Engine cooling	●	●	●	●	●	●	T001
2006	Cadillac	DTS	Engine electrical	●	●	●	●	●	●	T001
2006	Cadillac	DTS	Shift lock control	●	●	●	●	○	○	
2006	Cadillac	DTS	Automatic transaxle	●	●	●	●	●	○	
2006	Cadillac	DTS	Body rear end	●	●	●	●	○	○	
2006	Cadillac	DTS	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Cadillac	DTS	Cruise control	●	●	●	●	●	●	T001
2006	Cadillac	DTS	Doors	●	●	●	●	●	○	
2006	Cadillac	DTS	Entertainment	●	●	●	●	●	●	T111
2006	Cadillac	DTS	Horns	●	●	●	●	○	○	
2006	Cadillac	DTS	Instrument panel	●	●	●	●	●	●	T001
2006	Cadillac	DTS	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Cadillac	DTS	Lighting systems	●	●	●	●	○	○	
2006	Cadillac	DTS	Body control module	●	●	●	●	○	○	
2006	Cadillac	DTS	Seats	●	●	●	●	●	○	
2006	Cadillac	DTS	Stationary windows	●	●	●	●	○	○	
2006	Cadillac	DTS	Theft deterrent	●	●	●	●	●	●	T001
2006	Cadillac	DTS	Wipers/washer systems	●	●	●	●	○	○	
2006	Cadillac	DTS	Rear parking assist	●	●	●	●	●	○	
2006	Cadillac	DTS	Seat belts	●	●	●	●	●	●	T005
2006	Cadillac	DTS	SIR	●	●	●	●	●	●	T005
2006	Cadillac	STS	Shift lock control	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Automatic transmission	●	●	●	●	●	○	
2006	Cadillac	STS	HVAC systems - automatic	●	●	●	●	●	●	T001

2006	Cadillac	STS	Variable effort steering	●	●	○	●	○	○	
2006	Cadillac	STS	Steering wheel and column	●	●	●	●	●	●	T059
2006	Cadillac	STS	Electronic suspension control (ESC)	●	●	○	●	●	○	
2006	Cadillac	STS	Antilock brake system	●	●	●	●	●	●	T001
2006	Cadillac	STS	Hydraulic brakes	●	●	○	●	○	○	
2006	Cadillac	STS	Park brake	●	●	●	●	●	○	
2006	Cadillac	STS	Engine controls	●	●	●	●	●	●	T001
2006	Cadillac	STS	Engine cooling	●	●	●	●	●	●	T001
2006	Cadillac	STS	Engine electrical	●	●	●	●	●	●	T067
2006	Cadillac	STS	Body rear end	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Cadillac	STS	Cruise control	●	●	●	●	●	●	T001
2006	Cadillac	STS	Doors	●	●	●	●	●	●	T068
2006	Cadillac	STS	Entertainment	●	●	●	●	●	●	T024
2006	Cadillac	STS	Horns	●	●	●	●	●	○	
2006	Cadillac	STS	Instrument panel	●	●	●	●	●	●	T001
2006	Cadillac	STS	Keyless entry	●	●	●	●	●	●	T059
2006	Cadillac	STS	Lighting systems	●	●	●	●	●	●	T059
2006	Cadillac	STS	Seats	●	●	●	●	●	○	
2006	Cadillac	STS	Stationary windows	●	●	●	●	●	○	
2006	Cadillac	STS	Theft deterrent	●	●	●	●	●	●	T001
2006	Cadillac	STS	Wipers/washer systems	●	●	●	●	●	●	T059
2006	Cadillac	STS	Rear parking assist	●	●	●	●	●	○	
2006	Cadillac	STS	Seat belts	●	●	●	●	●	●	T067
2006	Cadillac	STS	SIR	●	●	●	●	●	●	T067
2006	Cadillac	STS	HVAC systems - automatic	●	●	●	●	●	●	T001

2006	Cadillac	STS	Variable effort steering	●	●	○	●	○	○	
2006	Cadillac	STS	Steering wheel and column	●	●	●	●	●	●	T059
2006	Cadillac	STS	Tire pressure monitoring	●	●	●	●	●	●	T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066
2006	Cadillac	STS	Electronic suspension control (ESC)	●	●	○	●	●	○	
2006	Cadillac	STS	Antilock brake system	●	●	●	●	●	●	T001
2006	Cadillac	STS	Hydraulic brakes	●	●	○	●	●	○	
2006	Cadillac	STS	Park brake	●	●	●	●	●	○	
2006	Cadillac	STS	Engine controls	●	●	●	●	●	●	T001
2006	Cadillac	STS	Engine cooling	●	●	●	●	●	●	T001
2006	Cadillac	STS	Engine electrical	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Shift lock control	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Automatic transmission	●	●	●	●	●	○	
2006	Cadillac	STS	Body rear end	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Cadillac	STS	Cruise control	●	●	●	●	●	●	T059
2006	Cadillac	STS	Doors	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Entertainment	●	●	●	●	●	●	T024

2006	Cadillac	STS	Horns	●	●	●	●	●	○	
2006	Cadillac	STS	Instrument panel	●	●	●	●	●	●	T059
2006	Cadillac	STS	Keyless entry	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Lighting systems	●	●	●	●	●	●	T059
2006	Cadillac	STS	Seats	●	●	●	●	●	○	
2006	Cadillac	STS	Stationary windows	●	●	●	●	●	○	
2006	Cadillac	STS	Theft deterrent	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Wipers/washer systems	●	●	●	●	●	●	T059
2006	Cadillac	STS	Rear parking assist	●	●	●	●	●	○	
2006	Cadillac	STS	Seat belts	●	●	●	●	●	●	T067
2006	Cadillac	STS	SIR	●	●	●	●	●	●	T067
2006	Cadillac	STS	Variable effort steering	●	●	○	●	○	○	
2006	Cadillac	STS	Steering wheel and column	●	●	●	●	●	●	T059
2006	Cadillac	STS	Tire pressure monitoring	●	●	●	●	●	●	T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066
2006	Cadillac	STS	Electronic suspension control (ESC)	●	●	○	●	●	○	
2006	Cadillac	STS	Seat belts	●	●	●	●	●	●	T067
2006	Cadillac	STS	SIR	●	●	●	●	●	●	T067
2006	Cadillac	STS	HVAC systems - automatic	●	●	●	●	●	○	
2006	Cadillac	STS	Antilock brake system	●	●	●	●	●	●	T014
2006	Cadillac	STS	Hydraulic brakes	●	●	○	●	●	○	
2006	Cadillac	STS	Park brake	●	●	●	●	●	○	
2006	Cadillac	STS	Engine controls	●	●	●	●	●	○	
2006	Cadillac	STS	Engine cooling	●	●	●	●	●	○	

2006	Cadillac	STS	Engine electrical	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Shift lock control	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Automatic transmission	●	●	●	●	●	○	
2006	Cadillac	STS	Body rear end	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Cadillac	STS	Cruise control	●	●	●	●	●	●	T059
2006	Cadillac	STS	Doors	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Entertainment	●	●	●	●	●	●	T024
2006	Cadillac	STS	Horns	●	●	●	●	●	○	
2006	Cadillac	STS	Instrument panel	●	●	●	●	●	●	T059
2006	Cadillac	STS	Keyless entry	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Lighting systems	●	●	●	●	●	●	T059
2006	Cadillac	STS	Seats	●	●	●	●	●	○	
2006	Cadillac	STS	Stationary windows	●	●	●	●	●	○	
2006	Cadillac	STS	Theft deterrent	●	●	●	●	●	●	T063 T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2006	Cadillac	STS	Wipers/washer systems	●	●	●	●	●	●	T059

2006	Cadillac	STS	Rear parking assist	●	●	●	●	●	○	
2006	Cadillac	XLR	HVAC systems - automatic	●	●	●	●	●	●	T001
2006	Cadillac	XLR	Variable effort steering	●	●	○	●	○	○	
2006	Cadillac	XLR	Steering wheel and column	●	●	○	●	●	○	
2006	Cadillac	XLR	Tire pressure monitoring	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Cadillac	XLR	Electronic suspension control (ESC)	●	●	○	●	●	○	
2006	Cadillac	XLR	Antilock brake system	●	●	●	●	●	●	T001
2006	Cadillac	XLR	Hydraulic brakes	●	●	○	●	●	○	
2006	Cadillac	XLR	Park brake	●	●	○	●	●	○	
2006	Cadillac	XLR	Engine exhaust	●	●	●	●	●	○	
2006	Cadillac	XLR	Engine controls	●	●	●	●	●	●	T001
2006	Cadillac	XLR	Engine cooling	●	●	●	●	●	●	T001
2006	Cadillac	XLR	Engine electrical	●	●	●	●	●	●	T001
2006	Cadillac	XLR	Shift lock control	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Cadillac	XLR	Automatic transmission	●	●	●	●	●	○	
2006	Cadillac	XLR	Body rear end	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Cadillac	XLR	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Cadillac	XLR	Cruise control	●	●	●	●	●	●	T001
2006	Cadillac	XLR	Doors	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Cadillac	XLR	Entertainment	●	●	●	●	●	●	T024
2006	Cadillac	XLR	Horns	●	●	○	●	●	○	
2006	Cadillac	XLR	Instrument panel	●	●	●	●	●	●	T001

2006	Cadillac	XLR	Keyless entry	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Cadillac	XLR	Lighting systems	●	●	●	●	●	○	
2006	Cadillac	XLR	Roof	●	●	●	●	●	○	
2006	Cadillac	XLR	Seats	●	●	●	●	●	●	T030 T154
2006	Cadillac	XLR	Theft deterrent	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Cadillac	XLR	Wipers/washer systems	●	●	○	●	●	○	
2006	Cadillac	XLR	Seat belts	●	●	●	●	●	●	T023
2006	Cadillac	XLR	SIR	●	●	●	●	●	●	T023
2006	Cadillac	XLR	HVAC systems - automatic	●	●	●	●	●	●	T001
2006	Cadillac	XLR	Variable effort steering	●	●	○	●	○	○	
2006	Cadillac	XLR	Steering wheel and column	●	●	○	●	●	○	
2006	Cadillac	XLR	Tire pressure monitoring	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Cadillac	XLR	Electronic suspension control (ESC)	●	●	○	●	●	○	
2006	Cadillac	XLR	Antilock brake system	●	●	●	●	●	●	T001
2006	Cadillac	XLR	Hydraulic brakes	●	●	○	●	●	○	
2006	Cadillac	XLR	Park brake	●	●	○	●	●	○	
2006	Cadillac	XLR	Engine exhaust	●	●	●	●	●	○	
2006	Cadillac	XLR	Engine controls	●	●	●	●	●	●	T001
2006	Cadillac	XLR	Engine cooling	●	●	●	●	●	●	T001
2006	Cadillac	XLR	Engine electrical	●	●	●	●	●	●	T001
2006	Cadillac	XLR	Shift lock control	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Cadillac	XLR	Automatic transmission	●	●	●	●	●	○	

2006	Cadillac	XLR	Body rear end	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Cadillac	XLR	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Cadillac	XLR	Cruise control	●	●	●	●	●	●	T001
2006	Cadillac	XLR	Doors	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Cadillac	XLR	Entertainment	●	●	●	●	●	●	T024
2006	Cadillac	XLR	Horns	●	●	○	●	●	○	
2006	Cadillac	XLR	Instrument panel	●	●	○	●	●	○	
2006	Cadillac	XLR	Keyless entry	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Cadillac	XLR	Lighting systems	●	●	●	●	●	○	
2006	Cadillac	XLR	Roof	●	●	●	●	●	○	
2006	Cadillac	XLR	Seats	●	●	●	●	●	●	T030 T154
2006	Cadillac	XLR	Theft deterrent	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Cadillac	XLR	Wipers/washer systems	●	●	○	●	●	○	
2006	Cadillac	XLR	Seat belts	●	●	●	●	●	●	T023
2006	Cadillac	XLR	SIR	●	●	●	●	●	●	T023
2006	Chevrolet	Aveo	Powertrain	●	●	●	●	●	●	T015
2006	Chevrolet	Aveo	Supplemental inflatable restraint	●	●	●	●	●	○	
2006	Chevrolet	Aveo	Chassis	●	●	●	●	●	●	T014
2006	Chevrolet	Chevy	Powertrain	●	●	●	●	●	●	T001
2006	Chevrolet	Chevy	Immobilizer	●	●	●	●	○	●	T052 T053
2006	Chevrolet	Cobalt	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	Cobalt	Power steering system	●	●	○	●	○	○	
2006	Chevrolet	Cobalt	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Cobalt	Park brake	●	●	●	○	○	○	
2006	Chevrolet	Cobalt	Engine controls	●	●	●	●	●	●	T001

2006	Chevrolet	Cobalt	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Cobalt	Engine electrical	●	●	●	●	●	●	T023
2006	Chevrolet	Cobalt	Shift lock control	●	●	●	●	●	●	T023
2006	Chevrolet	Cobalt	Automatic transaxle	●	●	●	●	●	○	
2006	Chevrolet	Cobalt	Cellular communication	●	●	●	●	●	●	T155 T093
2006	Chevrolet	Cobalt	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Cobalt	Entertainment	●	●	●	●	●	○	
2006	Chevrolet	Cobalt	Horns	●	●	●	●	●	●	T023
2006	Chevrolet	Cobalt	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Cobalt	Keyless entry	●	●	●	●	●	●	T023
2006	Chevrolet	Cobalt	Lighting systems	●	●	●	●	●	●	T023
2006	Chevrolet	Cobalt	Stationary windows	●	●	●	●	●	●	T023
2006	Chevrolet	Cobalt	Theft deterrent	●	●	●	●	●	●	T023
2006	Chevrolet	Cobalt	Seat belts	●	●	●	●	●	●	T023
2006	Chevrolet	Cobalt	SIR	●	●	●	●	●	●	T023
2006	Chevrolet	Corvette	HVAC systems - automatic	●	●	●	●	●	●	T008 T031
2006	Chevrolet	Corvette	Variable effort steering	●	●	○	●	○	○	
2006	Chevrolet	Corvette	Steering wheel and column	●	●	●	●	●	○	
2006	Chevrolet	Corvette	Tire pressure monitoring	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Chevrolet	Corvette	Electronic suspension control (ESC)	●	●	○	●	●	○	
2006	Chevrolet	Corvette	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Corvette	Hydraulic brakes	●	●	○	●	●	○	
2006	Chevrolet	Corvette	Engine exhaust	●	●	●	●	●	○	
2006	Chevrolet	Corvette	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	Corvette	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Corvette	Engine electrical	●	●	●	●	●	●	T001
2006	Chevrolet	Corvette	Shift lock control	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029

2006	Chevrolet	Corvette	Automatic transmission	●	●	●	●	●	○	
2006	Chevrolet	Corvette	Body rear end	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Chevrolet	Corvette	Cellular communication	●	●	●	●	●	●	T155 T093
2006	Chevrolet	Corvette	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Corvette	Doors	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Chevrolet	Corvette	Entertainment	●	●	●	●	●	●	T024
2006	Chevrolet	Corvette	Horns	●	●	●	●	●	○	
2006	Chevrolet	Corvette	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Corvette	Keyless entry	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Chevrolet	Corvette	Lighting systems	●	●	●	●	●	○	
2006	Chevrolet	Corvette	Navigation systems	●	●	●	●	○	●	T033
2006	Chevrolet	Corvette	Roof	●	●	●	●	●	○	
2006	Chevrolet	Corvette	Seats	●	●	●	●	●	●	T030
2006	Chevrolet	Corvette	Theft deterrent	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2006	Chevrolet	Corvette	Wipers/washer systems	●	●	●	●	●	○	
2006	Chevrolet	Corvette	Seat belts	●	●	●	●	●	●	T023
2006	Chevrolet	Corvette	SIR	●	●	●	●	●	●	T020
2006	Chevrolet	Epica	Powertrain	●	●	●	●	●	●	T001
2006	Chevrolet	Epica	ISU	●	●	○	●	●	○	
2006	Chevrolet	Epica	Supplemental inflatable restraint	●	●	●	●	●	○	
2006	Chevrolet	Epica	Antilock brake system	●	●	●	●	●	●	T014
2006	Chevrolet	Impala	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Steering wheel and column	●	●	●	●	○	○	
2006	Chevrolet	Impala	Tire pressure monitoring	●	●	●	●	●	●	T021 T022

2006	Chevrolet	Impala	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Hydraulic brakes	●	●	●	○	○	○	
2006	Chevrolet	Impala	Park brake	●	●	●	●	○	○	
2006	Chevrolet	Impala	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Engine electrical	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Shift lock control	●	●	●	●	○	○	
2006	Chevrolet	Impala	Automatic transaxle	●	●	●	●	●	○	
2006	Chevrolet	Impala	Body rear end	●	●	●	●	○	○	
2006	Chevrolet	Impala	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Chevrolet	Impala	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Doors	●	●	●	●	○	○	
2006	Chevrolet	Impala	Entertainment	●	●	●	●	●	○	
2006	Chevrolet	Impala	Horns	●	●	●	●	○	○	
2006	Chevrolet	Impala	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Impala	Lighting systems	●	●	●	●	○	○	
2006	Chevrolet	Impala	Instrument panel cluster	●	●	●	○	○	○	
2006	Chevrolet	Impala	Body control module	●	●	●	●	○	○	
2006	Chevrolet	Impala	Seats	●	●	●	●	●	○	
2006	Chevrolet	Impala	Stationary windows	●	●	●	●	●	○	
2006	Chevrolet	Impala	Theft deterrent	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Wipers/washer systems	●	●	●	●	○	○	
2006	Chevrolet	Impala	Seat belts	●	●	●	●	●	●	T005
2006	Chevrolet	Impala	SIR	●	●	●	●	●	●	T005
2006	Chevrolet	Impala	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Steering wheel and column	●	●	●	●	○	○	
2006	Chevrolet	Impala	Tire pressure monitoring	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Impala	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Hydraulic brakes	●	●	●	○	○	○	
2006	Chevrolet	Impala	Park brake	●	●	●	●	○	○	

2006	Chevrolet	Impala	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Engine electrical	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Shift lock control	●	●	●	●	○	○	
2006	Chevrolet	Impala	Automatic transaxle	●	●	●	●	●	○	
2006	Chevrolet	Impala	Body rear end	●	●	●	●	○	○	
2006	Chevrolet	Impala	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Chevrolet	Impala	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Doors	●	●	●	●	○	○	
2006	Chevrolet	Impala	Entertainment	●	●	●	●	●	○	
2006	Chevrolet	Impala	Horns	●	●	●	●	○	○	
2006	Chevrolet	Impala	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Impala	Lighting systems	●	●	●	●	○	○	
2006	Chevrolet	Impala	Instrument panel cluster	●	●	●	○	○	○	
2006	Chevrolet	Impala	Body control module	●	●	●	●	○	○	
2006	Chevrolet	Impala	Seats	●	●	●	●	●	○	
2006	Chevrolet	Impala	Stationary windows	●	●	●	●	●	○	
2006	Chevrolet	Impala	Theft deterrent	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Wipers/washer systems	●	●	●	●	○	○	
2006	Chevrolet	Impala	Seat belts	●	●	●	●	●	●	T005
2006	Chevrolet	Impala	SIR	●	●	●	●	●	●	T005
2006	Chevrolet	Impala	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Steering wheel and column	●	●	●	●	○	○	
2006	Chevrolet	Impala	Tire pressure monitoring	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Impala	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Hydraulic brakes	●	●	●	○	○	○	
2006	Chevrolet	Impala	Park brake	●	●	●	●	○	○	
2006	Chevrolet	Impala	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Engine electrical	●	●	●	●	●	●	T001

2006	Chevrolet	Impala	Shift lock control	●	●	●	●	○	○	
2006	Chevrolet	Impala	Automatic transaxle	●	●	●	●	●	○	
2006	Chevrolet	Impala	Body rear end	●	●	●	●	○	○	
2006	Chevrolet	Impala	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Chevrolet	Impala	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Doors	●	●	●	●	○	○	
2006	Chevrolet	Impala	Entertainment	●	●	●	●	●	○	
2006	Chevrolet	Impala	Horns	●	●	●	●	○	○	
2006	Chevrolet	Impala	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Impala	Lighting systems	●	●	●	●	○	○	
2006	Chevrolet	Impala	Instrument panel cluster	●	●	●	○	○	○	
2006	Chevrolet	Impala	Body control module	●	●	●	●	○	○	
2006	Chevrolet	Impala	Seats	●	●	●	●	●	○	
2006	Chevrolet	Impala	Stationary windows	●	●	●	●	●	○	
2006	Chevrolet	Impala	Theft deterrent	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Wipers/washer systems	●	●	●	●	○	○	
2006	Chevrolet	Impala	Seat belts	●	●	●	●	●	●	T005
2006	Chevrolet	Impala	SIR	●	●	●	●	●	●	T005
2006	Chevrolet	Impala	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Steering wheel and column	●	●	●	●	○	○	
2006	Chevrolet	Impala	Tire pressure monitoring	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Impala	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Hydraulic brakes	●	●	●	○	○	○	
2006	Chevrolet	Impala	Park brake	●	●	●	●	○	○	
2006	Chevrolet	Impala	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Engine electrical	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Shift lock control	●	●	●	●	○	○	
2006	Chevrolet	Impala	Automatic transaxle	●	●	●	●	●	○	
2006	Chevrolet	Impala	Body rear end	●	●	●	●	○	○	

2006	Chevrolet	Impala	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Chevrolet	Impala	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Doors	●	●	●	●	○	○	
2006	Chevrolet	Impala	Entertainment	●	●	●	●	●	○	
2006	Chevrolet	Impala	Horns	●	●	●	●	○	○	
2006	Chevrolet	Impala	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Impala	Lighting systems	●	●	●	●	○	○	
2006	Chevrolet	Impala	Instrument panel cluster	●	●	●	○	○	○	
2006	Chevrolet	Impala	Body control module	●	●	●	●	○	○	
2006	Chevrolet	Impala	Seats	●	●	●	●	●	○	
2006	Chevrolet	Impala	Stationary windows	●	●	●	●	●	○	
2006	Chevrolet	Impala	Theft deterrent	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Wipers/washer systems	●	●	●	●	○	○	
2006	Chevrolet	Impala	Seat belts	●	●	●	●	●	●	T005
2006	Chevrolet	Impala	SIR	●	●	●	●	●	●	T005
2006	Chevrolet	Impala	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Steering wheel and column	●	●	●	●	○	○	
2006	Chevrolet	Impala	Tire pressure monitoring	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Impala	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Hydraulic brakes	●	●	●	○	○	○	
2006	Chevrolet	Impala	Park brake	●	●	●	●	○	○	
2006	Chevrolet	Impala	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Engine electrical	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Shift lock control	●	●	●	●	○	○	
2006	Chevrolet	Impala	Automatic transaxle	●	●	●	●	●	○	
2006	Chevrolet	Impala	Body rear end	●	●	●	●	○	○	
2006	Chevrolet	Impala	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Chevrolet	Impala	Cruise control	●	●	●	●	●	●	T001

2006	Chevrolet	Impala	Doors	●	●	●	●	○	○	
2006	Chevrolet	Impala	Entertainment	●	●	●	●	●	○	
2006	Chevrolet	Impala	Horns	●	●	●	●	○	○	
2006	Chevrolet	Impala	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Impala	Lighting systems	●	●	●	●	○	○	
2006	Chevrolet	Impala	Instrument panel cluster	●	●	●	○	○	○	
2006	Chevrolet	Impala	Body control module	●	●	●	●	○	○	
2006	Chevrolet	Impala	Seats	●	●	●	●	●	○	
2006	Chevrolet	Impala	Stationary windows	●	●	●	●	●	○	
2006	Chevrolet	Impala	Theft deterrent	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Wipers/washer systems	●	●	●	●	○	○	
2006	Chevrolet	Impala	Seat belts	●	●	●	●	●	●	T005
2006	Chevrolet	Impala	SIR	●	●	●	●	●	●	T005
2006	Chevrolet	Impala	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Steering wheel and column	●	●	●	●	○	○	
2006	Chevrolet	Impala	Tire pressure monitoring	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Impala	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Hydraulic brakes	●	●	●	○	○	○	
2006	Chevrolet	Impala	Park brake	●	●	●	●	○	○	
2006	Chevrolet	Impala	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Engine electrical	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Shift lock control	●	●	●	●	○	○	
2006	Chevrolet	Impala	Automatic transaxle	●	●	●	●	●	○	
2006	Chevrolet	Impala	Body rear end	●	●	●	●	○	○	
2006	Chevrolet	Impala	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Chevrolet	Impala	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Doors	●	●	●	●	○	○	
2006	Chevrolet	Impala	Entertainment	●	●	●	●	●	○	
2006	Chevrolet	Impala	Horns	●	●	●	●	○	○	

2006	Chevrolet	Impala	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Impala	Lighting systems	●	●	●	●	○	○	
2006	Chevrolet	Impala	Instrument panel cluster	●	●	●	○	○	○	
2006	Chevrolet	Impala	Body control module	●	●	●	●	○	○	
2006	Chevrolet	Impala	Seats	●	●	●	●	●	○	
2006	Chevrolet	Impala	Stationary windows	●	●	●	●	●	○	
2006	Chevrolet	Impala	Theft deterrent	●	●	●	●	●	●	T001
2006	Chevrolet	Impala	Wipers/washer systems	●	●	●	●	○	○	
2006	Chevrolet	Impala	Seat belts	●	●	●	●	●	●	T005
2006	Chevrolet	Impala	SIR	●	●	●	●	●	●	T005
2006	Chevrolet	Malibu	HVAC systems - automatic	●	●	●	●	●	○	
2006	Chevrolet	Malibu	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	Malibu	Power steering system	●	●	○	●	●	●	T104
2006	Chevrolet	Malibu	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Malibu	Park brake	●	●	●	●	●	●	T023
2006	Chevrolet	Malibu	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	Malibu	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Malibu	Engine electrical	●	●	●	●	●	●	T001
2006	Chevrolet	Malibu	Shift lock control	●	●	●	●	●	●	T023
2006	Chevrolet	Malibu	Automatic transaxle	●	●	●	●	●	●	T023
2006	Chevrolet	Malibu	Body rear end	●	●	●	●	●	●	T023
2006	Chevrolet	Malibu	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Chevrolet	Malibu	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Malibu	Doors	●	●	●	●	●	●	T023
2006	Chevrolet	Malibu	Entertainment	●	●	●	●	●	●	T102 T103 T033
2006	Chevrolet	Malibu	Horns	●	●	●	●	●	●	T023
2006	Chevrolet	Malibu	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Malibu	Keyless entry	●	●	●	●	●	●	T001
2006	Chevrolet	Malibu	Lighting systems	●	●	●	●	●	●	T023
2006	Chevrolet	Malibu	Stationary windows	●	●	●	●	●	●	T023
2006	Chevrolet	Malibu	Theft deterrent	●	●	●	●	●	●	T001

2006	Chevrolet	Malibu	Wipers/washer systems	●	●	●	●	●	●	T023
2006	Chevrolet	Malibu	Adjustable pedals	●	●	●	●	●	●	T023
2006	Chevrolet	Malibu	Seat belts	●	●	●	●	●	●	T023
2006	Chevrolet	Malibu	SIR	●	●	●	●	●	●	T023
2006	Chevrolet	Monte carlo	HVAC systems - automatic	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Tire pressure monitoring	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Monte carlo	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Hydraulic brakes	●	●	●	○	○	○	
2006	Chevrolet	Monte carlo	Park brake	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Engine electrical	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Shift lock control	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Automatic transaxle	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Body rear end	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Chevrolet	Monte carlo	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Doors	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Entertainment	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Horns	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Monte carlo	Lighting systems	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Instrument panel cluster	●	●	●	○	○	○	
2006	Chevrolet	Monte carlo	Body control module	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Seats	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Stationary windows	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Theft deterrent	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Wipers/washer systems	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Seat belts	●	●	●	●	●	●	T005

2006	Chevrolet	Monte carlo	SIR	●	●	●	●	●	●	T005
2006	Chevrolet	Monte carlo	HVAC systems - automatic	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Tire pressure monitoring	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Monte carlo	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Hydraulic brakes	●	●	●	○	○	○	
2006	Chevrolet	Monte carlo	Park brake	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Engine electrical	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Shift lock control	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Automatic transaxle	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Body rear end	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Chevrolet	Monte carlo	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Doors	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Entertainment	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Horns	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Monte carlo	Lighting systems	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Instrument panel cluster	●	●	●	○	○	○	
2006	Chevrolet	Monte carlo	Body control module	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Seats	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Stationary windows	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Theft deterrent	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Wipers/washer systems	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Seat belts	●	●	●	●	●	●	T005
2006	Chevrolet	Monte carlo	SIR	●	●	●	●	●	●	T005
2006	Chevrolet	Monte carlo	HVAC systems - automatic	●	●	●	●	●	●	T001

2006	Chevrolet	Monte carlo	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Tire pressure monitoring	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Monte carlo	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Hydraulic brakes	●	●	●	○	○	○	
2006	Chevrolet	Monte carlo	Park brake	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Engine electrical	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Shift lock control	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Automatic transaxle	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Body rear end	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Chevrolet	Monte carlo	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Doors	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Entertainment	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Horns	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Monte carlo	Lighting systems	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Instrument panel cluster	●	●	●	○	○	○	
2006	Chevrolet	Monte carlo	Body control module	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Seats	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Stationary windows	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Theft deterrent	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Wipers/washer systems	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Seat belts	●	●	●	●	●	●	T005
2006	Chevrolet	Monte carlo	SIR	●	●	●	●	●	●	T005
2006	Chevrolet	Monte carlo	HVAC systems - automatic	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Tire pressure monitoring	●	●	●	●	●	●	T021 T022

2006	Chevrolet	Monte carlo	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Hydraulic brakes	●	●	●	○	○	○	
2006	Chevrolet	Monte carlo	Park brake	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Engine electrical	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Shift lock control	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Automatic transaxle	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Body rear end	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Chevrolet	Monte carlo	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Doors	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Entertainment	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Horns	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Monte carlo	Lighting systems	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Instrument panel cluster	●	●	●	○	○	○	
2006	Chevrolet	Monte carlo	Body control module	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Seats	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Stationary windows	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Theft deterrent	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Wipers/washer systems	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Seat belts	●	●	●	●	●	●	T005
2006	Chevrolet	Monte carlo	SIR	●	●	●	●	●	●	T005
2006	Chevrolet	Monte carlo	HVAC systems - automatic	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Tire pressure monitoring	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Monte carlo	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Hydraulic brakes	●	●	●	○	○	○	
2006	Chevrolet	Monte carlo	Park brake	●	●	●	●	○	○	

2006	Chevrolet	Monte carlo	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Engine electrical	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Shift lock control	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Automatic transaxle	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Body rear end	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Chevrolet	Monte carlo	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Doors	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Entertainment	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Horns	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Chevrolet	Monte carlo	Lighting systems	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Instrument panel cluster	●	●	●	○	○	○	
2006	Chevrolet	Monte carlo	Body control module	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Seats	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Stationary windows	●	●	●	●	●	○	
2006	Chevrolet	Monte carlo	Theft deterrent	●	●	●	●	●	●	T001
2006	Chevrolet	Monte carlo	Wipers/washer systems	●	●	●	●	○	○	
2006	Chevrolet	Monte carlo	Seat belts	●	●	●	●	●	●	T005
2006	Chevrolet	Monte carlo	SIR	●	●	●	●	●	●	T005
2006	Chevrolet	Optra	Powertrain	●	●	●	●	●	●	T015
2006	Chevrolet	Optra	Supplemental inflatable restraint	●	●	●	●	●	○	
2006	Chevrolet	Optra	Electronic brake control module	●	●	●	●	●	●	T014
2006	Chevrolet	Optra - mexico	Powertrain	●	●	●	●	●	●	T015
2006	Chevrolet	Optra - mexico	Supplemental inflatable restraint	●	●	●	●	●	○	
2006	Chevrolet	Optra - mexico	Electronic brake control module	●	●	●	●	●	●	T014
2006	Chevrolet	Vivant	Powertrain	●	●	●	●	●	●	T015

2006	Chevrolet	Vivant	Supplemental inflatable restraint	●	●	○	●	○	○	
2006	Chevrolet	Vivant	Chassis	●	●	●	●	●	●	T014
2006	Chevrolet	Others	Supplemental inflatable restraint	●	●	●	●	●	○	
2006	Chevrolet	Others	Powertrain	●	●	●	●	●	●	T015
2006	Chevrolet	Others	Antilock brake system	●	●	●	●	●	●	T014
2006	Pontiac	G6	HVAC systems - automatic	●	●	●	●	●	○	
2006	Pontiac	G6	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Pontiac	G6	Power steering system	●	●	○	●	●	●	T104
2006	Pontiac	G6	Antilock brake system	●	●	●	●	●	●	T014
2006	Pontiac	G6	Park brake	●	●	●	●	●	●	T023
2006	Pontiac	G6	Engine controls	●	●	●	●	●	●	T001
2006	Pontiac	G6	Engine cooling	●	●	●	●	●	●	T001
2006	Pontiac	G6	Engine electrical	●	●	●	●	●	●	T023
2006	Pontiac	G6	Shift lock control	●	●	●	●	●	●	T023
2006	Pontiac	G6	Automatic transaxle	●	●	●	●	●	●	T023
2006	Pontiac	G6	Body rear end	●	●	●	●	●	●	T023
2006	Pontiac	G6	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Pontiac	G6	Cruise control	●	●	●	●	●	●	T023
2006	Pontiac	G6	Doors	●	●	●	●	●	●	T023
2006	Pontiac	G6	Entertainment	●	●	●	●	●	●	T089 T090 T033
2006	Pontiac	G6	Horns	●	●	●	●	●	●	T023
2006	Pontiac	G6	Instrument panel	●	●	●	●	●	●	T001
2006	Pontiac	G6	Lighting systems	●	●	●	●	●	●	T023
2006	Pontiac	G6	Roof	●	●	●	●	●	○	
2006	Pontiac	G6	Stationary windows	●	●	●	●	●	●	T023
2006	Pontiac	G6	Theft deterrent	●	●	●	●	●	●	T023
2006	Pontiac	G6	Wipers/washer systems	●	●	●	●	●	●	T023
2006	Pontiac	G6	Adjustable pedals	●	●	●	●	●	●	T023
2006	Pontiac	G6	Keyless entry	●	●	●	●	●	●	T001
2006	Pontiac	G6	Seat belts	●	●	●	●	●	●	T023
2006	Pontiac	G6	SIR	●	●	●	●	●	●	T023

2006	Pontiac	GTO	Powertrain	●	●	●	●	●	●	T001
2006	Pontiac	GTO	Supplemental inflatable restraint	●	●	○	○	○	○	
2006	Pontiac	GTO	ABS/TCS	●	●	●	●	●	●	T070
2006	Pontiac	Grand prix	HVAC systems - manual	●	●	●	●	●	●	T007
2006	Pontiac	Grand prix	HVAC systems - automatic	●	●	●	●	●	●	T008
2006	Pontiac	Grand prix	Antilock brake system	●	●	●	●	●	●	T001
2006	Pontiac	Grand prix	Engine controls	●	●	●	●	●	●	T007
2006	Pontiac	Grand prix	Engine cooling	●	●	●	●	●	●	T001
2006	Pontiac	Grand prix	Engine electrical	●	●	●	●	●	●	T007
2006	Pontiac	Grand prix	Shift lock control	●	●	●	●	●	●	T007
2006	Pontiac	Grand prix	Automatic transaxle	●	●	●	●	●	●	T007
2006	Pontiac	Grand prix	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2006	Pontiac	Grand prix	Cruise control	●	●	●	●	●	●	T001
2006	Pontiac	Grand prix	Entertainment	●	●	●	●	●	●	T024
2006	Pontiac	Grand prix	Horns	●	●	●	●	●	●	T007
2006	Pontiac	Grand prix	Instrument panel	●	●	●	●	●	●	T001
2006	Pontiac	Grand prix	Keyless entry	●	●	●	●	●	●	T007
2006	Pontiac	Grand prix	Lighting systems	●	●	●	●	●	●	T007
2006	Pontiac	Grand prix	Stationary windows	●	●	●	●	●	●	T007
2006	Pontiac	Grand prix	Theft deterrent	●	●	●	●	●	●	T007
2006	Pontiac	Grand prix	Wipers/washer systems	●	●	●	●	●	●	T007
2006	Pontiac	Grand prix	Seat belts	●	●	●	●	●	●	T147 T023
2006	Pontiac	Grand prix	SIR	●	●	●	●	●	●	T147 T023
2006	Pontiac	Solstice	HVAC systems - manual	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Antilock brake system	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Park brake	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Engine controls	●	●	●	●	●	●	T001
2006	Pontiac	Solstice	Engine cooling	●	●	●	●	●	●	T001
2006	Pontiac	Solstice	Engine electrical	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Shift lock control	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Automatic transmission	●	●	●	●	●	○	
2006	Pontiac	Solstice	Body rear end	●	●	●	●	●	●	T023

2006	Pontiac	Solstice	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Pontiac	Solstice	Cruise control	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Doors	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Entertainment	●	●	●	●	●	●	T033
2006	Pontiac	Solstice	Horns	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Instrument panel	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Keyless entry	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Lighting systems	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Body control module	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Stationary windows	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Theft deterrent	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Wipers/washer systems	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	Seat belts	●	●	●	●	●	●	T023
2006	Pontiac	Solstice	SIR	●	●	●	●	●	●	T023
2006	Pontiac	Pursuit	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Pontiac	Pursuit	Power steering system	●	●	○	●	○	○	
2006	Pontiac	Pursuit	Antilock brake system	●	●	●	●	●	●	T001
2006	Pontiac	Pursuit	Park brake	●	●	●	○	○	○	
2006	Pontiac	Pursuit	Engine controls	●	●	●	●	●	●	T001
2006	Pontiac	Pursuit	Engine cooling	●	●	●	●	●	●	T001
2006	Pontiac	Pursuit	Engine electrical	●	●	●	●	●	●	T023
2006	Pontiac	Pursuit	Shift lock control	●	●	●	●	●	●	T023
2006	Pontiac	Pursuit	Automatic transaxle	●	●	●	●	●	○	
2006	Pontiac	Pursuit	Cellular communication	●	●	●	●	●	●	T155 T093
2006	Pontiac	Pursuit	Cruise control	●	●	●	●	●	●	T001
2006	Pontiac	Pursuit	Entertainment	●	●	●	●	●	○	
2006	Pontiac	Pursuit	Horns	●	●	●	●	●	●	T023
2006	Pontiac	Pursuit	Instrument panel	●	●	●	●	●	●	T001
2006	Pontiac	Pursuit	Keyless entry	●	●	●	●	●	●	T023
2006	Pontiac	Pursuit	Lighting systems	●	●	●	●	●	●	T023
2006	Pontiac	Pursuit	Stationary windows	●	●	●	●	●	●	T023
2006	Pontiac	Pursuit	Theft deterrent	●	●	●	●	●	●	T023
2006	Pontiac	Pursuit	Seat belts	●	●	●	●	●	●	T023
2006	Pontiac	Pursuit	SIR	●	●	●	●	●	●	T023

2006	Pontiac	Vibe - AWD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Pontiac	Vibe - AWD	Radio	●	●	○	●	●	●	T080
2006	Pontiac	Vibe - AWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2006	Pontiac	Vibe - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Pontiac	Vibe - AWD	Chassis	●	●	○	●	●	●	T105
2006	Pontiac	Vibe - FWD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Pontiac	Vibe - FWD	Radio	●	●	○	●	●	●	T080
2006	Pontiac	Vibe - FWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2006	Pontiac	Vibe - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Pontiac	Vibe - FWD	Chassis	●	●	○	●	●	●	T105
2006	Pontiac	Wave	Powertrain	●	●	●	●	●	●	T001
2006	Pontiac	Wave	Supplemental inflatable restraint	●	●	●	●	●	○	
2006	Pontiac	Wave	Chassis	●	●	●	●	●	●	T014
2006	Pontiac	Others	Antilock brake system	●	●	●	●	●	●	T014
2006	Pontiac	Others	Powertrain	●	●	●	●	●	●	T015
2006	Pontiac	Others	Supplemental inflatable restraint	●	●	○	●	○	○	
2006	Saturn	ION	Powertrain	●	●	●	●	●	●	T001
2006	Saturn	ION	Digital radio receiver	●	●	●	●	○	○	
2006	Saturn	ION	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2006	Saturn	ION	Body control module	●	●	●	●	●	●	T141 T142 T143
2006	Saturn	ION	Radio	●	●	●	●	●	●	T059
2006	Saturn	ION	Instrument panel cluster	●	●	●	●	●	○	
2006	Saturn	ION	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Saturn	ION	Antilock brake system	●	●	○	●	●	●	T014
2006	Buick	Rainier	Powertrain	●	●	●	●	●	●	T001

2006	Buick	Rainier	Disc player and video display	●	●	●	○	○	○	
2006	Buick	Rainier	Digital radio receiver	●	●	●	●	○	●	T024
2006	Buick	Rainier	Radio	●	●	●	●	○	○	
2006	Buick	Rainier	Rear seat audio	●	●	●	●	○	○	
2006	Buick	Rainier	Body control module	●	●	●	●	●	●	T058
2006	Buick	Rainier	Instrument panel cluster	●	●	●	●	●	○	
2006	Buick	Rainier	Driver door module	●	●	●	●	●	○	
2006	Buick	Rainier	Driver seat module	●	●	●	●	●	○	
2006	Buick	Rainier	Heating and air conditioning	●	●	●	●	●	○	
2006	Buick	Rainier	Lift gate module	●	●	●	●	●	○	
2006	Buick	Rainier	Passenger door module	●	●	●	●	●	○	
2006	Buick	Rainier	Passenger presence system	●	●	○	○	○	●	T020
2006	Buick	Rainier	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Buick	Rainier	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	Buick	Rainier	Navigation radio	●	●	●	●	●	●	T033
2006	Buick	Rainier	ABS/TCS/VSES	●	●	●	●	●	●	T001
2006	Buick	Rainier - 2WD	Powertrain	●	●	●	●	●	●	T001
2006	Buick	Rainier - 2WD	Disc player and video display	●	●	●	○	○	○	
2006	Buick	Rainier - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Buick	Rainier - 2WD	Radio	●	●	●	●	○	○	
2006	Buick	Rainier - 2WD	Rear seat audio	●	●	●	●	○	○	
2006	Buick	Rainier - 2WD	Body control module	●	●	●	●	●	●	T058
2006	Buick	Rainier - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2006	Buick	Rainier - 2WD	Driver door module	●	●	●	●	●	○	
2006	Buick	Rainier - 2WD	Driver seat module	●	●	●	●	●	○	
2006	Buick	Rainier - 2WD	Heating and air conditioning	●	●	●	●	●	○	

2006	Buick	Rainier - 2WD	Lift gate module	●	●	●	●	●	○	
2006	Buick	Rainier - 2WD	Passenger door module	●	●	●	●	●	○	
2006	Buick	Rainier - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2006	Buick	Rainier - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Buick	Rainier - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	Buick	Rainier - 2WD	Navigation radio	●	●	●	●	●	●	T033
2006	Buick	Rainier - 2WD	ABS/TCS/VSES	●	●	●	●	●	●	T001
2006	Buick	Rendezvous - AWD	Powertrain	●	●	●	●	●	○	
2006	Buick	Rendezvous - AWD	Radio	●	●	●	●	●	●	T081 T082 T144 T080 T032
2006	Buick	Rendezvous - AWD	Disc player and video display	●	●	●	○	○	○	
2006	Buick	Rendezvous - AWD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Buick	Rendezvous - AWD	Navigation radio	●	●	●	●	●	●	T033
2006	Buick	Rendezvous - AWD	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Buick	Rendezvous - AWD	Passenger presence system	●	●	○	○	○	●	T020
2006	Buick	Rendezvous - AWD	Body control module	●	●	○	●	●	●	T068 T023 T136 T145 T122
2006	Buick	Rendezvous - AWD	Head up display	●	●	○	●	○	○	
2006	Buick	Rendezvous - AWD	Instrument panel cluster	●	●	○	●	●	○	
2006	Buick	Rendezvous - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Buick	Rendezvous - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T023

2006	Buick	Rendezvous - AWD	Memory seat module	●	●	●	●	●	●	T081 T082 T144 T080 T032
2006	Buick	Rendezvous - AWD	Chassis	●	●	●	●	●	●	T014
2006	Buick	Rendezvous - FWD	Powertrain	●	●	●	●	●	○	
2006	Buick	Rendezvous - FWD	Radio	●	●	●	●	●	●	T081 T082 T144 T080 T032
2006	Buick	Rendezvous - FWD	Disc player and video display	●	●	●	○	○	○	
2006	Buick	Rendezvous - FWD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Buick	Rendezvous - FWD	Navigation radio	●	●	●	●	●	●	T033
2006	Buick	Rendezvous - FWD	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Buick	Rendezvous - FWD	Passenger presence system	●	●	○	○	○	●	T020
2006	Buick	Rendezvous - FWD	Body control module	●	●	○	●	●	●	T068 T023 T136 T145 T122
2006	Buick	Rendezvous - FWD	Head up display	●	●	○	●	○	○	
2006	Buick	Rendezvous - FWD	Instrument panel cluster	●	●	○	●	●	○	
2006	Buick	Rendezvous - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Buick	Rendezvous - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2006	Buick	Rendezvous - FWD	Memory seat module	●	●	●	●	●	●	T081 T082 T144 T080 T032
2006	Buick	Rendezvous - FWD	Chassis	●	●	●	●	●	●	T014
2006	Buick	Terraza	HVAC systems - manual	●	●	●	●	●	●	T007
2006	Buick	Terraza	Antilock brake system	●	●	●	●	●	●	T014
2006	Buick	Terraza	Engine controls	●	●	●	●	●	●	T001

2006	Buick	Terraza	Engine cooling	●	●	●	●	●	●	T001
2006	Buick	Terraza	Engine electrical	●	●	●	●	●	●	T007
2006	Buick	Terraza	Shift lock control	●	●	●	●	●	●	T007
2006	Buick	Terraza	Automatic transaxle	●	●	●	●	●	●	T007
2006	Buick	Terraza	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2006	Buick	Terraza	Cruise control	●	●	●	●	●	●	T001
2006	Buick	Terraza	Doors	●	●	●	●	●	○	
2006	Buick	Terraza	Entertainment	●	●	●	●	●	●	T024
2006	Buick	Terraza	Horns	●	●	●	●	●	●	T007
2006	Buick	Terraza	Instrument panel	●	●	●	●	●	●	T007
2006	Buick	Terraza	Lighting systems	●	●	●	●	●	●	T007
2006	Buick	Terraza	Navigation systems	●	●	●	●	●	●	T033
2006	Buick	Terraza	Seats	●	●	●	●	●	○	
2006	Buick	Terraza	Stationary windows	●	●	●	●	●	○	
2006	Buick	Terraza	Theft deterrent	●	●	●	●	●	●	T007
2006	Buick	Terraza	Wipers/washer systems	●	●	●	●	●	●	T007
2006	Buick	Terraza	Keyless entry	●	●	●	●	●	●	T007
2006	Buick	Terraza	Seat belts	●	●	●	●	●	●	T147 T023
2006	Buick	Terraza	SIR	●	●	●	●	●	●	T147 T023
2006	Buick	Terraza - 4WD	HVAC systems - manual	●	●	●	●	●	●	T007
2006	Buick	Terraza - 4WD	Antilock brake system	●	●	●	●	●	●	T014
2006	Buick	Terraza - 4WD	Engine controls	●	●	○	●	●	○	
2006	Buick	Terraza - 4WD	Engine cooling	●	●	○	●	●	○	
2006	Buick	Terraza - 4WD	Engine electrical	●	●	●	●	●	●	T007
2006	Buick	Terraza - 4WD	Shift lock control	●	●	●	●	●	●	T007
2006	Buick	Terraza - 4WD	Automatic transaxle	●	●	●	●	●	●	T007
2006	Buick	Terraza - 4WD	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2006	Buick	Terraza - 4WD	Cruise control	●	●	●	●	●	●	T001
2006	Buick	Terraza - 4WD	Doors	●	●	●	●	●	○	
2006	Buick	Terraza - 4WD	Entertainment	●	●	●	●	●	●	T024
2006	Buick	Terraza - 4WD	Horns	●	●	●	●	●	●	T007
2006	Buick	Terraza - 4WD	Instrument panel	●	●	●	●	●	●	T007
2006	Buick	Terraza - 4WD	Keyless entry	●	●	●	●	●	●	T007
2006	Buick	Terraza - 4WD	Lighting systems	●	●	●	●	●	●	T007
2006	Buick	Terraza - 4WD	Navigation systems	●	●	●	●	●	●	T033

2006	Buick	Terraza - 4WD	Seats	●	●	●	●	●	○	
2006	Buick	Terraza - 4WD	Stationary windows	●	●	●	●	●	○	
2006	Buick	Terraza - 4WD	Theft deterrent	●	●	●	●	●	●	T007
2006	Buick	Terraza - 4WD	Wipers/washer systems	●	●	●	●	●	●	T007
2006	Buick	Terraza - 4WD	Seat belts	●	●	●	●	●	●	T147 T023
2006	Buick	Terraza - 4WD	SIR	●	●	●	●	●	●	T147 T023
2006	Buick	Terraza ext.	HVAC systems - manual	●	●	●	●	●	●	T007
2006	Buick	Terraza ext.	Antilock brake system	●	●	●	●	●	●	T014
2006	Buick	Terraza ext.	Engine controls	●	●	○	●	●	○	
2006	Buick	Terraza ext.	Engine cooling	●	●	○	●	●	○	
2006	Buick	Terraza ext.	Engine electrical	●	●	●	●	●	●	T007
2006	Buick	Terraza ext.	Shift lock control	●	●	●	●	●	●	T007
2006	Buick	Terraza ext.	Automatic transaxle	●	●	●	●	●	●	T007
2006	Buick	Terraza ext.	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2006	Buick	Terraza ext.	Cruise control	●	●	●	●	●	●	T001
2006	Buick	Terraza ext.	Doors	●	●	●	●	●	○	
2006	Buick	Terraza ext.	Entertainment	●	●	●	●	●	●	T024
2006	Buick	Terraza ext.	Horns	●	●	●	●	●	●	T007
2006	Buick	Terraza ext.	Instrument panel	●	●	●	●	●	●	T007
2006	Buick	Terraza ext.	Keyless entry	●	●	●	●	●	●	T007
2006	Buick	Terraza ext.	Lighting systems	●	●	●	●	●	●	T007
2006	Buick	Terraza ext.	Navigation systems	●	●	●	●	●	●	T033
2006	Buick	Terraza ext.	Seats	●	●	●	●	●	○	
2006	Buick	Terraza ext.	Stationary windows	●	●	●	●	●	○	
2006	Buick	Terraza ext.	Theft deterrent	●	●	●	●	●	●	T007
2006	Buick	Terraza ext.	Wipers/washer systems	●	●	●	●	●	●	T007
2006	Buick	Terraza ext.	Seat belts	●	●	●	●	●	●	T147 T023
2006	Buick	Terraza ext.	SIR	●	●	●	●	●	●	T147 T023
2006	Cadillac	Escalade - 2WD	Powertrain	●	●	●	●	●	○	
2006	Cadillac	Escalade - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	Cadillac	Escalade - 2WD	CD changer	●	●	●	○	○	○	
2006	Cadillac	Escalade - 2WD	Chime	●	●	●	●	●	○	
2006	Cadillac	Escalade - 2WD	Disc player and video display	●	●	●	○	○	○	
2006	Cadillac	Escalade - 2WD	Digital radio receiver	●	●	●	●	○	●	T024

2006	Cadillac	Escalade - 2WD	Radio	●	●	●	●	○	○	
2006	Cadillac	Escalade - 2WD	Rear seat audio	●	●	●	●	○	○	
2006	Cadillac	Escalade - 2WD	Driver door module	●	●	●	●	●	○	
2006	Cadillac	Escalade - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2006	Cadillac	Escalade - 2WD	Passenger door module	●	●	●	●	●	○	
2006	Cadillac	Escalade - 2WD	Rear HVAC	●	●	●	●	○	○	
2006	Cadillac	Escalade - 2WD	Generator battery control module	●	●	●	●	●	○	
2006	Cadillac	Escalade - 2WD	Driver seat module	●	●	●	●	●	○	
2006	Cadillac	Escalade - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2006	Cadillac	Escalade - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2006	Cadillac	Escalade - 2WD	Body control module	●	●	●	●	●	○	
2006	Cadillac	Escalade - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	Cadillac	Escalade - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2006	Cadillac	Escalade - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Cadillac	Escalade - 2WD	Navigation radio	●	●	●	●	●	●	T033
2006	Cadillac	Escalade - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	Cadillac	Escalade - 2WD	ABS	●	●	●	●	●	○	
2006	Cadillac	Escalade - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	Cadillac	Escalade - 2WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	Cadillac	Escalade - AWD	Powertrain	●	●	●	●	●	○	
2006	Cadillac	Escalade - AWD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	Cadillac	Escalade - AWD	CD changer	●	●	●	○	○	○	
2006	Cadillac	Escalade - AWD	Chime	●	●	●	●	●	○	
2006	Cadillac	Escalade - AWD	Disc player and video display	●	●	●	○	○	○	
2006	Cadillac	Escalade - AWD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Cadillac	Escalade - AWD	Radio	●	●	●	●	○	○	

2006	Cadillac	Escalade - AWD	Rear seat audio	●	●	●	●	○	○	
2006	Cadillac	Escalade - AWD	Driver door module	●	●	●	●	●	○	
2006	Cadillac	Escalade - AWD	Heating and air conditioning	●	●	●	●	●	○	
2006	Cadillac	Escalade - AWD	Passenger door module	●	●	●	●	●	○	
2006	Cadillac	Escalade - AWD	Rear HVAC	●	●	●	●	○	○	
2006	Cadillac	Escalade - AWD	Generator battery control module	●	●	●	●	●	○	
2006	Cadillac	Escalade - AWD	Driver seat module	●	●	●	●	●	○	
2006	Cadillac	Escalade - AWD	Rear aux. climate module	●	●	●	●	●	○	
2006	Cadillac	Escalade - AWD	Instrument panel cluster	●	●	●	●	●	○	
2006	Cadillac	Escalade - AWD	Body control module	●	●	●	●	●	○	
2006	Cadillac	Escalade - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	Cadillac	Escalade - AWD	Passenger presence system	●	●	○	○	○	●	T020
2006	Cadillac	Escalade - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Cadillac	Escalade - AWD	Navigation radio	●	●	●	●	●	●	T033
2006	Cadillac	Escalade - AWD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	Cadillac	Escalade - AWD	ABS	●	●	●	●	●	○	
2006	Cadillac	Escalade - AWD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	Cadillac	Escalade - AWD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	Cadillac	Escalade ESV	Powertrain	●	●	●	●	●	○	
2006	Cadillac	Escalade ESV	Amplifier (bose)	●	●	●	●	●	●	T139
2006	Cadillac	Escalade ESV	CD changer	●	●	●	○	○	○	
2006	Cadillac	Escalade ESV	Chime	●	●	●	●	●	○	
2006	Cadillac	Escalade ESV	Disc player and video display	●	●	●	○	○	○	
2006	Cadillac	Escalade ESV	Digital radio receiver	●	●	●	●	○	●	T024
2006	Cadillac	Escalade ESV	Radio	●	●	●	●	○	○	
2006	Cadillac	Escalade ESV	Rear seat audio	●	●	●	●	○	○	

2006	Cadillac	Escalade ESV	Driver door module	●	●	●	●	●	○	
2006	Cadillac	Escalade ESV	Heating and air conditioning	●	●	●	●	●	○	
2006	Cadillac	Escalade ESV	Passenger door module	●	●	●	●	●	○	
2006	Cadillac	Escalade ESV	Rear HVAC	●	●	●	●	○	○	
2006	Cadillac	Escalade ESV	Generator battery control module	●	●	●	●	●	○	
2006	Cadillac	Escalade ESV	Driver seat module	●	●	●	●	●	○	
2006	Cadillac	Escalade ESV	Rear aux. climate module	●	●	●	●	●	○	
2006	Cadillac	Escalade ESV	Instrument panel cluster	●	●	●	●	●	○	
2006	Cadillac	Escalade ESV	Body control module	●	●	●	●	●	○	
2006	Cadillac	Escalade ESV	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	Cadillac	Escalade ESV	Passenger presence system	●	●	○	○	○	●	T020
2006	Cadillac	Escalade ESV	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Cadillac	Escalade ESV	Navigation radio	●	●	●	●	●	●	T033
2006	Cadillac	Escalade ESV	Traction assist (if equipped)	●	●	○	●	●	○	
2006	Cadillac	Escalade ESV	ABS	●	●	●	●	●	○	
2006	Cadillac	Escalade ESV	ESC (if equipped)	●	●	●	●	●	●	T156
2006	Cadillac	Escalade ESV	Tire pressure monitor	●	●	●	●	●	●	T022
2006	Cadillac	Escalade EXT	Powertrain	●	●	●	●	●	○	
2006	Cadillac	Escalade EXT	Amplifier (bose)	●	●	●	●	●	●	T139
2006	Cadillac	Escalade EXT	CD changer	●	●	●	○	○	○	
2006	Cadillac	Escalade EXT	Chime	●	●	●	●	●	○	
2006	Cadillac	Escalade EXT	Disc player and video display	●	●	●	○	○	○	
2006	Cadillac	Escalade EXT	Digital radio receiver	●	●	●	●	○	●	T024
2006	Cadillac	Escalade EXT	Radio	●	●	●	●	○	○	
2006	Cadillac	Escalade EXT	Rear seat audio	●	●	●	●	○	○	
2006	Cadillac	Escalade EXT	Driver door module	●	●	●	●	●	○	

2006	Cadillac	Escalade EXT	Heating and air conditioning	●	●	●	●	●	○	
2006	Cadillac	Escalade EXT	Passenger door module	●	●	●	●	●	○	
2006	Cadillac	Escalade EXT	Rear HVAC	●	●	●	●	○	○	
2006	Cadillac	Escalade EXT	Generator battery control module	●	●	●	●	●	○	
2006	Cadillac	Escalade EXT	Driver seat module	●	●	●	●	●	○	
2006	Cadillac	Escalade EXT	Rear aux. climate module	●	●	●	●	●	○	
2006	Cadillac	Escalade EXT	Instrument panel cluster	●	●	●	●	●	○	
2006	Cadillac	Escalade EXT	Body control module	●	●	●	●	●	○	
2006	Cadillac	Escalade EXT	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	Cadillac	Escalade EXT	Passenger presence system	●	●	○	○	○	●	T020
2006	Cadillac	Escalade EXT	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Cadillac	Escalade EXT	Navigation radio	●	●	●	●	●	●	T033
2006	Cadillac	Escalade EXT	Traction assist (if equipped)	●	●	○	●	●	○	
2006	Cadillac	Escalade EXT	ABS	●	●	●	●	●	○	
2006	Cadillac	Escalade EXT	ESC (if equipped)	●	●	●	●	●	●	T156
2006	Cadillac	Escalade EXT	Tire pressure monitor	●	●	●	●	●	●	T022
2006	Cadillac	SRX	Powertrain	●	●	●	●	●	●	T001
2006	Cadillac	SRX	Digital radio receiver	●	●	●	●	○	●	T024
2006	Cadillac	SRX	Amplifier (bose)	●	●	●	●	●	○	
2006	Cadillac	SRX	Amplifier (delco)	●	●	●	●	●	○	
2006	Cadillac	SRX	CD changer	○	○	●	○	○	○	
2006	Cadillac	SRX	Disc player and video display	●	●	●	○	○	○	
2006	Cadillac	SRX	Radio	●	●	●	●	○	●	T157 T158 T159 T094 T095 T160 T161 T162 T163 T116 T033 T033

2006	Cadillac	SRX	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2006	Cadillac	SRX	Remote function actuation	●	●	●	●	●	●	T164
2006	Cadillac	SRX	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Cadillac	SRX	Dash integration module	●	●	●	●	●	●	T112 T113
2006	Cadillac	SRX	Driver door module	●	●	●	●	●	●	T117 T117 T117 T117
2006	Cadillac	SRX	Driver door switch	●	●	●	●	○	○	
2006	Cadillac	SRX	Left rear door module	●	●	●	●	●	○	
2006	Cadillac	SRX	Passenger door module	●	●	●	●	●	●	T116
2006	Cadillac	SRX	Right rear door module	●	●	●	●	●	○	
2006	Cadillac	SRX	Climate control panel	●	●	●	●	●	●	T122 T123 T124 T126 T127 T118 T128 T119 T129 T120 T130 T131 T132 T133 T134 T135 T165 T136
2006	Cadillac	SRX	Personalization	●	●	●	●	●	○	
2006	Cadillac	SRX	Memory seat module	●	●	●	●	●	○	
2006	Cadillac	SRX	Rear seat module	●	●	●	●	●	○	
2006	Cadillac	SRX	Instrument panel cluster	●	●	●	●	●	○	
2006	Cadillac	SRX	Liftgate module	●	●	●	●	●	○	
2006	Cadillac	SRX	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Cadillac	SRX	Navigation radio	●	●	●	●	●	●	T166
2006	Cadillac	SRX	Tire pressure monitor	●	●	○	●	●	●	T137
2006	Cadillac	SRX	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2006	Cadillac	SRX	Electronic suspension control	●	●	●	●	●	○	
2006	Cadillac	Hearse	HVAC systems - automatic	●	●	●	●	●	●	T001
2006	Cadillac	Hearse	Steering	●	●	●	●	○	○	

2006	Cadillac	Hearse	Tire pressure monitoring	●	●	●	●	●	●	T021 T022
2006	Cadillac	Hearse	Air suspension	●	●	●	●	●	○	
2006	Cadillac	Hearse	Antilock brake system	●	●	●	●	●	●	T014
2006	Cadillac	Hearse	Hydraulic brakes	●	●	●	○	○	○	
2006	Cadillac	Hearse	Park brake	●	●	●	●	○	○	
2006	Cadillac	Hearse	Engine controls	●	●	●	●	●	●	T001
2006	Cadillac	Hearse	Engine cooling	●	●	●	●	●	●	T001
2006	Cadillac	Hearse	Engine electrical	●	●	●	●	●	●	T001
2006	Cadillac	Hearse	Shift lock control	●	●	●	●	○	○	
2006	Cadillac	Hearse	Automatic transaxle	●	●	●	●	●	○	
2006	Cadillac	Hearse	Body rear end	●	●	●	●	○	○	
2006	Cadillac	Hearse	Cellular communication	●	●	●	●	●	●	T002 T099 T003 T093
2006	Cadillac	Hearse	Cruise control	●	●	●	●	●	●	T001
2006	Cadillac	Hearse	Doors	●	●	●	●	●	○	
2006	Cadillac	Hearse	Entertainment	●	●	●	●	●	○	
2006	Cadillac	Hearse	Horns	●	●	●	●	○	○	
2006	Cadillac	Hearse	Instrument panel	●	●	●	●	●	●	T001
2006	Cadillac	Hearse	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Cadillac	Hearse	Lighting systems	●	●	●	●	○	○	
2006	Cadillac	Hearse	Body control module	●	●	●	●	○	○	
2006	Cadillac	Hearse	Seats	●	●	●	●	●	○	
2006	Cadillac	Hearse	Stationary windows	●	●	●	●	○	○	
2006	Cadillac	Hearse	Theft deterrent	●	●	●	●	●	●	T001
2006	Cadillac	Hearse	Wipers/washer systems	●	●	●	●	○	○	
2006	Cadillac	Hearse	Seat belts	●	●	●	●	●	●	T005
2006	Cadillac	Hearse	SIR	●	●	●	●	●	●	T005
2006	Cadillac	Limousine	HVAC systems - automatic	●	●	●	●	●	●	T001
2006	Cadillac	Limousine	Steering	●	●	●	●	○	○	
2006	Cadillac	Limousine	Tire pressure monitoring	●	●	●	●	●	●	T021 T022
2006	Cadillac	Limousine	Air suspension	●	●	●	●	●	○	
2006	Cadillac	Limousine	Antilock brake system	●	●	●	●	●	●	T014
2006	Cadillac	Limousine	Hydraulic brakes	●	●	●	○	○	○	

2006	Cadillac	Limousine	Park brake	●	●	●	●	○	○	
2006	Cadillac	Limousine	Engine controls	●	●	●	●	●	●	T001
2006	Cadillac	Limousine	Engine cooling	●	●	●	●	●	●	T001
2006	Cadillac	Limousine	Engine electrical	●	●	●	●	●	●	T001
2006	Cadillac	Limousine	Shift lock control	●	●	●	●	○	○	
2006	Cadillac	Limousine	Automatic transaxle	●	●	●	●	●	○	
2006	Cadillac	Limousine	Body rear end	●	●	●	●	○	○	
2006	Cadillac	Limousine	Cellular communication	●	●	●	●	●	●	T002 T099 T003 T093
2006	Cadillac	Limousine	Cruise control	●	●	●	●	●	●	T001
2006	Cadillac	Limousine	Doors	●	●	●	●	●	○	
2006	Cadillac	Limousine	Entertainment	●	●	●	●	●	○	
2006	Cadillac	Limousine	Horns	●	●	●	●	○	○	
2006	Cadillac	Limousine	Instrument panel	●	●	●	●	●	●	T001
2006	Cadillac	Limousine	Keyless entry	●	●	●	●	●	●	T021 T022
2006	Cadillac	Limousine	Lighting systems	●	●	●	●	○	○	
2006	Cadillac	Limousine	Body control module	●	●	●	●	○	○	
2006	Cadillac	Limousine	Seats	●	●	●	●	●	○	
2006	Cadillac	Limousine	Stationary windows	●	●	●	●	○	○	
2006	Cadillac	Limousine	Theft deterrent	●	●	●	●	●	●	T001
2006	Cadillac	Limousine	Wipers/washer systems	●	●	●	●	○	○	
2006	Cadillac	Limousine	Seat belts	●	●	●	●	●	●	T005
2006	Cadillac	Limousine	SIR	●	●	●	●	●	●	T005
2006	Chevrolet	Avalanche - 2WD	Powertrain	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	Chevrolet	Avalanche - 2WD	CD changer	●	●	●	○	○	○	
2006	Chevrolet	Avalanche - 2WD	Chime	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 2WD	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Avalanche - 2WD	Radio	●	●	●	●	○	○	
2006	Chevrolet	Avalanche - 2WD	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	Avalanche - 2WD	Driver door module	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 2WD	Passenger door module	●	●	●	●	●	○	

2006	Chevrolet	Avalanche - 2WD	Rear HVAC	●	●	●	●	○	○	
2006	Chevrolet	Avalanche - 2WD	Generator battery control module	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 2WD	Driver seat module	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	Chevrolet	Avalanche - 2WD	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Avalanche - 2WD	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	Avalanche - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	Chevrolet	Avalanche - 2WD	ABS	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	Chevrolet	Avalanche - 2WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	Chevrolet	Avalanche - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	Chevrolet	Avalanche - 4WD	Powertrain	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	Chevrolet	Avalanche - 4WD	CD changer	●	●	●	○	○	○	
2006	Chevrolet	Avalanche - 4WD	Chime	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 4WD	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Avalanche - 4WD	Radio	●	●	●	●	○	○	
2006	Chevrolet	Avalanche - 4WD	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	Avalanche - 4WD	Driver door module	●	●	●	●	●	○	

2006	Chevrolet	Avalanche - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 4WD	Passenger door module	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 4WD	Rear HVAC	●	●	●	●	○	○	
2006	Chevrolet	Avalanche - 4WD	Generator battery control module	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 4WD	Driver seat module	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	Chevrolet	Avalanche - 4WD	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Avalanche - 4WD	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	Avalanche - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	Chevrolet	Avalanche - 4WD	ABS	●	●	●	●	●	○	
2006	Chevrolet	Avalanche - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	Chevrolet	Avalanche - 4WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	Chevrolet	Avalanche - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	Chevrolet	Colorado pickup - 2WD	Powertrain	●	●	●	●	●	○	
2006	Chevrolet	Colorado pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Colorado pickup - 2WD	Radio	●	●	●	●	○	○	
2006	Chevrolet	Colorado pickup - 2WD	Passenger presence system	●	●	○	○	○	●	T020

2006	Chevrolet	Colorado pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Colorado pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Colorado pickup - 2WD	Body control module	●	●	●	●	●	●	T058
2006	Chevrolet	Colorado pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2006	Chevrolet	Colorado pickup - 2WD	ABS	●	●	●	●	●	●	T024
2006	Chevrolet	Colorado pickup - 2WD	Powertrain	●	●	●	●	●	○	
2006	Chevrolet	Colorado pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Colorado pickup - 2WD	Radio	●	●	●	●	○	○	
2006	Chevrolet	Colorado pickup - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Colorado pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Colorado pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Colorado pickup - 2WD	Body control module	●	●	●	●	●	●	T058
2006	Chevrolet	Colorado pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2006	Chevrolet	Colorado pickup - 2WD	ABS	●	●	●	●	●	●	T024
2006	Chevrolet	Colorado pickup - 4WD	Powertrain	●	●	●	●	●	○	
2006	Chevrolet	Colorado pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Colorado pickup - 4WD	Radio	●	●	●	●	○	○	

2006	Chevrolet	Colorado pickup - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Colorado pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Colorado pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Colorado pickup - 4WD	Body control module	●	●	●	●	●	●	T058
2006	Chevrolet	Colorado pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2006	Chevrolet	Colorado pickup - 4WD	ABS	●	●	●	●	●	●	T024
2006	Chevrolet	Colorado pickup - 4WD	Powertrain	●	●	●	●	●	○	
2006	Chevrolet	Colorado pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Colorado pickup - 4WD	Radio	●	●	●	●	○	○	
2006	Chevrolet	Colorado pickup - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Colorado pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Colorado pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Colorado pickup - 4WD	Body control module	●	●	●	●	●	●	T058
2006	Chevrolet	Colorado pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2006	Chevrolet	Colorado pickup - 4WD	ABS	●	●	●	●	●	●	T024
2006	Chevrolet	Equinox	Powertrain	●	●	●	●	●	●	T001
2006	Chevrolet	Equinox	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Equinox	Instrument panel cluster	○	○	●	○	●	○	

2006	Chevrolet	Equinox	Radio	●	●	●	●	●	●	T081 T086 T087 T080 T060 T033
2006	Chevrolet	Equinox	Body control module	●	●	●	●	●	●	T141 T148 T142 T143
2006	Chevrolet	Equinox	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T023
2006	Chevrolet	Equinox	Vehicle comm. interface module	●	●	●	●	●	●	T155 T093
2006	Chevrolet	Equinox	Electric power steering	●	●	○	●	●	○	
2006	Chevrolet	Equinox	Antilock brake system	●	●	●	●	●	●	T014
2006	Chevrolet	Express	Powertrain	●	●	●	●	●	●	T146
2006	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	○	
2006	Chevrolet	Express	Radio	●	●	●	●	○	○	
2006	Chevrolet	Express	Passenger presence system	●	●	○	○	○	○	
2006	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2006	Chevrolet	Express	Remote function actuation	●	●	●	●	●	○	
2006	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Express	Body control module	●	●	●	●	●	○	
2006	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Express	ABS	●	●	●	●	●	○	
2006	Chevrolet	Express	Powertrain	●	●	●	●	●	●	T146
2006	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	○	
2006	Chevrolet	Express	Radio	●	●	●	●	○	○	
2006	Chevrolet	Express	Passenger presence system	●	●	○	○	○	○	
2006	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T039

2006	Chevrolet	Express	Remote function actuation	●	●	●	●	●	○	
2006	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Express	Body control module	●	●	●	●	●	○	
2006	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Express	ABS	●	●	●	●	●	○	
2006	Chevrolet	Express	Powertrain	●	●	●	●	●	○	
2006	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	○	
2006	Chevrolet	Express	Radio	●	●	●	●	○	○	
2006	Chevrolet	Express	Passenger presence system	●	●	○	○	○	○	
2006	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2006	Chevrolet	Express	Remote function actuation	●	●	●	●	●	○	
2006	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Express	Body control module	●	●	●	●	●	○	
2006	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Express	ABS	●	●	●	●	●	○	
2006	Chevrolet	Express	Powertrain	●	●	●	●	●	○	
2006	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	○	
2006	Chevrolet	Express	Radio	●	●	●	●	○	○	
2006	Chevrolet	Express	Passenger presence system	●	●	○	○	○	○	
2006	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2006	Chevrolet	Express	Remote function actuation	●	●	●	●	●	○	

2006	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Express	Body control module	●	●	●	●	●	○	
2006	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Express	ABS	●	●	●	●	●	○	
2006	Chevrolet	HHR	HVAC systems - manual	●	●	●	●	●	●	T001
2006	Chevrolet	HHR	Power steering system	●	●	○	●	○	○	
2006	Chevrolet	HHR	Antilock brake system	●	●	●	●	●	●	T001
2006	Chevrolet	HHR	Park brake	●	●	●	●	●	●	T023
2006	Chevrolet	HHR	Engine controls	●	●	●	●	●	●	T001
2006	Chevrolet	HHR	Engine cooling	●	●	●	●	●	●	T001
2006	Chevrolet	HHR	Engine electrical	●	●	●	●	●	●	T001
2006	Chevrolet	HHR	Shift lock control	●	●	●	●	●	●	T023
2006	Chevrolet	HHR	Automatic transaxle	●	●	●	●	●	○	
2006	Chevrolet	HHR	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T003 T093
2006	Chevrolet	HHR	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	HHR	Entertainment	●	●	●	●	●	●	T036
2006	Chevrolet	HHR	Horns	●	●	●	●	●	●	T023
2006	Chevrolet	HHR	Instrument panel	●	●	●	●	●	●	T001
2006	Chevrolet	HHR	Keyless entry	●	●	●	●	●	●	T023
2006	Chevrolet	HHR	Lighting systems	●	●	●	●	●	●	T023
2006	Chevrolet	HHR	Theft deterrent	●	●	●	●	●	●	T023
2006	Chevrolet	HHR	Wipers/washer systems	●	●	●	●	●	●	T023
2006	Chevrolet	HHR	Seat belts	●	●	●	●	●	●	T023
2006	Chevrolet	HHR	SIR	●	●	●	●	●	●	T023
2006	Chevrolet	K silverado - 4WD	Powertrain	●	●	●	●	●	●	T146
2006	Chevrolet	K silverado - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	Chevrolet	K silverado - 4WD	CD changer	●	●	●	○	○	○	
2006	Chevrolet	K silverado - 4WD	Chime	●	●	●	●	●	○	

2006	Chevrolet	K silverado - 4WD	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	K silverado - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	Chevrolet	K silverado - 4WD	ABS	●	●	●	●	●	○	
2006	Chevrolet	K silverado - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	Chevrolet	K silverado - 4WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	Chevrolet	K silverado - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	Chevrolet	K silverado - 4WD (CNG)	Powertrain	●	●	●	●	●	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Amplifier (bose)	●	●	●	●	●	●	T139
2006	Chevrolet	K silverado - 4WD (CNG)	CD changer	●	●	●	○	○	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Chime	●	●	●	●	●	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	K silverado - 4WD (CNG)	Radio	●	●	●	●	○	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Driver door module	●	●	●	●	●	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Passenger door module	●	●	●	●	●	○	

2006	Chevrolet	K silverado - 4WD (CNG)	Rear HVAC	●	●	●	●	○	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Generator battery control module	●	●	●	●	●	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Driver seat module	●	●	●	●	●	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Rear aux. climate module	●	●	●	●	●	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Body control module	●	●	●	●	●	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	Chevrolet	K silverado - 4WD (CNG)	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Chevrolet	K silverado - 4WD (CNG)	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	K silverado - 4WD (CNG)	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	K silverado - 4WD (CNG)	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	K silverado - 4WD (CNG)	Traction assist (if equipped)	●	●	○	●	●	○	
2006	Chevrolet	K silverado - 4WD (CNG)	ABS	●	●	●	●	●	○	
2006	Chevrolet	K silverado - 4WD (CNG)	ESC (if equipped)	●	●	●	●	●	●	T156
2006	Chevrolet	K silverado - 4WD (CNG)	Tire pressure monitor	●	●	●	●	●	●	T022
2006	Chevrolet	K silverado - 4WD (CNG)	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	Chevrolet	SSR	Powertrain	●	●	●	●	●	●	T001
2006	Chevrolet	SSR	Radio	●	●	●	●	○	○	
2006	Chevrolet	SSR	Amplifier (bose)	●	●	●	●	●	○	

2006	Chevrolet	SSR	Driver seat module	●	●	●	●	●	○	
2006	Chevrolet	SSR	Roof and door module	●	●	●	●	●	○	
2006	Chevrolet	SSR	Supplemental inflatable restraint	●	●	●	●	●	○	
2006	Chevrolet	SSR	Remote function actuation	●	●	●	●	●	○	
2006	Chevrolet	SSR	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	SSR	Body control module	●	●	●	●	●	○	
2006	Chevrolet	SSR	Traction assist (if equipped)	●	●	○	●	●	○	
2006	Chevrolet	SSR	4WAL 3 sensor	●	●	○	●	●	○	
2006	Chevrolet	Suburban - 2WD	Powertrain	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	Chevrolet	Suburban - 2WD	CD changer	●	●	●	○	○	○	
2006	Chevrolet	Suburban - 2WD	Chime	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 2WD	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Suburban - 2WD	Radio	●	●	●	●	○	○	
2006	Chevrolet	Suburban - 2WD	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	Suburban - 2WD	Driver door module	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 2WD	Passenger door module	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 2WD	Rear HVAC	●	●	●	●	○	○	
2006	Chevrolet	Suburban - 2WD	Generator battery control module	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 2WD	Driver seat module	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	○	

2006	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	Chevrolet	Suburban - 2WD	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Suburban - 2WD	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	Suburban - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	Chevrolet	Suburban - 2WD	ABS	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	Chevrolet	Suburban - 2WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	Chevrolet	Suburban - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	Chevrolet	Suburban - 4WD	Powertrain	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	Chevrolet	Suburban - 4WD	CD changer	●	●	●	○	○	○	
2006	Chevrolet	Suburban - 4WD	Chime	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 4WD	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Suburban - 4WD	Radio	●	●	●	●	○	○	
2006	Chevrolet	Suburban - 4WD	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	Suburban - 4WD	Driver door module	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 4WD	Passenger door module	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 4WD	Rear HVAC	●	●	●	●	○	○	
2006	Chevrolet	Suburban - 4WD	Generator battery control module	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 4WD	Driver seat module	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 4WD	Rear aux. climate module	●	●	●	●	●	○	

2006	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	Chevrolet	Suburban - 4WD	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Suburban - 4WD	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	Suburban - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	Chevrolet	Suburban - 4WD	ABS	●	●	●	●	●	○	
2006	Chevrolet	Suburban - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	Chevrolet	Suburban - 4WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	Chevrolet	Suburban - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	Chevrolet	Tahoe - 2WD	Powertrain	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	Chevrolet	Tahoe - 2WD	CD changer	●	●	●	○	○	○	
2006	Chevrolet	Tahoe - 2WD	Chime	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 2WD	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	Tahoe - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Tahoe - 2WD	Radio	●	●	●	●	○	○	
2006	Chevrolet	Tahoe - 2WD	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	Tahoe - 2WD	Driver door module	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 2WD	Passenger door module	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 2WD	Rear HVAC	●	●	●	●	○	○	
2006	Chevrolet	Tahoe - 2WD	Generator battery control module	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 2WD	Driver seat module	●	●	●	●	●	○	

2006	Chevrolet	Tahoe - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 2WD	Body control module	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	Chevrolet	Tahoe - 2WD	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Chevrolet	Tahoe - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Tahoe - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Tahoe - 2WD	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	Tahoe - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	Chevrolet	Tahoe - 2WD	ABS	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	Chevrolet	Tahoe - 2WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	Chevrolet	Tahoe - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	Chevrolet	Tahoe - 4WD	Powertrain	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	Chevrolet	Tahoe - 4WD	CD changer	●	●	●	○	○	○	
2006	Chevrolet	Tahoe - 4WD	Chime	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 4WD	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	Tahoe - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Tahoe - 4WD	Radio	●	●	●	●	○	○	
2006	Chevrolet	Tahoe - 4WD	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	Tahoe - 4WD	Driver door module	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 4WD	Passenger door module	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 4WD	Rear HVAC	●	●	●	●	○	○	

2006	Chevrolet	Tahoe - 4WD	Generator battery control module	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 4WD	Driver seat module	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 4WD	Body control module	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	Chevrolet	Tahoe - 4WD	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Chevrolet	Tahoe - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Tahoe - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Tahoe - 4WD	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	Tahoe - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	Chevrolet	Tahoe - 4WD	ABS	●	●	●	●	●	○	
2006	Chevrolet	Tahoe - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	Chevrolet	Tahoe - 4WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	Chevrolet	Tahoe - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	Chevrolet	Trailblazer	Powertrain	●	●	●	●	●	●	T001
2006	Chevrolet	Trailblazer	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	Trailblazer	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Trailblazer	Radio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer	Body control module	●	●	●	●	●	●	T058
2006	Chevrolet	Trailblazer	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Driver door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Driver seat module	●	●	●	●	●	○	

2006	Chevrolet	Trailblazer	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Lift gate module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Passenger door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Trailblazer	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Trailblazer	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	Chevrolet	Trailblazer	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	Trailblazer	ABS/TCS/VSES	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Tire pressure monitor	●	●	○	●	●	●	T022
2006	Chevrolet	Trailblazer	Powertrain	●	●	●	●	●	●	T001
2006	Chevrolet	Trailblazer	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	Trailblazer	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Trailblazer	Radio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer	Body control module	●	●	●	●	●	●	T058
2006	Chevrolet	Trailblazer	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Driver door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Driver seat module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Lift gate module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Passenger door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Rear HVAC/RSA	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Trailblazer	Vehicle theft deterrent	●	●	●	●	○	○	

2006	Chevrolet	Trailblazer	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Trailblazer	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	Chevrolet	Trailblazer	Rear HVAC	●	●	●	●	●	●	T020
2006	Chevrolet	Trailblazer	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	Trailblazer	ABS/TCS/VSES	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Powertrain	●	●	●	●	●	●	T001
2006	Chevrolet	Trailblazer	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	Trailblazer	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Trailblazer	Radio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer	Body control module	●	●	●	●	●	●	T058
2006	Chevrolet	Trailblazer	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Driver door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Driver seat module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Lift gate module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Passenger door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Trailblazer	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Trailblazer	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	Chevrolet	Trailblazer	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	Trailblazer	ABS/TCS/VSES	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Tire pressure monitor	●	●	○	●	●	●	T022
2006	Chevrolet	Trailblazer	Powertrain	●	●	●	●	●	●	T001

2006	Chevrolet	Trailblazer	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	Trailblazer	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Trailblazer	Radio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer	Body control module	●	●	●	●	●	●	T058
2006	Chevrolet	Trailblazer	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Driver door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Driver seat module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Lift gate module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Passenger door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Rear HVAC/RSA	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Trailblazer	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Trailblazer	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	Chevrolet	Trailblazer	Rear HVAC	●	●	●	●	●	●	T020
2006	Chevrolet	Trailblazer	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	Trailblazer	ABS/TCS/VSES	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Powertrain	●	●	●	●	●	●	T001
2006	Chevrolet	Trailblazer EXT	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	Trailblazer EXT	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Trailblazer EXT	Radio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer EXT	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer EXT	Body control module	●	●	●	●	●	●	T058
2006	Chevrolet	Trailblazer EXT	Instrument panel cluster	●	●	●	●	●	○	

2006	Chevrolet	Trailblazer EXT	Driver door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Driver seat module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Lift gate module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Passenger door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Trailblazer EXT	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer EXT	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Trailblazer EXT	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	Chevrolet	Trailblazer EXT	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	Trailblazer EXT	ABS/TCS/VSES	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Tire pressure monitor	●	●	○	●	●	●	T022
2006	Chevrolet	Trailblazer EXT	Powertrain	●	●	●	●	●	●	T001
2006	Chevrolet	Trailblazer EXT	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	Trailblazer EXT	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Trailblazer EXT	Radio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer EXT	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer EXT	Body control module	●	●	●	●	●	●	T058
2006	Chevrolet	Trailblazer EXT	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Driver door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Driver seat module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Lift gate module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Passenger door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Rear HVAC/RSA	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Passenger presence system	●	●	○	○	○	●	T020

2006	Chevrolet	Trailblazer EXT	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer EXT	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Trailblazer EXT	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	Chevrolet	Trailblazer EXT	Rear HVAC	●	●	●	●	●	●	T020
2006	Chevrolet	Trailblazer EXT	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	Trailblazer EXT	ABS/TCS/VSES	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Powertrain	●	●	●	●	●	●	T001
2006	Chevrolet	Trailblazer EXT	Disc player and video display	●	●	●	○	○	○	
2006	Chevrolet	Trailblazer EXT	Digital radio receiver	●	●	●	●	○	●	T024
2006	Chevrolet	Trailblazer EXT	Radio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer EXT	Rear seat audio	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer EXT	Body control module	●	●	●	●	●	●	T058
2006	Chevrolet	Trailblazer EXT	Instrument panel cluster	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Driver door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Driver seat module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Heating and air conditioning	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Lift gate module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Passenger door module	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Passenger presence system	●	●	○	○	○	●	T020
2006	Chevrolet	Trailblazer EXT	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Chevrolet	Trailblazer EXT	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Chevrolet	Trailblazer EXT	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	Chevrolet	Trailblazer EXT	Navigation radio	●	●	●	●	●	●	T033
2006	Chevrolet	Trailblazer EXT	ABS/TCS/VSES	●	●	●	●	●	○	
2006	Chevrolet	Trailblazer EXT	Tire pressure monitor	●	●	○	●	●	●	T022

2006	Chevrolet	Uplander	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Uplander	Doors	●	●	●	●	●	○	
2006	Chevrolet	Uplander	Entertainment	●	●	●	●	●	●	T024
2006	Chevrolet	Uplander	Horns	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander	Instrument panel	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander	Lighting systems	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander	Navigation systems	●	●	●	●	●	●	T033
2006	Chevrolet	Uplander	Stationary windows	●	●	●	●	●	○	
2006	Chevrolet	Uplander	Theft deterrent	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander	Wipers/washer systems	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander	Keyless entry	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander	Seat belts	●	●	●	●	●	●	T147 T023
2006	Chevrolet	Uplander	SIR	●	●	●	●	●	●	T147 T023
2006	Chevrolet	Uplander - 4WD	HVAC systems - manual	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander - 4WD	Antilock brake system	●	●	●	●	●	●	T014
2006	Chevrolet	Uplander - 4WD	Engine controls	●	●	○	●	●	○	
2006	Chevrolet	Uplander - 4WD	Engine cooling	●	●	○	●	●	○	
2006	Chevrolet	Uplander - 4WD	Engine electrical	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander - 4WD	Shift lock control	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander - 4WD	Automatic transaxle	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander - 4WD	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2006	Chevrolet	Uplander - 4WD	Cruise control	●	●	●	●	●	●	T001
2006	Chevrolet	Uplander - 4WD	Doors	●	●	●	●	●	○	
2006	Chevrolet	Uplander - 4WD	Entertainment	●	●	●	●	●	●	T024
2006	Chevrolet	Uplander - 4WD	Horns	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander - 4WD	Instrument panel	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander - 4WD	Keyless entry	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander - 4WD	Lighting systems	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander - 4WD	Navigation systems	●	●	●	●	●	●	T033
2006	Chevrolet	Uplander - 4WD	Stationary windows	●	●	●	●	●	○	
2006	Chevrolet	Uplander - 4WD	Theft deterrent	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander - 4WD	Wipers/washer systems	●	●	●	●	●	●	T007
2006	Chevrolet	Uplander - 4WD	Seat belts	●	●	●	●	●	●	T147 T023
2006	Chevrolet	Uplander - 4WD	SIR	●	●	●	●	●	●	T147 T023
2006	Chevrolet	Uplander ext.	HVAC systems - manual	●	●	●	●	●	●	T007

2006	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058
2006	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2006	GMC truck	Canyon pickup - 2WD	ABS	●	●	●	●	●	●	T024
2006	GMC truck	Canyon pickup - 2WD	Powertrain	●	●	●	●	●	○	
2006	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	
2006	GMC truck	Canyon pickup - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Canyon pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058
2006	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2006	GMC truck	Canyon pickup - 2WD	ABS	●	●	●	●	●	●	T024
2006	GMC truck	Canyon pickup - 4WD	Powertrain	●	●	●	●	●	○	
2006	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	
2006	GMC truck	Canyon pickup - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	

2006	GMC truck	Canyon pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058
2006	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2006	GMC truck	Canyon pickup - 4WD	ABS	●	●	●	●	●	●	T024
2006	GMC truck	Canyon pickup - 4WD	Powertrain	●	●	●	●	●	○	
2006	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	
2006	GMC truck	Canyon pickup - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Canyon pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058
2006	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2006	GMC truck	Canyon pickup - 4WD	ABS	●	●	●	●	●	●	T024
2006	GMC truck	Envoy	Powertrain	●	●	●	●	●	●	T001
2006	GMC truck	Envoy	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	Envoy	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Envoy	Radio	●	●	●	●	○	○	
2006	GMC truck	Envoy	Rear seat audio	●	●	●	●	○	○	
2006	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058
2006	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	

2006	GMC truck	Envoy	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	GMC truck	Envoy	Rear HVAC	●	●	●	●	●	●	T020
2006	GMC truck	Envoy	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	Envoy	ABS/TCS/VSES	●	●	●	●	●	○	
2006	GMC truck	Envoy	Powertrain	●	●	●	●	●	●	T001
2006	GMC truck	Envoy	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	Envoy	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Envoy	Radio	●	●	●	●	○	○	
2006	GMC truck	Envoy	Rear seat audio	●	●	●	●	○	○	
2006	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058
2006	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Envoy	Driver door module	●	●	●	●	●	○	
2006	GMC truck	Envoy	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	Envoy	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	Envoy	Lift gate module	●	●	●	●	●	○	
2006	GMC truck	Envoy	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	Envoy	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Envoy	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Envoy	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	GMC truck	Envoy	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	Envoy	ABS/TCS/VSES	●	●	●	●	●	○	
2006	GMC truck	Envoy	Powertrain	●	●	●	●	●	●	T001
2006	GMC truck	Envoy	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	Envoy	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Envoy	Radio	●	●	●	●	○	○	
2006	GMC truck	Envoy	Rear seat audio	●	●	●	●	○	○	
2006	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058

2006	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Envoy	Driver door module	●	●	●	●	●	○	
2006	GMC truck	Envoy	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	Envoy	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	Envoy	Lift gate module	●	●	●	●	●	○	
2006	GMC truck	Envoy	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	Envoy	Rear HVAC/RSA	●	●	●	●	●	○	
2006	GMC truck	Envoy	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Envoy	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Envoy	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	GMC truck	Envoy	Rear HVAC	●	●	●	●	●	●	T020
2006	GMC truck	Envoy	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	Envoy	ABS/TCS/VSES	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Powertrain	●	●	●	●	●	●	T001
2006	GMC truck	Envoy XL	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	Envoy XL	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Envoy XL	Radio	●	●	●	●	○	○	
2006	GMC truck	Envoy XL	Rear seat audio	●	●	●	●	○	○	
2006	GMC truck	Envoy XL	Body control module	●	●	●	●	●	●	T058
2006	GMC truck	Envoy XL	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Driver door module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Lift gate module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Passenger presence system	●	●	○	○	○	●	T020

2006	GMC truck	Envoy XL	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Envoy XL	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	GMC truck	Envoy XL	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	Envoy XL	ABS/TCS/VSES	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Powertrain	●	●	●	●	●	●	T001
2006	GMC truck	Envoy XL	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	Envoy XL	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Envoy XL	Radio	●	●	●	●	○	○	
2006	GMC truck	Envoy XL	Rear seat audio	●	●	●	●	○	○	
2006	GMC truck	Envoy XL	Body control module	●	●	●	●	●	●	T058
2006	GMC truck	Envoy XL	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Driver door module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Lift gate module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Rear HVAC/RSA	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Envoy XL	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Envoy XL	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	GMC truck	Envoy XL	Rear HVAC	●	●	●	●	●	●	T020
2006	GMC truck	Envoy XL	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	Envoy XL	ABS/TCS/VSES	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Powertrain	●	●	●	●	●	●	T001
2006	GMC truck	Envoy XL	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	Envoy XL	Digital radio receiver	●	●	●	●	○	●	T024

2006	GMC truck	Envoy XL	Radio	●	●	●	●	○	○	
2006	GMC truck	Envoy XL	Rear seat audio	●	●	●	●	○	○	
2006	GMC truck	Envoy XL	Body control module	●	●	●	●	●	●	T058
2006	GMC truck	Envoy XL	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Driver door module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Lift gate module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Envoy XL	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Envoy XL	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	GMC truck	Envoy XL	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	Envoy XL	ABS/TCS/VSES	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Powertrain	●	●	●	●	●	●	T001
2006	GMC truck	Envoy XL	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	Envoy XL	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Envoy XL	Radio	●	●	●	●	○	○	
2006	GMC truck	Envoy XL	Rear seat audio	●	●	●	●	○	○	
2006	GMC truck	Envoy XL	Body control module	●	●	●	●	●	●	T058
2006	GMC truck	Envoy XL	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Driver door module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Lift gate module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	Envoy XL	Rear HVAC/RSA	●	●	●	●	●	○	

2006	GMC truck	Envoy XL	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Envoy XL	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Envoy XL	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	GMC truck	Envoy XL	Rear HVAC	●	●	●	●	●	●	T020
2006	GMC truck	Envoy XL	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	Envoy XL	ABS/TCS/VSES	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD	Powertrain	●	●	●	●	●	●	T146
2006	GMC truck	GMC c-series - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	GMC truck	GMC c-series - 2WD	CD changer	●	●	●	○	○	○	
2006	GMC truck	GMC c-series - 2WD	Chime	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	GMC c-series - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	GMC c-series - 2WD	Radio	●	●	●	●	○	○	
2006	GMC truck	GMC c-series - 2WD	Rear seat audio	●	●	●	●	○	○	
2006	GMC truck	GMC c-series - 2WD	Driver door module	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD	Rear HVAC	●	●	●	●	○	○	
2006	GMC truck	GMC c-series - 2WD	Generator battery control module	●	●	●	●	●	○	

2006	GMC truck	GMC c-series - 2WD	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD	Body control module	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	GMC truck	GMC c-series - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	GMC c-series - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	GMC c-series - 2WD	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	GMC c-series - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	GMC truck	GMC c-series - 2WD	ABS	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	GMC truck	GMC c-series - 2WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	GMC truck	GMC c-series - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	GMC truck	GMC c-series - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Amplifier (bose)	●	●	●	●	●	●	T139
2006	GMC truck	GMC c-series - 2WD (CNG)	CD changer	●	●	●	○	○	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Chime	●	●	●	●	●	○	

2006	GMC truck	GMC c-series - 2WD (CNG)	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	GMC c-series - 2WD (CNG)	Radio	●	●	●	●	○	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Rear seat audio	●	●	●	●	○	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Driver door module	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Rear HVAC	●	●	●	●	○	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Generator battery control module	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Rear aux. climate module	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Body control module	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	GMC truck	GMC c-series - 2WD (CNG)	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	GMC c-series - 2WD (CNG)	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	GMC c-series - 2WD (CNG)	Navigation radio	●	●	●	●	●	●	T033

2006	GMC truck	GMC c-series - 2WD (CNG)	Traction assist (if equipped)	●	●	○	●	●	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	ABS	●	●	●	●	●	○	
2006	GMC truck	GMC c-series - 2WD (CNG)	ESC (if equipped)	●	●	●	●	●	●	T156
2006	GMC truck	GMC c-series - 2WD (CNG)	Tire pressure monitor	●	●	●	●	●	●	T022
2006	GMC truck	GMC c-series - 2WD (CNG)	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	GMC truck	GMC K sierra - 4WD	Powertrain	●	●	●	●	●	●	T146
2006	GMC truck	GMC K sierra - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	GMC truck	GMC K sierra - 4WD	CD changer	●	●	●	○	○	○	
2006	GMC truck	GMC K sierra - 4WD	Chime	●	●	●	●	●	○	
2006	GMC truck	GMC K sierra - 4WD	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	GMC K sierra - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	GMC K sierra - 4WD	Radio	●	●	●	●	○	○	
2006	GMC truck	GMC K sierra - 4WD	Rear seat audio	●	●	●	●	○	○	
2006	GMC truck	GMC K sierra - 4WD	Driver door module	●	●	●	●	●	○	
2006	GMC truck	GMC K sierra - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	GMC K sierra - 4WD	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	GMC K sierra - 4WD	Rear HVAC	●	●	●	●	○	○	

2006	GMC truck	GMC K sierra - 4WD	Generator battery control module	●	●	●	●	●	○	
2006	GMC truck	GMC K sierra - 4WD	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	GMC K sierra - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2006	GMC truck	GMC K sierra - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	GMC K sierra - 4WD	Body control module	●	●	●	●	●	○	
2006	GMC truck	GMC K sierra - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	GMC truck	GMC K sierra - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	GMC K sierra - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	GMC K sierra - 4WD	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	GMC K sierra - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	GMC truck	GMC K sierra - 4WD	ABS	●	●	●	●	●	○	
2006	GMC truck	GMC K sierra - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	GMC truck	GMC K sierra - 4WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	GMC truck	GMC K sierra - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	GMC truck	GMC K sierra - 4WD (CNG)	Powertrain	●	●	●	●	●	○	
2006	GMC truck	GMC K sierra - 4WD (CNG)	Amplifier (bose)	●	●	●	●	●	●	T139
2006	GMC truck	GMC K sierra - 4WD (CNG)	CD changer	●	●	●	○	○	○	

2006	GMC truck	GMC K sierra - 4WD (CNG)	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	GMC K sierra - 4WD (CNG)	Traction assist (if equipped)	●	●	○	●	●	○	
2006	GMC truck	GMC K sierra - 4WD (CNG)	ABS	●	●	●	●	●	○	
2006	GMC truck	GMC K sierra - 4WD (CNG)	ESC (if equipped)	●	●	●	●	●	●	T156
2006	GMC truck	GMC K sierra - 4WD (CNG)	Tire pressure monitor	●	●	●	●	●	●	T022
2006	GMC truck	GMC K sierra - 4WD (CNG)	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	GMC truck	GMC sierra denali	Powertrain	●	●	●	●	●	●	T146
2006	GMC truck	GMC sierra denali	Amplifier (bose)	●	●	●	●	●	●	T139
2006	GMC truck	GMC sierra denali	CD changer	●	●	●	○	○	○	
2006	GMC truck	GMC sierra denali	Chime	●	●	●	●	●	○	
2006	GMC truck	GMC sierra denali	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	GMC sierra denali	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	GMC sierra denali	Radio	●	●	●	●	○	○	
2006	GMC truck	GMC sierra denali	Rear seat audio	●	●	●	●	○	○	
2006	GMC truck	GMC sierra denali	Driver door module	●	●	●	●	●	○	
2006	GMC truck	GMC sierra denali	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	GMC sierra denali	Passenger door module	●	●	●	●	●	○	

2006	GMC truck	GMC sierra denali	Rear HVAC	●	●	●	●	○	○	
2006	GMC truck	GMC sierra denali	Generator battery control module	●	●	●	●	●	○	
2006	GMC truck	GMC sierra denali	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	GMC sierra denali	Rear aux. climate module	●	●	●	●	●	○	
2006	GMC truck	GMC sierra denali	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	GMC sierra denali	Body control module	●	●	●	●	●	○	
2006	GMC truck	GMC sierra denali	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	GMC truck	GMC sierra denali	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	GMC sierra denali	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	GMC sierra denali	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	GMC sierra denali	Traction assist (if equipped)	●	●	○	●	●	○	
2006	GMC truck	GMC sierra denali	ABS	●	●	●	●	●	○	
2006	GMC truck	GMC sierra denali	ESC (if equipped)	●	●	●	●	●	●	T156
2006	GMC truck	GMC sierra denali	Tire pressure monitor	●	●	●	●	●	●	T022
2006	GMC truck	GMC sierra denali	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	GMC truck	Savana	Powertrain	●	●	●	●	●	●	T146
2006	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	○	
2006	GMC truck	Savana	Radio	●	●	●	●	○	○	

2006	GMC truck	Savana	Passenger presence system	●	●	○	○	○	○	
2006	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2006	GMC truck	Savana	Remote function actuation	●	●	●	●	●	○	
2006	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Savana	Body control module	●	●	●	●	●	○	
2006	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Savana	ABS	●	●	●	●	●	○	
2006	GMC truck	Savana	Powertrain	●	●	●	●	●	●	T146
2006	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	○	
2006	GMC truck	Savana	Radio	●	●	●	●	○	○	
2006	GMC truck	Savana	Passenger presence system	●	●	○	○	○	○	
2006	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2006	GMC truck	Savana	Remote function actuation	●	●	●	●	●	○	
2006	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Savana	Body control module	●	●	●	●	●	○	
2006	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Savana	ABS	●	●	●	●	●	○	
2006	GMC truck	Savana	Powertrain	●	●	●	●	●	○	
2006	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	○	
2006	GMC truck	Savana	Radio	●	●	●	●	○	○	
2006	GMC truck	Savana	Passenger presence system	●	●	○	○	○	○	

2006	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2006	GMC truck	Savana	Remote function actuation	●	●	●	●	●	○	
2006	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Savana	Body control module	●	●	●	●	●	○	
2006	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Savana	ABS	●	●	●	●	●	○	
2006	GMC truck	Savana	Powertrain	●	●	●	●	●	○	
2006	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	○	
2006	GMC truck	Savana	Radio	●	●	●	●	○	○	
2006	GMC truck	Savana	Passenger presence system	●	●	○	○	○	○	
2006	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2006	GMC truck	Savana	Remote function actuation	●	●	●	●	●	○	
2006	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Savana	Body control module	●	●	●	●	●	○	
2006	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Savana	ABS	●	●	●	●	●	○	
2006	GMC truck	Yukon - 2WD	Powertrain	●	●	●	●	●	○	
2006	GMC truck	Yukon - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	GMC truck	Yukon - 2WD	CD changer	●	●	●	○	○	○	
2006	GMC truck	Yukon - 2WD	Chime	●	●	●	●	●	○	
2006	GMC truck	Yukon - 2WD	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	Yukon - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Yukon - 2WD	Radio	●	●	●	●	○	○	
2006	GMC truck	Yukon - 2WD	Rear seat audio	●	●	●	●	○	○	

2006	GMC truck	Yukon - 2WD	Driver door module	●	●	●	●	●	○	
2006	GMC truck	Yukon - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	Yukon - 2WD	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	Yukon - 2WD	Rear HVAC	●	●	●	●	○	○	
2006	GMC truck	Yukon - 2WD	Generator battery control module	●	●	●	●	●	○	
2006	GMC truck	Yukon - 2WD	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	Yukon - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2006	GMC truck	Yukon - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Yukon - 2WD	Body control module	●	●	●	●	●	○	
2006	GMC truck	Yukon - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	GMC truck	Yukon - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Yukon - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Yukon - 2WD	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	Yukon - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	GMC truck	Yukon - 2WD	ABS	●	●	●	●	●	○	
2006	GMC truck	Yukon - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	GMC truck	Yukon - 2WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	GMC truck	Yukon - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	GMC truck	Yukon - 4WD	Powertrain	●	●	●	●	●	○	
2006	GMC truck	Yukon - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	GMC truck	Yukon - 4WD	CD changer	●	●	●	○	○	○	
2006	GMC truck	Yukon - 4WD	Chime	●	●	●	●	●	○	
2006	GMC truck	Yukon - 4WD	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	Yukon - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Yukon - 4WD	Radio	●	●	●	●	○	○	
2006	GMC truck	Yukon - 4WD	Rear seat audio	●	●	●	●	○	○	

2006	GMC truck	Yukon - 4WD	Driver door module	●	●	●	●	●	○	
2006	GMC truck	Yukon - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	Yukon - 4WD	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	Yukon - 4WD	Rear HVAC	●	●	●	●	○	○	
2006	GMC truck	Yukon - 4WD	Generator battery control module	●	●	●	●	●	○	
2006	GMC truck	Yukon - 4WD	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	Yukon - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2006	GMC truck	Yukon - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Yukon - 4WD	Body control module	●	●	●	●	●	○	
2006	GMC truck	Yukon - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	GMC truck	Yukon - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Yukon - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Yukon - 4WD	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	Yukon - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	GMC truck	Yukon - 4WD	ABS	●	●	●	●	●	○	
2006	GMC truck	Yukon - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	GMC truck	Yukon - 4WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	GMC truck	Yukon - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	GMC truck	Yukon denali	Powertrain	●	●	●	●	●	○	
2006	GMC truck	Yukon denali	Amplifier (bose)	●	●	●	●	●	●	T139
2006	GMC truck	Yukon denali	CD changer	●	●	●	○	○	○	
2006	GMC truck	Yukon denali	Chime	●	●	●	●	●	○	
2006	GMC truck	Yukon denali	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	Yukon denali	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Yukon denali	Radio	●	●	●	●	○	○	
2006	GMC truck	Yukon denali	Rear seat audio	●	●	●	●	○	○	

2006	GMC truck	Yukon denali	Driver door module	●	●	●	●	●	○	
2006	GMC truck	Yukon denali	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	Yukon denali	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	Yukon denali	Rear HVAC	●	●	●	●	○	○	
2006	GMC truck	Yukon denali	Generator battery control module	●	●	●	●	●	○	
2006	GMC truck	Yukon denali	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	Yukon denali	Rear aux. climate module	●	●	●	●	●	○	
2006	GMC truck	Yukon denali	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Yukon denali	Body control module	●	●	●	●	●	○	
2006	GMC truck	Yukon denali	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	GMC truck	Yukon denali	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Yukon denali	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Yukon denali	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	Yukon denali	Traction assist (if equipped)	●	●	○	●	●	○	
2006	GMC truck	Yukon denali	ABS	●	●	●	●	●	○	
2006	GMC truck	Yukon denali	ESC (if equipped)	●	●	●	●	●	●	T156
2006	GMC truck	Yukon denali	Tire pressure monitor	●	●	●	●	●	●	T022
2006	GMC truck	Yukon denali	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	GMC truck	Yukon XL - 2WD	Powertrain	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	GMC truck	Yukon XL - 2WD	CD changer	●	●	●	○	○	○	
2006	GMC truck	Yukon XL - 2WD	Chime	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 2WD	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	Yukon XL - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Yukon XL - 2WD	Radio	●	●	●	●	○	○	
2006	GMC truck	Yukon XL - 2WD	Rear seat audio	●	●	●	●	○	○	

2006	GMC truck	Yukon XL - 2WD	Driver door module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 2WD	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 2WD	Rear HVAC	●	●	●	●	○	○	
2006	GMC truck	Yukon XL - 2WD	Generator battery control module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 2WD	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 2WD	Body control module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	GMC truck	Yukon XL - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Yukon XL - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Yukon XL - 2WD	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	Yukon XL - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	GMC truck	Yukon XL - 2WD	ABS	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	GMC truck	Yukon XL - 2WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	GMC truck	Yukon XL - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	GMC truck	Yukon XL - 4WD	Powertrain	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2006	GMC truck	Yukon XL - 4WD	CD changer	●	●	●	○	○	○	
2006	GMC truck	Yukon XL - 4WD	Chime	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 4WD	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	Yukon XL - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Yukon XL - 4WD	Radio	●	●	●	●	○	○	
2006	GMC truck	Yukon XL - 4WD	Rear seat audio	●	●	●	●	○	○	

2006	GMC truck	Yukon XL - 4WD	Driver door module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 4WD	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 4WD	Rear HVAC	●	●	●	●	○	○	
2006	GMC truck	Yukon XL - 4WD	Generator battery control module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 4WD	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 4WD	Body control module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	GMC truck	Yukon XL - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Yukon XL - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Yukon XL - 4WD	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	Yukon XL - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2006	GMC truck	Yukon XL - 4WD	ABS	●	●	●	●	●	○	
2006	GMC truck	Yukon XL - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2006	GMC truck	Yukon XL - 4WD	Tire pressure monitor	●	●	●	●	●	●	T022
2006	GMC truck	Yukon XL - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	GMC truck	Yukon XL denali	Powertrain	●	●	●	●	●	○	
2006	GMC truck	Yukon XL denali	Amplifier (bose)	●	●	●	●	●	●	T139
2006	GMC truck	Yukon XL denali	CD changer	●	●	●	○	○	○	
2006	GMC truck	Yukon XL denali	Chime	●	●	●	●	●	○	
2006	GMC truck	Yukon XL denali	Disc player and video display	●	●	●	○	○	○	
2006	GMC truck	Yukon XL denali	Digital radio receiver	●	●	●	●	○	●	T024
2006	GMC truck	Yukon XL denali	Radio	●	●	●	●	○	○	
2006	GMC truck	Yukon XL denali	Rear seat audio	●	●	●	●	○	○	

2006	GMC truck	Yukon XL denali	Driver door module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL denali	Heating and air conditioning	●	●	●	●	●	○	
2006	GMC truck	Yukon XL denali	Passenger door module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL denali	Rear HVAC	●	●	●	●	○	○	
2006	GMC truck	Yukon XL denali	Generator battery control module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL denali	Driver seat module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL denali	Rear aux. climate module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL denali	Instrument panel cluster	●	●	●	●	●	○	
2006	GMC truck	Yukon XL denali	Body control module	●	●	●	●	●	○	
2006	GMC truck	Yukon XL denali	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	GMC truck	Yukon XL denali	Passenger presence system	●	●	○	○	○	●	T020
2006	GMC truck	Yukon XL denali	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	GMC truck	Yukon XL denali	Navigation radio	●	●	●	●	●	●	T033
2006	GMC truck	Yukon XL denali	Traction assist (if equipped)	●	●	○	●	●	○	
2006	GMC truck	Yukon XL denali	ABS	●	●	●	●	●	○	
2006	GMC truck	Yukon XL denali	ESC (if equipped)	●	●	●	●	●	●	T156
2006	GMC truck	Yukon XL denali	Tire pressure monitor	●	●	●	●	●	●	T022
2006	GMC truck	Yukon XL denali	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2006	Pontiac	Montana SV6	HVAC systems - manual	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6	Antilock brake system	●	●	●	●	●	●	T014
2006	Pontiac	Montana SV6	Engine controls	●	●	○	●	●	○	
2006	Pontiac	Montana SV6	Engine cooling	●	●	○	●	●	○	
2006	Pontiac	Montana SV6	Engine electrical	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6	Shift lock control	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6	Automatic transaxle	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2006	Pontiac	Montana SV6	Cruise control	●	●	●	●	●	●	T001

2006	Pontiac	Montana SV6	Doors	●	●	●	●	●	○	
2006	Pontiac	Montana SV6	Entertainment	●	●	●	●	●	●	T024
2006	Pontiac	Montana SV6	Horns	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6	Instrument panel	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6	Keyless entry	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6	Lighting systems	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6	Navigation systems	●	●	●	●	●	●	T033
2006	Pontiac	Montana SV6	Stationary windows	●	●	●	●	●	○	
2006	Pontiac	Montana SV6	Theft deterrent	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6	Wipers/washer systems	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6	Seat belts	●	●	●	●	●	●	T147 T023
2006	Pontiac	Montana SV6	SIR	●	●	●	●	●	●	T147 T023
2006	Pontiac	Montana SV6 - AWD	HVAC systems - manual	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6 - AWD	Antilock brake system	●	●	●	●	●	●	T014
2006	Pontiac	Montana SV6 - AWD	Engine controls	●	●	○	●	●	○	
2006	Pontiac	Montana SV6 - AWD	Engine cooling	●	●	○	●	●	○	
2006	Pontiac	Montana SV6 - AWD	Engine electrical	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6 - AWD	Shift lock control	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6 - AWD	Automatic transaxle	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6 - AWD	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2006	Pontiac	Montana SV6 - AWD	Cruise control	●	●	●	●	●	●	T001
2006	Pontiac	Montana SV6 - AWD	Doors	●	●	●	●	●	○	
2006	Pontiac	Montana SV6 - AWD	Entertainment	●	●	●	●	●	●	T024

2006	Pontiac	Montana SV6 - AWD	Horns	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6 - AWD	Instrument panel	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6 - AWD	Keyless entry	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6 - AWD	Lighting systems	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6 - AWD	Navigation systems	●	●	●	●	●	●	T033
2006	Pontiac	Montana SV6 - AWD	Stationary windows	●	●	●	●	●	○	
2006	Pontiac	Montana SV6 - AWD	Theft deterrent	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6 - AWD	Wipers/washer systems	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6 - AWD	Seat belts	●	●	●	●	●	●	T147 T023
2006	Pontiac	Montana SV6 - AWD	SIR	●	●	●	●	●	●	T147 T023
2006	Pontiac	Montana SV6 ext.	HVAC systems - manual	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6 ext.	Antilock brake system	●	●	●	●	●	●	T014
2006	Pontiac	Montana SV6 ext.	Engine controls	●	●	○	●	●	○	
2006	Pontiac	Montana SV6 ext.	Engine cooling	●	●	○	●	●	○	
2006	Pontiac	Montana SV6 ext.	Engine electrical	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6 ext.	Shift lock control	●	●	●	●	●	●	T007
2006	Pontiac	Montana SV6 ext.	Automatic transaxle	●	●	●	●	●	●	T007

2006	Pontiac	Torrent	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2006	Pontiac	Torrent	Vehicle comm. interface module	●	●	●	●	●	●	T155 T093
2006	Pontiac	Torrent	Electric power steering	●	●	○	●	●	○	
2006	Pontiac	Torrent	Antilock brake system	●	●	●	●	●	●	T014
2006	Saturn	RELAY	HVAC systems - manual	●	●	●	●	●	●	T007
2006	Saturn	RELAY	Antilock brake system	●	●	●	●	●	●	T014
2006	Saturn	RELAY	Engine controls	●	●	○	●	●	○	
2006	Saturn	RELAY	Engine cooling	●	●	○	●	●	○	
2006	Saturn	RELAY	Engine electrical	●	●	●	●	●	●	T007
2006	Saturn	RELAY	Shift lock control	●	●	●	●	●	●	T007
2006	Saturn	RELAY	Automatic transaxle	●	●	●	●	●	●	T007
2006	Saturn	RELAY	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2006	Saturn	RELAY	Cruise control	●	●	●	●	●	●	T001
2006	Saturn	RELAY	Doors	●	●	●	●	●	○	
2006	Saturn	RELAY	Entertainment	●	●	●	●	●	●	T024
2006	Saturn	RELAY	Horns	●	●	●	●	●	●	T007
2006	Saturn	RELAY	Instrument panel	●	●	●	●	●	●	T007
2006	Saturn	RELAY	Keyless entry	●	●	●	●	●	●	T007
2006	Saturn	RELAY	Lighting systems	●	●	●	●	●	●	T007
2006	Saturn	RELAY	Navigation systems	●	●	●	●	●	●	T033
2006	Saturn	RELAY	Stationary windows	●	●	●	●	●	○	
2006	Saturn	RELAY	Theft deterrent	●	●	●	●	●	●	T007
2006	Saturn	RELAY	Wipers/washer systems	●	●	●	●	●	●	T007
2006	Saturn	RELAY	Seat belts	●	●	●	●	●	●	T147 T023
2006	Saturn	RELAY	SIR	●	●	●	●	●	●	T147 T023
2006	Saturn	RELAY - AWD	HVAC systems - manual	●	●	●	●	●	●	T007
2006	Saturn	RELAY - AWD	Antilock brake system	●	●	●	●	●	●	T014
2006	Saturn	RELAY - AWD	Engine controls	●	●	○	●	●	○	
2006	Saturn	RELAY - AWD	Engine cooling	●	●	○	●	●	○	
2006	Saturn	RELAY - AWD	Engine electrical	●	●	●	●	●	●	T007
2006	Saturn	RELAY - AWD	Shift lock control	●	●	●	●	●	●	T007
2006	Saturn	RELAY - AWD	Automatic transaxle	●	●	●	●	●	●	T007

2006	Saturn	RELAY - AWD	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2006	Saturn	RELAY - AWD	Cruise control	●	●	●	●	●	●	T001
2006	Saturn	RELAY - AWD	Doors	●	●	●	●	●	○	
2006	Saturn	RELAY - AWD	Entertainment	●	●	●	●	●	●	T024
2006	Saturn	RELAY - AWD	Horns	●	●	●	●	●	●	T007
2006	Saturn	RELAY - AWD	Instrument panel	●	●	●	●	●	●	T007
2006	Saturn	RELAY - AWD	Keyless entry	●	●	●	●	●	●	T007
2006	Saturn	RELAY - AWD	Lighting systems	●	●	●	●	●	●	T007
2006	Saturn	RELAY - AWD	Navigation systems	●	●	●	●	●	●	T033
2006	Saturn	RELAY - AWD	Stationary windows	●	●	●	●	●	○	
2006	Saturn	RELAY - AWD	Theft deterrent	●	●	●	●	●	●	T007
2006	Saturn	RELAY - AWD	Wipers/washer systems	●	●	●	●	●	●	T007
2006	Saturn	RELAY - AWD	Seat belts	●	●	●	●	●	●	T147 T023
2006	Saturn	RELAY - AWD	SIR	●	●	●	●	●	●	T147 T023
2006	Saturn	RELAY ext.	HVAC systems - manual	●	●	●	●	●	●	T007
2006	Saturn	RELAY ext.	Antilock brake system	●	●	●	●	●	●	T014
2006	Saturn	RELAY ext.	Engine controls	●	●	○	●	●	○	
2006	Saturn	RELAY ext.	Engine cooling	●	●	○	●	●	○	
2006	Saturn	RELAY ext.	Engine electrical	●	●	●	●	●	●	T007
2006	Saturn	RELAY ext.	Shift lock control	●	●	●	●	●	●	T007
2006	Saturn	RELAY ext.	Automatic transaxle	●	●	●	●	●	●	T007
2006	Saturn	RELAY ext.	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2006	Saturn	RELAY ext.	Cruise control	●	●	●	●	●	●	T001
2006	Saturn	RELAY ext.	Doors	●	●	●	●	●	○	
2006	Saturn	RELAY ext.	Entertainment	●	●	●	●	●	●	T024
2006	Saturn	RELAY ext.	Horns	●	●	●	●	●	●	T007
2006	Saturn	RELAY ext.	Instrument panel	●	●	●	●	●	●	T007
2006	Saturn	RELAY ext.	Keyless entry	●	●	●	●	●	●	T007
2006	Saturn	RELAY ext.	Lighting systems	●	●	●	●	●	●	T007
2006	Saturn	RELAY ext.	Navigation systems	●	●	●	●	●	●	T033
2006	Saturn	RELAY ext.	Stationary windows	●	●	●	●	●	○	
2006	Saturn	RELAY ext.	Theft deterrent	●	●	●	●	●	●	T007
2006	Saturn	RELAY ext.	Wipers/washer systems	●	●	●	●	●	●	T007
2006	Saturn	RELAY ext.	Seat belts	●	●	●	●	●	●	T147 T023
2006	Saturn	RELAY ext.	SIR	●	●	●	●	●	●	T147 T023

2006	Saturn	VUE - AWD	Powertrain	●	●	●	●	●	●	T001
2006	Saturn	VUE - AWD	Digital radio receiver	●	●	●	●	○	○	
2006	Saturn	VUE - AWD	Instrument panel cluster	○	○	●	○	●	○	
2006	Saturn	VUE - AWD	Radio	●	●	●	●	●	●	T059
2006	Saturn	VUE - AWD	Body control module	●	●	●	●	●	●	T141 T148 T142 T143 T008
2006	Saturn	VUE - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093 T093
2006	Saturn	VUE - AWD	Supplemental inflatable restraint	●	●	●	●	●	○	
2006	Saturn	VUE - AWD	Antilock brake system	●	●	○	●	●	○	
2006	Saturn	VUE - FWD	Powertrain	●	●	●	●	●	●	T001
2006	Saturn	VUE - FWD	Digital radio receiver	●	●	●	●	○	○	
2006	Saturn	VUE - FWD	Instrument panel cluster	○	○	●	○	●	○	
2006	Saturn	VUE - FWD	Radio	●	●	●	●	●	●	T059
2006	Saturn	VUE - FWD	Body control module	●	●	●	●	●	●	T141 T148 T142 T143 T008
2006	Saturn	VUE - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093 T093
2006	Saturn	VUE - FWD	Supplemental inflatable restraint	●	●	●	●	●	○	
2006	Saturn	VUE - FWD	Antilock brake system	●	●	○	●	●	○	
2006	HUMMER	H2	Powertrain	●	●	●	●	●	○	
2006	HUMMER	H2	Digital radio receiver	●	●	●	●	○	●	T024
2006	HUMMER	H2	Radio	●	●	●	●	○	○	
2006	HUMMER	H2	Rear seat audio	●	●	●	●	○	○	
2006	HUMMER	H2	Driver door module	●	●	●	●	●	○	
2006	HUMMER	H2	Heating and air conditioning	●	●	●	●	●	○	
2006	HUMMER	H2	Passenger door module	●	●	●	●	●	○	
2006	HUMMER	H2	Driver seat module	●	●	●	●	●	○	
2006	HUMMER	H2	Instrument panel cluster	●	●	●	●	●	○	

2006	HUMMER	H2	Body control module	●	●	●	●	●	○	
2006	HUMMER	H2	Supplemental inflatable restraint	●	●	●	●	●	●	T147
2006	HUMMER	H2	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	HUMMER	H2	Navigation radio	●	●	●	●	●	●	T033
2006	HUMMER	H2	Air suspension	●	●	●	●	●	○	
2006	HUMMER	H2	ABS	●	●	○	●	●	○	
2006	HUMMER	H3	HVAC systems - manual	●	●	●	●	●	○	
2006	HUMMER	H3	Tire pressure monitoring	●	●	●	●	○	●	T022
2006	HUMMER	H3	Driveline/axle	●	●	○	●	●	○	
2006	HUMMER	H3	Antilock brake system	●	●	●	●	●	○	
2006	HUMMER	H3	Park brake	●	●	●	●	●	○	
2006	HUMMER	H3	Engine controls	●	●	○	●	●	○	
2006	HUMMER	H3	Engine cooling	●	●	○	●	●	○	
2006	HUMMER	H3	Engine electrical	●	●	○	●	●	○	
2006	HUMMER	H3	Shift lock control	●	●	●	●	●	○	
2006	HUMMER	H3	Automatic transmission	●	●	○	●	●	○	
2006	HUMMER	H3	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2006	HUMMER	H3	Cruise control	●	●	○	●	●	○	
2006	HUMMER	H3	Doors	●	●	●	●	●	●	T058
2006	HUMMER	H3	Entertainment	●	●	●	●	●	●	T024
2006	HUMMER	H3	Instrument panel	●	●	●	●	●	●	T058
2006	HUMMER	H3	Keyless entry	●	●	●	●	●	●	T058
2006	HUMMER	H3	Lighting systems	●	●	●	●	●	●	T058
2006	HUMMER	H3	Navigation systems	●	●	●	●	●	●	T033
2006	HUMMER	H3	Stationary windows	●	●	●	●	●	●	T058
2006	HUMMER	H3	Theft deterrent	●	●	●	●	●	●	T058
2006	HUMMER	H3	Wipers/washer systems	●	●	●	●	●	●	T058
2006	HUMMER	H3	Seat belts	●	●	●	●	●	○	
2006	HUMMER	H3	SIR	●	●	●	●	●	●	T023
2006	Saab	Saab 9-7x	Powertrain	●	●	●	●	●	●	T001
2006	Saab	Saab 9-7x	Disc player and video display	●	●	●	○	○	○	

2006	Saab	Saab 9-7x	Digital radio receiver	●	●	●	●	○	●	T024
2006	Saab	Saab 9-7x	Rear seat audio	●	●	●	●	○	○	
2006	Saab	Saab 9-7x	Body control module	●	●	●	●	●	●	T058
2006	Saab	Saab 9-7x	Instrument panel cluster	●	●	●	●	●	○	
2006	Saab	Saab 9-7x	Driver door module	●	●	●	●	●	○	
2006	Saab	Saab 9-7x	Driver seat module	●	●	●	●	●	○	
2006	Saab	Saab 9-7x	Heating and air conditioning	●	●	●	●	●	○	
2006	Saab	Saab 9-7x	Lift gate module	●	●	●	●	●	○	
2006	Saab	Saab 9-7x	Passenger door module	●	●	●	●	●	○	
2006	Saab	Saab 9-7x	Radio	●	●	●	●	●	●	T080 T144 T032
2006	Saab	Saab 9-7x	Vehicle theft deterrent	●	●	●	●	○	○	
2006	Saab	Saab 9-7x	Passenger presence system	●	●	○	○	○	●	T020
2006	Saab	Saab 9-7x	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2006	Saab	Saab 9-7x	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2006	Saab	Saab 9-7x	Navigation radio	●	●	●	●	●	●	T033
2006	Saab	Saab 9-7x	ABS/TCS/VSES	●	●	●	●	●	○	
2005	Buick	Century	Powertrain	●	●	●	●	●	○	
2005	Buick	Century	Supplemental inflatable restraint	●	●	●	●	○	○	
2005	Buick	Century	Body control module	●	●	○	●	●	●	T122 T170 T136
2005	Buick	Century	Radio	●	●	○	●	●	●	T081 T144 T080
2005	Buick	Century	Vehicle comm. interface module	●	●	●	●	●	●	T155 T093
2005	Buick	Century	Heating and air conditioning	●	●	○	●	●	○	
2005	Buick	Century	Chassis	●	●	●	●	●	●	T014
2005	Buick	Lacrosse	HVAC systems - manual	●	●	○	●	●	○	
2005	Buick	Lacrosse	HVAC systems - automatic	●	●	●	●	●	●	T008

2005	Buick	Lacrosse	Brakes	●	●	●	●	●	●	T014
2005	Buick	Lacrosse	Engine controls	●	●	○	●	●	○	
2005	Buick	Lacrosse	Engine cooling	●	●	○	●	●	○	
2005	Buick	Lacrosse	Engine electrical	●	●	●	●	●	●	T023
2005	Buick	Lacrosse	Shift lock control	●	●	●	●	●	●	T007
2005	Buick	Lacrosse	Automatic transaxle	●	●	●	●	●	●	T007
2005	Buick	Lacrosse	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Buick	Lacrosse	Cruise control	●	●	○	●	●	○	
2005	Buick	Lacrosse	Entertainment	●	●	●	●	●	●	T024
2005	Buick	Lacrosse	Horns	●	●	●	●	●	●	T007
2005	Buick	Lacrosse	Instrument panel	●	●	●	●	●	●	T171
2005	Buick	Lacrosse	Keyless entry	●	●	●	●	●	●	T007
2005	Buick	Lacrosse	Lighting systems	●	●	●	●	●	●	T007
2005	Buick	Lacrosse	Seats	●	●	●	●	●	●	T007
2005	Buick	Lacrosse	Stationary windows	●	●	●	●	●	●	T007
2005	Buick	Lacrosse	Theft deterrent	●	●	●	●	●	●	T007
2005	Buick	Lacrosse	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Buick	Lacrosse	Seat belts	●	●	●	●	○	●	T023
2005	Buick	Lacrosse	SIR	●	●	●	●	○	●	T023
2005	Buick	Lacrosse (allure in canada)	HVAC systems - manual	●	●	○	●	●	○	
2005	Buick	Lacrosse (allure in canada)	HVAC systems - automatic	●	●	●	●	●	●	T008
2005	Buick	Lacrosse (allure in canada)	Brakes	●	●	●	●	●	●	T014
2005	Buick	Lacrosse (allure in canada)	Engine controls	●	●	○	●	●	○	
2005	Buick	Lacrosse (allure in canada)	Engine cooling	●	●	○	●	●	○	

2005	Buick	Lacrosse (allure in canada)	Engine electrical	●	●	●	●	●	●	T023
2005	Buick	Lacrosse (allure in canada)	Shift lock control	●	●	●	●	●	●	T007
2005	Buick	Lacrosse (allure in canada)	Automatic transaxle	●	●	●	●	●	●	T007
2005	Buick	Lacrosse (allure in canada)	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Buick	Lacrosse (allure in canada)	Cruise control	●	●	○	●	●	○	
2005	Buick	Lacrosse (allure in canada)	Entertainment	●	●	●	●	●	●	T024
2005	Buick	Lacrosse (allure in canada)	Horns	●	●	●	●	●	●	T007
2005	Buick	Lacrosse (allure in canada)	Instrument panel	●	●	●	●	●	●	T171
2005	Buick	Lacrosse (allure in canada)	Keyless entry	●	●	●	●	●	●	T007
2005	Buick	Lacrosse (allure in canada)	Lighting systems	●	●	●	●	●	●	T007
2005	Buick	Lacrosse (allure in canada)	Seats	●	●	●	●	●	●	T007

2005	Buick	Lacrosse (allure in canada)	Stationary windows	●	●	●	●	●	●	T007
2005	Buick	Lacrosse (allure in canada)	Theft deterrent	●	●	●	●	●	●	T007
2005	Buick	Lacrosse (allure in canada)	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Buick	Lacrosse (allure in canada)	Seat belts	●	●	●	●	○	●	T023
2005	Buick	Lacrosse (allure in canada)	SIR	●	●	●	●	○	●	T023
2005	Buick	Lesabre	Powertrain	●	●	●	●	●	○	
2005	Buick	Lesabre	Dash integration module	●	●	●	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112
2005	Buick	Lesabre	Head up display	●	●	●	●	●	○	
2005	Buick	Lesabre	Rear integration module	●	●	●	●	●	○	
2005	Buick	Lesabre	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Buick	Lesabre	Driver door module	●	●	●	●	●	○	
2005	Buick	Lesabre	CD changer	●	●	●	●	○	○	
2005	Buick	Lesabre	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060
2005	Buick	Lesabre	Digital radio receiver	●	●	●	●	○	●	T024
2005	Buick	Lesabre	Supplemental inflatable restraint	●	●	●	●	○	●	T113
2005	Buick	Lesabre	Remote function actuation	●	●	●	●	●	○	
2005	Buick	Lesabre	Vehicle theft deterrent	●	●	●	●	○	○	

2005	Buick	Park avenue	Memory seat module	●	●	●	●	●	●	T177
2005	Buick	Park avenue	Driver door module	●	●	●	●	●	○	
2005	Buick	Park avenue	Supplemental inflatable restraint	●	●	●	●	○	●	T023
2005	Buick	Park avenue	Remote function actuation	○	○	●	●	●	○	
2005	Buick	Park avenue	Vehicle theft deterrent	●	●	○	●	○	○	
2005	Buick	Park avenue	Heating and air conditioning	●	●	●	●	●	●	T138
2005	Buick	Park avenue	Vehicle comm. interface module	●	●	●	●	○	●	T155 T093
2005	Buick	Park avenue	DRP/ABS/TIM	●	●	○	●	●	●	T014
2005	Cadillac	CTS	Powertrain	●	●	●	●	●	○	
2005	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T122 T123 T124 T125 T126 T127 T128 T129 T130 T131 T132 T133 T134 T135 T136
2005	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2005	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2005	Cadillac	CTS	Driver door switch	●	●	●	●	○	●	T117 T117 T117 T117
2005	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2005	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2005	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2005	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2005	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2005	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T155 T093
2005	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2005	Cadillac	CTS	Radio	●	●	●	●	○	●	T114 T094 T095 T086 T087 T115 T033 T033
2005	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2005	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	

2005	Cadillac	CTS	Remote function actuation	●	●	●	●	●	○	
2005	Cadillac	CTS	Vehicle theft deterrent	●	●	●	●	○	○	
2005	Cadillac	CTS	Passenger presence system	●	●	○	○	○	○	
2005	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2005	Cadillac	CTS	Climate control panel	●	●	●	●	●	●	T032
2005	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2005	Cadillac	CTS	Powertrain	●	●	●	●	●	○	
2005	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T122 T123 T124 T125 T126 T127 T128 T129 T130 T131 T132 T133 T134 T135 T136
2005	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2005	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2005	Cadillac	CTS	Driver door switch	●	●	●	●	○	○	
2005	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2005	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2005	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2005	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2005	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2005	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T155 T093
2005	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2005	Cadillac	CTS	Radio	●	●	●	●	○	●	T114 T094 T095 T086 T087 T115 T033 T033
2005	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2005	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2005	Cadillac	CTS	Remote function actuation	●	●	●	●	●	○	
2005	Cadillac	CTS	Vehicle theft deterrent	●	●	●	●	○	○	

2005	Cadillac	CTS	Passenger presence system	●	●	○	○	○	○	
2005	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2005	Cadillac	CTS	Climate control panel	●	●	●	●	●	●	T032
2005	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2005	Cadillac	CTS	Powertrain	●	●	●	●	●	○	
2005	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T122 T123 T124 T125 T126 T127 T128 T129 T130 T131 T132 T133 T134 T135 T136
2005	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2005	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2005	Cadillac	CTS	Driver door switch	●	●	●	●	○	○	
2005	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2005	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2005	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2005	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2005	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2005	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T155 T093
2005	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2005	Cadillac	CTS	Radio	●	●	●	●	○	●	T114 T094 T095 T086 T087 T115 T033 T033
2005	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2005	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2005	Cadillac	CTS	Remote function actuation	●	●	●	●	●	○	
2005	Cadillac	CTS	Vehicle theft deterrent	●	●	●	●	○	○	
2005	Cadillac	CTS	Passenger presence system	●	●	○	○	○	○	
2005	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	

2005	Cadillac	CTS	Climate control panel	●	●	●	●	●	●	T032
2005	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2005	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T122 T123 T124 T125 T126 T127 T128 T129 T130 T131 T132 T133 T134 T135 T136
2005	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2005	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2005	Cadillac	CTS	Driver door switch	●	●	●	●	○	○	
2005	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2005	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2005	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2005	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2005	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2005	Cadillac	CTS	Vehicle comm. interface module	●	●	●	●	●	●	T155 T093
2005	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2005	Cadillac	CTS	Radio	●	●	●	●	○	●	T114 T094 T095 T086 T087 T115 T033 T033
2005	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2005	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2005	Cadillac	CTS	Remote function actuation	●	●	●	●	●	○	
2005	Cadillac	CTS	Vehicle theft deterrent	●	●	●	●	○	○	
2005	Cadillac	CTS	Passenger presence system	●	●	○	○	○	○	
2005	Cadillac	CTS	Instrument panel cluster	●	●	●	●	●	○	
2005	Cadillac	CTS	Climate control panel	●	●	●	●	●	●	T112 T113
2005	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2005	Cadillac	CTS	Tire pressure monitor	●	●	○	●	●	●	T137
2005	Cadillac	CTS	Powertrain	●	●	●	●	●	○	
2005	Cadillac	Deville	Powertrain	●	●	●	●	●	○	

2005	Cadillac	Deville	Dash integration module	●	●	○	●	●	●	T122 T172 T123 T127 T178 T136
2005	Cadillac	Deville	Personalization	●	●	○	●	●	○	
2005	Cadillac	Deville	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Cadillac	Deville	Digital radio receiver	●	●	●	●	○	●	T024
2005	Cadillac	Deville	CD changer	●	●	●	●	○	○	
2005	Cadillac	Deville	Memory seat module	●	●	○	●	●	○	
2005	Cadillac	Deville	Driver door switch	●	●	●	●	○	○	
2005	Cadillac	Deville	Driver door module	●	●	●	●	●	○	
2005	Cadillac	Deville	Passenger door module	●	●	●	●	●	○	
2005	Cadillac	Deville	Left rear door module	●	●	●	●	●	○	
2005	Cadillac	Deville	Right rear door module	●	●	●	●	●	○	
2005	Cadillac	Deville	Amplifier (delco)	●	●	○	●	●	○	
2005	Cadillac	Deville	Navigation radio	●	●	●	●	○	●	T166
2005	Cadillac	Deville	Radio	●	●	●	●	●	●	T179 T086 T087 T033
2005	Cadillac	Deville	Remote function actuation	●	●	●	●	●	●	T180
2005	Cadillac	Deville	Vehicle theft deterrent	●	●	○	●	○	○	
2005	Cadillac	Deville	Instrument panel cluster	●	●	○	●	●	●	T159 T158 T181 T094 T122
2005	Cadillac	Deville	Instrument panel module	●	●	○	●	●	●	T138 T175
2005	Cadillac	Deville	Rear climate control panel	●	●	○	●	●	○	
2005	Cadillac	Deville	Speed sensitive steering	●	●	○	●	○	○	
2005	Cadillac	DHS	Powertrain	●	●	●	●	●	○	
2005	Cadillac	DHS	Dash integration module	●	●	○	●	●	●	T122 T172 T123 T127 T178 T136
2005	Cadillac	DHS	Personalization	●	●	○	●	●	○	
2005	Cadillac	DHS	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Cadillac	DHS	Digital radio receiver	●	●	●	●	○	●	T024

2005	Cadillac	DHS	CD changer	●	●	●	●	○	○	
2005	Cadillac	DHS	Memory seat module	●	●	○	●	●	○	
2005	Cadillac	DHS	Driver door switch	●	●	●	●	○	○	
2005	Cadillac	DHS	Driver door module	●	●	●	●	●	○	
2005	Cadillac	DHS	Passenger door module	●	●	●	●	●	○	
2005	Cadillac	DHS	Left rear door module	●	●	●	●	●	○	
2005	Cadillac	DHS	Right rear door module	●	●	●	●	●	○	
2005	Cadillac	DHS	Amplifier (bose)	●	●	○	●	●	○	
2005	Cadillac	DHS	Navigation radio	●	●	●	●	○	●	T166
2005	Cadillac	DHS	Radio	●	●	●	●	●	●	T179 T086 T087 T033
2005	Cadillac	DHS	Remote function actuation	●	●	●	●	●	●	T180
2005	Cadillac	DHS	Vehicle theft deterrent	●	●	○	●	○	○	
2005	Cadillac	DHS	Instrument panel cluster	●	●	○	●	●	●	T159 T158 T181 T094 T122
2005	Cadillac	DHS	Instrument panel module	●	●	○	●	●	●	T138 T175
2005	Cadillac	DHS	Rear climate control panel	●	●	○	●	●	○	
2005	Cadillac	DHS	Speed sensitive steering	●	●	○	●	○	○	
2005	Cadillac	DTS	Powertrain	●	●	●	●	●	○	
2005	Cadillac	DTS	Dash integration module	●	●	○	●	●	●	T122 T172 T123 T127 T178 T136
2005	Cadillac	DTS	Personalization	●	●	○	●	●	○	
2005	Cadillac	DTS	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Cadillac	DTS	Digital radio receiver	●	●	●	●	○	●	T024
2005	Cadillac	DTS	CD changer	●	●	●	●	○	○	
2005	Cadillac	DTS	Memory seat module	●	●	○	●	●	○	
2005	Cadillac	DTS	Driver door switch	●	●	●	●	○	○	
2005	Cadillac	DTS	Driver door module	●	●	●	●	●	○	
2005	Cadillac	DTS	Passenger door module	●	●	●	●	●	○	
2005	Cadillac	DTS	Left rear door module	●	●	●	●	●	○	

2005	Cadillac	DTS	Right rear door module	●	●	●	●	●	○	
2005	Cadillac	DTS	Amplifier (bose)	●	●	○	●	●	○	
2005	Cadillac	DTS	Navigation radio	●	●	●	●	○	●	T166
2005	Cadillac	DTS	Radio	●	●	●	●	●	●	T179 T086 T087 T033
2005	Cadillac	DTS	Remote function actuation	●	●	●	●	●	●	T180
2005	Cadillac	DTS	Vehicle theft deterrent	●	●	○	●	○	○	
2005	Cadillac	DTS	Instrument panel cluster	●	●	○	●	●	●	T159 T158 T181 T094 T122
2005	Cadillac	DTS	Instrument panel module	●	●	○	●	●	●	T138 T175
2005	Cadillac	DTS	Rear climate control panel	●	●	○	●	●	○	
2005	Cadillac	DTS	Speed sensitive steering	●	●	○	●	○	○	
2005	Cadillac	STS	HVAC systems - automatic	●	●	●	●	●	●	T001
2005	Cadillac	STS	Variable effort steering	●	●	○	●	○	○	
2005	Cadillac	STS	Steering wheel and column	●	●	●	●	●	●	T059
2005	Cadillac	STS	Tire pressure monitoring	●	●	●	●	●	●	T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066
2005	Cadillac	STS	Electronic suspension control (ESC)	●	●	○	●	●	○	
2005	Cadillac	STS	Antilock brake system	●	●	●	●	●	●	T014
2005	Cadillac	STS	Hydraulic brakes	●	●	○	●	●	○	
2005	Cadillac	STS	Park brake	●	●	●	●	●	○	
2005	Cadillac	STS	Engine controls	●	●	●	●	●	●	T001
2005	Cadillac	STS	Engine cooling	●	●	●	●	●	●	T001
2005	Cadillac	STS	Engine electrical	●	●	●	●	●	●	T059

2005	Cadillac	STS	Shift lock control	●	●	●	●	●	●	T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2005	Cadillac	STS	Automatic transmission	●	●	●	●	●	○	
2005	Cadillac	STS	Body rear end	●	●	●	●	●	●	T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2005	Cadillac	STS	Cellular communication	●	●	●	●	●	●	T155
2005	Cadillac	STS	Cruise control	●	●	●	●	●	●	T059
2005	Cadillac	STS	Doors	●	●	●	●	●	●	T068
2005	Cadillac	STS	Entertainment	●	●	●	●	●	●	T069 T033 T033
2005	Cadillac	STS	Horns	●	●	●	●	●	○	
2005	Cadillac	STS	Instrument panel	●	●	●	●	●	●	T059
2005	Cadillac	STS	Keyless entry	●	●	●	●	●	●	T059
2005	Cadillac	STS	Lighting systems	●	●	●	●	●	●	T059
2005	Cadillac	STS	Driver position module	●	●	○	●	○	○	
2005	Cadillac	STS	Seats	●	●	●	●	●	○	
2005	Cadillac	STS	Stationary windows	●	●	●	●	●	○	
2005	Cadillac	STS	Theft deterrent	●	●	●	●	●	●	T059
2005	Cadillac	STS	Wipers/washer systems	●	●	●	●	●	●	T059
2005	Cadillac	STS	Rear parking assist	●	●	●	●	●	○	
2005	Cadillac	STS	Seat belts	●	●	●	●	○	●	T067
2005	Cadillac	STS	SIR	●	●	●	●	○	●	T067
2005	Cadillac	STS	Variable effort steering	●	●	○	●	○	○	
2005	Cadillac	STS	Steering wheel and column	●	●	●	●	●	●	T059
2005	Cadillac	STS	Tire pressure monitoring	●	●	●	●	●	●	T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066
2005	Cadillac	STS	Electronic suspension control (ESC)	●	●	○	●	●	○	

2005	Cadillac	STS	Shift lock control	●	●	●	●	●	●	T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2005	Cadillac	STS	Automatic transmission	●	●	●	●	●	●	T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2005	Cadillac	STS	Body rear end	●	●	●	●	●	●	T026 T064 T065 T027 T028 T066 T026 T064 T065 T027 T028 T066 T100 T101
2005	Cadillac	STS	Cellular communication	●	●	●	●	●	●	T155
2005	Cadillac	STS	Doors	●	●	●	●	●	●	T068
2005	Cadillac	STS	Entertainment	●	●	●	●	●	●	T069 T033 T033
2005	Cadillac	STS	Horns	●	●	●	●	●	○	
2005	Cadillac	STS	Keyless entry	●	●	●	●	●	●	T059
2005	Cadillac	STS	Lighting systems	●	●	●	●	●	●	T059
2005	Cadillac	STS	Driver position module	●	●	○	●	○	○	
2005	Cadillac	STS	Seats	●	●	●	●	●	○	
2005	Cadillac	STS	Stationary windows	●	●	●	●	●	○	
2005	Cadillac	STS	Wipers/washer systems	●	●	●	●	●	●	T059
2005	Cadillac	STS	Rear parking assist	●	●	●	●	●	○	
2005	Cadillac	STS	Cruise control	●	●	●	●	●	●	T059
2005	Cadillac	STS	Instrument panel	●	●	●	●	●	●	T059
2005	Cadillac	STS	Theft deterrent	●	●	●	●	●	●	T059
2005	Cadillac	STS	Seat belts	●	●	●	●	○	●	T067
2005	Cadillac	STS	SIR	●	●	●	●	○	●	T067
2005	Cadillac	STS	HVAC systems - automatic	●	●	●	●	●	○	
2005	Cadillac	STS	Antilock brake system	●	●	●	●	●	●	T014
2005	Cadillac	STS	Hydraulic brakes	●	●	○	●	●	○	
2005	Cadillac	STS	Park brake	●	●	●	●	●	○	
2005	Cadillac	STS	Engine controls	●	●	●	●	●	○	
2005	Cadillac	STS	Engine cooling	●	●	●	●	●	○	

2005	Cadillac	STS	Engine electrical	●	●	●	●	●	●	T059
2005	Cadillac	XLR	HVAC systems - automatic	●	●	●	●	●	●	T008 T001
2005	Cadillac	XLR	Variable effort steering	●	●	○	●	○	○	
2005	Cadillac	XLR	Steering wheel and column	●	●	○	●	●	○	
2005	Cadillac	XLR	Tire pressure monitoring	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2005	Cadillac	XLR	Electronic suspension control (ESC)	●	●	○	●	●	○	
2005	Cadillac	XLR	Antilock brake system	●	●	●	●	●	●	T014 T001
2005	Cadillac	XLR	Hydraulic brakes	●	●	○	●	●	○	
2005	Cadillac	XLR	Park brake	●	●	○	●	●	○	
2005	Cadillac	XLR	Engine controls	●	●	●	●	●	●	T001
2005	Cadillac	XLR	Engine cooling	●	●	●	●	●	●	T001
2005	Cadillac	XLR	Engine electrical	●	●	●	●	●	●	T001
2005	Cadillac	XLR	Shift lock control	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2005	Cadillac	XLR	Automatic transmission	●	●	●	●	●	○	
2005	Cadillac	XLR	Body rear end	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2005	Cadillac	XLR	Cellular communication	●	●	●	●	●	●	T155 T093
2005	Cadillac	XLR	Cruise control	●	●	●	●	●	●	T001
2005	Cadillac	XLR	Doors	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2005	Cadillac	XLR	Entertainment	●	●	●	●	●	●	T024
2005	Cadillac	XLR	Horns	●	●	○	●	●	○	
2005	Cadillac	XLR	Instrument panel	●	●	●	●	●	●	T001

2005	Cadillac	XLR	Keyless entry	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2005	Cadillac	XLR	Lighting systems	●	●	●	●	●	○	
2005	Cadillac	XLR	Navigation systems	●	●	○	●	○	●	T033
2005	Cadillac	XLR	Roof	●	●	●	●	●	○	
2005	Cadillac	XLR	Seats	●	●	●	●	●	●	T030 T154
2005	Cadillac	XLR	Theft deterrent	●	●	●	●	●	●	T001
2005	Cadillac	XLR	Wipers/washer systems	●	●	○	●	●	○	
2005	Cadillac	XLR	Seat belts	●	●	●	●	●	●	T023
2005	Cadillac	XLR	SIR	●	●	●	●	●	●	T023
2005	Chevrolet	Aveo	Powertrain	●	●	●	●	●	●	T001
2005	Chevrolet	Aveo	Chassis	●	●	●	●	●	●	T014
2005	Chevrolet	Cavalier	Powertrain	●	●	●	●	●	○	
2005	Chevrolet	Cavalier	Onstar	●	●	●	●	●	●	T155 T093
2005	Chevrolet	Cavalier	Radio	●	●	○	●	●	●	T183
2005	Chevrolet	Cavalier	Body control module	●	●	●	●	●	●	T141
2005	Chevrolet	Cavalier	Supplemental inflatable restraint	●	●	●	●	○	●	T023
2005	Chevrolet	Cavalier	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Cavalier	Chassis	●	●	●	●	●	●	T014
2005	Chevrolet	Classic	Powertrain	●	●	●	●	●	○	
2005	Chevrolet	Classic	Radio	●	●	○	●	●	○	
2005	Chevrolet	Classic	Supplemental inflatable restraint	●	●	●	●	○	○	
2005	Chevrolet	Classic	Body control module	●	●	●	●	●	●	T141
2005	Chevrolet	Classic	Remote function actuation	●	●	●	●	●	○	
2005	Chevrolet	Classic	Chassis	●	●	●	●	●	●	T014
2005	Chevrolet	Cobalt	HVAC systems - manual	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Power steering system	●	●	○	●	○	○	
2005	Chevrolet	Cobalt	Antilock brake system	●	●	●	●	●	●	T014
2005	Chevrolet	Cobalt	Park brake	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Engine controls	●	●	●	●	●	●	T001
2005	Chevrolet	Cobalt	Engine cooling	●	●	●	●	●	●	T001

2005	Chevrolet	Cobalt	Engine electrical	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Shift lock control	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Automatic transaxle	●	●	●	●	●	○	
2005	Chevrolet	Cobalt	Body rear end	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Cellular communication	●	●	●	●	●	●	T155 T093
2005	Chevrolet	Cobalt	Cruise control	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Entertainment	●	●	●	●	●	●	T024
2005	Chevrolet	Cobalt	Horns	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Instrument panel	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Keyless entry	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Lighting systems	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Body control module	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Stationary windows	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Theft deterrent	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Wipers/washer systems	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	Seat belts	●	●	●	●	●	●	T023
2005	Chevrolet	Cobalt	SIR	●	●	●	●	○	●	T023
2005	Chevrolet	Corvette	HVAC systems - automatic	●	●	●	●	●	●	T008
2005	Chevrolet	Corvette	Variable effort steering	●	●	○	●	○	○	
2005	Chevrolet	Corvette	Steering wheel and column	●	●	●	●	●	●	T184
2005	Chevrolet	Corvette	Tire pressure monitoring	●	●	●	●	●	●	T026 T027 T028 T026 T027 T028 T026 T027 T028 T029
2005	Chevrolet	Corvette	Electronic suspension control (ESC)	●	●	○	●	●	○	
2005	Chevrolet	Corvette	Antilock brake system	●	●	●	●	●	●	T014
2005	Chevrolet	Corvette	Hydraulic brakes	●	●	○	●	●	○	
2005	Chevrolet	Corvette	Park brake	●	●	●	●	●	○	
2005	Chevrolet	Corvette	Engine controls	●	●	●	●	●	●	T001
2005	Chevrolet	Corvette	Engine cooling	●	●	●	●	●	●	T001
2005	Chevrolet	Corvette	Engine electrical	●	●	●	●	●	●	T001

2005	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	○	○	
2005	Chevrolet	Impala	Radio	●	●	○	●	●	●	T080 T081 T082
2005	Chevrolet	Impala	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Impala	Driver information center	●	●	○	○	○	○	
2005	Chevrolet	Impala	Body control module	●	●	○	●	●	●	T023 T136 T122
2005	Chevrolet	Impala	Heating and air conditioning	●	●	○	○	○	○	
2005	Chevrolet	Impala	Chassis	●	●	●	●	●	●	T014
2005	Chevrolet	Malibu	HVAC systems - manual	●	●	○	●	●	○	
2005	Chevrolet	Malibu	HVAC systems - automatic	●	●	●	●	●	○	
2005	Chevrolet	Malibu	Power steering system	●	●	○	●	●	●	T104
2005	Chevrolet	Malibu	Antilock brake system	●	●	●	●	●	●	T014
2005	Chevrolet	Malibu	Hydraulic brakes	●	●	○	●	○	○	
2005	Chevrolet	Malibu	Engine controls	●	●	●	●	●	●	T001
2005	Chevrolet	Malibu	Engine cooling	●	●	○	●	●	○	
2005	Chevrolet	Malibu	Engine electrical	●	●	●	●	●	●	T023
2005	Chevrolet	Malibu	Shift lock control	●	●	○	●	○	○	
2005	Chevrolet	Malibu	Automatic transaxle	●	●	○	●	●	○	
2005	Chevrolet	Malibu	Body rear end	●	●	○	●	●	○	
2005	Chevrolet	Malibu	Cellular communication	●	●	●	●	●	●	T155
2005	Chevrolet	Malibu	Cruise control	●	●	○	●	○	○	
2005	Chevrolet	Malibu	Doors	●	●	○	●	●	○	
2005	Chevrolet	Malibu	Entertainment	●	●	●	●	●	●	T024
2005	Chevrolet	Malibu	Instrument panel	●	●	●	●	●	○	
2005	Chevrolet	Malibu	Keyless entry	●	●	○	●	○	○	
2005	Chevrolet	Malibu	Lighting systems	●	●	○	●	●	○	
2005	Chevrolet	Malibu	Stationary windows	●	●	○	●	●	○	
2005	Chevrolet	Malibu	Theft deterrent	●	●	●	●	●	○	
2005	Chevrolet	Malibu	Wipers/washer systems	●	●	○	●	●	○	
2005	Chevrolet	Malibu	Adjustable pedals	●	●	○	●	●	○	
2005	Chevrolet	Malibu	Seat belts	●	●	●	●	●	●	T023
2005	Chevrolet	Malibu	SIR	●	●	●	●	●	●	T023

2005	Chevrolet	Monte carlo	Powertrain	●	●	●	●	●	○	
2005	Chevrolet	Monte carlo	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Monte carlo	Supplemental inflatable restraint	●	●	●	●	○	○	
2005	Chevrolet	Monte carlo	Radio	●	●	○	●	●	●	T080 T081 T082
2005	Chevrolet	Monte carlo	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Monte carlo	Driver information center	●	●	○	○	○	○	
2005	Chevrolet	Monte carlo	Body control module	●	●	○	●	●	●	T023 T136 T122
2005	Chevrolet	Monte carlo	Heating and air conditioning	●	●	○	○	○	○	
2005	Chevrolet	Monte carlo	Chassis	●	●	●	●	●	●	T014
2005	Chevrolet	Optra	Powertrain	●	●	●	●	●	●	T015
2005	Chevrolet	Optra	Antilock brake system	●	●	●	●	●	●	T014
2005	Chevrolet	Spark	Powertrain	●	●	●	●	●	○	
2005	Chevrolet	Spark	Chassis	●	●	●	●	●	○	
2005	Chevrolet	Vivant	Powertrain	●	●	●	●	●	●	T015
2005	Chevrolet	Vivant	Supplemental inflatable restraint	●	●	○	●	○	○	
2005	Chevrolet	Vivant	Chassis	●	●	●	●	●	●	T014
2005	Chevrolet	Monza	Powertrain	●	●	●	●	●	●	T001
2005	Chevrolet	Chevy	Powertrain	●	●	●	●	●	●	T001
2005	Chevrolet	Others	Powertrain	●	●	●	●	●	●	T001
2005	Chevrolet	Others	Antilock brake system	●	●	●	●	●	●	T014
2005	Chevrolet	Others	ISU	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Powertrain	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Dash integration module	●	●	●	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112
2005	Pontiac	Bonneville	Head up display	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Rear integration module	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Driver door module	●	●	●	●	●	○	
2005	Pontiac	Bonneville	CD changer	●	●	●	●	○	○	

2005	Pontiac	Bonneville	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060
2005	Pontiac	Bonneville	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Pontiac	Bonneville	Digital radio receiver	●	●	●	●	○	●	T024
2005	Pontiac	Bonneville	Supplemental inflatable restraint	●	●	●	●	○	●	T113
2005	Pontiac	Bonneville	Remote function actuation	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Vehicle theft deterrent	●	●	●	●	○	●	T185
2005	Pontiac	Bonneville	Instrument panel cluster	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Climate control panel	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Instrument panel module	●	●	●	●	●	●	T138 T175
2005	Pontiac	Bonneville	DRP/ABS/TIM	●	●	○	●	●	●	T014
2005	Pontiac	Bonneville	Powertrain	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Dash integration module	●	●	●	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112
2005	Pontiac	Bonneville	Head up display	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Rear integration module	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Driver door module	●	●	●	●	●	○	
2005	Pontiac	Bonneville	CD changer	●	●	●	●	○	○	
2005	Pontiac	Bonneville	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060
2005	Pontiac	Bonneville	Memory seat module	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Pontiac	Bonneville	Digital radio receiver	●	●	●	●	○	●	T024
2005	Pontiac	Bonneville	Supplemental inflatable restraint	●	●	●	●	○	●	T113

2005	Pontiac	Bonneville	Remote function actuation	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Vehicle theft deterrent	●	●	●	●	○	●	T185
2005	Pontiac	Bonneville	Instrument panel cluster	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Climate control panel	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Instrument panel module	●	●	●	●	●	●	T138 T175
2005	Pontiac	Bonneville	DRP/ABS/TIM	●	●	○	●	●	●	T014
2005	Pontiac	Bonneville	Powertrain	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Dash integration module	●	●	○	○	○	●	T122 T172 T123 T127 T173 T174 T126 T112
2005	Pontiac	Bonneville	Head up display	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Rear integration module	●	●	●	●	●	●	T186
2005	Pontiac	Bonneville	Driver door module	●	●	●	●	●	○	
2005	Pontiac	Bonneville	CD changer	●	●	●	●	○	○	
2005	Pontiac	Bonneville	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060
2005	Pontiac	Bonneville	Memory seat module	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Pontiac	Bonneville	Digital radio receiver	●	●	●	●	○	●	T024
2005	Pontiac	Bonneville	Supplemental inflatable restraint	●	●	●	●	○	●	T113
2005	Pontiac	Bonneville	Remote function actuation	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Vehicle theft deterrent	●	●	●	●	○	●	T185
2005	Pontiac	Bonneville	Instrument panel cluster	●	●	●	●	●	○	
2005	Pontiac	Bonneville	Climate control panel	●	●	●	●	●	○	

2005	Pontiac	Bonneville	Instrument panel module	●	●	●	●	●	●	T138 T175
2005	Pontiac	Bonneville	DRP/ABS/TIM	●	●	○	●	●	●	T014
2005	Pontiac	Bonneville	Magna steer	●	●	○	●	○	○	
2005	Pontiac	G6	HVAC systems - manual	●	●	○	●	●	○	
2005	Pontiac	G6	Power steering system	●	●	○	●	●	●	T104
2005	Pontiac	G6	Antilock brake system	●	●	●	●	●	●	T014
2005	Pontiac	G6	Hydraulic brakes	●	●	○	●	○	○	
2005	Pontiac	G6	Engine controls	●	●	●	●	●	●	T001
2005	Pontiac	G6	Engine cooling	●	●	○	●	●	○	
2005	Pontiac	G6	Engine electrical	●	●	●	●	●	●	T023
2005	Pontiac	G6	Shift lock control	●	●	○	●	○	○	
2005	Pontiac	G6	Automatic transaxle	●	●	○	●	●	○	
2005	Pontiac	G6	Body rear end	●	●	○	●	●	○	
2005	Pontiac	G6	Cellular communication	●	●	●	●	●	●	T155
2005	Pontiac	G6	Cruise control	●	●	○	●	○	○	
2005	Pontiac	G6	Doors	●	●	○	●	●	○	
2005	Pontiac	G6	Entertainment	●	●	●	●	●	●	T024
2005	Pontiac	G6	Instrument panel	●	●	●	●	●	○	
2005	Pontiac	G6	Keyless entry	●	●	○	●	○	○	
2005	Pontiac	G6	Lighting systems	●	●	○	●	●	○	
2005	Pontiac	G6	Stationary windows	●	●	○	●	●	○	
2005	Pontiac	G6	Theft deterrent	●	●	●	●	●	○	
2005	Pontiac	G6	Wipers/washer systems	●	●	○	●	●	○	
2005	Pontiac	G6	Adjustable pedals	●	●	○	●	●	○	
2005	Pontiac	G6	Seat belts	●	●	●	●	●	●	T023
2005	Pontiac	G6	SIR	●	●	●	●	●	●	T023
2005	Pontiac	GTO	Powertrain	●	●	●	●	●	●	T001
2005	Pontiac	GTO	Supplemental inflatable restraint	●	●	○	○	○	○	
2005	Pontiac	GTO	ABS/TCS	●	●	●	●	●	●	T070
2005	Pontiac	Grand am	Powertrain	●	●	●	●	●	○	
2005	Pontiac	Grand am	Radio	●	●	○	●	●	●	T183
2005	Pontiac	Grand am	Digital radio receiver	●	●	●	●	○	●	T024

2005	Pontiac	Grand am	Supplemental inflatable restraint	●	●	●	●	○	○	
2005	Pontiac	Grand am	Body control module	●	●	●	●	●	●	T141
2005	Pontiac	Grand am	Remote function actuation	●	●	●	●	●	○	
2005	Pontiac	Grand am	Chassis	●	●	●	●	●	●	T014
2005	Pontiac	Grand prix	HVAC systems - manual	●	●	●	●	●	●	T007
2005	Pontiac	Grand prix	HVAC systems - automatic	●	●	●	●	●	●	T008
2005	Pontiac	Grand prix	Brakes	●	●	●	●	●	●	T014
2005	Pontiac	Grand prix	Engine controls	●	●	●	●	●	●	T007
2005	Pontiac	Grand prix	Engine cooling	●	●	●	●	●	●	T001
2005	Pontiac	Grand prix	Engine electrical	●	●	●	●	●	●	T023
2005	Pontiac	Grand prix	Shift lock control	●	●	●	●	●	●	T007
2005	Pontiac	Grand prix	Automatic transaxle	●	●	●	●	●	●	T007
2005	Pontiac	Grand prix	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Pontiac	Grand prix	Cruise control	●	●	●	●	●	●	T001
2005	Pontiac	Grand prix	Entertainment	●	●	●	●	●	●	T024
2005	Pontiac	Grand prix	Horns	●	●	●	●	●	●	T007
2005	Pontiac	Grand prix	Instrument panel	●	●	●	●	●	●	T001
2005	Pontiac	Grand prix	Keyless entry	●	●	●	●	●	●	T007
2005	Pontiac	Grand prix	Lighting systems	●	●	●	●	●	●	T007
2005	Pontiac	Grand prix	Navigation systems	●	●	●	●	○	●	T033
2005	Pontiac	Grand prix	Seats	●	●	●	●	●	●	T007
2005	Pontiac	Grand prix	Stationary windows	●	●	●	●	●	●	T007
2005	Pontiac	Grand prix	Theft deterrent	●	●	●	●	●	●	T007
2005	Pontiac	Grand prix	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Pontiac	Grand prix	Seat belts	●	●	●	●	○	●	T023
2005	Pontiac	Grand prix	SIR	●	●	●	●	○	●	T023
2005	Pontiac	Matiz	Powertrain	●	●	●	●	●	○	
2005	Pontiac	Matiz	Chassis	●	●	●	●	●	○	
2005	Pontiac	Pursuit	HVAC systems - manual	●	●	●	●	●	●	T001
2005	Pontiac	Pursuit	Power steering system	●	●	○	●	○	○	
2005	Pontiac	Pursuit	Antilock brake system	●	●	●	●	●	●	T014
2005	Pontiac	Pursuit	Park brake	●	●	●	●	●	●	T023

2005	Pontiac	Pursuit	Engine controls	●	●	●	●	●	●	T001
2005	Pontiac	Pursuit	Engine cooling	●	●	●	●	●	●	T001
2005	Pontiac	Pursuit	Engine electrical	●	●	●	●	●	●	T023
2005	Pontiac	Pursuit	Shift lock control	●	●	●	●	●	●	T023
2005	Pontiac	Pursuit	Automatic transaxle	●	●	●	●	●	○	
2005	Pontiac	Pursuit	Body rear end	●	●	●	●	●	●	T023
2005	Pontiac	Pursuit	Cellular communication	●	●	●	●	●	●	T155 T093
2005	Pontiac	Pursuit	Cruise control	●	●	●	●	●	●	T001
2005	Pontiac	Pursuit	Entertainment	●	●	●	●	●	●	T024
2005	Pontiac	Pursuit	Horns	●	●	●	●	●	●	T023
2005	Pontiac	Pursuit	Instrument panel	●	●	●	●	●	●	T001
2005	Pontiac	Pursuit	Keyless entry	●	●	●	●	●	●	T023
2005	Pontiac	Pursuit	Lighting systems	●	●	●	●	●	●	T023
2005	Pontiac	Pursuit	Body control module	●	●	●	●	●	●	T023
2005	Pontiac	Pursuit	Stationary windows	●	●	●	●	●	●	T023
2005	Pontiac	Pursuit	Wipers/washer systems	●	●	●	●	●	●	T023
2005	Pontiac	Pursuit	Theft deterrent	●	●	●	●	●	●	T023
2005	Pontiac	Pursuit	Seat belts	●	●	●	●	●	●	T023
2005	Pontiac	Pursuit	SIR	●	●	●	●	○	●	T023
2005	Pontiac	Sunfire	Powertrain	●	●	●	●	●	○	
2005	Pontiac	Sunfire	Onstar	●	●	●	●	●	●	T155 T093
2005	Pontiac	Sunfire	Radio	●	●	○	●	●	●	T183
2005	Pontiac	Sunfire	Supplemental inflatable restraint	●	●	●	●	○	●	T023
2005	Pontiac	Sunfire	Digital radio receiver	●	●	●	●	○	●	T024
2005	Pontiac	Sunfire	Body control module	●	●	●	●	●	●	T141
2005	Pontiac	Sunfire	Chassis	●	●	●	●	●	●	T014
2005	Pontiac	Vibe - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Pontiac	Vibe - AWD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Pontiac	Vibe - AWD	Cruise control	●	●	○	●	●	●	T080
2005	Pontiac	Vibe - AWD	Chassis	●	●	○	●	●	●	T105
2005	Pontiac	Vibe - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Pontiac	Vibe - FWD	Digital radio receiver	●	●	●	●	○	●	T024

2005	Pontiac	Vibe - FWD	Cruise control	●	●	○	●	●	●	T080
2005	Pontiac	Vibe - FWD	Chassis	●	●	○	●	●	●	T105
2005	Pontiac	Wave	Powertrain	●	●	●	●	●	●	T001
2005	Pontiac	Wave	Chassis	●	●	●	●	●	●	T014
2005	Saturn	ION	Powertrain	●	●	●	●	●	●	T001
2005	Saturn	ION	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Saturn	ION	Digital radio receiver	●	●	●	●	○	●	T024
2005	Saturn	ION	Radio	●	●	○	●	●	●	T032 T059
2005	Saturn	ION	Supplemental inflatable restraint	●	●	●	●	○	●	T023
2005	Saturn	ION	Instrument panel cluster	●	●	●	●	●	○	
2005	Saturn	ION	Body control module	●	●	●	●	●	●	T141 T142 T143
2005	Saturn	ION	Antilock brake system	●	●	○	●	●	●	T014
2005	Saturn	L300/LW300	Powertrain	●	●	●	●	●	○	
2005	Saturn	L300/LW300	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Saturn	L300/LW300	Supplemental inflatable restraint	●	●	●	●	○	○	
2005	Saturn	L300/LW300	Auto. HVAC	●	●	●	●	●	○	
2005	Saturn	L300/LW300	Body control module	●	●	●	●	●	●	T141 T148 T142 T143
2005	Saturn	L300/LW300	Chassis	●	●	○	●	●	○	
2005	Buick	Rainier	Powertrain	●	●	●	●	●	●	T001
2005	Buick	Rainier	Digital radio receiver	●	●	●	●	○	●	T024
2005	Buick	Rainier	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Buick	Rainier	Radio	●	●	●	●	○	○	
2005	Buick	Rainier	Disc player and video display	●	●	●	○	○	○	
2005	Buick	Rainier	Passenger presence system	●	●	○	○	○	●	T020
2005	Buick	Rainier	Instrument panel cluster	●	●	●	●	●	○	
2005	Buick	Rainier	Driver door module	●	●	●	●	●	○	

2005	Buick	Rainier	Driver seat module	●	●	●	●	●	○	
2005	Buick	Rainier	Heating and air conditioning	●	●	●	●	●	○	
2005	Buick	Rainier	Lift gate module	●	●	●	●	●	○	
2005	Buick	Rainier	Passenger door module	●	●	●	●	●	○	
2005	Buick	Rainier	Rear seat audio	●	●	●	●	○	○	
2005	Buick	Rainier	Body control module	●	●	●	●	●	●	T058
2005	Buick	Rainier	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	Buick	Rainier	Navigation radio	●	●	●	●	●	●	T033
2005	Buick	Rainier	ABS	●	●	●	●	●	○	
2005	Buick	Rainier	4WAL 3 sensor	●	●	●	●	●	●	T001
2005	Buick	Rainier - 2WD	Powertrain	●	●	●	●	●	●	T001
2005	Buick	Rainier - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Buick	Rainier - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Buick	Rainier - 2WD	Radio	●	●	●	●	○	○	
2005	Buick	Rainier - 2WD	Disc player and video display	●	●	●	○	○	○	
2005	Buick	Rainier - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2005	Buick	Rainier - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2005	Buick	Rainier - 2WD	Driver door module	●	●	●	●	●	○	
2005	Buick	Rainier - 2WD	Driver seat module	●	●	●	●	●	○	
2005	Buick	Rainier - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2005	Buick	Rainier - 2WD	Lift gate module	●	●	●	●	●	○	
2005	Buick	Rainier - 2WD	Passenger door module	●	●	●	●	●	○	
2005	Buick	Rainier - 2WD	Rear seat audio	●	●	●	●	○	○	
2005	Buick	Rainier - 2WD	Body control module	●	●	●	●	●	●	T058
2005	Buick	Rainier - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	Buick	Rainier - 2WD	Navigation radio	●	●	●	●	●	●	T033
2005	Buick	Rainier - 2WD	ABS	●	●	●	●	●	○	

2005	Buick	Rainier - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T001
2005	Buick	Rendezvous - AWD	Powertrain	●	●	●	●	●	○	
2005	Buick	Rendezvous - AWD	Disc player and video display	●	●	●	○	○	○	
2005	Buick	Rendezvous - AWD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Buick	Rendezvous - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Buick	Rendezvous - AWD	Radio	○	○	○	○	○	●	T032
2005	Buick	Rendezvous - AWD	Heating and air conditioning	●	●	○	●	●	○	
2005	Buick	Rendezvous - AWD	Vehicle theft deterrent	●	●	○	●	○	○	
2005	Buick	Rendezvous - AWD	Passenger presence system	●	●	○	○	○	●	T020
2005	Buick	Rendezvous - AWD	Head up display	●	●	○	●	○	○	
2005	Buick	Rendezvous - AWD	Memory seat module	●	●	○	●	●	○	
2005	Buick	Rendezvous - AWD	Instrument panel cluster	●	●	○	●	●	○	
2005	Buick	Rendezvous - AWD	Body control module	●	●	●	●	●	●	T068 T023 T136 T122
2005	Buick	Rendezvous - AWD	Navigation radio	●	●	●	●	●	●	T033
2005	Buick	Rendezvous - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2005	Buick	Rendezvous - AWD	Chassis	●	●	●	●	●	●	T014
2005	Buick	Rendezvous - FWD	Powertrain	●	●	●	●	●	○	
2005	Buick	Rendezvous - FWD	Disc player and video display	●	●	●	○	○	○	

2005	Buick	Rendezvous - FWD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Buick	Rendezvous - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Buick	Rendezvous - FWD	Radio	○	○	○	○	○	●	T032
2005	Buick	Rendezvous - FWD	Heating and air conditioning	●	●	○	●	●	○	
2005	Buick	Rendezvous - FWD	Vehicle theft deterrent	●	●	○	●	○	○	
2005	Buick	Rendezvous - FWD	Passenger presence system	●	●	○	○	○	●	T020
2005	Buick	Rendezvous - FWD	Head up display	●	●	○	●	○	○	
2005	Buick	Rendezvous - FWD	Memory seat module	●	●	○	●	●	○	
2005	Buick	Rendezvous - FWD	Instrument panel cluster	●	●	○	●	●	○	
2005	Buick	Rendezvous - FWD	Body control module	●	●	●	●	●	●	T068 T023 T136 T122
2005	Buick	Rendezvous - FWD	Navigation radio	●	●	●	●	●	●	T033
2005	Buick	Rendezvous - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2005	Buick	Rendezvous - FWD	Chassis	●	●	●	●	●	●	T014
2005	Buick	Terraza	HVAC	●	●	●	●	●	●	T007
2005	Buick	Terraza	Brakes	●	●	○	●	●	●	T014
2005	Buick	Terraza	Engine controls	●	●	○	●	●	○	
2005	Buick	Terraza	Engine cooling	●	●	○	●	●	○	
2005	Buick	Terraza	Engine electrical	●	●	●	●	●	●	T007
2005	Buick	Terraza	Shift lock control	●	●	●	●	●	●	T007
2005	Buick	Terraza	Automatic transaxle	●	●	○	●	●	○	
2005	Buick	Terraza	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Buick	Terraza	Cruise control	●	●	○	●	●	○	

2005	Buick	Terraza	Doors	●	●	●	●	●	○	
2005	Buick	Terraza	Entertainment	●	●	●	●	●	●	T024
2005	Buick	Terraza	Horns	●	●	●	●	●	●	T007
2005	Buick	Terraza	Instrument panel	●	●	●	●	●	●	T007
2005	Buick	Terraza	Keyless entry	●	●	●	●	●	●	T007
2005	Buick	Terraza	Lighting systems	●	●	●	●	●	●	T007
2005	Buick	Terraza	Navigation systems	●	●	●	●	●	●	T033
2005	Buick	Terraza	Seats	●	●	●	●	●	○	
2005	Buick	Terraza	Stationary windows	●	●	●	●	●	○	
2005	Buick	Terraza	Theft deterrent	●	●	●	●	●	●	T007
2005	Buick	Terraza	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Buick	Terraza	Seat belts	●	●	●	●	●	●	T023
2005	Buick	Terraza	SIR	●	●	●	●	●	●	T020
2005	Buick	Terraza - 4WD	HVAC	●	●	●	●	●	●	T007
2005	Buick	Terraza - 4WD	Brakes	●	●	○	●	●	●	T014
2005	Buick	Terraza - 4WD	Engine controls	●	●	○	●	●	○	
2005	Buick	Terraza - 4WD	Engine cooling	●	●	○	●	●	○	
2005	Buick	Terraza - 4WD	Engine electrical	●	●	●	●	●	●	T007
2005	Buick	Terraza - 4WD	Shift lock control	●	●	●	●	●	●	T007
2005	Buick	Terraza - 4WD	Automatic transaxle	●	●	○	●	●	○	
2005	Buick	Terraza - 4WD	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Buick	Terraza - 4WD	Cruise control	●	●	○	●	●	○	
2005	Buick	Terraza - 4WD	Doors	●	●	●	●	●	○	
2005	Buick	Terraza - 4WD	Entertainment	●	●	●	●	●	●	T024
2005	Buick	Terraza - 4WD	Horns	●	●	●	●	●	●	T007
2005	Buick	Terraza - 4WD	Instrument panel	●	●	●	●	●	●	T007
2005	Buick	Terraza - 4WD	Keyless entry	●	●	●	●	●	●	T007
2005	Buick	Terraza - 4WD	Lighting systems	●	●	●	●	●	●	T007
2005	Buick	Terraza - 4WD	Navigation systems	●	●	●	●	●	●	T033
2005	Buick	Terraza - 4WD	Seats	●	●	●	●	●	○	
2005	Buick	Terraza - 4WD	Stationary windows	●	●	●	●	●	○	
2005	Buick	Terraza - 4WD	Theft deterrent	●	●	●	●	●	●	T007
2005	Buick	Terraza - 4WD	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Buick	Terraza - 4WD	Seat belts	●	●	●	●	●	●	T023
2005	Buick	Terraza - 4WD	SIR	●	●	●	●	●	●	T020

2005	Buick	Terraza ext.	HVAC	●	●	●	●	●	●	T007
2005	Buick	Terraza ext.	Brakes	●	●	○	●	●	●	T014
2005	Buick	Terraza ext.	Engine controls	●	●	○	●	●	○	
2005	Buick	Terraza ext.	Engine cooling	●	●	○	●	●	○	
2005	Buick	Terraza ext.	Engine electrical	●	●	●	●	●	●	T007
2005	Buick	Terraza ext.	Shift lock control	●	●	●	●	●	●	T007
2005	Buick	Terraza ext.	Automatic transaxle	●	●	○	●	●	○	
2005	Buick	Terraza ext.	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Buick	Terraza ext.	Cruise control	●	●	○	●	●	○	
2005	Buick	Terraza ext.	Doors	●	●	●	●	●	○	
2005	Buick	Terraza ext.	Entertainment	●	●	●	●	●	●	T024
2005	Buick	Terraza ext.	Horns	●	●	●	●	●	●	T007
2005	Buick	Terraza ext.	Instrument panel	●	●	●	●	●	●	T007
2005	Buick	Terraza ext.	Keyless entry	●	●	●	●	●	●	T007
2005	Buick	Terraza ext.	Lighting systems	●	●	●	●	●	●	T007
2005	Buick	Terraza ext.	Navigation systems	●	●	●	●	●	●	T033
2005	Buick	Terraza ext.	Seats	●	●	●	●	●	○	
2005	Buick	Terraza ext.	Stationary windows	●	●	●	●	●	○	
2005	Buick	Terraza ext.	Theft deterrent	●	●	●	●	●	●	T007
2005	Buick	Terraza ext.	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Buick	Terraza ext.	Seat belts	●	●	●	●	●	●	T023
2005	Buick	Terraza ext.	SIR	●	●	●	●	●	●	T020
2005	Cadillac	Escalade - 2WD	Powertrain	●	●	●	●	●	○	
2005	Cadillac	Escalade - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Cadillac	Escalade - 2WD	CD changer	●	●	●	○	○	○	
2005	Cadillac	Escalade - 2WD	Chime	●	●	●	●	●	○	
2005	Cadillac	Escalade - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Cadillac	Escalade - 2WD	Radio	●	●	●	●	○	○	
2005	Cadillac	Escalade - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	Cadillac	Escalade - 2WD	Disc player and video display	●	●	●	○	○	○	
2005	Cadillac	Escalade - 2WD	Passenger presence system	●	●	○	○	○	●	T020

2005	Cadillac	Escalade - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2005	Cadillac	Escalade - 2WD	Driver door module	●	●	●	●	●	○	
2005	Cadillac	Escalade - 2WD	Passenger door module	●	●	●	●	●	○	
2005	Cadillac	Escalade - 2WD	Body control module	●	●	●	●	●	○	
2005	Cadillac	Escalade - 2WD	Driver seat module	●	●	●	●	●	○	
2005	Cadillac	Escalade - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2005	Cadillac	Escalade - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2005	Cadillac	Escalade - 2WD	Rear HVAC	●	●	●	●	○	○	
2005	Cadillac	Escalade - 2WD	Rear seat audio	●	●	●	●	○	○	
2005	Cadillac	Escalade - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Cadillac	Escalade - 2WD	Generator battery control module	●	●	●	●	●	○	
2005	Cadillac	Escalade - 2WD	Remote function actuation	●	●	●	●	●	●	T139
2005	Cadillac	Escalade - 2WD	Navigation radio	●	●	●	●	●	●	T033
2005	Cadillac	Escalade - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Cadillac	Escalade - 2WD	ABS	●	●	●	●	●	○	
2005	Cadillac	Escalade - 2WD	Rear wheel steering	●	●	●	●	●	○	
2005	Cadillac	Escalade - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2005	Cadillac	Escalade - 2WD	Tire pressure monitor	●	●	●	●	●	●	T022
2005	Cadillac	Escalade - AWD	Powertrain	●	●	●	●	●	○	
2005	Cadillac	Escalade - AWD	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Cadillac	Escalade - AWD	CD changer	●	●	●	○	○	○	
2005	Cadillac	Escalade - AWD	Chime	●	●	●	●	●	○	
2005	Cadillac	Escalade - AWD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Cadillac	Escalade - AWD	Radio	●	●	●	●	○	○	
2005	Cadillac	Escalade - AWD	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	Cadillac	Escalade - AWD	Disc player and video display	●	●	●	○	○	○	

2005	Cadillac	Escalade - AWD	Passenger presence system	●	●	○	○	○	●	T020
2005	Cadillac	Escalade - AWD	Instrument panel cluster	●	●	●	●	●	○	
2005	Cadillac	Escalade - AWD	Driver door module	●	●	●	●	●	○	
2005	Cadillac	Escalade - AWD	Passenger door module	●	●	●	●	●	○	
2005	Cadillac	Escalade - AWD	Body control module	●	●	●	●	●	○	
2005	Cadillac	Escalade - AWD	Driver seat module	●	●	●	●	●	○	
2005	Cadillac	Escalade - AWD	Heating and air conditioning	●	●	●	●	●	○	
2005	Cadillac	Escalade - AWD	Rear aux. climate module	●	●	●	●	●	○	
2005	Cadillac	Escalade - AWD	Rear HVAC	●	●	●	●	○	○	
2005	Cadillac	Escalade - AWD	Rear seat audio	●	●	●	●	○	○	
2005	Cadillac	Escalade - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Cadillac	Escalade - AWD	Generator battery control module	●	●	●	●	●	○	
2005	Cadillac	Escalade - AWD	Remote function actuation	●	●	●	●	●	●	T139
2005	Cadillac	Escalade - AWD	Navigation radio	●	●	●	●	●	●	T033
2005	Cadillac	Escalade - AWD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Cadillac	Escalade - AWD	ABS	●	●	●	●	●	○	
2005	Cadillac	Escalade - AWD	Rear wheel steering	●	●	●	●	●	○	
2005	Cadillac	Escalade - AWD	ESC (if equipped)	●	●	●	●	●	●	T156
2005	Cadillac	Escalade - AWD	Tire pressure monitor	●	●	●	●	●	●	T022
2005	Cadillac	Escalade ESV	Powertrain	●	●	●	●	●	○	
2005	Cadillac	Escalade ESV	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Cadillac	Escalade ESV	CD changer	●	●	●	○	○	○	
2005	Cadillac	Escalade ESV	Chime	●	●	●	●	●	○	
2005	Cadillac	Escalade ESV	Digital radio receiver	●	●	●	●	○	●	T024
2005	Cadillac	Escalade ESV	Radio	●	●	●	●	○	○	
2005	Cadillac	Escalade ESV	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147

2005	Cadillac	Escalade ESV	Disc player and video display	●	●	●	○	○	○	
2005	Cadillac	Escalade ESV	Passenger presence system	●	●	○	○	○	●	T020
2005	Cadillac	Escalade ESV	Instrument panel cluster	●	●	●	●	●	○	
2005	Cadillac	Escalade ESV	Driver door module	●	●	●	●	●	○	
2005	Cadillac	Escalade ESV	Passenger door module	●	●	●	●	●	○	
2005	Cadillac	Escalade ESV	Body control module	●	●	●	●	●	○	
2005	Cadillac	Escalade ESV	Driver seat module	●	●	●	●	●	○	
2005	Cadillac	Escalade ESV	Heating and air conditioning	●	●	●	●	●	○	
2005	Cadillac	Escalade ESV	Rear aux. climate module	●	●	●	●	●	○	
2005	Cadillac	Escalade ESV	Rear HVAC	●	●	●	●	○	○	
2005	Cadillac	Escalade ESV	Rear seat audio	●	●	●	●	○	○	
2005	Cadillac	Escalade ESV	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Cadillac	Escalade ESV	Generator battery control module	●	●	●	●	●	○	
2005	Cadillac	Escalade ESV	Remote function actuation	●	●	●	●	●	●	T139
2005	Cadillac	Escalade ESV	Navigation radio	●	●	●	●	●	●	T033
2005	Cadillac	Escalade ESV	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Cadillac	Escalade ESV	ABS	●	●	●	●	●	○	
2005	Cadillac	Escalade ESV	Rear wheel steering	●	●	●	●	●	○	
2005	Cadillac	Escalade ESV	ESC (if equipped)	●	●	●	●	●	●	T156
2005	Cadillac	Escalade ESV	Tire pressure monitor	●	●	●	●	●	●	T022
2005	Cadillac	Escalade EXT	Powertrain	●	●	●	●	●	○	
2005	Cadillac	Escalade EXT	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Cadillac	Escalade EXT	CD changer	●	●	●	○	○	○	
2005	Cadillac	Escalade EXT	Chime	●	●	●	●	●	○	
2005	Cadillac	Escalade EXT	Digital radio receiver	●	●	●	●	○	●	T024
2005	Cadillac	Escalade EXT	Radio	●	●	●	●	○	○	

2005	Cadillac	Escalade EXT	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	Cadillac	Escalade EXT	Disc player and video display	●	●	●	○	○	○	
2005	Cadillac	Escalade EXT	Passenger presence system	●	●	○	○	○	●	T020
2005	Cadillac	Escalade EXT	Instrument panel cluster	●	●	●	●	●	○	
2005	Cadillac	Escalade EXT	Driver door module	●	●	●	●	●	○	
2005	Cadillac	Escalade EXT	Passenger door module	●	●	●	●	●	○	
2005	Cadillac	Escalade EXT	Body control module	●	●	●	●	●	○	
2005	Cadillac	Escalade EXT	Driver seat module	●	●	●	●	●	○	
2005	Cadillac	Escalade EXT	Heating and air conditioning	●	●	●	●	●	○	
2005	Cadillac	Escalade EXT	Rear aux. climate module	●	●	●	●	●	○	
2005	Cadillac	Escalade EXT	Rear HVAC	●	●	●	●	○	○	
2005	Cadillac	Escalade EXT	Rear seat audio	●	●	●	●	○	○	
2005	Cadillac	Escalade EXT	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Cadillac	Escalade EXT	Generator battery control module	●	●	●	●	●	○	
2005	Cadillac	Escalade EXT	Remote function actuation	●	●	●	●	●	●	T139
2005	Cadillac	Escalade EXT	Navigation radio	●	●	●	●	●	●	T033
2005	Cadillac	Escalade EXT	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Cadillac	Escalade EXT	ABS	●	●	●	●	●	○	
2005	Cadillac	Escalade EXT	Rear wheel steering	●	●	●	●	●	○	
2005	Cadillac	Escalade EXT	ESC (if equipped)	●	●	●	●	●	●	T156
2005	Cadillac	Escalade EXT	Tire pressure monitor	●	●	●	●	●	●	T022
2005	Cadillac	SRX	Powertrain	●	●	●	●	●	●	T001
2005	Cadillac	SRX	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092

2005	Cadillac	SRX	Disc player and video display	●	●	●	○	○	○	
2005	Cadillac	SRX	Digital radio receiver	●	●	●	●	○	●	T024
2005	Cadillac	SRX	Vehicle comm. interface module	●	●	●	●	●	●	T155 T093
2005	Cadillac	SRX	Radio	●	●	●	●	○	●	T157 T158 T159 T094 T095 T160 T161 T162 T163 T116 T033 T033
2005	Cadillac	SRX	TV antenna module	●	●	●	●	●	○	
2005	Cadillac	SRX	Amplifier (delco)	●	●	●	●	●	○	
2005	Cadillac	SRX	Amplifier (bose)	●	●	●	●	●	○	
2005	Cadillac	SRX	CD changer	○	○	●	○	○	○	
2005	Cadillac	SRX	Driver door module	●	●	●	●	●	●	T117 T117 T117 T117
2005	Cadillac	SRX	Driver door switch	●	●	●	●	○	○	
2005	Cadillac	SRX	Left rear door module	●	●	●	●	●	○	
2005	Cadillac	SRX	Passenger door module	●	●	●	●	●	●	T116
2005	Cadillac	SRX	Right rear door module	●	●	●	●	●	○	
2005	Cadillac	SRX	Dash integration module	●	●	●	●	●	●	T122 T123 T124 T126 T127 T118 T128 T119 T129 T120 T130 T131 T132 T133 T134 T135 T165 T136
2005	Cadillac	SRX	Personalization	●	●	●	●	●	○	
2005	Cadillac	SRX	Remote function actuation	●	●	●	●	●	○	
2005	Cadillac	SRX	Vehicle theft deterrent	●	●	●	●	○	○	
2005	Cadillac	SRX	Memory seat module	●	●	●	●	●	○	
2005	Cadillac	SRX	Rear seat module	●	●	●	●	●	○	
2005	Cadillac	SRX	Instrument panel cluster	●	●	●	●	●	○	
2005	Cadillac	SRX	Climate control panel	●	●	●	●	●	●	T112 T113
2005	Cadillac	SRX	Tire pressure monitor	●	●	○	●	●	●	T137
2005	Cadillac	SRX	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014

2005	Cadillac	SRX	Electronic suspension control	●	●	●	●	●	○	
2005	Cadillac	Hearse	Powertrain	●	●	●	●	●	○	
2005	Cadillac	Hearse	Driver door module	●	●	●	●	●	○	
2005	Cadillac	Hearse	Driver door switch	●	●	●	●	○	○	
2005	Cadillac	Hearse	Passenger door module	●	●	●	●	●	○	
2005	Cadillac	Hearse	Rear integration module	○	○	○	●	○	○	
2005	Cadillac	Hearse	Dash integration module	●	●	○	●	●	●	T122 T123 T127 T136
2005	Cadillac	Hearse	Remote function actuation	●	●	●	●	●	○	
2005	Cadillac	Hearse	Digital radio receiver	●	●	●	●	○	●	T024
2005	Cadillac	Hearse	Vehicle theft deterrent	●	●	○	●	○	○	
2005	Cadillac	Hearse	Amplifier (delco)	●	●	●	●	●	●	T179 T086 T087 T033
2005	Cadillac	Hearse	Instrument panel module	●	●	○	●	●	●	T138 T175
2005	Cadillac	Hearse	Instrument panel cluster	●	●	○	●	●	●	T159 T158 T181 T094 T122
2005	Cadillac	Hearse	Tire pressure monitor	●	●	○	●	○	●	T022 T188 T189
2005	Cadillac	Hearse	DRP/ABS/TCS	●	●	○	●	●	○	
2005	Cadillac	Limousine	Powertrain	●	●	●	●	●	○	
2005	Cadillac	Limousine	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Cadillac	Limousine	Driver door module	●	●	●	●	●	○	
2005	Cadillac	Limousine	Driver door switch	●	●	●	●	○	○	
2005	Cadillac	Limousine	Left mid door module	●	●	●	●	●	○	
2005	Cadillac	Limousine	Left rear door module	●	●	●	●	●	○	
2005	Cadillac	Limousine	Passenger door module	●	●	●	●	●	○	
2005	Cadillac	Limousine	Right mid door module	●	●	●	●	●	○	
2005	Cadillac	Limousine	Right rear door module	●	●	●	●	●	○	
2005	Cadillac	Limousine	Rear integration module	○	○	○	●	●	○	

2005	Cadillac	Limousine	Dash integration module	●	●	○	●	●	●	T122 T123 T127 T136
2005	Cadillac	Limousine	Remote function actuation	●	●	●	●	●	○	
2005	Cadillac	Limousine	Digital radio receiver	●	●	●	●	○	●	T024
2005	Cadillac	Limousine	Vehicle theft deterrent	●	●	○	●	○	○	
2005	Cadillac	Limousine	Amplifier (delco)	●	●	○	●	○	○	
2005	Cadillac	Limousine	Navigation radio	●	●	●	●	●	●	T166
2005	Cadillac	Limousine	Rear climate control panel	●	●	○	●	●	○	
2005	Cadillac	Limousine	Instrument panel module	●	●	○	●	●	●	T138 T175
2005	Cadillac	Limousine	Instrument panel cluster	●	●	○	●	●	●	T159 T158 T181 T094 T122
2005	Cadillac	Limousine	Tire pressure monitor	●	●	○	●	○	●	T022 T188 T189
2005	Cadillac	Limousine	DRP/ABS/TCS	●	●	○	●	●	○	
2005	Chevrolet	Astro - 2WD	Powertrain	●	●	●	●	●	●	T146
2005	Chevrolet	Astro - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2005	Chevrolet	Astro - 2WD	Body control module	●	●	○	●	●	○	
2005	Chevrolet	Astro - 2WD	Supplemental inflatable restraint	●	●	●	●	○	○	
2005	Chevrolet	Astro - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2005	Chevrolet	Astro - 2WD	Powertrain	●	●	●	●	●	●	T146
2005	Chevrolet	Astro - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2005	Chevrolet	Astro - 2WD	Body control module	●	●	○	●	●	○	
2005	Chevrolet	Astro - 2WD	Supplemental inflatable restraint	●	●	●	●	○	○	
2005	Chevrolet	Astro - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2005	Chevrolet	Astro - 4WD	Powertrain	●	●	●	●	●	●	T146
2005	Chevrolet	Astro - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2005	Chevrolet	Astro - 4WD	Body control module	●	●	○	●	●	○	

2005	Chevrolet	Astro - 4WD	Supplemental inflatable restraint	●	●	●	●	○	○	
2005	Chevrolet	Astro - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2005	Chevrolet	Astro - 4WD	Powertrain	●	●	●	●	●	●	T146
2005	Chevrolet	Astro - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2005	Chevrolet	Astro - 4WD	Body control module	●	●	○	●	●	○	
2005	Chevrolet	Astro - 4WD	Supplemental inflatable restraint	●	●	●	●	○	○	
2005	Chevrolet	Astro - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2005	Chevrolet	Avalanche - 2WD	Powertrain	●	●	●	●	●	●	T169
2005	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Chevrolet	Avalanche - 2WD	CD changer	●	●	●	○	○	○	
2005	Chevrolet	Avalanche - 2WD	Chime	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Avalanche - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Avalanche - 2WD	Radio	●	●	●	●	○	○	
2005	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	Chevrolet	Avalanche - 2WD	Disc player and video display	●	●	●	○	○	○	
2005	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2005	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 2WD	Driver door module	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 2WD	Passenger door module	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 2WD	Driver seat module	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 2WD	Rear HVAC	●	●	●	●	○	○	

2005	Chevrolet	Avalanche - 2WD	Rear seat audio	●	●	●	●	○	○	
2005	Chevrolet	Avalanche - 2WD	Generator battery control module	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 2WD	Vehicle theft deterrent	●	●	●	●	●	●	T139
2005	Chevrolet	Avalanche - 2WD	Navigation radio	●	●	●	●	●	●	T033
2005	Chevrolet	Avalanche - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	Avalanche - 2WD	ABS	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 2WD	Rear wheel steering	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2005	Chevrolet	Avalanche - 2WD	Tire pressure monitor	●	●	●	●	●	●	T022
2005	Chevrolet	Avalanche - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2005	Chevrolet	Avalanche - 4WD	Powertrain	●	●	●	●	●	●	T169
2005	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Chevrolet	Avalanche - 4WD	CD changer	●	●	●	○	○	○	
2005	Chevrolet	Avalanche - 4WD	Chime	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Avalanche - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Avalanche - 4WD	Radio	●	●	●	●	○	○	
2005	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	Chevrolet	Avalanche - 4WD	Disc player and video display	●	●	●	○	○	○	
2005	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2005	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 4WD	Driver door module	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 4WD	Passenger door module	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 4WD	Driver seat module	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 4WD	Heating and air conditioning	●	●	●	●	●	○	

2005	Chevrolet	Avalanche - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 4WD	Rear HVAC	●	●	●	●	○	○	
2005	Chevrolet	Avalanche - 4WD	Rear seat audio	●	●	●	●	○	○	
2005	Chevrolet	Avalanche - 4WD	Generator battery control module	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 4WD	Vehicle theft deterrent	●	●	●	●	●	●	T139
2005	Chevrolet	Avalanche - 4WD	Navigation radio	●	●	●	●	●	●	T033
2005	Chevrolet	Avalanche - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	Avalanche - 4WD	ABS	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 4WD	Rear wheel steering	●	●	●	●	●	○	
2005	Chevrolet	Avalanche - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2005	Chevrolet	Avalanche - 4WD	Tire pressure monitor	●	●	●	●	●	●	T022
2005	Chevrolet	Avalanche - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2005	Chevrolet	Blazer - 2WD	Powertrain	●	●	●	●	●	●	T146
2005	Chevrolet	Blazer - 2WD	Radio	●	●	●	●	○	○	
2005	Chevrolet	Blazer - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	Chevrolet	Blazer - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2005	Chevrolet	Blazer - 2WD	Body control module	●	●	○	●	●	○	
2005	Chevrolet	Blazer - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	Blazer - 2WD	Memory seat module	●	●	●	●	●	●	T039
2005	Chevrolet	Blazer - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	Blazer - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2005	Chevrolet	Blazer - 2WD	Powertrain	●	●	●	●	●	●	T146
2005	Chevrolet	Blazer - 2WD	Radio	●	●	●	●	○	○	
2005	Chevrolet	Blazer - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	Chevrolet	Blazer - 2WD	Instrument panel cluster	●	●	○	●	●	○	

2005	Chevrolet	Blazer - 2WD	Body control module	●	●	○	●	●	○	
2005	Chevrolet	Blazer - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	Blazer - 2WD	Memory seat module	●	●	●	●	●	●	T039
2005	Chevrolet	Blazer - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	Blazer - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2005	Chevrolet	Blazer - 4WD	Powertrain	●	●	●	●	●	●	T146
2005	Chevrolet	Blazer - 4WD	Radio	●	●	●	●	○	○	
2005	Chevrolet	Blazer - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	Chevrolet	Blazer - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2005	Chevrolet	Blazer - 4WD	Body control module	●	●	○	●	●	○	
2005	Chevrolet	Blazer - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	Blazer - 4WD	Memory seat module	●	●	●	●	●	●	T039
2005	Chevrolet	Blazer - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	Blazer - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2005	Chevrolet	Blazer - 4WD	Powertrain	●	●	●	●	●	●	T146
2005	Chevrolet	Blazer - 4WD	Radio	●	●	●	●	○	○	
2005	Chevrolet	Blazer - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	Chevrolet	Blazer - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2005	Chevrolet	Blazer - 4WD	Body control module	●	●	○	●	●	○	
2005	Chevrolet	Blazer - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	Blazer - 4WD	Memory seat module	●	●	●	●	●	●	T039
2005	Chevrolet	Blazer - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	Blazer - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2005	Chevrolet	C cab/chassis HD (GMT 400)	Powertrain	●	●	●	●	●	●	T169

2005	Chevrolet	C cab/chassis HD (GMT 400)	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Chevrolet	C cab/chassis HD (GMT 400)	CD changer	●	●	●	○	○	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Chime	●	●	●	●	●	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	C cab/chassis HD (GMT 400)	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	C cab/chassis HD (GMT 400)	Radio	●	●	●	●	○	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	Chevrolet	C cab/chassis HD (GMT 400)	Disc player and video display	●	●	●	○	○	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Passenger presence system	●	●	○	○	○	●	T020
2005	Chevrolet	C cab/chassis HD (GMT 400)	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Driver door module	●	●	●	●	●	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Passenger door module	●	●	●	●	●	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Body control module	●	●	●	●	●	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Driver seat module	●	●	●	●	●	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Rear aux. climate module	●	●	●	●	●	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Rear HVAC	●	●	●	●	○	○	

2005	Chevrolet	C cab/chassis HD (GMT 400)	Rear seat audio	●	●	●	●	○	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Generator battery control module	●	●	●	●	●	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Vehicle theft deterrent	●	●	●	●	●	●	T139
2005	Chevrolet	C cab/chassis HD (GMT 400)	Navigation radio	●	●	●	●	●	●	T033
2005	Chevrolet	C cab/chassis HD (GMT 400)	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	ABS	●	●	●	●	●	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	Rear wheel steering	●	●	●	●	●	○	
2005	Chevrolet	C cab/chassis HD (GMT 400)	ESC (if equipped)	●	●	●	●	●	●	T156
2005	Chevrolet	C cab/chassis HD (GMT 400)	Tire pressure monitor	●	●	●	●	●	●	T022
2005	Chevrolet	C cab/chassis HD (GMT 400)	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2005	Chevrolet	C silverado - 2WD	Powertrain	●	●	●	●	●	●	T146
2005	Chevrolet	C silverado - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Chevrolet	C silverado - 2WD	CD changer	●	●	●	○	○	○	
2005	Chevrolet	C silverado - 2WD	Chime	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	C silverado - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	C silverado - 2WD	Radio	●	●	●	●	○	○	

2005	Chevrolet	C silverado - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	Chevrolet	C silverado - 2WD	Disc player and video display	●	●	●	○	○	○	
2005	Chevrolet	C silverado - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2005	Chevrolet	C silverado - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD	Driver door module	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD	Passenger door module	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD	Body control module	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD	Driver seat module	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD	Rear HVAC	●	●	●	●	○	○	
2005	Chevrolet	C silverado - 2WD	Rear seat audio	●	●	●	●	○	○	
2005	Chevrolet	C silverado - 2WD	Generator battery control module	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD	Vehicle theft deterrent	●	●	●	●	●	●	T139
2005	Chevrolet	C silverado - 2WD	Navigation radio	●	●	●	●	●	●	T033
2005	Chevrolet	C silverado - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	C silverado - 2WD	ABS	●	●	●	●	●	○	

2005	Chevrolet	C silverado - 2WD	Rear wheel steering	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2005	Chevrolet	C silverado - 2WD	Tire pressure monitor	●	●	●	●	●	●	T022
2005	Chevrolet	C silverado - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2005	Chevrolet	C silverado - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Chevrolet	C silverado - 2WD (CNG)	CD changer	●	●	●	○	○	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Chime	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	C silverado - 2WD (CNG)	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	C silverado - 2WD (CNG)	Radio	●	●	●	●	○	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	Chevrolet	C silverado - 2WD (CNG)	Disc player and video display	●	●	●	○	○	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Passenger presence system	●	●	○	○	○	●	T020
2005	Chevrolet	C silverado - 2WD (CNG)	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Driver door module	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Passenger door module	●	●	●	●	●	○	

2005	Chevrolet	C silverado - 2WD (CNG)	Body control module	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Driver seat module	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Rear aux. climate module	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Rear HVAC	●	●	●	●	○	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Rear seat audio	●	●	●	●	○	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Generator battery control module	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Vehicle theft deterrent	●	●	●	●	●	●	T139
2005	Chevrolet	C silverado - 2WD (CNG)	Navigation radio	●	●	●	●	●	●	T033
2005	Chevrolet	C silverado - 2WD (CNG)	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	C silverado - 2WD (CNG)	ABS	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD (CNG)	Rear wheel steering	●	●	●	●	●	○	
2005	Chevrolet	C silverado - 2WD (CNG)	ESC (if equipped)	●	●	●	●	●	●	T156
2005	Chevrolet	C silverado - 2WD (CNG)	Tire pressure monitor	●	●	●	●	●	●	T022
2005	Chevrolet	C silverado - 2WD (CNG)	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2005	Chevrolet	Colorado pickup - 2WD	Powertrain	●	●	●	●	●	○	
2005	Chevrolet	Colorado pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024

2005	Chevrolet	Colorado pickup - 4WD	Radio	●	●	●	●	○	○	
2005	Chevrolet	Colorado pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Colorado pickup - 4WD	Body control module	●	●	●	●	●	●	T058
2005	Chevrolet	Colorado pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2005	Chevrolet	Colorado pickup - 4WD	ABS	●	●	●	●	●	●	T024
2005	Chevrolet	Colorado pickup - 4WD	Powertrain	●	●	●	●	●	○	
2005	Chevrolet	Colorado pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Colorado pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Colorado pickup - 4WD	Radio	●	●	●	●	○	○	
2005	Chevrolet	Colorado pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Colorado pickup - 4WD	Body control module	●	●	●	●	●	●	T058
2005	Chevrolet	Colorado pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2005	Chevrolet	Colorado pickup - 4WD	ABS	●	●	●	●	●	●	T024
2005	Chevrolet	Equinox	Powertrain	●	●	●	●	●	●	T001
2005	Chevrolet	Equinox	Instrument panel cluster	○	○	●	○	●	○	
2005	Chevrolet	Equinox	Supplemental inflatable restraint	●	●	●	●	○	○	
2005	Chevrolet	Equinox	Body control module	●	●	●	●	●	●	T141 T148 T142 T143
2005	Chevrolet	Equinox	Radio	●	●	●	●	●	●	T081 T086 T087 T080 T060 T033

2005	Chevrolet	Equinox	Vehicle comm. interface module	●	●	●	●	●	●	T155 T093
2005	Chevrolet	Equinox	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Equinox	Electric power steering	●	●	○	●	●	○	
2005	Chevrolet	Equinox	Antilock brake system	●	●	●	●	●	●	T014
2005	Chevrolet	Express	Powertrain	●	●	●	●	●	●	T146
2005	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Express	Radio	●	●	●	●	○	○	
2005	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Express	Body control module	●	●	●	●	●	○	
2005	Chevrolet	Express	Remote function actuation	●	●	●	●	●	○	
2005	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	●	T110
2005	Chevrolet	Express	ABS	●	●	●	●	●	○	
2005	Chevrolet	Express	Powertrain	●	●	●	●	●	●	T146
2005	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Express	Radio	●	●	●	●	○	○	
2005	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Express	Body control module	●	●	●	●	●	○	
2005	Chevrolet	Express	Remote function actuation	●	●	●	●	●	○	
2005	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	●	T110
2005	Chevrolet	Express	ABS	●	●	●	●	●	○	
2005	Chevrolet	Express	Powertrain	●	●	●	●	●	○	

2005	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Express	Radio	●	●	●	●	○	○	
2005	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Express	Body control module	●	●	●	●	●	○	
2005	Chevrolet	Express	Remote function actuation	●	●	●	●	●	○	
2005	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	●	T110
2005	Chevrolet	Express	ABS	●	●	●	●	●	○	
2005	Chevrolet	Express	Powertrain	●	●	●	●	●	○	
2005	Chevrolet	Express	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Express	Radio	●	●	●	●	○	○	
2005	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Express	Body control module	●	●	●	●	●	○	
2005	Chevrolet	Express	Remote function actuation	●	●	●	●	●	○	
2005	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	●	T110
2005	Chevrolet	Express	ABS	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD	Powertrain	●	●	●	●	●	●	T146
2005	Chevrolet	K silverado - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Chevrolet	K silverado - 4WD	CD changer	●	●	●	○	○	○	
2005	Chevrolet	K silverado - 4WD	Chime	●	●	●	●	●	○	

2005	Chevrolet	K silverado - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	K silverado - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	K silverado - 4WD	Radio	●	●	●	●	○	○	
2005	Chevrolet	K silverado - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	Chevrolet	K silverado - 4WD	Disc player and video display	●	●	●	○	○	○	
2005	Chevrolet	K silverado - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2005	Chevrolet	K silverado - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD	Driver door module	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD	Passenger door module	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD	Body control module	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD	Driver seat module	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD	Rear HVAC	●	●	●	●	○	○	
2005	Chevrolet	K silverado - 4WD	Rear seat audio	●	●	●	●	○	○	
2005	Chevrolet	K silverado - 4WD	Generator battery control module	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD	Vehicle theft deterrent	●	●	●	●	●	●	T139

2005	Chevrolet	K silverado - 4WD	Navigation radio	●	●	●	●	●	●	T033
2005	Chevrolet	K silverado - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	K silverado - 4WD	ABS	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD	Rear wheel steering	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2005	Chevrolet	K silverado - 4WD	Tire pressure monitor	●	●	●	●	●	●	T022
2005	Chevrolet	K silverado - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2005	Chevrolet	K silverado - 4WD (CNG)	Powertrain	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Chevrolet	K silverado - 4WD (CNG)	CD changer	●	●	●	○	○	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Chime	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	K silverado - 4WD (CNG)	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	K silverado - 4WD (CNG)	Radio	●	●	●	●	○	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	Chevrolet	K silverado - 4WD (CNG)	Disc player and video display	●	●	●	○	○	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Passenger presence system	●	●	○	○	○	●	T020

2005	Chevrolet	K silverado - 4WD (CNG)	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Driver door module	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Passenger door module	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Body control module	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Driver seat module	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Rear aux. climate module	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Rear HVAC	●	●	●	●	○	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Rear seat audio	●	●	●	●	○	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Generator battery control module	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Vehicle theft deterrent	●	●	●	●	●	●	T139
2005	Chevrolet	K silverado - 4WD (CNG)	Navigation radio	●	●	●	●	●	●	T033
2005	Chevrolet	K silverado - 4WD (CNG)	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	K silverado - 4WD (CNG)	ABS	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD (CNG)	Rear wheel steering	●	●	●	●	●	○	
2005	Chevrolet	K silverado - 4WD (CNG)	ESC (if equipped)	●	●	●	●	●	●	T156
2005	Chevrolet	K silverado - 4WD (CNG)	Tire pressure monitor	●	●	●	●	●	●	T022

2005	Chevrolet	K silverado - 4WD (CNG)	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2005	Chevrolet	SSR	Powertrain	●	●	●	●	●	●	T001
2005	Chevrolet	SSR	Radio	●	●	●	●	○	○	
2005	Chevrolet	SSR	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	Chevrolet	SSR	Roof and door module	●	●	●	●	●	○	
2005	Chevrolet	SSR	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	SSR	Body control module	●	●	●	●	●	○	
2005	Chevrolet	SSR	Driver seat module	●	●	●	●	●	○	
2005	Chevrolet	SSR	Remote function actuation	●	●	●	●	●	○	
2005	Chevrolet	SSR	Amplifier (bose)	●	●	●	●	●	○	
2005	Chevrolet	SSR	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	SSR	4WAL 3 sensor	●	●	○	●	●	○	
2005	Chevrolet	Suburban - 2WD	Powertrain	●	●	●	●	●	●	T169
2005	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Chevrolet	Suburban - 2WD	CD changer	●	●	●	○	○	○	
2005	Chevrolet	Suburban - 2WD	Chime	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Suburban - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Suburban - 2WD	Radio	●	●	●	●	○	○	
2005	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	Chevrolet	Suburban - 2WD	Disc player and video display	●	●	●	○	○	○	
2005	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2005	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 2WD	Driver door module	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 2WD	Passenger door module	●	●	●	●	●	○	

2005	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 2WD	Driver seat module	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 2WD	Rear HVAC	●	●	●	●	○	○	
2005	Chevrolet	Suburban - 2WD	Rear seat audio	●	●	●	●	○	○	
2005	Chevrolet	Suburban - 2WD	Generator battery control module	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 2WD	Vehicle theft deterrent	●	●	●	●	●	●	T139
2005	Chevrolet	Suburban - 2WD	Navigation radio	●	●	●	●	●	●	T033
2005	Chevrolet	Suburban - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	Suburban - 2WD	ABS	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 2WD	Rear wheel steering	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2005	Chevrolet	Suburban - 2WD	Tire pressure monitor	●	●	●	●	●	●	T022
2005	Chevrolet	Suburban - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2005	Chevrolet	Suburban - 4WD	Powertrain	●	●	●	●	●	●	T169
2005	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Chevrolet	Suburban - 4WD	CD changer	●	●	●	○	○	○	
2005	Chevrolet	Suburban - 4WD	Chime	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Suburban - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Suburban - 4WD	Radio	●	●	●	●	○	○	
2005	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	Chevrolet	Suburban - 4WD	Disc player and video display	●	●	●	○	○	○	
2005	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	○	○	○	●	T020

2005	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 4WD	Driver door module	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 4WD	Passenger door module	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 4WD	Driver seat module	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 4WD	Rear HVAC	●	●	●	●	○	○	
2005	Chevrolet	Suburban - 4WD	Rear seat audio	●	●	●	●	○	○	
2005	Chevrolet	Suburban - 4WD	Generator battery control module	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 4WD	Vehicle theft deterrent	●	●	●	●	●	●	T139
2005	Chevrolet	Suburban - 4WD	Navigation radio	●	●	●	●	●	●	T033
2005	Chevrolet	Suburban - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	Suburban - 4WD	ABS	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 4WD	Rear wheel steering	●	●	●	●	●	○	
2005	Chevrolet	Suburban - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2005	Chevrolet	Suburban - 4WD	Tire pressure monitor	●	●	●	●	●	●	T022
2005	Chevrolet	Suburban - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2005	Chevrolet	Tahoe - 2WD	Powertrain	●	●	●	●	●	○	
2005	Chevrolet	Tahoe - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2005	Chevrolet	Tahoe - 2WD	CD changer	●	●	●	○	○	○	
2005	Chevrolet	Tahoe - 2WD	Chime	●	●	●	●	●	○	
2005	Chevrolet	Tahoe - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Tahoe - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Tahoe - 2WD	Radio	●	●	●	●	○	○	
2005	Chevrolet	Tahoe - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147

2005	Chevrolet	Trailblazer	Radio	●	●	●	●	○	○	
2005	Chevrolet	Trailblazer	Disc player and video display	●	●	●	○	○	○	
2005	Chevrolet	Trailblazer	Passenger presence system	●	●	○	○	○	●	T020
2005	Chevrolet	Trailblazer	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	Driver door module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	Driver seat module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	Lift gate module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	Passenger door module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	Rear seat audio	●	●	●	●	○	○	
2005	Chevrolet	Trailblazer	Body control module	●	●	●	●	●	●	T058
2005	Chevrolet	Trailblazer	Vehicle theft deterrent	●	●	●	●	●	●	T058
2005	Chevrolet	Trailblazer	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	Chevrolet	Trailblazer	Navigation radio	●	●	●	●	●	●	T033
2005	Chevrolet	Trailblazer	ABS	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	4WAL 3 sensor	●	●	●	●	●	●	T024
2005	Chevrolet	Trailblazer	Powertrain	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Trailblazer	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Trailblazer	Radio	●	●	●	●	○	○	
2005	Chevrolet	Trailblazer	Disc player and video display	●	●	●	○	○	○	
2005	Chevrolet	Trailblazer	Passenger presence system	●	●	○	○	○	●	T020
2005	Chevrolet	Trailblazer	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	Driver door module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	Driver seat module	●	●	●	●	●	○	

2005	Chevrolet	Trailblazer	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	Lift gate module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	Passenger door module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	Rear seat audio	●	●	●	●	○	○	
2005	Chevrolet	Trailblazer	Body control module	●	●	●	●	●	●	T058
2005	Chevrolet	Trailblazer	Vehicle theft deterrent	●	●	●	●	●	●	T058
2005	Chevrolet	Trailblazer	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	Chevrolet	Trailblazer	Navigation radio	●	●	●	●	●	●	T033
2005	Chevrolet	Trailblazer	ABS	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer	4WAL 3 sensor	●	●	●	●	●	●	T024
2005	Chevrolet	Trailblazer EXT	Powertrain	●	●	●	●	●	●	T001
2005	Chevrolet	Trailblazer EXT	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Trailblazer EXT	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Trailblazer EXT	Radio	●	●	●	●	○	○	
2005	Chevrolet	Trailblazer EXT	Disc player and video display	●	●	●	○	○	○	
2005	Chevrolet	Trailblazer EXT	Passenger presence system	●	●	○	○	○	●	T020
2005	Chevrolet	Trailblazer EXT	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Driver door module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Driver seat module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Lift gate module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Passenger door module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Rear HVAC/RSA	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Rear seat audio	●	●	●	●	○	○	
2005	Chevrolet	Trailblazer EXT	Body control module	●	●	●	●	●	●	T058
2005	Chevrolet	Trailblazer EXT	Vehicle theft deterrent	●	●	●	●	●	●	T058

2005	Chevrolet	Trailblazer EXT	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	Chevrolet	Trailblazer EXT	Rear HVAC	●	●	●	●	●	●	T058
2005	Chevrolet	Trailblazer EXT	Navigation radio	●	●	●	●	●	●	T033
2005	Chevrolet	Trailblazer EXT	ABS	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	4WAL 3 sensor	●	●	●	●	●	●	T001
2005	Chevrolet	Trailblazer EXT	Powertrain	●	●	●	●	●	●	T001
2005	Chevrolet	Trailblazer EXT	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Trailblazer EXT	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	Chevrolet	Trailblazer EXT	Radio	●	●	●	●	○	○	
2005	Chevrolet	Trailblazer EXT	Disc player and video display	●	●	●	○	○	○	
2005	Chevrolet	Trailblazer EXT	Passenger presence system	●	●	○	○	○	●	T020
2005	Chevrolet	Trailblazer EXT	Instrument panel cluster	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Driver door module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Driver seat module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Lift gate module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Passenger door module	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Rear HVAC/RSA	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	Rear seat audio	●	●	●	●	○	○	
2005	Chevrolet	Trailblazer EXT	Body control module	●	●	●	●	●	●	T058
2005	Chevrolet	Trailblazer EXT	Vehicle theft deterrent	●	●	●	●	●	●	T058
2005	Chevrolet	Trailblazer EXT	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	Chevrolet	Trailblazer EXT	Rear HVAC	●	●	●	●	●	●	T058
2005	Chevrolet	Trailblazer EXT	Navigation radio	●	●	●	●	●	●	T033
2005	Chevrolet	Trailblazer EXT	ABS	●	●	●	●	●	○	
2005	Chevrolet	Trailblazer EXT	4WAL 3 sensor	●	●	●	●	●	●	T001
2005	Chevrolet	Blazer	Radio	●	●	●	●	○	○	

2005	Chevrolet	Blazer	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	Chevrolet	Blazer	Instrument panel cluster	●	●	○	●	●	○	
2005	Chevrolet	Blazer	Body control module	●	●	○	●	●	○	
2005	Chevrolet	Blazer	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	Blazer	Memory seat module	●	●	●	●	●	●	T039
2005	Chevrolet	Blazer	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	Blazer	4WAL 3 sensor	●	●	●	●	●	●	T039
2005	Chevrolet	Blazer	Radio	●	●	●	●	○	○	
2005	Chevrolet	Blazer	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	Chevrolet	Blazer	Instrument panel cluster	●	●	○	●	●	○	
2005	Chevrolet	Blazer	Body control module	●	●	○	●	●	○	
2005	Chevrolet	Blazer	Heating and air conditioning	●	●	●	●	●	○	
2005	Chevrolet	Blazer	Memory seat module	●	●	●	●	●	●	T039
2005	Chevrolet	Blazer	Traction assist (if equipped)	●	●	○	●	●	○	
2005	Chevrolet	Blazer	4WAL 3 sensor	●	●	●	●	●	●	T039
2005	Chevrolet	Uplander	HVAC	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Brakes	●	●	○	●	●	●	T014
2005	Chevrolet	Uplander	Engine controls	●	●	○	●	●	○	
2005	Chevrolet	Uplander	Engine cooling	●	●	○	●	●	○	
2005	Chevrolet	Uplander	Engine electrical	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Shift lock control	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Automatic transaxle	●	●	○	●	●	○	
2005	Chevrolet	Uplander	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Chevrolet	Uplander	Cruise control	●	●	○	●	●	○	
2005	Chevrolet	Uplander	Doors	●	●	●	●	●	○	
2005	Chevrolet	Uplander	Entertainment	●	●	●	●	●	●	T024
2005	Chevrolet	Uplander	Horns	●	●	●	●	●	●	T007

2005	Chevrolet	Uplander	Instrument panel	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Keyless entry	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Lighting systems	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Navigation systems	●	●	●	●	●	●	T033
2005	Chevrolet	Uplander	Stationary windows	●	●	●	●	●	○	
2005	Chevrolet	Uplander	Theft deterrent	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Seat belts	●	●	●	●	●	●	T023
2005	Chevrolet	Uplander	SIR	●	●	●	●	●	●	T020
2005	Chevrolet	Uplander	HVAC	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Brakes	●	●	○	●	●	●	T014
2005	Chevrolet	Uplander	Engine controls	●	●	○	●	●	○	
2005	Chevrolet	Uplander	Engine cooling	●	●	○	●	●	○	
2005	Chevrolet	Uplander	Engine electrical	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Shift lock control	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Automatic transaxle	●	●	○	●	●	○	
2005	Chevrolet	Uplander	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Chevrolet	Uplander	Cruise control	●	●	○	●	●	○	
2005	Chevrolet	Uplander	Doors	●	●	●	●	●	○	
2005	Chevrolet	Uplander	Entertainment	●	●	●	●	●	●	T024
2005	Chevrolet	Uplander	Horns	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Instrument panel	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Keyless entry	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Lighting systems	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Navigation systems	●	●	●	●	●	●	T033
2005	Chevrolet	Uplander	Stationary windows	●	●	●	●	●	○	
2005	Chevrolet	Uplander	Theft deterrent	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander	Seat belts	●	●	●	●	●	●	T023
2005	Chevrolet	Uplander	SIR	●	●	●	●	●	●	T020
2005	Chevrolet	Uplander - 4WD	HVAC	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Brakes	●	●	○	●	●	●	T014
2005	Chevrolet	Uplander - 4WD	Engine controls	●	●	○	●	●	○	
2005	Chevrolet	Uplander - 4WD	Engine cooling	●	●	○	●	●	○	
2005	Chevrolet	Uplander - 4WD	Engine electrical	●	●	●	●	●	●	T007

2005	Chevrolet	Uplander - 4WD	Shift lock control	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Automatic transaxle	●	●	○	●	●	○	
2005	Chevrolet	Uplander - 4WD	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Chevrolet	Uplander - 4WD	Cruise control	●	●	○	●	●	○	
2005	Chevrolet	Uplander - 4WD	Doors	●	●	●	●	●	○	
2005	Chevrolet	Uplander - 4WD	Entertainment	●	●	●	●	●	●	T024
2005	Chevrolet	Uplander - 4WD	Horns	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Instrument panel	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Keyless entry	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Lighting systems	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Navigation systems	●	●	●	●	●	●	T033
2005	Chevrolet	Uplander - 4WD	Stationary windows	●	●	●	●	●	○	
2005	Chevrolet	Uplander - 4WD	Theft deterrent	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Seat belts	●	●	●	●	●	●	T023
2005	Chevrolet	Uplander - 4WD	SIR	●	●	●	●	●	●	T020
2005	Chevrolet	Uplander - 4WD	HVAC	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Brakes	●	●	○	●	●	●	T014
2005	Chevrolet	Uplander - 4WD	Engine controls	●	●	○	●	●	○	
2005	Chevrolet	Uplander - 4WD	Engine cooling	●	●	○	●	●	○	
2005	Chevrolet	Uplander - 4WD	Engine electrical	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Shift lock control	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Automatic transaxle	●	●	○	●	●	○	
2005	Chevrolet	Uplander - 4WD	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Chevrolet	Uplander - 4WD	Cruise control	●	●	○	●	●	○	
2005	Chevrolet	Uplander - 4WD	Doors	●	●	●	●	●	○	
2005	Chevrolet	Uplander - 4WD	Entertainment	●	●	●	●	●	●	T024
2005	Chevrolet	Uplander - 4WD	Horns	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Instrument panel	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Keyless entry	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Lighting systems	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Navigation systems	●	●	●	●	●	●	T033
2005	Chevrolet	Uplander - 4WD	Stationary windows	●	●	●	●	●	○	
2005	Chevrolet	Uplander - 4WD	Theft deterrent	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander - 4WD	Wipers/washer systems	●	●	●	●	●	●	T007

2005	Chevrolet	Uplander - 4WD	Seat belts	●	●	●	●	●	●	T023
2005	Chevrolet	Uplander - 4WD	SIR	●	●	●	●	●	●	T020
2005	Chevrolet	Uplander ext.	HVAC	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Brakes	●	●	○	●	●	●	T014
2005	Chevrolet	Uplander ext.	Engine controls	●	●	○	●	●	○	
2005	Chevrolet	Uplander ext.	Engine cooling	●	●	○	●	●	○	
2005	Chevrolet	Uplander ext.	Engine electrical	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Shift lock control	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Automatic transaxle	●	●	○	●	●	○	
2005	Chevrolet	Uplander ext.	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Chevrolet	Uplander ext.	Cruise control	●	●	○	●	●	○	
2005	Chevrolet	Uplander ext.	Doors	●	●	●	●	●	○	
2005	Chevrolet	Uplander ext.	Entertainment	●	●	●	●	●	●	T024
2005	Chevrolet	Uplander ext.	Horns	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Instrument panel	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Keyless entry	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Lighting systems	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Navigation systems	●	●	●	●	●	●	T033
2005	Chevrolet	Uplander ext.	Stationary windows	●	●	●	●	●	○	
2005	Chevrolet	Uplander ext.	Theft deterrent	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Seat belts	●	●	●	●	●	●	T023
2005	Chevrolet	Uplander ext.	SIR	●	●	●	●	●	●	T020
2005	Chevrolet	Uplander ext.	HVAC	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Brakes	●	●	○	●	●	●	T014
2005	Chevrolet	Uplander ext.	Engine controls	●	●	○	●	●	○	
2005	Chevrolet	Uplander ext.	Engine cooling	●	●	○	●	●	○	
2005	Chevrolet	Uplander ext.	Engine electrical	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Shift lock control	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Automatic transaxle	●	●	○	●	●	○	
2005	Chevrolet	Uplander ext.	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Chevrolet	Uplander ext.	Cruise control	●	●	○	●	●	○	
2005	Chevrolet	Uplander ext.	Doors	●	●	●	●	●	○	
2005	Chevrolet	Uplander ext.	Entertainment	●	●	●	●	●	●	T024
2005	Chevrolet	Uplander ext.	Horns	●	●	●	●	●	●	T007

2005	Chevrolet	Uplander ext.	Instrument panel	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Keyless entry	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Lighting systems	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Navigation systems	●	●	●	●	●	●	T033
2005	Chevrolet	Uplander ext.	Stationary windows	●	●	●	●	●	○	
2005	Chevrolet	Uplander ext.	Theft deterrent	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Chevrolet	Uplander ext.	Seat belts	●	●	●	●	●	●	T023
2005	Chevrolet	Uplander ext.	SIR	●	●	●	●	●	●	T020
2005	Chevrolet	Venture	Powertrain	●	●	●	●	●	○	
2005	Chevrolet	Venture	Digital radio receiver	●	●	●	●	○	●	T024
2005	Chevrolet	Venture	Vehicle comm. interface module	●	●	●	●	●	●	T155 T093
2005	Chevrolet	Venture	Vehicle theft deterrent	●	●	○	●	○	○	
2005	Chevrolet	Venture	Driver information center	●	●	○	○	○	○	
2005	Chevrolet	Venture	Instrument panel cluster	●	●	○	●	●	●	T190 T136
2005	Chevrolet	Venture	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060 T080 T032
2005	Chevrolet	Venture	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2005	Chevrolet	Venture	Chassis	●	●	●	●	●	●	T014
2005	Chevrolet	Venture	HVAC	●	●	●	●	●	●	T007
2005	Chevrolet	Venture	Brakes	●	●	○	●	●	●	T014
2005	Chevrolet	Venture	Engine controls	●	●	○	●	●	○	
2005	Chevrolet	Venture	Engine cooling	●	●	○	●	●	○	
2005	Chevrolet	Venture	Engine electrical	●	●	●	●	●	●	T007
2005	Chevrolet	Venture	Shift lock control	●	●	●	●	●	●	T007
2005	Chevrolet	Venture	Automatic transaxle	●	●	○	●	●	○	
2005	Chevrolet	Venture	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Chevrolet	Venture	Cruise control	●	●	○	●	●	○	
2005	Chevrolet	Venture	Doors	●	●	●	●	●	○	

2005	Chevrolet	Venture	Cruise control	●	●	○	●	●	○	
2005	Chevrolet	Venture	Doors	●	●	●	●	●	○	
2005	Chevrolet	Venture	Entertainment	●	●	●	●	●	●	T024
2005	Chevrolet	Venture	Horns	●	●	●	●	●	●	T007
2005	Chevrolet	Venture	Instrument panel	●	●	●	●	●	●	T007
2005	Chevrolet	Venture	Keyless entry	●	●	●	●	●	●	T007
2005	Chevrolet	Venture	Lighting systems	●	●	●	●	●	●	T007
2005	Chevrolet	Venture	Navigation systems	●	●	●	●	●	●	T033
2005	Chevrolet	Venture	Stationary windows	●	●	●	●	●	○	
2005	Chevrolet	Venture	Theft deterrent	●	●	●	●	●	●	T007
2005	Chevrolet	Venture	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Chevrolet	Venture	Seat belts	●	●	●	●	●	●	T023
2005	Chevrolet	Venture	SIR	●	●	●	●	●	●	T020
2005	Chevrolet	Venture - 4WD	HVAC	●	●	●	●	●	●	T007
2005	Chevrolet	Venture - 4WD	Brakes	●	●	○	●	●	●	T014
2005	Chevrolet	Venture - 4WD	Engine controls	●	●	○	●	●	○	
2005	Chevrolet	Venture - 4WD	Engine cooling	●	●	○	●	●	○	
2005	Chevrolet	Venture - 4WD	Engine electrical	●	●	●	●	●	●	T007
2005	Chevrolet	Venture - 4WD	Shift lock control	●	●	●	●	●	●	T007
2005	Chevrolet	Venture - 4WD	Automatic transaxle	●	●	○	●	●	○	
2005	Chevrolet	Venture - 4WD	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Chevrolet	Venture - 4WD	Cruise control	●	●	○	●	●	○	
2005	Chevrolet	Venture - 4WD	Doors	●	●	●	●	●	○	
2005	Chevrolet	Venture - 4WD	Entertainment	●	●	●	●	●	●	T024
2005	Chevrolet	Venture - 4WD	Horns	●	●	●	●	●	●	T007
2005	Chevrolet	Venture - 4WD	Instrument panel	●	●	●	●	●	●	T007
2005	Chevrolet	Venture - 4WD	Keyless entry	●	●	●	●	●	●	T007
2005	Chevrolet	Venture - 4WD	Lighting systems	●	●	●	●	●	●	T007
2005	Chevrolet	Venture - 4WD	Navigation systems	●	●	●	●	●	●	T033
2005	Chevrolet	Venture - 4WD	Stationary windows	●	●	●	●	●	○	
2005	Chevrolet	Venture - 4WD	Theft deterrent	●	●	●	●	●	●	T007
2005	Chevrolet	Venture - 4WD	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Chevrolet	Venture - 4WD	Seat belts	●	●	●	●	●	●	T023
2005	Chevrolet	Venture - 4WD	SIR	●	●	●	●	●	●	T020
2005	Chevrolet	Venture ext.	HVAC	●	●	●	●	●	●	T007

2005	Chevrolet	Venture ext.	Brakes	●	●	○	●	●	●	T014
2005	Chevrolet	Venture ext.	Engine controls	●	●	○	●	●	○	
2005	Chevrolet	Venture ext.	Engine cooling	●	●	○	●	●	○	
2005	Chevrolet	Venture ext.	Engine electrical	●	●	●	●	●	●	T007
2005	Chevrolet	Venture ext.	Shift lock control	●	●	●	●	●	●	T007
2005	Chevrolet	Venture ext.	Automatic transaxle	●	●	○	●	●	○	
2005	Chevrolet	Venture ext.	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Chevrolet	Venture ext.	Cruise control	●	●	○	●	●	○	
2005	Chevrolet	Venture ext.	Doors	●	●	●	●	●	○	
2005	Chevrolet	Venture ext.	Entertainment	●	●	●	●	●	●	T024
2005	Chevrolet	Venture ext.	Horns	●	●	●	●	●	●	T007
2005	Chevrolet	Venture ext.	Instrument panel	●	●	●	●	●	●	T007
2005	Chevrolet	Venture ext.	Keyless entry	●	●	●	●	●	●	T007
2005	Chevrolet	Venture ext.	Lighting systems	●	●	●	●	●	●	T007
2005	Chevrolet	Venture ext.	Navigation systems	●	●	●	●	●	●	T033
2005	Chevrolet	Venture ext.	Stationary windows	●	●	●	●	●	○	
2005	Chevrolet	Venture ext.	Theft deterrent	●	●	●	●	●	●	T007
2005	Chevrolet	Venture ext.	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Chevrolet	Venture ext.	Seat belts	●	●	●	●	●	●	T023
2005	Chevrolet	Venture ext.	SIR	●	●	●	●	●	●	T020
2005	Chevrolet	Others	Powertrain	●	●	●	●	●	○	
2005	GMC truck	Canyon pickup - 2WD	Powertrain	●	●	●	●	●	○	
2005	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Canyon pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	
2005	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023

2005	GMC truck	Canyon pickup - 2WD	ABS	●	●	●	●	●	●	T024
2005	GMC truck	Canyon pickup - 2WD	Powertrain	●	●	●	●	●	○	
2005	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Canyon pickup - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	
2005	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2005	GMC truck	Canyon pickup - 2WD	ABS	●	●	●	●	●	●	T024
2005	GMC truck	Canyon pickup - 4WD	Powertrain	●	●	●	●	●	○	
2005	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Canyon pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	
2005	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2005	GMC truck	Canyon pickup - 4WD	ABS	●	●	●	●	●	●	T024

2005	GMC truck	Canyon pickup - 4WD	Powertrain	●	●	●	●	●	○	
2005	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Canyon pickup - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	
2005	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2005	GMC truck	Canyon pickup - 4WD	ABS	●	●	●	●	●	●	T024
2005	GMC truck	Envoy	Powertrain	●	●	●	●	●	●	T001
2005	GMC truck	Envoy	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Envoy	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Envoy	Radio	●	●	●	●	○	○	
2005	GMC truck	Envoy	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Envoy	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Envoy	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Envoy	Lift gate module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058

2005	GMC truck	Envoy	Radio	●	●	●	●	○	○	
2005	GMC truck	Envoy	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Envoy	End gate module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Envoy	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Power roof module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Envoy	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	GMC truck	Envoy	Navigation radio	●	●	●	●	●	●	T033
2005	GMC truck	Envoy	ABS	●	●	●	●	●	○	
2005	GMC truck	Envoy	4WAL 3 sensor	●	●	○	●	●	○	
2005	GMC truck	Envoy	Powertrain	●	●	●	●	●	●	T001
2005	GMC truck	Envoy	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Envoy	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Envoy	Radio	●	●	●	●	○	○	
2005	GMC truck	Envoy	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Envoy	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Envoy	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Envoy	Lift gate module	●	●	●	●	●	○	

2005	GMC truck	Envoy	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Envoy	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	GMC truck	Envoy	Navigation radio	●	●	●	●	●	●	T033
2005	GMC truck	Envoy	ABS	●	●	●	●	●	○	
2005	GMC truck	Envoy	Powertrain	●	●	●	●	●	●	T001
2005	GMC truck	Envoy	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Envoy	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Envoy	Radio	●	●	●	●	○	○	
2005	GMC truck	Envoy	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Envoy	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Envoy	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Envoy	Lift gate module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Rear HVAC/RSA	●	●	●	●	●	○	
2005	GMC truck	Envoy	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Envoy	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	GMC truck	Envoy	Rear HVAC	●	●	●	●	●	●	T058
2005	GMC truck	Envoy	Navigation radio	●	●	●	●	●	●	T033
2005	GMC truck	Envoy	ABS	●	●	●	●	●	○	
2005	GMC truck	Envoy	Powertrain	●	●	●	●	●	●	T001
2005	GMC truck	Envoy	Digital radio receiver	●	●	●	●	○	●	T024

2005	GMC truck	Envoy	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Envoy	Radio	●	●	●	●	○	○	
2005	GMC truck	Envoy	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Envoy	End gate module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Envoy	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Power roof module	●	●	●	●	●	○	
2005	GMC truck	Envoy	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Envoy	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	GMC truck	Envoy	Navigation radio	●	●	●	●	●	●	T033
2005	GMC truck	Envoy	ABS	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Powertrain	●	●	●	●	●	●	T001
2005	GMC truck	Envoy XL	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Envoy XL	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Envoy XL	Radio	●	●	●	●	○	○	
2005	GMC truck	Envoy XL	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Envoy XL	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Envoy XL	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Heating and air conditioning	●	●	●	●	●	○	

2005	GMC truck	Envoy XL	Lift gate module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Envoy XL	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Envoy XL	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	GMC truck	Envoy XL	Navigation radio	●	●	●	●	●	●	T033
2005	GMC truck	Envoy XL	ABS	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	4WAL 3 sensor	●	●	○	●	●	○	
2005	GMC truck	Envoy XL	Powertrain	●	●	●	●	●	●	T001
2005	GMC truck	Envoy XL	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Envoy XL	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Envoy XL	Radio	●	●	●	●	○	○	
2005	GMC truck	Envoy XL	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Envoy XL	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Envoy XL	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Lift gate module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Rear HVAC/RSA	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Envoy XL	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Envoy XL	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	GMC truck	Envoy XL	Rear HVAC	●	●	●	●	●	●	T058
2005	GMC truck	Envoy XL	Navigation radio	●	●	●	●	●	●	T033
2005	GMC truck	Envoy XL	ABS	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	4WAL 3 sensor	●	●	○	●	●	○	

2005	GMC truck	Envoy XL	Powertrain	●	●	●	●	●	●	T001
2005	GMC truck	Envoy XL	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Envoy XL	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Envoy XL	Radio	●	●	●	●	○	○	
2005	GMC truck	Envoy XL	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Envoy XL	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Envoy XL	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Lift gate module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Envoy XL	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Envoy XL	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	GMC truck	Envoy XL	Navigation radio	●	●	●	●	●	●	T033
2005	GMC truck	Envoy XL	ABS	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Powertrain	●	●	●	●	●	●	T001
2005	GMC truck	Envoy XL	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Envoy XL	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Envoy XL	Radio	●	●	●	●	○	○	
2005	GMC truck	Envoy XL	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Envoy XL	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Envoy XL	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Driver door module	●	●	●	●	●	○	

2005	GMC truck	Envoy XL	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Lift gate module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Rear HVAC/RSA	●	●	●	●	●	○	
2005	GMC truck	Envoy XL	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Envoy XL	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Envoy XL	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	GMC truck	Envoy XL	Rear HVAC	●	●	●	●	●	●	T058
2005	GMC truck	Envoy XL	Navigation radio	●	●	●	●	●	●	T033
2005	GMC truck	Envoy XL	ABS	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Powertrain	●	●	●	●	●	●	T001
2005	GMC truck	Envoy XUV	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Envoy XUV	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Envoy XUV	Radio	●	●	●	●	○	○	
2005	GMC truck	Envoy XUV	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Envoy XUV	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Envoy XUV	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Lift gate module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Envoy XUV	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Envoy XUV	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	GMC truck	Envoy XUV	Navigation radio	●	●	●	●	●	●	T033

2005	GMC truck	Envoy XUV	ABS	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	4WAL 3 sensor	●	●	○	●	●	○	
2005	GMC truck	Envoy XUV	Powertrain	●	●	●	●	●	●	T001
2005	GMC truck	Envoy XUV	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Envoy XUV	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Envoy XUV	Radio	●	●	●	●	○	○	
2005	GMC truck	Envoy XUV	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Envoy XUV	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	End gate module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Power roof module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Envoy XUV	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Envoy XUV	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	GMC truck	Envoy XUV	Navigation radio	●	●	●	●	●	●	T033
2005	GMC truck	Envoy XUV	ABS	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	4WAL 3 sensor	●	●	○	●	●	○	
2005	GMC truck	Envoy XUV	Powertrain	●	●	●	●	●	●	T001
2005	GMC truck	Envoy XUV	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Envoy XUV	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Envoy XUV	Radio	●	●	●	●	○	○	
2005	GMC truck	Envoy XUV	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Envoy XUV	Passenger presence system	●	●	○	○	○	●	T020

2005	GMC truck	Envoy XUV	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Lift gate module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Envoy XUV	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Envoy XUV	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	GMC truck	Envoy XUV	Navigation radio	●	●	●	●	●	●	T033
2005	GMC truck	Envoy XUV	ABS	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Powertrain	●	●	●	●	●	●	T001
2005	GMC truck	Envoy XUV	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Envoy XUV	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Envoy XUV	Radio	●	●	●	●	○	○	
2005	GMC truck	Envoy XUV	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Envoy XUV	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	End gate module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Power roof module	●	●	●	●	●	○	
2005	GMC truck	Envoy XUV	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Envoy XUV	Body control module	●	●	●	●	●	●	T058
2005	GMC truck	Envoy XUV	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	GMC truck	Envoy XUV	Navigation radio	●	●	●	●	●	●	T033

2005	GMC truck	Envoy XUV	ABS	●	●	●	●	●	○	
2005	GMC truck	Jimmy - 2WD	Powertrain	●	●	●	●	●	●	T146
2005	GMC truck	Jimmy - 2WD	Radio	●	●	●	●	○	○	
2005	GMC truck	Jimmy - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	GMC truck	Jimmy - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2005	GMC truck	Jimmy - 2WD	Body control module	●	●	○	●	●	○	
2005	GMC truck	Jimmy - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Jimmy - 2WD	Memory seat module	●	●	●	●	●	●	T039
2005	GMC truck	Jimmy - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	GMC truck	Jimmy - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2005	GMC truck	Jimmy - 2WD	Powertrain	●	●	●	●	●	●	T146
2005	GMC truck	Jimmy - 2WD	Radio	●	●	●	●	○	○	
2005	GMC truck	Jimmy - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	GMC truck	Jimmy - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2005	GMC truck	Jimmy - 2WD	Body control module	●	●	○	●	●	○	
2005	GMC truck	Jimmy - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Jimmy - 2WD	Memory seat module	●	●	●	●	●	●	T039
2005	GMC truck	Jimmy - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	GMC truck	Jimmy - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2005	GMC truck	Jimmy - 4WD	Powertrain	●	●	●	●	●	●	T146
2005	GMC truck	Jimmy - 4WD	Radio	●	●	●	●	○	○	
2005	GMC truck	Jimmy - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	GMC truck	Jimmy - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2005	GMC truck	Jimmy - 4WD	Body control module	●	●	○	●	●	○	

2005	GMC truck	Jimmy - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Jimmy - 4WD	Memory seat module	●	●	●	●	●	●	T039
2005	GMC truck	Jimmy - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	GMC truck	Jimmy - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2005	GMC truck	Jimmy - 4WD	Powertrain	●	●	●	●	●	●	T146
2005	GMC truck	Jimmy - 4WD	Radio	●	●	●	●	○	○	
2005	GMC truck	Jimmy - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	GMC truck	Jimmy - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2005	GMC truck	Jimmy - 4WD	Body control module	●	●	○	●	●	○	
2005	GMC truck	Jimmy - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Jimmy - 4WD	Memory seat module	●	●	●	●	●	●	T039
2005	GMC truck	Jimmy - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	GMC truck	Jimmy - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2005	GMC truck	Safari - 2WD	Powertrain	●	●	●	●	●	●	T146
2005	GMC truck	Safari - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2005	GMC truck	Safari - 2WD	Body control module	●	●	○	●	●	○	
2005	GMC truck	Safari - 2WD	Supplemental inflatable restraint	●	●	●	●	○	○	
2005	GMC truck	Safari - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2005	GMC truck	Safari - 4WD	Powertrain	●	●	●	●	●	●	T146
2005	GMC truck	Safari - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2005	GMC truck	Safari - 4WD	Body control module	●	●	○	●	●	○	
2005	GMC truck	Safari - 4WD	Supplemental inflatable restraint	●	●	●	●	○	○	
2005	GMC truck	Safari - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2005	GMC truck	Savana	Powertrain	●	●	●	●	●	●	T146

2005	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Savana	Radio	●	●	●	●	○	○	
2005	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Savana	Body control module	●	●	●	●	●	○	
2005	GMC truck	Savana	Remote function actuation	●	●	●	●	●	○	
2005	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	●	T110
2005	GMC truck	Savana	ABS	●	●	●	●	●	○	
2005	GMC truck	Savana	Powertrain	●	●	●	●	●	●	T146
2005	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Savana	Radio	●	●	●	●	○	○	
2005	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Savana	Body control module	●	●	●	●	●	○	
2005	GMC truck	Savana	Remote function actuation	●	●	●	●	●	○	
2005	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	●	T110
2005	GMC truck	Savana	ABS	●	●	●	●	●	○	
2005	GMC truck	Savana	Powertrain	●	●	●	●	●	○	
2005	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Savana	Radio	●	●	●	●	○	○	
2005	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	

2005	GMC truck	Savana	Body control module	●	●	●	●	●	○	
2005	GMC truck	Savana	Remote function actuation	●	●	●	●	●	○	
2005	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	●	T110
2005	GMC truck	Savana	ABS	●	●	●	●	●	○	
2005	GMC truck	Savana	Powertrain	●	●	●	●	●	○	
2005	GMC truck	Savana	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Savana	Radio	●	●	●	●	○	○	
2005	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Savana	Body control module	●	●	●	●	●	○	
2005	GMC truck	Savana	Remote function actuation	●	●	●	●	●	○	
2005	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	●	T110
2005	GMC truck	Savana	ABS	●	●	●	●	●	○	
2005	GMC truck	Sonoma	Powertrain	●	●	●	●	●	●	T146
2005	GMC truck	Sonoma	Radio	●	●	●	●	○	○	
2005	GMC truck	Sonoma	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2005	GMC truck	Sonoma	Instrument panel cluster	●	●	○	●	●	○	
2005	GMC truck	Sonoma	Body control module	●	●	●	●	●	●	T039
2005	GMC truck	Sonoma	Traction assist (if equipped)	●	●	○	●	●	○	
2005	GMC truck	Sonoma	4WAL 3 sensor	●	●	●	●	●	●	T146
2005	GMC truck	Sonoma	Powertrain	●	●	●	●	●	●	T146
2005	GMC truck	Sonoma	Radio	●	●	●	●	○	○	
2005	GMC truck	Sonoma	Supplemental inflatable restraint	●	●	●	●	○	●	T039

2005	GMC truck	Sonoma	Instrument panel cluster	●	●	○	●	●	○	
2005	GMC truck	Sonoma	Body control module	●	●	●	●	●	●	T039
2005	GMC truck	Sonoma	Traction assist (if equipped)	●	●	○	●	●	○	
2005	GMC truck	Sonoma	4WAL 3 sensor	●	●	●	●	●	●	T146
2005	GMC truck	Yukon - 2WD	Powertrain	●	●	●	●	●	○	
2005	GMC truck	Yukon - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2005	GMC truck	Yukon - 2WD	CD changer	●	●	●	○	○	○	
2005	GMC truck	Yukon - 2WD	Chime	●	●	●	●	●	○	
2005	GMC truck	Yukon - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Yukon - 2WD	Radio	●	●	●	●	○	○	
2005	GMC truck	Yukon - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	GMC truck	Yukon - 2WD	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Yukon - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Yukon - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Yukon - 2WD	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Yukon - 2WD	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Yukon - 2WD	Body control module	●	●	●	●	●	○	
2005	GMC truck	Yukon - 2WD	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Yukon - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Yukon - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2005	GMC truck	Yukon - 2WD	Rear HVAC	●	●	●	●	○	○	
2005	GMC truck	Yukon - 2WD	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Yukon - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Yukon - 2WD	Generator battery control module	●	●	●	●	●	●	T139
2005	GMC truck	Yukon - 2WD	Navigation radio	●	●	●	●	●	●	T033

2005	GMC truck	Yukon - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	GMC truck	Yukon - 2WD	ABS	●	●	●	●	●	○	
2005	GMC truck	Yukon - 2WD	Rear wheel steering	●	●	●	●	●	○	
2005	GMC truck	Yukon - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2005	GMC truck	Yukon - 2WD	Tire pressure monitor	●	●	●	●	●	●	T022
2005	GMC truck	Yukon - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2005	GMC truck	Yukon - 4WD	Powertrain	●	●	●	●	●	○	
2005	GMC truck	Yukon - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2005	GMC truck	Yukon - 4WD	CD changer	●	●	●	○	○	○	
2005	GMC truck	Yukon - 4WD	Chime	●	●	●	●	●	○	
2005	GMC truck	Yukon - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Yukon - 4WD	Radio	●	●	●	●	○	○	
2005	GMC truck	Yukon - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	GMC truck	Yukon - 4WD	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Yukon - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Yukon - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Yukon - 4WD	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Yukon - 4WD	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Yukon - 4WD	Body control module	●	●	●	●	●	○	
2005	GMC truck	Yukon - 4WD	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Yukon - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Yukon - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2005	GMC truck	Yukon - 4WD	Rear HVAC	●	●	●	●	○	○	
2005	GMC truck	Yukon - 4WD	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Yukon - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Yukon - 4WD	Generator battery control module	●	●	●	●	●	●	T139

2005	GMC truck	Yukon denali	Generator battery control module	●	●	●	●	●	●	T139
2005	GMC truck	Yukon denali	Navigation radio	●	●	●	●	●	●	T033
2005	GMC truck	Yukon denali	Traction assist (if equipped)	●	●	○	●	●	○	
2005	GMC truck	Yukon denali	ABS	●	●	●	●	●	○	
2005	GMC truck	Yukon denali	Rear wheel steering	●	●	●	●	●	○	
2005	GMC truck	Yukon denali	ESC (if equipped)	●	●	●	●	●	●	T156
2005	GMC truck	Yukon denali	Tire pressure monitor	●	●	●	●	●	●	T022
2005	GMC truck	Yukon denali	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2005	GMC truck	Yukon XL - 2WD	Powertrain	●	●	●	●	●	●	T169
2005	GMC truck	Yukon XL - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2005	GMC truck	Yukon XL - 2WD	CD changer	●	●	●	○	○	○	
2005	GMC truck	Yukon XL - 2WD	Chime	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Yukon XL - 2WD	Radio	●	●	●	●	○	○	
2005	GMC truck	Yukon XL - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	GMC truck	Yukon XL - 2WD	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Yukon XL - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Yukon XL - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 2WD	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 2WD	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 2WD	Body control module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 2WD	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 2WD	Rear HVAC	●	●	●	●	○	○	
2005	GMC truck	Yukon XL - 2WD	Rear seat audio	●	●	●	●	○	○	

2005	GMC truck	Yukon XL - 2WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Yukon XL - 2WD	Generator battery control module	●	●	●	●	●	●	T139
2005	GMC truck	Yukon XL - 2WD	Navigation radio	●	●	●	●	●	●	T033
2005	GMC truck	Yukon XL - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	GMC truck	Yukon XL - 2WD	ABS	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 2WD	Rear wheel steering	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2005	GMC truck	Yukon XL - 2WD	Tire pressure monitor	●	●	●	●	●	●	T022
2005	GMC truck	Yukon XL - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2005	GMC truck	Yukon XL - 4WD	Powertrain	●	●	●	●	●	●	T169
2005	GMC truck	Yukon XL - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2005	GMC truck	Yukon XL - 4WD	CD changer	●	●	●	○	○	○	
2005	GMC truck	Yukon XL - 4WD	Chime	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Yukon XL - 4WD	Radio	●	●	●	●	○	○	
2005	GMC truck	Yukon XL - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	GMC truck	Yukon XL - 4WD	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Yukon XL - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Yukon XL - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 4WD	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 4WD	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 4WD	Body control module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 4WD	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 4WD	Rear HVAC	●	●	●	●	○	○	

2005	GMC truck	Yukon XL - 4WD	Rear seat audio	●	●	●	●	○	○	
2005	GMC truck	Yukon XL - 4WD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	GMC truck	Yukon XL - 4WD	Generator battery control module	●	●	●	●	●	●	T139
2005	GMC truck	Yukon XL - 4WD	Navigation radio	●	●	●	●	●	●	T033
2005	GMC truck	Yukon XL - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2005	GMC truck	Yukon XL - 4WD	ABS	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 4WD	Rear wheel steering	●	●	●	●	●	○	
2005	GMC truck	Yukon XL - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2005	GMC truck	Yukon XL - 4WD	Tire pressure monitor	●	●	●	●	●	●	T022
2005	GMC truck	Yukon XL - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2005	GMC truck	Yukon XL denali	Powertrain	●	●	●	●	●	○	
2005	GMC truck	Yukon XL denali	Amplifier (bose)	●	●	●	●	●	●	T139
2005	GMC truck	Yukon XL denali	CD changer	●	●	●	○	○	○	
2005	GMC truck	Yukon XL denali	Chime	●	●	●	●	●	○	
2005	GMC truck	Yukon XL denali	Digital radio receiver	●	●	●	●	○	●	T024
2005	GMC truck	Yukon XL denali	Radio	●	●	●	●	○	○	
2005	GMC truck	Yukon XL denali	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	GMC truck	Yukon XL denali	Disc player and video display	●	●	●	○	○	○	
2005	GMC truck	Yukon XL denali	Passenger presence system	●	●	○	○	○	●	T020
2005	GMC truck	Yukon XL denali	Instrument panel cluster	●	●	●	●	●	○	
2005	GMC truck	Yukon XL denali	Driver door module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL denali	Passenger door module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL denali	Body control module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL denali	Driver seat module	●	●	●	●	●	○	
2005	GMC truck	Yukon XL denali	Heating and air conditioning	●	●	●	●	●	○	
2005	GMC truck	Yukon XL denali	Rear aux. climate module	●	●	●	●	●	○	

2005	Pontiac	Aztek - FWD	Disc player and video display	●	●	●	○	○	○	
2005	Pontiac	Aztek - FWD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Pontiac	Aztek - FWD	Radio	○	○	○	○	●	○	
2005	Pontiac	Aztek - FWD	Vehicle theft deterrent	●	●	○	●	○	○	
2005	Pontiac	Aztek - FWD	Passenger presence system	●	●	○	○	○	●	T020
2005	Pontiac	Aztek - FWD	Head up display	●	●	○	●	○	○	
2005	Pontiac	Aztek - FWD	Instrument panel cluster	●	●	○	●	●	○	
2005	Pontiac	Aztek - FWD	Body control module	●	●	●	●	●	●	T068 T023 T136 T122
2005	Pontiac	Aztek - FWD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2005	Pontiac	Aztek - FWD	Chassis	●	●	●	●	●	●	T014
2005	Pontiac	Montana	HVAC	●	●	●	●	●	●	T007
2005	Pontiac	Montana	Brakes	●	●	○	●	●	●	T014
2005	Pontiac	Montana	Engine controls	●	●	○	●	●	○	
2005	Pontiac	Montana	Engine cooling	●	●	○	●	●	○	
2005	Pontiac	Montana	Engine electrical	●	●	●	●	●	●	T007
2005	Pontiac	Montana	Shift lock control	●	●	●	●	●	●	T007
2005	Pontiac	Montana	Automatic transaxle	●	●	○	●	●	○	
2005	Pontiac	Montana	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Pontiac	Montana	Cruise control	●	●	○	●	●	○	
2005	Pontiac	Montana	Doors	●	●	●	●	●	○	
2005	Pontiac	Montana	Entertainment	●	●	●	●	●	●	T024
2005	Pontiac	Montana	Horns	●	●	●	●	●	●	T007
2005	Pontiac	Montana	Instrument panel	●	●	●	●	●	●	T007
2005	Pontiac	Montana	Keyless entry	●	●	●	●	●	●	T007
2005	Pontiac	Montana	Lighting systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana	Navigation systems	●	●	●	●	●	●	T033
2005	Pontiac	Montana	Stationary windows	●	●	●	●	●	○	
2005	Pontiac	Montana	Theft deterrent	●	●	●	●	●	●	T007
2005	Pontiac	Montana	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana	Seat belts	●	●	●	●	●	●	T023

2005	Pontiac	Montana	SIR	●	●	●	●	●	●	T020
2005	Pontiac	Montana - 4WD	HVAC	●	●	●	●	●	●	T007
2005	Pontiac	Montana - 4WD	Brakes	●	●	○	●	●	●	T014
2005	Pontiac	Montana - 4WD	Engine controls	●	●	○	●	●	○	
2005	Pontiac	Montana - 4WD	Engine cooling	●	●	○	●	●	○	
2005	Pontiac	Montana - 4WD	Engine electrical	●	●	●	●	●	●	T007
2005	Pontiac	Montana - 4WD	Shift lock control	●	●	●	●	●	●	T007
2005	Pontiac	Montana - 4WD	Automatic transaxle	●	●	○	●	●	○	
2005	Pontiac	Montana - 4WD	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Pontiac	Montana - 4WD	Cruise control	●	●	○	●	●	○	
2005	Pontiac	Montana - 4WD	Doors	●	●	●	●	●	○	
2005	Pontiac	Montana - 4WD	Entertainment	●	●	●	●	●	●	T024
2005	Pontiac	Montana - 4WD	Horns	●	●	●	●	●	●	T007
2005	Pontiac	Montana - 4WD	Instrument panel	●	●	●	●	●	●	T007
2005	Pontiac	Montana - 4WD	Keyless entry	●	●	●	●	●	●	T007
2005	Pontiac	Montana - 4WD	Lighting systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana - 4WD	Navigation systems	●	●	●	●	●	●	T033
2005	Pontiac	Montana - 4WD	Stationary windows	●	●	●	●	●	○	
2005	Pontiac	Montana - 4WD	Theft deterrent	●	●	●	●	●	●	T007
2005	Pontiac	Montana - 4WD	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana - 4WD	Seat belts	●	●	●	●	●	●	T023
2005	Pontiac	Montana - 4WD	SIR	●	●	●	●	●	●	T020
2005	Pontiac	Montana SV6	HVAC	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Brakes	●	●	○	●	●	●	T014
2005	Pontiac	Montana SV6	Engine controls	●	●	○	●	●	○	
2005	Pontiac	Montana SV6	Engine cooling	●	●	○	●	●	○	
2005	Pontiac	Montana SV6	Engine electrical	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Shift lock control	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Automatic transaxle	●	●	○	●	●	○	
2005	Pontiac	Montana SV6	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Pontiac	Montana SV6	Cruise control	●	●	○	●	●	○	
2005	Pontiac	Montana SV6	Doors	●	●	●	●	●	○	
2005	Pontiac	Montana SV6	Entertainment	●	●	●	●	●	●	T024
2005	Pontiac	Montana SV6	Horns	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Instrument panel	●	●	●	●	●	●	T007

2005	Pontiac	Montana SV6	Keyless entry	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Lighting systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Navigation systems	●	●	●	●	●	●	T033
2005	Pontiac	Montana SV6	Stationary windows	●	●	●	●	●	○	
2005	Pontiac	Montana SV6	Theft deterrent	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Seat belts	●	●	●	●	●	●	T023
2005	Pontiac	Montana SV6	SIR	●	●	●	●	●	●	T020
2005	Pontiac	Montana SV6	HVAC	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Brakes	●	●	○	●	●	●	T014
2005	Pontiac	Montana SV6	Engine controls	●	●	○	●	●	○	
2005	Pontiac	Montana SV6	Engine cooling	●	●	○	●	●	○	
2005	Pontiac	Montana SV6	Engine electrical	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Shift lock control	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Automatic transaxle	●	●	○	●	●	○	
2005	Pontiac	Montana SV6	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Pontiac	Montana SV6	Cruise control	●	●	○	●	●	○	
2005	Pontiac	Montana SV6	Doors	●	●	●	●	●	○	
2005	Pontiac	Montana SV6	Entertainment	●	●	●	●	●	●	T024
2005	Pontiac	Montana SV6	Horns	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Instrument panel	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Keyless entry	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Lighting systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Navigation systems	●	●	●	●	●	●	T033
2005	Pontiac	Montana SV6	Stationary windows	●	●	●	●	●	○	
2005	Pontiac	Montana SV6	Theft deterrent	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Seat belts	●	●	●	●	●	●	T023
2005	Pontiac	Montana SV6	SIR	●	●	●	●	●	●	T020
2005	Pontiac	Montana SV6	Powertrain	●	●	●	●	●	○	
2005	Pontiac	Montana SV6	Digital radio receiver	●	●	●	●	○	●	T024
2005	Pontiac	Montana SV6	Vehicle comm. interface module	●	●	●	●	●	●	T155 T093
2005	Pontiac	Montana SV6	Vehicle theft deterrent	●	●	○	●	○	○	

2005	Pontiac	Montana SV6	Driver information center	●	●	○	○	○	○	
2005	Pontiac	Montana SV6	Instrument panel cluster	●	●	○	●	●	●	T190 T136
2005	Pontiac	Montana SV6	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060 T080 T032
2005	Pontiac	Montana SV6	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2005	Pontiac	Montana SV6	Chassis	●	●	●	●	●	●	T014
2005	Pontiac	Montana SV6	HVAC	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Brakes	●	●	○	●	●	●	T014
2005	Pontiac	Montana SV6	Engine controls	●	●	○	●	●	○	
2005	Pontiac	Montana SV6	Engine cooling	●	●	○	●	●	○	
2005	Pontiac	Montana SV6	Engine electrical	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Shift lock control	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Automatic transaxle	●	●	○	●	●	○	
2005	Pontiac	Montana SV6	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Pontiac	Montana SV6	Cruise control	●	●	○	●	●	○	
2005	Pontiac	Montana SV6	Doors	●	●	●	●	●	○	
2005	Pontiac	Montana SV6	Entertainment	●	●	●	●	●	●	T024
2005	Pontiac	Montana SV6	Horns	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Instrument panel	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Keyless entry	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Lighting systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Navigation systems	●	●	●	●	●	●	T033
2005	Pontiac	Montana SV6	Stationary windows	●	●	●	●	●	○	
2005	Pontiac	Montana SV6	Theft deterrent	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6	Seat belts	●	●	●	●	●	●	T023
2005	Pontiac	Montana SV6	SIR	●	●	●	●	●	●	T020
2005	Pontiac	Montana SV6 - AWD	HVAC	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Brakes	●	●	○	●	●	●	T014

2005	Pontiac	Montana SV6 - AWD	Engine controls	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Engine cooling	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Engine electrical	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Shift lock control	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Automatic transaxle	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Pontiac	Montana SV6 - AWD	Cruise control	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Doors	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Entertainment	●	●	●	●	●	●	T024
2005	Pontiac	Montana SV6 - AWD	Horns	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Instrument panel	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Keyless entry	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Lighting systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Navigation systems	●	●	●	●	●	●	T033
2005	Pontiac	Montana SV6 - AWD	Stationary windows	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Theft deterrent	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Wipers/washer systems	●	●	●	●	●	●	T007

2005	Pontiac	Montana SV6 - AWD	Seat belts	●	●	●	●	●	●	T023
2005	Pontiac	Montana SV6 - AWD	SIR	●	●	●	●	●	●	T020
2005	Pontiac	Montana SV6 - AWD	HVAC	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Brakes	●	●	○	●	●	●	T014
2005	Pontiac	Montana SV6 - AWD	Engine controls	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Engine cooling	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Engine electrical	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Shift lock control	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Automatic transaxle	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Pontiac	Montana SV6 - AWD	Cruise control	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Doors	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Entertainment	●	●	●	●	●	●	T024
2005	Pontiac	Montana SV6 - AWD	Horns	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Instrument panel	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Keyless entry	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Lighting systems	●	●	●	●	●	●	T007

2005	Pontiac	Montana SV6 - AWD	Navigation systems	●	●	●	●	●	●	T033
2005	Pontiac	Montana SV6 - AWD	Stationary windows	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Theft deterrent	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Seat belts	●	●	●	●	●	●	T023
2005	Pontiac	Montana SV6 - AWD	SIR	●	●	●	●	●	●	T020
2005	Pontiac	Montana SV6 - AWD	Powertrain	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Digital radio receiver	●	●	●	●	○	●	T024
2005	Pontiac	Montana SV6 - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T155 T093
2005	Pontiac	Montana SV6 - AWD	Vehicle theft deterrent	●	●	○	●	○	○	
2005	Pontiac	Montana SV6 - AWD	Driver information center	●	●	○	○	○	○	
2005	Pontiac	Montana SV6 - AWD	Instrument panel cluster	●	●	○	●	●	●	T190 T136
2005	Pontiac	Montana SV6 - AWD	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060 T080 T032
2005	Pontiac	Montana SV6 - AWD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2005	Pontiac	Montana SV6 - AWD	Chassis	●	●	●	●	●	●	T014
2005	Pontiac	Montana SV6 - AWD	HVAC	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Brakes	●	●	○	●	●	●	T014

2005	Pontiac	Montana SV6 - AWD	Engine controls	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Engine cooling	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Engine electrical	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Shift lock control	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Automatic transaxle	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Pontiac	Montana SV6 - AWD	Cruise control	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Doors	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Entertainment	●	●	●	●	●	●	T024
2005	Pontiac	Montana SV6 - AWD	Horns	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Instrument panel	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Keyless entry	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Lighting systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Navigation systems	●	●	●	●	●	●	T033
2005	Pontiac	Montana SV6 - AWD	Stationary windows	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 - AWD	Theft deterrent	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 - AWD	Wipers/washer systems	●	●	●	●	●	●	T007

2005	Pontiac	Montana SV6 - AWD	Seat belts	●	●	●	●	●	●	T023
2005	Pontiac	Montana SV6 - AWD	SIR	●	●	●	●	●	●	T020
2005	Pontiac	Montana SV6 ext.	HVAC	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Brakes	●	●	○	●	●	●	T014
2005	Pontiac	Montana SV6 ext.	Engine controls	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 ext.	Engine cooling	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 ext.	Engine electrical	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Shift lock control	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Automatic transaxle	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 ext.	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Pontiac	Montana SV6 ext.	Cruise control	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 ext.	Doors	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 ext.	Entertainment	●	●	●	●	●	●	T024
2005	Pontiac	Montana SV6 ext.	Horns	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Instrument panel	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Keyless entry	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Lighting systems	●	●	●	●	●	●	T007

2005	Pontiac	Montana SV6 ext.	Navigation systems	●	●	●	●	●	●	T033
2005	Pontiac	Montana SV6 ext.	Stationary windows	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 ext.	Theft deterrent	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Seat belts	●	●	●	●	●	●	T023
2005	Pontiac	Montana SV6 ext.	SIR	●	●	●	●	●	●	T020
2005	Pontiac	Montana SV6 ext.	HVAC	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Brakes	●	●	○	●	●	●	T014
2005	Pontiac	Montana SV6 ext.	Engine controls	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 ext.	Engine cooling	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 ext.	Engine electrical	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Shift lock control	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Automatic transaxle	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 ext.	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Pontiac	Montana SV6 ext.	Cruise control	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 ext.	Doors	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 ext.	Entertainment	●	●	●	●	●	●	T024

2005	Pontiac	Montana SV6 ext.	Horns	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Instrument panel	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Keyless entry	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Lighting systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Navigation systems	●	●	●	●	●	●	T033
2005	Pontiac	Montana SV6 ext.	Stationary windows	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 ext.	Theft deterrent	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Seat belts	●	●	●	●	●	●	T023
2005	Pontiac	Montana SV6 ext.	SIR	●	●	●	●	●	●	T020
2005	Pontiac	Montana SV6 ext.	Powertrain	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 ext.	Digital radio receiver	●	●	●	●	○	●	T024
2005	Pontiac	Montana SV6 ext.	Vehicle comm. interface module	●	●	●	●	●	●	T155 T093
2005	Pontiac	Montana SV6 ext.	Vehicle theft deterrent	●	●	○	●	○	○	
2005	Pontiac	Montana SV6 ext.	Driver information center	●	●	○	○	○	○	
2005	Pontiac	Montana SV6 ext.	Instrument panel cluster	●	●	○	●	●	●	T190 T136
2005	Pontiac	Montana SV6 ext.	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060 T080 T032

2005	Pontiac	Montana SV6 ext.	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2005	Pontiac	Montana SV6 ext.	Chassis	●	●	●	●	●	●	T014
2005	Pontiac	Montana SV6 ext.	HVAC	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Brakes	●	●	○	●	●	●	T014
2005	Pontiac	Montana SV6 ext.	Engine controls	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 ext.	Engine cooling	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 ext.	Engine electrical	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Shift lock control	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Automatic transaxle	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 ext.	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Pontiac	Montana SV6 ext.	Cruise control	●	●	○	●	●	○	
2005	Pontiac	Montana SV6 ext.	Doors	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 ext.	Entertainment	●	●	●	●	●	●	T024
2005	Pontiac	Montana SV6 ext.	Horns	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Instrument panel	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Keyless entry	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Lighting systems	●	●	●	●	●	●	T007

2005	Pontiac	Montana SV6 ext.	Navigation systems	●	●	●	●	●	●	T033
2005	Pontiac	Montana SV6 ext.	Stationary windows	●	●	●	●	●	○	
2005	Pontiac	Montana SV6 ext.	Theft deterrent	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Pontiac	Montana SV6 ext.	Seat belts	●	●	●	●	●	●	T023
2005	Pontiac	Montana SV6 ext.	SIR	●	●	●	●	●	●	T020
2005	Saturn	Relay	HVAC	●	●	●	●	●	●	T007
2005	Saturn	Relay	Brakes	●	●	○	●	●	●	T014
2005	Saturn	Relay	Engine controls	●	●	○	●	●	○	
2005	Saturn	Relay	Engine cooling	●	●	○	●	●	○	
2005	Saturn	Relay	Engine electrical	●	●	●	●	●	●	T007
2005	Saturn	Relay	Shift lock control	●	●	●	●	●	●	T007
2005	Saturn	Relay	Automatic transaxle	●	●	○	●	●	○	
2005	Saturn	Relay	Cellular communication	●	●	●	●	●	●	T002 T099 T073 T093
2005	Saturn	Relay	Cruise control	●	●	○	●	●	○	
2005	Saturn	Relay	Doors	●	●	●	●	●	○	
2005	Saturn	Relay	Entertainment	●	●	●	●	●	●	T024
2005	Saturn	Relay	Horns	●	●	●	●	●	●	T007
2005	Saturn	Relay	Instrument panel	●	●	●	●	●	●	T007
2005	Saturn	Relay	Keyless entry	●	●	●	●	●	●	T007
2005	Saturn	Relay	Lighting systems	●	●	●	●	●	●	T007
2005	Saturn	Relay	Navigation systems	●	●	●	●	●	●	T033
2005	Saturn	Relay	Stationary windows	●	●	●	●	●	○	
2005	Saturn	Relay	Theft deterrent	●	●	●	●	●	●	T007
2005	Saturn	Relay	Wipers/washer systems	●	●	●	●	●	●	T007
2005	Saturn	Relay	Seat belts	●	●	●	●	●	●	T023
2005	Saturn	Relay	SIR	●	●	●	●	●	●	T020
2005	Saturn	VUE - AWD	Powertrain	●	●	●	●	●	●	T001

2005	Saturn	VUE - AWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093 T093
2005	Saturn	VUE - AWD	Digital radio receiver	●	●	●	●	○	○	
2005	Saturn	VUE - AWD	Radio	●	●	○	●	●	●	T032 T059
2005	Saturn	VUE - AWD	Body control module	●	●	●	●	●	●	T141 T148 T142 T143 T008
2005	Saturn	VUE - AWD	Supplemental inflatable restraint	●	●	●	●	●	○	
2005	Saturn	VUE - AWD	Antilock brake system	●	●	○	●	●	○	
2005	Saturn	VUE - FWD	Powertrain	●	●	●	●	●	●	T001
2005	Saturn	VUE - FWD	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093 T093
2005	Saturn	VUE - FWD	Digital radio receiver	●	●	●	●	○	○	
2005	Saturn	VUE - FWD	Radio	●	●	○	●	●	●	T032 T059
2005	Saturn	VUE - FWD	Body control module	●	●	●	●	●	●	T141 T148 T142 T143 T008
2005	Saturn	VUE - FWD	Supplemental inflatable restraint	●	●	●	●	●	○	
2005	Saturn	VUE - FWD	Antilock brake system	●	●	○	●	●	○	
2005	Hummer	H2	Powertrain	●	●	●	●	●	○	
2005	Hummer	H2	Digital radio receiver	●	●	●	●	○	●	T024
2005	Hummer	H2	Radio	●	●	●	●	○	○	
2005	Hummer	H2	Supplemental inflatable restraint	●	●	●	●	○	●	T039 T147
2005	Hummer	H2	Instrument panel cluster	●	●	●	●	●	○	
2005	Hummer	H2	Heating and air conditioning	●	●	●	●	●	○	
2005	Hummer	H2	Passenger door module	●	●	●	●	●	○	
2005	Hummer	H2	Body control module	●	●	●	●	●	○	
2005	Hummer	H2	Driver seat module	●	●	●	●	●	○	
2005	Hummer	H2	Rear seat audio	●	●	●	●	○	○	
2005	Hummer	H2	Driver door module	●	●	●	●	●	○	
2005	Hummer	H2	GPS communication module	●	●	●	●	●	●	T024

2005	Hummer	H2	Navigation radio	●	●	●	●	●	●	T033
2005	Hummer	H2	Air suspension	●	●	●	●	●	○	
2005	Hummer	H2	ABS	●	●	○	●	●	●	T149
2005	SAAB	Saab 9-7x	Powertrain	●	●	●	●	●	●	T001
2005	SAAB	Saab 9-7x	Digital radio receiver	●	●	●	●	○	●	T024
2005	SAAB	Saab 9-7x	Vehicle comm. interface module	●	●	●	●	●	●	T099 T002 T073 T093
2005	SAAB	Saab 9-7x	Disc player and video display	●	●	●	○	○	○	
2005	SAAB	Saab 9-7x	Instrument panel cluster	●	●	●	●	●	○	
2005	SAAB	Saab 9-7x	Driver door module	●	●	●	●	●	○	
2005	SAAB	Saab 9-7x	Driver seat module	●	●	●	●	●	○	
2005	SAAB	Saab 9-7x	Lift gate module	●	●	●	●	●	○	
2005	SAAB	Saab 9-7x	Passenger door module	●	●	●	●	●	○	
2005	SAAB	Saab 9-7x	Rear seat audio	●	●	●	●	○	○	
2005	SAAB	Saab 9-7x	Heating and air conditioning	●	●	●	●	●	○	
2005	SAAB	Saab 9-7x	Radio	●	●	●	●	●	●	T080 T032
2005	SAAB	Saab 9-7x	Body control module	●	●	●	●	●	●	T058
2005	SAAB	Saab 9-7x	Vehicle theft deterrent	●	●	●	●	○	○	
2005	SAAB	Saab 9-7x	Passenger presence system	●	●	○	○	○	●	T020
2005	SAAB	Saab 9-7x	Supplemental inflatable restraint	●	●	●	●	●	●	T024
2005	SAAB	Saab 9-7x	ABS	●	●	●	●	●	○	
2004	Buick	Century	Powertrain	●	●	●	●	●	○	
2004	Buick	Century	Onstar	●	●	●	●	●	●	T155 T191
2004	Buick	Century	Body control module	●	●	○	●	●	●	T122 T170 T136 T081 T144 T080
2004	Buick	Century	Supplemental inflatable restraint	●	●	○	●	○	●	T023
2004	Buick	Century	Chassis	●	●	●	●	●	●	T014
2004	Buick	Lesabre	Powertrain	●	●	●	●	●	○	

2004	Buick	Lesabre	Onstar	●	●	●	●	●	●	T155 T191
2004	Buick	Lesabre	Digital radio receiver	●	●	●	●	○	●	T024
2004	Buick	Lesabre	CD changer	●	●	●	●	○	○	
2004	Buick	Lesabre	Climate control panel	●	●	○	○	○	○	
2004	Buick	Lesabre	Dash integration module	●	●	○	○	○	●	T122 T172 T123 T127 T173 T174 T126 T112
2004	Buick	Lesabre	Driver door module	●	●	●	●	●	○	
2004	Buick	Lesabre	Head up display	●	●	○	○	●	○	
2004	Buick	Lesabre	Instrument panel module	●	●	○	○	○	●	T138 T175
2004	Buick	Lesabre	Rear integration module	●	●	○	○	○	○	
2004	Buick	Lesabre	Remote function actuation	●	●	●	●	●	○	
2004	Buick	Lesabre	Instrument panel cluster	●	●	○	○	●	○	
2004	Buick	Lesabre	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060
2004	Buick	Lesabre	Vehicle theft deterrent	●	●	●	●	●	○	
2004	Buick	Lesabre	Supplemental inflatable restraint	●	●	●	●	●	●	T112
2004	Buick	Lesabre	DRP/ABS/TIM	●	●	○	●	●	●	T014
2004	Buick	Lesabre	Powertrain	●	●	●	●	●	○	
2004	Buick	Lesabre	Onstar	●	●	●	●	●	●	T155 T191
2004	Buick	Lesabre	Digital radio receiver	●	●	●	●	○	●	T024
2004	Buick	Lesabre	CD changer	●	●	●	●	○	○	
2004	Buick	Lesabre	Climate control panel	●	●	○	○	○	○	
2004	Buick	Lesabre	Dash integration module	●	●	○	○	○	●	T122 T172 T123 T127 T173 T174 T126 T112
2004	Buick	Lesabre	Driver door module	●	●	●	●	●	○	
2004	Buick	Lesabre	Head up display	●	●	○	○	●	○	
2004	Buick	Lesabre	Instrument panel module	●	●	○	○	○	●	T138 T175

2004	Buick	Lesabre	Memory seat module	●	●	●	●	●	○	
2004	Buick	Lesabre	Rear integration module	●	●	○	○	○	○	
2004	Buick	Lesabre	Remote function actuation	●	●	●	●	●	○	
2004	Buick	Lesabre	Instrument panel cluster	●	●	○	○	●	○	
2004	Buick	Lesabre	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060
2004	Buick	Lesabre	Vehicle theft deterrent	●	●	●	●	●	○	
2004	Buick	Lesabre	Supplemental inflatable restraint	●	●	●	●	●	●	T112
2004	Buick	Lesabre	DRP/ABS/TIM	●	●	○	●	●	●	T014
2004	Buick	Park avenue	Powertrain	●	●	●	●	●	○	
2004	Buick	Park avenue	Onstar	●	●	●	●	○	●	T155 T003 T191
2004	Buick	Park avenue	Driver door module	●	●	●	●	●	○	
2004	Buick	Park avenue	Memory seat module	●	●	●	●	●	●	T177
2004	Buick	Park avenue	Heating and air conditioning	●	●	●	●	●	●	T138
2004	Buick	Park avenue	Remote function actuation	○	○	●	●	●	○	
2004	Buick	Park avenue	Body control module	●	●	●	●	●	●	T122 T176 T058
2004	Buick	Park avenue	Cellular telephone	●	●	●	●	○	●	T192
2004	Buick	Park avenue	Instrument panel cluster	●	●	●	●	●	●	T058 T058
2004	Buick	Park avenue	Vehicle theft deterrent	●	●	○	●	○	○	
2004	Buick	Park avenue	DRP/ABS/TIM	●	●	○	●	●	●	T014
2004	Buick	Regal	Powertrain	●	●	●	●	●	○	
2004	Buick	Regal	Onstar	●	●	●	●	●	●	T155 T191
2004	Buick	Regal	Body control module	●	●	○	●	●	●	T122 T170 T136 T081 T144 T080

2004	Buick	Regal	Supplemental inflatable restraint	●	●	○	●	○	●	T023
2004	Buick	Regal	Chassis	●	●	●	●	●	●	T014
2004	Cadillac	CTS	Powertrain	●	●	●	●	●	○	
2004	Cadillac	CTS	Onstar	●	●	●	●	●	●	T155 T191
2004	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2004	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T118 T119 T120
2004	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2004	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2004	Cadillac	CTS	Climate control panel	●	●	●	●	●	●	T122 T123 T124 T125 T126 T127 T128 T129 T130 T131 T132 T133 T134 T135 T136
2004	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2004	Cadillac	CTS	Driver door switch	●	●	●	●	○	○	
2004	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2004	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2004	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2004	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2004	Cadillac	CTS	Instrument panel cluster	●	●	○	○	○	○	
2004	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2004	Cadillac	CTS	Remote function actuation	●	●	●	●	●	○	
2004	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2004	Cadillac	CTS	Vehicle theft deterrent	●	●	●	●	○	○	
2004	Cadillac	CTS	Radio	●	●	●	●	●	●	T114 T094 T095 T086 T087 T115 T033 T033
2004	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2004	Cadillac	CTS	Powertrain	●	●	●	●	●	○	
2004	Cadillac	CTS	Onstar	●	●	●	●	●	●	T155 T191
2004	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024

2004	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T118 T119 T120
2004	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2004	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	
2004	Cadillac	CTS	Climate control panel	●	●	●	●	●	●	T122 T123 T124 T125 T126 T127 T128 T129 T130 T131 T132 T133 T134 T135 T136
2004	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2004	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2004	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2004	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2004	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2004	Cadillac	CTS	Instrument panel cluster	●	●	○	○	○	○	
2004	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2004	Cadillac	CTS	Remote function actuation	●	●	●	●	●	○	
2004	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2004	Cadillac	CTS	Vehicle theft deterrent	●	●	●	●	○	○	
2004	Cadillac	CTS	Radio	●	●	●	●	●	●	T114 T094 T095 T086 T087 T115 T033 T033
2004	Cadillac	CTS	Driver door switch	●	●	●	●	●	●	T112 T113
2004	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2004	Cadillac	CTS	Onstar	●	●	●	●	●	●	T155 T191
2004	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024
2004	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T118 T119 T120
2004	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	○	
2004	Cadillac	CTS	Amplifier (delco)	●	●	●	●	●	○	

2004	Cadillac	CTS	Climate control panel	●	●	●	●	●	●	T122 T123 T124 T125 T126 T127 T128 T129 T130 T131 T132 T133 T134 T135 T136
2004	Cadillac	CTS	Driver door module	●	●	●	●	●	●	T116
2004	Cadillac	CTS	Left rear door module	●	●	●	●	●	○	
2004	Cadillac	CTS	Passenger door module	●	●	●	●	●	●	T116
2004	Cadillac	CTS	Right rear door module	●	●	●	●	●	○	
2004	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2004	Cadillac	CTS	Instrument panel cluster	●	●	○	○	○	○	
2004	Cadillac	CTS	Memory seat module	●	●	●	●	●	○	
2004	Cadillac	CTS	Remote function actuation	●	●	●	●	●	○	
2004	Cadillac	CTS	TV antenna module	●	●	●	●	●	○	
2004	Cadillac	CTS	Vehicle theft deterrent	●	●	●	●	○	○	
2004	Cadillac	CTS	Radio	●	●	●	●	●	●	T114 T094 T095 T086 T087 T115 T033 T033
2004	Cadillac	CTS	Driver door switch	●	●	●	●	●	●	T112 T113
2004	Cadillac	CTS	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2004	Cadillac	CTS	Tire pressure monitor	●	●	○	●	●	●	T137
2004	Cadillac	CTS	Powertrain	●	●	●	●	●	○	
2004	Cadillac	Deville	Powertrain	●	●	●	●	●	○	
2004	Cadillac	Deville	Memory seat module	○	○	○	○	●	○	
2004	Cadillac	Deville	Onstar	●	●	●	●	●	●	T155 T191
2004	Cadillac	Deville	Digital radio receiver	●	●	●	●	○	●	T024
2004	Cadillac	Deville	Navigation radio	●	●	●	●	○	●	T166
2004	Cadillac	Deville	Amplifier (delco)	●	●	○	●	●	○	
2004	Cadillac	Deville	CD changer	●	●	●	●	○	○	
2004	Cadillac	Deville	Dash integration module	●	●	○	○	○	●	T172 T123 T178 T136
2004	Cadillac	Deville	Instrument panel module	●	●	○	○	○	●	T138

2004	Cadillac	Deville	Rear climate control panel	●	●	○	○	○	○	
2004	Cadillac	Deville	Remote function actuation	●	●	○	●	●	●	T180
2004	Cadillac	Deville	Vehicle theft deterrent	●	●	○	●	○	○	
2004	Cadillac	Deville	Radio	●	●	○	○	●	●	T179 T086 T087 T033
2004	Cadillac	Deville	Instrument panel cluster	●	●	○	●	●	●	T094
2004	Cadillac	Deville	Driver door module	●	●	●	●	●	○	
2004	Cadillac	Deville	Rear integration module	●	●	○	○	○	○	
2004	Cadillac	Deville	Personalization	●	●	○	●	●	●	T138 T175
2004	Cadillac	Deville	Right rear door module	●	●	●	●	●	○	
2004	Cadillac	Deville	Left rear door module	●	●	●	●	●	○	
2004	Cadillac	Deville	Passenger door module	●	●	●	●	●	○	
2004	Cadillac	Deville	Driver door switch	●	●	●	●	○	●	T112 T113
2004	Cadillac	Deville	Speed sensitive steering	●	●	○	●	○	○	
2004	Cadillac	DHS	Powertrain	●	●	●	●	●	○	
2004	Cadillac	DHS	Onstar	●	●	●	●	●	●	T155 T191
2004	Cadillac	DHS	Digital radio receiver	●	●	●	●	○	●	T024
2004	Cadillac	DHS	Navigation radio	●	●	●	●	○	●	T166
2004	Cadillac	DHS	CD changer	●	●	●	●	○	○	
2004	Cadillac	DHS	Dash integration module	●	●	○	○	○	●	T172 T123 T178 T136
2004	Cadillac	DHS	Instrument panel cluster	○	○	○	●	○	●	T116
2004	Cadillac	DHS	Instrument panel module	●	●	○	○	○	●	T138
2004	Cadillac	DHS	Rear climate control panel	●	●	○	○	○	○	
2004	Cadillac	DHS	Remote function actuation	●	●	○	●	●	●	T180

2004	Cadillac	DHS	Vehicle theft deterrent	●	●	○	●	○	○	
2004	Cadillac	DHS	Radio	●	●	○	●	●	●	T179 T086 T087 T033
2004	Cadillac	DHS	Amplifier (bose)	●	●	○	●	●	○	
2004	Cadillac	DHS	Memory seat module	●	●	○	●	●	●	T126
2004	Cadillac	DHS	Driver door module	●	●	●	●	●	○	
2004	Cadillac	DHS	Rear integration module	●	●	○	○	○	○	
2004	Cadillac	DHS	Personalization	●	●	○	●	●	●	T138 T175
2004	Cadillac	DHS	Right rear door module	●	●	●	●	●	○	
2004	Cadillac	DHS	Left rear door module	●	●	●	●	●	○	
2004	Cadillac	DHS	Passenger door module	●	●	●	●	●	○	
2004	Cadillac	DHS	Driver door switch	●	●	●	●	○	●	T112 T113
2004	Cadillac	DHS	Speed sensitive steering	●	●	○	●	○	○	
2004	Cadillac	DTS	Powertrain	●	●	●	●	●	○	
2004	Cadillac	DTS	Onstar	●	●	●	●	●	●	T155 T191
2004	Cadillac	DTS	Digital radio receiver	●	●	●	●	○	●	T024
2004	Cadillac	DTS	Navigation radio	●	●	●	●	○	●	T166
2004	Cadillac	DTS	CD changer	●	●	●	●	○	○	
2004	Cadillac	DTS	Dash integration module	●	●	○	○	○	●	T172 T123 T178 T136
2004	Cadillac	DTS	Instrument panel cluster	○	○	○	●	○	●	T116
2004	Cadillac	DTS	Instrument panel module	●	●	○	○	○	●	T138
2004	Cadillac	DTS	Rear climate control panel	●	●	○	○	○	○	
2004	Cadillac	DTS	Remote function actuation	●	●	○	●	●	●	T180
2004	Cadillac	DTS	Vehicle theft deterrent	●	●	○	●	○	○	
2004	Cadillac	DTS	Radio	●	●	○	●	●	●	T179 T086 T087 T033
2004	Cadillac	DTS	Amplifier (bose)	●	●	○	●	●	○	
2004	Cadillac	DTS	Memory seat module	●	●	○	●	●	●	T126

2004	Cadillac	DTS	Driver door module	●	●	●	●	●	○	
2004	Cadillac	DTS	Rear integration module	●	●	○	○	○	○	
2004	Cadillac	DTS	Personalization	●	●	○	●	●	●	T138 T175
2004	Cadillac	DTS	Right rear door module	●	●	●	●	●	○	
2004	Cadillac	DTS	Left rear door module	●	●	●	●	●	○	
2004	Cadillac	DTS	Passenger door module	●	●	●	●	●	○	
2004	Cadillac	DTS	Driver door switch	●	●	●	●	○	●	T112 T113
2004	Cadillac	DTS	Speed sensitive steering	●	●	○	●	○	○	
2004	Cadillac	Seville	Powertrain	●	●	●	●	●	○	
2004	Cadillac	Seville	Onstar	●	●	●	●	●	●	T155 T191
2004	Cadillac	Seville	Digital radio receiver	●	●	●	●	○	●	T024
2004	Cadillac	Seville	Instrument panel module	●	●	○	●	●	○	
2004	Cadillac	Seville	Dash integration module	●	●	○	●	●	●	T122 T125 T194 T195
2004	Cadillac	Seville	Navigation radio	●	●	●	●	○	●	T166
2004	Cadillac	Seville	Amplifier (delco)	●	●	○	●	●	○	
2004	Cadillac	Seville	CD changer	●	●	●	●	○	●	T172 T123 T178 T136
2004	Cadillac	Seville	Driver door module	●	●	○	●	●	○	
2004	Cadillac	Seville	Instrument panel cluster	●	●	○	●	○	●	T116
2004	Cadillac	Seville	Remote function actuation	●	●	○	●	●	●	T180
2004	Cadillac	Seville	Vehicle theft deterrent	●	●	○	●	○	○	
2004	Cadillac	Seville	Radio	●	●	○	●	●	●	T179 T086 T087 T033
2004	Cadillac	Seville	Memory seat module	●	●	○	●	●	○	
2004	Cadillac	Seville	Amplifier (bose)	●	●	○	●	●	○	
2004	Cadillac	Seville	Rear integration module	●	●	○	●	●	●	T182
2004	Cadillac	Seville	Speed sensitive steering	●	●	○	●	○	○	
2004	Cadillac	Seville	Powertrain	●	●	●	●	●	○	

2004	Cadillac	Seville	Onstar	●	●	●	●	●	●	T155 T191
2004	Cadillac	Seville	Digital radio receiver	●	●	●	●	○	●	T024
2004	Cadillac	Seville	Instrument panel module	●	●	○	●	●	○	
2004	Cadillac	Seville	Dash integration module	●	●	○	●	●	●	T122 T125 T194 T195
2004	Cadillac	Seville	Navigation radio	●	●	●	●	○	●	T166
2004	Cadillac	Seville	Amplifier (delco)	●	●	○	●	●	○	
2004	Cadillac	Seville	CD changer	●	●	●	●	○	●	T172 T123 T178 T136
2004	Cadillac	Seville	Driver door module	●	●	○	●	●	○	
2004	Cadillac	Seville	Instrument panel cluster	●	●	○	●	○	●	T116
2004	Cadillac	Seville	Remote function actuation	●	●	○	●	●	●	T180
2004	Cadillac	Seville	Vehicle theft deterrent	●	●	○	●	○	○	
2004	Cadillac	Seville	Radio	●	●	○	●	●	●	T179 T086 T087 T033
2004	Cadillac	Seville	Memory seat module	●	●	○	●	●	○	
2004	Cadillac	Seville	Amplifier (bose)	●	●	○	●	●	○	
2004	Cadillac	Seville	Rear integration module	●	●	○	●	●	●	T182
2004	Cadillac	Seville	Speed sensitive steering	●	●	○	●	○	○	
2004	Cadillac	XLR	HVAC systems - automatic	●	●	●	●	●	●	T008 T001
2004	Cadillac	XLR	Variable effort steering	●	●	○	●	●	○	
2004	Cadillac	XLR	Steering wheel and column	●	●	○	●	●	○	
2004	Cadillac	XLR	Tire pressure monitoring	●	●	●	●	●	●	T029
2004	Cadillac	XLR	Electronic suspension control (ESC)	●	●	○	●	●	○	
2004	Cadillac	XLR	Antilock brake system	●	●	●	●	●	●	T014 T001
2004	Cadillac	XLR	Hydraulic brakes	●	●	○	●	●	○	

2004	Cadillac	XLR	Park brake	●	●	○	●	●	○	
2004	Cadillac	XLR	Engine controls	●	●	●	●	●	●	T001
2004	Cadillac	XLR	Engine cooling	●	●	●	●	●	●	T001
2004	Cadillac	XLR	Engine electrical	●	●	●	●	●	●	T001
2004	Cadillac	XLR	Shift lock control	●	●	●	●	●	●	T029
2004	Cadillac	XLR	Automatic transmission	●	●	●	●	●	○	
2004	Cadillac	XLR	Body rear end	●	●	●	●	●	●	T029
2004	Cadillac	XLR	Cellular communication	●	●	●	●	●	●	T155 T093
2004	Cadillac	XLR	Cruise control	●	●	●	●	●	●	T001
2004	Cadillac	XLR	Doors	●	●	●	●	●	●	T029
2004	Cadillac	XLR	Entertainment	●	●	●	●	●	●	T033
2004	Cadillac	XLR	Horns	●	●	○	●	●	○	
2004	Cadillac	XLR	Instrument panel	●	●	●	●	●	●	T001
2004	Cadillac	XLR	Keyless entry	●	●	○	●	●	●	T029
2004	Cadillac	XLR	Lighting systems	●	●	○	●	●	○	
2004	Cadillac	XLR	Navigation systems	●	●	○	●	○	●	T033
2004	Cadillac	XLR	Roof	●	●	○	●	●	○	
2004	Cadillac	XLR	Seats	●	●	○	●	●	●	T030 T154
2004	Cadillac	XLR	Theft deterrent	●	●	●	●	●	●	T001
2004	Cadillac	XLR	Wipers/washer systems	●	●	○	●	●	○	
2004	Cadillac	XLR	Seat belts	○	○	○	●	●	●	T023
2004	Cadillac	XLR	SIR	○	○	○	●	●	●	T023
2004	Chevrolet	Aveo	Powertrain	●	●	●	●	●	●	T001
2004	Chevrolet	Aveo	Antilock brake system	●	●	●	●	●	●	T014
2004	Chevrolet	Aveo	Chassis	●	●	●	●	●	●	T014
2004	Chevrolet	U100	Powertrain	●	●	●	●	●	●	T001
2004	Chevrolet	U100	Chassis	●	●	●	●	●	●	T014
2004	Chevrolet	Alero (export)	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Alero (export)	Body control module	●	●	●	●	●	●	T183
2004	Chevrolet	Alero (export)	Chassis	●	●	●	●	●	●	T014
2004	Chevrolet	Cavalier	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Cavalier	Body control module	●	●	●	●	○	○	
2004	Chevrolet	Cavalier	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Cavalier	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Cavalier	Radio	●	●	○	●	○	●	T023

2004	Chevrolet	Cavalier	Chassis	●	●	●	●	●	●	T014
2004	Chevrolet	Cavalier (CNG)	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Cavalier (CNG)	Body control module	●	●	●	●	○	○	
2004	Chevrolet	Cavalier (CNG)	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Cavalier (CNG)	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Cavalier (CNG)	Radio	●	●	○	●	○	●	T023
2004	Chevrolet	Cavalier (CNG)	Chassis	●	●	●	●	●	●	T014
2004	Chevrolet	Classic	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Classic	Body control module	●	●	●	○	●	●	T141
2004	Chevrolet	Classic	Remote function actuation	●	●	○	●	●	○	
2004	Chevrolet	Classic	Radio	●	●	●	●	●	○	
2004	Chevrolet	Classic	Chassis	●	●	●	●	●	●	T014
2004	Chevrolet	Corvette	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Corvette	Body control module	●	●	○	●	●	●	T181
2004	Chevrolet	Corvette	Supplemental inflatable restraint	●	●	○	●	●	●	T181
2004	Chevrolet	Corvette	ABS/TCS	●	●	●	●	●	○	
2004	Chevrolet	Corvette	RTD	●	●	●	●	●	○	
2004	Chevrolet	Epica	Powertrain	●	●	●	●	●	●	T001
2004	Chevrolet	Epica	ISU	●	●	○	●	●	○	
2004	Chevrolet	Epica	Antilock brake system	●	●	●	●	●	●	T014
2004	Chevrolet	Impala	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Impala	Body control module	●	●	○	●	●	●	T198 T023 T136 T122 T088 T080 T081 T082
2004	Chevrolet	Impala	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Impala	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Impala	Supplemental inflatable restraint	●	●	○	○	○	○	
2004	Chevrolet	Impala	Heating and air conditioning	●	●	○	○	○	○	
2004	Chevrolet	Impala	Chassis	●	●	●	●	●	●	T014
2004	Chevrolet	Malibu	HVAC systems - automatic	●	●	●	●	●	○	
2004	Chevrolet	Malibu	HVAC systems - manual	●	●	●	●	●	○	

2004	Chevrolet	Malibu	Power steering system	●	●	○	●	●	●	T104
2004	Chevrolet	Malibu	Antilock brake system	●	●	●	●	●	●	T014
2004	Chevrolet	Malibu	Hydraulic brakes	●	●	●	●	●	●	T014
2004	Chevrolet	Malibu	Engine controls	●	●	○	●	●	○	
2004	Chevrolet	Malibu	Engine cooling	●	●	○	●	●	○	
2004	Chevrolet	Malibu	Engine electrical	●	●	●	●	●	○	
2004	Chevrolet	Malibu	Shift lock control	●	●	○	●	○	○	
2004	Chevrolet	Malibu	Automatic transmission	●	●	○	●	●	○	
2004	Chevrolet	Malibu	Body rear end	●	●	○	●	●	○	
2004	Chevrolet	Malibu	Cellular communication	●	●	●	●	●	●	T155
2004	Chevrolet	Malibu	Cruise control	●	●	○	●	○	○	
2004	Chevrolet	Malibu	Doors	●	●	○	●	●	○	
2004	Chevrolet	Malibu	Entertainment	●	●	●	●	●	●	T024
2004	Chevrolet	Malibu	Instrument panel	●	●	●	●	●	○	
2004	Chevrolet	Malibu	Keyless entry	●	●	○	●	○	○	
2004	Chevrolet	Malibu	Lighting systems	●	●	○	●	●	○	
2004	Chevrolet	Malibu	Stationary windows	●	●	○	●	●	○	
2004	Chevrolet	Malibu	Theft deterrent	●	●	○	●	●	○	
2004	Chevrolet	Malibu	Wipers/washer systems	●	●	○	●	●	○	
2004	Chevrolet	Malibu	Adjustable pedals	●	●	●	●	●	●	T155
2004	Chevrolet	Malibu	Seat belts	●	●	●	●	●	●	T023
2004	Chevrolet	Malibu	SIR	●	●	●	●	●	●	T023
2004	Chevrolet	Monte carlo	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Monte carlo	Body control module	●	●	○	●	●	●	T198 T023 T136 T122 T088 T080 T081 T082
2004	Chevrolet	Monte carlo	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Monte carlo	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Monte carlo	Supplemental inflatable restraint	●	●	○	○	○	○	
2004	Chevrolet	Monte carlo	Heating and air conditioning	●	●	○	○	○	○	
2004	Chevrolet	Monte carlo	Chassis	●	●	●	●	●	●	T014
2004	Chevrolet	Optra	Powertrain	●	●	●	●	●	●	T001
2004	Chevrolet	Optra	Antilock brake system	●	●	●	●	●	●	T014
2004	Chevrolet	Spark	Powertrain	●	●	●	●	●	○	

2004	Chevrolet	Spark	Chassis	●	●	●	●	●	○	
2004	Chevrolet	Others	Powertrain	●	●	●	●	●	●	T001
2004	Chevrolet	Others	Antilock brake system	●	●	●	●	●	●	T014
2004	Chevrolet	Others	ISU	●	●	●	●	●	○	
2004	Chevrolet	Monza	Powertrain	●	●	●	●	●	●	T001
2004	Oldsmobile	Alero	Powertrain	●	●	●	●	●	○	
2004	Oldsmobile	Alero	Instrument panel cluster	○	○	●	●	○	○	
2004	Oldsmobile	Alero	Body control module	●	●	●	●	●	●	T141 T183
2004	Oldsmobile	Alero	Radio	●	●	○	●	○	○	
2004	Oldsmobile	Alero	Remote function actuation	●	●	○	●	●	○	
2004	Oldsmobile	Alero	Chassis	●	●	●	●	●	●	T014
2004	Pontiac	Bonneville	Powertrain	●	●	●	●	●	○	
2004	Pontiac	Bonneville	Onstar	●	●	●	●	●	●	T155 T191
2004	Pontiac	Bonneville	Digital radio receiver	●	●	●	●	○	●	T024
2004	Pontiac	Bonneville	CD changer	●	●	●	●	○	○	
2004	Pontiac	Bonneville	Climate control panel	●	●	○	○	○	○	
2004	Pontiac	Bonneville	Dash integration module	●	●	○	○	○	●	T122 T172 T123 T127 T173 T174 T126 T112
2004	Pontiac	Bonneville	Head up display	●	●	○	○	●	○	
2004	Pontiac	Bonneville	Instrument panel cluster	○	○	●	●	○	○	
2004	Pontiac	Bonneville	Instrument panel module	●	●	○	○	○	●	T138 T175
2004	Pontiac	Bonneville	Rear integration module	●	●	○	○	○	○	
2004	Pontiac	Bonneville	Remote function actuation	●	●	●	●	●	○	
2004	Pontiac	Bonneville	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060
2004	Pontiac	Bonneville	Driver door module	●	●	●	●	●	○	
2004	Pontiac	Bonneville	Vehicle theft deterrent	●	●	●	●	●	●	T185

2004	Pontiac	Bonneville	Supplemental inflatable restraint	●	●	●	●	●	●	T112
2004	Pontiac	Bonneville	DRP/ABS/TIM	●	●	○	●	●	●	T014
2004	Pontiac	Bonneville	Powertrain	●	●	●	●	●	○	
2004	Pontiac	Bonneville	Onstar	●	●	●	●	●	●	T155 T191
2004	Pontiac	Bonneville	Digital radio receiver	●	●	●	●	○	●	T024
2004	Pontiac	Bonneville	CD changer	●	●	●	●	○	○	
2004	Pontiac	Bonneville	Climate control panel	●	●	○	○	○	○	
2004	Pontiac	Bonneville	Dash integration module	●	●	○	○	○	●	T122 T172 T123 T127 T173 T174 T126 T112
2004	Pontiac	Bonneville	Head up display	●	●	○	○	●	○	
2004	Pontiac	Bonneville	Instrument panel module	●	●	○	○	○	●	T138 T175
2004	Pontiac	Bonneville	Rear integration module	●	●	○	○	○	○	
2004	Pontiac	Bonneville	Remote function actuation	●	●	●	●	●	○	
2004	Pontiac	Bonneville	Instrument panel cluster	●	●	●	●	●	○	
2004	Pontiac	Bonneville	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060
2004	Pontiac	Bonneville	Driver door module	●	●	●	●	●	○	
2004	Pontiac	Bonneville	Vehicle theft deterrent	●	●	●	●	○	●	T185
2004	Pontiac	Bonneville	Memory seat module	●	●	●	●	●	○	
2004	Pontiac	Bonneville	Supplemental inflatable restraint	●	●	●	●	●	●	T112
2004	Pontiac	Bonneville	DRP/ABS/TIM	●	●	○	●	●	●	T014
2004	Pontiac	Bonneville	Powertrain	●	●	●	●	●	○	
2004	Pontiac	Bonneville	Onstar	●	●	●	●	●	●	T155 T191
2004	Pontiac	Bonneville	Digital radio receiver	●	●	●	●	○	●	T024
2004	Pontiac	Bonneville	CD changer	●	●	●	●	○	○	
2004	Pontiac	Bonneville	Climate control panel	●	●	○	○	○	○	

2004	Pontiac	Bonneville	Dash integration module	●	●	○	○	○	●	T122 T172 T123 T127 T173 T174 T126 T112
2004	Pontiac	Bonneville	Head up display	●	●	○	○	●	○	
2004	Pontiac	Bonneville	Instrument panel module	●	●	○	○	○	●	T138 T175
2004	Pontiac	Bonneville	Rear integration module	●	●	○	○	○	○	
2004	Pontiac	Bonneville	Remote function actuation	●	●	●	●	●	○	
2004	Pontiac	Bonneville	Instrument panel cluster	●	●	○	○	●	○	
2004	Pontiac	Bonneville	Radio	●	●	●	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060
2004	Pontiac	Bonneville	Driver door module	●	●	●	●	●	●	T186
2004	Pontiac	Bonneville	Vehicle theft deterrent	●	●	●	●	○	●	T185
2004	Pontiac	Bonneville	Memory seat module	●	●	●	●	●	●	T136
2004	Pontiac	Bonneville	Supplemental inflatable restraint	●	●	●	●	●	●	T112
2004	Pontiac	Bonneville	DRP/ABS/TIM	●	●	○	●	●	●	T014
2004	Pontiac	Bonneville	Magna steer	●	●	○	●	○	○	
2004	Pontiac	GTO	Powertrain	●	●	●	●	●	○	
2004	Pontiac	GTO	Supplemental inflatable restraint	●	●	○	○	○	○	
2004	Pontiac	Grand am	Powertrain	●	●	●	●	●	○	
2004	Pontiac	Grand am	Body control module	●	●	●	●	●	●	T141 T183
2004	Pontiac	Grand am	Instrument panel cluster	○	○	●	●	○	○	
2004	Pontiac	Grand am	Radio	○	○	○	●	○	○	
2004	Pontiac	Grand am	Digital radio receiver	●	●	●	●	○	●	T024
2004	Pontiac	Grand am	Remote function actuation	●	●	○	●	●	○	
2004	Pontiac	Grand am	Chassis	●	●	●	●	●	●	T014
2004	Pontiac	Grand prix	Powertrain	●	●	●	●	●	○	

2004	Pontiac	Grand prix	Onstar	●	●	●	●	●	●	T155 T191
2004	Pontiac	Grand prix	Body control module	●	●	○	●	●	●	T198 T080 T032
2004	Pontiac	Grand prix	Digital radio receiver	●	●	●	●	○	●	T024
2004	Pontiac	Grand prix	Supplemental inflatable restraint	●	●	●	●	○	●	T023
2004	Pontiac	Grand prix	Driver information center	●	●	●	●	●	●	T023 T145 T136 T007
2004	Pontiac	Grand prix	Heating and air conditioning	○	○	○	○	●	●	T138
2004	Pontiac	Grand prix	Chassis	●	●	○	●	●	●	T014
2004	Pontiac	Matiz	Powertrain	●	●	●	●	●	○	
2004	Pontiac	Matiz	Chassis	●	●	●	●	●	○	
2004	Pontiac	Sunfire	Powertrain	●	●	●	●	●	○	
2004	Pontiac	Sunfire	Body control module	●	●	●	●	○	○	
2004	Pontiac	Sunfire	Digital radio receiver	●	●	●	●	○	●	T024
2004	Pontiac	Sunfire	Onstar	●	●	●	●	●	●	T155 T191
2004	Pontiac	Sunfire	Radio	●	●	○	●	○	●	T023
2004	Pontiac	Sunfire	Chassis	●	●	●	●	●	●	T014
2004	Pontiac	Vibe - AWD	Cruise control	●	●	○	●	●	●	T080
2004	Pontiac	Vibe - AWD	Digital radio receiver	●	●	●	●	○	●	T024 T024
2004	Pontiac	Vibe - AWD	Chassis	●	●	○	●	●	○	
2004	Pontiac	Vibe - FWD	Cruise control	●	●	○	●	●	●	T080
2004	Pontiac	Vibe - FWD	Digital radio receiver	●	●	●	●	○	●	T024 T024
2004	Pontiac	Vibe - FWD	Chassis	●	●	○	●	●	○	
2004	Buick	Rainier	Powertrain	●	●	●	●	●	○	
2004	Buick	Rainier	Onstar	●	●	●	●	●	●	T155 T191
2004	Buick	Rainier	Digital radio receiver	●	●	●	●	○	●	T024
2004	Buick	Rainier	Body control module	●	●	●	●	●	●	T058
2004	Buick	Rainier	Instrument panel cluster	●	●	●	●	●	○	
2004	Buick	Rainier	Driver door module	●	●	●	●	●	○	
2004	Buick	Rainier	Passenger door module	●	●	●	●	●	○	
2004	Buick	Rainier	Driver seat module	●	●	●	●	●	○	
2004	Buick	Rainier	Heating and air conditioning	●	●	●	●	●	○	

2004	Buick	Rainier	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Buick	Rainier	Amplifier (bose)	●	●	●	●	●	○	
2004	Buick	Rainier	Radio	●	●	●	●	○	●	T032
2004	Buick	Rainier	Rear seat audio	●	●	●	●	○	○	
2004	Buick	Rainier	Lift gate module	●	●	●	●	●	○	
2004	Buick	Rainier	Rear seat entertainment	●	●	●	●	●	●	T058
2004	Buick	Rainier	Navigation radio	●	●	●	●	●	●	T033
2004	Buick	Rainier	ABS	●	●	●	●	●	○	
2004	Buick	Rainier	4WAL 3 sensor	●	●	●	●	●	●	T155 T191
2004	Buick	Rainier - 2WD	Powertrain	●	●	●	●	●	○	
2004	Buick	Rainier - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Buick	Rainier - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Buick	Rainier - 2WD	Body control module	●	●	●	●	●	●	T058
2004	Buick	Rainier - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2004	Buick	Rainier - 2WD	Driver door module	●	●	●	●	●	○	
2004	Buick	Rainier - 2WD	Passenger door module	●	●	●	●	●	○	
2004	Buick	Rainier - 2WD	Driver seat module	●	●	●	●	●	○	
2004	Buick	Rainier - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Buick	Rainier - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Buick	Rainier - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2004	Buick	Rainier - 2WD	Radio	●	●	●	●	○	●	T032
2004	Buick	Rainier - 2WD	Rear seat audio	●	●	●	●	○	○	
2004	Buick	Rainier - 2WD	Lift gate module	●	●	●	●	●	○	
2004	Buick	Rainier - 2WD	Rear seat entertainment	●	●	●	●	●	●	T058
2004	Buick	Rainier - 2WD	Navigation radio	●	●	●	●	●	●	T033
2004	Buick	Rainier - 2WD	ABS	●	●	●	●	●	○	
2004	Buick	Rainier - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T155 T191
2004	Buick	Rendezvous - AWD	Powertrain	●	●	●	●	●	○	

2004	Buick	Rendezvous - AWD	Onstar	●	●	●	●	●	●	T155 T191
2004	Buick	Rendezvous - AWD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Buick	Rendezvous - AWD	Body control module	●	●	○	●	●	●	T068 T023 T136 T122 T081 T082 T144 T080
2004	Buick	Rendezvous - AWD	Navigation radio	●	●	●	●	○	●	T033
2004	Buick	Rendezvous - AWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2004	Buick	Rendezvous - AWD	Vehicle theft deterrent	●	●	○	●	○	○	
2004	Buick	Rendezvous - AWD	Rear seat entertainment	●	●	●	○	○	○	
2004	Buick	Rendezvous - AWD	Head up display	●	●	○	○	○	○	
2004	Buick	Rendezvous - AWD	Radio	●	●	●	●	●	●	T081 T082 T144 T080
2004	Buick	Rendezvous - AWD	Chassis	●	●	●	●	●	●	T014
2004	Buick	Rendezvous - FWD	Powertrain	●	●	●	●	●	○	
2004	Buick	Rendezvous - FWD	Onstar	●	●	●	●	●	●	T155 T191
2004	Buick	Rendezvous - FWD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Buick	Rendezvous - FWD	Body control module	●	●	○	●	●	●	T068 T023 T136 T122 T081 T082 T144 T080
2004	Buick	Rendezvous - FWD	Navigation radio	●	●	●	●	○	●	T033
2004	Buick	Rendezvous - FWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2004	Buick	Rendezvous - FWD	Vehicle theft deterrent	●	●	○	●	○	○	

2004	Buick	Rendezvous - FWD	Rear seat entertainment	●	●	●	○	○	○	
2004	Buick	Rendezvous - FWD	Head up display	●	●	○	○	○	○	
2004	Buick	Rendezvous - FWD	Radio	●	●	●	●	●	●	T081 T082 T144 T080
2004	Buick	Rendezvous - FWD	Chassis	●	●	●	●	●	●	T014
2004	Cadillac	Escalade	Powertrain	●	●	●	●	●	○	
2004	Cadillac	Escalade	Digital radio receiver	●	●	●	●	○	●	T024
2004	Cadillac	Escalade	Body control module	●	●	●	●	●	○	
2004	Cadillac	Escalade	Instrument panel cluster	●	●	●	●	●	○	
2004	Cadillac	Escalade	Passenger presence system	●	●	○	○	○	●	T020
2004	Cadillac	Escalade	Amplifier (bose)	●	●	●	●	●	●	T139
2004	Cadillac	Escalade	Chime	●	●	●	●	●	○	
2004	Cadillac	Escalade	Passenger door module	●	●	●	●	●	○	
2004	Cadillac	Escalade	Driver door module	●	●	●	●	●	○	
2004	Cadillac	Escalade	Onstar	●	●	●	●	●	●	T155 T191
2004	Cadillac	Escalade	Driver seat module	●	●	●	●	●	○	
2004	Cadillac	Escalade	Rear HVAC	●	●	●	●	○	○	
2004	Cadillac	Escalade	Heating and air conditioning	●	●	●	●	●	○	
2004	Cadillac	Escalade	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Cadillac	Escalade	CD changer	●	●	●	○	○	○	
2004	Cadillac	Escalade	Radio	●	●	●	●	○	○	
2004	Cadillac	Escalade	Rear seat entertainment	●	●	●	○	○	○	
2004	Cadillac	Escalade	Rear seat audio	●	●	●	●	○	○	
2004	Cadillac	Escalade	Rear aux. climate module	●	●	●	●	●	●	T024
2004	Cadillac	Escalade	Navigation radio	●	●	●	●	●	●	T033
2004	Cadillac	Escalade	Rear wheel steering	●	●	●	●	●	○	

2004	Cadillac	Escalade	ABS	●	●	●	●	●	○	
2004	Cadillac	Escalade	ESC (if equipped)	●	●	●	●	●	●	T156
2004	Cadillac	Escalade	Tire pressure monitor	●	●	○	●	●	●	T022
2004	Cadillac	Escalade	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	Cadillac	SRX	Powertrain	●	●	●	●	●	●	T001
2004	Cadillac	SRX	Onstar	●	●	●	●	●	●	T155 T191
2004	Cadillac	SRX	Digital radio receiver	●	●	●	●	○	●	T024
2004	Cadillac	SRX	Amplifier (bose)	●	●	●	●	○	○	
2004	Cadillac	SRX	Amplifier (delco)	●	●	●	●	●	○	
2004	Cadillac	SRX	Climate control panel	●	●	●	●	●	○	
2004	Cadillac	SRX	Dash integration module	●	●	●	●	●	●	T122 T123 T124 T126 T127 T128 T129 T130 T131 T132 T133 T134 T135 T165 T136
2004	Cadillac	SRX	Driver door module	●	●	●	●	●	●	T116
2004	Cadillac	SRX	Driver door switch	●	●	●	●	○	○	
2004	Cadillac	SRX	Left rear door module	●	●	●	●	●	○	
2004	Cadillac	SRX	Right rear door module	●	●	●	●	●	○	
2004	Cadillac	SRX	Passenger door module	●	●	●	●	●	●	T116
2004	Cadillac	SRX	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2004	Cadillac	SRX	Memory seat module	●	●	●	●	●	○	
2004	Cadillac	SRX	Instrument panel cluster	●	●	●	●	●	○	
2004	Cadillac	SRX	Radio	●	●	●	●	○	●	T157 T158 T159 T094 T095 T160 T161 T162 T163 T116 T033 T033
2004	Cadillac	SRX	Remote function actuation	●	●	●	●	●	●	T118 T119 T120
2004	Cadillac	SRX	Rear seat module	●	●	●	●	●	○	
2004	Cadillac	SRX	TV antenna module	●	●	●	●	●	○	
2004	Cadillac	SRX	Vehicle theft deterrent	●	●	●	●	○	●	T117 T117 T117 T117

2004	Cadillac	SRX	Disc player and video display	●	●	●	○	○	○	
2004	Cadillac	SRX	CD changer	●	●	●	●	●	●	T112 T113
2004	Cadillac	SRX	Navigation radio	●	●	●	●	●	●	T166
2004	Cadillac	SRX	DRP/ABS/TCS/VSES	●	●	●	●	●	●	T014
2004	Cadillac	SRX	Electronic suspension control	●	●	●	●	●	○	
2004	Cadillac	SRX	Tire pressure monitor	●	●	○	●	●	●	T137
2004	Cadillac	Incomplete (hearse)	Powertrain	●	●	●	●	●	○	
2004	Cadillac	Incomplete (hearse)	Amplifier (delco)	●	●	○	●	●	●	T126 T127 T112 T136 T158 T094 T138 T175 T179 T086 T087 T033 T113 T199 T200
2004	Cadillac	Incomplete (hearse)	Rear integration module	●	●	○	●	●	●	T136 T179 T086 T087 T033 T199 T200
2004	Cadillac	Incomplete (hearse)	Driver door module	●	●	●	●	●	○	
2004	Cadillac	Incomplete (hearse)	Passenger door module	●	●	●	●	●	○	
2004	Cadillac	Incomplete (hearse)	Driver door switch	●	●	●	●	●	○	
2004	Cadillac	Incomplete (hearse)	DRP/ABS/TCS	●	●	○	●	●	○	
2004	Cadillac	Incomplete (hearse)	Tire pressure monitor	●	●	○	●	○	●	T022 T188 T189
2004	Cadillac	Incomplete (limousine)	Powertrain	●	●	●	●	●	○	
2004	Cadillac	Incomplete (limousine)	Onstar	●	●	●	●	●	●	T155 T191
2004	Cadillac	Incomplete (limousine)	Amplifier (delco)	●	●	○	●	●	●	T126 T127 T112 T136 T158 T094 T138 T175 T179 T086 T087 T033 T113 T199 T200

2004	Cadillac	Incomplete (limo usine)	Navigation radio	●	●	●	●	●	●	T166
2004	Cadillac	Incomplete (limo usine)	Driver door module	●	●	●	●	●	○	
2004	Cadillac	Incomplete (limo usine)	Passenger door module	●	●	●	●	●	○	
2004	Cadillac	Incomplete (limo usine)	Driver door switch	●	●	●	●	○	○	
2004	Cadillac	Incomplete (limo usine)	Left rear door module	●	●	●	●	●	○	
2004	Cadillac	Incomplete (limo usine)	Right rear door module	●	●	●	●	●	○	
2004	Cadillac	Incomplete (limo usine)	Left mid door module	●	●	●	●	●	○	
2004	Cadillac	Incomplete (limo usine)	Right mid door module	●	●	●	●	●	○	
2004	Cadillac	Incomplete (limo usine)	Rear climate control panel	●	●	○	●	●	○	
2004	Cadillac	Incomplete (limo usine)	DRP/ABS/TCS	●	●	○	●	●	○	
2004	Cadillac	Incomplete (limo usine)	Tire pressure monitor	●	●	○	●	○	●	T022 T188 T189
2004	Chevrolet	Astro - 2WD	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	Astro - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Astro - 2WD	Body control module	●	●	○	●	●	○	
2004	Chevrolet	Astro - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2004	Chevrolet	Astro - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	Chevrolet	Astro - 4WD	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	Astro - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Astro - 4WD	Body control module	●	●	○	●	●	○	
2004	Chevrolet	Astro - 4WD	Instrument panel cluster	●	●	○	●	●	○	

2004	Chevrolet	Astro - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	Chevrolet	Avalanche - 2WD	Powertrain	●	●	●	●	●	●	T169
2004	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2004	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2004	Chevrolet	Avalanche - 2WD	Chime	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 2WD	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 2WD	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Avalanche - 2WD	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 2WD	Rear HVAC	●	●	●	●	○	○	
2004	Chevrolet	Avalanche - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Avalanche - 2WD	CD changer	●	●	●	○	○	○	
2004	Chevrolet	Avalanche - 2WD	Radio	●	●	●	●	○	○	
2004	Chevrolet	Avalanche - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	Avalanche - 2WD	Rear seat audio	●	●	●	●	○	○	
2004	Chevrolet	Avalanche - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 2WD	Vehicle theft deterrent	●	●	●	●	●	●	T024
2004	Chevrolet	Avalanche - 2WD	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	Avalanche - 2WD	Rear wheel steering	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 2WD	ABS	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	Avalanche - 2WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	Chevrolet	Avalanche - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156

2004	Chevrolet	Avalanche - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	Chevrolet	Avalanche - 4WD	Powertrain	●	●	●	●	●	●	T169
2004	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2004	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2004	Chevrolet	Avalanche - 4WD	Chime	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 4WD	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 4WD	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Avalanche - 4WD	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 4WD	Rear HVAC	●	●	●	●	○	○	
2004	Chevrolet	Avalanche - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Avalanche - 4WD	CD changer	●	●	●	○	○	○	
2004	Chevrolet	Avalanche - 4WD	Radio	●	●	●	●	○	○	
2004	Chevrolet	Avalanche - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	Avalanche - 4WD	Rear seat audio	●	●	●	●	○	○	
2004	Chevrolet	Avalanche - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 4WD	Vehicle theft deterrent	●	●	●	●	●	●	T024
2004	Chevrolet	Avalanche - 4WD	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	Avalanche - 4WD	Rear wheel steering	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 4WD	ABS	●	●	●	●	●	○	
2004	Chevrolet	Avalanche - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	Avalanche - 4WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	Chevrolet	Avalanche - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156

2004	Chevrolet	Avalanche - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	Chevrolet	Blazer - 2WD	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	Blazer - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Blazer - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Blazer - 2WD	Memory seat module	●	●	●	●	○	○	
2004	Chevrolet	Blazer - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2004	Chevrolet	Blazer - 2WD	Body control module	●	●	○	●	●	○	
2004	Chevrolet	Blazer - 2WD	Radio	●	●	●	●	●	●	T039
2004	Chevrolet	Blazer - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	Chevrolet	Blazer - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	Chevrolet	Blazer - 2WD	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	Blazer - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Blazer - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Blazer - 2WD	Memory seat module	●	●	●	●	○	○	
2004	Chevrolet	Blazer - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2004	Chevrolet	Blazer - 2WD	Body control module	●	●	○	●	●	○	
2004	Chevrolet	Blazer - 2WD	Radio	●	●	●	●	●	●	T039
2004	Chevrolet	Blazer - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	Chevrolet	Blazer - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	Chevrolet	Blazer - 4WD	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	Blazer - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Blazer - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Blazer - 4WD	Memory seat module	●	●	●	●	○	○	
2004	Chevrolet	Blazer - 4WD	Instrument panel cluster	●	●	○	●	●	○	

2004	Chevrolet	Blazer - 4WD	Body control module	●	●	○	●	●	○	
2004	Chevrolet	Blazer - 4WD	Radio	●	●	●	●	●	●	T039
2004	Chevrolet	Blazer - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	Chevrolet	Blazer - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	Chevrolet	Blazer - 4WD	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	Blazer - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Blazer - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Blazer - 4WD	Memory seat module	●	●	●	●	○	○	
2004	Chevrolet	Blazer - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2004	Chevrolet	Blazer - 4WD	Body control module	●	●	○	●	●	○	
2004	Chevrolet	Blazer - 4WD	Radio	●	●	●	●	●	●	T039
2004	Chevrolet	Blazer - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	Chevrolet	Blazer - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	Chevrolet	C cab/chassis HD (GMT 400)	Powertrain	●	●	●	●	●	●	T169
2004	Chevrolet	C cab/chassis HD (GMT 400)	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	C cab/chassis HD (GMT 400)	Body control module	●	●	●	●	●	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	Passenger presence system	●	●	○	○	○	●	T020
2004	Chevrolet	C cab/chassis HD (GMT 400)	Amplifier (bose)	●	●	●	●	●	●	T139
2004	Chevrolet	C cab/chassis HD (GMT 400)	Chime	●	●	●	●	●	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	Passenger door module	●	●	●	●	●	○	

2004	Chevrolet	C cab/chassis HD (GMT 400)	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	C cab/chassis HD (GMT 400)	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	Rear HVAC	●	●	●	●	○	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	C cab/chassis HD (GMT 400)	CD changer	●	●	●	○	○	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	Radio	●	●	●	●	○	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	Rear seat audio	●	●	●	●	○	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	Rear aux. climate module	●	●	●	●	●	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	Vehicle theft deterrent	●	●	●	●	●	●	T024
2004	Chevrolet	C cab/chassis HD (GMT 400)	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	C cab/chassis HD (GMT 400)	Rear wheel steering	●	●	●	●	●	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	ABS	●	●	●	●	●	○	
2004	Chevrolet	C cab/chassis HD (GMT 400)	ESC (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	C cab/chassis HD (GMT 400)	Tire pressure monitor	●	●	○	●	●	●	T022

2004	Chevrolet	C cab/chassis HD (GMT 400)	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	C cab/chassis HD (GMT 400)	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	Chevrolet	C silverado - 2WD	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	C silverado - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	C silverado - 2WD	Body control module	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2004	Chevrolet	C silverado - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2004	Chevrolet	C silverado - 2WD	Chime	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	C silverado - 2WD	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD	Rear HVAC	●	●	●	●	○	○	
2004	Chevrolet	C silverado - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	C silverado - 2WD	CD changer	●	●	●	○	○	○	

2004	Chevrolet	C silverado - 2WD	Radio	●	●	●	●	○	○	
2004	Chevrolet	C silverado - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	C silverado - 2WD	Rear seat audio	●	●	●	●	○	○	
2004	Chevrolet	C silverado - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD	Vehicle theft deterrent	●	●	●	●	●	●	T024
2004	Chevrolet	C silverado - 2WD	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	C silverado - 2WD	Rear wheel steering	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD	ABS	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	C silverado - 2WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	Chevrolet	C silverado - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	C silverado - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	Chevrolet	C silverado - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	C silverado - 2WD (CNG)	Body control module	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Passenger presence system	●	●	○	○	○	●	T020

2004	Chevrolet	C silverado - 2WD (CNG)	Amplifier (bose)	●	●	●	●	●	●	T139
2004	Chevrolet	C silverado - 2WD (CNG)	Chime	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	C silverado - 2WD (CNG)	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Rear HVAC	●	●	●	●	○	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	C silverado - 2WD (CNG)	CD changer	●	●	●	○	○	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Radio	●	●	●	●	○	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Rear seat audio	●	●	●	●	○	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Rear aux. climate module	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD (CNG)	Vehicle theft deterrent	●	●	●	●	●	●	T024
2004	Chevrolet	C silverado - 2WD (CNG)	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	C silverado - 2WD (CNG)	Rear wheel steering	●	●	●	●	●	○	

2004	Chevrolet	C silverado - 2WD (CNG)	ABS	●	●	●	●	●	○	
2004	Chevrolet	C silverado - 2WD (CNG)	ESC (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	C silverado - 2WD (CNG)	Tire pressure monitor	●	●	○	●	●	●	T022
2004	Chevrolet	C silverado - 2WD (CNG)	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	C silverado - 2WD (CNG)	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	Chevrolet	Colorado pickup - 2WD	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Colorado pickup - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Colorado pickup - 2WD	Instrument panel cluster	●	●	●	●	●	●	T108
2004	Chevrolet	Colorado pickup - 2WD	Radio	●	●	●	●	○	○	
2004	Chevrolet	Colorado pickup - 2WD	Body control module	●	●	●	●	●	●	T058
2004	Chevrolet	Colorado pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Colorado pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2004	Chevrolet	Colorado pickup - 2WD	ABS	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Colorado pickup - 2WD	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Colorado pickup - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Colorado pickup - 2WD	Instrument panel cluster	●	●	●	●	●	●	T108
2004	Chevrolet	Colorado pickup - 2WD	Radio	●	●	●	●	○	○	

2004	Chevrolet	Colorado pickup - 2WD	Body control module	●	●	●	●	●	●	T058
2004	Chevrolet	Colorado pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Colorado pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2004	Chevrolet	Colorado pickup - 2WD	ABS	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Colorado pickup - 4WD	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Colorado pickup - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Colorado pickup - 4WD	Instrument panel cluster	●	●	●	●	●	●	T108
2004	Chevrolet	Colorado pickup - 4WD	Radio	●	●	●	●	○	○	
2004	Chevrolet	Colorado pickup - 4WD	Body control module	●	●	●	●	●	●	T058
2004	Chevrolet	Colorado pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Colorado pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2004	Chevrolet	Colorado pickup - 4WD	ABS	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Colorado pickup - 4WD	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Colorado pickup - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Colorado pickup - 4WD	Instrument panel cluster	●	●	●	●	●	●	T108
2004	Chevrolet	Colorado pickup - 4WD	Radio	●	●	●	●	○	○	
2004	Chevrolet	Colorado pickup - 4WD	Body control module	●	●	●	●	●	●	T058

2004	Chevrolet	Colorado pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Colorado pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2004	Chevrolet	Colorado pickup - 4WD	ABS	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Express	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	Express	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Express	Body control module	●	●	●	●	●	○	
2004	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Express	Remote function actuation	●	●	●	●	●	○	
2004	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	○	
2004	Chevrolet	Express	Radio	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Express	ABS	●	●	●	●	●	○	
2004	Chevrolet	Express	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	Express	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Express	Body control module	●	●	●	●	●	○	
2004	Chevrolet	Express	Remote function actuation	●	●	●	●	●	○	
2004	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	○	
2004	Chevrolet	Express	Radio	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Express	ABS	●	●	●	●	●	○	
2004	Chevrolet	Express	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Express	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Express	Body control module	●	●	●	●	●	○	

2004	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Express	Remote function actuation	●	●	●	●	●	○	
2004	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	○	
2004	Chevrolet	Express	Radio	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Express	ABS	●	●	●	●	●	○	
2004	Chevrolet	Express	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Express	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Express	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Express	Body control module	●	●	●	●	●	○	
2004	Chevrolet	Express	Remote function actuation	●	●	●	●	●	○	
2004	Chevrolet	Express	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Express	Multifunction alarm module	●	●	●	●	●	○	
2004	Chevrolet	Express	Radio	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Express	ABS	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	K silverado - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	K silverado - 4WD	Body control module	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2004	Chevrolet	K silverado - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139

2004	Chevrolet	K silverado - 4WD	Chime	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	K silverado - 4WD	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD	Rear HVAC	●	●	●	●	○	○	
2004	Chevrolet	K silverado - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	K silverado - 4WD	CD changer	●	●	●	○	○	○	
2004	Chevrolet	K silverado - 4WD	Radio	●	●	●	●	○	○	
2004	Chevrolet	K silverado - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	K silverado - 4WD	Rear seat audio	●	●	●	●	○	○	
2004	Chevrolet	K silverado - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD	Vehicle theft deterrent	●	●	●	●	●	●	T024
2004	Chevrolet	K silverado - 4WD	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	K silverado - 4WD	Rear wheel steering	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD	ABS	●	●	●	●	●	○	

2004	Chevrolet	K silverado - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	K silverado - 4WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	Chevrolet	K silverado - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	K silverado - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	Chevrolet	K silverado - 4WD (CNG)	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD (CNG)	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	K silverado - 4WD (CNG)	Body control module	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD (CNG)	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD (CNG)	Passenger presence system	●	●	○	○	○	●	T020
2004	Chevrolet	K silverado - 4WD (CNG)	Amplifier (bose)	●	●	●	●	●	●	T139
2004	Chevrolet	K silverado - 4WD (CNG)	Chime	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD (CNG)	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD (CNG)	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD (CNG)	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	K silverado - 4WD (CNG)	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD (CNG)	Rear HVAC	●	●	●	●	○	○	
2004	Chevrolet	K silverado - 4WD (CNG)	Heating and air conditioning	●	●	●	●	●	○	

2004	Chevrolet	K silverado - 4WD (CNG)	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	K silverado - 4WD (CNG)	CD changer	●	●	●	○	○	○	
2004	Chevrolet	K silverado - 4WD (CNG)	Radio	●	●	●	●	○	○	
2004	Chevrolet	K silverado - 4WD (CNG)	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	K silverado - 4WD (CNG)	Rear seat audio	●	●	●	●	○	○	
2004	Chevrolet	K silverado - 4WD (CNG)	Rear aux. climate module	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD (CNG)	Vehicle theft deterrent	●	●	●	●	●	●	T024
2004	Chevrolet	K silverado - 4WD (CNG)	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	K silverado - 4WD (CNG)	Rear wheel steering	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD (CNG)	ABS	●	●	●	●	●	○	
2004	Chevrolet	K silverado - 4WD (CNG)	ESC (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	K silverado - 4WD (CNG)	Tire pressure monitor	●	●	○	●	●	●	T022
2004	Chevrolet	K silverado - 4WD (CNG)	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	K silverado - 4WD (CNG)	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	Chevrolet	S10 pickup - 2WD	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	S10 pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	S10 pickup - 2WD	Instrument panel cluster	●	●	○	●	●	○	

2004	Chevrolet	S10 pickup - 2WD	Body control module	●	●	○	●	●	○	
2004	Chevrolet	S10 pickup - 2WD	Radio	●	●	●	●	●	●	T039
2004	Chevrolet	S10 pickup - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	Chevrolet	S10 pickup - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	Chevrolet	S10 pickup - 2WD	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	S10 pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	S10 pickup - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2004	Chevrolet	S10 pickup - 2WD	Body control module	●	●	○	●	●	○	
2004	Chevrolet	S10 pickup - 2WD	Radio	●	●	●	●	●	●	T039
2004	Chevrolet	S10 pickup - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	Chevrolet	S10 pickup - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	Chevrolet	S10 pickup - 4WD	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	S10 pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	S10 pickup - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2004	Chevrolet	S10 pickup - 4WD	Body control module	●	●	○	●	●	○	
2004	Chevrolet	S10 pickup - 4WD	Radio	●	●	●	●	●	●	T039
2004	Chevrolet	S10 pickup - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	

2004	Chevrolet	S10 pickup - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	Chevrolet	S10 pickup - 4WD	Powertrain	●	●	●	●	●	●	T146
2004	Chevrolet	S10 pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	S10 pickup - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2004	Chevrolet	S10 pickup - 4WD	Body control module	●	●	○	●	●	○	
2004	Chevrolet	S10 pickup - 4WD	Radio	●	●	●	●	●	●	T039
2004	Chevrolet	S10 pickup - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	Chevrolet	S10 pickup - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	Chevrolet	SSR	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	SSR	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	SSR	Roof and door module	●	●	●	●	●	○	
2004	Chevrolet	SSR	Amplifier (bose)	●	●	●	●	●	○	
2004	Chevrolet	SSR	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	SSR	Radio	●	●	●	●	○	●	T032
2004	Chevrolet	SSR	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	SSR	Body control module	●	●	●	●	●	○	
2004	Chevrolet	SSR	Remote function actuation	●	●	●	●	●	○	
2004	Chevrolet	SSR	Traction assist (if equipped)	●	●	○	●	●	○	
2004	Chevrolet	SSR	4WAL 3 sensor	●	●	○	●	●	○	
2004	Chevrolet	Suburban - 2WD	Powertrain	●	●	●	●	●	●	T169
2004	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	○	

2004	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2004	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2004	Chevrolet	Suburban - 2WD	Chime	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 2WD	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 2WD	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Suburban - 2WD	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 2WD	Rear HVAC	●	●	●	●	○	○	
2004	Chevrolet	Suburban - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Suburban - 2WD	CD changer	●	●	●	○	○	○	
2004	Chevrolet	Suburban - 2WD	Radio	●	●	●	●	○	○	
2004	Chevrolet	Suburban - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	Suburban - 2WD	Rear seat audio	●	●	●	●	○	○	
2004	Chevrolet	Suburban - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 2WD	Vehicle theft deterrent	●	●	●	●	●	●	T024
2004	Chevrolet	Suburban - 2WD	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	Suburban - 2WD	Rear wheel steering	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 2WD	ABS	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	Suburban - 2WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	Chevrolet	Suburban - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	Suburban - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	Chevrolet	Suburban - 4WD	Powertrain	●	●	●	●	●	●	T169
2004	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	○	

2004	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2004	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2004	Chevrolet	Suburban - 4WD	Chime	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 4WD	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 4WD	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Suburban - 4WD	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 4WD	Rear HVAC	●	●	●	●	○	○	
2004	Chevrolet	Suburban - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Suburban - 4WD	CD changer	●	●	●	○	○	○	
2004	Chevrolet	Suburban - 4WD	Radio	●	●	●	●	○	○	
2004	Chevrolet	Suburban - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	Suburban - 4WD	Rear seat audio	●	●	●	●	○	○	
2004	Chevrolet	Suburban - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 4WD	Vehicle theft deterrent	●	●	●	●	●	●	T024
2004	Chevrolet	Suburban - 4WD	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	Suburban - 4WD	Rear wheel steering	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 4WD	ABS	●	●	●	●	●	○	
2004	Chevrolet	Suburban - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	Suburban - 4WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	Chevrolet	Suburban - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	Suburban - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	Chevrolet	Tahoe - 2WD	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Tahoe - 2WD	Body control module	●	●	●	●	●	○	

2004	Chevrolet	Tahoe - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2004	Chevrolet	Tahoe - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2004	Chevrolet	Tahoe - 2WD	Chime	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 2WD	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 2WD	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Tahoe - 2WD	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 2WD	Rear HVAC	●	●	●	●	○	○	
2004	Chevrolet	Tahoe - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Tahoe - 2WD	CD changer	●	●	●	○	○	○	
2004	Chevrolet	Tahoe - 2WD	Radio	●	●	●	●	○	○	
2004	Chevrolet	Tahoe - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	Tahoe - 2WD	Rear seat audio	●	●	●	●	○	○	
2004	Chevrolet	Tahoe - 2WD	Rear aux. climate module	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 2WD	Vehicle theft deterrent	●	●	●	●	●	●	T024
2004	Chevrolet	Tahoe - 2WD	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	Tahoe - 2WD	Rear wheel steering	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 2WD	ABS	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	Tahoe - 2WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	Chevrolet	Tahoe - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	Tahoe - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	Chevrolet	Tahoe - 4WD	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Tahoe - 4WD	Body control module	●	●	●	●	●	○	

2004	Chevrolet	Tahoe - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2004	Chevrolet	Tahoe - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2004	Chevrolet	Tahoe - 4WD	Chime	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 4WD	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 4WD	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Tahoe - 4WD	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 4WD	Rear HVAC	●	●	●	●	○	○	
2004	Chevrolet	Tahoe - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Tahoe - 4WD	CD changer	●	●	●	○	○	○	
2004	Chevrolet	Tahoe - 4WD	Radio	●	●	●	●	○	○	
2004	Chevrolet	Tahoe - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	Tahoe - 4WD	Rear seat audio	●	●	●	●	○	○	
2004	Chevrolet	Tahoe - 4WD	Rear aux. climate module	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 4WD	Vehicle theft deterrent	●	●	●	●	●	●	T024
2004	Chevrolet	Tahoe - 4WD	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	Tahoe - 4WD	Rear wheel steering	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 4WD	ABS	●	●	●	●	●	○	
2004	Chevrolet	Tahoe - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	Tahoe - 4WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	Chevrolet	Tahoe - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	Chevrolet	Tahoe - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	Chevrolet	Tracker - 2WD	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Tracker - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	

2004	Chevrolet	Tracker - 2WD	Chassis	●	●	●	●	●	●	T014
2004	Chevrolet	Tracker - 4WD	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Tracker - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2004	Chevrolet	Tracker - 4WD	Chassis	●	●	●	●	●	●	T014
2004	Chevrolet	Trailblazer	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Trailblazer	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Trailblazer	Body control module	●	●	●	●	●	●	T058
2004	Chevrolet	Trailblazer	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Trailblazer	Amplifier (bose)	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Radio	●	●	●	●	○	●	T032
2004	Chevrolet	Trailblazer	Rear seat audio	●	●	●	●	○	○	
2004	Chevrolet	Trailblazer	Lift gate module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	Trailblazer	Vehicle theft deterrent	●	●	●	●	●	●	T058
2004	Chevrolet	Trailblazer	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	Trailblazer	ABS	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	4WAL 3 sensor	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Trailblazer	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Trailblazer	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Trailblazer	Body control module	●	●	●	●	●	●	T058
2004	Chevrolet	Trailblazer	Instrument panel cluster	●	●	●	●	●	○	

2004	Chevrolet	Trailblazer	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Trailblazer	Amplifier (bose)	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Radio	●	●	●	●	○	●	T032
2004	Chevrolet	Trailblazer	Rear seat audio	●	●	●	●	○	○	
2004	Chevrolet	Trailblazer	Lift gate module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	Trailblazer	Vehicle theft deterrent	●	●	●	●	●	●	T058
2004	Chevrolet	Trailblazer	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	Trailblazer	ABS	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	4WAL 3 sensor	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Trailblazer	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Trailblazer	Memory seat module	●	●	●	●	○	○	
2004	Chevrolet	Trailblazer	Instrument panel cluster	●	●	○	●	●	○	
2004	Chevrolet	Trailblazer	Body control module	●	●	○	●	●	○	
2004	Chevrolet	Trailblazer	Radio	●	●	●	●	●	●	T039
2004	Chevrolet	Trailblazer	4WAL 3 sensor	●	●	○	●	●	○	
2004	Chevrolet	Trailblazer	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Trailblazer	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Trailblazer	Body control module	●	●	●	●	●	●	T058
2004	Chevrolet	Trailblazer	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Driver door module	●	●	●	●	●	○	

2004	Chevrolet	Trailblazer	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Trailblazer	Amplifier (bose)	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Radio	●	●	●	●	○	●	T032
2004	Chevrolet	Trailblazer	Rear HVAC/RSA	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Lift gate module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	Trailblazer	Vehicle theft deterrent	●	●	●	●	●	●	T058
2004	Chevrolet	Trailblazer	Rear HVAC	●	●	●	●	●	●	T058
2004	Chevrolet	Trailblazer	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	Trailblazer	ABS	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer	4WAL 3 sensor	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Trailblazer EXT	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Trailblazer EXT	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Trailblazer EXT	Body control module	●	●	●	●	●	●	T058
2004	Chevrolet	Trailblazer EXT	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Trailblazer EXT	Amplifier (bose)	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Radio	●	●	●	●	○	●	T032
2004	Chevrolet	Trailblazer EXT	Rear HVAC/RSA	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Lift gate module	●	●	●	●	●	○	

2004	Chevrolet	Trailblazer EXT	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	Trailblazer EXT	Vehicle theft deterrent	●	●	●	●	●	●	T058
2004	Chevrolet	Trailblazer EXT	Rear HVAC	●	●	●	●	●	●	T058
2004	Chevrolet	Trailblazer EXT	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	Trailblazer EXT	ABS	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	4WAL 3 sensor	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Trailblazer EXT	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Trailblazer EXT	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Trailblazer EXT	Body control module	●	●	●	●	●	●	T058
2004	Chevrolet	Trailblazer EXT	Instrument panel cluster	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Driver door module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Passenger door module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Driver seat module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Heating and air conditioning	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Trailblazer EXT	Amplifier (bose)	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Radio	●	●	●	●	○	●	T032
2004	Chevrolet	Trailblazer EXT	Rear HVAC/RSA	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Lift gate module	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	Rear seat entertainment	●	●	●	○	○	○	
2004	Chevrolet	Trailblazer EXT	Vehicle theft deterrent	●	●	●	●	●	●	T058
2004	Chevrolet	Trailblazer EXT	Rear HVAC	●	●	●	●	●	●	T058
2004	Chevrolet	Trailblazer EXT	Navigation radio	●	●	●	●	●	●	T033
2004	Chevrolet	Trailblazer EXT	ABS	●	●	●	●	●	○	
2004	Chevrolet	Trailblazer EXT	4WAL 3 sensor	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Blazer	Heating and air conditioning	●	●	●	●	●	○	

2004	Chevrolet	Blazer	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Chevrolet	Blazer	Memory seat module	●	●	●	●	○	○	
2004	Chevrolet	Blazer	Instrument panel cluster	●	●	○	●	●	○	
2004	Chevrolet	Blazer	Body control module	●	●	○	●	●	○	
2004	Chevrolet	Blazer	Radio	●	●	●	●	●	●	T039
2004	Chevrolet	Blazer	Traction assist (if equipped)	●	●	○	●	●	○	
2004	Chevrolet	Blazer	4WAL 3 sensor	●	●	○	●	●	○	
2004	Chevrolet	Venture	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Venture	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Venture	Supplemental inflatable restraint	●	●	○	●	○	○	
2004	Chevrolet	Venture	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080
2004	Chevrolet	Venture	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Venture	Radio	●	●	●	●	●	●	T032
2004	Chevrolet	Venture	Chassis	●	●	●	●	●	●	T014
2004	Chevrolet	Vivant	Powertrain	●	●	●	●	●	○	
2004	Chevrolet	Vivant	Onstar	●	●	●	●	●	●	T155 T191
2004	Chevrolet	Vivant	Supplemental inflatable restraint	●	●	○	●	○	○	
2004	Chevrolet	Vivant	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080
2004	Chevrolet	Vivant	Digital radio receiver	●	●	●	●	○	●	T024
2004	Chevrolet	Vivant	Radio	●	●	●	●	●	●	T032
2004	Chevrolet	Vivant	Chassis	●	●	●	●	●	●	T014
2004	Chevrolet	Others	Chassis	●	●	●	●	●	●	T014
2004	GMC truck	Canyon pickup - 2WD	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Canyon pickup - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	●	T108

2004	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	
2004	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2004	GMC truck	Canyon pickup - 2WD	ABS	●	●	●	●	●	●	T155 T191
2004	GMC truck	Canyon pickup - 2WD	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Canyon pickup - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Canyon pickup - 2WD	Instrument panel cluster	●	●	●	●	●	●	T108
2004	GMC truck	Canyon pickup - 2WD	Radio	●	●	●	●	○	○	
2004	GMC truck	Canyon pickup - 2WD	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Canyon pickup - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Canyon pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2004	GMC truck	Canyon pickup - 2WD	ABS	●	●	●	●	●	●	T155 T191
2004	GMC truck	Canyon pickup - 4WD	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Canyon pickup - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	●	T108
2004	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	

2004	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2004	GMC truck	Canyon pickup - 4WD	ABS	●	●	●	●	●	●	T155 T191
2004	GMC truck	Canyon pickup - 4WD	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Canyon pickup - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Canyon pickup - 4WD	Instrument panel cluster	●	●	●	●	●	●	T108
2004	GMC truck	Canyon pickup - 4WD	Radio	●	●	●	●	○	○	
2004	GMC truck	Canyon pickup - 4WD	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Canyon pickup - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Canyon pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T023
2004	GMC truck	Canyon pickup - 4WD	ABS	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Envoy	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Heating and air conditioning	●	●	●	●	●	○	

2004	GMC truck	Envoy	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy	Radio	●	●	●	●	○	●	T032
2004	GMC truck	Envoy	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Envoy	Lift gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Rear seat entertainment	●	●	●	●	●	●	T058
2004	GMC truck	Envoy	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy	ABS	●	●	●	●	●	○	
2004	GMC truck	Envoy	4WAL 3 sensor	●	●	○	●	●	○	
2004	GMC truck	Envoy	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Envoy	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Envoy	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy	Radio	●	●	●	●	○	●	T032
2004	GMC truck	Envoy	Rear HVAC/RSA	●	●	●	●	●	○	
2004	GMC truck	Envoy	Lift gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Rear seat entertainment	●	●	●	●	●	●	T058
2004	GMC truck	Envoy	Rear HVAC	●	●	●	●	●	●	T058
2004	GMC truck	Envoy	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy	ABS	●	●	●	●	●	○	
2004	GMC truck	Envoy	4WAL 3 sensor	●	●	○	●	●	○	
2004	GMC truck	Envoy	Powertrain	●	●	●	●	●	○	

2004	GMC truck	Envoy	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Envoy	End gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Envoy	Power roof module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy	Radio	●	●	●	●	○	●	T032
2004	GMC truck	Envoy	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Envoy	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy	ABS	●	●	●	●	●	○	
2004	GMC truck	Envoy	4WAL 3 sensor	●	●	○	●	●	○	
2004	GMC truck	Envoy	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Envoy	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Envoy	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy	Radio	●	●	●	●	○	●	T032

2004	GMC truck	Envoy	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Envoy	Lift gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Rear seat entertainment	●	●	●	●	●	●	T058
2004	GMC truck	Envoy	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy	ABS	●	●	●	●	●	○	
2004	GMC truck	Envoy	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Envoy	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Envoy	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy	Radio	●	●	●	●	○	●	T032
2004	GMC truck	Envoy	Rear HVAC/RSA	●	●	●	●	●	○	
2004	GMC truck	Envoy	Lift gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Rear seat entertainment	●	●	●	●	●	●	T058
2004	GMC truck	Envoy	Rear HVAC	●	●	●	●	●	●	T058
2004	GMC truck	Envoy	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy	ABS	●	●	●	●	●	○	
2004	GMC truck	Envoy	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Envoy	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Envoy	End gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy	Driver door module	●	●	●	●	●	○	

2004	GMC truck	Envoy	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Envoy	Power roof module	●	●	●	●	●	○	
2004	GMC truck	Envoy	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy	Radio	●	●	●	●	○	●	T032
2004	GMC truck	Envoy	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Envoy	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy	ABS	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy XL	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Envoy XL	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XL	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy XL	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Radio	●	●	●	●	○	●	T032
2004	GMC truck	Envoy XL	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Envoy XL	Lift gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Rear seat entertainment	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XL	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy XL	ABS	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	4WAL 3 sensor	●	●	○	●	●	○	

2004	GMC truck	Envoy XL	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy XL	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Envoy XL	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XL	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy XL	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Radio	●	●	●	●	○	●	T032
2004	GMC truck	Envoy XL	Rear HVAC/RSA	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Lift gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Rear seat entertainment	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XL	Rear HVAC	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XL	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy XL	ABS	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	4WAL 3 sensor	●	●	○	●	●	○	
2004	GMC truck	Envoy XL	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy XL	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Envoy XL	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XL	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Heating and air conditioning	●	●	●	●	●	○	

2004	GMC truck	Envoy XL	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy XL	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Radio	●	●	●	●	○	●	T032
2004	GMC truck	Envoy XL	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Envoy XL	Lift gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Rear seat entertainment	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XL	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy XL	ABS	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy XL	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Envoy XL	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XL	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy XL	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Radio	●	●	●	●	○	●	T032
2004	GMC truck	Envoy XL	Rear HVAC/RSA	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Lift gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy XL	Rear seat entertainment	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XL	Rear HVAC	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XL	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy XL	ABS	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy XUV	Digital radio receiver	●	●	●	●	○	●	T024

2004	GMC truck	Envoy XUV	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XUV	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy XUV	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Radio	●	●	●	●	○	●	T032
2004	GMC truck	Envoy XUV	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Envoy XUV	Lift gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Rear seat entertainment	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XUV	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy XUV	ABS	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	4WAL 3 sensor	●	●	○	●	●	○	
2004	GMC truck	Envoy XUV	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Envoy XUV	End gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XUV	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Power roof module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy XUV	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Radio	●	●	●	●	○	●	T032

2004	GMC truck	Envoy XUV	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Envoy XUV	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy XUV	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy XUV	ABS	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	4WAL 3 sensor	●	●	○	●	●	○	
2004	GMC truck	Envoy XUV	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy XUV	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Envoy XUV	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XUV	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy XUV	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Radio	●	●	●	●	○	●	T032
2004	GMC truck	Envoy XUV	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Envoy XUV	Lift gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Rear seat entertainment	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XUV	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy XUV	ABS	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Envoy XUV	End gate module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Body control module	●	●	●	●	●	●	T058
2004	GMC truck	Envoy XUV	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Driver seat module	●	●	●	●	●	○	

2004	GMC truck	Envoy XUV	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Power roof module	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Envoy XUV	Amplifier (bose)	●	●	●	●	●	○	
2004	GMC truck	Envoy XUV	Radio	●	●	●	●	○	●	T032
2004	GMC truck	Envoy XUV	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Envoy XUV	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Envoy XUV	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Envoy XUV	ABS	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	GMC c-series - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	GMC c-series - 2WD	Body control module	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2004	GMC truck	GMC c-series - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2004	GMC truck	GMC c-series - 2WD	Chime	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD	Driver door module	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	GMC c-series - 2WD	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD	Rear HVAC	●	●	●	●	○	○	

2004	GMC truck	GMC c-series - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	GMC c-series - 2WD	CD changer	●	●	●	○	○	○	
2004	GMC truck	GMC c-series - 2WD	Radio	●	●	●	●	○	○	
2004	GMC truck	GMC c-series - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2004	GMC truck	GMC c-series - 2WD	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	GMC c-series - 2WD	Rear aux. climate module	●	●	●	●	●	●	T024
2004	GMC truck	GMC c-series - 2WD	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	GMC c-series - 2WD	Rear wheel steering	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD	ABS	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	GMC c-series - 2WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	GMC truck	GMC c-series - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	GMC c-series - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	GMC truck	GMC c-series - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	GMC c-series - 2WD (CNG)	Body control module	●	●	●	●	●	○	

2004	GMC truck	GMC c-series - 2WD (CNG)	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	Passenger presence system	●	●	○	○	○	●	T020
2004	GMC truck	GMC c-series - 2WD (CNG)	Amplifier (bose)	●	●	●	●	●	●	T139
2004	GMC truck	GMC c-series - 2WD (CNG)	Chime	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	Driver door module	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	GMC c-series - 2WD (CNG)	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	Rear HVAC	●	●	●	●	○	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	GMC c-series - 2WD (CNG)	CD changer	●	●	●	○	○	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	Radio	●	●	●	●	○	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	Rear seat entertainment	●	●	●	○	○	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	Rear aux. climate module	●	●	●	●	●	●	T024
2004	GMC truck	GMC c-series - 2WD (CNG)	Navigation radio	●	●	●	●	●	●	T033

2004	GMC truck	GMC c-series - 2WD (CNG)	Rear wheel steering	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	ABS	●	●	●	●	●	○	
2004	GMC truck	GMC c-series - 2WD (CNG)	ESC (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	GMC c-series - 2WD (CNG)	Tire pressure monitor	●	●	○	●	●	●	T022
2004	GMC truck	GMC c-series - 2WD (CNG)	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	GMC c-series - 2WD (CNG)	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	GMC truck	GMC K sierra - 4WD	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	GMC K sierra - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	GMC K sierra - 4WD	Body control module	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2004	GMC truck	GMC K sierra - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2004	GMC truck	GMC K sierra - 4WD	Chime	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD	Driver door module	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	GMC K sierra - 4WD	Driver seat module	●	●	●	●	●	○	

2004	GMC truck	GMC K sierra - 4WD	Rear HVAC	●	●	●	●	○	○	
2004	GMC truck	GMC K sierra - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	GMC K sierra - 4WD	CD changer	●	●	●	○	○	○	
2004	GMC truck	GMC K sierra - 4WD	Radio	●	●	●	●	○	○	
2004	GMC truck	GMC K sierra - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2004	GMC truck	GMC K sierra - 4WD	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	GMC K sierra - 4WD	Rear aux. climate module	●	●	●	●	●	●	T024
2004	GMC truck	GMC K sierra - 4WD	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	GMC K sierra - 4WD	Rear wheel steering	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD	ABS	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	GMC K sierra - 4WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	GMC truck	GMC K sierra - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	GMC K sierra - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	GMC truck	GMC K sierra - 4WD (CNG)	Powertrain	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	Digital radio receiver	●	●	●	●	○	●	T024

2004	GMC truck	GMC K sierra - 4WD (CNG)	Body control module	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	Passenger presence system	●	●	○	○	○	●	T020
2004	GMC truck	GMC K sierra - 4WD (CNG)	Amplifier (bose)	●	●	●	●	●	●	T139
2004	GMC truck	GMC K sierra - 4WD (CNG)	Chime	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	Driver door module	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	GMC K sierra - 4WD (CNG)	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	Rear HVAC	●	●	●	●	○	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	GMC K sierra - 4WD (CNG)	CD changer	●	●	●	○	○	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	Radio	●	●	●	●	○	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	Rear seat entertainment	●	●	●	○	○	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	Rear aux. climate module	●	●	●	●	●	●	T024

2004	GMC truck	GMC K sierra - 4WD (CNG)	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	GMC K sierra - 4WD (CNG)	Rear wheel steering	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	ABS	●	●	●	●	●	○	
2004	GMC truck	GMC K sierra - 4WD (CNG)	ESC (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	GMC K sierra - 4WD (CNG)	Tire pressure monitor	●	●	○	●	●	●	T022
2004	GMC truck	GMC K sierra - 4WD (CNG)	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	GMC K sierra - 4WD (CNG)	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	GMC truck	GMC sierra denali	Powertrain	●	●	●	●	●	○	
2004	GMC truck	GMC sierra denali	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	GMC sierra denali	Body control module	●	●	●	●	●	○	
2004	GMC truck	GMC sierra denali	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	GMC sierra denali	Passenger presence system	●	●	○	○	○	●	T020
2004	GMC truck	GMC sierra denali	Amplifier (bose)	●	●	●	●	●	●	T139
2004	GMC truck	GMC sierra denali	Chime	●	●	●	●	●	○	
2004	GMC truck	GMC sierra denali	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	GMC sierra denali	Driver door module	●	●	●	●	●	○	
2004	GMC truck	GMC sierra denali	Onstar	●	●	●	●	●	●	T155 T191

2004	GMC truck	GMC sierra denali	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	GMC sierra denali	Rear HVAC	●	●	●	●	○	○	
2004	GMC truck	GMC sierra denali	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	GMC sierra denali	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	GMC sierra denali	CD changer	●	●	●	○	○	○	
2004	GMC truck	GMC sierra denali	Radio	●	●	●	●	○	○	
2004	GMC truck	GMC sierra denali	Rear seat entertainment	●	●	●	○	○	○	
2004	GMC truck	GMC sierra denali	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	GMC sierra denali	Rear aux. climate module	●	●	●	●	●	●	T024
2004	GMC truck	GMC sierra denali	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	GMC sierra denali	Rear wheel steering	●	●	●	●	●	○	
2004	GMC truck	GMC sierra denali	ABS	●	●	●	●	●	○	
2004	GMC truck	GMC sierra denali	ESC (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	GMC sierra denali	Tire pressure monitor	●	●	○	●	●	●	T022
2004	GMC truck	GMC sierra denali	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	GMC sierra denali	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	GMC truck	Jimmy - 2WD	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	Jimmy - 2WD	Heating and air conditioning	●	●	●	●	●	○	

2004	GMC truck	Jimmy - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Jimmy - 2WD	Memory seat module	●	●	●	●	○	○	
2004	GMC truck	Jimmy - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2004	GMC truck	Jimmy - 2WD	Body control module	●	●	○	●	●	○	
2004	GMC truck	Jimmy - 2WD	Radio	●	●	●	●	●	●	T039
2004	GMC truck	Jimmy - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	GMC truck	Jimmy - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	GMC truck	Jimmy - 2WD	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	Jimmy - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Jimmy - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Jimmy - 2WD	Memory seat module	●	●	●	●	○	○	
2004	GMC truck	Jimmy - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2004	GMC truck	Jimmy - 2WD	Body control module	●	●	○	●	●	○	
2004	GMC truck	Jimmy - 2WD	Radio	●	●	●	●	●	●	T039
2004	GMC truck	Jimmy - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	GMC truck	Jimmy - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	GMC truck	Jimmy - 4WD	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	Jimmy - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Jimmy - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Jimmy - 4WD	Memory seat module	●	●	●	●	○	○	
2004	GMC truck	Jimmy - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2004	GMC truck	Jimmy - 4WD	Body control module	●	●	○	●	●	○	
2004	GMC truck	Jimmy - 4WD	Radio	●	●	●	●	●	●	T039
2004	GMC truck	Jimmy - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	

2004	GMC truck	Jimmy - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	GMC truck	Jimmy - 4WD	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	Jimmy - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Jimmy - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Jimmy - 4WD	Memory seat module	●	●	●	●	○	○	
2004	GMC truck	Jimmy - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2004	GMC truck	Jimmy - 4WD	Body control module	●	●	○	●	●	○	
2004	GMC truck	Jimmy - 4WD	Radio	●	●	●	●	●	●	T039
2004	GMC truck	Jimmy - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	GMC truck	Jimmy - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	GMC truck	Safari - 2WD	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	Safari - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Safari - 2WD	Body control module	●	●	○	●	●	○	
2004	GMC truck	Safari - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2004	GMC truck	Safari - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	GMC truck	Safari - 4WD	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	Safari - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Safari - 4WD	Body control module	●	●	○	●	●	○	
2004	GMC truck	Safari - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2004	GMC truck	Safari - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	GMC truck	Savana	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	Savana	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Savana	Body control module	●	●	●	●	●	○	
2004	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Savana	Remote function actuation	●	●	●	●	●	○	

2004	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	○	
2004	GMC truck	Savana	Radio	●	●	●	●	●	●	T155 T191
2004	GMC truck	Savana	ABS	●	●	●	●	●	○	
2004	GMC truck	Savana	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	Savana	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Savana	Body control module	●	●	●	●	●	○	
2004	GMC truck	Savana	Remote function actuation	●	●	●	●	●	○	
2004	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	○	
2004	GMC truck	Savana	Radio	●	●	●	●	●	●	T155 T191
2004	GMC truck	Savana	ABS	●	●	●	●	●	○	
2004	GMC truck	Savana	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Savana	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Savana	Body control module	●	●	●	●	●	○	
2004	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Savana	Remote function actuation	●	●	●	●	●	○	
2004	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	○	
2004	GMC truck	Savana	Radio	●	●	●	●	●	●	T155 T191
2004	GMC truck	Savana	ABS	●	●	●	●	●	○	
2004	GMC truck	Savana	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Savana	Onstar	●	●	●	●	●	●	T155 T191

2004	GMC truck	Savana	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Savana	Body control module	●	●	●	●	●	○	
2004	GMC truck	Savana	Remote function actuation	●	●	●	●	●	○	
2004	GMC truck	Savana	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Savana	Multifunction alarm module	●	●	●	●	●	○	
2004	GMC truck	Savana	Radio	●	●	●	●	●	●	T155 T191
2004	GMC truck	Savana	ABS	●	●	●	●	●	○	
2004	GMC truck	Sonoma pickup - 2WD	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	Sonoma pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Sonoma pickup - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2004	GMC truck	Sonoma pickup - 2WD	Body control module	●	●	○	●	●	○	
2004	GMC truck	Sonoma pickup - 2WD	Radio	●	●	●	●	●	●	T039
2004	GMC truck	Sonoma pickup - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	GMC truck	Sonoma pickup - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	GMC truck	Sonoma pickup - 2WD	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	Sonoma pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Sonoma pickup - 2WD	Instrument panel cluster	●	●	○	●	●	○	
2004	GMC truck	Sonoma pickup - 2WD	Body control module	●	●	○	●	●	○	
2004	GMC truck	Sonoma pickup - 2WD	Radio	●	●	●	●	●	●	T039

2004	GMC truck	Sonoma pickup - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	GMC truck	Sonoma pickup - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	GMC truck	Sonoma pickup - 4WD	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	Sonoma pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Sonoma pickup - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2004	GMC truck	Sonoma pickup - 4WD	Body control module	●	●	○	●	●	○	
2004	GMC truck	Sonoma pickup - 4WD	Radio	●	●	●	●	●	●	T039
2004	GMC truck	Sonoma pickup - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	GMC truck	Sonoma pickup - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	GMC truck	Sonoma pickup - 4WD	Powertrain	●	●	●	●	●	●	T146
2004	GMC truck	Sonoma pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Sonoma pickup - 4WD	Instrument panel cluster	●	●	○	●	●	○	
2004	GMC truck	Sonoma pickup - 4WD	Body control module	●	●	○	●	●	○	
2004	GMC truck	Sonoma pickup - 4WD	Radio	●	●	●	●	●	●	T039
2004	GMC truck	Sonoma pickup - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2004	GMC truck	Sonoma pickup - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T146
2004	GMC truck	Yukon - 2WD	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Yukon - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Yukon - 2WD	Body control module	●	●	●	●	●	○	

2004	GMC truck	Yukon - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Yukon - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2004	GMC truck	Yukon - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2004	GMC truck	Yukon - 2WD	Chime	●	●	●	●	●	○	
2004	GMC truck	Yukon - 2WD	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Yukon - 2WD	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Yukon - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Yukon - 2WD	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Yukon - 2WD	Rear HVAC	●	●	●	●	○	○	
2004	GMC truck	Yukon - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Yukon - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Yukon - 2WD	CD changer	●	●	●	○	○	○	
2004	GMC truck	Yukon - 2WD	Radio	●	●	●	●	○	○	
2004	GMC truck	Yukon - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2004	GMC truck	Yukon - 2WD	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Yukon - 2WD	Rear aux. climate module	●	●	●	●	●	●	T024
2004	GMC truck	Yukon - 2WD	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Yukon - 2WD	Rear wheel steering	●	●	●	●	●	○	
2004	GMC truck	Yukon - 2WD	ABS	●	●	●	●	●	○	
2004	GMC truck	Yukon - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon - 2WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	GMC truck	Yukon - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon - 4WD	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Yukon - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Yukon - 4WD	Body control module	●	●	●	●	●	○	
2004	GMC truck	Yukon - 4WD	Instrument panel cluster	●	●	●	●	●	○	

2004	GMC truck	Yukon - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2004	GMC truck	Yukon - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2004	GMC truck	Yukon - 4WD	Chime	●	●	●	●	●	○	
2004	GMC truck	Yukon - 4WD	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Yukon - 4WD	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Yukon - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Yukon - 4WD	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Yukon - 4WD	Rear HVAC	●	●	●	●	○	○	
2004	GMC truck	Yukon - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Yukon - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Yukon - 4WD	CD changer	●	●	●	○	○	○	
2004	GMC truck	Yukon - 4WD	Radio	●	●	●	●	○	○	
2004	GMC truck	Yukon - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2004	GMC truck	Yukon - 4WD	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Yukon - 4WD	Rear aux. climate module	●	●	●	●	●	●	T024
2004	GMC truck	Yukon - 4WD	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Yukon - 4WD	Rear wheel steering	●	●	●	●	●	○	
2004	GMC truck	Yukon - 4WD	ABS	●	●	●	●	●	○	
2004	GMC truck	Yukon - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon - 4WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	GMC truck	Yukon - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon denali	Powertrain	●	●	●	●	●	○	
2004	GMC truck	Yukon denali	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Yukon denali	Body control module	●	●	●	●	●	○	
2004	GMC truck	Yukon denali	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Yukon denali	Passenger presence system	●	●	○	○	○	●	T020

2004	GMC truck	Yukon denali	Amplifier (bose)	●	●	●	●	●	●	T139
2004	GMC truck	Yukon denali	Chime	●	●	●	●	●	○	
2004	GMC truck	Yukon denali	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Yukon denali	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Yukon denali	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Yukon denali	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Yukon denali	Rear HVAC	●	●	●	●	○	○	
2004	GMC truck	Yukon denali	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Yukon denali	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Yukon denali	CD changer	●	●	●	○	○	○	
2004	GMC truck	Yukon denali	Radio	●	●	●	●	○	○	
2004	GMC truck	Yukon denali	Rear seat entertainment	●	●	●	○	○	○	
2004	GMC truck	Yukon denali	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Yukon denali	Rear aux. climate module	●	●	●	●	●	●	T024
2004	GMC truck	Yukon denali	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Yukon denali	Rear wheel steering	●	●	●	●	●	○	
2004	GMC truck	Yukon denali	ABS	●	●	●	●	●	○	
2004	GMC truck	Yukon denali	ESC (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon denali	Tire pressure monitor	●	●	○	●	●	●	T022
2004	GMC truck	Yukon denali	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon denali	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon XL - 2WD	Powertrain	●	●	●	●	●	●	T169
2004	GMC truck	Yukon XL - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Yukon XL - 2WD	Body control module	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 2WD	Passenger presence system	●	●	○	○	○	●	T020
2004	GMC truck	Yukon XL - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2004	GMC truck	Yukon XL - 2WD	Chime	●	●	●	●	●	○	

2004	GMC truck	Yukon XL - 2WD	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 2WD	Driver door module	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Yukon XL - 2WD	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 2WD	Rear HVAC	●	●	●	●	○	○	
2004	GMC truck	Yukon XL - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Yukon XL - 2WD	CD changer	●	●	●	○	○	○	
2004	GMC truck	Yukon XL - 2WD	Radio	●	●	●	●	○	○	
2004	GMC truck	Yukon XL - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2004	GMC truck	Yukon XL - 2WD	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Yukon XL - 2WD	Rear aux. climate module	●	●	●	●	●	●	T024
2004	GMC truck	Yukon XL - 2WD	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Yukon XL - 2WD	Rear wheel steering	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 2WD	ABS	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon XL - 2WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	GMC truck	Yukon XL - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon XL - 2WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon XL - 4WD	Powertrain	●	●	●	●	●	●	T169
2004	GMC truck	Yukon XL - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	GMC truck	Yukon XL - 4WD	Body control module	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 4WD	Passenger presence system	●	●	○	○	○	●	T020
2004	GMC truck	Yukon XL - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2004	GMC truck	Yukon XL - 4WD	Chime	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 4WD	Passenger door module	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 4WD	Driver door module	●	●	●	●	●	○	

2004	GMC truck	Yukon XL - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2004	GMC truck	Yukon XL - 4WD	Driver seat module	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 4WD	Rear HVAC	●	●	●	●	○	○	
2004	GMC truck	Yukon XL - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 4WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	GMC truck	Yukon XL - 4WD	CD changer	●	●	●	○	○	○	
2004	GMC truck	Yukon XL - 4WD	Radio	●	●	●	●	○	○	
2004	GMC truck	Yukon XL - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2004	GMC truck	Yukon XL - 4WD	Rear seat audio	●	●	●	●	○	○	
2004	GMC truck	Yukon XL - 4WD	Rear aux. climate module	●	●	●	●	●	●	T024
2004	GMC truck	Yukon XL - 4WD	Navigation radio	●	●	●	●	●	●	T033
2004	GMC truck	Yukon XL - 4WD	Rear wheel steering	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 4WD	ABS	●	●	●	●	●	○	
2004	GMC truck	Yukon XL - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon XL - 4WD	Tire pressure monitor	●	●	○	●	●	●	T022
2004	GMC truck	Yukon XL - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2004	GMC truck	Yukon XL - 4WD	EHPS (parallel hybrid)	●	●	●	●	●	●	T156
2004	Oldsmobile	Bravada	Powertrain	●	●	●	●	●	○	
2004	Oldsmobile	Bravada	Onstar	●	●	●	●	●	●	T155 T191
2004	Oldsmobile	Bravada	Digital radio receiver	●	●	●	●	○	●	T024
2004	Oldsmobile	Bravada	Body control module	●	●	●	●	●	●	T058
2004	Oldsmobile	Bravada	Instrument panel cluster	●	●	●	●	●	○	
2004	Oldsmobile	Bravada	Driver door module	●	●	●	●	●	○	
2004	Oldsmobile	Bravada	Passenger door module	●	●	●	●	●	○	
2004	Oldsmobile	Bravada	Driver seat module	●	●	●	●	●	○	
2004	Oldsmobile	Bravada	Heating and air conditioning	●	●	●	●	●	○	
2004	Oldsmobile	Bravada	Supplemental inflatable restraint	●	●	●	●	○	●	T039

2004	Oldsmobile	Bravada	Amplifier (bose)	●	●	●	●	●	○	
2004	Oldsmobile	Bravada	Radio	●	●	●	●	○	●	T032
2004	Oldsmobile	Bravada	Rear seat audio	●	●	●	●	○	○	
2004	Oldsmobile	Bravada	Lift gate module	●	●	●	●	●	○	
2004	Oldsmobile	Bravada	Rear seat entertainment	●	●	●	●	●	●	T058
2004	Oldsmobile	Bravada	ABS	●	●	●	●	●	○	
2004	Oldsmobile	Bravada	4WAL 3 sensor	●	●	●	●	●	●	T155 T191
2004	Oldsmobile	Bravada - 2WD	Powertrain	●	●	●	●	●	○	
2004	Oldsmobile	Bravada - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2004	Oldsmobile	Bravada - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Oldsmobile	Bravada - 2WD	Body control module	●	●	●	●	●	●	T058
2004	Oldsmobile	Bravada - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2004	Oldsmobile	Bravada - 2WD	Driver door module	●	●	●	●	●	○	
2004	Oldsmobile	Bravada - 2WD	Passenger door module	●	●	●	●	●	○	
2004	Oldsmobile	Bravada - 2WD	Driver seat module	●	●	●	●	●	○	
2004	Oldsmobile	Bravada - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2004	Oldsmobile	Bravada - 2WD	Supplemental inflatable restraint	●	●	●	●	○	●	T039
2004	Oldsmobile	Bravada - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2004	Oldsmobile	Bravada - 2WD	Radio	●	●	●	●	○	●	T032
2004	Oldsmobile	Bravada - 2WD	Rear seat audio	●	●	●	●	○	○	
2004	Oldsmobile	Bravada - 2WD	Lift gate module	●	●	●	●	●	○	
2004	Oldsmobile	Bravada - 2WD	Rear seat entertainment	●	●	●	●	●	●	T058
2004	Oldsmobile	Bravada - 2WD	ABS	●	●	●	●	●	○	
2004	Oldsmobile	Bravada - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T155 T191
2004	Oldsmobile	Silhouette	Powertrain	●	●	●	●	●	○	
2004	Oldsmobile	Silhouette	Onstar	●	●	●	●	●	●	T155 T191
2004	Oldsmobile	Silhouette	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080
2004	Oldsmobile	Silhouette	Memory seat module	●	●	○	●	●	○	
2004	Oldsmobile	Silhouette	Digital radio receiver	●	●	●	●	○	●	T024

2004	Pontiac	Montana	Supplemental inflatable restraint	●	●	○	●	○	○	
2004	Pontiac	Montana	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080
2004	Pontiac	Montana	Digital radio receiver	●	●	●	●	○	●	T024
2004	Pontiac	Montana	Radio	●	●	●	●	●	●	T032
2004	Pontiac	Montana	Chassis	●	●	●	●	●	●	T014
2004	Pontiac	Montana - 4WD	Powertrain	●	●	●	●	●	○	
2004	Pontiac	Montana - 4WD	Onstar	●	●	●	●	●	●	T155 T191 T191
2004	Pontiac	Montana - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2004	Pontiac	Montana - 4WD	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080
2004	Pontiac	Montana - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2004	Pontiac	Montana - 4WD	Radio	●	●	●	●	●	●	T032
2004	Pontiac	Montana - 4WD	Chassis	●	●	●	●	●	●	T014
2004	Pontiac	Montana ext.	Powertrain	●	●	●	●	●	○	
2004	Pontiac	Montana ext.	Onstar	●	●	●	●	●	●	T155 T191 T191
2004	Pontiac	Montana ext.	Supplemental inflatable restraint	●	●	○	●	○	○	
2004	Pontiac	Montana ext.	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080
2004	Pontiac	Montana ext.	Digital radio receiver	●	●	●	●	○	●	T024
2004	Pontiac	Montana ext.	Radio	●	●	●	●	●	●	T032
2004	Pontiac	Montana ext.	Chassis	●	●	●	●	●	●	T014
2004	Hummer	H2	Powertrain	●	●	●	●	●	○	
2004	Hummer	H2	Onstar	●	●	●	●	●	●	T155 T191
2004	Hummer	H2	Digital radio receiver	●	●	●	●	○	●	T024
2004	Hummer	H2	Body control module	●	●	●	●	●	○	
2004	Hummer	H2	Passenger door module	●	●	●	●	●	○	
2004	Hummer	H2	Driver door module	●	●	●	●	●	○	
2004	Hummer	H2	Driver seat module	●	●	●	●	●	○	
2004	Hummer	H2	Amplifier (bose)	●	●	●	●	●	○	
2004	Hummer	H2	Supplemental inflatable restraint	●	●	●	●	○	●	T039

2004	Hummer	H2	Radio	●	●	●	●	○	●	T032
2004	Hummer	H2	Rear seat audio	●	●	●	●	○	○	
2004	Hummer	H2	Heating and air conditioning	●	●	●	●	●	○	
2004	Hummer	H2	Instrument panel cluster	●	●	●	●	●	●	T155 T191
2004	Hummer	H2	Navigation radio	●	●	●	●	●	●	T033
2004	Hummer	H2	Air suspension	●	●	●	●	●	○	
2004	Hummer	H2	ABS	●	●	○	●	●	●	T149
2003	Buick	Century	Powertrain	●	●	●	●	●	●	T001
2003	Buick	Century	Body control module	●	●	○	●	●	●	T122 T170 T198 T136
2003	Buick	Century	Onstar	●	●	●	●	●	●	T155 T191
2003	Buick	Century	Supplemental inflatable restraint	●	●	○	●	○	●	T023
2003	Buick	Century	Chassis	●	●	●	●	●	●	T014
2003	Buick	Lesabre	Powertrain	●	●	●	●	●	●	T001
2003	Buick	Lesabre	Dash integration module	○	○	○	●	●	●	T159 T158 T081 T082 T083 T084 T085 T086 T087 T144 T080 T060
2003	Buick	Lesabre	CD changer	●	●	○	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112 T136 T112
2003	Buick	Lesabre	Climate control panel	●	●	○	●	●	○	
2003	Buick	Lesabre	Instrument panel module	●	●	○	●	●	●	T138 T175
2003	Buick	Lesabre	Onstar	●	●	●	●	●	●	T155 T191
2003	Buick	Lesabre	Digital radio receiver	●	●	●	●	○	●	T024
2003	Buick	Lesabre	Remote function actuation	●	●	○	○	●	○	
2003	Buick	Lesabre	Supplemental inflatable restraint	●	●	○	○	○	○	
2003	Buick	Lesabre	Vehicle theft deterrent	●	●	○	●	●	●	T159 T158 T081 T082 T083 T084 T085 T086 T087 T144 T080 T060
2003	Buick	Lesabre	Memory seat module	●	●	●	●	●	●	T155 T191

2003	Buick	Lesabre	Rear integration module	●	●	○	●	●	○	
2003	Buick	Lesabre	DRP/ABS/TIM	●	●	○	●	●	●	T014
2003	Buick	Park avenue	Powertrain	●	●	●	●	●	●	T001
2003	Buick	Park avenue	Body control module	●	●	○	●	●	●	T122 T176 T192 T138 T177
2003	Buick	Park avenue	Onstar	●	●	●	●	○	●	T155 T191
2003	Buick	Park avenue	Personalization	●	●	○	●	●	●	T058 T058
2003	Buick	Park avenue	Vehicle theft deterrent	●	●	○	○	○	○	
2003	Buick	Park avenue	DRP/ABS/TIM	●	●	○	●	●	●	T014
2003	Buick	Regal	Powertrain	●	●	●	●	●	●	T001
2003	Buick	Regal	Body control module	●	●	○	●	●	●	T122 T170 T198 T136
2003	Buick	Regal	Onstar	●	●	●	●	●	●	T155 T191
2003	Buick	Regal	Supplemental inflatable restraint	●	●	○	●	○	●	T023
2003	Buick	Regal	Chassis	●	●	●	●	●	●	T014
2003	Cadillac	CTS	Powertrain	●	●	●	●	●	○	
2003	Cadillac	CTS	Amplifier (bose)	●	●	●	●	●	●	T122 T123 T124 T125 T126 T127 T118 T128 T119 T129 T120 T130 T131 T132 T133 T134 T136 T116 T116
2003	Cadillac	CTS	Radio	○	○	●	●	○	●	T114 T094 T095 T086 T087 T115 T033 T033
2003	Cadillac	CTS	Lt. headlamp leveling mod.	●	●	●	●	●	●	T092 T092
2003	Cadillac	CTS	Onstar	●	●	●	●	●	●	T155 T191
2003	Cadillac	CTS	Rear integration module	●	●	●	●	●	○	
2003	Cadillac	CTS	Vehicle theft deterrent	●	●	○	○	○	○	
2003	Cadillac	CTS	Remote function actuation	●	●	○	○	●	○	
2003	Cadillac	CTS	Digital radio receiver	●	●	●	●	○	●	T024

2003	Cadillac	CTS	Dash integration module	●	●	●	●	●	●	T112 T113
2003	Cadillac	CTS	DRP/ABS/TCS	●	●	●	●	●	●	T014
2003	Cadillac	CTS	VES	●	●	●	●	●	●	T014
2003	Cadillac	Deville	Powertrain	●	●	●	●	●	○	
2003	Cadillac	Deville	Dash integration module	●	●	○	●	●	●	T122 T123 T127 T094 T138 T175
2003	Cadillac	Deville	CD changer	●	●	○	●	●	●	T178 T178 T136 T159 T158 T181 T122
2003	Cadillac	Deville	Instrument panel cluster	○	○	○	●	○	○	
2003	Cadillac	Deville	Amplifier (delco)	●	●	○	●	●	○	
2003	Cadillac	Deville	Radio	●	●	○	○	●	●	T033
2003	Cadillac	Deville	Memory seat module	○	○	○	○	●	○	
2003	Cadillac	Deville	Onstar	●	●	●	●	●	●	T155 T191
2003	Cadillac	Deville	Digital radio receiver	●	●	●	●	○	●	T024
2003	Cadillac	Deville	Navigation radio	●	●	●	●	○	●	T166
2003	Cadillac	Deville	Remote function actuation	●	●	○	○	●	●	T180
2003	Cadillac	Deville	Vehicle theft deterrent	●	●	○	○	○	●	T193
2003	Cadillac	Deville	Driver door switch	●	●	●	●	○	○	
2003	Cadillac	Deville	Left rear door module	●	●	●	●	●	○	
2003	Cadillac	Deville	Right rear door module	●	●	●	●	●	○	
2003	Cadillac	Deville	Driver door module	●	●	●	●	●	○	
2003	Cadillac	Deville	Passenger door module	●	●	●	●	○	●	T112 T113
2003	Cadillac	Deville	Speed sensitive steering	●	●	○	●	○	○	
2003	Cadillac	DHS	Powertrain	●	●	●	●	●	○	
2003	Cadillac	DHS	Dash integration module	●	●	○	●	●	●	T122 T123 T127 T094 T138 T175
2003	Cadillac	DHS	Amplifier (bose)	●	●	○	●	●	○	
2003	Cadillac	DHS	CD changer	●	●	○	●	●	●	T178 T178 T136 T159 T158 T181 T122

2003	Cadillac	DHS	Instrument panel cluster	○	○	○	●	○	●	T116
2003	Cadillac	DHS	Radio	●	●	○	○	●	●	T033
2003	Cadillac	DHS	Onstar	●	●	●	●	●	●	T155 T191
2003	Cadillac	DHS	Digital radio receiver	●	●	●	●	○	●	T024
2003	Cadillac	DHS	Navigation radio	●	●	●	●	○	●	T166
2003	Cadillac	DHS	Remote function actuation	●	●	○	○	●	●	T180
2003	Cadillac	DHS	Vehicle theft deterrent	●	●	○	○	○	●	T193
2003	Cadillac	DHS	Driver door switch	●	●	●	●	○	○	
2003	Cadillac	DHS	Left rear door module	●	●	●	●	●	○	
2003	Cadillac	DHS	Right rear door module	●	●	●	●	●	○	
2003	Cadillac	DHS	Driver door module	●	●	●	●	●	○	
2003	Cadillac	DHS	Passenger door module	●	●	●	●	○	●	T112 T113
2003	Cadillac	DHS	Speed sensitive steering	●	●	○	●	○	○	
2003	Cadillac	DTS	Powertrain	●	●	●	●	●	○	
2003	Cadillac	DTS	Dash integration module	●	●	○	●	●	●	T122 T123 T127 T094 T138 T175
2003	Cadillac	DTS	Amplifier (bose)	●	●	○	●	●	○	
2003	Cadillac	DTS	CD changer	●	●	○	●	●	●	T178 T178 T136 T159 T158 T181 T122
2003	Cadillac	DTS	Instrument panel cluster	○	○	○	●	○	●	T116
2003	Cadillac	DTS	Radio	●	●	○	○	●	●	T033
2003	Cadillac	DTS	Onstar	●	●	●	●	●	●	T155 T191
2003	Cadillac	DTS	Digital radio receiver	●	●	●	●	○	●	T024
2003	Cadillac	DTS	Navigation radio	●	●	●	●	○	●	T166
2003	Cadillac	DTS	Remote function actuation	●	●	○	○	●	●	T180
2003	Cadillac	DTS	Vehicle theft deterrent	●	●	○	○	○	●	T193
2003	Cadillac	DTS	Driver door switch	●	●	●	●	○	○	
2003	Cadillac	DTS	Left rear door module	●	●	●	●	●	○	

2003	Cadillac	DTS	Right rear door module	●	●	●	●	●	○	
2003	Cadillac	DTS	Driver door module	●	●	●	●	●	○	
2003	Cadillac	DTS	Passenger door module	●	●	●	●	○	●	T112 T113
2003	Cadillac	DTS	Speed sensitive steering	●	●	○	●	○	○	
2003	Cadillac	Seville	Powertrain	●	●	●	●	●	○	
2003	Cadillac	Seville	Amplifier (bose)	●	●	○	●	●	●	T122 T123 T125 T194 T195 T193 T094 T138
2003	Cadillac	Seville	CD changer	●	●	○	●	●	●	T178 T178 T136 T159 T158 T181 T122
2003	Cadillac	Seville	Amplifier (delco)	●	●	○	●	●	○	
2003	Cadillac	Seville	Instrument panel cluster	○	○	○	●	○	●	T116
2003	Cadillac	Seville	Memory seat module	●	●	○	●	●	○	
2003	Cadillac	Seville	Radio	●	●	○	○	●	●	T033
2003	Cadillac	Seville	Onstar	●	●	●	●	●	●	T155 T191
2003	Cadillac	Seville	Digital radio receiver	●	●	●	●	○	●	T024
2003	Cadillac	Seville	Navigation radio	●	●	●	●	○	●	T166
2003	Cadillac	Seville	Dash integration module	○	○	○	○	○	●	T172
2003	Cadillac	Seville	Remote function actuation	●	●	○	●	●	●	T180
2003	Cadillac	Seville	Vehicle theft deterrent	●	●	●	●	●	●	T122 T123 T125 T194 T195 T193 T094 T138
2003	Cadillac	Seville	Speed sensitive steering	●	●	○	●	○	○	
2003	Chevrolet	Alero (export)	Powertrain	●	●	●	●	●	●	T001
2003	Chevrolet	Alero (export)	Body control module	●	●	●	●	●	●	T183
2003	Chevrolet	Alero (export)	Radio	●	●	○	●	○	○	
2003	Chevrolet	Alero (export)	Vehicle theft deterrent	●	●	○	●	○	○	
2003	Chevrolet	Alero (export)	Chassis	●	●	●	●	●	●	T014
2003	Chevrolet	Cavalier	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	Cavalier	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	Cavalier	Body control module	●	●	●	●	●	●	T141 T183

2003	Chevrolet	Cavalier	Radio	○	○	○	●	○	○	
2003	Chevrolet	Cavalier	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Cavalier	Chassis	●	●	●	●	●	●	T014
2003	Chevrolet	Cavalier (CNG)	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	Cavalier (CNG)	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	Cavalier (CNG)	Body control module	●	●	●	●	●	●	T141 T183
2003	Chevrolet	Cavalier (CNG)	Radio	○	○	○	●	○	○	
2003	Chevrolet	Cavalier (CNG)	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Cavalier (CNG)	Chassis	●	●	●	●	●	●	T014
2003	Chevrolet	Optra	Powertrain	●	●	●	●	●	●	T001
2003	Chevrolet	Corvette	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	Corvette	Body control module	●	●	○	●	●	●	T196
2003	Chevrolet	Corvette	Remote function actuation	●	●	○	○	○	●	T181
2003	Chevrolet	Corvette	Supplemental inflatable restraint	●	●	○	●	●	●	T196
2003	Chevrolet	Corvette	ABS/TCS	●	●	●	●	●	○	
2003	Chevrolet	Corvette	RTD	●	●	●	●	●	○	
2003	Chevrolet	Impala	Powertrain	●	●	●	●	●	●	T001
2003	Chevrolet	Impala	Body control module	●	●	○	●	●	●	T023 T136 T122 T088 T080 T081 T082
2003	Chevrolet	Impala	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Impala	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T023 T136 T122 T088 T080 T081 T082
2003	Chevrolet	Impala	Chassis	●	●	○	○	●	●	T014
2003	Chevrolet	Malibu	Powertrain	●	●	●	●	●	●	T001
2003	Chevrolet	Malibu	Body control module	●	●	●	●	●	●	T141
2003	Chevrolet	Malibu	Radio	○	○	○	●	○	○	
2003	Chevrolet	Malibu	Remote function actuation	●	●	○	●	●	○	
2003	Chevrolet	Malibu	Chassis	●	●	●	●	●	●	T014
2003	Chevrolet	Monte carlo	Powertrain	●	●	●	●	●	●	T001
2003	Chevrolet	Monte carlo	Body control module	●	●	○	●	●	●	T023 T136 T122 T088 T080 T081 T082

2003	Chevrolet	Monte carlo	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Monte carlo	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	Monte carlo	Supplemental inflatable restraint	●	●	●	●	●	●	T023 T136 T122 T088 T080 T081 T082
2003	Chevrolet	Monte carlo	Chassis	●	●	○	○	●	●	T014
2003	Chevrolet	Others	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	Others	ISU	●	●	○	●	●	○	
2003	Chevrolet	Others	Antilock brake system	●	●	●	●	●	●	T014
2003	Chevrolet	Others	Chassis	●	●	●	●	●	●	T014
2003	Oldsmobile	Alero	Powertrain	●	●	●	●	●	●	T001
2003	Oldsmobile	Alero	Body control module	●	●	●	○	●	●	T141
2003	Oldsmobile	Alero	Radio	●	●	●	●	●	●	T183
2003	Oldsmobile	Alero	Instrument panel cluster	○	○	●	●	○	○	
2003	Oldsmobile	Alero	Onstar	●	●	●	●	●	●	T155 T191
2003	Oldsmobile	Alero	Digital radio receiver	●	●	●	●	○	●	T024
2003	Oldsmobile	Alero	Remote function actuation	●	●	○	●	●	○	
2003	Oldsmobile	Alero	Chassis	●	●	●	●	●	●	T014
2003	Oldsmobile	Aurora	Powertrain	●	●	●	●	●	○	
2003	Oldsmobile	Aurora	CD changer	●	●	○	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112 T136 T138 T175 T081 T082 T083 T084 T085 T086 T087 T080 T060 T033 T081 T082 T083 T084 T085 T086 T087 T144 T080 T060 T201 T112
2003	Oldsmobile	Aurora	Memory seat module	●	●	○	●	●	○	
2003	Oldsmobile	Aurora	Onstar	●	●	●	●	●	●	T155 T191
2003	Oldsmobile	Aurora	Remote function actuation	●	●	○	○	●	○	
2003	Oldsmobile	Aurora	Supplemental inflatable restraint	●	●	○	○	○	○	

2003	Oldsmobile	Aurora	Vehicle theft deterrent	●	●	○	○	○	●	T185
2003	Oldsmobile	Aurora	Rear integration module	●	●	○	●	●	○	
2003	Oldsmobile	Aurora	DRP/ABS/TIM	●	●	○	●	●	●	T014
2003	Pontiac	Bonneville	Powertrain	●	●	●	●	●	●	T001
2003	Pontiac	Bonneville	Instrument panel cluster	○	○	○	●	○	○	
2003	Pontiac	Bonneville	Dash integration module	○	○	○	●	●	●	T081 T082 T083 T084 T085 T086 T087 T144 T080 T060
2003	Pontiac	Bonneville	CD changer	●	●	○	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112 T136 T112
2003	Pontiac	Bonneville	Instrument panel module	●	●	○	●	●	●	T138 T175
2003	Pontiac	Bonneville	Digital radio receiver	●	●	●	●	○	●	T024
2003	Pontiac	Bonneville	Onstar	●	●	●	●	●	●	T155 T191
2003	Pontiac	Bonneville	Supplemental inflatable restraint	●	●	○	○	○	○	
2003	Pontiac	Bonneville	Vehicle theft deterrent	●	●	○	●	●	●	T185
2003	Pontiac	Bonneville	Climate control panel	●	●	●	●	●	●	T024
2003	Pontiac	Bonneville	Remote function actuation	●	●	○	●	●	●	T185
2003	Pontiac	Bonneville	Rear integration module	●	●	●	●	●	●	T186
2003	Pontiac	Bonneville	DRP/ABS/TIM	●	●	○	●	●	●	T014
2003	Pontiac	Grand am	Powertrain	●	●	●	●	●	●	T001
2003	Pontiac	Grand am	Body control module	●	●	●	○	●	●	T141
2003	Pontiac	Grand am	Radio	●	●	●	●	●	●	T183
2003	Pontiac	Grand am	Instrument panel cluster	○	○	●	●	○	○	
2003	Pontiac	Grand am	Onstar	●	●	●	●	●	●	T155 T191
2003	Pontiac	Grand am	Digital radio receiver	●	●	●	●	○	●	T024

2003	Pontiac	Grand am	Remote function actuation	●	●	○	●	●	○	
2003	Pontiac	Grand am	Chassis	●	●	●	●	●	●	T014
2003	Pontiac	Grand prix	Powertrain	●	●	●	●	●	●	T001
2003	Pontiac	Grand prix	Vehicle theft deterrent	○	○	○	●	○	○	
2003	Pontiac	Grand prix	Onstar	●	●	●	●	○	●	T155 T191
2003	Pontiac	Grand prix	Supplemental inflatable restraint	●	●	○	●	○	○	
2003	Pontiac	Grand am	Powertrain	●	●	●	●	●	●	T001
2003	Pontiac	Grand am	Body control module	●	●	●	○	●	●	T141
2003	Pontiac	Grand am	Radio	●	●	●	●	●	●	T183
2003	Pontiac	Grand am	Instrument panel cluster	○	○	●	●	○	○	
2003	Pontiac	Grand am	Onstar	●	●	●	●	●	●	T155 T191
2003	Pontiac	Grand am	Digital radio receiver	●	●	●	●	○	●	T024
2003	Pontiac	Grand am	Remote function actuation	●	●	○	●	●	○	
2003	Pontiac	Grand am	Chassis	●	●	●	●	●	●	T014
2003	Pontiac	Sunfire	Powertrain	●	●	●	●	●	○	
2003	Pontiac	Sunfire	Radio	○	○	○	●	○	○	
2003	Pontiac	Sunfire	Body control module	●	●	●	●	●	●	T141 T183
2003	Pontiac	Sunfire	Onstar	●	●	●	●	●	●	T155 T191
2003	Pontiac	Sunfire	Digital radio receiver	●	●	●	●	○	●	T024
2003	Pontiac	Sunfire	Chassis	●	●	●	●	●	●	T014
2003	Pontiac	Vibe - AWD	Cruise control	●	●	○	○	○	○	
2003	Pontiac	Vibe - AWD	Chassis	●	●	○	●	●	○	
2003	Pontiac	Vibe - FWD	Cruise control	●	●	○	○	○	○	
2003	Pontiac	Vibe - FWD	Chassis	●	●	○	●	●	○	
2003	Pontiac	Others	Powertrain	●	●	●	●	●	○	
2003	Pontiac	Others	Chassis	●	●	●	●	●	○	
2003	Buick	Rendezvous - AWD	Powertrain	●	●	●	●	●	●	T001
2003	Buick	Rendezvous - AWD	Body control module	●	●	○	●	●	●	T068 T023 T136 T122 T081 T082 T144 T080

2003	Buick	Rendezvous - AWD	Onstar	●	●	●	●	●	●	T155 T191
2003	Buick	Rendezvous - AWD	Digital radio receiver	●	●	●	●	●	●	T024
2003	Buick	Rendezvous - AWD	Vehicle theft deterrent	●	●	○	○	○	○	
2003	Buick	Rendezvous - AWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2003	Buick	Rendezvous - AWD	Rear seat entertainment	●	●	●	●	●	●	T068 T023 T136 T122 T081 T082 T144 T080
2003	Buick	Rendezvous - AWD	Chassis	●	●	○	●	●	●	T014
2003	Buick	Rendezvous - FWD	Powertrain	●	●	●	●	●	●	T001
2003	Buick	Rendezvous - FWD	Body control module	●	●	○	●	●	●	T068 T023 T136 T122 T081 T082 T144 T080
2003	Buick	Rendezvous - FWD	Onstar	●	●	●	●	●	●	T155 T191
2003	Buick	Rendezvous - FWD	Digital radio receiver	●	●	●	●	●	●	T024
2003	Buick	Rendezvous - FWD	Vehicle theft deterrent	●	●	○	○	○	○	
2003	Buick	Rendezvous - FWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2003	Buick	Rendezvous - FWD	Rear seat entertainment	●	●	●	●	●	●	T068 T023 T136 T122 T081 T082 T144 T080
2003	Buick	Rendezvous - FWD	Chassis	●	●	○	●	●	●	T014
2003	Cadillac	Escalade - 2WD	Powertrain	●	●	●	●	●	○	
2003	Cadillac	Escalade - 2WD	Body control module	●	●	●	●	●	○	
2003	Cadillac	Escalade - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2003	Cadillac	Escalade - 2WD	Radio	○	○	○	●	○	○	
2003	Cadillac	Escalade - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039

2003	Cadillac	Escalade - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2003	Cadillac	Escalade - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	Cadillac	Escalade - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2003	Cadillac	Escalade - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2003	Cadillac	Escalade - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2003	Cadillac	Escalade - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Cadillac	Escalade - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	Cadillac	Escalade - 2WD	ABS	●	●	●	●	●	○	
2003	Cadillac	Escalade - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Cadillac	Escalade - AWD	Powertrain	●	●	●	●	●	○	
2003	Cadillac	Escalade - AWD	Body control module	●	●	●	●	●	○	
2003	Cadillac	Escalade - AWD	Heating and air conditioning	●	●	●	●	●	○	
2003	Cadillac	Escalade - AWD	Radio	○	○	○	●	○	○	
2003	Cadillac	Escalade - AWD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Cadillac	Escalade - AWD	Onstar	●	●	●	●	●	●	T155 T191
2003	Cadillac	Escalade - AWD	Digital radio receiver	●	●	●	●	○	●	T024
2003	Cadillac	Escalade - AWD	Instrument panel cluster	●	●	●	●	●	○	
2003	Cadillac	Escalade - AWD	Rear seat entertainment	●	●	●	○	○	○	
2003	Cadillac	Escalade - AWD	Passenger presence system	●	●	●	●	●	●	T020
2003	Cadillac	Escalade - AWD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Cadillac	Escalade - AWD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	Cadillac	Escalade - AWD	ABS	●	●	●	●	●	○	
2003	Cadillac	Escalade - AWD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Cadillac	Escalade ESV	Powertrain	●	●	●	●	●	○	
2003	Cadillac	Escalade ESV	Body control module	●	●	●	●	●	○	

2003	Cadillac	Escalade ESV	Heating and air conditioning	●	●	●	●	●	○	
2003	Cadillac	Escalade ESV	Radio	○	○	○	●	○	○	
2003	Cadillac	Escalade ESV	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Cadillac	Escalade ESV	Onstar	●	●	●	●	●	●	T155 T191
2003	Cadillac	Escalade ESV	Digital radio receiver	●	●	●	●	○	●	T024
2003	Cadillac	Escalade ESV	Instrument panel cluster	●	●	●	●	●	○	
2003	Cadillac	Escalade ESV	Rear seat entertainment	●	●	●	○	○	○	
2003	Cadillac	Escalade ESV	Passenger presence system	●	●	●	●	●	●	T020
2003	Cadillac	Escalade ESV	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Cadillac	Escalade ESV	ESC (if equipped)	●	●	●	●	●	●	T156
2003	Cadillac	Escalade ESV	ABS	●	●	●	●	●	○	
2003	Cadillac	Escalade ESV	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Cadillac	Escalade EXT	Powertrain	●	●	●	●	●	○	
2003	Cadillac	Escalade EXT	Body control module	●	●	●	●	●	○	
2003	Cadillac	Escalade EXT	Heating and air conditioning	●	●	●	●	●	○	
2003	Cadillac	Escalade EXT	Radio	○	○	○	●	○	○	
2003	Cadillac	Escalade EXT	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Cadillac	Escalade EXT	Onstar	●	●	●	●	●	●	T155 T191
2003	Cadillac	Escalade EXT	Digital radio receiver	●	●	●	●	○	●	T024
2003	Cadillac	Escalade EXT	Instrument panel cluster	●	●	●	●	●	○	
2003	Cadillac	Escalade EXT	Rear seat entertainment	●	●	●	○	○	○	
2003	Cadillac	Escalade EXT	Passenger presence system	●	●	●	●	●	●	T020
2003	Cadillac	Escalade EXT	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Cadillac	Escalade EXT	ESC (if equipped)	●	●	●	●	●	●	T156

2003	Cadillac	Escalade EXT	ABS	●	●	●	●	●	○	
2003	Cadillac	Escalade EXT	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Cadillac	Incomplete	Amplifier (delco)	●	●	○	●	●	●	T172 T126 T127 T136 T158 T094 T138 T175 T179 T086 T087 T033
2003	Cadillac	Incomplete	Rear integration module	○	○	○	●	○	○	
2003	Cadillac	Incomplete	Vehicle theft deterrent	●	●	○	○	○	●	T199 T200
2003	Cadillac	Incomplete	Dash integration module	●	●	○	○	○	●	T112 T113
2003	Cadillac	Incomplete	Remote function actuation	●	●	○	○	●	○	
2003	Cadillac	Incomplete	Driver door module	●	●	●	●	●	○	
2003	Cadillac	Incomplete	Driver door switch	●	●	●	●	○	○	
2003	Cadillac	Incomplete	Passenger door module	●	●	●	●	●	●	T172 T126 T127 T136 T158 T094 T138 T175 T179 T086 T087 T033
2003	Cadillac	Incomplete	Rear climate control panel	●	●	○	●	●	○	
2003	Cadillac	Incomplete	Onstar	●	●	●	●	●	●	T155 T191
2003	Cadillac	Incomplete	Left mid door module	●	●	●	●	●	○	
2003	Cadillac	Incomplete	Left rear door module	●	●	●	●	●	○	
2003	Cadillac	Incomplete	Right mid door module	●	●	●	●	●	○	
2003	Cadillac	Incomplete	Right rear door module	●	●	●	●	●	○	
2003	Cadillac	Incomplete	DRP/ABS/TCS	●	●	○	●	●	○	
2003	Cadillac	Incomplete	Powertrain	●	●	●	●	●	●	T001
2003	Chevrolet	Astro - 2WD	Powertrain	●	●	●	●	●	●	T146
2003	Chevrolet	Astro - 2WD	Body control module	●	●	○	●	●	○	
2003	Chevrolet	Astro - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2003	Chevrolet	Astro - 2WD	Instrument panel cluster	○	○	○	○	●	●	T039
2003	Chevrolet	Astro - 2WD	4WAL 3 sensor	●	●	○	●	●	○	

2003	Chevrolet	Astro - 4WD	Powertrain	●	●	●	●	●	●	T146
2003	Chevrolet	Astro - 4WD	Body control module	●	●	○	●	●	○	
2003	Chevrolet	Astro - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2003	Chevrolet	Astro - 4WD	Instrument panel cluster	○	○	○	○	●	●	T039
2003	Chevrolet	Astro - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	Chevrolet	Avalanche - 2WD	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	○	
2003	Chevrolet	Avalanche - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2003	Chevrolet	Avalanche - 2WD	Radio	○	○	○	●	○	○	
2003	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	Avalanche - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Avalanche - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	Avalanche - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2003	Chevrolet	Avalanche - 2WD	Vehicle theft deterrent	●	●	●	●	○	○	
2003	Chevrolet	Avalanche - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2003	Chevrolet	Avalanche - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2003	Chevrolet	Avalanche - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Chevrolet	Avalanche - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	Avalanche - 2WD	ABS	●	●	●	●	●	○	
2003	Chevrolet	Avalanche - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	Avalanche - 4WD	Powertrain	●	●	●	●	●	●	T079
2003	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	○	
2003	Chevrolet	Avalanche - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2003	Chevrolet	Avalanche - 4WD	Radio	○	○	○	●	○	○	

2003	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	Avalanche - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Avalanche - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	Avalanche - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2003	Chevrolet	Avalanche - 4WD	Vehicle theft deterrent	●	●	●	●	○	○	
2003	Chevrolet	Avalanche - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2003	Chevrolet	Avalanche - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2003	Chevrolet	Avalanche - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Chevrolet	Avalanche - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	Avalanche - 4WD	ABS	●	●	●	●	●	○	
2003	Chevrolet	Avalanche - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	Blazer - 2WD	Powertrain	●	●	●	●	●	●	T146
2003	Chevrolet	Blazer - 2WD	Body control module	●	●	○	●	●	●	T032
2003	Chevrolet	Blazer - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2003	Chevrolet	Blazer - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	Chevrolet	Blazer - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	Chevrolet	Blazer - 4WD	Powertrain	●	●	●	●	●	●	T146
2003	Chevrolet	Blazer - 4WD	Body control module	●	●	○	●	●	●	T032
2003	Chevrolet	Blazer - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2003	Chevrolet	Blazer - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	Chevrolet	Blazer - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	Chevrolet	Blazer - 4WD - RHD	Powertrain	●	●	●	●	●	●	T146
2003	Chevrolet	Blazer - 4WD - RHD	Body control module	●	●	○	●	●	●	T032

2003	Chevrolet	Blazer - 4WD - RHD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	Blazer - 4WD - RHD	4WAL 3 sensor	●	●	○	●	●	○	
2003	Chevrolet	Blazer - 4WD - RHD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	Chevrolet	C silverado - 2WD	Powertrain	●	●	●	●	●	●	T146
2003	Chevrolet	C silverado - 2WD	Body control module	●	●	●	●	●	○	
2003	Chevrolet	C silverado - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2003	Chevrolet	C silverado - 2WD	Radio	○	○	○	●	○	○	
2003	Chevrolet	C silverado - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	C silverado - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	C silverado - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	C silverado - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2003	Chevrolet	C silverado - 2WD	Vehicle theft deterrent	●	●	●	●	○	○	
2003	Chevrolet	C silverado - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2003	Chevrolet	C silverado - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2003	Chevrolet	C silverado - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Chevrolet	C silverado - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	C silverado - 2WD	ABS	●	●	●	●	●	○	

2003	Chevrolet	C silverado - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	C silverado - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	C silverado - 2WD (CNG)	Body control module	●	●	●	●	●	○	
2003	Chevrolet	C silverado - 2WD (CNG)	Heating and air conditioning	●	●	●	●	●	○	
2003	Chevrolet	C silverado - 2WD (CNG)	Radio	○	○	○	●	○	○	
2003	Chevrolet	C silverado - 2WD (CNG)	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	C silverado - 2WD (CNG)	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	C silverado - 2WD (CNG)	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	C silverado - 2WD (CNG)	Instrument panel cluster	●	●	●	●	●	○	
2003	Chevrolet	C silverado - 2WD (CNG)	Vehicle theft deterrent	●	●	●	●	○	○	
2003	Chevrolet	C silverado - 2WD (CNG)	Rear seat entertainment	●	●	●	○	○	○	
2003	Chevrolet	C silverado - 2WD (CNG)	Passenger presence system	●	●	●	●	●	●	T020
2003	Chevrolet	C silverado - 2WD (CNG)	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Chevrolet	C silverado - 2WD (CNG)	ESC (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	C silverado - 2WD (CNG)	ABS	●	●	●	●	●	○	
2003	Chevrolet	C silverado - 2WD (CNG)	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	Express (CNG)	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	Express (CNG)	Body control module	●	●	●	●	●	○	

2003	Chevrolet	Express (CNG)	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2003	Chevrolet	Express (CNG)	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Express (CNG)	ABS	●	●	●	●	●	○	
2003	Chevrolet	Express - 2WD	Powertrain	●	●	●	●	●	●	T146
2003	Chevrolet	Express - 2WD	Body control module	●	●	●	●	●	○	
2003	Chevrolet	Express - 2WD	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2003	Chevrolet	Express - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Express - 2WD	ABS	●	●	●	●	●	○	
2003	Chevrolet	Express - AWD	Powertrain	●	●	●	●	●	●	T146
2003	Chevrolet	Express - AWD	Body control module	●	●	●	●	●	○	
2003	Chevrolet	Express - AWD	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2003	Chevrolet	Express - AWD	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Express - AWD	ABS	●	●	●	●	●	○	
2003	Chevrolet	K silverado - 4WD	Powertrain	●	●	●	●	●	●	T146
2003	Chevrolet	K silverado - 4WD	Body control module	●	●	●	●	●	○	
2003	Chevrolet	K silverado - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2003	Chevrolet	K silverado - 4WD	Radio	○	○	○	●	○	○	
2003	Chevrolet	K silverado - 4WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	K silverado - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	K silverado - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	K silverado - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2003	Chevrolet	K silverado - 4WD	Vehicle theft deterrent	●	●	●	●	○	○	

2003	Chevrolet	K silverado - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2003	Chevrolet	K silverado - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2003	Chevrolet	K silverado - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Chevrolet	K silverado - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	K silverado - 4WD	ABS	●	●	●	●	●	○	
2003	Chevrolet	K silverado - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	K silverado - 4WD (CNG)	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	K silverado - 4WD (CNG)	Body control module	●	●	●	●	●	○	
2003	Chevrolet	K silverado - 4WD (CNG)	Heating and air conditioning	●	●	●	●	●	○	
2003	Chevrolet	K silverado - 4WD (CNG)	Radio	○	○	○	●	○	○	
2003	Chevrolet	K silverado - 4WD (CNG)	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	K silverado - 4WD (CNG)	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	K silverado - 4WD (CNG)	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	K silverado - 4WD (CNG)	Instrument panel cluster	●	●	●	●	●	○	
2003	Chevrolet	K silverado - 4WD (CNG)	Vehicle theft deterrent	●	●	●	●	○	○	
2003	Chevrolet	K silverado - 4WD (CNG)	Rear seat entertainment	●	●	●	○	○	○	
2003	Chevrolet	K silverado - 4WD (CNG)	Passenger presence system	●	●	●	●	●	●	T020

2003	Chevrolet	K silverado - 4WD (CNG)	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Chevrolet	K silverado - 4WD (CNG)	ESC (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	K silverado - 4WD (CNG)	ABS	●	●	●	●	●	○	
2003	Chevrolet	K silverado - 4WD (CNG)	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	S10 pickup - 2WD	Powertrain	●	●	●	●	●	●	T146
2003	Chevrolet	S10 pickup - 2WD	Body control module	●	●	○	●	●	●	T032
2003	Chevrolet	S10 pickup - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2003	Chevrolet	S10 pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	Chevrolet	S10 pickup - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	Chevrolet	S10 pickup - 4WD	Powertrain	●	●	●	●	●	●	T146
2003	Chevrolet	S10 pickup - 4WD	Body control module	●	●	○	●	●	●	T032
2003	Chevrolet	S10 pickup - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2003	Chevrolet	S10 pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	Chevrolet	S10 pickup - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	Chevrolet	SSR	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	SSR	Amplifier (bose)	●	●	●	●	●	○	
2003	Chevrolet	SSR	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	SSR	4WAL 3 sensor	●	●	○	●	●	○	
2003	Chevrolet	SSR	Traction assist (if equipped)	●	●	○	●	●	○	

2003	Chevrolet	Suburban - 2WD	Powertrain	●	●	●	●	●	●	T079
2003	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	○	
2003	Chevrolet	Suburban - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2003	Chevrolet	Suburban - 2WD	Radio	○	○	○	●	○	○	
2003	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	Suburban - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Suburban - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	Suburban - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2003	Chevrolet	Suburban - 2WD	Vehicle theft deterrent	●	●	●	●	○	○	
2003	Chevrolet	Suburban - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2003	Chevrolet	Suburban - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2003	Chevrolet	Suburban - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Chevrolet	Suburban - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	Suburban - 2WD	ABS	●	●	●	●	●	○	
2003	Chevrolet	Suburban - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	Suburban - 4WD	Powertrain	●	●	●	●	●	●	T079
2003	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	○	
2003	Chevrolet	Suburban - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2003	Chevrolet	Suburban - 4WD	Radio	○	○	○	●	○	○	
2003	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	Suburban - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Suburban - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	Suburban - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2003	Chevrolet	Suburban - 4WD	Vehicle theft deterrent	●	●	●	●	○	○	

2003	Chevrolet	Suburban - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2003	Chevrolet	Suburban - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2003	Chevrolet	Suburban - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Chevrolet	Suburban - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	Suburban - 4WD	ABS	●	●	●	●	●	○	
2003	Chevrolet	Suburban - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	Tahoe - 2WD	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	Tahoe - 2WD	Body control module	●	●	●	●	●	○	
2003	Chevrolet	Tahoe - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2003	Chevrolet	Tahoe - 2WD	Radio	○	○	○	●	○	○	
2003	Chevrolet	Tahoe - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	Tahoe - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Tahoe - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	Tahoe - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2003	Chevrolet	Tahoe - 2WD	Vehicle theft deterrent	●	●	●	●	○	○	
2003	Chevrolet	Tahoe - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2003	Chevrolet	Tahoe - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2003	Chevrolet	Tahoe - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Chevrolet	Tahoe - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	Tahoe - 2WD	ABS	●	●	●	●	●	○	
2003	Chevrolet	Tahoe - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	Tahoe - 4WD	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	Tahoe - 4WD	Body control module	●	●	●	●	●	○	
2003	Chevrolet	Tahoe - 4WD	Heating and air conditioning	●	●	●	●	●	○	

2003	Chevrolet	Tahoe - 4WD	Radio	○	○	○	●	○	○	
2003	Chevrolet	Tahoe - 4WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	Tahoe - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Tahoe - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	Chevrolet	Tahoe - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2003	Chevrolet	Tahoe - 4WD	Vehicle theft deterrent	●	●	●	●	○	○	
2003	Chevrolet	Tahoe - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2003	Chevrolet	Tahoe - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2003	Chevrolet	Tahoe - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	Chevrolet	Tahoe - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	Tahoe - 4WD	ABS	●	●	●	●	●	○	
2003	Chevrolet	Tahoe - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Chevrolet	Tracker - 2WD	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	Tracker - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2003	Chevrolet	Tracker - 2WD	Chassis	●	●	●	●	●	●	T014
2003	Chevrolet	Tracker - 4WD	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	Tracker - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2003	Chevrolet	Tracker - 4WD	Chassis	●	●	●	●	●	●	T014
2003	Chevrolet	Trailblazer - 2WD	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	Trailblazer - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2003	Chevrolet	Trailblazer - 2WD	Rear seat audio	○	○	○	●	○	○	
2003	Chevrolet	Trailblazer - 2WD	Heating and air conditioning	○	○	○	●	●	○	

2003	Chevrolet	Trailblazer - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	Trailblazer - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Trailblazer - 2WD	Vehicle theft deterrent	●	●	●	●	○	○	
2003	Chevrolet	Trailblazer - 2WD	Radio	●	●	○	●	○	○	
2003	Chevrolet	Trailblazer - 2WD	Body control module	●	●	●	●	●	●	T058
2003	Chevrolet	Trailblazer - 2WD	Rear HVAC/RSA	●	●	●	●	●	●	T039
2003	Chevrolet	Trailblazer - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	Chevrolet	Trailblazer - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	Chevrolet	Trailblazer - 4WD	Powertrain	●	●	●	●	●	○	
2003	Chevrolet	Trailblazer - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2003	Chevrolet	Trailblazer - 4WD	Rear seat audio	○	○	○	●	○	○	
2003	Chevrolet	Trailblazer - 4WD	Heating and air conditioning	○	○	○	●	●	○	
2003	Chevrolet	Trailblazer - 4WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Chevrolet	Trailblazer - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Trailblazer - 4WD	Vehicle theft deterrent	●	●	●	●	○	○	
2003	Chevrolet	Trailblazer - 4WD	Radio	●	●	○	●	○	○	
2003	Chevrolet	Trailblazer - 4WD	Body control module	●	●	●	●	●	●	T058

2003	Chevrolet	Trailblazer - 4WD	Rear HVAC/RSA	●	●	●	●	●	●	T039
2003	Chevrolet	Trailblazer - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	Chevrolet	Trailblazer - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	Chevrolet	Venture	Powertrain	●	●	●	●	●	●	T001
2003	Chevrolet	Venture	Onstar	●	●	●	●	●	●	T155 T191
2003	Chevrolet	Venture	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080
2003	Chevrolet	Venture	Radio	○	○	○	●	○	○	
2003	Chevrolet	Venture	Supplemental inflatable restraint	●	●	●	●	●	●	T032
2003	Chevrolet	Venture	Chassis	●	●	●	●	●	●	T014
2003	GMC truck	Envoy - 2WD	Powertrain	●	●	●	●	●	○	
2003	GMC truck	Envoy - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2003	GMC truck	Envoy - 2WD	Rear seat audio	○	○	○	●	○	○	
2003	GMC truck	Envoy - 2WD	Heating and air conditioning	○	○	○	●	●	○	
2003	GMC truck	Envoy - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	GMC truck	Envoy - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	Envoy - 2WD	Radio	●	●	○	●	○	○	
2003	GMC truck	Envoy - 2WD	Body control module	●	●	●	●	●	●	T058
2003	GMC truck	Envoy - 2WD	Rear HVAC/RSA	●	●	●	●	●	●	T039
2003	GMC truck	Envoy - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	GMC truck	Envoy - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	GMC truck	Envoy - 4WD	Powertrain	●	●	●	●	●	○	
2003	GMC truck	Envoy - 4WD	Amplifier (bose)	●	●	●	●	●	○	
2003	GMC truck	Envoy - 4WD	Rear seat audio	○	○	○	●	○	○	
2003	GMC truck	Envoy - 4WD	Heating and air conditioning	○	○	○	●	●	○	
2003	GMC truck	Envoy - 4WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039

2003	GMC truck	Envoy - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	Envoy - 4WD	Radio	●	●	○	●	○	○	
2003	GMC truck	Envoy - 4WD	Body control module	●	●	●	●	●	●	T058
2003	GMC truck	Envoy - 4WD	Rear HVAC/RSA	●	●	●	●	●	●	T039
2003	GMC truck	Envoy - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	GMC truck	Envoy - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	GMC truck	GMC c-series - 2WD	Powertrain	●	●	●	●	●	●	T146
2003	GMC truck	GMC c-series - 2WD	Body control module	●	●	●	●	●	○	
2003	GMC truck	GMC c-series - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2003	GMC truck	GMC c-series - 2WD	Radio	○	○	○	●	○	○	
2003	GMC truck	GMC c-series - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	GMC truck	GMC c-series - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	GMC c-series - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	GMC truck	GMC c-series - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2003	GMC truck	GMC c-series - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2003	GMC truck	GMC c-series - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2003	GMC truck	GMC c-series - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	GMC truck	GMC c-series - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	GMC c-series - 2WD	ABS	●	●	●	●	●	○	
2003	GMC truck	GMC c-series - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156

2003	GMC truck	GMC c-series - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
2003	GMC truck	GMC c-series - 2WD (CNG)	Body control module	●	●	●	●	●	○	
2003	GMC truck	GMC c-series - 2WD (CNG)	Heating and air conditioning	●	●	●	●	●	○	
2003	GMC truck	GMC c-series - 2WD (CNG)	Radio	○	○	○	●	○	○	
2003	GMC truck	GMC c-series - 2WD (CNG)	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	GMC truck	GMC c-series - 2WD (CNG)	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	GMC c-series - 2WD (CNG)	Digital radio receiver	●	●	●	●	○	●	T024
2003	GMC truck	GMC c-series - 2WD (CNG)	Instrument panel cluster	●	●	●	●	●	○	
2003	GMC truck	GMC c-series - 2WD (CNG)	Rear seat entertainment	●	●	●	○	○	○	
2003	GMC truck	GMC c-series - 2WD (CNG)	Passenger presence system	●	●	●	●	●	●	T020
2003	GMC truck	GMC c-series - 2WD (CNG)	Amplifier (bose)	●	●	●	●	●	●	T139
2003	GMC truck	GMC c-series - 2WD (CNG)	ESC (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	GMC c-series - 2WD (CNG)	ABS	●	●	●	●	●	○	
2003	GMC truck	GMC c-series - 2WD (CNG)	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	GMC K sierra - 4WD	Powertrain	●	●	●	●	●	●	T146
2003	GMC truck	GMC K sierra - 4WD	Body control module	●	●	●	●	●	○	
2003	GMC truck	GMC K sierra - 4WD	Heating and air conditioning	●	●	●	●	●	○	

2003	GMC truck	GMC K sierra - 4WD	Radio	○	○	○	●	○	○	
2003	GMC truck	GMC K sierra - 4WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	GMC truck	GMC K sierra - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	GMC K sierra - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	GMC truck	GMC K sierra - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2003	GMC truck	GMC K sierra - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2003	GMC truck	GMC K sierra - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2003	GMC truck	GMC K sierra - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	GMC truck	GMC K sierra - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	GMC K sierra - 4WD	ABS	●	●	●	●	●	○	
2003	GMC truck	GMC K sierra - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	GMC K sierra - 4WD (CNG)	Powertrain	●	●	●	●	●	○	
2003	GMC truck	GMC K sierra - 4WD (CNG)	Body control module	●	●	●	●	●	○	
2003	GMC truck	GMC K sierra - 4WD (CNG)	Heating and air conditioning	●	●	●	●	●	○	
2003	GMC truck	GMC K sierra - 4WD (CNG)	Radio	○	○	○	●	○	○	
2003	GMC truck	GMC K sierra - 4WD (CNG)	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	GMC truck	GMC K sierra - 4WD (CNG)	Onstar	●	●	●	●	●	●	T155 T191

2003	GMC truck	GMC K sierra - 4WD (CNG)	Digital radio receiver	●	●	●	●	○	●	T024
2003	GMC truck	GMC K sierra - 4WD (CNG)	Instrument panel cluster	●	●	●	●	●	○	
2003	GMC truck	GMC K sierra - 4WD (CNG)	Rear seat entertainment	●	●	●	○	○	○	
2003	GMC truck	GMC K sierra - 4WD (CNG)	Passenger presence system	●	●	●	●	●	●	T020
2003	GMC truck	GMC K sierra - 4WD (CNG)	Amplifier (bose)	●	●	●	●	●	●	T139
2003	GMC truck	GMC K sierra - 4WD (CNG)	ESC (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	GMC K sierra - 4WD (CNG)	ABS	●	●	●	●	●	○	
2003	GMC truck	GMC K sierra - 4WD (CNG)	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	GMC sierra denali	Powertrain	●	●	●	●	●	○	
2003	GMC truck	GMC sierra denali	Body control module	●	●	●	●	●	○	
2003	GMC truck	GMC sierra denali	Heating and air conditioning	●	●	●	●	●	○	
2003	GMC truck	GMC sierra denali	Radio	○	○	○	●	○	○	
2003	GMC truck	GMC sierra denali	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	GMC truck	GMC sierra denali	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	GMC sierra denali	Digital radio receiver	●	●	●	●	○	●	T024
2003	GMC truck	GMC sierra denali	Instrument panel cluster	●	●	●	●	●	○	
2003	GMC truck	GMC sierra denali	Rear seat entertainment	●	●	●	○	○	○	

2003	GMC truck	GMC sierra denali	Passenger presence system	●	●	●	●	●	●	T020
2003	GMC truck	GMC sierra denali	Amplifier (bose)	●	●	●	●	●	●	T139
2003	GMC truck	GMC sierra denali	ESC (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	GMC sierra denali	ABS	●	●	●	●	●	○	
2003	GMC truck	GMC sierra denali	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	Jimmy - 2WD	Powertrain	●	●	●	●	●	●	T146
2003	GMC truck	Jimmy - 2WD	Body control module	●	●	○	●	●	●	T032
2003	GMC truck	Jimmy - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2003	GMC truck	Jimmy - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	GMC truck	Jimmy - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	GMC truck	Jimmy - 4WD	Powertrain	●	●	●	●	●	●	T146
2003	GMC truck	Jimmy - 4WD	Body control module	●	●	○	●	●	●	T032
2003	GMC truck	Jimmy - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2003	GMC truck	Jimmy - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	GMC truck	Jimmy - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	GMC truck	Safari - 2WD	Powertrain	●	●	●	●	●	●	T146
2003	GMC truck	Safari - 2WD	Body control module	●	●	○	●	●	○	
2003	GMC truck	Safari - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2003	GMC truck	Safari - 2WD	Instrument panel cluster	○	○	○	○	●	●	T039
2003	GMC truck	Safari - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	GMC truck	Safari - 4WD	Powertrain	●	●	●	●	●	●	T146
2003	GMC truck	Safari - 4WD	Body control module	●	●	○	●	●	○	
2003	GMC truck	Safari - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039

2003	GMC truck	Safari - 4WD	Instrument panel cluster	○	○	○	○	●	●	T039
2003	GMC truck	Safari - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	GMC truck	Savana (CNG)	Powertrain	●	●	●	●	●	○	
2003	GMC truck	Savana (CNG)	Body control module	●	●	●	●	●	○	
2003	GMC truck	Savana (CNG)	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2003	GMC truck	Savana (CNG)	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	Savana (CNG)	ABS	●	●	●	●	●	○	
2003	GMC truck	Savana - 2WD	Powertrain	●	●	●	●	●	●	T146
2003	GMC truck	Savana - 2WD	Body control module	●	●	●	●	●	○	
2003	GMC truck	Savana - 2WD	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2003	GMC truck	Savana - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	Savana - 2WD	ABS	●	●	●	●	●	○	
2003	GMC truck	Savana - AWD	Powertrain	●	●	●	●	●	●	T146
2003	GMC truck	Savana - AWD	Body control module	●	●	●	●	●	○	
2003	GMC truck	Savana - AWD	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2003	GMC truck	Savana - AWD	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	Savana - AWD	ABS	●	●	●	●	●	○	
2003	GMC truck	Sonoma pickup - 2WD	Powertrain	●	●	●	●	●	●	T146
2003	GMC truck	Sonoma pickup - 2WD	Body control module	●	●	○	●	●	●	T032
2003	GMC truck	Sonoma pickup - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2003	GMC truck	Sonoma pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	GMC truck	Sonoma pickup - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	GMC truck	Sonoma pickup - 4WD	Powertrain	●	●	●	●	●	●	T146
2003	GMC truck	Sonoma pickup - 4WD	Body control module	●	●	○	●	●	●	T032

2003	GMC truck	Sonoma pickup - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2003	GMC truck	Sonoma pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	GMC truck	Sonoma pickup - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	GMC truck	Yukon - 2WD	Powertrain	●	●	●	●	●	○	
2003	GMC truck	Yukon - 2WD	Body control module	●	●	●	●	●	○	
2003	GMC truck	Yukon - 2WD	Heating and air conditioning	●	●	●	●	●	○	
2003	GMC truck	Yukon - 2WD	Radio	○	○	○	●	○	○	
2003	GMC truck	Yukon - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	GMC truck	Yukon - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	Yukon - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	GMC truck	Yukon - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2003	GMC truck	Yukon - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2003	GMC truck	Yukon - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2003	GMC truck	Yukon - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	GMC truck	Yukon - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	Yukon - 2WD	ABS	●	●	●	●	●	○	
2003	GMC truck	Yukon - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	Yukon - 4WD	Powertrain	●	●	●	●	●	○	
2003	GMC truck	Yukon - 4WD	Body control module	●	●	●	●	●	○	
2003	GMC truck	Yukon - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2003	GMC truck	Yukon - 4WD	Radio	○	○	○	●	○	○	
2003	GMC truck	Yukon - 4WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	GMC truck	Yukon - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	Yukon - 4WD	Digital radio receiver	●	●	●	●	○	●	T024

2003	GMC truck	Yukon - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2003	GMC truck	Yukon - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2003	GMC truck	Yukon - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2003	GMC truck	Yukon - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	GMC truck	Yukon - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	Yukon - 4WD	ABS	●	●	●	●	●	○	
2003	GMC truck	Yukon - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	Yukon denali	Powertrain	●	●	●	●	●	○	
2003	GMC truck	Yukon denali	Body control module	●	●	●	●	●	○	
2003	GMC truck	Yukon denali	Heating and air conditioning	●	●	●	●	●	○	
2003	GMC truck	Yukon denali	Radio	○	○	○	●	○	○	
2003	GMC truck	Yukon denali	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	GMC truck	Yukon denali	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	Yukon denali	Digital radio receiver	●	●	●	●	○	●	T024
2003	GMC truck	Yukon denali	Instrument panel cluster	●	●	●	●	●	○	
2003	GMC truck	Yukon denali	Rear seat entertainment	●	●	●	○	○	○	
2003	GMC truck	Yukon denali	Passenger presence system	●	●	●	●	●	●	T020
2003	GMC truck	Yukon denali	Amplifier (bose)	●	●	●	●	●	●	T139
2003	GMC truck	Yukon denali	ESC (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	Yukon denali	ABS	●	●	●	●	●	○	
2003	GMC truck	Yukon denali	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	Yukon XL - 2WD	Powertrain	●	●	●	●	●	●	T079
2003	GMC truck	Yukon XL - 2WD	Body control module	●	●	●	●	●	○	
2003	GMC truck	Yukon XL - 2WD	Heating and air conditioning	●	●	●	●	●	○	

2003	GMC truck	Yukon XL - 2WD	Radio	○	○	○	●	○	○	
2003	GMC truck	Yukon XL - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	GMC truck	Yukon XL - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	Yukon XL - 2WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	GMC truck	Yukon XL - 2WD	Instrument panel cluster	●	●	●	●	●	○	
2003	GMC truck	Yukon XL - 2WD	Rear seat entertainment	●	●	●	○	○	○	
2003	GMC truck	Yukon XL - 2WD	Passenger presence system	●	●	●	●	●	●	T020
2003	GMC truck	Yukon XL - 2WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	GMC truck	Yukon XL - 2WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	Yukon XL - 2WD	ABS	●	●	●	●	●	○	
2003	GMC truck	Yukon XL - 2WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	Yukon XL - 4WD	Powertrain	●	●	●	●	●	○	
2003	GMC truck	Yukon XL - 4WD	Body control module	●	●	●	●	●	○	
2003	GMC truck	Yukon XL - 4WD	Heating and air conditioning	●	●	●	●	●	○	
2003	GMC truck	Yukon XL - 4WD	Radio	○	○	○	●	○	○	
2003	GMC truck	Yukon XL - 4WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	GMC truck	Yukon XL - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2003	GMC truck	Yukon XL - 4WD	Digital radio receiver	●	●	●	●	○	●	T024
2003	GMC truck	Yukon XL - 4WD	Instrument panel cluster	●	●	●	●	●	○	
2003	GMC truck	Yukon XL - 4WD	Rear seat entertainment	●	●	●	○	○	○	
2003	GMC truck	Yukon XL - 4WD	Passenger presence system	●	●	●	●	●	●	T020
2003	GMC truck	Yukon XL - 4WD	Amplifier (bose)	●	●	●	●	●	●	T139
2003	GMC truck	Yukon XL - 4WD	ESC (if equipped)	●	●	●	●	●	●	T156
2003	GMC truck	Yukon XL - 4WD	ABS	●	●	●	●	●	○	

2003	GMC truck	Yukon XL - 4WD	Traction assist (if equipped)	●	●	●	●	●	●	T156
2003	Isuzu	Ascender - 4WD	Powertrain	●	●	●	●	●	○	
2003	Isuzu	Ascender - 4WD	Body control module	●	●	○	●	●	●	T032
2003	Isuzu	Ascender - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2003	Isuzu	Ascender - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	Isuzu	Ascender - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2003	Oldsmobile	Bravada	Powertrain	●	●	●	●	●	○	
2003	Oldsmobile	Bravada	Amplifier (bose)	●	●	●	●	●	○	
2003	Oldsmobile	Bravada	Rear seat audio	○	○	○	●	○	○	
2003	Oldsmobile	Bravada	Heating and air conditioning	○	○	○	●	●	○	
2003	Oldsmobile	Bravada	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Oldsmobile	Bravada	Onstar	●	●	●	●	●	●	T155 T191
2003	Oldsmobile	Bravada	Radio	●	●	○	●	○	○	
2003	Oldsmobile	Bravada	Body control module	●	●	●	●	●	●	T058
2003	Oldsmobile	Bravada	4WAL 3 sensor	●	●	○	●	●	○	
2003	Oldsmobile	Bravada	Traction assist (if equipped)	●	●	○	●	●	○	
2003	Oldsmobile	Bravada - 2WD	Powertrain	●	●	●	●	●	○	
2003	Oldsmobile	Bravada - 2WD	Amplifier (bose)	●	●	●	●	●	○	
2003	Oldsmobile	Bravada - 2WD	Rear seat audio	○	○	○	●	○	○	
2003	Oldsmobile	Bravada - 2WD	Heating and air conditioning	○	○	○	●	●	○	
2003	Oldsmobile	Bravada - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2003	Oldsmobile	Bravada - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2003	Oldsmobile	Bravada - 2WD	Radio	●	●	○	●	○	○	
2003	Oldsmobile	Bravada - 2WD	Body control module	●	●	●	●	●	●	T058
2003	Oldsmobile	Bravada - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2003	Oldsmobile	Bravada - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	

2003	Oldsmobile	Silhouette	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080
2003	Oldsmobile	Silhouette	Memory seat module	●	●	○	●	●	○	
2003	Oldsmobile	Silhouette	Radio	○	○	○	●	○	○	
2003	Oldsmobile	Silhouette	Onstar	●	●	●	●	●	●	T155 T191
2003	Oldsmobile	Silhouette	Supplemental inflatable restraint	●	●	●	●	●	●	T032
2003	Oldsmobile	Silhouette	Chassis	●	●	●	●	●	●	T014
2003	Oldsmobile	Silhouette	Powertrain	●	●	●	●	●	●	T001
2003	Pontiac	Aztek - AWD	Powertrain	●	●	●	●	●	●	T001
2003	Pontiac	Aztek - AWD	Body control module	●	●	○	●	●	●	T145
2003	Pontiac	Aztek - AWD	Onstar	●	●	●	●	●	●	T155 T191
2003	Pontiac	Aztek - AWD	Digital radio receiver	●	●	●	●	●	●	T024
2003	Pontiac	Aztek - AWD	Vehicle theft deterrent	●	●	○	○	○	○	
2003	Pontiac	Aztek - AWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2003	Pontiac	Aztek - AWD	Rear seat entertainment	●	●	●	●	●	●	T145
2003	Pontiac	Aztek - AWD	Chassis	●	●	○	●	●	●	T014
2003	Pontiac	Aztek - FWD	Powertrain	●	●	●	●	●	●	T001
2003	Pontiac	Aztek - FWD	Body control module	●	●	○	●	●	●	T145
2003	Pontiac	Aztek - FWD	Onstar	●	●	●	●	●	●	T155 T191
2003	Pontiac	Aztek - FWD	Digital radio receiver	●	●	●	●	●	●	T024
2003	Pontiac	Aztek - FWD	Vehicle theft deterrent	●	●	○	○	○	○	
2003	Pontiac	Aztek - FWD	Supplemental inflatable restraint	●	●	○	●	○	○	
2003	Pontiac	Aztek - FWD	Rear seat entertainment	●	●	●	●	●	●	T145
2003	Pontiac	Aztek - FWD	Chassis	●	●	○	●	●	●	T014
2003	Pontiac	Montana	Powertrain	●	●	●	●	●	●	T001
2003	Pontiac	Montana	Onstar	●	●	●	●	●	●	T155 T191
2003	Pontiac	Montana	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080

2003	Pontiac	Montana	Radio	○	○	○	●	○	○	
2003	Pontiac	Montana	Supplemental inflatable restraint	●	●	●	●	●	●	T032
2003	Pontiac	Montana	Chassis	●	●	●	●	●	●	T014
2003	Hummer	H2	Powertrain	●	●	●	●	●	○	
2003	Hummer	H2	Body control module	●	●	●	●	●	○	
2003	Hummer	H2	Amplifier (bose)	●	●	●	●	●	○	
2003	Hummer	H2	Supplemental inflatable restraint	●	●	○	○	○	○	
2003	Hummer	H2	Onstar	●	●	●	●	●	●	T155 T191
2003	Hummer	H2	Digital radio receiver	●	●	●	●	○	●	T024
2003	Hummer	H2	Instrument panel cluster	●	●	●	●	●	○	
2003	Hummer	H2	ABS	●	●	●	●	●	○	
2002	Buick	Century	Powertrain	●	●	●	●	●	●	T001
2002	Buick	Century	Body control module	●	●	○	●	●	●	T122 T170 T198 T136
2002	Buick	Century	Onstar	●	●	●	●	●	●	T155 T191
2002	Buick	Century	Supplemental inflatable restraint	●	●	○	●	○	●	T023
2002	Buick	Century	Chassis	●	●	●	●	●	●	T014
2002	Buick	Lesabre	Powertrain	●	●	●	●	●	●	T001
2002	Buick	Lesabre	Dash integration module	○	○	○	●	●	●	T159 T158
2002	Buick	Lesabre	CD changer	●	●	○	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112 T136 T112
2002	Buick	Lesabre	Instrument panel module	●	●	○	●	●	●	T138 T175
2002	Buick	Lesabre	Radio	○	○	○	●	○	●	T081 T082 T083 T084 T085 T202 T203 T086 T087 T144 T080 T060
2002	Buick	Lesabre	Onstar	●	●	●	●	○	●	T155 T191
2002	Buick	Lesabre	Remote function actuation	●	●	○	○	●	○	

2002	Buick	Lesabre	Supplemental inflatable restraint	●	●	○	○	○	○	
2002	Buick	Lesabre	Vehicle theft deterrent	●	●	○	●	●	●	T159 T158
2002	Buick	Lesabre	Memory seat module	●	●	●	●	●	●	T081 T082 T083 T084 T085 T202 T203 T086 T087 T144 T080 T060
2002	Buick	Lesabre	Rear integration module	●	●	○	●	●	○	
2002	Buick	Lesabre	DRP/ABS/TIM	●	●	○	●	●	●	T014
2002	Buick	Park avenue	Powertrain	●	●	●	●	●	●	T001
2002	Buick	Park avenue	Body control module	●	●	○	●	●	●	T122 T176 T192 T138
2002	Buick	Park avenue	Onstar	●	●	●	●	○	●	T155 T191
2002	Buick	Park avenue	Personalization	●	●	○	●	●	●	T058 T058
2002	Buick	Park avenue	Vehicle theft deterrent	●	●	○	○	○	○	
2002	Buick	Park avenue	DRP/ABS/TIM	●	●	○	●	●	●	T014
2002	Buick	Regal	Powertrain	●	●	●	●	●	●	T001
2002	Buick	Regal	Body control module	●	●	○	●	●	●	T122 T170 T198 T136
2002	Buick	Regal	Onstar	●	●	●	●	●	●	T155 T191
2002	Buick	Regal	Supplemental inflatable restraint	●	●	○	●	○	●	T023
2002	Buick	Regal	Chassis	●	●	●	●	●	●	T014
2002	Cadillac	Deville	Powertrain	●	●	●	●	●	○	
2002	Cadillac	Deville	Dash integration module	●	●	○	●	●	●	T122 T123 T127 T204 T094 T138 T175
2002	Cadillac	Deville	CD changer	●	●	○	●	●	●	T178 T178 T136 T159 T158 T181 T122 T180
2002	Cadillac	Deville	Instrument panel cluster	○	○	○	●	○	○	
2002	Cadillac	Deville	Amplifier (delco)	●	●	○	●	●	○	
2002	Cadillac	Deville	Memory seat module	●	●	○	●	●	○	
2002	Cadillac	Deville	Onstar	●	●	●	●	●	●	T155 T191
2002	Cadillac	Deville	Digital radio receiver	●	●	●	●	○	●	T172

2002	Cadillac	Deville	Remote function actuation	●	●	○	○	●	○	
2002	Cadillac	Deville	Vehicle theft deterrent	●	●	○	○	○	○	
2002	Cadillac	Deville	Driver door switch	●	●	●	●	○	○	
2002	Cadillac	Deville	Left rear door module	●	●	●	●	●	○	
2002	Cadillac	Deville	Right rear door module	●	●	●	●	●	○	
2002	Cadillac	Deville	Driver door module	●	●	●	●	●	○	
2002	Cadillac	Deville	Passenger door module	●	●	●	●	○	●	T193
2002	Cadillac	Deville	Tire pressure monitor	●	●	○	●	○	○	
2002	Cadillac	Deville	DRP/ABS/TCS/VSES/BLW	●	●	○	●	●	○	
2002	Cadillac	Deville	Speed sensitive steering	●	●	○	●	○	○	
2002	Cadillac	Deville	Electronic suspension control	●	●	●	●	●	○	
2002	Cadillac	DHS	Powertrain	●	●	●	●	●	○	
2002	Cadillac	DHS	Dash integration module	●	●	○	●	●	●	T122 T123 T127 T204 T094 T138 T175
2002	Cadillac	DHS	Amplifier (bose)	●	●	○	●	●	○	
2002	Cadillac	DHS	CD changer	●	●	○	●	●	●	T178 T178 T136 T159 T158 T181 T122 T180
2002	Cadillac	DHS	Instrument panel cluster	●	●	●	●	○	●	T116 T166
2002	Cadillac	DHS	Memory seat module	●	●	○	●	●	○	
2002	Cadillac	DHS	Onstar	●	●	●	●	●	●	T155 T191
2002	Cadillac	DHS	Digital radio receiver	●	●	●	●	○	●	T172
2002	Cadillac	DHS	Remote function actuation	●	●	○	○	●	○	
2002	Cadillac	DHS	Vehicle theft deterrent	●	●	○	○	○	○	
2002	Cadillac	DHS	Driver door switch	●	●	●	●	○	○	
2002	Cadillac	DHS	Left rear door module	●	●	●	●	●	○	
2002	Cadillac	DHS	Right rear door module	●	●	●	●	●	○	
2002	Cadillac	DHS	Driver door module	●	●	●	●	●	○	
2002	Cadillac	DHS	Passenger door module	●	●	●	●	○	●	T193

2002	Cadillac	DHS	Tire pressure monitor	●	●	○	●	○	○	
2002	Cadillac	DHS	DRP/ABS/TCS/VSES/BLW	●	●	○	●	●	○	
2002	Cadillac	DHS	Speed sensitive steering	●	●	○	●	○	○	
2002	Cadillac	DHS	Electronic suspension control	●	●	●	●	●	○	
2002	Cadillac	DTS	Powertrain	●	●	●	●	●	○	
2002	Cadillac	DTS	Dash integration module	●	●	○	●	●	●	T122 T123 T127 T204 T094 T138 T175
2002	Cadillac	DTS	Amplifier (bose)	●	●	○	●	●	○	
2002	Cadillac	DTS	CD changer	●	●	○	●	●	●	T178 T178 T136 T159 T158 T181 T122 T180
2002	Cadillac	DTS	Instrument panel cluster	●	●	●	●	○	●	T116 T166
2002	Cadillac	DTS	Memory seat module	●	●	○	●	●	●	T182
2002	Cadillac	DTS	Onstar	●	●	●	●	●	●	T155 T191
2002	Cadillac	DTS	Digital radio receiver	●	●	●	●	○	●	T172
2002	Cadillac	DTS	Remote function actuation	●	●	○	○	●	○	
2002	Cadillac	DTS	Vehicle theft deterrent	●	●	○	○	○	○	
2002	Cadillac	DTS	Driver door switch	●	●	●	●	○	○	
2002	Cadillac	DTS	Left rear door module	●	●	●	●	●	○	
2002	Cadillac	DTS	Right rear door module	●	●	●	●	●	○	
2002	Cadillac	DTS	Driver door module	●	●	●	●	●	○	
2002	Cadillac	DTS	Passenger door module	●	●	●	●	○	●	T193
2002	Cadillac	DTS	Tire pressure monitor	●	●	○	●	○	○	
2002	Cadillac	DTS	DRP/ABS/TCS/VSES/BLW	●	●	○	●	●	○	
2002	Cadillac	DTS	Speed sensitive steering	●	●	○	●	○	○	
2002	Cadillac	DTS	Electronic suspension control	●	●	●	●	●	○	
2002	Cadillac	Eldorado	Powertrain	●	●	●	●	●	○	
2002	Cadillac	Eldorado	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190 T033

2002	Cadillac	Eldorado	Radio	●	●	○	●	●	●	T210
2002	Cadillac	Eldorado	Onstar	●	●	●	●	○	●	T155 T191
2002	Cadillac	Eldorado	Remote function actuation	●	●	○	○	●	○	
2002	Cadillac	Eldorado	Supplemental inflatable restraint	●	●	○	○	○	○	
2002	Cadillac	Eldorado	Delco/Xtool ABS/TCS	●	●	○	○	●	●	T149 T014
2002	Cadillac	Eldorado	Magna steer	●	●	○	○	○	○	
2002	Cadillac	Seville	Powertrain	●	●	●	●	●	○	
2002	Cadillac	Seville	Amplifier (bose)	●	●	○	●	●	●	T122 T123 T125 T194 T195 T193 T094
2002	Cadillac	Seville	CD changer	●	●	○	●	●	●	T178 T178 T136 T159 T158 T181 T122 T180
2002	Cadillac	Seville	Amplifier (delco)	●	●	○	●	●	○	
2002	Cadillac	Seville	Instrument panel cluster	●	●	●	●	○	●	T116 T166
2002	Cadillac	Seville	Memory seat module	●	●	○	●	●	●	T182
2002	Cadillac	Seville	Onstar	●	●	●	●	●	●	T155 T191
2002	Cadillac	Seville	Digital radio receiver	●	●	●	●	○	○	
2002	Cadillac	Seville	Dash integration module	○	○	○	○	○	●	T172
2002	Cadillac	Seville	Remote function actuation	●	●	○	●	●	●	T112 T113
2002	Cadillac	Seville	Vehicle theft deterrent	●	●	●	●	●	●	T122 T123 T125 T194 T195 T193 T094
2002	Cadillac	Seville	Tire pressure monitor	●	●	○	●	○	○	
2002	Cadillac	Seville	DRP/ABS/TCS/VSES/BLW	●	●	○	●	●	○	
2002	Cadillac	Seville	Speed sensitive steering	●	●	○	●	○	○	
2002	Cadillac	Seville	Electronic suspension control	●	●	●	●	●	○	
2002	Chevrolet	Alero (export)	Powertrain	●	●	●	●	●	●	T001
2002	Chevrolet	Alero (export)	Body control module	●	●	●	○	●	●	T141
2002	Chevrolet	Alero (export)	Radio	●	●	●	●	●	●	T183

2002	Chevrolet	Alero (export)	Vehicle theft deterrent	●	●	○	●	○	○	
2002	Chevrolet	Alero (export)	Chassis	●	●	●	●	●	●	T014
2002	Chevrolet	Camaro	Powertrain	●	●	●	●	●	●	T001
2002	Chevrolet	Camaro	Instrument panel cluster	●	●	○	●	●	●	T190
2002	Chevrolet	Camaro	Supplemental inflatable restraint	●	●	○	●	●	●	T190
2002	Chevrolet	Camaro	Chassis	●	●	○	●	●	●	T014
2002	Chevrolet	Cavalier	Powertrain	●	●	●	●	●	○	
2002	Chevrolet	Cavalier	Radio	○	○	○	●	○	○	
2002	Chevrolet	Cavalier	Body control module	●	●	●	●	●	●	T141 T183
2002	Chevrolet	Cavalier	Chassis	●	●	●	●	●	●	T014
2002	Chevrolet	Cavalier (CNG)	Powertrain	●	●	●	●	●	○	
2002	Chevrolet	Cavalier (CNG)	Radio	○	○	○	●	○	○	
2002	Chevrolet	Cavalier (CNG)	Body control module	●	●	●	●	●	●	T141 T183
2002	Chevrolet	Cavalier (CNG)	Chassis	●	●	●	●	●	●	T014
2002	Chevrolet	Corvette	Powertrain	●	●	●	●	●	○	
2002	Chevrolet	Corvette	Body control module	●	●	○	●	●	●	T196
2002	Chevrolet	Corvette	Remote function actuation	●	●	○	○	○	●	T181
2002	Chevrolet	Corvette	Supplemental inflatable restraint	●	●	○	●	●	●	T196
2002	Chevrolet	Corvette	ABS/TCS	●	●	●	●	●	○	
2002	Chevrolet	Corvette	RTD	●	●	●	●	●	○	
2002	Chevrolet	Impala	Powertrain	●	●	●	●	●	●	T001
2002	Chevrolet	Impala	Radio	○	○	○	●	○	○	
2002	Chevrolet	Impala	Body control module	●	●	○	●	●	●	T023 T136 T122 T088 T080 T081 T082 T211
2002	Chevrolet	Impala	Onstar	●	●	●	●	●	●	T155 T191
2002	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T023 T136 T122 T088 T080 T081 T082 T211
2002	Chevrolet	Impala	Chassis	●	●	●	○	●	●	T014
2002	Chevrolet	Malibu	Powertrain	●	●	●	●	●	●	T001
2002	Chevrolet	Malibu	Body control module	●	●	●	○	●	●	T141

2002	Chevrolet	Malibu	Radio	○	○	●	●	●	○	
2002	Chevrolet	Malibu	Remote function actuation	●	●	○	●	●	○	
2002	Chevrolet	Malibu	Chassis	●	●	●	●	●	●	T014
2002	Chevrolet	Lumina	Powertrain	●	●	●	●	●	●	T001
2002	Chevrolet	Monte carlo	Powertrain	●	●	●	●	●	●	T001
2002	Chevrolet	Monte carlo	Radio	○	○	○	●	○	○	
2002	Chevrolet	Monte carlo	Body control module	●	●	○	●	●	●	T023 T136 T122 T088 T080 T081 T082 T211
2002	Chevrolet	Monte carlo	Onstar	●	●	●	●	●	●	T155 T191
2002	Chevrolet	Monte carlo	Supplemental inflatable restraint	●	●	●	●	●	●	T023 T136 T122 T088 T080 T081 T082 T211
2002	Chevrolet	Monte carlo	Chassis	●	●	●	○	●	●	T014
2002	Chevrolet	Prizm	Supplemental inflatable restraint	●	●	○	○	○	○	
2002	Oldsmobile	Alero	Powertrain	●	●	●	●	●	●	T001
2002	Oldsmobile	Alero	Body control module	●	●	●	○	●	●	T141
2002	Oldsmobile	Alero	Radio	●	●	●	●	●	●	T183
2002	Oldsmobile	Alero	Instrument panel cluster	○	○	○	●	○	○	
2002	Oldsmobile	Alero	Onstar	●	●	●	●	●	●	T155 T191
2002	Oldsmobile	Alero	Remote function actuation	●	●	○	●	●	○	
2002	Oldsmobile	Alero	Chassis	●	●	●	●	●	●	T014
2002	Oldsmobile	Aurora	Powertrain	●	●	●	●	●	○	
2002	Oldsmobile	Aurora	CD changer	●	●	○	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112 T136 T138 T175 T081 T082 T083 T084 T085 T202 T203 T086 T087 T080 T060 T033 T081 T082 T083 T084 T085 T202 T203 T086 T087 T144 T080 T060 T201 T112

2002	Oldsmobile	Aurora	Memory seat module	●	●	○	●	●	○	
2002	Oldsmobile	Aurora	Onstar	●	●	●	●	○	●	T155 T191
2002	Oldsmobile	Aurora	Remote function actuation	●	●	○	○	●	○	
2002	Oldsmobile	Aurora	Supplemental inflatable restraint	●	●	○	○	○	○	
2002	Oldsmobile	Aurora	Vehicle theft deterrent	●	●	○	○	○	●	T185
2002	Oldsmobile	Aurora	Rear integration module	●	●	○	●	●	○	
2002	Oldsmobile	Aurora	DRP/ABS/TIM	●	●	○	●	●	●	T014
2002	Oldsmobile	Intrigue	Powertrain	●	●	●	●	●	○	
2002	Oldsmobile	Intrigue	Body control module	●	●	○	●	●	●	T170 T198 T136 T080 T082 T033
2002	Oldsmobile	Intrigue	Onstar	●	●	●	●	●	●	T155 T191
2002	Oldsmobile	Intrigue	Supplemental inflatable restraint	●	●	○	●	○	●	T023
2002	Oldsmobile	Intrigue	Chassis	●	●	○	●	●	●	T212
2002	Pontiac	Bonneville	Powertrain	●	●	●	●	●	●	T001
2002	Pontiac	Bonneville	Instrument panel cluster	○	○	○	●	○	○	
2002	Pontiac	Bonneville	Dash integration module	○	○	○	●	●	●	T081 T082 T083 T084 T085 T202 T203 T086 T087 T144 T080 T060
2002	Pontiac	Bonneville	CD changer	●	●	○	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112 T136 T112
2002	Pontiac	Bonneville	Instrument panel module	●	●	○	●	●	●	T138 T175
2002	Pontiac	Bonneville	Onstar	●	●	●	●	○	●	T155 T191
2002	Pontiac	Bonneville	Supplemental inflatable restraint	●	●	○	○	○	○	
2002	Pontiac	Bonneville	Vehicle theft deterrent	●	●	○	●	●	●	T185
2002	Pontiac	Bonneville	Climate control panel	●	●	●	●	●	●	T155 T191

2002	Pontiac	Bonneville	Remote function actuation	●	●	○	●	●	●	T185
2002	Pontiac	Bonneville	Rear integration module	●	●	●	●	●	●	T186
2002	Pontiac	Bonneville	DRP/ABS/TIM	●	●	○	●	●	●	T014
2002	Pontiac	Firebird	Powertrain	●	●	●	●	●	●	T001
2002	Pontiac	Firebird	Instrument panel cluster	●	●	○	●	●	●	T190
2002	Pontiac	Firebird	Supplemental inflatable restraint	●	●	○	●	●	●	T190
2002	Pontiac	Firebird	Chassis	●	●	○	●	●	●	T014
2002	Pontiac	Grand am	Powertrain	●	●	●	●	●	●	T001
2002	Pontiac	Grand am	Body control module	●	●	●	○	●	●	T141
2002	Pontiac	Grand am	Radio	●	●	●	●	●	●	T183
2002	Pontiac	Grand am	Instrument panel cluster	○	○	○	●	○	○	
2002	Pontiac	Grand am	Onstar	●	●	●	●	●	●	T155 T191
2002	Pontiac	Grand am	Remote function actuation	●	●	○	●	●	○	
2002	Pontiac	Grand am	Chassis	●	●	●	●	●	●	T014
2002	Pontiac	Grand prix	Powertrain	●	●	●	●	●	●	T001
2002	Pontiac	Grand prix	Onstar	●	●	●	●	○	●	T155 T191
2002	Pontiac	Grand prix	Supplemental inflatable restraint	●	●	○	●	○	○	
2002	Pontiac	Grand prix	Vehicle theft deterrent	●	●	○	●	○	○	
2002	Pontiac	Sunfire	Powertrain	●	●	●	●	●	○	
2002	Pontiac	Sunfire	Radio	○	○	○	●	○	○	
2002	Pontiac	Sunfire	Body control module	●	●	●	●	●	●	T141 T183
2002	Pontiac	Sunfire	Chassis	●	●	●	●	●	●	T014
2002	Buick	Rendezvous - AWD	Powertrain	●	●	●	●	●	●	T001
2002	Buick	Rendezvous - AWD	Body control module	●	●	○	●	●	●	T068 T023 T136 T122 T213 T081 T082 T144 T080

2002	Buick	Rendezvous - AWD	Onstar	●	●	●	●	○	●	T155 T191
2002	Buick	Rendezvous - AWD	Supplemental inflatable restraint	●	●	○	○	○	○	
2002	Buick	Rendezvous - AWD	Vehicle theft deterrent	●	●	●	●	●	●	T068 T023 T136 T122 T213 T081 T082 T144 T080
2002	Buick	Rendezvous - AWD	Chassis	●	●	○	●	●	●	T014
2002	Buick	Rendezvous - FWD	Powertrain	●	●	●	●	●	●	T001
2002	Buick	Rendezvous - FWD	Body control module	●	●	○	●	●	●	T068 T023 T136 T122 T213 T081 T082 T144 T080
2002	Buick	Rendezvous - FWD	Onstar	●	●	●	●	○	●	T155 T191
2002	Buick	Rendezvous - FWD	Supplemental inflatable restraint	●	●	○	○	○	○	
2002	Buick	Rendezvous - FWD	Vehicle theft deterrent	●	●	●	●	●	●	T068 T023 T136 T122 T213 T081 T082 T144 T080
2002	Buick	Rendezvous - FWD	Chassis	●	●	○	●	●	●	T014
2002	Cadillac	Escalade - 2WD	Powertrain	●	●	●	●	●	○	
2002	Cadillac	Escalade - 2WD	Body control module	●	●	●	●	●	●	T031
2002	Cadillac	Escalade - 2WD	Memory mirror module	●	●	○	●	●	○	
2002	Cadillac	Escalade - 2WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	Cadillac	Escalade - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2002	Cadillac	Escalade - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Cadillac	Escalade - 2WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Cadillac	Escalade - 2WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Cadillac	Escalade - AWD	Powertrain	●	●	●	●	●	○	
2002	Cadillac	Escalade - AWD	Body control module	●	●	●	●	●	●	T031
2002	Cadillac	Escalade - AWD	Memory mirror module	●	●	○	●	●	○	

2002	Cadillac	Escalade - AWD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	Cadillac	Escalade - AWD	Onstar	●	●	●	●	●	●	T155 T191
2002	Cadillac	Escalade - AWD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Cadillac	Escalade - AWD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Cadillac	Escalade - AWD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Cadillac	Escalade EXT	Powertrain	●	●	●	●	●	○	
2002	Cadillac	Escalade EXT	Body control module	●	●	●	●	●	●	T031
2002	Cadillac	Escalade EXT	Memory mirror module	●	●	○	●	●	○	
2002	Cadillac	Escalade EXT	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	Cadillac	Escalade EXT	Onstar	●	●	●	●	●	●	T155 T191
2002	Cadillac	Escalade EXT	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Cadillac	Escalade EXT	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Cadillac	Escalade EXT	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Cadillac	Incomplete	Powertrain	●	●	●	●	●	●	T001
2002	Cadillac	Incomplete	Amplifier (delco)	●	●	○	●	●	●	T172 T126 T127 T136 T158 T094 T138 T175 T179 T086 T087 T033
2002	Cadillac	Incomplete	Rear integration module	○	○	○	●	○	○	
2002	Cadillac	Incomplete	Remote function actuation	●	●	○	○	●	○	
2002	Cadillac	Incomplete	Dash integration module	●	●	○	○	○	●	T112 T113
2002	Cadillac	Incomplete	Vehicle theft deterrent	●	●	○	○	○	●	T199
2002	Cadillac	Incomplete	Driver door module	●	●	●	●	●	○	
2002	Cadillac	Incomplete	Driver door switch	●	●	●	●	○	○	
2002	Cadillac	Incomplete	Passenger door module	●	●	●	●	●	●	T172 T126 T127 T136 T158 T094 T138 T175 T179 T086 T087 T033
2002	Cadillac	Incomplete	Rear climate control panel	●	●	○	●	●	○	
2002	Cadillac	Incomplete	Onstar	●	●	●	●	●	●	T155 T191

2002	Cadillac	Incomplete	Left mid door module	●	●	●	●	●	○	
2002	Cadillac	Incomplete	Left rear door module	●	●	●	●	●	○	
2002	Cadillac	Incomplete	Right mid door module	●	●	●	●	●	○	
2002	Cadillac	Incomplete	Right rear door module	●	●	●	●	●	○	
2002	Cadillac	Incomplete	DRP/ABS/TCS	●	●	○	●	●	○	
2002	Chevrolet	Astro - 2WD	Powertrain	●	●	●	●	●	●	T146
2002	Chevrolet	Astro - 2WD	Body control module	●	●	○	●	●	○	
2002	Chevrolet	Astro - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2002	Chevrolet	Astro - 2WD	Instrument panel cluster	●	●	○	○	●	●	T039
2002	Chevrolet	Astro - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	Chevrolet	Astro - 4WD	Powertrain	●	●	●	●	●	●	T146
2002	Chevrolet	Astro - 4WD	Body control module	●	●	○	●	●	○	
2002	Chevrolet	Astro - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2002	Chevrolet	Astro - 4WD	Instrument panel cluster	●	●	○	○	●	●	T039
2002	Chevrolet	Astro - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	Chevrolet	Avalanche - 2WD	Powertrain	●	●	●	●	●	●	T079
2002	Chevrolet	Avalanche - 2WD	Body control module	●	●	●	●	●	●	T031
2002	Chevrolet	Avalanche - 2WD	Memory mirror module	●	●	○	●	●	○	
2002	Chevrolet	Avalanche - 2WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	Chevrolet	Avalanche - 2WD	Onstar	●	●	●	●	○	●	T155 T191
2002	Chevrolet	Avalanche - 2WD	Vehicle theft deterrent	●	●	●	●	●	●	T031
2002	Chevrolet	Avalanche - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Chevrolet	Avalanche - 2WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Chevrolet	Avalanche - 2WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Chevrolet	Avalanche - 4WD	Powertrain	●	●	●	●	●	●	T079
2002	Chevrolet	Avalanche - 4WD	Body control module	●	●	●	●	●	●	T031
2002	Chevrolet	Avalanche - 4WD	Memory mirror module	●	●	○	●	●	○	
2002	Chevrolet	Avalanche - 4WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039

2002	Chevrolet	Avalanche - 4WD	Onstar	●	●	●	●	○	●	T155 T191
2002	Chevrolet	Avalanche - 4WD	Vehicle theft deterrent	●	●	●	●	●	●	T031
2002	Chevrolet	Avalanche - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Chevrolet	Avalanche - 4WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Chevrolet	Avalanche - 4WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Chevrolet	Blazer - 2WD	Powertrain	●	●	●	●	●	●	T146
2002	Chevrolet	Blazer - 2WD	Amplifier (bose)	●	●	●	●	●	●	T058
2002	Chevrolet	Blazer - 2WD	Rear seat audio	○	○	○	●	○	○	
2002	Chevrolet	Blazer - 2WD	Heating and air conditioning	○	○	○	●	●	○	
2002	Chevrolet	Blazer - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2002	Chevrolet	Blazer - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2002	Chevrolet	Blazer - 2WD	Radio	●	●	●	●	●	●	T058
2002	Chevrolet	Blazer - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	Chevrolet	Blazer - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2002	Chevrolet	Blazer - 4WD	Powertrain	●	●	●	●	●	●	T146
2002	Chevrolet	Blazer - 4WD	Amplifier (bose)	●	●	●	●	●	●	T058
2002	Chevrolet	Blazer - 4WD	Rear seat audio	○	○	○	●	○	○	
2002	Chevrolet	Blazer - 4WD	Heating and air conditioning	○	○	○	●	●	○	
2002	Chevrolet	Blazer - 4WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2002	Chevrolet	Blazer - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2002	Chevrolet	Blazer - 4WD	Radio	●	●	●	●	●	●	T058
2002	Chevrolet	Blazer - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	Chevrolet	Blazer - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2002	Chevrolet	Blazer - 4WD - RHD	Powertrain	●	●	●	●	●	●	T146
2002	Chevrolet	Blazer - 4WD - RHD	Amplifier (bose)	●	●	●	●	●	●	T058

2002	Chevrolet	Blazer - 4WD - RHD	Rear seat audio	○	○	○	●	○	○	
2002	Chevrolet	Blazer - 4WD - RHD	Heating and air conditioning	○	○	○	●	●	○	
2002	Chevrolet	Blazer - 4WD - RHD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2002	Chevrolet	Blazer - 4WD - RHD	Onstar	●	●	●	●	●	●	T155 T191
2002	Chevrolet	Blazer - 4WD - RHD	Radio	●	●	●	●	●	●	T058
2002	Chevrolet	Blazer - 4WD - RHD	4WAL 3 sensor	●	●	○	●	●	○	
2002	Chevrolet	Blazer - 4WD - RHD	Traction assist (if equipped)	●	●	○	●	●	○	
2002	Chevrolet	C cab/chassis HD (GMT 400)	Powertrain	●	●	●	●	●	●	T079
2002	Chevrolet	C cab/chassis HD (GMT 400)	Body control module	●	●	●	●	●	●	T031
2002	Chevrolet	C cab/chassis HD (GMT 400)	Memory mirror module	●	●	○	●	●	○	
2002	Chevrolet	C cab/chassis HD (GMT 400)	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	Chevrolet	C cab/chassis HD (GMT 400)	Onstar	●	●	●	●	○	●	T155 T191
2002	Chevrolet	C cab/chassis HD (GMT 400)	Vehicle theft deterrent	●	●	●	●	●	●	T031
2002	Chevrolet	C cab/chassis HD (GMT 400)	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Chevrolet	C cab/chassis HD (GMT 400)	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Chevrolet	C cab/chassis HD (GMT 400)	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Chevrolet	C silverado - 2WD	Powertrain	●	●	●	●	●	●	T146

2002	Chevrolet	C silverado - 2WD	Body control module	●	●	●	●	●	●	T031
2002	Chevrolet	C silverado - 2WD	Memory mirror module	●	●	○	●	●	○	
2002	Chevrolet	C silverado - 2WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	Chevrolet	C silverado - 2WD	Onstar	●	●	●	●	○	●	T155 T191
2002	Chevrolet	C silverado - 2WD	Vehicle theft deterrent	●	●	●	●	●	●	T031
2002	Chevrolet	C silverado - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Chevrolet	C silverado - 2WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Chevrolet	C silverado - 2WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Chevrolet	C silverado - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
2002	Chevrolet	C silverado - 2WD (CNG)	Body control module	●	●	●	●	●	●	T031
2002	Chevrolet	C silverado - 2WD (CNG)	Memory mirror module	●	●	○	●	●	○	
2002	Chevrolet	C silverado - 2WD (CNG)	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	Chevrolet	C silverado - 2WD (CNG)	Onstar	●	●	●	●	○	●	T155 T191
2002	Chevrolet	C silverado - 2WD (CNG)	Vehicle theft deterrent	●	●	●	●	●	●	T031
2002	Chevrolet	C silverado - 2WD (CNG)	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Chevrolet	C silverado - 2WD (CNG)	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Chevrolet	C silverado - 2WD (CNG)	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Chevrolet	Express (CNG)	Powertrain	●	●	●	●	●	○	

2002	Chevrolet	Express (CNG)	Immobilizer	●	●	○	●	●	●	T214 T215 T216 T217 T218 T032
2002	Chevrolet	Express (CNG)	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	Chevrolet	Express - 2WD	Powertrain	●	●	●	●	●	●	T146
2002	Chevrolet	Express - 2WD	Immobilizer	●	●	○	●	●	●	T214 T215 T216 T217 T218 T032
2002	Chevrolet	Express - 2WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	Chevrolet	K silverado - 4WD	Powertrain	●	●	●	●	●	●	T146
2002	Chevrolet	K silverado - 4WD	Body control module	●	●	●	●	●	●	T031
2002	Chevrolet	K silverado - 4WD	Memory mirror module	●	●	○	●	●	○	
2002	Chevrolet	K silverado - 4WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	Chevrolet	K silverado - 4WD	Onstar	●	●	●	●	○	●	T155 T191
2002	Chevrolet	K silverado - 4WD	Vehicle theft deterrent	●	●	●	●	●	●	T031
2002	Chevrolet	K silverado - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Chevrolet	K silverado - 4WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Chevrolet	K silverado - 4WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Chevrolet	K silverado - 4WD (CNG)	Powertrain	●	●	●	●	●	○	
2002	Chevrolet	K silverado - 4WD (CNG)	Body control module	●	●	●	●	●	●	T031
2002	Chevrolet	K silverado - 4WD (CNG)	Memory mirror module	●	●	○	●	●	○	
2002	Chevrolet	K silverado - 4WD (CNG)	Supplemental inflatable restraint	●	●	○	●	○	●	T039

2002	Chevrolet	K silverado - 4WD (CNG)	Onstar	●	●	●	●	○	●	T155 T191
2002	Chevrolet	K silverado - 4WD (CNG)	Vehicle theft deterrent	●	●	●	●	●	●	T031
2002	Chevrolet	K silverado - 4WD (CNG)	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Chevrolet	K silverado - 4WD (CNG)	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Chevrolet	K silverado - 4WD (CNG)	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Chevrolet	S10 pickup - 2WD	Powertrain	●	●	●	●	●	●	T146
2002	Chevrolet	S10 pickup - 2WD	Body control module	●	●	○	●	●	●	T032
2002	Chevrolet	S10 pickup - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2002	Chevrolet	S10 pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	Chevrolet	S10 pickup - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2002	Chevrolet	S10 pickup - 4WD	Powertrain	●	●	●	●	●	●	T146
2002	Chevrolet	S10 pickup - 4WD	Body control module	●	●	○	●	●	●	T032
2002	Chevrolet	S10 pickup - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2002	Chevrolet	S10 pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	Chevrolet	S10 pickup - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2002	Chevrolet	Suburban - 2WD	Powertrain	●	●	●	●	●	●	T079
2002	Chevrolet	Suburban - 2WD	Body control module	●	●	●	●	●	●	T031
2002	Chevrolet	Suburban - 2WD	Memory mirror module	●	●	○	●	●	○	
2002	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039

2002	Chevrolet	Suburban - 2WD	Onstar	●	●	●	●	○	●	T155 T191
2002	Chevrolet	Suburban - 2WD	Vehicle theft deterrent	●	●	●	●	●	●	T031
2002	Chevrolet	Suburban - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Chevrolet	Suburban - 2WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Chevrolet	Suburban - 2WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Chevrolet	Suburban - 4WD	Powertrain	●	●	●	●	●	●	T079
2002	Chevrolet	Suburban - 4WD	Body control module	●	●	●	●	●	●	T031
2002	Chevrolet	Suburban - 4WD	Memory mirror module	●	●	○	●	●	○	
2002	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	Chevrolet	Suburban - 4WD	Onstar	●	●	●	●	○	●	T155 T191
2002	Chevrolet	Suburban - 4WD	Vehicle theft deterrent	●	●	●	●	●	●	T031
2002	Chevrolet	Suburban - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Chevrolet	Suburban - 4WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Chevrolet	Suburban - 4WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Chevrolet	Tahoe - 2WD	Powertrain	●	●	●	●	●	○	
2002	Chevrolet	Tahoe - 2WD	Body control module	●	●	●	●	●	●	T031
2002	Chevrolet	Tahoe - 2WD	Memory mirror module	●	●	○	●	●	○	
2002	Chevrolet	Tahoe - 2WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	Chevrolet	Tahoe - 2WD	Onstar	●	●	●	●	○	●	T155 T191
2002	Chevrolet	Tahoe - 2WD	Vehicle theft deterrent	●	●	●	●	●	●	T031
2002	Chevrolet	Tahoe - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Chevrolet	Tahoe - 2WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Chevrolet	Tahoe - 2WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Chevrolet	Tahoe - 4WD	Powertrain	●	●	●	●	●	○	
2002	Chevrolet	Tahoe - 4WD	Body control module	●	●	●	●	●	●	T031
2002	Chevrolet	Tahoe - 4WD	Memory mirror module	●	●	○	●	●	○	
2002	Chevrolet	Tahoe - 4WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	Chevrolet	Tahoe - 4WD	Onstar	●	●	●	●	○	●	T155 T191

2002	Chevrolet	Tahoe - 4WD	Vehicle theft deterrent	●	●	●	●	●	●	T031
2002	Chevrolet	Tahoe - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	Chevrolet	Tahoe - 4WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	Chevrolet	Tahoe - 4WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Chevrolet	Tracker - 2WD	Powertrain	●	●	●	●	●	○	
2002	Chevrolet	Tracker - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2002	Chevrolet	Tracker - 2WD	Chassis	●	●	●	●	●	●	T014
2002	Chevrolet	Tracker - 4WD	Powertrain	●	●	●	●	●	○	
2002	Chevrolet	Tracker - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2002	Chevrolet	Tracker - 4WD	Chassis	●	●	●	●	●	●	T014
2002	Chevrolet	Trailblazer - 2WD	Powertrain	●	●	●	●	●	○	
2002	Chevrolet	Trailblazer - 2WD	Amplifier (bose)	●	●	●	●	●	●	T058
2002	Chevrolet	Trailblazer - 2WD	Rear seat audio	○	○	○	●	○	○	
2002	Chevrolet	Trailblazer - 2WD	Heating and air conditioning	○	○	○	●	●	○	
2002	Chevrolet	Trailblazer - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2002	Chevrolet	Trailblazer - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2002	Chevrolet	Trailblazer - 2WD	Vehicle theft deterrent	●	●	●	●	○	○	
2002	Chevrolet	Trailblazer - 2WD	Radio	●	●	●	●	●	●	T058
2002	Chevrolet	Trailblazer - 2WD	Rear HVAC/RSA	●	●	●	●	●	●	T039
2002	Chevrolet	Trailblazer - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	Chevrolet	Trailblazer - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	

2002	Chevrolet	Trailblazer - 4WD	Powertrain	●	●	●	●	●	○	
2002	Chevrolet	Trailblazer - 4WD	Amplifier (bose)	●	●	●	●	●	●	T058
2002	Chevrolet	Trailblazer - 4WD	Rear seat audio	○	○	○	●	○	○	
2002	Chevrolet	Trailblazer - 4WD	Heating and air conditioning	○	○	○	●	●	○	
2002	Chevrolet	Trailblazer - 4WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2002	Chevrolet	Trailblazer - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2002	Chevrolet	Trailblazer - 4WD	Vehicle theft deterrent	●	●	●	●	○	○	
2002	Chevrolet	Trailblazer - 4WD	Radio	●	●	●	●	●	●	T058
2002	Chevrolet	Trailblazer - 4WD	Rear HVAC/RSA	●	●	●	●	●	●	T039
2002	Chevrolet	Trailblazer - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	Chevrolet	Trailblazer - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2002	Chevrolet	Venture	Powertrain	●	●	●	●	●	●	T001
2002	Chevrolet	Venture	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032
2002	Chevrolet	Venture	Radio	○	○	○	●	○	○	
2002	Chevrolet	Venture	Onstar	●	●	●	●	○	●	T155 T191
2002	Chevrolet	Venture	Supplemental inflatable restraint	●	●	●	●	●	●	T190 T136 T081 T082 T080 T032
2002	Chevrolet	Venture	Chassis	●	●	●	●	●	●	T014
2002	GMC truck	Envoy - 2WD	Powertrain	●	●	●	●	●	○	
2002	GMC truck	Envoy - 2WD	Amplifier (bose)	●	●	●	●	●	●	T058
2002	GMC truck	Envoy - 2WD	Rear seat audio	○	○	○	●	○	○	
2002	GMC truck	Envoy - 2WD	Heating and air conditioning	○	○	○	●	●	○	

2002	GMC truck	Envoy - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2002	GMC truck	Envoy - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2002	GMC truck	Envoy - 2WD	Radio	●	●	●	●	●	●	T058
2002	GMC truck	Envoy - 2WD	Rear HVAC/RSA	●	●	●	●	●	●	T039
2002	GMC truck	Envoy - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	GMC truck	Envoy - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2002	GMC truck	Envoy - 4WD	Powertrain	●	●	●	●	●	○	
2002	GMC truck	Envoy - 4WD	Amplifier (bose)	●	●	●	●	●	●	T058
2002	GMC truck	Envoy - 4WD	Rear seat audio	○	○	○	●	○	○	
2002	GMC truck	Envoy - 4WD	Heating and air conditioning	○	○	○	●	●	○	
2002	GMC truck	Envoy - 4WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2002	GMC truck	Envoy - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2002	GMC truck	Envoy - 4WD	Radio	●	●	●	●	●	●	T058
2002	GMC truck	Envoy - 4WD	Rear HVAC/RSA	●	●	●	●	●	●	T039
2002	GMC truck	Envoy - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	GMC truck	Envoy - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2002	GMC truck	GMC C cab/chassis HD (GMT 400)	Powertrain	●	●	●	●	●	●	T079
2002	GMC truck	GMC C cab/chassis HD (GMT 400)	Body control module	●	●	●	●	●	●	T031
2002	GMC truck	GMC C cab/chassis HD (GMT 400)	Memory mirror module	●	●	○	●	●	○	
2002	GMC truck	GMC C cab/chassis HD (GMT 400)	Supplemental inflatable restraint	●	●	○	●	○	●	T039

2002	GMC truck	GMC C cab/chassis HD (GMT 400)	Onstar	●	●	●	●	●	●	T155 T191
2002	GMC truck	GMC C cab/chassis HD (GMT 400)	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	GMC truck	GMC C cab/chassis HD (GMT 400)	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	GMC truck	GMC C cab/chassis HD (GMT 400)	VSES (if equipped)	●	●	○	●	●	●	T156
2002	GMC truck	GMC c-series - 2WD	Powertrain	●	●	●	●	●	●	T146
2002	GMC truck	GMC c-series - 2WD	Body control module	●	●	●	●	●	●	T031
2002	GMC truck	GMC c-series - 2WD	Memory mirror module	●	●	○	●	●	○	
2002	GMC truck	GMC c-series - 2WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	GMC truck	GMC c-series - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2002	GMC truck	GMC c-series - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	GMC truck	GMC c-series - 2WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	GMC truck	GMC c-series - 2WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	GMC truck	GMC c-series - 2WD (CNG)	Powertrain	●	●	●	●	●	●	T001
2002	GMC truck	GMC c-series - 2WD (CNG)	Body control module	●	●	●	●	●	●	T031
2002	GMC truck	GMC c-series - 2WD (CNG)	Memory mirror module	●	●	○	●	●	○	

2002	GMC truck	GMC c-series - 2WD (CNG)	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	GMC truck	GMC c-series - 2WD (CNG)	Onstar	●	●	●	●	●	●	T155 T191
2002	GMC truck	GMC c-series - 2WD (CNG)	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	GMC truck	GMC c-series - 2WD (CNG)	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	GMC truck	GMC c-series - 2WD (CNG)	VSES (if equipped)	●	●	○	●	●	●	T156
2002	GMC truck	GMC K sierra - 4WD	Powertrain	●	●	●	●	●	●	T146
2002	GMC truck	GMC K sierra - 4WD	Body control module	●	●	●	●	●	●	T031
2002	GMC truck	GMC K sierra - 4WD	Memory mirror module	●	●	○	●	●	○	
2002	GMC truck	GMC K sierra - 4WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	GMC truck	GMC K sierra - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2002	GMC truck	GMC K sierra - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	GMC truck	GMC K sierra - 4WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	GMC truck	GMC K sierra - 4WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	GMC truck	GMC K sierra - 4WD (CNG)	Powertrain	●	●	●	●	●	○	
2002	GMC truck	GMC K sierra - 4WD (CNG)	Body control module	●	●	●	●	●	●	T031
2002	GMC truck	GMC K sierra - 4WD (CNG)	Memory mirror module	●	●	○	●	●	○	
2002	GMC truck	GMC K sierra - 4WD (CNG)	Supplemental inflatable restraint	●	●	○	●	○	●	T039

2002	GMC truck	GMC K sierra - 4WD (CNG)	Onstar	●	●	●	●	●	●	T155 T191
2002	GMC truck	GMC K sierra - 4WD (CNG)	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	GMC truck	GMC K sierra - 4WD (CNG)	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	GMC truck	GMC K sierra - 4WD (CNG)	VSES (if equipped)	●	●	○	●	●	●	T156
2002	GMC truck	Jimmy - 2WD	Powertrain	●	●	●	●	●	●	T146
2002	GMC truck	Jimmy - 2WD	Body control module	●	●	○	●	●	●	T032
2002	GMC truck	Jimmy - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2002	GMC truck	Jimmy - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	GMC truck	Jimmy - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2002	GMC truck	Jimmy - 4WD	Powertrain	●	●	●	●	●	●	T146
2002	GMC truck	Jimmy - 4WD	Body control module	●	●	○	●	●	●	T032
2002	GMC truck	Jimmy - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2002	GMC truck	Jimmy - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	GMC truck	Jimmy - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2002	GMC truck	Safari - 2WD	Powertrain	●	●	●	●	●	●	T146
2002	GMC truck	Safari - 2WD	Body control module	●	●	○	●	●	○	
2002	GMC truck	Safari - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2002	GMC truck	Safari - 2WD	Instrument panel cluster	●	●	○	○	●	●	T039
2002	GMC truck	Safari - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	GMC truck	Safari - 4WD	Powertrain	●	●	●	●	●	●	T146
2002	GMC truck	Safari - 4WD	Body control module	●	●	○	●	●	○	
2002	GMC truck	Safari - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2002	GMC truck	Safari - 4WD	Instrument panel cluster	●	●	○	○	●	●	T039

2002	GMC truck	Safari - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	GMC truck	Savana (CNG)	Powertrain	●	●	●	●	●	○	
2002	GMC truck	Savana (CNG)	Immobilizer	●	●	○	●	●	●	T214 T215 T216 T217 T218 T032
2002	GMC truck	Savana (CNG)	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	GMC truck	Savana - 2WD	Powertrain	●	●	●	●	●	●	T146
2002	GMC truck	Savana - 2WD	Immobilizer	●	●	○	●	●	●	T214 T215 T216 T217 T218 T032
2002	GMC truck	Savana - 2WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	GMC truck	Sonoma pickup - 2WD	Powertrain	●	●	●	●	●	●	T146
2002	GMC truck	Sonoma pickup - 2WD	Body control module	●	●	○	●	●	●	T032
2002	GMC truck	Sonoma pickup - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2002	GMC truck	Sonoma pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	GMC truck	Sonoma pickup - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2002	GMC truck	Sonoma pickup - 4WD	Powertrain	●	●	●	●	●	●	T146
2002	GMC truck	Sonoma pickup - 4WD	Body control module	●	●	○	●	●	●	T032
2002	GMC truck	Sonoma pickup - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2002	GMC truck	Sonoma pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	GMC truck	Sonoma pickup - 4WD	Traction assist (if equipped)	●	●	○	●	●	○	
2002	GMC truck	Yukon - 2WD	Powertrain	●	●	●	●	●	○	
2002	GMC truck	Yukon - 2WD	Body control module	●	●	●	●	●	●	T031
2002	GMC truck	Yukon - 2WD	Memory mirror module	●	●	○	●	●	○	

2002	GMC truck	Yukon - 2WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	GMC truck	Yukon - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2002	GMC truck	Yukon - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	GMC truck	Yukon - 2WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	GMC truck	Yukon - 2WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	GMC truck	Yukon - 4WD	Powertrain	●	●	●	●	●	○	
2002	GMC truck	Yukon - 4WD	Body control module	●	●	●	●	●	●	T031
2002	GMC truck	Yukon - 4WD	Memory mirror module	●	●	○	●	●	○	
2002	GMC truck	Yukon - 4WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	GMC truck	Yukon - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2002	GMC truck	Yukon - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	GMC truck	Yukon - 4WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	GMC truck	Yukon - 4WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	GMC truck	Yukon denali	Powertrain	●	●	●	●	●	○	
2002	GMC truck	Yukon denali	Body control module	●	●	●	●	●	●	T031
2002	GMC truck	Yukon denali	Memory mirror module	●	●	○	●	●	○	
2002	GMC truck	Yukon denali	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	GMC truck	Yukon denali	Onstar	●	●	●	●	●	●	T155 T191
2002	GMC truck	Yukon denali	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	GMC truck	Yukon denali	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	GMC truck	Yukon denali	VSES (if equipped)	●	●	○	●	●	●	T156
2002	GMC truck	Yukon XL - 2WD	Powertrain	●	●	●	●	●	●	T079
2002	GMC truck	Yukon XL - 2WD	Body control module	●	●	●	●	●	●	T031
2002	GMC truck	Yukon XL - 2WD	Memory mirror module	●	●	○	●	●	○	
2002	GMC truck	Yukon XL - 2WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	GMC truck	Yukon XL - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2002	GMC truck	Yukon XL - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	GMC truck	Yukon XL - 2WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	GMC truck	Yukon XL - 2WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	GMC truck	Yukon XL - 4WD	Powertrain	●	●	●	●	●	●	T079
2002	GMC truck	Yukon XL - 4WD	Body control module	●	●	●	●	●	●	T031

2002	GMC truck	Yukon XL - 4WD	Memory mirror module	●	●	○	●	●	○	
2002	GMC truck	Yukon XL - 4WD	Supplemental inflatable restraint	●	●	○	●	○	●	T039
2002	GMC truck	Yukon XL - 4WD	Onstar	●	●	●	●	●	●	T155 T191
2002	GMC truck	Yukon XL - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2002	GMC truck	Yukon XL - 4WD	4WAL 3 sensor	●	●	○	●	●	●	T156
2002	GMC truck	Yukon XL - 4WD	VSES (if equipped)	●	●	○	●	●	●	T156
2002	Oldsmobile	Bravada	Powertrain	●	●	●	●	●	○	
2002	Oldsmobile	Bravada	Amplifier (bose)	●	●	●	●	●	●	T058
2002	Oldsmobile	Bravada	Rear seat audio	○	○	○	●	○	○	
2002	Oldsmobile	Bravada	Heating and air conditioning	○	○	○	●	●	○	
2002	Oldsmobile	Bravada	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2002	Oldsmobile	Bravada	Onstar	●	●	●	●	●	●	T155 T191
2002	Oldsmobile	Bravada	Radio	●	●	●	●	●	●	T058
2002	Oldsmobile	Bravada	4WAL 3 sensor	●	●	○	●	●	○	
2002	Oldsmobile	Bravada	Traction assist (if equipped)	●	●	○	●	●	○	
2002	Oldsmobile	Bravada - 2WD	Powertrain	●	●	●	●	●	○	
2002	Oldsmobile	Bravada - 2WD	Amplifier (bose)	●	●	●	●	●	●	T058
2002	Oldsmobile	Bravada - 2WD	Rear seat audio	○	○	○	●	○	○	
2002	Oldsmobile	Bravada - 2WD	Heating and air conditioning	○	○	○	●	●	○	
2002	Oldsmobile	Bravada - 2WD	Supplemental inflatable restraint	●	●	○	○	○	●	T039
2002	Oldsmobile	Bravada - 2WD	Onstar	●	●	●	●	●	●	T155 T191
2002	Oldsmobile	Bravada - 2WD	Radio	●	●	●	●	●	●	T058
2002	Oldsmobile	Bravada - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2002	Oldsmobile	Bravada - 2WD	Traction assist (if equipped)	●	●	○	●	●	○	
2002	Oldsmobile	Silhouette	Powertrain	●	●	●	●	●	●	T001
2002	Oldsmobile	Silhouette	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032
2002	Oldsmobile	Silhouette	Memory seat module	●	●	○	●	●	○	

2002	Oldsmobile	Silhouette	Radio	○	○	○	●	○	○	
2002	Oldsmobile	Silhouette	Onstar	●	●	●	●	○	●	T155 T191
2002	Oldsmobile	Silhouette	Supplemental inflatable restraint	●	●	●	●	●	●	T190 T136 T081 T082 T080 T032
2002	Oldsmobile	Silhouette	Chassis	●	●	●	●	●	●	T014
2002	Pontiac	Aztek - AWD	Powertrain	●	●	●	●	●	●	T001
2002	Pontiac	Aztek - AWD	Body control module	●	●	○	●	●	●	T145
2002	Pontiac	Aztek - AWD	Onstar	●	●	●	●	○	●	T155 T191
2002	Pontiac	Aztek - AWD	Supplemental inflatable restraint	●	●	○	○	○	○	
2002	Pontiac	Aztek - AWD	Vehicle theft deterrent	●	●	●	●	●	●	T145
2002	Pontiac	Aztek - AWD	Chassis	●	●	○	●	●	●	T014
2002	Pontiac	Aztek - FWD	Powertrain	●	●	●	●	●	●	T001
2002	Pontiac	Aztek - FWD	Body control module	●	●	○	●	●	●	T145
2002	Pontiac	Aztek - FWD	Onstar	●	●	●	●	○	●	T155 T191
2002	Pontiac	Aztek - FWD	Supplemental inflatable restraint	●	●	○	○	○	○	
2002	Pontiac	Aztek - FWD	Vehicle theft deterrent	●	●	●	●	●	●	T145
2002	Pontiac	Aztek - FWD	Chassis	●	●	○	●	●	●	T014
2002	Pontiac	Montana	Powertrain	●	●	●	●	●	●	T001
2002	Pontiac	Montana	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032
2002	Pontiac	Montana	Radio	○	○	○	●	○	○	
2002	Pontiac	Montana	Onstar	●	●	●	●	○	●	T155 T191
2002	Pontiac	Montana	Supplemental inflatable restraint	●	●	●	●	●	●	T190 T136 T081 T082 T080 T032
2002	Pontiac	Montana	Chassis	●	●	●	●	●	●	T014
2001	Buick	Century	Powertrain	●	●	●	●	●	●	T001
2001	Buick	Century	Body control module	●	●	○	●	●	●	T122 T170 T198
2001	Buick	Century	Onstar	●	●	●	●	○	●	T191
2001	Buick	Century	Supplemental inflatable restraint	●	●	○	●	○	●	T023
2001	Buick	Century	Chassis	●	●	●	●	●	●	T014

2001	Buick	Lesabre	Powertrain	●	●	●	●	●	●	T001
2001	Buick	Lesabre	Dash integration module	○	○	○	●	●	●	T158 T082 T084
2001	Buick	Lesabre	CD changer	●	●	○	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112 T136 T112
2001	Buick	Lesabre	Instrument panel module	●	●	○	●	●	●	T138 T175
2001	Buick	Lesabre	Radio	○	○	○	○	○	●	T033
2001	Buick	Lesabre	Onstar	●	●	●	●	○	●	T191
2001	Buick	Lesabre	Vehicle theft deterrent	●	●	○	○	○	○	
2001	Buick	Lesabre	Supplemental inflatable restraint	●	●	○	○	○	○	
2001	Buick	Lesabre	Remote function actuation	●	●	○	●	●	●	T158 T082 T084
2001	Buick	Lesabre	Climate control panel	●	●	●	●	●	●	T033
2001	Buick	Lesabre	Rear integration module	●	●	○	●	●	○	
2001	Buick	Lesabre	DRP/ABS/TIM	●	●	○	●	●	●	T014
2001	Buick	Park avenue	Powertrain	●	●	●	●	●	●	T001
2001	Buick	Park avenue	Body control module	●	●	○	●	●	●	T122 T176 T192 T138
2001	Buick	Park avenue	Onstar	●	●	●	●	○	●	T191
2001	Buick	Park avenue	Vehicle theft deterrent	●	●	○	○	○	○	
2001	Buick	Park avenue	Personalization	●	●	○	●	●	●	T058 T058
2001	Buick	Park avenue	DRP/ABS/TIM	●	●	○	●	●	●	T014
2001	Buick	Regal	Powertrain	●	●	●	●	●	●	T001
2001	Buick	Regal	Body control module	●	●	○	●	●	●	T122 T170 T198
2001	Buick	Regal	Onstar	●	●	●	●	○	●	T191
2001	Buick	Regal	Supplemental inflatable restraint	●	●	○	●	○	●	T023
2001	Buick	Regal	Chassis	●	●	●	●	●	●	T014
2001	Cadillac	Catera	Powertrain	●	●	●	●	●	○	
2001	Cadillac	Catera	Body control module	●	●	○	●	●	●	T219 T136

2001	Cadillac	Catera	Radio	●	●	○	●	●	●	T179 T086 T087 T033
2001	Cadillac	Catera	Cellular telephone	○	○	○	○	○	●	T192
2001	Cadillac	Catera	Onstar	●	●	●	●	○	●	T191
2001	Cadillac	Catera	ABS	●	●	○	●	●	○	
2001	Cadillac	Deville	Powertrain	●	●	●	●	●	○	
2001	Cadillac	Deville	Dash integration module	●	●	○	●	●	●	T122 T172 T123 T127 T204 T220 T094 T138 T175
2001	Cadillac	Deville	Cellular telephone	●	●	○	●	●	●	T136 T159 T158 T181 T122 T180
2001	Cadillac	Deville	Instrument panel cluster	○	○	○	●	○	○	
2001	Cadillac	Deville	Amplifier (delco)	●	●	○	●	●	○	
2001	Cadillac	Deville	Memory seat module	●	●	○	●	●	○	
2001	Cadillac	Deville	Onstar	●	●	●	●	○	●	T191
2001	Cadillac	Deville	Vehicle theft deterrent	●	●	○	○	○	○	
2001	Cadillac	Deville	Remote function actuation	●	●	○	○	●	●	T193
2001	Cadillac	Deville	Left rear door module	●	●	●	●	●	○	
2001	Cadillac	Deville	Right rear door module	●	●	●	●	●	○	
2001	Cadillac	Deville	Driver door switch	●	●	●	●	○	○	
2001	Cadillac	Deville	Driver door module	●	●	●	●	●	○	
2001	Cadillac	Deville	Passenger door module	●	●	●	●	○	●	T112 T113
2001	Cadillac	Deville	Tire pressure monitor	●	●	○	●	○	○	
2001	Cadillac	Deville	DRP/ABS/TCS/VSES/BLW	●	●	○	●	●	○	
2001	Cadillac	Deville	Speed sensitive steering	●	●	○	●	○	○	
2001	Cadillac	Deville	CVRSS/ALC	●	●	○	●	●	○	
2001	Cadillac	DHS	Powertrain	●	●	●	●	●	○	
2001	Cadillac	DHS	Dash integration module	●	●	○	●	●	●	T122 T172 T123 T127 T204 T220 T094 T138 T175
2001	Cadillac	DHS	Amplifier (bose)	●	●	○	●	●	●	T221

2001	Cadillac	DHS	Cellular telephone	●	●	○	●	●	●	T136 T159 T158 T181 T122 T180
2001	Cadillac	DHS	Instrument panel cluster	●	●	○	●	●	●	T116 T086 T087 T166
2001	Cadillac	DHS	Memory seat module	●	●	○	●	●	○	
2001	Cadillac	DHS	Onstar	●	●	●	●	○	●	T191
2001	Cadillac	DHS	Vehicle theft deterrent	●	●	○	○	○	○	
2001	Cadillac	DHS	Remote function actuation	●	●	○	○	●	●	T193
2001	Cadillac	DHS	Left rear door module	●	●	●	●	●	○	
2001	Cadillac	DHS	Right rear door module	●	●	●	●	●	○	
2001	Cadillac	DHS	Driver door switch	●	●	●	●	○	○	
2001	Cadillac	DHS	Driver door module	●	●	●	●	●	○	
2001	Cadillac	DHS	Passenger door module	●	●	●	●	○	●	T112 T113
2001	Cadillac	DHS	Tire pressure monitor	●	●	○	●	○	○	
2001	Cadillac	DHS	DRP/ABS/TCS/VSES/BLW	●	●	○	●	●	○	
2001	Cadillac	DHS	Speed sensitive steering	●	●	○	●	○	○	
2001	Cadillac	DHS	CVRSS/ALC	●	●	○	●	●	○	
2001	Cadillac	DTS	Powertrain	●	●	●	●	●	○	
2001	Cadillac	DTS	Dash integration module	●	●	○	●	●	●	T122 T172 T123 T127 T204 T220 T094 T138 T175
2001	Cadillac	DTS	Amplifier (bose)	●	●	○	●	●	●	T221
2001	Cadillac	DTS	Cellular telephone	●	●	○	●	●	●	T136 T159 T158 T181 T122 T180
2001	Cadillac	DTS	Instrument panel cluster	●	●	○	●	●	●	T116 T086 T087 T166
2001	Cadillac	DTS	Memory seat module	●	●	○	●	●	●	T182
2001	Cadillac	DTS	Onstar	●	●	●	●	○	●	T191
2001	Cadillac	DTS	Vehicle theft deterrent	●	●	○	○	○	○	
2001	Cadillac	DTS	Remote function actuation	●	●	○	○	●	●	T193

2001	Cadillac	DTS	Left rear door module	●	●	●	●	●	○	
2001	Cadillac	DTS	Right rear door module	●	●	●	●	●	○	
2001	Cadillac	DTS	Driver door switch	●	●	●	●	○	○	
2001	Cadillac	DTS	Driver door module	●	●	●	●	●	○	
2001	Cadillac	DTS	Passenger door module	●	●	●	●	○	●	T112 T113
2001	Cadillac	DTS	Tire pressure monitor	●	●	○	●	○	○	
2001	Cadillac	DTS	DRP/ABS/TCS/VSES/BLW	●	●	○	●	●	○	
2001	Cadillac	DTS	Speed sensitive steering	●	●	○	●	○	○	
2001	Cadillac	DTS	CVRSS/ALC	●	●	○	●	●	○	
2001	Cadillac	Eldorado	Powertrain	●	●	●	●	●	○	
2001	Cadillac	Eldorado	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190
2001	Cadillac	Eldorado	Radio	●	●	○	●	●	●	T210 T033
2001	Cadillac	Eldorado	Onstar	●	●	●	●	○	●	T191
2001	Cadillac	Eldorado	Remote function actuation	●	●	○	○	●	○	
2001	Cadillac	Eldorado	Supplemental inflatable restraint	●	●	○	○	○	○	
2001	Cadillac	Eldorado	Delco/Xtool ABS/TCS	●	●	○	○	●	●	T149 T014
2001	Cadillac	Eldorado	Magna steer	●	●	○	○	○	○	
2001	Cadillac	Seville	Powertrain	●	●	●	●	●	○	
2001	Cadillac	Seville	Amplifier (bose)	●	●	○	●	●	●	T122 T172 T123 T125 T194 T195 T193 T220 T094
2001	Cadillac	Seville	Cellular telephone	●	●	○	●	●	●	T136 T159 T158 T181 T122 T180
2001	Cadillac	Seville	Instrument panel cluster	●	●	○	●	●	●	T116 T086 T087 T166
2001	Cadillac	Seville	Amplifier (delco)	●	●	○	●	●	○	
2001	Cadillac	Seville	Memory seat module	●	●	○	●	●	●	T182
2001	Cadillac	Seville	Onstar	●	●	●	●	○	●	T191
2001	Cadillac	Seville	Vehicle theft deterrent	●	●	○	○	○	○	

2001	Cadillac	Seville	Remote function actuation	●	●	○	○	●	○	
2001	Cadillac	Seville	Dash integration module	●	●	●	●	●	●	T112 T113
2001	Cadillac	Seville	Tire pressure monitor	●	●	○	●	○	○	
2001	Cadillac	Seville	DRP/ABS/TCS/VSES/BLW	●	●	○	●	●	○	
2001	Cadillac	Seville	Speed sensitive steering	●	●	○	●	○	○	
2001	Cadillac	Seville	CVRSS/ALC	●	●	○	●	●	○	
2001	Chevrolet	Alero (export)	Powertrain	●	●	●	●	●	●	T001
2001	Chevrolet	Alero (export)	Body control module	●	●	●	○	●	●	T141 T033
2001	Chevrolet	Alero (export)	Radio	●	●	●	●	●	●	T183
2001	Chevrolet	Alero (export)	Vehicle theft deterrent	●	●	○	●	○	○	
2001	Chevrolet	Alero (export)	Chassis	●	●	●	●	●	●	T014
2001	Chevrolet	Camaro	Powertrain	●	●	●	●	●	●	T001
2001	Chevrolet	Camaro	Instrument panel cluster	●	●	○	●	●	●	T190
2001	Chevrolet	Camaro	Supplemental inflatable restraint	●	●	○	●	●	●	T190
2001	Chevrolet	Camaro	Chassis	●	●	○	●	●	●	T014
2001	Chevrolet	Cavalier	Powertrain	●	●	●	●	●	○	
2001	Chevrolet	Cavalier	Radio	○	○	○	●	○	○	
2001	Chevrolet	Cavalier	Body control module	●	●	●	●	●	●	T141 T033 T183
2001	Chevrolet	Cavalier	Chassis	●	●	●	●	●	●	T014
2001	Chevrolet	Cavalier (CNG)	Powertrain	●	●	●	●	●	○	
2001	Chevrolet	Cavalier (CNG)	Radio	○	○	○	●	○	○	
2001	Chevrolet	Cavalier (CNG)	Body control module	●	●	●	●	●	●	T141 T033 T183
2001	Chevrolet	Cavalier (CNG)	Chassis	●	●	●	●	●	●	T014
2001	Chevrolet	Corvette	Powertrain	●	●	●	●	●	○	
2001	Chevrolet	Corvette	Body control module	●	●	○	●	●	○	
2001	Chevrolet	Corvette	Supplemental inflatable restraint	●	●	○	●	○	●	T196
2001	Chevrolet	Corvette	Remote function actuation	●	●	○	●	●	●	T181

2001	Chevrolet	Corvette	ABS/TCS	●	●	●	●	●	○	
2001	Chevrolet	Corvette	RTD	●	●	●	●	●	○	
2001	Chevrolet	Impala	Powertrain	●	●	●	●	●	●	T001
2001	Chevrolet	Impala	Radio	○	○	○	●	○	○	
2001	Chevrolet	Impala	Body control module	●	●	○	●	●	●	T023 T136 T122 T088 T080 T081 T082 T211
2001	Chevrolet	Impala	Onstar	●	●	●	●	○	●	T191
2001	Chevrolet	Impala	Supplemental inflatable restraint	●	●	●	●	●	●	T023 T136 T122 T088 T080 T081 T082 T211
2001	Chevrolet	Impala	Chassis	●	●	●	○	●	●	T014
2001	Chevrolet	Lumina	Powertrain	●	●	●	●	●	●	T001
2001	Chevrolet	Malibu	Powertrain	●	●	●	●	●	●	T001
2001	Chevrolet	Malibu	Body control module	●	●	●	○	●	●	T141 T033
2001	Chevrolet	Malibu	Radio	○	○	●	●	●	○	
2001	Chevrolet	Malibu	Remote function actuation	●	●	○	●	●	○	
2001	Chevrolet	Malibu	Chassis	●	●	●	●	●	●	T014
2001	Chevrolet	Monte carlo	Powertrain	●	●	●	●	●	●	T001
2001	Chevrolet	Monte carlo	Radio	○	○	○	●	○	○	
2001	Chevrolet	Monte carlo	Body control module	●	●	○	●	●	●	T023 T136 T122 T088 T080 T081 T082 T211
2001	Chevrolet	Monte carlo	Onstar	●	●	●	●	○	●	T191
2001	Chevrolet	Monte carlo	Supplemental inflatable restraint	●	●	●	●	●	●	T023 T136 T122 T088 T080 T081 T082 T211
2001	Chevrolet	Monte carlo	Chassis	●	●	●	○	●	●	T014
2001	Chevrolet	Prizm	Supplemental inflatable restraint	●	●	○	○	○	○	
2001	Oldsmobile	Alero	Powertrain	●	●	●	●	●	●	T001
2001	Oldsmobile	Alero	Body control module	●	●	●	○	●	●	T141 T033
2001	Oldsmobile	Alero	Radio	●	●	●	●	●	●	T183
2001	Oldsmobile	Alero	Instrument panel cluster	○	○	○	●	○	○	
2001	Oldsmobile	Alero	Remote function actuation	●	●	○	●	●	○	
2001	Oldsmobile	Alero	Chassis	●	●	●	●	●	●	T014

2001	Oldsmobile	Aurora	Powertrain	●	●	●	●	●	○	
2001	Oldsmobile	Aurora	CD changer	●	●	○	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112 T136 T138 T175 T081 T082 T083 T084 T085 T202 T203 T086 T087 T144 T080 T060 T201 T112
2001	Oldsmobile	Aurora	Memory seat module	●	●	○	●	●	○	
2001	Oldsmobile	Aurora	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Oldsmobile	Aurora	Remote function actuation	●	●	○	●	●	○	
2001	Oldsmobile	Aurora	Onstar	●	●	●	●	○	●	T191
2001	Oldsmobile	Aurora	Vehicle theft deterrent	●	●	○	○	○	●	T185
2001	Oldsmobile	Aurora	Rear integration module	●	●	○	●	●	○	
2001	Oldsmobile	Aurora	DRP/ABS/TIM	●	●	○	●	●	●	T014
2001	Oldsmobile	Intrigue	Powertrain	●	●	●	●	●	○	
2001	Oldsmobile	Intrigue	Body control module	●	●	○	●	●	●	T170 T198
2001	Oldsmobile	Intrigue	Onstar	●	●	●	●	○	●	T191
2001	Oldsmobile	Intrigue	Supplemental inflatable restraint	●	●	○	●	○	●	T023
2001	Oldsmobile	Intrigue	Chassis	●	●	○	●	●	●	T212
2001	Pontiac	Bonneville	Powertrain	●	●	●	●	●	●	T001
2001	Pontiac	Bonneville	Dash integration module	○	○	○	●	●	●	T222 T081 T082 T083 T084 T085 T202 T203 T086 T087 T144 T080 T060
2001	Pontiac	Bonneville	Instrument panel cluster	○	○	○	●	○	○	
2001	Pontiac	Bonneville	CD changer	●	●	○	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112 T136 T112

2001	Pontiac	Bonneville	Instrument panel module	●	●	○	●	●	●	T138 T175
2001	Pontiac	Bonneville	Onstar	●	●	●	●	○	●	T191
2001	Pontiac	Bonneville	Supplemental inflatable restraint	●	●	○	○	○	○	
2001	Pontiac	Bonneville	Vehicle theft deterrent	●	●	○	●	●	●	T185
2001	Pontiac	Bonneville	Climate control panel	●	●	●	●	●	●	T191
2001	Pontiac	Bonneville	Remote function actuation	●	●	○	●	●	●	T222 T081 T082 T083 T084 T085 T202 T203 T086 T087 T144 T080 T060
2001	Pontiac	Bonneville	Rear integration module	●	●	●	●	●	●	T186
2001	Pontiac	Bonneville	DRP/ABS/TIM	●	●	○	●	●	●	T014
2001	Pontiac	Firebird	Powertrain	●	●	●	●	●	●	T001
2001	Pontiac	Firebird	Instrument panel cluster	●	●	○	●	●	●	T190
2001	Pontiac	Firebird	Supplemental inflatable restraint	●	●	○	●	●	●	T190
2001	Pontiac	Firebird	Chassis	●	●	○	●	●	●	T014
2001	Pontiac	Grand am	Powertrain	●	●	●	●	●	●	T001
2001	Pontiac	Grand am	Body control module	●	●	●	○	●	●	T141 T033
2001	Pontiac	Grand am	Radio	●	●	●	●	●	●	T183
2001	Pontiac	Grand am	Instrument panel cluster	○	○	○	●	○	○	
2001	Pontiac	Grand am	Remote function actuation	●	●	○	●	●	○	
2001	Pontiac	Grand am	Chassis	●	●	●	●	●	●	T014
2001	Pontiac	Grand prix	Powertrain	●	●	●	●	●	●	T001
2001	Pontiac	Grand prix	Vehicle theft deterrent	●	●	○	●	○	○	
2001	Pontiac	Grand prix	Onstar	●	●	●	●	○	●	T191
2001	Pontiac	Grand prix	Supplemental inflatable restraint	●	●	○	●	○	○	

2001	Pontiac	Sunfire	Powertrain	●	●	●	●	●	○	
2001	Pontiac	Sunfire	Radio	○	○	○	●	○	○	
2001	Pontiac	Sunfire	Body control module	●	●	●	●	●	●	T141 T033 T183
2001	Pontiac	Sunfire	Chassis	●	●	●	●	●	●	T014
2001	Cadillac	Incomplete	Powertrain	●	●	●	●	●	●	T001
2001	Cadillac	Incomplete	Amplifier (delco)	●	●	○	●	●	●	T172 T126 T127 T136 T158 T094 T138 T175 T179 T086 T087 T033
2001	Cadillac	Incomplete	Rear integration module	○	○	○	●	○	○	
2001	Cadillac	Incomplete	Remote function actuation	●	●	○	○	●	○	
2001	Cadillac	Incomplete	Dash integration module	●	●	○	○	○	●	T112 T113
2001	Cadillac	Incomplete	Vehicle theft deterrent	●	●	○	○	○	●	T199
2001	Cadillac	Incomplete	Driver door module	●	●	●	●	●	○	
2001	Cadillac	Incomplete	Driver door switch	●	●	●	●	○	○	
2001	Cadillac	Incomplete	Passenger door module	●	●	●	●	●	●	T172 T126 T127 T136 T158 T094 T138 T175 T179 T086 T087 T033
2001	Cadillac	Incomplete	Rear climate control panel	●	●	○	●	●	○	
2001	Cadillac	Incomplete	Onstar	●	●	●	●	●	●	T191
2001	Cadillac	Incomplete	Left mid door module	●	●	●	●	●	○	
2001	Cadillac	Incomplete	Left rear door module	●	●	●	●	●	○	
2001	Cadillac	Incomplete	Right mid door module	●	●	●	●	●	○	
2001	Cadillac	Incomplete	Right rear door module	●	●	●	●	●	○	
2001	Cadillac	Incomplete	DRP/ABS/TCS	●	●	○	●	●	○	
2001	Chevrolet	Astro - 2WD	Powertrain	●	●	●	●	●	●	T146
2001	Chevrolet	Astro - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Astro - 2WD	Body control module	●	●	○	●	●	○	
2001	Chevrolet	Astro - 2WD	Instrument panel cluster	○	○	○	○	●	○	

2001	Chevrolet	Astro - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	Chevrolet	Astro - 4WD	Powertrain	●	●	●	●	●	●	T146
2001	Chevrolet	Astro - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Astro - 4WD	Body control module	●	●	○	●	●	○	
2001	Chevrolet	Astro - 4WD	Instrument panel cluster	○	○	○	○	●	○	
2001	Chevrolet	Astro - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	Chevrolet	Blazer - 2WD	Powertrain	●	●	●	●	●	●	T146
2001	Chevrolet	Blazer - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Blazer - 2WD	Body control module	●	●	○	●	●	○	
2001	Chevrolet	Blazer - 2WD	Onstar	●	●	●	●	●	●	T191
2001	Chevrolet	Blazer - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	Chevrolet	Blazer - 4WD	Powertrain	●	●	●	●	●	●	T146
2001	Chevrolet	Blazer - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Blazer - 4WD	Body control module	●	●	○	●	●	○	
2001	Chevrolet	Blazer - 4WD	Onstar	●	●	●	●	●	●	T191
2001	Chevrolet	Blazer - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	Chevrolet	Blazer - 4WD - RHD	Powertrain	●	●	●	●	●	●	T146
2001	Chevrolet	Blazer - 4WD - RHD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Blazer - 4WD - RHD	Body control module	●	●	○	●	●	○	
2001	Chevrolet	Blazer - 4WD - RHD	Onstar	●	●	●	●	●	●	T191
2001	Chevrolet	Blazer - 4WD - RHD	4WAL 3 sensor	●	●	○	●	●	○	
2001	Chevrolet	C cab/chassis HD (GMT 400)	Powertrain	●	●	●	●	●	●	T079
2001	Chevrolet	C cab/chassis HD (GMT 400)	Supplemental inflatable restraint	●	●	○	●	○	○	

2001	Chevrolet	C cab/chassis HD (GMT 400)	Passlock	●	●	○	●	●	○	
2001	Chevrolet	C cab/chassis HD (GMT 400)	Onstar	●	●	●	●	●	●	T191
2001	Chevrolet	C cab/chassis HD (GMT 400)	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	Chevrolet	C cab/chassis HD (GMT 400)	4WAL 3 sensor	●	●	○	●	●	○	
2001	Chevrolet	C silverado - 2WD	Powertrain	●	●	●	●	●	●	T146
2001	Chevrolet	C silverado - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	C silverado - 2WD	Passlock	●	●	○	●	●	○	
2001	Chevrolet	C silverado - 2WD	Onstar	●	●	●	●	○	●	T191
2001	Chevrolet	C silverado - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	Chevrolet	C silverado - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	Chevrolet	Express (CNG)	Powertrain	●	●	●	●	●	○	
2001	Chevrolet	Express (CNG)	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Express (CNG)	Immobilizer	●	●	○	●	●	●	T214 T215 T216 T217 T218 T032
2001	Chevrolet	Express - 2WD	Powertrain	●	●	●	●	●	●	T146
2001	Chevrolet	Express - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Express - 2WD	Immobilizer	●	●	○	●	●	●	T214 T215 T216 T217 T218 T032
2001	Chevrolet	K silverado - 4WD	Powertrain	●	●	●	●	●	●	T146
2001	Chevrolet	K silverado - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	

2001	Chevrolet	K silverado - 4WD	Passlock	●	●	○	●	●	○	
2001	Chevrolet	K silverado - 4WD	Onstar	●	●	●	●	○	●	T191
2001	Chevrolet	K silverado - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	Chevrolet	K silverado - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	Chevrolet	S10 pickup - 2WD	Powertrain	●	●	●	●	●	●	T146
2001	Chevrolet	S10 pickup - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	S10 pickup - 2WD	Body control module	●	●	○	●	●	○	
2001	Chevrolet	S10 pickup - 2WD	Onstar	●	●	●	●	●	●	T191
2001	Chevrolet	S10 pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	Chevrolet	S10 pickup - 4WD	Powertrain	●	●	●	●	●	●	T146
2001	Chevrolet	S10 pickup - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	S10 pickup - 4WD	Body control module	●	●	○	●	●	○	
2001	Chevrolet	S10 pickup - 4WD	Onstar	●	●	●	●	●	●	T191
2001	Chevrolet	S10 pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	Chevrolet	Suburban - 2WD	Powertrain	●	●	●	●	●	●	T079
2001	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Suburban - 2WD	Passlock	●	●	○	●	●	○	
2001	Chevrolet	Suburban - 2WD	Onstar	●	●	●	●	●	●	T191
2001	Chevrolet	Suburban - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	Chevrolet	Suburban - 2WD	4WAL 3 sensor	●	●	○	●	●	○	

2001	Chevrolet	Suburban - 4WD	Powertrain	●	●	●	●	●	●	T079
2001	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Suburban - 4WD	Passlock	●	●	○	●	●	○	
2001	Chevrolet	Suburban - 4WD	Onstar	●	●	●	●	●	●	T191
2001	Chevrolet	Suburban - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	Chevrolet	Suburban - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	Chevrolet	Tahoe - 2WD	Powertrain	●	●	●	●	●	○	
2001	Chevrolet	Tahoe - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Tahoe - 2WD	Passlock	●	●	○	●	●	○	
2001	Chevrolet	Tahoe - 2WD	Onstar	●	●	●	●	●	●	T191
2001	Chevrolet	Tahoe - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	Chevrolet	Tahoe - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	Chevrolet	Tahoe - 4WD	Powertrain	●	●	●	●	●	○	
2001	Chevrolet	Tahoe - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Tahoe - 4WD	Passlock	●	●	○	●	●	○	
2001	Chevrolet	Tahoe - 4WD	Onstar	●	●	●	●	●	●	T191
2001	Chevrolet	Tahoe - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	Chevrolet	Tahoe - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	Chevrolet	Tracker - 2WD	Powertrain	●	●	●	●	●	○	
2001	Chevrolet	Tracker - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Tracker - 2WD	Chassis	●	●	●	●	●	●	T014
2001	Chevrolet	Tracker - 4WD	Powertrain	●	●	●	●	●	○	
2001	Chevrolet	Tracker - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Tracker - 4WD	Chassis	●	●	●	●	●	●	T014
2001	Chevrolet	Venture	Powertrain	●	●	●	●	●	●	T001
2001	Chevrolet	Venture	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032
2001	Chevrolet	Venture	Vehicle theft deterrent	●	●	○	●	○	○	
2001	Chevrolet	Venture	Radio	○	○	○	●	○	○	

2001	Chevrolet	Venture	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Venture	Onstar	●	●	●	●	○	●	T191
2001	Chevrolet	Venture	Chassis	●	●	●	●	●	●	T014
2001	Chevrolet	Venture ext.	Powertrain	●	●	●	●	●	●	T001
2001	Chevrolet	Venture ext.	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032
2001	Chevrolet	Venture ext.	Vehicle theft deterrent	●	●	○	●	○	○	
2001	Chevrolet	Venture ext.	Radio	○	○	○	●	○	○	
2001	Chevrolet	Venture ext.	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Venture ext.	Onstar	●	●	●	●	○	●	T191
2001	Chevrolet	Venture ext.	Chassis	●	●	●	●	●	●	T014
2001	Chevrolet	Others	Radio	○	○	○	●	○	○	
2001	Chevrolet	Others	Onstar	●	●	●	●	○	●	T191
2001	Chevrolet	Others	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Chevrolet	Others	Vehicle theft deterrent	●	●	○	●	○	○	
2001	Chevrolet	Others	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032
2001	Chevrolet	Others	Chassis	●	●	●	●	●	●	T014
2001	GMC truck	Envoy - 4WD	Powertrain	●	●	●	●	●	●	T001
2001	GMC truck	Envoy - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	Envoy - 4WD	Body control module	●	●	○	●	●	○	
2001	GMC truck	Envoy - 4WD	Onstar	●	●	●	●	●	●	T191
2001	GMC truck	Envoy - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	GMC C cab/chassis HD (GMT 400)	Powertrain	●	●	●	●	●	●	T079
2001	GMC truck	GMC C cab/chassis HD (GMT 400)	Supplemental inflatable restraint	●	●	○	●	○	○	

2001	GMC truck	GMC C cab/chassis HD (GMT 400)	Passlock	●	●	○	●	●	○	
2001	GMC truck	GMC C cab/chassis HD (GMT 400)	Onstar	●	●	●	●	●	●	T191
2001	GMC truck	GMC C cab/chassis HD (GMT 400)	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	GMC truck	GMC C cab/chassis HD (GMT 400)	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	GMC c-series - 2WD	Powertrain	●	●	●	●	●	●	T146
2001	GMC truck	GMC c-series - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	GMC c-series - 2WD	Passlock	●	●	○	●	●	○	
2001	GMC truck	GMC c-series - 2WD	Onstar	●	●	●	●	●	●	T191
2001	GMC truck	GMC c-series - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	GMC truck	GMC c-series - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	GMC K sierra - 4WD	Powertrain	●	●	●	●	●	●	T146
2001	GMC truck	GMC K sierra - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	GMC K sierra - 4WD	Passlock	●	●	○	●	●	○	
2001	GMC truck	GMC K sierra - 4WD	Onstar	●	●	●	●	●	●	T191
2001	GMC truck	GMC K sierra - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	

2001	GMC truck	GMC K sierra - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	Jimmy - 2WD	Powertrain	●	●	●	●	●	●	T146
2001	GMC truck	Jimmy - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	Jimmy - 2WD	Body control module	●	●	○	●	●	○	
2001	GMC truck	Jimmy - 2WD	Onstar	●	●	●	●	●	●	T191
2001	GMC truck	Jimmy - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	Jimmy - 4WD	Powertrain	●	●	●	●	●	●	T146
2001	GMC truck	Jimmy - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	Jimmy - 4WD	Body control module	●	●	○	●	●	○	
2001	GMC truck	Jimmy - 4WD	Onstar	●	●	●	●	●	●	T191
2001	GMC truck	Jimmy - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	Safari - 2WD	Powertrain	●	●	●	●	●	●	T146
2001	GMC truck	Safari - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	Safari - 2WD	Body control module	●	●	○	●	●	○	
2001	GMC truck	Safari - 2WD	Instrument panel cluster	○	○	○	○	●	○	
2001	GMC truck	Safari - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	Safari - 4WD	Powertrain	●	●	●	●	●	●	T146
2001	GMC truck	Safari - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	Safari - 4WD	Body control module	●	●	○	●	●	○	
2001	GMC truck	Safari - 4WD	Instrument panel cluster	○	○	○	○	●	○	
2001	GMC truck	Safari - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	Savana - 2WD	Powertrain	●	●	●	●	●	●	T146
2001	GMC truck	Savana - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	Savana - 2WD	Immobilizer	●	●	○	●	●	●	T214 T215 T216 T217 T218 T032
2001	GMC truck	Sonoma pickup - 2WD	Powertrain	●	●	●	●	●	●	T146

2001	GMC truck	Sonoma pickup - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	Sonoma pickup - 2WD	Body control module	●	●	○	●	●	○	
2001	GMC truck	Sonoma pickup - 2WD	Onstar	●	●	●	●	●	●	T191
2001	GMC truck	Sonoma pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	Sonoma pickup - 4WD	Powertrain	●	●	●	●	●	●	T146
2001	GMC truck	Sonoma pickup - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	Sonoma pickup - 4WD	Body control module	●	●	○	●	●	○	
2001	GMC truck	Sonoma pickup - 4WD	Onstar	●	●	●	●	●	●	T191
2001	GMC truck	Sonoma pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	Yukon - 2WD	Powertrain	●	●	●	●	●	○	
2001	GMC truck	Yukon - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	Yukon - 2WD	Passlock	●	●	○	●	●	○	
2001	GMC truck	Yukon - 2WD	Onstar	●	●	●	●	●	●	T191
2001	GMC truck	Yukon - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	GMC truck	Yukon - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	Yukon - 4WD	Powertrain	●	●	●	●	●	○	
2001	GMC truck	Yukon - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	Yukon - 4WD	Passlock	●	●	○	●	●	○	
2001	GMC truck	Yukon - 4WD	Onstar	●	●	●	●	●	●	T191
2001	GMC truck	Yukon - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	GMC truck	Yukon - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	Yukon denali	Powertrain	●	●	●	●	●	○	
2001	GMC truck	Yukon denali	Supplemental inflatable restraint	●	●	○	●	○	○	

2001	GMC truck	Yukon denali	Passlock	●	●	○	●	●	○	
2001	GMC truck	Yukon denali	Onstar	●	●	●	●	●	●	T191
2001	GMC truck	Yukon denali	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	GMC truck	Yukon denali	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	Yukon XL - 2WD	Powertrain	●	●	●	●	●	●	T079
2001	GMC truck	Yukon XL - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	Yukon XL - 2WD	Passlock	●	●	○	●	●	○	
2001	GMC truck	Yukon XL - 2WD	Onstar	●	●	●	●	●	●	T191
2001	GMC truck	Yukon XL - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	GMC truck	Yukon XL - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	GMC truck	Yukon XL - 4WD	Powertrain	●	●	●	●	●	●	T079
2001	GMC truck	Yukon XL - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	GMC truck	Yukon XL - 4WD	Passlock	●	●	○	●	●	○	
2001	GMC truck	Yukon XL - 4WD	Onstar	●	●	●	●	●	●	T191
2001	GMC truck	Yukon XL - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2001	GMC truck	Yukon XL - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2001	Oldsmobile	Bravada	Powertrain	●	●	●	●	●	●	T146
2001	Oldsmobile	Bravada	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Oldsmobile	Bravada	Body control module	●	●	○	●	●	○	
2001	Oldsmobile	Bravada	Onstar	●	●	●	●	●	●	T191
2001	Oldsmobile	Bravada	4WAL 3 sensor	●	●	○	●	●	○	
2001	Oldsmobile	Others	Radio	○	○	○	●	○	○	
2001	Oldsmobile	Others	Memory seat module	●	●	○	●	●	○	
2001	Oldsmobile	Others	Onstar	●	●	●	●	○	●	T191
2001	Oldsmobile	Others	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Oldsmobile	Others	Vehicle theft deterrent	●	●	○	●	○	○	
2001	Oldsmobile	Others	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032
2001	Oldsmobile	Others	Chassis	●	●	●	●	●	●	T014
2001	Pontiac	Aztek - AWD	Powertrain	●	●	●	●	●	●	T001

2001	Pontiac	Aztek - AWD	Body control module	●	●	○	●	●	●	T145
2001	Pontiac	Aztek - AWD	Onstar	●	●	●	●	○	●	T191
2001	Pontiac	Aztek - AWD	Supplemental inflatable restraint	●	●	○	○	○	○	
2001	Pontiac	Aztek - AWD	Vehicle theft deterrent	●	●	●	●	●	●	T145
2001	Pontiac	Aztek - AWD	Chassis	●	●	○	●	●	●	T014
2001	Pontiac	Aztek - FWD	Powertrain	●	●	●	●	●	●	T001
2001	Pontiac	Aztek - FWD	Body control module	●	●	○	●	●	●	T145
2001	Pontiac	Aztek - FWD	Onstar	●	●	●	●	○	●	T191
2001	Pontiac	Aztek - FWD	Supplemental inflatable restraint	●	●	○	○	○	○	
2001	Pontiac	Aztek - FWD	Vehicle theft deterrent	●	●	●	●	●	●	T145
2001	Pontiac	Aztek - FWD	Chassis	●	●	○	●	●	●	T014
2001	Pontiac	Montana	Powertrain	●	●	●	●	●	●	T001
2001	Pontiac	Montana	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032
2001	Pontiac	Montana	Vehicle theft deterrent	●	●	○	●	○	○	
2001	Pontiac	Montana	Radio	○	○	○	●	○	○	
2001	Pontiac	Montana	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Pontiac	Montana	Onstar	●	●	●	●	○	●	T191
2001	Pontiac	Montana	Chassis	●	●	●	●	●	●	T014
2001	Pontiac	Montana ext.	Powertrain	●	●	●	●	●	●	T001
2001	Pontiac	Montana ext.	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032
2001	Pontiac	Montana ext.	Vehicle theft deterrent	●	●	○	●	○	○	
2001	Pontiac	Montana ext.	Radio	○	○	○	●	○	○	
2001	Pontiac	Montana ext.	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Pontiac	Montana ext.	Onstar	●	●	●	●	○	●	T191
2001	Pontiac	Montana ext.	Chassis	●	●	●	●	●	●	T014

2001	Pontiac	Others	Radio	○	○	○	●	○	○	
2001	Pontiac	Others	Onstar	●	●	●	●	○	●	T191
2001	Pontiac	Others	Supplemental inflatable restraint	●	●	○	●	○	○	
2001	Pontiac	Others	Vehicle theft deterrent	●	●	○	●	○	○	
2001	Pontiac	Others	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032
2001	Pontiac	Others	Chassis	●	●	●	●	●	●	T014
2001	Pontiac	Others	Powertrain	●	●	●	●	●	○	
2000	Buick	Century	Powertrain	●	●	●	●	●	●	T001
2000	Buick	Century	Body control module	●	●	○	●	●	●	T122 T170 T198
2000	Buick	Century	Onstar	●	●	●	●	○	●	T191
2000	Buick	Century	Supplemental inflatable restraint	●	●	○	●	○	●	T023
2000	Buick	Century	Chassis	●	●	●	○	●	●	T014
2000	Buick	Lesabre	Powertrain	●	●	●	●	●	●	T001
2000	Buick	Lesabre	Dash integration module	●	●	○	●	●	●	T158 T082 T084
2000	Buick	Lesabre	CD changer	●	●	○	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112 T136 T112 T199
2000	Buick	Lesabre	Instrument panel module	●	●	○	●	●	●	T138 T175
2000	Buick	Lesabre	Radio	○	○	○	○	○	●	T033
2000	Buick	Lesabre	Onstar	●	●	●	●	●	●	T191
2000	Buick	Lesabre	Climate control panel	●	●	●	●	●	●	T033
2000	Buick	Lesabre	Rear integration module	●	●	○	●	●	○	
2000	Buick	Lesabre	DRP/ABS/TIM	●	●	○	●	●	●	T014
2000	Buick	Park avenue	Powertrain	●	●	●	●	●	●	T001
2000	Buick	Park avenue	Body control module	●	●	○	●	●	●	T122 T176 T192 T138 T039 T200
2000	Buick	Park avenue	Onstar	●	●	●	●	○	●	T191
2000	Buick	Park avenue	DRP/ABS/TIM	●	●	○	●	●	●	T014

2000	Buick	Regal	Powertrain	●	●	●	●	●	●	T001
2000	Buick	Regal	Body control module	●	●	○	●	●	●	T122 T170 T198
2000	Buick	Regal	Onstar	●	●	●	●	○	●	T191
2000	Buick	Regal	Supplemental inflatable restraint	●	●	○	●	○	●	T023
2000	Buick	Regal	Chassis	●	●	●	○	●	●	T014
2000	Cadillac	Catera	Powertrain	●	●	●	●	●	○	
2000	Cadillac	Catera	Body control module	●	●	○	●	●	●	T219 T136
2000	Cadillac	Catera	Radio	●	●	○	●	●	●	T179 T086 T087 T033
2000	Cadillac	Catera	Cellular telephone	○	○	○	○	○	●	T192
2000	Cadillac	Catera	Onstar	●	●	●	●	○	●	T191
2000	Cadillac	Catera	ABS	●	●	○	●	●	○	
2000	Cadillac	Deville	Powertrain	●	●	●	●	●	○	
2000	Cadillac	Deville	Dash integration module	●	●	○	●	●	●	T122 T172 T123 T127 T204 T220 T094 T138 T175
2000	Cadillac	Deville	Cellular telephone	●	●	○	●	●	●	T136 T159 T158 T122 T179 T086 T087 T033 T199
2000	Cadillac	Deville	Instrument panel cluster	○	○	○	●	○	○	
2000	Cadillac	Deville	Memory seat module	●	●	○	●	●	○	
2000	Cadillac	Deville	Amplifier (delco)	●	●	○	●	●	●	T126
2000	Cadillac	Deville	Onstar	●	●	●	●	○	●	T191
2000	Cadillac	Deville	Left rear door module	●	●	●	●	●	○	
2000	Cadillac	Deville	Passenger door module	●	●	●	●	●	○	
2000	Cadillac	Deville	Right rear door module	●	●	●	●	●	○	
2000	Cadillac	Deville	Driver door module	●	●	●	●	●	○	
2000	Cadillac	Deville	Driver door switch	●	●	●	●	○	○	
2000	Cadillac	Deville	DRP/ABS/TCS/VSES/BLW	●	●	○	●	●	○	
2000	Cadillac	Deville	Speed sensitive steering	●	●	○	●	○	○	
2000	Cadillac	Deville	CVRSS/ALC	●	●	○	●	●	○	
2000	Cadillac	DHS	Powertrain	●	●	●	●	●	○	

2000	Cadillac	DHS	Dash integration module	●	●	○	●	●	●	T122 T172 T123 T127 T204 T220 T094 T138 T175
2000	Cadillac	DHS	Amplifier (bose)	●	●	○	●	●	●	T221
2000	Cadillac	DHS	Cellular telephone	●	●	○	●	●	●	T136 T159 T158 T122 T179 T086 T087 T033 T199
2000	Cadillac	DHS	Instrument panel cluster	●	●	○	●	●	●	T116 T086 T087 T166
2000	Cadillac	DHS	Memory seat module	●	●	○	●	●	●	T126
2000	Cadillac	DHS	Onstar	●	●	●	●	○	●	T191
2000	Cadillac	DHS	Left rear door module	●	●	●	●	●	○	
2000	Cadillac	DHS	Passenger door module	●	●	●	●	●	○	
2000	Cadillac	DHS	Right rear door module	●	●	●	●	●	○	
2000	Cadillac	DHS	Driver door module	●	●	●	●	●	○	
2000	Cadillac	DHS	Driver door switch	●	●	●	●	○	○	
2000	Cadillac	DHS	DRP/ABS/TCS/VSES/BLW	●	●	○	●	●	○	
2000	Cadillac	DHS	Speed sensitive steering	●	●	○	●	○	○	
2000	Cadillac	DHS	CVRSS/ALC	●	●	○	●	●	○	
2000	Cadillac	DTS	Powertrain	●	●	●	●	●	○	
2000	Cadillac	DTS	Dash integration module	●	●	○	●	●	●	T122 T172 T123 T127 T204 T220 T094 T138 T175
2000	Cadillac	DTS	Amplifier (bose)	●	●	○	●	●	●	T221
2000	Cadillac	DTS	Cellular telephone	●	●	○	●	●	●	T136 T159 T158 T122 T179 T086 T087 T033 T199
2000	Cadillac	DTS	Instrument panel cluster	●	●	○	●	●	●	T116 T086 T087 T166
2000	Cadillac	DTS	Memory seat module	●	●	○	●	●	●	T126
2000	Cadillac	DTS	Onstar	●	●	●	●	○	●	T191
2000	Cadillac	DTS	Left rear door module	●	●	●	●	●	○	
2000	Cadillac	DTS	Passenger door module	●	●	●	●	●	○	
2000	Cadillac	DTS	Right rear door module	●	●	●	●	●	○	

2000	Cadillac	DTS	Driver door module	●	●	●	●	●	○	
2000	Cadillac	DTS	Driver door switch	●	●	●	●	○	○	
2000	Cadillac	DTS	DRP/ABS/TCS/VSES/BLW	●	●	○	●	●	○	
2000	Cadillac	DTS	Speed sensitive steering	●	●	○	●	○	○	
2000	Cadillac	DTS	CVRSS/ALC	●	●	○	●	●	○	
2000	Cadillac	Eldorado	Powertrain	●	●	●	●	●	○	
2000	Cadillac	Eldorado	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190
2000	Cadillac	Eldorado	Radio	●	●	○	●	●	●	T210 T033
2000	Cadillac	Eldorado	Onstar	●	●	●	●	○	●	T191
2000	Cadillac	Eldorado	Delco/Xtool ABS/TCS	●	●	○	○	●	●	T149 T014
2000	Cadillac	Eldorado	Magna steer	●	●	○	○	○	○	
2000	Cadillac	Seville	Powertrain	●	●	●	●	●	○	
2000	Cadillac	Seville	Amplifier (bose)	●	●	○	●	●	●	T122 T172 T123 T125 T194 T195 T193 T220 T094
2000	Cadillac	Seville	Cellular telephone	●	●	○	●	●	●	T136 T159 T158 T122 T179 T086 T087 T033 T199
2000	Cadillac	Seville	Instrument panel cluster	●	●	○	●	●	●	T116 T086 T087 T166
2000	Cadillac	Seville	Amplifier (delco)	●	●	○	●	●	○	
2000	Cadillac	Seville	Memory seat module	●	●	○	●	●	●	T182
2000	Cadillac	Seville	Onstar	●	●	●	●	○	●	T191
2000	Cadillac	Seville	Dash integration module	●	●	●	●	●	●	T112 T113
2000	Cadillac	Seville	DRP/ABS/TCS/VSES/BLW	●	●	○	●	●	○	
2000	Cadillac	Seville	Speed sensitive steering	●	●	○	●	○	○	
2000	Cadillac	Seville	CVRSS/ALC	●	●	○	●	●	○	
2000	Chevrolet	Alero (export)	Powertrain	●	●	●	●	●	●	T001
2000	Chevrolet	Alero (export)	Body control module	●	●	●	●	●	●	T199
2000	Chevrolet	Alero (export)	Chassis	●	●	○	●	●	○	
2000	Chevrolet	Camaro	Powertrain	●	●	●	●	●	●	T001

2000	Chevrolet	Camaro	Instrument panel cluster	●	●	○	●	●	●	T190
2000	Chevrolet	Camaro	Supplemental inflatable restraint	●	●	○	●	●	●	T190
2000	Chevrolet	Camaro	Chassis	●	●	○	●	●	●	T014
2000	Chevrolet	Cavalier	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Cavalier	Radio	○	○	○	●	○	○	
2000	Chevrolet	Cavalier	Body control module	●	●	●	●	●	●	T141 T033 T183
2000	Chevrolet	Cavalier	Chassis	●	●	●	●	●	●	T014
2000	Chevrolet	Cavalier (CNG)	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Cavalier (CNG)	Radio	○	○	○	●	○	○	
2000	Chevrolet	Cavalier (CNG)	Body control module	●	●	●	●	●	●	T141 T033 T183
2000	Chevrolet	Cavalier (CNG)	Chassis	●	●	●	●	●	●	T014
2000	Chevrolet	Corvette	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Corvette	Body control module	●	●	○	●	●	●	T196
2000	Chevrolet	Corvette	Supplemental inflatable restraint	●	●	○	●	●	●	T196
2000	Chevrolet	Corvette	Abs/tcs/magna steer	●	●	●	●	●	○	
2000	Chevrolet	Corvette	RTD	●	●	●	●	●	○	
2000	Chevrolet	Impala	Powertrain	●	●	●	●	●	●	T001
2000	Chevrolet	Impala	Body control module	●	●	○	●	●	●	T023 T136 T122 T088 T080 T081 T082
2000	Chevrolet	Impala	Radio	○	○	○	●	○	○	
2000	Chevrolet	Impala	Onstar	●	●	●	●	●	●	T191
2000	Chevrolet	Impala	Chassis	●	●	●	○	●	●	T014
2000	Chevrolet	Lumina	Powertrain	●	●	●	●	●	●	T001
2000	Chevrolet	Malibu	Powertrain	●	●	●	●	●	●	T001
2000	Chevrolet	Malibu	Body control module	●	●	●	●	●	○	
2000	Chevrolet	Malibu	Chassis	●	●	○	●	●	○	
2000	Chevrolet	Monte carlo	Powertrain	●	●	●	●	●	●	T001
2000	Chevrolet	Monte carlo	Body control module	●	●	○	●	●	●	T023 T136 T122 T088 T080 T081 T082
2000	Chevrolet	Monte carlo	Radio	○	○	○	●	○	○	
2000	Chevrolet	Monte carlo	Onstar	●	●	●	●	●	●	T191
2000	Chevrolet	Monte carlo	Chassis	●	●	●	○	●	●	T014

2000	Chevrolet	Prizm	Supplemental inflatable restraint	●	●	○	○	○	○	
2000	Oldsmobile	Alero	Powertrain	●	●	●	●	●	●	T001
2000	Oldsmobile	Alero	Body control module	●	●	●	○	●	○	
2000	Oldsmobile	Alero	Entertainment & comfort bus	●	●	○	●	●	○	
2000	Oldsmobile	Alero	Chassis	●	●	○	●	●	○	
2000	Oldsmobile	Intrigue	Powertrain	●	●	●	●	●	○	
2000	Oldsmobile	Intrigue	Body control module	●	●	○	●	●	●	T170 T198
2000	Oldsmobile	Intrigue	Onstar	●	●	●	●	○	●	T191
2000	Oldsmobile	Intrigue	Supplemental inflatable restraint	●	●	○	●	○	●	T023
2000	Oldsmobile	Intrigue	Chassis	●	●	○	●	●	●	T223
2000	Pontiac	Bonneville	Powertrain	●	●	●	●	●	●	T001
2000	Pontiac	Bonneville	Dash integration module	○	○	○	●	●	●	T222 T081 T082 T083 T084 T085 T202 T203 T086 T087 T144 T080 T060 T185
2000	Pontiac	Bonneville	Instrument panel cluster	○	○	○	●	○	○	
2000	Pontiac	Bonneville	CD changer	●	●	○	●	●	●	T122 T172 T123 T127 T173 T174 T126 T112 T136 T112 T199
2000	Pontiac	Bonneville	Instrument panel module	●	●	○	●	●	●	T138 T175
2000	Pontiac	Bonneville	Onstar	●	●	●	●	●	●	T191
2000	Pontiac	Bonneville	Climate control panel	●	●	●	●	●	●	T191
2000	Pontiac	Bonneville	Rear integration module	●	●	●	●	●	●	T186
2000	Pontiac	Bonneville	DRP/ABS/TIM	●	●	○	●	●	●	T014
2000	Pontiac	Firebird	Powertrain	●	●	●	●	●	●	T001
2000	Pontiac	Firebird	Instrument panel cluster	●	●	○	●	●	●	T190
2000	Pontiac	Firebird	Supplemental inflatable restraint	●	●	○	●	●	●	T190

2000	Pontiac	Firebird	Chassis	●	●	○	●	●	●	T014
2000	Pontiac	Grand am	Powertrain	●	●	●	●	●	●	T001
2000	Pontiac	Grand am	Body control module	●	●	●	●	●	○	
2000	Pontiac	Grand am	Instrument panel cluster	●	●	○	●	○	○	
2000	Pontiac	Grand am	Chassis	●	●	○	●	●	○	
2000	Pontiac	Grand prix	Powertrain	●	●	●	●	●	●	T001
2000	Pontiac	Grand prix	Vehicle theft deterrent	●	●	○	●	○	●	T200
2000	Pontiac	Grand prix	Onstar	●	●	●	●	○	●	T191
2000	Pontiac	Grand prix	Supplemental inflatable restraint	●	●	○	●	○	○	
2000	Pontiac	Sunfire	Powertrain	●	●	●	●	●	○	
2000	Pontiac	Sunfire	Radio	○	○	○	●	○	○	
2000	Pontiac	Sunfire	Body control module	●	●	●	●	●	●	T141 T033 T183
2000	Pontiac	Sunfire	Chassis	●	●	●	●	●	●	T014
2000	Cadillac	Escalade - AWD	Powertrain	●	●	●	●	●	○	
2000	Cadillac	Escalade - AWD	Passlock	●	●	○	●	●	○	
2000	Cadillac	Escalade - AWD	Memory seat module	●	●	○	○	○	○	
2000	Cadillac	Escalade - AWD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	Cadillac	Escalade - AWD	Onstar	●	●	○	●	○	●	T191
2000	Cadillac	Escalade - AWD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2000	Cadillac	Escalade - AWD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	Cadillac	Escalade - AWD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Cadillac	Hearse	Powertrain	●	●	●	●	●	●	T001
2000	Cadillac	Hearse	Amplifier (delco)	●	●	○	●	●	●	T172 T126 T127 T112 T136 T158 T094 T138 T175 T179 T086 T087 T033 T113 T199 T200
2000	Cadillac	Hearse	Rear integration module	○	○	○	●	○	○	
2000	Cadillac	Hearse	Driver door module	●	●	●	●	●	○	
2000	Cadillac	Hearse	Passenger door module	●	●	●	●	○	○	
2000	Cadillac	Hearse	Driver door switch	●	●	●	●	○	○	

2000	Cadillac	Hearse	DRP/ABS/TCS	●	●	○	●	●	○	
2000	Cadillac	Limousine	Powertrain	●	●	●	●	●	●	T001
2000	Cadillac	Limousine	Amplifier (delco)	●	●	○	●	●	●	T172 T126 T127 T112 T136 T158 T094 T138 T175 T179 T086 T087 T033 T113 T199 T200
2000	Cadillac	Limousine	Rear climate control panel	●	●	○	●	●	○	
2000	Cadillac	Limousine	Onstar	●	●	●	●	○	●	T191
2000	Cadillac	Limousine	Driver door module	●	●	●	●	●	○	
2000	Cadillac	Limousine	Passenger door module	●	●	●	●	○	○	
2000	Cadillac	Limousine	Driver door switch	●	●	●	●	○	○	
2000	Cadillac	Limousine	Left mid door module	●	●	●	●	●	○	
2000	Cadillac	Limousine	Left rear door module	●	●	●	●	●	○	
2000	Cadillac	Limousine	Right mid door module	●	●	●	●	●	○	
2000	Cadillac	Limousine	Right rear door module	●	●	●	●	●	○	
2000	Cadillac	Limousine	DRP/ABS/TCS	●	●	○	●	●	○	
2000	Chevrolet	Astro - 2WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Astro - 2WD	Body control module	●	●	○	●	●	○	
2000	Chevrolet	Astro - 2WD	Instrument panel cluster	○	○	○	○	●	○	
2000	Chevrolet	Astro - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	Astro - 4WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Astro - 4WD	Body control module	●	●	○	●	●	○	
2000	Chevrolet	Astro - 4WD	Instrument panel cluster	○	○	○	○	●	○	
2000	Chevrolet	Astro - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	Blazer - 2WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Blazer - 2WD	Body control module	●	●	○	●	●	○	
2000	Chevrolet	Blazer - 2WD	Onstar	●	●	●	●	○	●	T191
2000	Chevrolet	Blazer - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2000	Chevrolet	Blazer - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	Blazer - 4WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Blazer - 4WD	Body control module	●	●	○	●	●	○	

2000	Chevrolet	Blazer - 4WD	Onstar	●	●	●	●	○	●	T191
2000	Chevrolet	Blazer - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2000	Chevrolet	Blazer - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	Blazer - 4WD - RHD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Blazer - 4WD - RHD	Body control module	●	●	○	●	●	○	
2000	Chevrolet	Blazer - 4WD - RHD	Onstar	●	●	●	●	○	●	T191
2000	Chevrolet	Blazer - 4WD - RHD	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2000	Chevrolet	Blazer - 4WD - RHD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	C pickup - 2WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	C pickup - 2WD	Passlock	●	●	○	●	●	○	
2000	Chevrolet	C pickup - 2WD	Memory seat module	●	●	○	○	○	○	
2000	Chevrolet	C pickup - 2WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	Chevrolet	C pickup - 2WD	Onstar	●	●	○	●	○	●	T191
2000	Chevrolet	C pickup - 2WD	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2000	Chevrolet	C pickup - 2WD	RTD (autorida) / EVO	●	●	○	●	●	○	
2000	Chevrolet	C pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	C pickup - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	C pickup - 2WD (CNG)	Passlock	●	●	○	●	●	○	
2000	Chevrolet	C pickup - 2WD (CNG)	Memory seat module	●	●	○	○	○	○	
2000	Chevrolet	C pickup - 2WD (CNG)	Onstar (VS-3B)	●	●	○	●	○	○	
2000	Chevrolet	C pickup - 2WD (CNG)	Onstar	●	●	○	●	○	●	T191
2000	Chevrolet	C pickup - 2WD (CNG)	Supplemental inflatable restraint	○	○	○	○	○	●	T039

2000	Chevrolet	C pickup - 2WD (CNG)	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	Chevrolet	C pickup - 2WD (CNG)	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	C silverado - 2WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	C silverado - 2WD	Passlock	●	●	○	●	●	○	
2000	Chevrolet	C silverado - 2WD	Memory seat module	●	●	○	○	○	○	
2000	Chevrolet	C silverado - 2WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	Chevrolet	C silverado - 2WD	Onstar	●	●	○	●	○	●	T191
2000	Chevrolet	C silverado - 2WD	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2000	Chevrolet	C silverado - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	Chevrolet	C silverado - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	Express - 2WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Express - 2WD	Immobilizer	●	●	○	●	●	●	T214 T215 T216 T217 T218
2000	Chevrolet	K pickup - 4WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	K pickup - 4WD	Passlock	●	●	○	●	●	○	
2000	Chevrolet	K pickup - 4WD	Memory seat module	●	●	○	○	○	○	
2000	Chevrolet	K pickup - 4WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	Chevrolet	K pickup - 4WD	Onstar	●	●	○	●	○	●	T191
2000	Chevrolet	K pickup - 4WD	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2000	Chevrolet	K pickup - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	Chevrolet	K pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	K pickup - 4WD (CNG)	Powertrain	●	●	●	●	●	○	

2000	Chevrolet	K pickup - 4WD (CNG)	Passlock	●	●	○	●	●	○	
2000	Chevrolet	K pickup - 4WD (CNG)	Memory seat module	●	●	○	○	○	○	
2000	Chevrolet	K pickup - 4WD (CNG)	Onstar (VS-3B)	●	●	○	●	○	○	
2000	Chevrolet	K pickup - 4WD (CNG)	Onstar	●	●	○	●	○	●	T191
2000	Chevrolet	K pickup - 4WD (CNG)	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2000	Chevrolet	K pickup - 4WD (CNG)	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	Chevrolet	K pickup - 4WD (CNG)	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	K silverado - 4WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	K silverado - 4WD	Passlock	●	●	○	●	●	○	
2000	Chevrolet	K silverado - 4WD	Memory seat module	●	●	○	○	○	○	
2000	Chevrolet	K silverado - 4WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	Chevrolet	K silverado - 4WD	Onstar	●	●	○	●	○	●	T191
2000	Chevrolet	K silverado - 4WD	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2000	Chevrolet	K silverado - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	Chevrolet	K silverado - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	S10 pickup - 2WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	S10 pickup - 2WD	Body control module	●	●	○	●	●	○	

2000	Chevrolet	S10 pickup - 2WD	Onstar	●	●	●	●	○	●	T191
2000	Chevrolet	S10 pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2000	Chevrolet	S10 pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	S10 pickup - 4WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	S10 pickup - 4WD	Body control module	●	●	○	●	●	○	
2000	Chevrolet	S10 pickup - 4WD	Onstar	●	●	●	●	○	●	T191
2000	Chevrolet	S10 pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2000	Chevrolet	S10 pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	Suburban - 2WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Suburban - 2WD	Passlock	●	●	○	●	●	○	
2000	Chevrolet	Suburban - 2WD	Memory seat module	●	●	○	○	○	○	
2000	Chevrolet	Suburban - 2WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	Chevrolet	Suburban - 2WD	Onstar	●	●	○	●	○	●	T191
2000	Chevrolet	Suburban - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2000	Chevrolet	Suburban - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	Chevrolet	Suburban - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	Suburban - 4WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Suburban - 4WD	Passlock	●	●	○	●	●	○	
2000	Chevrolet	Suburban - 4WD	Memory seat module	●	●	○	○	○	○	
2000	Chevrolet	Suburban - 4WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	Chevrolet	Suburban - 4WD	Onstar	●	●	○	●	○	●	T191
2000	Chevrolet	Suburban - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2000	Chevrolet	Suburban - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	Chevrolet	Suburban - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	Tahoe - 2WD	Powertrain	●	●	●	●	●	○	

2000	Chevrolet	Tahoe - 2WD	Passlock	●	●	○	●	●	○	
2000	Chevrolet	Tahoe - 2WD	Memory seat module	●	●	○	○	○	○	
2000	Chevrolet	Tahoe - 2WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	Chevrolet	Tahoe - 2WD	Onstar	●	●	○	●	○	●	T191
2000	Chevrolet	Tahoe - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2000	Chevrolet	Tahoe - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	Chevrolet	Tahoe - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	Tahoe - 4WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Tahoe - 4WD	Passlock	●	●	○	●	●	○	
2000	Chevrolet	Tahoe - 4WD	Memory seat module	●	●	○	○	○	○	
2000	Chevrolet	Tahoe - 4WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	Chevrolet	Tahoe - 4WD	Onstar	●	●	○	●	○	●	T191
2000	Chevrolet	Tahoe - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2000	Chevrolet	Tahoe - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	Chevrolet	Tahoe - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	Tahoe limited	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Tahoe limited	Passlock	●	●	○	●	●	○	
2000	Chevrolet	Tahoe limited	Memory seat module	●	●	○	○	○	○	
2000	Chevrolet	Tahoe limited	Onstar (VS-3B)	●	●	○	●	○	○	
2000	Chevrolet	Tahoe limited	Onstar	●	●	○	●	○	●	T191
2000	Chevrolet	Tahoe limited	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2000	Chevrolet	Tahoe limited	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	Chevrolet	Tahoe limited	4WAL 3 sensor	●	●	○	●	●	○	
2000	Chevrolet	Tahoe Z71	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Tahoe Z71	Passlock	●	●	○	●	●	○	
2000	Chevrolet	Tahoe Z71	Memory seat module	●	●	○	○	○	○	
2000	Chevrolet	Tahoe Z71	Onstar (VS-3B)	●	●	○	●	○	○	
2000	Chevrolet	Tahoe Z71	Onstar	●	●	○	●	○	●	T191
2000	Chevrolet	Tahoe Z71	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2000	Chevrolet	Tahoe Z71	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	Chevrolet	Tahoe Z71	4WAL 3 sensor	●	●	○	●	●	○	

2000	Chevrolet	Tracker - 2WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Tracker - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2000	Chevrolet	Tracker - 2WD	Body control module	●	●	○	●	●	○	
2000	Chevrolet	Tracker - 2WD	Chassis	●	●	●	●	●	●	T014
2000	Chevrolet	Tracker - 2WD	4WAL 3 sensor	●	●	●	●	●	●	T014
2000	Chevrolet	Tracker - 4WD	Powertrain	●	●	●	●	●	○	
2000	Chevrolet	Tracker - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
2000	Chevrolet	Tracker - 4WD	Body control module	●	●	○	●	●	○	
2000	Chevrolet	Tracker - 4WD	Chassis	●	●	●	●	●	●	T014
2000	Chevrolet	Tracker - 4WD	4WAL 3 sensor	●	●	●	●	●	●	T014
2000	Chevrolet	Trans sport (export)	Powertrain	●	●	●	●	●	●	T001
2000	Chevrolet	Trans sport (export)	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032 T200
2000	Chevrolet	Trans sport (export)	Supplemental inflatable restraint	●	●	○	●	○	○	
2000	Chevrolet	Trans sport (export)	Radio	○	○	○	●	○	○	
2000	Chevrolet	Trans sport (export)	Onstar	●	●	●	●	○	●	T191
2000	Chevrolet	Trans sport (export)	Chassis	●	●	●	●	●	●	T014
2000	Chevrolet	Venture	Powertrain	●	●	●	●	●	●	T001
2000	Chevrolet	Venture	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032 T200
2000	Chevrolet	Venture	Supplemental inflatable restraint	●	●	○	●	○	○	
2000	Chevrolet	Venture	Radio	○	○	○	●	○	○	
2000	Chevrolet	Venture	Onstar	●	●	●	●	●	●	T191
2000	Chevrolet	Venture	Chassis	●	●	●	●	●	●	T014
2000	Chevrolet	Others	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032 T200
2000	Chevrolet	Others	Radio	○	○	○	●	○	○	

2000	Chevrolet	Others	Onstar	●	●	●	●	○	●	T191
2000	GMC truck	Envoy - 4WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	Envoy - 4WD	Body control module	●	●	○	●	●	○	
2000	GMC truck	Envoy - 4WD	Onstar	●	●	●	●	○	●	T191
2000	GMC truck	Envoy - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2000	GMC truck	Envoy - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	GMC C pickup - 2WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	GMC C pickup - 2WD	Passlock	●	●	○	●	●	○	
2000	GMC truck	GMC C pickup - 2WD	Memory seat module	●	●	○	○	○	○	
2000	GMC truck	GMC C pickup - 2WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	GMC truck	GMC C pickup - 2WD	Onstar	●	●	○	●	○	●	T191
2000	GMC truck	GMC C pickup - 2WD	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2000	GMC truck	GMC C pickup - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	GMC truck	GMC C pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	GMC C pickup - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
2000	GMC truck	GMC C pickup - 2WD (CNG)	Passlock	●	●	○	●	●	○	
2000	GMC truck	GMC C pickup - 2WD (CNG)	Memory seat module	●	●	○	○	○	○	
2000	GMC truck	GMC C pickup - 2WD (CNG)	Onstar (VS-3B)	●	●	○	●	○	○	
2000	GMC truck	GMC C pickup - 2WD (CNG)	Onstar	●	●	○	●	○	●	T191
2000	GMC truck	GMC C pickup - 2WD (CNG)	Supplemental inflatable restraint	○	○	○	○	○	●	T039

2000	GMC truck	GMC C pickup - 2WD (CNG)	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	GMC truck	GMC C pickup - 2WD (CNG)	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	GMC c-series - 2WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	GMC c-series - 2WD	Passlock	●	●	○	●	●	○	
2000	GMC truck	GMC c-series - 2WD	Memory seat module	●	●	○	○	○	○	
2000	GMC truck	GMC c-series - 2WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	GMC truck	GMC c-series - 2WD	Onstar	●	●	○	●	○	●	T191
2000	GMC truck	GMC c-series - 2WD	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2000	GMC truck	GMC c-series - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	GMC truck	GMC c-series - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	GMC K pickup - 4WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	GMC K pickup - 4WD	Passlock	●	●	○	●	●	○	
2000	GMC truck	GMC K pickup - 4WD	Memory seat module	●	●	○	○	○	○	
2000	GMC truck	GMC K pickup - 4WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	GMC truck	GMC K pickup - 4WD	Onstar	●	●	○	●	○	●	T191
2000	GMC truck	GMC K pickup - 4WD	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2000	GMC truck	GMC K pickup - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	

2000	GMC truck	GMC K pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	GMC K pickup - 4WD (CNG)	Powertrain	●	●	●	●	●	○	
2000	GMC truck	GMC K pickup - 4WD (CNG)	Passlock	●	●	○	●	●	○	
2000	GMC truck	GMC K pickup - 4WD (CNG)	Memory seat module	●	●	○	○	○	○	
2000	GMC truck	GMC K pickup - 4WD (CNG)	Onstar (VS-3B)	●	●	○	●	○	○	
2000	GMC truck	GMC K pickup - 4WD (CNG)	Onstar	●	●	○	●	○	●	T191
2000	GMC truck	GMC K pickup - 4WD (CNG)	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2000	GMC truck	GMC K pickup - 4WD (CNG)	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	GMC truck	GMC K pickup - 4WD (CNG)	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	GMC K sierra - 4WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	GMC K sierra - 4WD	Passlock	●	●	○	●	●	○	
2000	GMC truck	GMC K sierra - 4WD	Memory seat module	●	●	○	○	○	○	
2000	GMC truck	GMC K sierra - 4WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	GMC truck	GMC K sierra - 4WD	Onstar	●	●	○	●	○	●	T191
2000	GMC truck	GMC K sierra - 4WD	Supplemental inflatable restraint	○	○	○	○	○	●	T039
2000	GMC truck	GMC K sierra - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	GMC truck	GMC K sierra - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	Jimmy - 2WD	Powertrain	●	●	●	●	●	○	

2000	GMC truck	Jimmy - 2WD	Body control module	●	●	○	●	●	○	
2000	GMC truck	Jimmy - 2WD	Onstar	●	●	●	●	○	●	T191
2000	GMC truck	Jimmy - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2000	GMC truck	Jimmy - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	Jimmy - 4WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	Jimmy - 4WD	Body control module	●	●	○	●	●	○	
2000	GMC truck	Jimmy - 4WD	Onstar	●	●	●	●	○	●	T191
2000	GMC truck	Jimmy - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2000	GMC truck	Jimmy - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	Safari - 2WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	Safari - 2WD	Body control module	●	●	○	●	●	○	
2000	GMC truck	Safari - 2WD	Instrument panel cluster	○	○	○	○	●	○	
2000	GMC truck	Safari - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	Safari - 4WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	Safari - 4WD	Body control module	●	●	○	●	●	○	
2000	GMC truck	Safari - 4WD	Instrument panel cluster	○	○	○	○	●	○	
2000	GMC truck	Safari - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	Savana - 2WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	Savana - 2WD	Immobilizer	●	●	○	●	●	●	T214 T215 T216 T217 T218
2000	GMC truck	Sonoma pickup - 2WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	Sonoma pickup - 2WD	Body control module	●	●	○	●	●	○	
2000	GMC truck	Sonoma pickup - 2WD	Onstar	●	●	●	●	○	●	T191
2000	GMC truck	Sonoma pickup - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2000	GMC truck	Sonoma pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	

2000	GMC truck	Sonoma pickup - 4WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	Sonoma pickup - 4WD	Body control module	●	●	○	●	●	○	
2000	GMC truck	Sonoma pickup - 4WD	Onstar	●	●	●	●	○	●	T191
2000	GMC truck	Sonoma pickup - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2000	GMC truck	Sonoma pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	Yukon - 2WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	Yukon - 2WD	Passlock	●	●	○	●	●	○	
2000	GMC truck	Yukon - 2WD	Memory seat module	●	●	○	○	○	○	
2000	GMC truck	Yukon - 2WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	GMC truck	Yukon - 2WD	Onstar	●	●	○	●	○	●	T191
2000	GMC truck	Yukon - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2000	GMC truck	Yukon - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	GMC truck	Yukon - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	Yukon - 4WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	Yukon - 4WD	Passlock	●	●	○	●	●	○	
2000	GMC truck	Yukon - 4WD	Memory seat module	●	●	○	○	○	○	
2000	GMC truck	Yukon - 4WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	GMC truck	Yukon - 4WD	Onstar	●	●	○	●	○	●	T191
2000	GMC truck	Yukon - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2000	GMC truck	Yukon - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	GMC truck	Yukon - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	Yukon denali	Powertrain	●	●	●	●	●	○	
2000	GMC truck	Yukon denali	Passlock	●	●	○	●	●	○	
2000	GMC truck	Yukon denali	Memory seat module	●	●	○	○	○	○	
2000	GMC truck	Yukon denali	Onstar (VS-3B)	●	●	○	●	○	○	
2000	GMC truck	Yukon denali	Onstar	●	●	○	●	○	●	T191
2000	GMC truck	Yukon denali	Supplemental inflatable restraint	●	●	○	●	●	●	T039

2000	GMC truck	Yukon denali	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	GMC truck	Yukon denali	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	Yukon XL - 2WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	Yukon XL - 2WD	Passlock	●	●	○	●	●	○	
2000	GMC truck	Yukon XL - 2WD	Memory seat module	●	●	○	○	○	○	
2000	GMC truck	Yukon XL - 2WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	GMC truck	Yukon XL - 2WD	Onstar	●	●	○	●	○	●	T191
2000	GMC truck	Yukon XL - 2WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2000	GMC truck	Yukon XL - 2WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	GMC truck	Yukon XL - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	GMC truck	Yukon XL - 4WD	Powertrain	●	●	●	●	●	○	
2000	GMC truck	Yukon XL - 4WD	Passlock	●	●	○	●	●	○	
2000	GMC truck	Yukon XL - 4WD	Memory seat module	●	●	○	○	○	○	
2000	GMC truck	Yukon XL - 4WD	Onstar (VS-3B)	●	●	○	●	○	○	
2000	GMC truck	Yukon XL - 4WD	Onstar	●	●	○	●	○	●	T191
2000	GMC truck	Yukon XL - 4WD	Supplemental inflatable restraint	●	●	○	●	●	●	T039
2000	GMC truck	Yukon XL - 4WD	RTD (autoride) / EVO	●	●	○	●	●	○	
2000	GMC truck	Yukon XL - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Isuzu	S/T isuzu - 2WD	Powertrain	●	●	●	●	●	○	
2000	Isuzu	S/T isuzu - 2WD	Body control module	●	●	○	●	●	○	
2000	Isuzu	S/T isuzu - 2WD	Onstar	●	●	●	●	○	●	T191
2000	Isuzu	S/T isuzu - 2WD	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2000	Isuzu	S/T isuzu - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Isuzu	S/T isuzu - 4WD	Powertrain	●	●	●	●	●	○	
2000	Isuzu	S/T isuzu - 4WD	Body control module	●	●	○	●	●	○	
2000	Isuzu	S/T isuzu - 4WD	Onstar	●	●	●	●	○	●	T191
2000	Isuzu	S/T isuzu - 4WD	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2000	Isuzu	S/T isuzu - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
2000	Oldsmobile	Bravada	Powertrain	●	●	●	●	●	○	
2000	Oldsmobile	Bravada	Body control module	●	●	○	●	●	○	
2000	Oldsmobile	Bravada	Onstar	●	●	●	●	○	●	T191

2000	Oldsmobile	Bravada	Supplemental inflatable restraint	●	●	●	●	●	●	T039
2000	Oldsmobile	Bravada	4WAL 3 sensor	●	●	○	●	●	○	
2000	Oldsmobile	Silhouette	Powertrain	●	●	●	●	●	●	T001
2000	Oldsmobile	Silhouette	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032 T200
2000	Oldsmobile	Silhouette	Supplemental inflatable restraint	●	●	○	●	○	○	
2000	Oldsmobile	Silhouette	Radio	○	○	○	●	○	○	
2000	Oldsmobile	Silhouette	Onstar	●	●	●	●	○	●	T191
2000	Oldsmobile	Silhouette	Chassis	●	●	●	●	●	●	T014
2000	Oldsmobile	Silhouette ext.	Powertrain	●	●	●	●	●	●	T001
2000	Oldsmobile	Silhouette ext.	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032 T200
2000	Oldsmobile	Silhouette ext.	Supplemental inflatable restraint	●	●	○	●	○	○	
2000	Oldsmobile	Silhouette ext.	Radio	○	○	○	●	○	○	
2000	Oldsmobile	Silhouette ext.	Onstar	●	●	●	●	○	●	T191
2000	Oldsmobile	Silhouette ext.	Chassis	●	●	●	●	●	●	T014
2000	Oldsmobile	Others	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032 T200
2000	Oldsmobile	Others	Radio	○	○	○	●	○	○	
2000	Oldsmobile	Others	Onstar	●	●	●	●	○	●	T191
2000	Pontiac	Montana	Powertrain	●	●	●	●	●	●	T001
2000	Pontiac	Montana	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032 T200
2000	Pontiac	Montana	Supplemental inflatable restraint	●	●	○	●	○	○	
2000	Pontiac	Montana	Radio	○	○	○	●	○	○	
2000	Pontiac	Montana	Onstar	●	●	●	●	●	●	T191
2000	Pontiac	Montana	Chassis	●	●	●	●	●	●	T014
2000	Pontiac	Others	Driver information center	●	●	○	●	●	●	T190 T136 T081 T082 T080 T032 T200
2000	Pontiac	Others	Radio	○	○	○	●	○	○	
2000	Pontiac	Others	Onstar	●	●	●	●	○	●	T191

2000	Pontiac	Others	Powertrain	●	●	●	●	●	○	
1999	Buick	Century	Powertrain	●	●	●	●	●	●	T001
1999	Buick	Century	Body control module	●	●	○	●	●	●	T122 T170 T198 T136
1999	Buick	Century	Onstar	●	●	○	●	○	●	T191
1999	Buick	Century	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Buick	Century	Supplemental inflatable restraint	●	●	○	●	○	●	T023
1999	Buick	Century	Chassis	●	●	●	○	●	●	T014
1999	Buick	Lesabre	Powertrain	●	●	●	●	●	●	T001
1999	Buick	Lesabre	Body control module	●	●	○	●	●	●	T122 T176 T058 T192 T058 T039 T200
1999	Buick	Lesabre	Onstar	●	●	○	●	○	●	T191
1999	Buick	Lesabre	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Buick	Lesabre	Remote function actuation	●	●	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1999	Buick	Lesabre	ABS	●	●	○	○	●	●	T149 T014
1999	Buick	Park avenue	Powertrain	●	●	●	●	●	●	T001
1999	Buick	Park avenue	Body control module	●	●	○	●	●	●	T122 T176 T058 T192 T058 T039 T200
1999	Buick	Park avenue	Onstar	●	●	○	●	○	●	T191
1999	Buick	Park avenue	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Buick	Park avenue	ABS	●	●	○	○	●	●	T149 T014
1999	Buick	Regal	Powertrain	●	●	●	●	●	●	T001
1999	Buick	Regal	Body control module	●	●	○	●	●	●	T122 T170 T198 T136
1999	Buick	Regal	Onstar	●	●	○	●	○	●	T191
1999	Buick	Regal	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Buick	Regal	Supplemental inflatable restraint	●	●	○	●	●	●	T023
1999	Buick	Regal	Chassis	●	●	●	○	●	●	T014
1999	Buick	Riviera	Powertrain	●	●	●	●	●	●	T001
1999	Buick	Riviera	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1999	Buick	Riviera	Onstar	●	●	○	●	○	●	T191
1999	Buick	Riviera	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Cadillac	Catera	Powertrain	●	●	●	●	●	●	T231

1999	Cadillac	Catera	Remote function actuator	●	●	○	●	○	○	
1999	Cadillac	Catera	Body control module	○	○	○	●	○	●	T136
1999	Cadillac	Catera	BCM/RFA	●	●	○	○	●	●	T219
1999	Cadillac	Catera	Radio	●	●	○	●	●	●	T179 T033
1999	Cadillac	Catera	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Cadillac	Catera	Cellular telephone	●	●	○	●	○	●	T192
1999	Cadillac	Catera	Onstar	●	●	○	●	●	●	T191
1999	Cadillac	Catera	ABS	●	●	○	●	●	○	
1999	Cadillac	Deville	Powertrain	●	●	●	●	●	●	T231
1999	Cadillac	Deville	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190
1999	Cadillac	Deville	Radio	●	●	○	●	●	●	T210 T033
1999	Cadillac	Deville	Onstar	●	●	○	●	○	●	T191
1999	Cadillac	Deville	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Cadillac	Deville	Cellular telephone	●	●	○	●	●	●	T205 T206 T207 T208 T209 T190
1999	Cadillac	Deville	Delco/Xtool ABS/TCS	●	●	○	○	●	●	T149 T014
1999	Cadillac	Deville	Magna steer	●	●	○	○	○	○	
1999	Cadillac	Deville	ABS/TCS BLW ICCS2	●	●	○	○	●	●	T149 T014
1999	Cadillac	Eldorado	Powertrain	●	●	●	●	●	●	T231
1999	Cadillac	Eldorado	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190
1999	Cadillac	Eldorado	Radio	●	●	○	●	●	●	T210 T033
1999	Cadillac	Eldorado	Onstar	●	●	○	●	○	●	T191
1999	Cadillac	Eldorado	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Cadillac	Eldorado	Delco/Xtool ABS/TCS	●	●	○	○	●	●	T149 T014
1999	Cadillac	Eldorado	Magna steer	●	●	○	○	○	○	
1999	Cadillac	Seville	Powertrain	●	●	●	●	●	●	T231
1999	Cadillac	Seville	Cellular telephone	●	●	○	●	○	○	
1999	Cadillac	Seville	Amplifier (bose)	●	●	○	●	●	●	T122 T172 T123 T125 T194 T195 T112 T193 T136 T159 T233 T094 T179 T179 T095 T033 T112 T234 T199 T200

1999	Cadillac	Seville	Memory seat module	●	●	○	●	●	○	
1999	Cadillac	Seville	Remote function actuation	●	●	○	●	○	●	T235
1999	Cadillac	Seville	Onstar	●	●	○	●	○	●	T191
1999	Cadillac	Seville	Onstar (VS-3B)	●	●	○	●	●	●	T122 T172 T123 T125 T194 T195 T112 T193 T136 T159 T233 T094 T179 T179 T095 T033 T112 T234 T199 T200
1999	Cadillac	Seville	ABS/TCS BLW ICCS2	●	●	○	○	●	●	T149 T014
1999	Chevrolet	Camaro	Powertrain	●	●	●	●	●	●	T001
1999	Chevrolet	Camaro	Instrument panel cluster	○	○	○	●	●	●	T190
1999	Chevrolet	Camaro	Entertainment & comfort bus	●	●	○	○	○	○	
1999	Chevrolet	Camaro	Supplemental inflatable restraint	●	●	○	●	●	●	T190
1999	Chevrolet	Camaro	Chassis	●	●	○	●	●	●	T014
1999	Chevrolet	Cavalier	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Cavalier (CNG)	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Corvette	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Corvette	Body control module	●	●	○	●	●	●	T196 T108
1999	Chevrolet	Corvette	Left door control module	○	○	○	○	●	○	
1999	Chevrolet	Corvette	Supplemental inflatable restraint	●	●	○	●	●	●	T196 T108
1999	Chevrolet	Corvette	Abs/tcs/magna steer	●	●	●	●	●	○	
1999	Chevrolet	Corvette	CVRTD	●	●	●	●	●	○	
1999	Chevrolet	Lumina	Powertrain	●	●	●	●	●	●	T001
1999	Chevrolet	Lumina	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	Lumina	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Chevrolet	Malibu	Powertrain	●	●	●	●	●	●	T001
1999	Chevrolet	Malibu	Body function controller	●	●	○	●	●	○	
1999	Chevrolet	Malibu	Chassis	●	●	○	●	●	○	

1999	Chevrolet	Monte carlo	Powertrain	●	●	●	●	●	●	T001
1999	Chevrolet	Monte carlo	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	Monte carlo	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Chevrolet	Prizm	Supplemental inflatable restraint	●	●	○	○	○	○	
1999	Oldsmobile	Alero	Powertrain	●	●	●	●	●	●	T001
1999	Oldsmobile	Alero	Body function controller	●	●	○	●	●	○	
1999	Oldsmobile	Alero	Vehicle theft deterrent	●	●	○	●	●	●	T199
1999	Oldsmobile	Alero	Chassis	●	●	○	●	●	○	
1999	Oldsmobile	Aurora	Powertrain	●	●	●	●	●	●	T232 T231
1999	Oldsmobile	Aurora	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1999	Oldsmobile	Aurora	Onstar	●	●	○	●	○	●	T191
1999	Oldsmobile	Aurora	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Oldsmobile	Cutlass	Powertrain	●	●	●	●	●	●	T001
1999	Oldsmobile	Cutlass	Body function controller	●	●	○	●	●	○	
1999	Oldsmobile	Cutlass	Vehicle theft deterrent	●	●	○	●	●	●	T199
1999	Oldsmobile	Cutlass	Chassis	●	●	○	●	●	○	
1999	Oldsmobile	Eighty eight	Powertrain	●	●	●	●	●	●	T001
1999	Oldsmobile	Eighty eight	Body control module	●	●	○	●	●	●	T122 T176 T058 T192 T058 T039 T200
1999	Oldsmobile	Eighty eight	Onstar	●	●	○	●	○	●	T191
1999	Oldsmobile	Eighty eight	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Oldsmobile	Eighty eight	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1999	Oldsmobile	Eighty eight	ABS	●	●	○	○	●	●	T149 T014
1999	Oldsmobile	Intrigue	Powertrain	●	●	●	●	●	●	T001
1999	Oldsmobile	Intrigue	Body control module	●	●	○	●	●	●	T170 T198
1999	Oldsmobile	Intrigue	Chassis	○	○	○	○	●	○	
1999	Pontiac	Bonneville	Powertrain	●	●	●	●	●	●	T001

1999	Pontiac	Bonneville	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1999	Pontiac	Bonneville	Onstar	●	●	○	●	○	●	T191
1999	Pontiac	Bonneville	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Pontiac	Bonneville	Body control module	●	●	○	●	●	●	T122 T176 T058 T192 T058 T039 T200
1999	Pontiac	Bonneville	ABS	●	●	○	○	●	●	T149 T014
1999	Pontiac	Firebird	Powertrain	●	●	●	●	●	●	T001
1999	Pontiac	Firebird	Instrument panel cluster	○	○	○	●	●	●	T190
1999	Pontiac	Firebird	Entertainment & comfort bus	●	●	○	○	○	○	
1999	Pontiac	Firebird	Supplemental inflatable restraint	●	●	○	●	●	●	T190
1999	Pontiac	Firebird	Chassis	●	●	○	●	●	●	T014
1999	Pontiac	Grand am	Powertrain	●	●	●	●	●	●	T001
1999	Pontiac	Grand am	Body function controller	●	●	○	●	●	○	
1999	Pontiac	Grand am	Vehicle theft deterrent	●	●	○	●	○	●	T199
1999	Pontiac	Grand am	Chassis	●	●	○	●	●	○	
1999	Pontiac	Grand prix	Powertrain	●	●	●	●	●	●	T001
1999	Pontiac	Grand prix	Supplemental inflatable restraint	●	●	○	●	○	○	
1999	Pontiac	Sunfire	Powertrain	●	●	●	●	●	○	
1999	Cadillac	Escalade - AWD	Powertrain	●	●	●	●	●	○	
1999	Cadillac	Escalade - AWD	Passlock	●	●	○	●	●	○	
1999	Cadillac	Escalade - AWD	Onstar	●	●	○	●	○	●	T191
1999	Cadillac	Escalade - AWD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	Cadillac	Escalade - AWD	Electronic variable orifice	●	●	○	●	○	○	
1999	Cadillac	Escalade - AWD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Cadillac	Hearse	Powertrain	●	●	●	●	●	●	T001
1999	Cadillac	Hearse	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190

1999	Cadillac	Hearse	Radio	○	○	○	○	○	●	T210
1999	Cadillac	Hearse	Delco/Xtool ABS/TCS	●	●	○	○	●	●	T149 T014
1999	Cadillac	Limousine	Powertrain	●	●	●	●	●	●	T001
1999	Cadillac	Limousine	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190
1999	Cadillac	Limousine	Radio	○	○	○	○	○	●	T210
1999	Cadillac	Limousine	Delco/Xtool ABS/TCS	●	●	○	○	●	●	T149 T014
1999	Chevrolet	Astro - 2WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Astro - 2WD	Passlock	●	●	○	●	●	○	
1999	Chevrolet	Astro - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	Astro - 4WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Astro - 4WD	Passlock	●	●	○	●	●	○	
1999	Chevrolet	Astro - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	Blazer - 2WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Blazer - 2WD	Heating and air conditioning	●	●	○	●	●	○	
1999	Chevrolet	Blazer - 2WD	Body control module	●	●	○	●	●	○	
1999	Chevrolet	Blazer - 2WD	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	Blazer - 2WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	Chevrolet	Blazer - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	Blazer - 4WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Blazer - 4WD	Heating and air conditioning	●	●	○	●	●	○	
1999	Chevrolet	Blazer - 4WD	Body control module	●	●	○	●	●	○	
1999	Chevrolet	Blazer - 4WD	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	Blazer - 4WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	Chevrolet	Blazer - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	Blazer - 4WD - RHD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Blazer - 4WD - RHD	Heating and air conditioning	●	●	○	●	●	○	
1999	Chevrolet	Blazer - 4WD - RHD	Body control module	●	●	○	●	●	○	
1999	Chevrolet	Blazer - 4WD - RHD	Onstar	●	●	○	●	○	●	T191

1999	Chevrolet	Blazer - 4WD - RHD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	Chevrolet	Blazer - 4WD - RHD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	C pickup - 2WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	C pickup - 2WD	Passlock	●	●	○	●	●	○	
1999	Chevrolet	C pickup - 2WD	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	C pickup - 2WD	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Chevrolet	C pickup - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1999	Chevrolet	C pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	C pickup - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	C pickup - 2WD (CNG)	Passlock	●	●	○	●	●	○	
1999	Chevrolet	C pickup - 2WD (CNG)	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	C pickup - 2WD (CNG)	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Chevrolet	C pickup - 2WD (CNG)	Electronic variable orifice	●	●	○	●	○	○	
1999	Chevrolet	C pickup - 2WD (CNG)	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	Express - 2WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Express - 2WD	Passlock	●	●	○	●	●	○	
1999	Chevrolet	Express - 2WD	Immobilizer	●	●	○	●	●	●	T214 T215 T216 T217 T218
1999	Chevrolet	K pickup - 4WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	K pickup - 4WD	Passlock	●	●	○	●	●	○	
1999	Chevrolet	K pickup - 4WD	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	K pickup - 4WD	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Chevrolet	K pickup - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1999	Chevrolet	K pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	

1999	Chevrolet	K pickup - 4WD (CNG)	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	K pickup - 4WD (CNG)	Passlock	●	●	○	●	●	○	
1999	Chevrolet	K pickup - 4WD (CNG)	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	K pickup - 4WD (CNG)	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Chevrolet	K pickup - 4WD (CNG)	Electronic variable orifice	●	●	○	●	○	○	
1999	Chevrolet	K pickup - 4WD (CNG)	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	K silverado - 4WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	K silverado - 4WD	Passlock	●	●	○	●	●	○	
1999	Chevrolet	K silverado - 4WD	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	K silverado - 4WD	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Chevrolet	K silverado - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1999	Chevrolet	K silverado - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	S10 pickup - 2WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	S10 pickup - 2WD	Heating and air conditioning	●	●	○	●	●	○	
1999	Chevrolet	S10 pickup - 2WD	Body control module	●	●	○	●	●	○	
1999	Chevrolet	S10 pickup - 2WD	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	S10 pickup - 2WD	Onstar (VS-3B)	●	●	○	●	●	●	T191

1999	Chevrolet	S10 pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	S10 pickup - 4WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	S10 pickup - 4WD	Heating and air conditioning	●	●	○	●	●	○	
1999	Chevrolet	S10 pickup - 4WD	Body control module	●	●	○	●	●	○	
1999	Chevrolet	S10 pickup - 4WD	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	S10 pickup - 4WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	Chevrolet	S10 pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	Suburban - 2WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Suburban - 2WD	Passlock	●	●	○	●	●	○	
1999	Chevrolet	Suburban - 2WD	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	Suburban - 2WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	Chevrolet	Suburban - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1999	Chevrolet	Suburban - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	Suburban - 4WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Suburban - 4WD	Passlock	●	●	○	●	●	○	
1999	Chevrolet	Suburban - 4WD	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	Suburban - 4WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	Chevrolet	Suburban - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1999	Chevrolet	Suburban - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	Suburban 4WD - RHD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Suburban 4WD - RHD	Passlock	●	●	○	●	●	○	
1999	Chevrolet	Suburban 4WD - RHD	Onstar	●	●	○	●	○	●	T191

1999	Chevrolet	Suburban 4WD - RHD	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Chevrolet	Suburban 4WD - RHD	Electronic variable orifice	●	●	○	●	○	○	
1999	Chevrolet	Suburban 4WD - RHD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	Tahoe - 2WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Tahoe - 2WD	Passlock	●	●	○	●	●	○	
1999	Chevrolet	Tahoe - 2WD	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	Tahoe - 2WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	Chevrolet	Tahoe - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1999	Chevrolet	Tahoe - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	Tahoe - 4WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Tahoe - 4WD	Passlock	●	●	○	●	●	○	
1999	Chevrolet	Tahoe - 4WD	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	Tahoe - 4WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	Chevrolet	Tahoe - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1999	Chevrolet	Tahoe - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	Tahoe 4WD - RHD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Tahoe 4WD - RHD	Passlock	●	●	○	●	●	○	
1999	Chevrolet	Tahoe 4WD - RHD	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	Tahoe 4WD - RHD	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Chevrolet	Tahoe 4WD - RHD	Electronic variable orifice	●	●	○	●	○	○	
1999	Chevrolet	Tahoe 4WD - RHD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Chevrolet	Tracker - 2WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Tracker - 2WD	Supplemental inflatable restraint	●	●	○	●	○	○	
1999	Chevrolet	Tracker - 2WD	Chassis	●	●	●	●	●	●	T014
1999	Chevrolet	Tracker - 4WD	Powertrain	●	●	●	●	●	○	
1999	Chevrolet	Tracker - 4WD	Supplemental inflatable restraint	●	●	○	●	○	○	
1999	Chevrolet	Tracker - 4WD	Chassis	●	●	●	●	●	●	T014

1999	Chevrolet	Venture	Powertrain	●	●	●	●	●	●	T001
1999	Chevrolet	Venture	Entertainment & comfort bus	●	●	○	●	○	○	
1999	Chevrolet	Venture	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	Venture	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Chevrolet	Venture ext.	Powertrain	●	●	●	●	●	●	T001
1999	Chevrolet	Venture ext.	Entertainment & comfort bus	●	●	○	●	○	○	
1999	Chevrolet	Venture ext.	Onstar	●	●	○	●	○	●	T191
1999	Chevrolet	Venture ext.	Onstar (VS-3B)	●	●	○	●	○	○	
1999	GMC truck	Envoy - 4WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	Envoy - 4WD	Heating and air conditioning	●	●	○	●	●	○	
1999	GMC truck	Envoy - 4WD	Body control module	●	●	○	●	●	○	
1999	GMC truck	Envoy - 4WD	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	Envoy - 4WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	GMC truck	Envoy - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	GMC C pickup - 2WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	GMC C pickup - 2WD	Passlock	●	●	○	●	●	○	
1999	GMC truck	GMC C pickup - 2WD	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	GMC C pickup - 2WD	Onstar (VS-3B)	●	●	○	●	○	○	
1999	GMC truck	GMC C pickup - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1999	GMC truck	GMC C pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	GMC C pickup - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
1999	GMC truck	GMC C pickup - 2WD (CNG)	Passlock	●	●	○	●	●	○	
1999	GMC truck	GMC C pickup - 2WD (CNG)	Onstar	●	●	○	●	○	●	T191

1999	GMC truck	GMC C pickup - 2WD (CNG)	Onstar (VS-3B)	●	●	○	●	○	○	
1999	GMC truck	GMC C pickup - 2WD (CNG)	Electronic variable orifice	●	●	○	●	○	○	
1999	GMC truck	GMC C pickup - 2WD (CNG)	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	GMC c-series - 2WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	GMC c-series - 2WD	Passlock	●	●	○	●	●	○	
1999	GMC truck	GMC c-series - 2WD	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	GMC c-series - 2WD	Onstar (VS-3B)	●	●	○	●	○	○	
1999	GMC truck	GMC c-series - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1999	GMC truck	GMC c-series - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	GMC K pickup - 4WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	GMC K pickup - 4WD	Passlock	●	●	○	●	●	○	
1999	GMC truck	GMC K pickup - 4WD	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	GMC K pickup - 4WD	Onstar (VS-3B)	●	●	○	●	○	○	
1999	GMC truck	GMC K pickup - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1999	GMC truck	GMC K pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	GMC K pickup - 4WD (CNG)	Powertrain	●	●	●	●	●	○	
1999	GMC truck	GMC K pickup - 4WD (CNG)	Passlock	●	●	○	●	●	○	

1999	GMC truck	GMC K pickup - 4WD (CNG)	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	GMC K pickup - 4WD (CNG)	Onstar (VS-3B)	●	●	○	●	○	○	
1999	GMC truck	GMC K pickup - 4WD (CNG)	Electronic variable orifice	●	●	○	●	○	○	
1999	GMC truck	GMC K pickup - 4WD (CNG)	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	GMC K sierra - 4WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	GMC K sierra - 4WD	Passlock	●	●	○	●	●	○	
1999	GMC truck	GMC K sierra - 4WD	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	GMC K sierra - 4WD	Onstar (VS-3B)	●	●	○	●	○	○	
1999	GMC truck	GMC K sierra - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1999	GMC truck	GMC K sierra - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	GMC suburban - 2WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	GMC suburban - 2WD	Passlock	●	●	○	●	●	○	
1999	GMC truck	GMC suburban - 2WD	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	GMC suburban - 2WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	GMC truck	GMC suburban - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1999	GMC truck	GMC suburban - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	GMC suburban - 4WD	Powertrain	●	●	●	●	●	○	

1999	GMC truck	GMC suburban - 4WD	Passlock	●	●	○	●	●	○	
1999	GMC truck	GMC suburban - 4WD	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	GMC suburban - 4WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	GMC truck	GMC suburban - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1999	GMC truck	GMC suburban - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	Jimmy - 2WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	Jimmy - 2WD	Heating and air conditioning	●	●	○	●	●	○	
1999	GMC truck	Jimmy - 2WD	Body control module	●	●	○	●	●	○	
1999	GMC truck	Jimmy - 2WD	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	Jimmy - 2WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	GMC truck	Jimmy - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	Jimmy - 4WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	Jimmy - 4WD	Heating and air conditioning	●	●	○	●	●	○	
1999	GMC truck	Jimmy - 4WD	Body control module	●	●	○	●	●	○	
1999	GMC truck	Jimmy - 4WD	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	Jimmy - 4WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	GMC truck	Jimmy - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	Safari - 2WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	Safari - 2WD	Passlock	●	●	○	●	●	○	
1999	GMC truck	Safari - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	Safari - 4WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	Safari - 4WD	Passlock	●	●	○	●	●	○	
1999	GMC truck	Safari - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	Savana - 2WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	Savana - 2WD	Passlock	●	●	○	●	●	○	
1999	GMC truck	Savana - 2WD	Immobilizer	●	●	○	●	●	●	T214 T215 T216 T217 T218

1999	GMC truck	Sonoma pickup - 2WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	Sonoma pickup - 2WD	Heating and air conditioning	●	●	○	●	●	○	
1999	GMC truck	Sonoma pickup - 2WD	Body control module	●	●	○	●	●	○	
1999	GMC truck	Sonoma pickup - 2WD	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	Sonoma pickup - 2WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	GMC truck	Sonoma pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	Sonoma pickup - 4WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	Sonoma pickup - 4WD	Heating and air conditioning	●	●	○	●	●	○	
1999	GMC truck	Sonoma pickup - 4WD	Body control module	●	●	○	●	●	○	
1999	GMC truck	Sonoma pickup - 4WD	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	Sonoma pickup - 4WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	GMC truck	Sonoma pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	Yukon - 2WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	Yukon - 2WD	Passlock	●	●	○	●	●	○	
1999	GMC truck	Yukon - 2WD	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	Yukon - 2WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	GMC truck	Yukon - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1999	GMC truck	Yukon - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	GMC truck	Yukon - 4WD	Powertrain	●	●	●	●	●	○	
1999	GMC truck	Yukon - 4WD	Passlock	●	●	○	●	●	○	
1999	GMC truck	Yukon - 4WD	Onstar	●	●	○	●	○	●	T191
1999	GMC truck	Yukon - 4WD	Onstar (VS-3B)	●	●	○	●	●	●	T191

1999	GMC truck	Yukon - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1999	GMC truck	Yukon - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Isuzu	S/T isuzu - 2WD	Powertrain	●	●	●	●	●	○	
1999	Isuzu	S/T isuzu - 2WD	Heating and air conditioning	●	●	○	●	●	○	
1999	Isuzu	S/T isuzu - 2WD	Body control module	●	●	○	●	●	○	
1999	Isuzu	S/T isuzu - 2WD	Onstar	●	●	○	●	○	●	T191
1999	Isuzu	S/T isuzu - 2WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	Isuzu	S/T isuzu - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Isuzu	S/T isuzu - 4WD	Powertrain	●	●	●	●	●	○	
1999	Isuzu	S/T isuzu - 4WD	Heating and air conditioning	●	●	○	●	●	○	
1999	Isuzu	S/T isuzu - 4WD	Body control module	●	●	○	●	●	○	
1999	Isuzu	S/T isuzu - 4WD	Onstar	●	●	○	●	○	●	T191
1999	Isuzu	S/T isuzu - 4WD	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	Isuzu	S/T isuzu - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1999	Oldsmobile	Bravada	Powertrain	●	●	●	●	●	○	
1999	Oldsmobile	Bravada	Heating and air conditioning	●	●	○	●	●	○	
1999	Oldsmobile	Bravada	Body control module	●	●	○	●	●	○	
1999	Oldsmobile	Bravada	Onstar	●	●	○	●	○	●	T191
1999	Oldsmobile	Bravada	Onstar (VS-3B)	●	●	○	●	●	●	T191
1999	Oldsmobile	Bravada	4WAL 3 sensor	●	●	○	●	●	○	
1999	Oldsmobile	Silhouette	Powertrain	●	●	●	●	●	●	T001
1999	Oldsmobile	Silhouette	Entertainment & comfort bus	●	●	○	●	○	○	
1999	Oldsmobile	Silhouette	Onstar	●	●	○	●	○	●	T191
1999	Oldsmobile	Silhouette	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Oldsmobile	Silhouette ext.	Powertrain	●	●	●	●	●	●	T001
1999	Oldsmobile	Silhouette ext.	Entertainment & comfort bus	●	●	○	●	○	○	
1999	Oldsmobile	Silhouette ext.	Onstar	●	●	○	●	○	●	T191
1999	Oldsmobile	Silhouette ext.	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Pontiac	Montana	Powertrain	●	●	●	●	●	●	T001

1999	Pontiac	Montana	Entertainment & comfort bus	●	●	○	●	○	○	
1999	Pontiac	Montana	Onstar	●	●	○	●	○	●	T191
1999	Pontiac	Montana	Onstar (VS-3B)	●	●	○	●	○	○	
1999	Pontiac	Montana ext.	Powertrain	●	●	●	●	●	●	T001
1999	Pontiac	Montana ext.	Entertainment & comfort bus	●	●	○	●	○	○	
1999	Pontiac	Montana ext.	Onstar	●	●	○	●	○	●	T191
1999	Pontiac	Montana ext.	Onstar (VS-3B)	●	●	○	●	○	○	
1998	Buick	Century	Powertrain	●	●	●	●	●	●	T001
1998	Buick	Century	Body control module	●	●	○	●	●	●	T122 T170 T198
1998	Buick	Century	Onstar	●	●	○	●	○	●	T191
1998	Buick	Century	Chassis	●	●	○	○	●	○	
1998	Buick	Lesabre	Powertrain	●	●	●	●	●	●	T001
1998	Buick	Lesabre	Body control module	●	●	○	●	●	●	T122 T176 T058 T192 T058 T039 T200
1998	Buick	Lesabre	Onstar	●	●	○	●	○	●	T191
1998	Buick	Lesabre	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1998	Buick	Lesabre	Entertainment & comfort bus	●	●	○	●	●	●	T191
1998	Buick	Lesabre	ABS	●	●	○	○	●	●	T149 T014
1998	Buick	Park avenue	Powertrain	●	●	●	●	●	●	T001
1998	Buick	Park avenue	Body control module	●	●	○	●	●	●	T122 T176 T058 T192 T058 T039 T200
1998	Buick	Park avenue	Onstar	●	●	○	●	○	●	T191
1998	Buick	Park avenue	ABS	●	●	○	○	●	●	T149 T014
1998	Buick	Regal	Powertrain	●	●	●	●	●	●	T001
1998	Buick	Regal	Body control module	●	●	○	●	●	●	T122 T170 T198
1998	Buick	Regal	Onstar	●	●	○	●	○	●	T191
1998	Buick	Regal	Chassis	●	●	○	○	●	○	
1998	Buick	Riviera	Powertrain	●	●	●	●	●	●	T001
1998	Buick	Riviera	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1998	Buick	Riviera	Onstar	●	●	○	●	○	●	T191

1998	Buick	Skylark	Powertrain	●	●	●	●	●	●	T001
1998	Buick	Skylark	Chassis	●	●	○	●	●	○	
1998	Cadillac	Catera	Powertrain	●	●	●	●	●	○	
1998	Cadillac	Catera	Remote function actuator	●	●	○	●	○	○	
1998	Cadillac	Catera	Body control module	●	●	○	●	●	●	T219 T136
1998	Cadillac	Catera	Radio	●	●	○	●	●	●	T033
1998	Cadillac	Catera	Immobilizer	○	○	○	○	●	○	
1998	Cadillac	Catera	Cellular telephone	●	●	○	●	○	●	T192
1998	Cadillac	Catera	Onstar	●	●	○	●	○	●	T191
1998	Cadillac	Catera	ABS	●	●	○	●	●	○	
1998	Cadillac	Deville	Powertrain	●	●	●	●	●	●	T232 T231
1998	Cadillac	Deville	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190
1998	Cadillac	Deville	Radio	●	●	○	●	●	●	T210 T033
1998	Cadillac	Deville	Onstar	●	●	○	●	○	●	T191
1998	Cadillac	Deville	Cellular telephone	●	●	○	●	●	●	T205 T206 T207 T208 T209 T190
1998	Cadillac	Deville	ABS/TCS BLW ICCS2	●	●	○	○	●	●	T149 T014
1998	Cadillac	Eldorado	Powertrain	●	●	●	●	●	●	T232 T231
1998	Cadillac	Eldorado	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190
1998	Cadillac	Eldorado	Radio	●	●	○	●	●	●	T210 T033
1998	Cadillac	Eldorado	Onstar	●	●	○	●	○	●	T191
1998	Cadillac	Seville	Powertrain	●	●	●	●	●	●	T231
1998	Cadillac	Seville	Cellular telephone	●	●	○	○	○	○	
1998	Cadillac	Seville	Amplifier (bose)	●	●	○	●	●	●	T122 T172 T123 T125 T194 T195 T112 T193 T136 T159 T233 T094 T179 T179 T095 T033 T112 T234 T199 T200
1998	Cadillac	Seville	Memory seat module	●	●	○	●	●	○	
1998	Cadillac	Seville	Remote function actuation	●	●	○	●	○	●	T235
1998	Cadillac	Seville	Onstar	●	●	○	●	●	●	T191

1998	Cadillac	Seville	ABS/TCS BLW ICCS2	●	●	○	○	●	●	T149 T014
1998	Chevrolet	Camaro	Powertrain	●	●	●	●	●	●	T001
1998	Chevrolet	Cavalier	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	Corvette	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	Corvette	Body control module	●	●	○	●	●	●	T196
1998	Chevrolet	Corvette	Abs/tcs/magna steer	●	●	●	●	●	○	
1998	Chevrolet	Corvette	CVRTD	●	●	●	●	●	○	
1998	Chevrolet	Lumina	Powertrain	●	●	●	●	●	●	T001
1998	Chevrolet	Lumina	Onstar	●	●	○	●	○	●	T191
1998	Chevrolet	Malibu	Powertrain	●	●	●	●	●	●	T001
1998	Chevrolet	Malibu	Body function controller	●	●	○	●	●	○	
1998	Chevrolet	Malibu	Chassis	●	●	○	●	●	○	
1998	Chevrolet	Monte carlo	Powertrain	●	●	●	●	●	●	T001
1998	Chevrolet	Monte carlo	Onstar	●	●	○	●	○	●	T191
1998	Chevrolet	Prizm	Supplemental inflatable restraint	●	●	○	○	○	○	
1998	Oldsmobile	Achieva	Powertrain	●	●	●	●	●	●	T001
1998	Oldsmobile	Achieva	Chassis	●	●	○	●	●	○	
1998	Oldsmobile	Aurora	Powertrain	●	●	●	●	●	●	T232 T231
1998	Oldsmobile	Aurora	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1998	Oldsmobile	Aurora	Onstar	●	●	○	●	○	●	T191
1998	Oldsmobile	Cutlass	Powertrain	●	●	●	●	●	●	T001
1998	Oldsmobile	Cutlass	Body function controller	●	●	○	●	●	○	
1998	Oldsmobile	Cutlass	Chassis	●	●	○	●	●	○	
1998	Oldsmobile	Eighty eight	Powertrain	●	●	●	●	●	●	T001
1998	Oldsmobile	Eighty eight	Body control module	●	●	○	●	●	●	T122 T176 T058 T192 T058 T039 T200
1998	Oldsmobile	Eighty eight	Onstar	●	●	○	●	○	●	T191
1998	Oldsmobile	Eighty eight	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1998	Oldsmobile	Eighty eight	ABS	●	●	○	○	●	●	T149 T014
1998	Oldsmobile	Intrigue	Powertrain	●	●	●	●	●	●	T001

1998	Oldsmobile	Intrigue	Body control module	●	●	○	●	●	●	T170 T198
1998	Oldsmobile	Intrigue	Chassis	○	○	○	○	●	○	
1998	Oldsmobile	LSS	Powertrain	●	●	●	●	●	●	T001
1998	Oldsmobile	LSS	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1998	Oldsmobile	LSS	Body control module	●	●	○	●	●	●	T122 T176 T058 T192 T058 T039 T200
1998	Oldsmobile	LSS	Onstar	●	●	○	●	○	●	T191
1998	Oldsmobile	LSS	ABS	●	●	○	○	●	●	T149 T014
1998	Pontiac	Bonneville	Powertrain	●	●	●	●	●	●	T001
1998	Pontiac	Bonneville	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1998	Pontiac	Bonneville	Onstar	●	●	○	●	○	●	T191
1998	Pontiac	Bonneville	Body control module	●	●	○	●	●	●	T122 T176 T058 T192 T058 T039 T200
1998	Pontiac	Bonneville	ABS	●	●	○	○	●	●	T149 T014
1998	Pontiac	Firebird	Powertrain	●	●	●	●	●	●	T001
1998	Pontiac	Grand am	Powertrain	●	●	●	●	●	●	T001
1998	Pontiac	Grand am	Chassis	●	●	○	●	●	○	
1998	Pontiac	Grand prix	Powertrain	●	●	●	●	●	●	T001
1998	Pontiac	Sunfire	Powertrain	●	●	●	●	●	○	
1998	Cadillac	Hearse	Powertrain	●	●	●	●	●	●	T001
1998	Cadillac	Hearse	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190
1998	Cadillac	Hearse	Radio	○	○	○	○	○	●	T210
1998	Cadillac	Hearse	Delco/Xtool ABS/TCS	●	●	○	○	●	●	T149 T014
1998	Cadillac	Limousine	Powertrain	●	●	●	●	●	●	T001
1998	Cadillac	Limousine	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190
1998	Cadillac	Limousine	Radio	○	○	○	○	○	●	T210
1998	Cadillac	Limousine	Delco/Xtool ABS/TCS	●	●	○	○	●	●	T149 T014
1998	Chevrolet	Astro - 2WD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	Astro - 2WD	Passlock	●	●	○	●	●	○	
1998	Chevrolet	Astro - 2WD	Electronic variable orifice	●	●	○	●	○	○	

1998	Chevrolet	Astro - 4WD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	Astro - 4WD	Passlock	●	●	○	●	●	○	
1998	Chevrolet	Astro - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1998	Chevrolet	Blazer - 2WD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	Blazer - 2WD	Heating and air conditioning	●	●	○	●	●	○	
1998	Chevrolet	Blazer - 2WD	Body control module	●	●	○	●	●	○	
1998	Chevrolet	Blazer - 2WD	Onstar	●	●	○	●	●	●	T191
1998	Chevrolet	Blazer - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	Blazer - 4WD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	Blazer - 4WD	Heating and air conditioning	●	●	○	●	●	○	
1998	Chevrolet	Blazer - 4WD	Body control module	●	●	○	●	●	○	
1998	Chevrolet	Blazer - 4WD	Onstar	●	●	○	●	●	●	T191
1998	Chevrolet	Blazer - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	C pickup - 2WD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	C pickup - 2WD	Passlock	●	●	○	●	●	○	
1998	Chevrolet	C pickup - 2WD	Onstar	●	●	○	●	○	●	T191
1998	Chevrolet	C pickup - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1998	Chevrolet	C pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	C pickup - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	C pickup - 2WD (CNG)	Passlock	●	●	○	●	●	○	
1998	Chevrolet	C pickup - 2WD (CNG)	Onstar	●	●	○	●	○	●	T191
1998	Chevrolet	C pickup - 2WD (CNG)	Electronic variable orifice	●	●	○	●	○	○	
1998	Chevrolet	C pickup - 2WD (CNG)	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	Express - 2WD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	Express - 2WD	Passlock	●	●	○	●	●	○	

1998	Chevrolet	Express - 2WD	Immobilizer	●	●	○	●	●	●	T214 T215 T216 T217 T218
1998	Chevrolet	Express - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1998	Chevrolet	K pickup - 4WD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	K pickup - 4WD	Passlock	●	●	○	●	●	○	
1998	Chevrolet	K pickup - 4WD	Onstar	●	●	○	●	○	●	T191
1998	Chevrolet	K pickup - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1998	Chevrolet	K pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	S10 pickup - 2WD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	S10 pickup - 2WD	Heating and air conditioning	●	●	○	●	●	○	
1998	Chevrolet	S10 pickup - 2WD	Body control module	●	●	○	●	●	○	
1998	Chevrolet	S10 pickup - 2WD	Onstar	●	●	○	●	●	●	T191
1998	Chevrolet	S10 pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	S10 pickup - 4WD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	S10 pickup - 4WD	Heating and air conditioning	●	●	○	●	●	○	
1998	Chevrolet	S10 pickup - 4WD	Body control module	●	●	○	●	●	○	
1998	Chevrolet	S10 pickup - 4WD	Onstar	●	●	○	●	●	●	T191
1998	Chevrolet	S10 pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	Suburban - 2WD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	Suburban - 2WD	Passlock	●	●	○	●	●	○	
1998	Chevrolet	Suburban - 2WD	Onstar	●	●	○	●	●	●	T191
1998	Chevrolet	Suburban - 2WD	Electronic variable orifice	●	●	○	●	○	○	

1998	Chevrolet	Suburban - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	Suburban - 4WD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	Suburban - 4WD	Passlock	●	●	○	●	●	○	
1998	Chevrolet	Suburban - 4WD	Onstar	●	●	○	●	●	●	T191
1998	Chevrolet	Suburban - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1998	Chevrolet	Suburban - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	Suburban 4WD - RHD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	Suburban 4WD - RHD	Passlock	●	●	○	●	●	○	
1998	Chevrolet	Suburban 4WD - RHD	Onstar	●	●	○	●	○	●	T191
1998	Chevrolet	Suburban 4WD - RHD	Electronic variable orifice	●	●	○	●	○	○	
1998	Chevrolet	Suburban 4WD - RHD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	Tahoe - 2WD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	Tahoe - 2WD	Passlock	●	●	○	●	●	○	
1998	Chevrolet	Tahoe - 2WD	Onstar	●	●	○	●	●	●	T191
1998	Chevrolet	Tahoe - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1998	Chevrolet	Tahoe - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	Tahoe - 4WD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	Tahoe - 4WD	Passlock	●	●	○	●	●	○	
1998	Chevrolet	Tahoe - 4WD	Onstar	●	●	○	●	●	●	T191
1998	Chevrolet	Tahoe - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1998	Chevrolet	Tahoe - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	Tahoe 4WD - RHD	Powertrain	●	●	●	●	●	○	
1998	Chevrolet	Tahoe 4WD - RHD	Passlock	●	●	○	●	●	○	
1998	Chevrolet	Tahoe 4WD - RHD	Onstar	●	●	○	●	○	●	T191
1998	Chevrolet	Tahoe 4WD - RHD	Electronic variable orifice	●	●	○	●	○	○	
1998	Chevrolet	Tahoe 4WD - RHD	4WAL 3 sensor	●	●	○	●	●	○	

1998	Chevrolet	Tracker - 2WD	Supplemental inflatable restraint	●	●	○	○	○	○	
1998	Chevrolet	Tracker - 2WD	Body control module	●	●	○	●	●	○	
1998	Chevrolet	Tracker - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	Tracker - 4WD	Supplemental inflatable restraint	●	●	○	○	○	○	
1998	Chevrolet	Tracker - 4WD	Body control module	●	●	○	●	●	○	
1998	Chevrolet	Tracker - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Chevrolet	Trans port (export)	Powertrain	●	●	●	●	●	●	T001
1998	Chevrolet	Trans port (export)	Onstar	●	●	○	●	○	●	T191
1998	Chevrolet	Venture	Powertrain	●	●	●	●	●	●	T001
1998	Chevrolet	Venture	Onstar	●	●	○	●	○	●	T191
1998	Chevrolet	Venture ext.	Powertrain	●	●	●	●	●	●	T001
1998	Chevrolet	Venture ext.	Onstar	●	●	○	●	○	●	T191
1998	GMC truck	GMC C pickup - 2WD	Powertrain	●	●	●	●	●	○	
1998	GMC truck	GMC C pickup - 2WD	Passlock	●	●	○	●	●	○	
1998	GMC truck	GMC C pickup - 2WD	Onstar	●	●	○	●	●	●	T191
1998	GMC truck	GMC C pickup - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1998	GMC truck	GMC C pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	GMC truck	GMC C pickup - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
1998	GMC truck	GMC C pickup - 2WD (CNG)	Passlock	●	●	○	●	●	○	
1998	GMC truck	GMC C pickup - 2WD (CNG)	Onstar	●	●	○	●	○	●	T191
1998	GMC truck	GMC C pickup - 2WD (CNG)	Electronic variable orifice	●	●	○	●	○	○	

1998	GMC truck	GMC C pickup - 2WD (CNG)	4WAL 3 sensor	●	●	○	●	●	○	
1998	GMC truck	GMC K pickup - 4WD	Powertrain	●	●	●	●	●	○	
1998	GMC truck	GMC K pickup - 4WD	Passlock	●	●	○	●	●	○	
1998	GMC truck	GMC K pickup - 4WD	Onstar	●	●	○	●	○	●	T191
1998	GMC truck	GMC K pickup - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1998	GMC truck	GMC K pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	GMC truck	GMC suburban - 2WD	Powertrain	●	●	●	●	●	○	
1998	GMC truck	GMC suburban - 2WD	Passlock	●	●	○	●	●	○	
1998	GMC truck	GMC suburban - 2WD	Onstar	●	●	○	●	●	●	T191
1998	GMC truck	GMC suburban - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1998	GMC truck	GMC suburban - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	GMC truck	GMC suburban - 4WD	Powertrain	●	●	●	●	●	○	
1998	GMC truck	GMC suburban - 4WD	Passlock	●	●	○	●	●	○	
1998	GMC truck	GMC suburban - 4WD	Onstar	●	●	○	●	●	●	T191
1998	GMC truck	GMC suburban - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1998	GMC truck	GMC suburban - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	GMC truck	Jimmy - 2WD	Powertrain	●	●	●	●	●	○	
1998	GMC truck	Jimmy - 2WD	Heating and air conditioning	●	●	○	●	●	○	

1998	GMC truck	Jimmy - 2WD	Body control module	●	●	○	●	●	○	
1998	GMC truck	Jimmy - 2WD	Onstar	●	●	○	●	●	●	T191
1998	GMC truck	Jimmy - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	GMC truck	Jimmy - 4WD	Powertrain	●	●	●	●	●	○	
1998	GMC truck	Jimmy - 4WD	Heating and air conditioning	●	●	○	●	●	○	
1998	GMC truck	Jimmy - 4WD	Body control module	●	●	○	●	●	○	
1998	GMC truck	Jimmy - 4WD	Onstar	●	●	○	●	●	●	T191
1998	GMC truck	Jimmy - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	GMC truck	Safari - 2WD	Powertrain	●	●	●	●	●	○	
1998	GMC truck	Safari - 2WD	Passlock	●	●	○	●	●	○	
1998	GMC truck	Safari - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1998	GMC truck	Safari - 4WD	Powertrain	●	●	●	●	●	○	
1998	GMC truck	Safari - 4WD	Passlock	●	●	○	●	●	○	
1998	GMC truck	Safari - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1998	GMC truck	Savana - 2WD	Powertrain	●	●	●	●	●	○	
1998	GMC truck	Savana - 2WD	Passlock	●	●	○	●	●	○	
1998	GMC truck	Savana - 2WD	Immobilizer	●	●	○	●	●	●	T214 T215 T216 T217 T218
1998	GMC truck	Savana - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1998	GMC truck	Sonoma pickup - 2WD	Powertrain	●	●	●	●	●	○	
1998	GMC truck	Sonoma pickup - 2WD	Heating and air conditioning	●	●	○	●	●	○	
1998	GMC truck	Sonoma pickup - 2WD	Body control module	●	●	○	●	●	○	
1998	GMC truck	Sonoma pickup - 2WD	Onstar	●	●	○	●	●	●	T191
1998	GMC truck	Sonoma pickup - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	GMC truck	Sonoma pickup - 4WD	Powertrain	●	●	●	●	●	○	

1998	GMC truck	Sonoma pickup - 4WD	Heating and air conditioning	●	●	○	●	●	○	
1998	GMC truck	Sonoma pickup - 4WD	Body control module	●	●	○	●	●	○	
1998	GMC truck	Sonoma pickup - 4WD	Onstar	●	●	○	●	●	●	T191
1998	GMC truck	Sonoma pickup - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	GMC truck	Yukon - 2WD	Powertrain	●	●	●	●	●	○	
1998	GMC truck	Yukon - 2WD	Passlock	●	●	○	●	●	○	
1998	GMC truck	Yukon - 2WD	Onstar	●	●	○	●	●	●	T191
1998	GMC truck	Yukon - 2WD	Electronic variable orifice	●	●	○	●	○	○	
1998	GMC truck	Yukon - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	GMC truck	Yukon - 4WD	Powertrain	●	●	●	●	●	○	
1998	GMC truck	Yukon - 4WD	Passlock	●	●	○	●	●	○	
1998	GMC truck	Yukon - 4WD	Onstar	●	●	○	●	●	●	T191
1998	GMC truck	Yukon - 4WD	Electronic variable orifice	●	●	○	●	○	○	
1998	GMC truck	Yukon - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Isuzu	S/T isuzu - 2WD	Powertrain	●	●	●	●	●	○	
1998	Isuzu	S/T isuzu - 2WD	Heating and air conditioning	●	●	○	●	●	○	
1998	Isuzu	S/T isuzu - 2WD	Body control module	●	●	○	●	●	○	
1998	Isuzu	S/T isuzu - 2WD	Onstar	●	●	○	●	●	●	T191
1998	Isuzu	S/T isuzu - 2WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Isuzu	S/T isuzu - 4WD	Powertrain	●	●	●	●	●	○	
1998	Isuzu	S/T isuzu - 4WD	Heating and air conditioning	●	●	○	●	●	○	
1998	Isuzu	S/T isuzu - 4WD	Body control module	●	●	○	●	●	○	
1998	Isuzu	S/T isuzu - 4WD	Onstar	●	●	○	●	●	●	T191
1998	Isuzu	S/T isuzu - 4WD	4WAL 3 sensor	●	●	○	●	●	○	
1998	Oldsmobile	Bravada	Powertrain	●	●	●	●	●	○	
1998	Oldsmobile	Bravada	Heating and air conditioning	●	●	○	●	●	○	

1998	Oldsmobile	Bravada	Body control module	●	●	○	●	●	○	
1998	Oldsmobile	Bravada	Onstar	●	●	○	●	●	●	T191
1998	Oldsmobile	Bravada	4WAL 3 sensor	●	●	○	●	●	○	
1998	Oldsmobile	Silhouette	Powertrain	●	●	●	●	●	●	T001
1998	Oldsmobile	Silhouette	Onstar	●	●	○	●	○	●	T191
1998	Oldsmobile	Silhouette ext.	Powertrain	●	●	●	●	●	●	T001
1998	Oldsmobile	Silhouette ext.	Onstar	●	●	○	●	○	●	T191
1998	Pontiac	Sun runner - 2WD (canada)	Powertrain	●	●	●	●	●	●	T001
1998	Pontiac	Sun runner - 2WD (canada)	Supplemental inflatable restraint	●	●	○	○	○	○	
1998	Pontiac	Sun runner - 2WD (canada)	Body control module	●	●	○	●	●	○	
1998	Pontiac	Sun runner - 2WD (canada)	4WAL 3 sensor	●	●	○	●	●	○	
1998	Pontiac	Sun runner - 4WD (canada)	Powertrain	●	●	●	●	●	●	T001
1998	Pontiac	Sun runner - 4WD (canada)	Supplemental inflatable restraint	●	●	○	○	○	○	
1998	Pontiac	Sun runner - 4WD (canada)	Body control module	●	●	○	●	●	○	
1998	Pontiac	Sun runner - 4WD (canada)	4WAL 3 sensor	●	●	○	●	●	○	
1998	Pontiac	Trans sport	Powertrain	●	●	●	●	●	●	T001
1998	Pontiac	Trans sport	Onstar	●	●	○	●	○	●	T191
1998	Pontiac	Trans sport ext.	Powertrain	●	●	●	●	●	●	T001
1998	Pontiac	Trans sport ext.	Onstar	●	●	○	●	○	●	T191
1997	Buick	Century	Powertrain	●	●	●	●	●	●	T001
1997	Buick	Century	Body control module	●	●	○	●	●	●	T122 T170 T198
1997	Buick	Lesabre	Powertrain	●	●	●	●	●	●	T001
1997	Buick	Lesabre	Body control module	●	●	○	●	●	●	T122 T176 T058 T192 T058 T039 T200

1997	Buick	Lesabre	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1997	Buick	Lesabre	ABS	●	●	○	○	●	●	T149 T014
1997	Buick	Park avenue	Powertrain	●	●	●	●	●	●	T001
1997	Buick	Park avenue	Body control module	●	●	○	●	●	●	T122 T176 T058 T192 T058 T039 T200
1997	Buick	Park avenue	ABS	●	●	○	○	●	●	T149 T014
1997	Buick	Regal	Powertrain	●	●	●	●	●	●	T001
1997	Buick	Regal	Body control module	●	●	○	●	●	●	T122 T170 T198
1997	Buick	Riviera	Powertrain	●	●	●	●	●	●	T001
1997	Buick	Riviera	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1997	Buick	Skylark	Powertrain	●	●	●	●	●	●	T001
1997	Cadillac	Concours	Powertrain	●	●	●	●	●	●	T231
1997	Cadillac	Concours	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190
1997	Cadillac	Concours	Radio	○	○	○	●	○	○	
1997	Cadillac	Concours	Cellular telephone	●	●	○	●	●	●	T210
1997	Cadillac	Concours	Magna steer	●	●	○	○	○	○	
1997	Cadillac	Concours	ABS	●	●	○	○	●	●	T149 T014
1997	Cadillac	Deville	Powertrain	●	●	●	●	●	●	T231
1997	Cadillac	Deville	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190
1997	Cadillac	Deville	Radio	○	○	○	●	○	○	
1997	Cadillac	Deville	Cellular telephone	●	●	○	●	●	●	T210
1997	Cadillac	Deville	Magna steer	●	●	○	○	○	○	
1997	Cadillac	Deville	ABS	●	●	○	○	●	●	T149 T014
1997	Cadillac	Eldorado	Powertrain	●	●	●	●	●	●	T231
1997	Cadillac	Eldorado	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190
1997	Cadillac	Eldorado	Radio	○	○	○	●	○	○	
1997	Cadillac	Eldorado	Cellular telephone	●	●	○	●	●	●	T210
1997	Cadillac	Eldorado	Magna steer	●	●	○	○	○	○	
1997	Cadillac	Eldorado	ABS	●	●	○	○	●	●	T149 T014
1997	Cadillac	Seville	Powertrain	●	●	●	●	●	●	T231

1997	Cadillac	Seville	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190
1997	Cadillac	Seville	Radio	○	○	○	●	○	○	
1997	Cadillac	Seville	Cellular telephone	●	●	○	●	●	●	T210
1997	Cadillac	Seville	Magna steer	●	●	○	○	○	○	
1997	Cadillac	Seville	ABS	●	●	○	○	●	●	T149 T014
1997	Chevrolet	Camaro	Powertrain	●	●	●	●	●	●	T001
1997	Chevrolet	Cavalier	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	Corvette	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	Corvette	Body control module	●	●	○	●	●	●	T196 T108
1997	Chevrolet	Corvette	Abs/tcs/magna steer	●	●	●	●	●	●	T149
1997	Chevrolet	Lumina	Powertrain	●	●	●	●	●	●	T001
1997	Chevrolet	Malibu	Powertrain	●	●	●	●	●	●	T001
1997	Chevrolet	Malibu	Body function controller	●	●	○	●	●	○	
1997	Chevrolet	Monte carlo	Powertrain	●	●	●	●	●	●	T001
1997	Oldsmobile	Achieva	Powertrain	●	●	●	●	●	●	T001
1997	Oldsmobile	Aurora	Powertrain	●	●	●	●	●	●	T232 T231
1997	Oldsmobile	Aurora	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1997	Oldsmobile	Cutlass	Powertrain	●	●	●	●	●	●	T001
1997	Oldsmobile	Cutlass	Body function controller	●	●	○	●	●	○	
1997	Oldsmobile	Cutlass supreme	Powertrain	●	●	●	●	●	●	T001
1997	Oldsmobile	Eighty eight	Powertrain	●	●	●	●	●	●	T001
1997	Oldsmobile	Eighty eight	Body control module	●	●	○	●	●	●	T122 T176 T058 T192 T058 T039 T200
1997	Oldsmobile	Eighty eight	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1997	Oldsmobile	Eighty eight	ABS	●	●	○	○	●	●	T149 T014
1997	Pontiac	Bonneville	Powertrain	●	●	●	●	●	●	T001
1997	Pontiac	Bonneville	Body control module	●	●	○	●	●	●	T122 T176 T058 T192 T058 T039 T200
1997	Pontiac	Bonneville	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230

1997	Pontiac	Bonneville	ABS	●	●	○	○	●	●	T149 T014
1997	Pontiac	Firebird	Powertrain	●	●	●	●	●	●	T001
1997	Pontiac	Grand am	Powertrain	●	●	●	●	●	●	T001
1997	Pontiac	Grand prix	Powertrain	●	●	●	●	●	●	T001
1997	Pontiac	Sunfire	Powertrain	●	●	●	●	●	○	
1997	Cadillac	Hearse	Powertrain	●	●	●	●	●	●	T001
1997	Cadillac	Hearse	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190 T210
1997	Cadillac	Hearse	Radio	○	○	○	●	●	○	
1997	Cadillac	Hearse	Delco/Xtool ABS/TCS	●	●	○	○	●	●	T149 T014
1997	Cadillac	Limousine	Powertrain	●	●	●	●	●	●	T001
1997	Cadillac	Limousine	Body control module	●	●	○	●	●	●	T192 T205 T206 T207 T208 T209 T190 T210
1997	Cadillac	Limousine	Radio	○	○	○	●	●	○	
1997	Cadillac	Limousine	Delco/Xtool ABS/TCS	●	●	○	○	●	●	T149 T014
1997	Chevrolet	Astro - 2WD	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	Astro - 2WD	Electronic variable orifice	●	●	○	●	●	○	
1997	Chevrolet	Astro - 4WD	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	Astro - 4WD	Electronic variable orifice	●	●	○	●	●	○	
1997	Chevrolet	Blazer - 2WD	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	Blazer - 4WD	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	C pickup - 2WD	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	C pickup - 2WD	Electronic variable orifice	●	●	○	●	●	○	
1997	Chevrolet	C pickup - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	C pickup - 2WD (CNG)	Electronic variable orifice	●	●	○	●	●	○	
1997	Chevrolet	Export express	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	Export express	Electronic variable orifice	●	●	○	●	●	○	
1997	Chevrolet	Express - 2WD	Powertrain	●	●	●	●	●	○	

1997	Chevrolet	Express - 2WD	Electronic variable orifice	●	●	○	●	●	○	
1997	Chevrolet	K pickup - 4WD	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	K pickup - 4WD	Electronic variable orifice	●	●	○	●	●	○	
1997	Chevrolet	S10 pickup - 2WD	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	S10 pickup - 4WD	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	Suburban - 2WD	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	Suburban - 2WD	Electronic variable orifice	●	●	○	●	●	○	
1997	Chevrolet	Suburban - 4WD	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	Suburban - 4WD	Electronic variable orifice	●	●	○	●	●	○	
1997	Chevrolet	Tahoe - 2WD	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	Tahoe - 2WD	Electronic variable orifice	●	●	○	●	●	○	
1997	Chevrolet	Tahoe - 4WD	Powertrain	●	●	●	●	●	○	
1997	Chevrolet	Tahoe - 4WD	Electronic variable orifice	●	●	○	●	●	○	
1997	Chevrolet	Venture	Powertrain	●	●	●	●	●	●	T001
1997	Chevrolet	Venture ext.	Powertrain	●	●	●	●	●	●	T001
1997	GMC truck	Export savana	Powertrain	●	●	●	●	●	○	
1997	GMC truck	Export savana	Electronic variable orifice	●	●	○	●	●	○	
1997	GMC truck	GMC C pickup - 2WD	Powertrain	●	●	●	●	●	○	
1997	GMC truck	GMC C pickup - 2WD	Electronic variable orifice	●	●	○	●	●	○	
1997	GMC truck	GMC C pickup - 2WD (CNG)	Powertrain	●	●	●	●	●	○	
1997	GMC truck	GMC C pickup - 2WD (CNG)	Electronic variable orifice	●	●	○	●	●	○	

1997	GMC truck	GMC K pickup - 4WD	Powertrain	●	●	●	●	●	○	
1997	GMC truck	GMC K pickup - 4WD	Electronic variable orifice	●	●	○	●	●	○	
1997	GMC truck	GMC suburban - 2WD	Powertrain	●	●	●	●	●	○	
1997	GMC truck	GMC suburban - 2WD	Electronic variable orifice	●	●	○	●	●	○	
1997	GMC truck	GMC suburban - 4WD	Powertrain	●	●	●	●	●	○	
1997	GMC truck	GMC suburban - 4WD	Electronic variable orifice	●	●	○	●	●	○	
1997	GMC truck	Jimmy - 2WD	Powertrain	●	●	●	●	●	○	
1997	GMC truck	Jimmy - 4WD	Powertrain	●	●	●	●	●	○	
1997	GMC truck	Safari - 2WD	Powertrain	●	●	●	●	●	○	
1997	GMC truck	Safari - 2WD	Electronic variable orifice	●	●	○	●	●	○	
1997	GMC truck	Safari - 4WD	Powertrain	●	●	●	●	●	○	
1997	GMC truck	Safari - 4WD	Electronic variable orifice	●	●	○	●	●	○	
1997	GMC truck	Savana - 2WD	Powertrain	●	●	●	●	●	○	
1997	GMC truck	Savana - 2WD	Electronic variable orifice	●	●	○	●	●	○	
1997	GMC truck	Sonoma pickup - 2WD	Powertrain	●	●	●	●	●	○	
1997	GMC truck	Sonoma pickup - 4WD	Powertrain	●	●	●	●	●	○	
1997	GMC truck	Yukon - 2WD	Powertrain	●	●	●	●	●	○	
1997	GMC truck	Yukon - 2WD	Electronic variable orifice	●	●	○	●	●	○	
1997	GMC truck	Yukon - 4WD	Powertrain	●	●	●	●	●	○	
1997	GMC truck	Yukon - 4WD	Electronic variable orifice	●	●	○	●	●	○	
1997	Isuzu	S/T isuzu - 2WD	Powertrain	●	●	●	●	●	○	
1997	Oldsmobile	Bravada	Powertrain	●	●	●	●	●	○	

1997	Oldsmobile	Silhouette	Powertrain	●	●	●	●	●	●	T001
1997	Oldsmobile	Silhouette ext.	Powertrain	●	●	●	●	●	●	T001
1997	Pontiac	Trans sport	Powertrain	●	●	●	●	●	●	T001
1997	Pontiac	Trans sport ext.	Powertrain	●	●	●	●	●	●	T001
1997	Opel	Sintra	Powertrain	●	●	●	●	●	●	T001
1996	Buick	Century	Powertrain	●	●	●	●	●	○	
1996	Buick	Lesabre	Powertrain	●	●	●	●	●	○	
1996	Buick	Lesabre	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1996	Buick	Park avenue	Powertrain	●	●	●	●	●	○	
1996	Buick	Park avenue	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1996	Buick	Regal	Powertrain	●	●	●	●	●	○	
1996	Buick	Riviera	Powertrain	●	●	●	●	●	○	
1996	Buick	Riviera	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1996	Buick	Roadmaster	Powertrain	●	●	●	●	●	○	
1996	Buick	Skylark	Powertrain	●	●	●	●	●	○	
1996	Cadillac	Concours	Powertrain	●	●	●	●	●	●	T232
1996	Cadillac	Concours	Body control module	●	●	○	●	●	●	T206 T209
1996	Cadillac	Concours	Radio	●	●	○	●	●	●	T206 T209
1996	Cadillac	Concours	CVRSS/ALC	●	●	○	●	●	○	
1996	Cadillac	Deville	Powertrain	●	●	●	●	●	●	T232
1996	Cadillac	Deville	Body control module	●	●	○	●	●	●	T206 T209
1996	Cadillac	Deville	Radio	●	●	○	●	●	●	T206 T209
1996	Cadillac	Deville	CVRSS/ALC	●	●	○	●	●	○	
1996	Cadillac	Eldorado	Powertrain	●	●	●	●	●	●	T232
1996	Cadillac	Eldorado	Body control module	●	●	○	●	●	●	T206 T209
1996	Cadillac	Eldorado	Radio	●	●	○	●	●	●	T206 T209
1996	Cadillac	Eldorado	CVRSS/ALC	●	●	○	●	●	○	
1996	Cadillac	Fleetwood	Powertrain	●	●	●	●	●	○	
1996	Cadillac	Seville	Powertrain	●	●	●	●	●	●	T232
1996	Cadillac	Seville	Body control module	●	●	○	●	●	●	T206 T209
1996	Cadillac	Seville	Radio	●	●	○	●	●	●	T206 T209

1996	Cadillac	Seville	CVRSS/ALC	●	●	○	●	●	○	
1996	Chevrolet	Beretta	Powertrain	●	●	●	●	●	○	
1996	Chevrolet	Camaro	Powertrain	●	●	●	●	●	○	
1996	Chevrolet	Caprice	Powertrain	●	●	●	●	●	○	
1996	Chevrolet	Cavalier	Powertrain	●	●	●	●	●	○	
1996	Chevrolet	Corsica	Powertrain	●	●	●	●	●	○	
1996	Chevrolet	Corvette	Powertrain	●	●	●	●	●	○	
1996	Chevrolet	Impala	Powertrain	●	●	●	●	●	○	
1996	Chevrolet	Lumina	Powertrain	●	●	●	●	●	○	
1996	Chevrolet	Monte carlo	Powertrain	●	●	●	●	●	○	
1996	Geo	Prizm	Powertrain	●	●	○	○	●	○	
1996	Oldsmobile	Achieva	Powertrain	●	●	●	●	●	○	
1996	Oldsmobile	Aurora	Powertrain	●	●	●	●	●	●	T232
1996	Oldsmobile	Aurora	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1996	Oldsmobile	Cutlass ciera	Powertrain	●	●	●	●	●	○	
1996	Oldsmobile	Cutlass supreme	Powertrain	●	●	●	●	●	○	
1996	Oldsmobile	Eighty eight	Powertrain	●	●	●	●	●	○	
1996	Oldsmobile	Eighty eight	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1996	Pontiac	Bonneville	Powertrain	●	●	●	●	●	○	
1996	Pontiac	Bonneville	Remote function actuation	○	○	○	●	●	●	T219 T224 T225 T226 T227 T228 T229 T230
1996	Pontiac	Firebird	Powertrain	●	●	●	●	●	○	
1996	Pontiac	Grand am	Powertrain	●	●	●	●	●	○	
1996	Pontiac	Grand prix	Powertrain	●	●	●	●	●	○	
1996	Pontiac	Sunfire	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	Astro - 2WD	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	Astro - 4WD	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	Blazer - 2WD	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	Blazer - 2WD	VCM 4WAL	○	○	○	●	●	○	

1996	Chevrolet truck	Blazer - 4WD	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	Blazer - 4WD	VCM 4WAL	○	○	○	●	●	○	
1996	Chevrolet truck	C pickup - 2WD	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	G van	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	K pickup - 4WD	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	Lumina APV	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	S10 pickup - 2WD	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	S10 pickup - 2WD	VCM 4WAL	○	○	○	●	●	○	
1996	Chevrolet truck	S10 pickup - 4WD	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	S10 pickup - 4WD	VCM 4WAL	○	○	○	●	●	○	
1996	Chevrolet truck	Suburban - 2WD	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	Suburban - 4WD	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	Tahoe - 2WD	Powertrain	●	●	●	●	●	○	
1996	Chevrolet truck	Tahoe - 4WD	Powertrain	●	●	●	●	●	○	
1996	GMC truck	GMC C pickup - 2WD	Powertrain	●	●	●	●	●	○	
1996	GMC truck	GMC G van	Powertrain	●	●	●	●	●	○	
1996	GMC truck	GMC K pickup - 4WD	Powertrain	●	●	●	●	●	○	
1996	GMC truck	GMC suburban - 2WD	Powertrain	●	●	●	●	●	○	

1996	GMC truck	GMC suburban - 4WD	Powertrain	●	●	●	●	●	○	
1996	GMC truck	Jimmy - 2WD	Powertrain	●	●	●	●	●	○	
1996	GMC truck	Jimmy - 2WD	VCM 4WAL	○	○	○	●	●	○	
1996	GMC truck	Jimmy - 4WD	Powertrain	●	●	●	●	●	○	
1996	GMC truck	Jimmy - 4WD	VCM 4WAL	○	○	○	●	●	○	
1996	GMC truck	Safari - 2WD	Powertrain	●	●	●	●	●	○	
1996	GMC truck	Safari - 4WD	Powertrain	●	●	●	●	●	○	
1996	GMC truck	Sonoma pickup - 2WD	Powertrain	●	●	●	●	●	○	
1996	GMC truck	Sonoma pickup - 2WD	VCM 4WAL	○	○	○	●	●	○	
1996	GMC truck	Sonoma pickup - 4WD	Powertrain	●	●	●	●	●	○	
1996	GMC truck	Sonoma pickup - 4WD	VCM 4WAL	○	○	○	●	●	○	
1996	GMC truck	Yukon - 2WD	Powertrain	●	●	●	●	●	○	
1996	GMC truck	Yukon - 4WD	Powertrain	●	●	●	●	●	○	
1996	Oldsmobile	Bravada	Powertrain	●	●	●	●	●	○	
1996	Oldsmobile	Bravada	VCM 4WAL	○	○	○	●	●	○	
1996	Pontiac	Trans sport	Powertrain	●	●	●	●	●	○	


S001	Brake Pedal Position Sensor Learn	S002	Headlamp Leveling Sensor Learn
S003	Erase/Program All Key Fobs	S004	Next Available Slot
S005	Key Fob 1	S006	Key Fob 2
S007	Key Fob 3	S008	Key Fob 4
S009	Key Fob 5	S010	Key Fob 6
S011	Key Fob 7	S012	Key Fob 8
S013	Battery Sensor Module Learn	S014	Clear Driver Window Learned Values

S015	Clear Passenger Window Learned Values	S016	Clear Left Rear Window Learned Values
S017	Clear Right Rear Window Learned Values	S018	Read LIN Bus Device ID Information
S019	Tire Pressure Sensors Learn	S020	Tire Pressure Sensor Signal Reset
S021	Tire Type/Pressure Selection	S022	CAN Bus Configuration Learn
S023	Transmission Service Fast Learn	S024	Configure New Module
S025	Fuel Trim Reset	S026	Crankshaft Position Variation Learn
S027	H02S Heater Learn	S028	Idle Learn
S029	Engine Oil Life Reset	S030	Remote Vehicle Start Disable History Reset
S031	Adjustable Pedals Softstops Learn	S032	HVAC Actuators Learn
S033	HVAC Afterblow Configuration	S034	Brake Pressure Sensor Calibration
S035	Steering Wheel Angle Sensor Learn	S036	Yaw Rate Sensor Learn
S037	Park Brake Calibration	S038	Suspension Position Sensor Trim Height
S039	Remote Vehicle Speed Limiting Reset	S040	Vehicle Health Data Upload

S041	WLAN Password Reset	S042	WLAN Service Set Identifier (SSID) Reset
S043	Passenger Presence Sensor Learn	S044	Clutch Pedal Position Learn
S045	Neutral Position Sensor Learn	S046	Fuel Pump Trim Reset
S047	Steering Wheel Angle Sensor Centering	S048	Transmission Adaptive Pressure Reset
S049	Liftgate Maximum Open Position Learn	S050	Clear Disable History Data
S051	Frontview Camera Learn	S052	Ambient Air Temperature Instant Update
S053	Setup SDM Part Number in BCM	S054	Erase All Key Fobs
S055	Clutch Control Module/Rear Drive System Matching Identification Setup	S056	Digital Radio Receiver Control Module
S057	Gear Selector -N- Position Learn	S058	Fuel Composition Reset
S059	Stop/Start Capacitor State of Health Reset	S060	AWD Disabled-by-Malfunction Counter Reset

S061	Long Range Radar Sensor Module Learn	S062	Hands-Free Liftgate Sensor Control Module Calibration
S063	Erase Valet Mode Code	S064	Control Module Reset
S065	Info Display/Infotainment Faceplate Reset	S066	Exhaust Flow Control Valve Learn
S067	Cylinder Deactivation Exhaust Flow Control Valve Learn	S068	Distance Sensing Cruise Control Module
S069	Adaptive Pressure Control Learn	S070	Yaw Rate Sensor Reset
S071	Gear Position Sensor Learn	S072	Transfer Case Clutch Identifier
S073	Transfer Case Clutch Overtemperature Counter Reset	S074	Vehicle Model
S075	Power Steering Softstops Learn	S076	Rear Suspension Position Sensor Trim Height
S077	Front Suspension Position Sensor Trim Height	S078	Reset History Buffer

S079	Rear Differential Clutch Service Calibration Setup	S080	Range Actuator Learn
S081	Parking Assist Sensor Learn	S082	Learned Values Reset
S083	Hybrid/EV Battery Pack Coolant Control Solenoid Valve Learn	S084	Hybrid/EV Battery Pack Capacity Learn
S085	Passenger Compartment Heater Coolant Control Solenoid Valve Learn	S086	Fuel Economy Reset
S087	Hybrid/EV Battery Contactor Open Reasons Reset	S088	Hybrid/EV Battery Pack Charging Adaptive Learn Reset
S089	Hybrid/EV Battery Pack Data Reset	S090	Manual Service Disconnect Fuse Life Reset
S091	Average Fuel Age Reset	S092	Electronic Brake Control Module Learn
S093	Steering Wheel Angle Sensor Reset	S094	Fuel Rail Pressure Relief Valve Learned Values Reset
S095	Idle Speed Control Reset	S096	ECM Reset
S097	Speedometer Calibration	S098	Retained Accessory Power



S099	Throttle Position Learn	S100	Automatic Braking Active Signal
S101	Transmission Oil Life Reset	S102	APP Learn
S103	Crankshaft Position Reluctor Ring Learn	S104	DPF Pressure Sensor Learn
S105	EGR Valve Learn	S106	Exhaust Gas Temperature Sensor Learn
S107	Flywheel Learn	S108	Fuel Rail Pressure Sensor or Fuel Rail Learn
S109	H02S Learn	S110	Intake Air Flow Valve Learn
S111	MAF Sensor Learn	S112	Turbocharger Learn
S113	DPF Reset	S114	Glow Plug Control Module Reset
S115	DPF Service Regeneration	S116	Inspection/Maintenance Data
S117	Calculated Fuel Economy Setup	S118	Injector Flow Rate Programming
S119	Ambient Air Temperature Calculation Reset	S120	Catalyst 1 Reset
S121	DPF/Catalyst 2 Reset	S122	DPF Pressure Sensor Reset
S123	Engine Serial Number	S124	Fuel Filter Life Reset
S125	NOx Catalyst Reset	S126	NOx Catalyst Reductant Loading Reset

S127	NOx Sensor 1 Reset	S128	NOx Sensor 2 Reset
S129	Reductant Fluid Tank Level Reset	S130	Reductant Injector Reset
S131	Reductant System Data Reset	S132	Reductant System Reset
S133	Display ECM and Glow Plug Control Module Injector Flow Identifiers	S134	Cylinder 1 Injector Flow Identifier
S135	Cylinder 2 Injector Flow Identifier	S136	Cylinder 3 Injector Flow Identifier
S137	Cylinder 4 Injector Flow Identifier	S138	Cylinder 5 Injector Flow Identifier
S139	Cylinder 6 Injector Flow Identifier	S140	Cylinder 7 Injector Flow Identifier
S141	Cylinder 8 Injector Flow Identifier	S142	Copy Injector Flow Identifiers from Glow Plug Control Module to ECM
S143	Copy Injector Flow Identifiers from ECM to Glow Plug Control Module	S144	Cylinder 1 Fuel Injector Correction Value Reset

S145	Cylinder 2 Fuel Injector Correction Value Reset	S146	Cylinder 3 Fuel Injector Correction Value Reset
S147	Cylinder 4 Fuel Injector Correction Value Reset	S148	Cylinder 5 Fuel Injector Correction Value Reset
S149	Cylinder 6 Fuel Injector Correction Value Reset	S150	Cylinder 7 Fuel Injector Correction Value Reset
S151	Cylinder 8 Fuel Injector Correction Value Reset	S152	All Cylinders Fuel Injector Correction Value Reset
S153	Fuel Injector Correction Value Preset	S154	Glow Plug Learn
S155	CO Adjust	S156	Clear Secured High Voltage DTCs
S157	On-Board Jump Assist Counter Reset	S158	Reset PTO Inhibit and Disengage History
S159	Restore Factory Settings	S160	DC Charging Disabled Reset
S161	EV Range Reset	S162	Idle Speed Adjustment
S163	Transmission Adaptive Torque Reset	S164	Fuel Rail Pressure Sensor Reset
S165	Power Steering Softstops Reset	S166	Transmission Adaptive Values Learn

S167	Turbocharger Learned Values Reset	S168	Vehicle Direction Camera Learn
S169	Fuel Pressure Regulator Learn	S170	Fuel Pressure Regulator Fast Learn
S171	Intake Manifold Runner Control Valve Learn	S172	High Pressure Fuel Pump Learn
S173	Boost Pressure Sensor Learn	S174	Cylinder 1 Injector
S175	Cylinder 2 Injector	S176	Cylinder 3 Injector
S177	Cylinder 4 Injector	S178	Vehicle Inclination Sensor
S179	Code Index	S180	Fuel Injection Small Quantity Data Reset
S181	Fuel Injection Small Quantity Learn	S182	Catalyst Reset
S183	Exhaust Gas Temperature Sensor Reset	S184	Idle Air Control Reset
S185	Throttle Actuator Reset	S186	Preferred Roaming List Update
S187	Module Setup	S188	Not Linked
S189	Linked	S190	Option Configuration
S191	Audio Code Index	S192	Personalization
S193	Total Fuel Consumed Reset	S194	Automatic Electric Door Locks (AU4) With Seat Belt Pretensioner (A70)

S195	Automatic Electric Door Locks (AU4) Without Seat Belt Pretensioner (-A70)	S196	Electric Door Locks (AU3) With Seat Belt Pretensioner (A70)
S197	Electric Door Locks (AU3) Without Seat Belt Pretensioner (-A70)	S198	Manual Door Locks (-AU3) (-AU4)
S199	Enable Deployment Loops	S200	Clear Transmission Counters
S201	Clutch Position Learn	S202	Clutch Purge
S203	Depressurize System	S204	Transmission Learn
S205	Fuel Injector Learn	S206	Low Speed Target Pressure
S207	High Speed Target Pressure	S208	Minimum Telltale Pressure
S209	Safe Telltale Pressure	S210	Low Speed Threshold
S211	High Speed Threshold	S212	Setup Module DTCs
S213	Reset		
T001	Crankshaft pos. variation learn	T002	PRL update
T003	Set language	T004	Stolen vehicle slowdown clear

T005	Setup SDM primary key in BCM	T006	Inclination sensor enable
T007	BPP sensor calibration	T008	Afterblow option
T009	Data recorder	T010	Audiopilot test
T011	Eject	T012	TV region lockout
T013	TV region select	T014	Automated bleed
T015	CO adjust (leaded fuel only)	T016	Change to neutral mode
T017	DPF reset replace ECM	T018	Learn sensor location
T019	Learn sen loc with tire press tool	T020	Re-zero passenger presence system
T021	Copy and paste TPM information	T022	Tire type/pressure selection
T023	Setup SDM part number in BCM	T024	DRR setup
T025	Passenger presence sensor learn	T026	Auto. door unlock
T027	Key fob in veh. warning	T028	Passive door lock
T029	Setup new RCDLR	T030	Column calibration
T031	Setup new HVAC	T032	Radio setup
T033	VIN relearn	T034	HVAC ambient temp. disp.
T035	Power window motor programming	T036	Digital radio receiver

XT-TOOL

T037	Radio RPO selection	T038	CCM RDS matching ID
T039	Clear manufacturer enable counter	T040	Bump stop
T041	Acceleration sensor reset	T042	BMC prim. piston pos. relearn
T043	EBCM relearn	T044	Steering pos./torque sensor cal.
T045	Preload passenger presence system	T046	Engine serial number
T047	Capture & restore data	T048	Injector flow rate programming
T049	Setup new ROS	T050	PTO options
T051	ECM PTO options	T052	Reset ECM
T053	Reset immobilizer	T054	Reset vehicle build settings
T055	Middle east speed bias (UC2)	T056	Brazil units (CV2)
T057	Module setup	T058	Setup SDM serial number in BCM
T059	Program VIN	T060	Tuner calibration
T061	Navigation option	T062	Transmission type
T063	Disable/enable secure car	T064	Auto. door unlock trigger
T065	Delayed locking	T066	Passive door unlock
T067	Setup SDM part number in IPM	T068	Disable dtc(s)
T069	Bluetooth	T070	System configuration

T071	PSCM calibration procedure	T072	New actuator setup procedure
T073	Program phone number	T074	Hybrid batt. charge hrs.
T075	Hybrid batt. discharge amp hrs.	T076	Erase transponder-keys
T077	Seat belt chime	T078	Learn tire pressure sensors
T079	Engine shutdown	T080	Country code
T081	Chime level	T082	Loud chime volume
T083	Loud amp chime volume	T084	Normal chime volume
T085	Normal amp chime volume	T086	AM pass A stopping
T087	FM pass A stopping	T088	IPC setup
T089	U85	T090	UZ6
T091	Driver info. display option	T092	Calibrate module
T093	VCIM setup	T094	Optional modules
T095	Region code options	T096	New tire/wheel base/booster info.
T097	Setup SDM part number in IPC	T098	Setup SDM serial number in IPC
T099	Acquisition setting	T100	Step 1
T101	Step 2	T102	North america
T103	Middle east	T104	Steering tuning selection
T105	Yaw rate sensor recalibration	T106	BCM copy and flash

XT
TOOL

T107	Reduction of pressure drive	T108	IPC recalibration
T109	Injector flow rates	T110	Vehicle speed limit
T111	Navigation voice	T112	Setup SDM serial number in DIM
T113	Setup SDM part number in DIM	T114	LONG WAVE
T115	Traffic seek	T116	Vehicle type
T117	Door zone module VIN relearn	T118	Intrusion sensor step 1
T119	Inclination sensor step 1	T120	Alarm siren module step 1
T121	Tap shift	T122	Point of sale
T123	Miscellaneous options 2	T124	Variable effort steering
T125	Right hand drive	T126	Personalization option
T127	Universal theft deterrent	T128	Intrusion sensor step 2
T129	Inclination sensor step 2	T130	Alarm siren module step 2
T131	Twilight sentinel	T132	Front fog lamp type
T133	DRL option	T134	Perimeter lighting
T135	TPM option enable	T136	New VIN
T137	Tire rotation procedure	T138	Afterblow
T139	Recalibration	T140	Accessory wheel size setup

T141	Clear memory and program all fobs	T142	CTD operation
T143	Fob feedback	T144	Theftlock LED
T145	Option configuration	T146	Fuel injector balance
T147	Buckle up reminder	T148	Pre-alarm option
T149	Solenoid test	T150	Cruise control options
T151	Exhaust brake options	T152	Gear down protection options
T153	Oil capacity options	T154	DPM setup
T155	Preferred system setting	T156	ALC trimset
T157	Dimming delay	T158	Export ID
T159	Language	T160	AM distant
T161	AM local	T162	FM distant
T163	FM local	T164	Fob button hold time
T165	Electronic suspension control	T166	Nav. radio theft
T167	Oil life monitor	T168	Axle ratio
T169	Fast learn adapt. process	T170	BCM reprogramming
T171	Setup IPC	T172	Miscellaneous options 1
T173	Automatic/manual HVAC options	T174	Magna steer option
T175	Temperature offset	T176	Load management option
T177	Disable belt tower dtc's	T178	Navigation radio present

T179	Military or standard time	T180	Tire pressure warning
T181	Tire pressure monitor	T182	Performance shift
T183	Key fob personalization	T184	SCLM setup
T185	DTC mask	T186	Accessory inflator
T187	Middle east region mode	T188	Tire rotation/sensor replacement
T189	Setup RFA	T190	Synchronize IPC and SIR
T191	Setup new onstar	T192	Electronic serial number
T193	Update HVAC calcs. in DIM	T194	LH drvr. personalization
T195	RH drvr. personalization	T196	BCM RPO reprogram
T197	Twilight sentinel reprogram	T198	Seed and key relearn
T199	Setup new VTD module	T200	Export option
T201	Valet lockout	T202	Compact disc
T203	Cellular telephone	T204	A/C compressor calibration
T205	Option A	T206	Option B
T207	Option C	T208	Option D
T209	Option E	T210	VIN information
T211	Bass frequency response	T212	Steering angle sensor centering
T213	Heater recalibration	T214	Door lock
T215	Door unlock	T216	Door jamb switch

XT-TOOL

T217	Brake pedal	T218	Ignition switch
T219	Option no. 0	T220	HVAC recal. download
T221	TV present	T222	Bose display
T223	Isolation valve test	T224	Option no. 1
T225	Fob 1 option 2	T226	Fob 1 option 3
T227	Fob 2 option 1	T228	Fob 2 option 2
T229	Fob 2 option 3	T230	Option no. 2
T231	Service spark retard reset	T232	Odometer reset
T233	Gauge setup	T234	Synchronize TTM and MSM
T235	Synchronize MSM and TTM		

*XT*TOOL



Shenzhen Xtooltech Co., Ltd.

Seat Function List V10.15

√ This function is supported. ※ This function may be supported which depends on the actual condition of the vehicle.

× This function is not supported.

As for special function please refer to the special function table.

Year	Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live data	Freeze Frame	Active Test	Special Function
1999 (X)- 2002 (2)	6K - Ibiza 1999 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Ibiza 1999 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Ibiza 1999 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Ibiza 1999 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Ibiza 1999 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Ibiza 1999 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Ibiza 1999 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Ibiza 1999 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Cordoba 1999 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Cordoba 1999 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Cordoba 1999 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Cordoba 1999 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

1999 (X)- 2002 (2)	6K - Cordoba 1999 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Cordoba 1999 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Cordoba 1999 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2002 (2)	6K - Cordoba 1999 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	11-Engine Control Module 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	2E-Media Player Position 3	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2009 (9)	1P - León 2006 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1P - León 2006 >	BD-High Voltage Battery Charge Ma	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Immobiliser and radio PIN - Online functions	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

All model years- All model years	Immobiliser and radio PIN - Online functions	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Immobiliser and radio PIN - Online functions	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Immobiliser and radio PIN - Online functions	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Immobiliser and radio PIN - Online functions	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Immobiliser and radio PIN - Online functions	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Immobiliser and radio PIN - Online functions	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Immobiliser and radio PIN - Online functions	35-Central Locking Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Immobiliser and radio PIN - Online functions	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2001 (1)- 2010 (A)	7M - Alhambra 2001 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	35-Central Locking Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Alhambra 2001 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2009 (9)	6L - Cordoba 2003 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2009 (9)	6L - Cordoba 2003 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2009 (9)	6L - Cordoba 2003 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2009 (9)	6L - Cordoba 2003 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2009 (9)	6L - Cordoba 2003 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2009 (9)	6L - Cordoba 2003 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2009 (9)	6L - Cordoba 2003 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2009 (9)	6L - Cordoba 2003 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2009 (9)	6L - Cordoba 2003 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2003 (3)- 2009 (9)	6L - Cordoba 2003 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2009 (9)	6L - Cordoba 2003 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2009 (9)	6L - Cordoba 2003 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2009 (9)	6L - Cordoba 2003 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2009 (9)	6L - Cordoba 2003 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	5P - Altea XL/Freetrack 2007 >	BD-High Voltage Battery Charge Ma	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2000 (Y)- 2006 (6)	1M - Leon 2000 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	35-Central Locking Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2006 (6)	1M - Leon 2000 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2005 (5)- 2009 (9)	5P - Toledo 2005 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2005 (5)- 2009 (9)	5P - Toledo 2005 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5P - Toledo 2005 >	BD-High Voltage Battery Charge Ma	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2004 (4)- 2009 (9)	5P - Altea 2004 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2004 (4)- 2009 (9)	5P - Altea 2004 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	5P - Altea 2004 >	BD-High Voltage Battery Charge Ma	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2009 (9)	6L - Ibiza 2002 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2009 (9)	6L - Ibiza 2002 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2009 (9)	6L - Ibiza 2002 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2009 (9)	6L - Ibiza 2002 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2009 (9)	6L - Ibiza 2002 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2009 (9)	6L - Ibiza 2002 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2009 (9)	6L - Ibiza 2002 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2009 (9)	6L - Ibiza 2002 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2009 (9)	6L - Ibiza 2002 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2009 (9)	6L - Ibiza 2002 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2009 (9)	6L - Ibiza 2002 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2009 (9)	6L - Ibiza 2002 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2009 (9)	6L - Ibiza 2002 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2002 (2)- 2009 (9)	6L - Ibiza 2002 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	35-Central Locking Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2004 (4)	1M - Toledo 1999 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	9K - Inca 2001 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	9K - Inca 2001 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2001 (1)- 2003 (3)	9K - Inca 2001 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	9K - Inca 2001 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	9K - Inca 2001 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	9K - Inca 2001 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2004 (4)	6H - Arosa 2001 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2004 (4)	6H - Arosa 2001 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2004 (4)	6H - Arosa 2001 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2004 (4)	6H - Arosa 2001 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2004 (4)	6H - Arosa 2001 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2004 (4)	6H - Arosa 2001 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2004 (4)	6H - Arosa 2001 >	35-Central Locking Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2004 (4)	6H - Arosa 2001 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2012 (C)	6J - Ibiza 2008 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	4B-Multifunction Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2012 (C)	6J - Ibiza 2008 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2015 (F)	7N - Alhambra 2011 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2015 (F)	7N - Alhambra 2011 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2015 (F)	7N - Alhambra 2011 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	A5-Front Sensors Driver Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	BD-High Voltage Battery Charge Ma	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2015 (F)	7N - Alhambra 2011 >	BE-Sliding Door Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	7N - Alhambra 2011 >	BF-Sliding Door Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	45-Interior Monitoring	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	4C-Tire Pressure Monitoring 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2014 (E)	3R - Exeo 2009 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	3R - Exeo 2009 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2015 (F)	5P - Altea 2009 > PA	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	42-Door Electronics Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	51-Drive Motor Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	62-Door Electronics Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	72-Door Electronics Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea 2009 > PA	BD-High Voltage Battery Charge Ma	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2013 (D)	1P - León 2009 > PA	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2013 (D)	1P - León 2009 > PA	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	62-Door Electronics Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	72-Door Electronics Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	1P - León 2009 > PA	BD-High Voltage Battery Charge Ma	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freerack 2009 > PA	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freerack 2009 > PA	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freerack 2009 > PA	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freerack 2009 > PA	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freerack 2009 > PA	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freerack 2009 > PA	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freerack 2009 > PA	11-Engine Control Module 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freerack 2009 > PA	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freerack 2009 > PA	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freerack 2009 > PA	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2015 (F)	5P - Altea XL/Freetrack 2009 > PA	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2015 (F)	5P - Altea XL/Freerack 2009 > PA	BD-High Voltage Battery Charge Ma	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2010 (A)	5P - Toledo 2009 > PA	BD-High Voltage Battery Charge Ma	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2016 (G)	AA - Mii 2012 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	23-Brake Boost	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	AD-Sensors Brake Systems	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	BD-High Voltage Battery Charge Ma	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	C0-Actuator For Exterior Noise	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	AA - Mii 2012 >	C6-Battery Charger Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	4B-Multifunction Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	6J - Ibiza 2012 > PA	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2016 (G)	NH - Toledo 2013 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	NH - Toledo 2013 >	B7-Access Startsystem Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2016 (G)	5F - León 2013 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	2B-Steering Column Locking	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	32-Lock Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	3C-Lane Change Assistant	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	3D-Special Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	42-Door Electronics Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	6C-Camera System Rear View	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	6D-Deck Lid Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	A5-Front Sensors Driver Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2016 (G)	5F - León 2013 >	A9-Actuator For Structure-Borne S	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	B7-Access Startsystem Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	CA-Control Module For Sunroof	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	5F - León 2013 >	DD-Control Module 2 For Sunroof	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	A5-Front Sensors Driver Assistanc	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	BD-High Voltage Battery Charge Ma	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	BE-Sliding Door Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2016 (G)	7N - Alhambra 2016 >PA	BF-Sliding Door Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2017_H- 2017_H	5F - Ateca 2017 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	32-Lock Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2017_H- 2017_H	5F - Ateca 2017 >	A5-Front Sensors Driver Assistanc	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	A9-Actuator For Structure-Borne S	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	B7-Access Startsystem Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	CA-Control Module For Sunroof	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017_H- 2017_H	5F - Ateca 2017 >	DD-Control Module 2 For Sunroof	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

Index	Specil Function Name	Index	Specil Function Name
0001	Coding	0002	Basic Settings
0003	Adaptation	0004	Security Access
0005	AdvancedDataStream	0006	Login CodingII
0007	Advanced ID		

XT **TOOL**



Shenzhen Xtooltech Co., Ltd.

Skoda Function List V10.15

√ This function is supported. ※ This function may be supported which depends on the actual condition of the vehicle.

× This function is not supported.

As for special function please refer to the special function table.

Year	Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live data	Freeze Frame	Active Test	Special Function
1997 (V) - 2011 (B)	Octavia 1997 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	35-Central Locking Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

1997 (V) - 2011 (B)	Octavia 1997 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V) - 2011 (B)	Octavia 1997 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y) - 2008 (8)	Fabia 1999 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2000 (Y)- 2008 (8)	Fabia 1999 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2000 (Y)- 2008 (8)	Fabia 1999 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2008 (8)	Superb 2001 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6) - 2015 (F)	Roomster 2006 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6) - 2015 (F)	Roomster 2006 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (G) - 2015 (F)	Roomster 2006 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (G) - 2015 (F)	Roomster 2006 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (G) - 2015 (F)	Roomster 2006 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2016 (G) - 2016 (G)	Roomster 2016 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Roomster 2016 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2004 (4) - 2013 (D)	Octavia 2004 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4) - 2013 (D)	Octavia 2004 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2004 (4)- 2013 (D)	Octavia 2004 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2013 (D)	Octavia 2004 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2013 (D)	Octavia 2004 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2013 (D)	Octavia 2004 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2013 (D)	Octavia 2004 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2013 (D)	Octavia 2004 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2013 (D)	Octavia 2004 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2013 (D)	Octavia 2004 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2013 (D)	Octavia 2004 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2013 (D)	Octavia 2004 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining vehicles for immobilizer online	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining vehicles for immobilizer online	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining vehicles for immobilizer online	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining vehicles for immobilizer online	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining vehicles for immobilizer online	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining vehicles for immobilizer online	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining vehicles for immobilizer online	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining vehicles for immobilizer online	35-Central Locking Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining vehicles for immobilizer online	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2007 (7)- 2015 (F)	Fabia 2007 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2015 (F)	Fabia 2007 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2007 (7) - 2015 (F)	Fabia 2007 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7) - 2015 (F)	Fabia 2007 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7) - 2015 (F)	Fabia 2007 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F) - 2016 (G)	Fabia 2015 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2015 (F) - 2016 (G)	Fabia 2015 >	B7-Access Startsystem Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9) - 2015 (F)	Superb 2008 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9) - 2015 (F)	Superb 2008 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2016 (G) - 2016 (G)	Superb 2016 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	4B-Multifunction Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2016 (G) - 2016 (G)	Superb 2016 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	A5-Front Sensors Driver Assistance Sys	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	B7-Access Startsystem Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	BB-Door Electronics Rear Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	BC-Door Electronics Rear Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G) - 2016 (G)	Superb 2016 >	CA-Control Module For Sunroof	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A) - 2016 (G)	Yeti 2010 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A) - 2016 (G)	Yeti 2010 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A) - 2016 (G)	Yeti 2010 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C) - 2016 (G)	Rapid NA (India) 2012 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C) - 2016 (G)	Rapid NA (India) 2012 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C) - 2016 (G)	Rapid NA (India) 2012 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C) - 2016 (G)	Rapid NA (India) 2012 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C) - 2016 (G)	Rapid NA (India) 2012 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C) - 2016 (G)	Rapid NA (India) 2012 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C) - 2016 (G)	Rapid NA (India) 2012 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C) - 2016 (G)	Rapid NA (India) 2012 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C) - 2016 (G)	Rapid NA (India) 2012 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2016 (G)	Rapid NA (India) 2012 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Rapid NA (India) 2012 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Rapid NA (India) 2012 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Rapid NA (India) 2012 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Rapid NA (India) 2012 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Rapid NA (India) 2012 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Rapid NA (India) 2012 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Rapid NA (India) 2012 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Rapid NA (India) 2012 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Rapid NA (India) 2012 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Rapid NA (India) 2012 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Rapid NA (India) 2012 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Rapid NA (India) 2012 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2016 (G)	Citigo 2012 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	23-Brake Boost	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	AD-Sensors Brake Systems	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	BD-High Voltage Battery Charge Manager	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	C0-Actuator For Exterior Noise	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	Citigo 2012 >	C6-Battery Charger Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Rapid NH (EU) 2013 >	B7-Access Startsystem Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2016 (G)	Octavia 2013 >	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	32-Lock Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	4B-Multifunction Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2016 (G)	Octavia 2013 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	A5-Front Sensors Driver Assistance Sys	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	A9-Actuator For Structure-Borne Sound	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	B7-Access Startsystem Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	BB-Door Electronics Rear Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	BC-Door Electronics Rear Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	CA-Control Module For Sunroof	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	D6-Light Control Left 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	Octavia 2013 >	D7-Light Control Right 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

Index	Specil Function Name	Index	Specil Function Name
0001	Coding	0002	Basic Settings
0003	Adaptation	0004	Security Access
0005	AdvancedDataStream	0006	Login CodingII
0007	Advanced ID		



Shenzhen Xtooltech Co., Ltd.

Smart Function List V18.20

NOTES:

- √ This function is supported.
- * This function is new added.

Model	Engne Type	Year Model	System Name	Identific ation	Read fault memory	Read Event fault	Clear fault memory	Data stream	Compone nt activation	Special Function
smart forfour (W454)	diesel engine		A1 (Instrument cluster)	√	√		√			√
smart forfour (W454)	diesel engine		A2 (smart radio five)	√	√		√	√	√	
smart forfour (W454)	diesel engine		Audio 20 with integrated audio gateway	√	√		√	√		
smart forfour (W454)	diesel engine		Audio gateway	√	√		√	√		
smart forfour (W454)	diesel engine		CD changer	√	√		√	√		
smart forfour (W454)	diesel engine		COMAND or AUDIO	√	√		√	√	√	
smart forfour (W454)	diesel engine		Multifunction steering wheel	√	√		√	√		
smart forfour (W454)	diesel engine		N10/10 (Left SAM control unit)	√	√		√			
smart forfour (W454)	diesel engine		N2/7 (Restraint systems control unit)	√	√		√		√	
smart forfour (W454)	diesel engine		N22 (AAC [KLA] control and operating unit)	√	√		√	√	√	
smart forfour (W454)	diesel engine		N3/9 (EDG control unit)	√	√		√	√		
smart forfour (W454)	diesel engine		N47-5 (ESP control unit)	√	√		√	√		
smart forfour (W454)	diesel engine		N68 (Steering assist control module)	√	√		√	√	√	
smart forfour (W454)	diesel engine		N93 (Central gateway control unit)	√	√		√			
smart forfour (W454)	diesel engine		Telecommunications	√	√		√	√		
smart forfour (W454)	gasoline engine		A1 (Instrument cluster)	√	√		√			√
smart forfour (W454)	gasoline engine		A2 (smart radio five)	√	√		√	√	√	
smart forfour (W454)	gasoline engine		Audio 20 with integrated audio gateway	√	√		√	√		
smart forfour (W454)	gasoline engine		Audio gateway	√	√		√	√		
smart forfour (W454)	gasoline engine		CD changer	√	√		√	√		
smart forfour (W454)	gasoline engine		COMAND or AUDIO	√	√		√	√	√	

smart forfour (W454)	gasoline		Multifunction steering wheel	√	√		√	√		
smart forfour (W454)	gasoline		N10/10 (Left SAM control unit)	√	√		√			
smart forfour (W454)	gasoline		N2/7 (Restraint systems control unit)	√	√		√		√	
smart forfour (W454)	gasoline		N22 (AAC [KLA] control and operating unit)	√	√		√	√	√	
smart forfour (W454)	gasoline		N3/10 (MEG motor electronics control unit)	√	√		√		√	
smart forfour (W454)	gasoline		N47-5 (ESP control unit)	√	√		√	√		
smart forfour (W454)	gasoline		N47-7 (ABS control module)	√	√		√	√		
smart forfour (W454)	gasoline		N68 (Steering assist control module)	√	√		√	√	√	
smart forfour (W454)	gasoline		N93 (Central gateway control unit)	√	√		√			
smart forfour (W454)	gasoline		Telecommunications	√	√		√	√		
smart fortwo (A/C450)	crossblade		A1 (Instrument cluster)	√	√		√			√
smart fortwo (A/C450)	crossblade		N10/10 (SAM control unit)	√	√		√	√		
smart fortwo (A/C450)	crossblade		N2/7 (Restraint systems control unit)	√	√		√	√		
smart fortwo (A/C450)	crossblade		N2/7 (Restraint systems control unit)	√	√		√	√		
smart fortwo (A/C450)	crossblade		N3/10 (MEG motor electronics control unit)	√	√		√	√		
smart fortwo (A/C450)	crossblade		N47-5 (ESP control unit)	√	√		√	√		
smart fortwo (A/C450)	crossblade		N68 (Steering assist control module)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	1998 - 2002	A1 (Instrument cluster)	√	√		√			√
smart fortwo (A/C450)	diesel engine	1998 - 2002	N10 (Central electronics)	√	√		√	√	√	
smart fortwo (A/C450)	diesel engine	1998 - 2002	N2/7 (Restraint systems control unit)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	1998 - 2002	N2/7 (Restraint systems control unit)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	1998 - 2002	N3/9 (EDG control unit)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	1998 - 2002	N47-7 (ABS control module)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	2003 - 2004	A1 (Instrument cluster)	√	√		√			√
smart fortwo (A/C450)	diesel engine	2003 - 2004	N10/10 (SAM control unit)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	2003 - 2004	N2/7 (Restraint systems control unit)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	2003 - 2004	N2/7 (Restraint systems control unit)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	2003 - 2004	N3/9 (EDG control unit)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	2003 - 2004	N47-5 (ESP control unit)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	2003 - 2004	N68 (Steering assist control module)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	2005	A1 (Instrument cluster)	√	√		√			√
smart fortwo (A/C450)	diesel engine	2005	N10/10 (SAM control unit)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	2005	N2/7 (Restraint systems control unit)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	2005	N2/7 (Restraint systems control unit)	√	√		√	√		
smart fortwo (A/C450)	diesel engine	2005	N3/9 (EDG control unit)	√	√		√	√		

smart fortwo (A/C450)	diesel engine	2005	N47-5 (ESP control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	diesel engine	2005	N68 (Steering assist control module)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	1998 - 2002	A1 (Instrument cluster)	✓	✓		✓			✓
smart fortwo (A/C450)	gasoline	1998 - 2002	N10 (Central electronics)	✓	✓		✓	✓	✓	
smart fortwo (A/C450)	gasoline	1998 - 2002	N2/7 (Restraint systems control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	1998 - 2002	N2/7 (Restraint systems control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	1998 - 2002	N3/10 (MEG motor electronics control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	1998 - 2002	N47-7 (ABS control module)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	2003 - 2004	A1 (Instrument cluster)	✓	✓		✓			✓
smart fortwo (A/C450)	gasoline	2003 - 2004	N10/10 (SAM control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	2003 - 2004	N2/7 (Restraint systems control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	2003 - 2004	N2/7 (Restraint systems control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	2003 - 2004	N3/10 (MEG motor electronics control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	2003 - 2004	N47-5 (ESP control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	2003 - 2004	N68 (Steering assist control module)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	2005	A1 (Instrument cluster)	✓	✓		✓			✓
smart fortwo (A/C450)	gasoline	2005	N10/10 (SAM control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	2005	N2/7 (Restraint systems control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	2005	N2/7 (Restraint systems control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	2005	N3/10 (MEG motor electronics control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	2005	N47-5 (ESP control unit)	✓	✓		✓	✓		
smart fortwo (A/C450)	gasoline	2005	N68 (Steering assist control module)	✓	✓		✓	✓		
smart fortwo (C/A451)			A1 (Instrument cluster)	✓	✓		✓			✓
smart fortwo (C/A451)			H4/16 (Electric vehicle sound generator)	✓	✓		✓			
smart fortwo (C/A451)			N10/10 (SAM control unit)	✓	✓		✓		✓	
smart fortwo (C/A451)			N110 (Weight Sensing System (WSS) control unit)	✓	✓		✓			
smart fortwo (C/A451)			N112/2 (Electric vehicle communication module control unit)	✓	✓		✓	✓		
smart fortwo (C/A451)			N127 (Drivetrain control unit)	✓	✓		✓			
smart fortwo (C/A451)			N129 (Starter generator squib)	✓	✓		✓	✓		
smart fortwo (C/A451)			N129/1 (Power electronics control unit)	✓	✓		✓			
smart fortwo (C/A451)			N13/5 (Electronic selector lever module control unit)	✓	✓		✓			
smart fortwo (C/A451)			N15/6 (Sprintshift control module)	✓	✓		✓			
smart fortwo (C/A451)			N19/4 (Electric refrigerant compressor control unit)	✓	✓	✓	✓	✓		
smart fortwo (C/A451)			N2/1 (Crash sensor, high-voltage battery)	✓	✓		✓			
smart fortwo (C/A451)			N2/7 (Restraint systems control unit)	✓	✓		✓		✓	

smart fortwo (C/A451)			N23 (Heater/air conditioning operating unit)	√	√		√		√	
smart fortwo (C/A451)			N3/10 (ME-SFI [ME] control unit)	√	√		√	√	√	
smart fortwo (C/A451)			N3/9 (CDI control unit)	√	√		√		√	
smart fortwo (C/A451)			N47-5 (ESP control unit)	√	√		√	√		
smart fortwo (C/A451)			N65/5 (Brake booster vacuum pump control module)	√	√		√			
smart fortwo (C/A451)			N68 (Steering assist control module)	√	√		√	√		
smart fortwo (C/A451)			N82/2 (Battery management system control unit)	√	√		√			
smart fortwo (C/A451)			N83 (Onboard charger 3kW)	√	√		√			
smart fortwo (C/A451)			N83/10 (Onboard charger 22kW)	√	√		√			
smart fortwo (C/A451)			N83n1 (Powerline gateway control unit)	√	√		√			
smart fortwo (C/A451)			N88/1 (Tire pressure monitoring system (TPM [RDK]))	√	√		√	√		
smart fortwo (C/A451)			A1 (Instrument cluster)	√	√		√	√		√
smart fortwo (C/A451)			N10/10 (SAM control unit)	√	√		√	√		
smart fortwo (C/A451)			N2/7 (Restraint systems control unit)	√	√		√	√		
smart fortwo (C/A451)			N3/10 (MEG motor electronics control unit)	√	√		√	√		
smart fortwo (C/A451)			N47-5 (ESP control unit)	√	√		√	√		
smart fortwo (C/A451)			N68 (Steering assist control module)	√	√		√	√		
smart 453	gasoline engine		N3/10-Motor electronics ME17_453 for combustion engine M 281 (ME)	√	√		√			
smart 453	gasoline engine		N3/10-Motor electronics ME30 for combustion engine M 281 (ME)							
smart 453	gasoline engine		N15/13-Electronic transmission control for double-plate clutch transmission (DKG)	√	√		√			
smart 453	gasoline engine		N15/5-Electronic selector module (EWM)	√	√		√			
smart 453	gasoline engine		N127-Control unit Powertrain (PTCU)							
smart 453	gasoline engine		N129/1-Power electronics (SG-EM)							
smart 453	gasoline engine		N68-Electrical power steering (ES)	√	√		√			
smart 453	gasoline engine		N30/4-Electronic stability program (ESP)	√	√		√			
smart 453	gasoline engine		N93/2-Gateway COLLISION PREVENTION ASSIST PLUS (GW-AWF)							
smart 453	gasoline engine		A89-Control unit COLLISION PREVENTION ASSIST PLUS (SG-AWF)							
smart 453	gasoline engine		A90-COLLISION PREVENTION ASSIST PLUS							
smart 453	gasoline engine		A40/11-Multifunction camera (MFK)							
smart 453	gasoline engine		N22/1-Air conditioning (AAC)	√	√		√			

smart 453	gasoline engine		N93/1-Audio gateway (AGW)	√	√		√			
smart 453	gasoline engine		N112/2-Communication module Telematics services (KOMU)							
smart 453	gasoline engine		A40/3-Audio/COMAND display (ZAN)							
smart 453	gasoline engine		A2-Radio-Smart Audio System (Audio)	√	√		√			
smart 453	gasoline engine		A2-Radio-Smart Media System (Audio)							
smart 453	gasoline engine		A1-Instrument cluster (IC)	√	√		√			
smart 453	gasoline engine		A2/13-Sound system (SOUND)							
smart 453	gasoline engine		N112/3-Windshield reading system							
smart 453	gasoline engine		N82/2-Battery management system (BMS)							
smart 453	gasoline engine		A52n1-Soft top control (VDS)							
smart 453	gasoline engine		N27/1-Crash sensor, high-voltage battery (GSJIV)							
smart 453	gasoline engine		N63/3-Charger for high-voltage battery (SG-LG)							
smart 453	gasoline engine		N83/10-Charger (22kW) (SG-LG)							
smart 453	gasoline engine		N83/2-Charging control (VCCU)							
smart 453	gasoline engine		N24/5-Powerline gateway (SG-PLCGW)							
smart 453	gasoline engine		N10/11-Signal acquisition and actuation module (Driver-side SAM)	√	√		√			
smart 453	gasoline engine		N10/10-Signal acquisition and actuation module (SAM-M)	√	√		√			
smart 453	gasoline engine		N2/10-Supplemental restraint system (SRS)	√	√		√			
smart 453	gasoline engine		N110-Weight sensing system (WSS)							
smart 453	Electric engine		N15/13-Electronic transmission control for double-plate clutch transmission (DKG)	√	√		√			
smart 453	Electric engine		N15/5-Electronic selector module (EWM)	√	√		√			
smart 453	Electric engine		N127-Control unit Powertrain (PTCU)							
smart 453	Electric engine		N129/1-Power electronics (SG-EM)							
smart 453	Electric engine		N68-Electrical power steering (ES)	√	√		√			
smart 453	Electric engine		N30/4-Electronic stability program (ESP)	√	√		√			
smart 453	Electric engine		N93/2-Gateway COLLISION PREVENTION ASSIST PLUS (GW-AWF)							
smart 453	Electric engine		A89-Control unit COLLISION PREVENTION ASSIST PLUS (SG-AWF)							
smart 453	Electric engine		A90-COLLISION PREVENTION ASSIST PLUS							
smart 453	Electric engine		A40/11-Multifunction camera (MFK)							
smart 453	Electric engine		N22/1-Air conditioning (AAC)	√	√		√			

smart 453	Electric engine		N93/1-Audio gateway (AGW)	√	√		√			
smart 453	Electric engine		N112/2-Communication module Telematics services (KOMO)							
smart 453	Electric engine		A40/3-Audio/COMAND display (ZAN)							
smart 453	Electric engine		A2-Radio-Smart Audio System (Audio)	√	√		√			
smart 453	Electric engine		A2-Radio-Smart Media System (Audio)							
smart 453	Electric engine		A1-Instrument cluster (IC)	√	√		√			
smart 453	Electric engine		A2/13-Sound system (SOUND)							
smart 453	Electric engine		N112/3-Windshield reading system							
smart 453	Electric engine		N82/2-Battery management system (BMS)							
smart 453	Electric engine		A52n1-Soft top control (VDS)							
smart 453	Electric engine		N27/1-Crash sensor, high-voltage battery (CSJIV)							
smart 453	Electric engine		N63/3-Charger for high-voltage battery (SG-LG)							
smart 453	Electric engine		N83/10-Charger (22kW) (SG-LG)							
smart 453	Electric engine		N83/2-Charging control (VCCU)							
smart 453	Electric engine		N24/5-Powerline gateway (SG-PLCGW)							
smart 453	Electric engine		N10/11-Signal acquisition and actuation module (Driver-side SAM)	√	√		√			
smart 453	Electric engine		N10/10-Signal acquisition and actuation module (SAM-M)	√	√		√			
smart 453	Electric engine		N2/10-Supplemental restraint system (SRS)	√	√		√			
smart 453	Electric engine		N110-Weight sensing system (WSS)							

Special Function

smart forfour (W454)	diesel engine	A1 (Instrument cluster)	Reset of maintenance interval display
smart forfour (W454)	gasoline engine	A1 (Instrument cluster)	Reset of maintenance interval display
smart fortwo (A/C450)	crossblade	A1 (Instrument cluster)	Reset of maintenance interval display
smart fortwo (A/C450)	crossblade	A1 (Instrument cluster)	Reset of maintenance interval display at a driving distance of < 200 km since the last oil change
smart fortwo (A/C450)	crossblade	A1 (Instrument cluster)	Writing of maintenance interval display parameters

smart fortwo (A/C450)	diesel engine	A1 (Instrument cluster)	Reset of maintenance interval display
smart fortwo (A/C450)	diesel engine	A1 (Instrument cluster)	Reset of maintenance interval display at a driving distance of < 200 km since the last oil change
smart fortwo (A/C450)	diesel engine	A1 (Instrument cluster)	Writing of maintenance interval display parameters
smart fortwo (A/C450)	diesel engine	A1 (Instrument cluster)	Reset of maintenance interval display
smart fortwo (A/C450)	diesel engine	A1 (Instrument cluster)	Reset of maintenance interval display at a driving distance of < 200 km since the last oil change
smart fortwo (A/C450)	diesel engine	A1 (Instrument cluster)	Writing of maintenance interval display parameters
smart fortwo (A/C450)	diesel engine	A1 (Instrument cluster)	Reset of maintenance interval display
smart fortwo (A/C450)	diesel engine	A1 (Instrument cluster)	Reset of maintenance interval display at a driving distance of < 200 km since the last oil change
smart fortwo (A/C450)	diesel engine	A1 (Instrument cluster)	Writing of maintenance interval display parameters
smart fortwo (A/C450)	gasoline engine	A1 (Instrument cluster)	Reset of maintenance interval display
smart fortwo (A/C450)	gasoline engine	A1 (Instrument cluster)	Reset of maintenance interval display at a driving distance of < 200 km since the last oil change
smart fortwo (A/C450)	gasoline engine	A1 (Instrument cluster)	Writing of maintenance interval display parameters
smart fortwo (A/C450)	gasoline engine	A1 (Instrument cluster)	Reset of maintenance interval display
smart fortwo (A/C450)	gasoline engine	A1 (Instrument cluster)	Reset of maintenance interval display at a driving distance of < 200 km since the last oil change
smart fortwo (A/C450)	gasoline engine	A1 (Instrument cluster)	Writing of maintenance interval display parameters
smart fortwo (A/C450)	gasoline engine	A1 (Instrument cluster)	Reset of maintenance interval display
smart fortwo (A/C450)	gasoline engine	A1 (Instrument cluster)	Reset of maintenance interval display at a driving distance of < 200 km since the last oil change
smart fortwo (A/C450)	gasoline engine	A1 (Instrument cluster)	Writing of maintenance interval display parameters
smart fortwo (C/A451)		A1 (Instrument cluster)	Reset of maintenance interval display

smart fortwo (C/A451)		A1 (Instrument cluster)	Reset of maintenance interval display at a driving distance of < 250 km since the last oil change
smart roadster (R/C452)		A1 (Instrument cluster)	Reset of maintenance interval display
smart roadster (R/C452)		A1 (Instrument cluster)	Reset of maintenance interval display at a driving distance of < 200 km since the last oil change
smart roadster (R/C452)		A1 (Instrument cluster)	Writing of maintenance interval display parameters

XTOOL

SSANGYONG Function list V9.30

Notes:								
✓	Functions is fully supported and already existed in former software version.							
*	Functions is fully supported and newly added in current software version.							
#	Functions is partially supported, which means the functions is verified on some vehicle models or systems and it might supports other vehicle models or systems.							
	Functions left with blank is not supported.							
Vehicle Type	System	Subsystem	Ecu Info	Read Codes	Erase Codes	Live Data	Act Test	Special_Function
MUSSEO	ECM	2.3 MSE/RATIO	✓	✓	✓	✓	✓	0001
MUSSEO	ECM	3.2 MSE/RATIO	✓	✓	✓	✓	✓	0002
MUSSEO	TCM	BTRA 4	✓	✓	✓	✓		0003
MUSSEO	TCM	BTR BOSCH	✓	✓	✓	✓		
MUSSEO	ABS	ABS 5.0	✓	✓	✓	✓	✓	
MUSSEO	ABS	ABS-ABD 5.0	✓	✓	✓	✓	✓	
MUSSEO	ABS	ABS-EBD 5.3	✓	✓	✓	✓	✓	
MUSSEO	ABS	ABD-EBD 5.3	✓	✓	✓	✓	✓	
MUSSEO	ABS	ABS 5.3(Running Change)	✓	✓	✓	✓	✓	
MUSSEO	ECS	ALL	✓	✓	✓	✓	✓	
MUSSEO	AIRBAG	ALL	✓	✓	✓			
MUSSEO	TOD	ALL	✓	✓	✓			
MUSSEO	TCCU (P/T)	ALL	✓					00,050,006
MUSSEO	Huber EGR	ALL	✓	✓	✓			07,08,09
KORANDO	ECM	2.3 MSE/RATIO	✓	✓	✓	✓	✓	0001
KORANDO	ECM	3.2 MSE/RATIO	✓	✓	✓	✓	✓	0002
KORANDO	TCM	BTRA 4	✓	✓	✓	✓		0003
KORANDO	TCM	BTR BOSCH	✓	✓	✓	✓		
KORANDO	ABS	ABS 5.0	✓	✓	✓	✓	✓	
KORANDO	ABS	ABS-ABD 5.0	✓	✓	✓	✓	✓	
KORANDO	ABS	ABS-EBD 5.3	✓	✓	✓	✓	✓	
KORANDO	ABS	ABD-EBD 5.3	✓	✓	✓	✓	✓	
KORANDO	ABS	ABS 5.3(Running Change)	✓	✓	✓	✓	✓	
KORANDO	ECS	ALL	✓	✓	✓	✓	✓	
KORANDO	AIRBAG	ALL	✓	✓	✓			
KORANDO	TOD	ALL	✓	✓	✓			
KORANDO	TCCU (P/T)	ALL	✓					00,050,006
KORANDO	Huber EGR	ALL	✓	✓	✓			07,08,09
ISTANA	ECM	2.3 MSE/RATIO	✓	✓	✓	✓	✓	0001
ISTANA	ABS	ABS 5.0 Free Running	✓	✓	✓	✓	✓	
ISTANA	ABS	ABS (TEVES)	✓	✓	✓	✓	✓	000A, 000F, 0010
CHAIRMAN	ECM	3.6 BOSCH	✓	✓	✓	✓	✓	0037
CHAIRMAN	ECM	3.2 DOHC BOSCH	✓	✓	✓	✓		
CHAIRMAN	ECM	2.3 MSE/RATIO	✓	✓	✓	✓	✓	0037
CHAIRMAN	ECM	2.8 MSE/RATIO	✓	✓	✓	✓	✓	0037
CHAIRMAN	ECM	3.2 MSE/RATIO	✓	✓	✓	✓	✓	0037
CHAIRMAN	TCM	BTRA 4	✓	✓	✓	✓		0039
CHAIRMAN	TCM	NAG 5 A/T	✓	✓	✓			
CHAIRMAN	TCM	DC 5 A/T	✓	✓	✓	✓		00,040,006
CHAIRMAN	ABS	ABS 5.3(Running Change)	✓	✓	✓	✓	✓	
CHAIRMAN	ABS	ABD 5.3	✓	✓	✓	✓	✓	
CHAIRMAN	ABS	ASR 5.3	✓	✓	✓	✓	✓	
CHAIRMAN	ABS	TEVES (ABS/ESP)	✓	✓	✓	✓	✓	0011, 0013, 0015, 0017, 0019, 0021, 0023, 0025
								002,700,290,031
CHAIRMAN	ABS	TEVES (ABS)	✓	✓	✓	✓	✓	0011, 0013, 0015, 0017, 0019, 0021, 0023, 0025
								002,700,290,031
CHAIRMAN	ECS	VDO	✓	✓	✓	✓		
CHAIRMAN	ECS	SACHS	✓	✓	✓	✓		
CHAIRMAN	AIRBAG	BOSCH	✓	✓	✓			
CHAIRMAN	AIRBAG	BOSCH	✓	✓	✓			
CHAIRMAN	AIRBAG	SRE-NCS	✓	✓	✓			
CHAIRMAN	Power Trank	CHAIRMAN ALL	✓	✓	✓			
CHAIRMAN	TPMS	CHAIRMAN ALL	✓	✓	✓	✓		
CHAIRMAN	Dual Rekes	CHAIRMAN ALL	✓	✓	✓			
CHAIRMAN	IMMOBILIZER	GASOLINE						00,080,051
CHAIRMAN	IMMOBILIZER	DIESEL						00,120,010
REXTON	ECM	2.3 MSE	✓	✓	✓	✓	✓	0037
REXTON	ECM	2.8 MSE	✓	✓	✓	✓	✓	0037
REXTON	ECM	3.2 MSE	✓	✓	✓	✓	✓	0037
REXTON	ECM	DSL 2.7 (C21)	✓	✓	✓	✓	✓	0033, 0035, 0047, 0049
REXTON	ECM	DSL 2.7 (C31)	✓	✓	✓	✓	✓	001,400,180,020
REXTON	TCM	BTRA 4	✓	✓	✓	✓		0039
REXTON	TCM	DC 5 A/T	✓	✓	✓	✓		00,040,006
REXTON	ABS	TEVES (ABS/ESP)	✓	✓	✓	✓	✓	0011, 0013, 0015, 0017, 0019, 0021, 0023, 0025
								002,700,290,031
REXTON	ABS	Bosch	✓	✓	✓	✓	✓	0001, 0005, 0007, 0009
REXTON	AIRBAG	SRE-NCS	✓	✓	✓			
REXTON	AIRBAG	SRE-SMART	✓	✓	✓			
REXTON	TOD	OLD	✓	✓	✓			
REXTON	TOD	NEW	✓	✓	✓	✓		
REXTON	TCCU	OLD	✓	✓	✓			00,080,051
REXTON	TCCU	NEW	✓	✓	✓	✓		
REXTON	Huber EGR	A11	✓	✓	✓	✓		004,100,430,045
REXTON	SSPS	A11	✓	✓	✓			
REXTON	TPMS	A11	✓	✓	✓	✓		
REXTON	TGS Lever	A11	✓	✓	✓			
REXTON	IMMOBILIZER	GASOLINE						00,080,051
REXTON	IMMOBILIZER	DIESEL						00,120,010
RODIUS/STAVIC	ECM	DSL D27DT (C21)	✓	✓	✓	✓	✓	001,400,180,020
RODIUS/STAVIC	ECM	DSL D27DT (C21)	✓	✓	✓	✓	✓	0033, 0035, 0047, 0049
RODIUS/STAVIC	ECM	DSL D27DT (C31)	✓	✓	✓	✓	✓	001,400,180,020
RODIUS/STAVIC	ECM	DSL D27DT (C31)	✓	✓	✓	✓	✓	0033, 0035, 0047, 0049
RODIUS/STAVIC	ECM	3.2 MSE/RATIO	✓	✓	✓	✓	✓	0037
RODIUS/STAVIC	TCM	DC 5 A/T	✓	✓	✓	✓		00,040,006
RODIUS/STAVIC	ABS	TEVES (ABS/ESP)	✓	✓	✓	✓	✓	0011, 0013, 0015, 0017, 0019, 0021, 0023, 0025
								002,700,290,031
RODIUS/STAVIC	AIRBAG	SRE-SMART	✓	✓	✓			
RODIUS/STAVIC	TOD	NEW	✓	✓	✓	✓		
RODIUS/STAVIC	TCCU	NEW	✓	✓	✓	✓		
RODIUS/STAVIC	TGS Lever	A11	✓	✓	✓			
RODIUS/STAVIC	IMMOBILIZER	GASOLINE						00,080,051
RODIUS/STAVIC	IMMOBILIZER	DIESEL						00,120,010
KYRON	ECM	2.3 MSE	✓	✓	✓	✓	✓	0037
KYRON	ECM	3.2 MSE	✓	✓	✓	✓	✓	0037
KYRON	ECM	DSL 2.0 (C21)	✓	✓	✓	✓	✓	0033, 0035, 0002, 0049
KYRON	ECM	DSL 2.0 (C31)	✓	✓	✓	✓	✓	001,600,180,020
KYRON	ECM	DSL 2.7 (C21)	✓	✓	✓	✓	✓	0033, 0035, 0047, 0049
KYRON	ECM	DSL 2.7 (C31)	✓	✓	✓	✓	✓	001,400,180,020
KYRON	TCM	BTRA 4	✓	✓	✓	✓		0039

KYRON	TCM	DC 5 A/T	✓	✓	✓	✓		00,040,006
KYRON	ABS	TEVES (ABS/ESP)	✓	✓	✓	✓	✓	0011,0013,0015,0017,0019,0021,0023,0025 002,700,290,031
KYRON	AIRBAG	SRE-SMART	✓	✓	✓			
KYRON	TCU	ALL	✓	✓	✓	✓		
KYRON	SSPS	ALL	✓	✓	✓			
KYRON	TGS Lever	ALL	✓	✓	✓			
KYRON	IMMOBILIZER	GASOLINE						00,080,051
KYRON	IMMOBILIZER	DIESEL						00,120,010
ACTYON	ECM	2.3 MSE	✓	✓	✓	✓	✓	0037
ACTYON	ECM	DSL 2.0 (C2I)	✓	✓	✓	✓	✓	0033,0035,0002,0049
ACTYON	ECM	DSL 2.0 (C3I)	✓	✓	✓	✓	✓	001,600,180,020
ACTYON	TCM	BTRA 4	✓	✓	✓	✓		0039
ACTYON	TCM	DC 5 A/T	✓	✓	✓	✓	✓	00,040,006
ACTYON	ABS	TEVES (ABS/ESP)	✓	✓	✓	✓	✓	0011,0013,0015,0017,0019,0021,0023,0025 002,700,290,031
ACTYON	AIRBAG	SRE-SMART	✓	✓	✓			
ACTYON	TCU	ALL	✓	✓	✓	✓		
ACTYON	SSPS	ALL	✓	✓	✓			
ACTYON	IMMOBILIZER	GASOLINE						00,080,051
ACTYON	IMMOBILIZER	DIESEL						00,120,010
KORANDO C	ECM	ALL	✓	✓	✓	✓	✓	0032,0034,0036,0038,0040,0042,0044,0046 0,048
KORANDO C	TCM	ALL		✓	✓	✓		00,280,030
KORANDO C	ABS/ESP	ALL	✓	✓	✓	✓	✓	002,400,260,050
KORANDO C	E-Coupling	ALL	✓	✓	✓	✓		
KORANDO C	EPS	ALL	✓	✓	✓	✓		0022
KORANDO C	BCM	ALL	✓	✓	✓	✓		
KORANDO C	SKM	ALL	✓			✓		
TIVOLI	ECM	GSL G16DF		✓	✓			
TIVOLI	ECM	DSL D16DTF		✓	✓			
TIVOLI	TCM	AT5IN 6 A/T		✓	✓			
TIVOLI	TPMS	ALL		✓	✓			
TIVOLI	BCM	GASOLINE		✓	✓			
TIVOLI	BCM	DIESEL		✓	✓			
TIVOLI	ABS/ESP	ABS		✓	✓			
TIVOLI	ABS/ESP	ESP		✓	✓			
TIVOLI	EPS	ALL		✓	✓			
TIVOLI	SKM	ALL		✓	✓			
TIVOLI	AIRBAG	ALL		✓	✓			
TIVOLI	E-Coupling	ALL		✓	✓			
TIVOLI	FCM	ALL		✓	✓			

Special_Function

0001	Air Bleeding				0002	Injector Coding
0003	Rear right line Air Bleeding(RR)				0004	Reset Adaption
0005	Rear left line Air Bleeding(LR)				0006	Read and Write Adaption
0007	Front left line Air Bleeding(LF)				0008	Finger Data
0009	Front right line Air Bleeding(RF)				0010	Key Coding
0011	Select Sensor Reset Item				0012	Key Coding Status
0013	Pitch G-Sensor (4WD only)				0014	C3I 5 Injector Corrections
0015	Yaw G-sensor				0016	C3I 4 Injector Corrections
0017	Pressure Sensor				0018	Engine Variant Coding
0019	All listed sensors				0020	Chassis Variant Coding
0021	CLEAR VARIANT CODE				0022	Steering Reset
0023	AIR BLEEDING (TEVES)				0024	Coding Erase
0025	Air Bleeding (TEVES) Rear right line				0026	Longitudinal acceleration sensor
0027	Air Bleeding (TEVES) Rear left line				0028	TCU Adaption Reset
0029	Air Bleeding (TEVES) Front left line				0030	TCU Initial hydraulic calibration
0031	Air Bleeding (TEVES) Front right line				0032	Injector Coding
0033	Leak Detection				0034	Engine Variant Coding
0035	Rail Pressure Reset				0036	Chassis Variant Coding
0037	ECU RESET				0038	EGR Position Relearning
0039	TPS VALUE CLEAR (DIESEL ONLY)				0040	Throttle Position Relearning
0041	Huber EGR VIN Write				0042	Swirl Valve Relearning
0043	Huber EGR Initial				0044	Rail Pressure Initialization
0045	Huber EGR System Reset				0046	O2 Sensor Initialization
0047	Injector Coding				0048	VIN Write
0049	Variant Coding				0050	Air Bleeding
0051	Key Coding					

SUBARU Function list V7.33

Notes:

✓	Functions is fully supported and already existed in former software version.
*	Functions is fully supported and newly added in current software version.
#	Functions is partially supported , which means the functions is verified on some vehicle models or systems and it might supports other vehicle models or systems.

Functions left with blank is not supported.

SYSTEM NAME	ECU Infor	Read Codes	Erase Codes	Live Data	Actuators	Special Function
Engine Control System	✓	✓	✓	✓	1-17、 89-125	1-17、 89-125
Transmission Control System	✓	✓	✓	✓	83-84、 126-133	83-84、 126-133
Brake Control System	✓	✓	✓	✓	18-22、 85-86、 134-135	18-22、 85-86、 134-135
Airbag System	✓	✓	✓	✓		
Integ.unit mode	✓	✓	✓	✓	18-22、 87-88、 136-176	18-22、 87-88、 136-176
Cruise Control System	✓	✓	✓	✓		
Occupant Detection System	✓	✓	✓	✓	177-178	177-178
Keyless access system	✓	✓	✓	✓	179-180	179-180
Power Steering System	✓	✓	✓	✓	181-182	181-182
Tire Pressure Monitor	✓	✓	✓	✓	63-64	63-64
Parking Brake System	✓	✓	✓	✓	65-70	65-70
Air Condition System	✓	✓	✓	✓	71-82、 322-324	71-82、 322-324
CAN system	✓	✓	✓	✓		
Combination meter	✓	✓	✓	✓	189-296	189-296
Auto Start Stop	✓	✓	✓	✓	297-313	297-313
Automatic Light and Wiper system	✓	✓	✓	✓	183-188	183-188
Automatic Headlight Leveling System	✓	✓	✓	✓		
Hybrid Powertrain Control System	✓	✓	✓	✓	314-321	314-321
Drive Motor Control System	✓	✓	✓	✓		
Power Rear Gate	✓	✓	✓	✓		
Battery Energy Control System	✓	✓	✓	✓		
Adaptive cruise control, radar type	✓	✓	✓	✓		
RADAR ASSY B&S LH	✓	✓	✓	✓		
RADAR ASSY B&S RH	✓	✓	✓	✓		
EyeSight (from 2009MY)	✓	✓	✓	✓		
Multi-function display	✓	✓	✓	✓		
Immobilizer System	✓	✓	✓	✓		
EyeSight Assist Monitor	✓	✓	✓	✓		
Power Seat Memory Mode	✓	✓	✓	✓		
Infotainment System	✓	✓	✓	✓		
Telematics System	✓	✓	✓	✓		

SUBARU Actiontest & WorkSupport TABLE

IndexNO.	ActionTest&WorkSupportName	SystemName
1	DealerCheckModeProcedure	ENGINE
2	ImmobilizerSystem	ENGINE
3	TwinTurbochargerSystem	ENGINE
4	ActuatorON/OFFOperation	ENGINE
5	InjectorControl	ENGINE
6	FuelPumpControl	ENGINE
7	EGRValveControl	ENGINE
8	FixedIdleIgnitionTiming	ENGINE
9	IdleSpeedControl	ENGINE
10	EGRSystemDiagnosis	ENGINE
11	DiagnosticCodeDetails	ENGINE
12	LatestDiagnosticCode(s)	ENGINE
13	MemorizedDiagnosticCode(s)	ENGINE
14	DPFmaintenance	ENGINE
15	MaintenanceatthetimeofECMreplacement	ENGINE
16	ATairbleedingmode	ENGINE
17	ATlearningmode	ENGINE
18	ABSSequenceControlMode	ABS
19	VDCCheckMode	ABS
20	SetmodeStr. A. Sen. N&Lat. Gsen. Op	ABS
21	SteeringNeutralGsensor0Set	ABS
22	LongitudinalGsensor0pointsettingmode	ABS
23	Offdelaytime	Integ. unitmode
24	Autolocktime	Integ. unitmode
25	Rrdefoggerop. mode	Integ. unitmode
26	Wiperdeicerop. mode	Integ. unitmode
27	SecurityAlarmSetup	Integ. unitmode
28	ImpactSensorSetup	Integ. unitmode
29	Alarmdelaysetup	Integ. unitmode
30	Lockoutprevention	Integ. unitmode
31	Impacksensor	Integ. unitmode
32	Sirenssetting	Integ. unitmode
33	Answer-backbuzzersetup	Integ. unitmode
34	Hazardanswer-backsetup	Integ. unitmode
35	Automaticlockingsetup	Integ. unitmode
36	Asn. -backBuzzer	Integ. unitmode
37	Autolocking	Integ. unitmode
38	InitialkeylessSetting	Integ. unitmode
39	Initialbuttonsetting	Integ. unitmode
40	InitialSecuritysetting	Integ. unitmode
41	PassiveAlarm	Integ. unitmode
42	Dooropenwarning	Integ. unitmode
43	A/CECMsetting	Integ. unitmode
44	P/WECMsetting	Integ. unitmode
45	Centerdisplayfailure	Integ. unitmode
46	Wiperdeicer	Integ. unitmode

47	Rearfoglightsetting	Integ. unitmode
48	Factoryinitialsetting	Integ. unitmode
49	Securitysetup	Integ. unitmode
50	Heatercockvalveoutput	Integ. unitmode
51	lockactuat. lockoutput	Integ. unitmode
52	AllseatUNLOCKoutput	Integ. unitmode
53	Rgate/trunkUNLKoutput	Integ. unitmode
54	Doublelockoutput	Integ. unitmode
55	ShiftLockSolenoid	Integ. unitmode
56	KeyLockingOutput	Integ. unitmode
57	KeylessBuzzerOutput	Integ. unitmode
58	Beltbuzzeroutput	Integ. unitmode
59	SirenOutput	Integ. unitmode
60	EKalarmoutput	Integ. unitmode
61	TLalarmoutput	Integ. unitmode
62	HornOutput	Integ. unitmode
63	IDregistration	TirePressureMonitor
64	TransmitterIDdatamonitor	TirePressureMonitor
65	ForceSensorCalibrationMode	ParkingBrakeSystem
66	Break-inParkingBrakeDriveMode	ParkingBrakeSystem
67	ParkingBrakeRemovalMode	ParkingBrakeSystem
68	ClutchEngagementPositionSetting	ParkingBrakeSystem
69	ClutchSensorCalibrationMode	ParkingBrakeSystem
70	ParameterInitializationMode	ParkingBrakeSystem
71	A/CChangeSetting	AirConditionSystem
72	BlowerFanLevelSetting	AirConditionSystem
73	ModeDoorActuatorOpeningAngleTarget	AirConditionSystem
74	Fresh/RecAirDrActTrgtOpenAngle	AirConditionSystem
75	RearVentDrActTrgtOpenAngle	AirConditionSystem
76	AirmixDrActTrgtOpenAngle (Pas' s)	AirConditionSystem
77	AirmixDrActTrgtOpenAngle (Driver' s)	AirConditionSystem
78	HeaterCoretemperatureSetting	AirConditionSystem
79	PTCSteps	AirConditionSystem
80	Fresh/RecAirDractOpenAngletarget	AirConditionSystem
81	VariableFlowChangeSolDutySetting	AirConditionSystem
82	Variablecompressorbreak-indrive	AirConditionSystem
83	Clear AT learning Value	ECT
84	AWD ON/OFF switching mode	ECT
85	Mode Transition	ABS
86	Brake Lamp Lighting Operation	ABS
87	Keyless ID erasure	Integ. unitmode
88	Keyless ID registration	Integ. unitmode
89	Fuel pump relay	ENGINE
90	CPC relay	ENGINE
91	Radiator Fan Relay	ENGINE
92	A/C Compressor Relay	ENGINE
93	PCV Solenoid Valve	ENGINE
94	Vent Control Solenoid Valve	ENGINE
95	Tank internal pressure exchange solenoid	ENGINE

96	Turbocharger Wastegate Solenoid	ENGINE
97	Secondary Air Combi Valve 1	ENGINE
98	Secondary Air Combi Valve 2	ENGINE
99	Sec. Air Pump Relay	ENGINE
100	CPC Relay 2	ENGINE
101	Sub Fuel Pump Relay	ENGINE
102	Fuel Pressure Switching Solenoid	ENGINE
103	ELCM switching valve	ENGINE
104	ELCM pump	ENGINE
105	Brake Vacuum Pump Relay	ENGINE
106	Immobilizer System	ENGINE
107	Injector Control	ENGINE
108	EGR Valve Control	ENGINE
109	LP-EGR Valve Control	ENGINE
110	Exhaust Control Valve Control	ENGINE
111	High Pressure Fuel Inspection	ENGINE
112	Alternator control	ENGINE
113	Active Grille Shutter Control	ENGINE
114	Compression monitor	ENGINE
115	Injector Code Registration Mode	ENGINE
116	Fuel pump duty learning	ENGINE
117	Fuel injector injection amount learning	ENGINE
118	EGR valve opening angle learning	ENGINE
119	Turbo vanes angle learning	ENGINE
120	Air flow sensor learning	ENGINE
121	Engine oil change	ENGINE
122	DPF change	ENGINE
123	DPF regeneration	ENGINE
124	Cancel Code(s) Display	ENGINE
125	ECU spec. information	ENGINE
126	F&R Clutch Solenoid	ECT
127	Secondary Solenoid	ECT
128	Primary Down Solenoid	ECT
129	Primary Up Solenoid	ECT
130	AWD Solenoid	ECT
131	Lock-Up Duty Solenoid	ECT
132	Lock-Up ON/OFF Solenoid	ECT
133	ECU spec. information	ECT
134	Brake Maintenance Mode	ABS
135	ECU spec. information	ABS
136	Heater cock valve output	Integ.unitmode
137	lock actuator LOCK output	Integ.unitmode
138	All seat UNLOCK output	Integ.unitmode
139	R gate/trunk UNLOCK output	Integ.unitmode
140	Double lock output	Integ.unitmode
141	Shift lock solenoid output	Integ.unitmode
142	Key lock solenoid output	Integ.unitmode
143	Keyless Buzzer Output	Integ.unitmode
144	EK alarm output	Integ.unitmode

145	Horn Output	Integ. unitmode
146	Panic Braking Hazard Light Signal	Integ. unitmode
147	Door Mirror Light Signal	Integ. unitmode
148	ECU spec. information	Integ. unitmode
149	Off delay time	Integ. unitmode
150	Auto lock time	Integ. unitmode
151	Rr Defogger op. mode	Integ. unitmode
152	Lockout prevention	Integ. unitmode
153	Abnormal warning lamp flashing setting	Integ. unitmode
154	Automatic lock setting	Integ. unitmode
155	Initial keyless setting	Integ. unitmode
156	Initial button setting	Integ. unitmode
157	Select unlock switch	Integ. unitmode
158	Door open warning	Integ. unitmode
159	Auto A/C setting	Integ. unitmode
160	Wiper Deicer setting	Integ. unitmode
161	Rear fog light setting	Integ. unitmode
162	Illumination Control On/Off	Integ. unitmode
163	Sedan/Wagon Setting	Integ. unitmode
164	MT/AT Setting	Integ. unitmode
165	6MT Setting	Integ. unitmode
166	Rain drop Detection Sensor Setting	Integ. unitmode
167	Illumination Sensor Setting	Integ. unitmode
168	Factory initial setting	Integ. unitmode
169	Auto Wiper/INT Setting	Integ. unitmode
170	Power rear gate setting	Integ. unitmode
171	Lane change signal setting	Integ. unitmode
172	Rear wiper auto setting	Integ. unitmode
173	Xmode SW setting	Integ. unitmode
174	TPMS Setting	Integ. unitmode
175	Driver's Door Unlock Setting	Integ. unitmode
176	Rear Gate Unlock Setting	Integ. unitmode
177	ECU spec. information	Occupant Detection System
178	Re-zeroing	Occupant Detection System
179	ECU spec. information	Keyless access system
180	Collation result history Clear	Keyless access system
181	ECU spec. information	Power Steering System
182	Clear Vehicle Specific Assist Map	Power Steering System
183	Sensor initial setting	Automatic Light and Wiper system
184	Auto Light Sensitivity Adjustment	Automatic Light and Wiper system
185	Auto Wiper/INT Setting	Automatic Light and Wiper system
186	Wiper link Auto Light Setting	Automatic Light and Wiper system
187	Auto Dimmer Cancel setting	Automatic Light and Wiper system
188	Auto Wiper at startup Setting	Automatic Light and Wiper system
189	Air temperature correction	Combination meter
190	Mean fuel efficiency correction	Combination meter
191	Rear seat belt warning customize	Combination meter
192	Second level belt warning customize	Combination meter
193	EPS setting presence state	Combination meter

194	Demonstration mode premission / fault permission	Combination meter
195	Speed Meter Operation	Combination meter
196	TachoMeter Operation	Combination meter
197	Fuel Meter Operation	Combination meter
198	Water thermometer	Combination meter
199	Voltmeter	Combination meter
200	Oil pressure gauge	Combination meter
201	Economy gauge	Combination meter
202	Power meter	Combination meter
203	LCD display all lighted	Combination meter
204	AT shift	Combination meter
205	MT shift	Combination meter
206	Odometer	Combination meter
207	Trip meter	Combination meter
208	Fuel gauge bar display	Combination meter
209	Water thermometer bar display	Combination meter
210	SPORT indicator	Combination meter
211	Shift-up indicator	Combination meter
212	CRUISE(CC) indicator	Combination meter
213	CRUISE(ACC) indicator	Combination meter
214	SET indicator	Combination meter
215	READY indicator	Combination meter
216	SI drive indicator	Combination meter
217	X mode indicator	Combination meter
218	Eyesight display	Combination meter
219	Each seat door display	Combination meter
220	[S] indicator	Combination meter
221	Lamp check	Combination meter
222	High-beam indicator	Combination meter
223	Position light indicator	Combination meter
224	Front fog light indicator	Combination meter
225	Rear fog light indicator	Combination meter
226	Water temperature (COOL) indicator	Combination meter
227	VDC OFF indicator	Combination meter
228	VDC operation/failure indicator	Combination meter
229	Hill start assist OFF/failure indicator	Combination meter
230	ECO indicator	Combination meter
231	SPORT indicator	Combination meter
232	Shift-up indicator	Combination meter
233	Glow indicator	Combination meter
234	Auto Start Stop operating light	Combination meter
235	Auto Start Stop OFF/failure indicator	Combination meter
236	LANE OFF indicator	Combination meter
237	P-CR OFF indicator	Combination meter
238	Hill descent assist indicator	Combination meter
239	EV mode indicator	Combination meter
240	HEV READY indicator	Combination meter
241	EPB hill hold indicator	Combination meter
242	Dual-range LO indicator	Combination meter

243	REV/RED ZONE indicator	Combination meter
244	Traction mode indicator	Combination meter
245	EPB active indicator	Combination meter
246	SPF OFF indicator	Combination meter
247	AFS OFF indicator	Combination meter
248	HBA indicator	Combination meter
249	SRVD OFF indicator	Combination meter
250	Driver side seat belt warning	Combination meter
251	Airbag warning	Combination meter
252	TPMS warning	Combination meter
253	No-key warning	Combination meter
254	All seats door warning	Combination meter
255	Water temperature (HOT) warning	Combination meter
256	E/G remaining oil warning	Combination meter
257	AT (CVT) oil temperature warning	Combination meter
258	R.DIFF oil temperature warning	Combination meter
259	ABS warning	Combination meter
260	BRAKE warning	Combination meter
261	EPB warning	Combination meter
262	EPB hill start assist warning	Combination meter
263	AWD warning	Combination meter
264	Sedimenter warning	Combination meter
265	DPF clogging warning	Combination meter
267	Remaining washer fluid washer	Combination meter
268	Remaining fuel warning	Combination meter
269	EPS warning	Combination meter
270	Diesel over-rev indicator	Combination meter
271	Remaining urea warning	Combination meter
272	EYESIGHT failure warning	Combination meter
273	Check E/G warning	Combination meter
274	Obstacle detected warning	Combination meter
275	Lane departure warning	Combination meter
276	Stay alert warning	Combination meter
277	HEV fail warning	Combination meter
278	Charge warning	Combination meter
279	Oil pressure warning	Combination meter
280	LED LO beam warning	Combination meter
281	Vacuum pump warning	Combination meter
282	Rear seat (right) seat belt warning	Combination meter
283	HID auto leveler warning	Combination meter
284	Passenger side seat belt warning	Combination meter
285	Rear seat (center) seat belt warning	Combination meter
286	Rear seat (left) seat belt warning	Combination meter
287	Mean fuel efficiency A display value	Combination meter
288	Lifetime fuel efficiency display value	Combination meter
289	Momentary fuel efficiency display value	Combination meter
290	Mean fuel efficiency B display value	Combination meter
291	Remaining fuel cruising distance display value	Combination meter
292	Ambient Air Temperature	Combination meter

293	Mean vehicle speed display value	Combination meter
294	Brightness check	Combination meter
295	Buzzer output	Combination meter
296	Display Operation Check Mode	Combination meter
297	ECU spec. information	Auto Start Stop
298	Engine start	Auto Start Stop
299	Cut relay ON/OFF drive	Auto Start Stop
300	Relay 1 ON/OFF drive	Auto Start Stop
301	Relay 2 ON/OFF drive	Auto Start Stop
302	ICR relay ON/OFF drive	Auto Start Stop
303	Electric oil pump control	Auto Start Stop
304	Relay ON/OFF drive	Auto Start Stop
305	Pump ON/OFF drive	Auto Start Stop
306	Sub power supply control	Auto Start Stop
307	Engine stop control	Auto Start Stop
308	Maintenance at the time of starter replacement	Auto Start Stop
309	Maintenance at the time of ECU replacement	Auto Start Stop
310	Turn signal ON stop prohibition setting	Auto Start Stop
311	Wiper ON stop prohibition setting	Auto Start Stop
312	Inclination stop prohibition setting	Auto Start Stop
313	Hazard lamp ON stop prohibition setting	Auto Start Stop
314	ECU spec. information	Hybrid Powertrain Control System
315	ISG Cranking Operation	Hybrid Powertrain Control System
316	ISG Voltage Control	Hybrid Powertrain Control System
317	Brake Vacuum Pump System Check	Hybrid Powertrain Control System
318	12V Battery Relay Operation	Hybrid Powertrain Control System
319	DCDC Converter Output Voltage Control	Hybrid Powertrain Control System
320	Engine only Drive Mode	Hybrid Powertrain Control System
321	Auto Start Stop Cancel Drive Mode (Engine only o	Hybrid Powertrain Control System
322	ECU spec. information	Air Condition System
323	Variable compressor break-in drive	Air Condition System
324	System Operation Check Mode	Air Condition System

SUZUKI Function list V9.22

- Notes:**
- ✓ Functions marked with ✓ is fully supported and already existed in former software version.
 - * Functions marked with * is fully supported and newly added in current software version.
 - # Functions marked with # is partially supported , which means the functions is verified on some vehicle models or systems and it might supports other vehicle models or systems.

Functions left with blank is not supported.

Vehicle	Mode	Read Codes	Erase Codes	Live Data	Actuators	ECU Infor	Special Function
	Engine	✓	✓	✓	✓	✓	1;8;9;10;11;12;13;14
	Transmission	✓	✓	✓	✓	✓	2;
	ABS	✓	✓	✓	✓	✓	4;5;
	Airbag	✓	✓	✓	✓	✓	
	BCM	✓	✓	✓	✓	✓	6;15
	AC	✓	✓	✓	✓	✓	
	Power Steering	✓	✓	✓	✓	✓	
	4WD	✓	✓	✓	✓	✓	
	Immobilizer	✓	✓	✓	✓	✓	3;7;
	AC2	✓	✓	✓	✓	✓	
	TPMS	✓	✓	✓	✓	✓	
	IPDM E/R	✓	✓	✓	✓	✓	
	Meter/M&A	✓	✓	✓	✓	✓	
	Speed Convert Controller	✓	✓	✓	✓	✓	
	DIFFLOCK	✓	✓	✓	✓	✓	
	OCM	✓	✓	✓	✓	✓	
	CNG/LPG	✓	✓	✓	✓	✓	
	Engine Auto Stop And Start	✓	✓	✓	✓	✓	
	Automatic Regulating Light Balance	✓	✓	✓	✓	✓	
	ACCM	✓	✓	✓	✓	✓	
	Electromagnet control device	✓	✓	✓	✓		
	Electrical vehicle motor system	✓	✓	✓	✓		
	SSPS	✓	✓	✓	✓		
	Theft Deterrent Module	✓	✓	✓	✓		
	Radio	✓	✓	✓	✓		
	Passenger Presence System	✓	✓	✓	✓		

Remote Control Door Lock Receiver	✓	✓	✓	✓		
Rollover Sensor	✓	✓	✓	✓		
Remote Function Actuation	✓	✓	✓	✓		

XTOOL

SUZUKI Work Support TABLE

Index NO.	Work Support Name	System Name
1	VIN_Registration	Engine
2	Configuration	Transmission
3	Keyless_Start_System	Immobilizer
4	ESP_function_setting	ABS
5	sensor_calibration	ABS
6	Configuration	BCM
7	Configuration	Immobilizer
8	Vehicle variant registration	Engine
9	Injector calibration code	Engine
10	Replace ECM	Engine
11	Initialize EGR valve data	Engine
12	Initialize inlet throttle valve data	Engine
13	Initialize Diesel PF data	Engine
14	Injector calibration code--Registration	Engine
15	Tire Type/Pressure Selection	BCM

TOYOTA(Europe or Others) Function list V11.57

Notes:

✓	Functions is fully supported and already existed in former software version.
*	Functions is fully supported and newly added in current software version.
#	Functions is partially supported , which means the functions is verified on some vehicle models or systems and it might supports other vehicle models or systems.
	Functions left with blank is not supported.

Module	Read Codes	Erase Codes	Freeze Frame	Live Data	Actuators	Special Function
Multi Bus Monitor No.1	✓	✓	※	✓	※	
Body No.2	✓	✓	※	✓	1-54	
Multi Bus Monitor No.2	✓	✓	※	✓	※	
Body No.3	✓	✓	※	✓	117-172	
Body No.4	✓	✓	※	✓	229-288	
Body No.5	✓	✓	※	✓	289-338	
A/B	✓	✓	※	✓	※	
ASC	✓	✓	※	✓	746-746	
ASG	✓	✓	※	✓	※	31
DRS	※	※	※	✓	※	32, 33, 35
E-ACM	✓	✓	※	✓	752-752	
ECB Gateway	✓	✓	※	✓	※	
EFI	✓	✓	※	✓	753-769	
EMPS	✓	✓	✓	✓	※	0B, 11, 12
EHPS	✓	✓	※	✓	※	0B, 11, 12
EV Battery	✓	✓	✓	✓	795-795	13, 81
EV	✓	✓	✓	✓	※	
Free-Tronic	✓	✓	✓	✓	813-816	0A, 77, 78
HL AutoLeveling	✓	✓	※	✓	※	6B
HV Gateway	✓	✓	※	✓	※	
IPA/Parking Assist Monitor	✓	✓	※	✓	※	2B
P Master Switch	✓	✓	※	✓	984-984	
PM2 Gateway	✓	✓	※	✓	※	
Tvss	✓	✓	※	✓	1003-1024	
Immobiliser	✓	✓	※	✓	1003-1024	
SRS Airbag	✓	✓	※	✓	※	0B
Back Door	✓	✓	※	✓	※	
Back Door P/W	✓	✓	※	✓	1055-1057	
Accessory Gateway	※	※	※	✓	※	
Lane Departure Alert	✓	✓	※	✓	1058-1058	37, 38
Plug-in Control	※	※	※	✓	1059-1060	
Lane Keeping Assist	✓	✓	✓	✓	※	

Vehicle Proximity Notification System	√	√	※	√	※	
Vehicle Control	√	√	※	√	1064-1075	64
Body	√	√	※	√	1076-1139	13
Gateway	√	√	※	√	1076-1139	13
Telematics	√	√	※	√	※	5A, 5B
Passenger Door	√	√	※	√	※	
Passenger Seat	※	※	※	√	1307-1318	
Occupant Detection	√	√	※	√	※	25, 26, 27, 28
Charging Control	√	√	※	√	1319-1320	
Navigation System	√	√	※	√	※	9B, 9C
Electric Power Control	√	√	※	√	1321-1325	0B, 20
EPS	√	√	※	√	※	
Electric Propulsion Control System	√	√	※	√	※	
Power Source Control	√	√	※	√	1326-1338	
Electric Parking Brake	√	√	※	√	1339-1356	
Multi-Mode M/T	√	√	※	√	1357-1359	
Multi Bus Gateway	√	√	※	√	※	
Engine2	√	√	√	√	※	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F, 54, 55, 56, 57, 6C, 6D, 76
Engine (RH Bank)	√	√	√	√	1541-1788	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F, 54, 55, 56, 57, 6C, 6D, 76
Steering Pad Switch	√	√	※	√	※	
ABS/VSC/TRC	√	√	√	√	※	1, 0A, 4, 0B, 0C, 0D, 0E, 36, 60, 61, 6E, 7F, 99, 9A
Immobiliser	※	※	※	√	1990-2006	16, 17, 51, 52, 53
Steering Lock	√	√	※	√	2007-2014	73

Theft System	✓	✓	※	✓	2007-2015	13, 14, 68, 74, 75
Grill Shutter	✓	✓	※	✓	※	60
Wiper	✓	✓	※	✓	2046-2048	
Rear Console Switch	✓	✓	※	✓	2049-2067	
Mirror L	✓	✓	✓	✓	2084-2093	
Mirror R	✓	✓	※	✓	2123-2136	
Front Right Door	✓	✓	✓	✓	※	
Driver Door	✓	✓	※	✓	2177-2191	
Rear Stabilizer	✓	✓	※	✓	2206-2206	2C
Sliding Roof	✓	✓	※	✓	2208-2208	
Sliding Sunshade	✓	✓	※	✓	※	
Hybrid Control	✓	✓	※	✓	2248-2266	4, 13, 5D, 5E, 5F, 6F, 70, 71, 72
Laser Cruise	✓	✓	※	✓	※	
Radar cruise	✓	✓	※	✓	※	22, 23, 24
Driver Door	✓	✓	※	✓	※	
D-Door Motor	※	※	※	✓	※	
Driver Seat	✓	✓	※	✓	※	
Clearance sonar	✓	✓	※	✓	2330-2333	1E
Entry&Start	✓	✓	※	✓	2347-2365	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F
Entry&Start (CAN)	※	※	※	✓	2366-2394	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F
Retractable Hardtop	✓	✓	※	✓	※	
A/C	※	※	※	✓	※	0F, 10, 9f
Air suspension	※	※	※	✓	※	0B, 18
AHC	✓	✓	※	✓	2644-2703	0B, 18
EMS	✓	✓	※	✓	2644-2704	
Radar cruise	✓	✓	※	✓	※	22, 23, 24
Laser Cruise	※	※	※	✓	※	
Tire Pressure Monitor	✓	✓	※	✓	※	0B, 20
Blind Spot Monitor Slave	✓	✓	※	✓	※	34, 7E

Blind Spot Monitor Master	✓	✓	※	✓	※	34, 7E
Pre-Crash 2	※	※	※	✓	2743-2749	13, 2E, 63
Pre-Crash	✓	✓	※	✓	2750-2753	42, 43, 48, 49, 4A
Starting Control	✓	✓	※	✓	※	
Front Stabilizer	✓	✓	※	✓	2758-2758	
Tilt&Telescopic	✓	✓	✓	✓	※	
4WD	※	※	※	✓	2838-2841	4, 2A
Stop and Start	✓	✓	✓	✓	2847-2864	44, 45, 46, 47, AC, AD, AE, AF, BO
AFS	✓	✓	※	✓	2917-2939	2B
HL AutoLeveling	✓	✓	※	✓	2917-2939	
Gateway V	✓	✓	※	✓	※	13
Gateway CAN	✓	✓	※	✓	※	13
Gateway	✓	✓	※	✓	※	13
Cruise Control	✓	✓	※	✓	※	
Remote Engine Starter	✓	✓	※	✓	※	2D, 9D, 9E
Night View	※	※	※	✓	3040-3049	58, 59
Engine and ECT	✓	✓	✓	✓	3752-4384	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F, 54, 55, 56, 57, 6C, 6D, 76, 83, 84, 85, 86, 87, 88, 89, 8A, 8B, 8C, 8D, 8E, 8F, 90, 91, 92, 93, 94, 95, 96, 97, 98

Engine	✓	✓	✓	✓	3752-4384	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F, 54, 55, 56, 57, 6C, 6D, 76, 83, 84, 85, 86, 87, 88, 89, 8A, 8B, 8C, 8D, 8E, 8F, 90, 91, 92, 93, 94, 95, 96, 97, 98
Engine (LH Bank)	✓	✓	✓	✓	3752-4384	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F, 54, 55, 56, 57, 6C, 6D, 76, 83, 84, 85, 86, 87, 88, 89, 8A, 8B, 8C, 8D, 8E, 8F, 90, 91, 92, 93, 94, 95, 96, 97, 98
RR-Door Motor	✓	✓	※	✓	4569-4569	
RR-Door	✓	✓	※	✓	※	
Rear Right Seat A/C	✓	✓	※	✓	※	
Rear Right Seat	✓	✓	※	✓	4599-4609	
Front Right Seat A/C	✓	✓	※	✓	4623-4626	
Rain Sensor	✓	✓	※	✓	※	
KDSS	✓	✓	✓	✓	4638-4641	65
Center Console Switch	✓	✓	※	✓	4726-4728	
Main Body	✓	✓	※	✓	4729-4799	13, 14, 15, 50
Active Rear Wing	✓	✓	※	✓	4800-4804	30
Active Headrest L	✓	✓	※	✓	※	
Active Headrest R	✓	✓	※	✓	※	
Main Switch	✓	✓	※	✓	※	

ECT	√	√	※	√	4906-5106, 5107-5271	4
Automatic High Beam	√	√	※	√	5361-5361	
Combination Switch	√	√	※	√	※	
Combination Meter	√	√	※	√	5362-5572	
Rear Left Door	√	√	※	√	5574-5598	
Rear Left Seat A/C	√	√	※	√	※	
Rear Left Seat	√	√	※	√	5625-5635	
Front Left Seat A/C	√	√	※	√	※	
Parking Assist Camera	√	√	※	√	※	
LKA/LDA	√	√	※	√	※	
LKA/LDA (Sub)	√	√	※	√	※	
Radar Cruise1	√	√	※	√	※	
Radar Cruise2	√	√	※	√	※	
LH Door	√	√	※	√	※	
Advanced Parking Guidance/ICS/Intuitive P/A	√	√	※	√	※	
Panoramic view monitor	√	√	※	√	※	
PCS/LDA/RSA/LVN	√	√	※	√	5653-5659	
Central Gateway	√	√	※	√	※	
Front Recognition Camera	√	√	※	√	5660	
Head Up Display	√	√	※	√	5661-5665	
Road Sign Assist	√	√	※	√	5666	
TVD	√	√	※	√	5667-5668	
PSD LH	√	√	※	√	※	
PSD RH	√	√	※	√	※	
Motor Generator	√	√	※	√	※	
Rear Motor Generator	√	√	※	√	※	
Restraint Control Module	√	√	※	√	※	
ABS/DSC/TCS	√	√	√	√	※	

Electronic- Controlled Power Steering	√	√	√	√	※	
SCBS	√	√	※	√	※	
Navigation Receiver	√	√	※	√	※	

XTOOL

TOYOTA(USA) Function list V11.56

Notes:

√	Functions is fully supported and already existed in former software version.
*	Functions is fully supported and newly added in current software version.
#	Functions is partially supported , which means the functions is verified on some vehcile models or systems and it might supports other vehcile models or systems.

Functions left with blank is not supported.

Module	Read Codes	Erase Codes	Freeze Frame	Live Data	Actuators	Special Function
Multi Bus Monitor No.1	√	√	※	√	※	
Body No.2	√	√	※	√	1-54	
Multi Bus Monitor No.2	√	√	※	√	※	
Body No.3	√	√	※	√	117-172	
Body No.4	√	√	※	√	229-288	
Body No.5	√	√	※	√	289-338	
ABS/VSC/TRAC	√	√	√	√	479-623	
AHC	√	√	※	√	699-745	0B, 18
ASC	√	√	※	√	746-746	
ASG	√	√	※	√	※	
DRS	※	※	※	√	※	
E-ACM	√	√	※	√	752-752	
ECB Gateway	√	√	※	√	※	
EHPS	√	√	※	√	※	0B, 11, 12
EMPS	√	√	√	√	※	0B, 11, 12
EMS	√	√	※	√	770-794	
EV Battery	√	√	√	√	795-795	66, 67
EV	√	√	√	√	※	
FC	√	√	※	√	809-811	
FCHV	√	√	※	√	812-812	
HL AutoLeveling	√	√	※	√	817-848	
HV Gateway	√	√	※	√	※	
P Master Switch	√	√	※	√	984-984	
PM2 Gateway	√	√	※	√	※	
SRS Airbag	√	√	※	√	※	0B
Back Door	√	√	※	√	※	

Back Door P/W	√	√	※	√	1055-1057	
Accessory Gateway	※	※	※	√	※	
Lane Departure Alert	√	√	※	√	1058-1058	37, 38
Plug-in Control	※	※	※	√	1059-1060	
Lane Keeping Assist	√	√	√	√	※	
Vehicle Proximity Notification System	√	√	※	√	※	
Body	√	√	※	√	1076-1139	13
Telematics	√	√	※	√	※	5A, 5B
Passenger Door	√	√	※	√	※	
Passenger Seat	※	※	※	√	1307-1318	
Occupant Detection	√	√	※	√	※	25, 26, 27, 28
Charging Control	√	√	※	√	1319-1320	
Navigation System	√	√	※	√	※	
Electric Power Control	√	√	※	√	1321-1325	
Electric Propulsion Control System	√	√	※	√	※	
Power Source Control	√	√	※	√	1326-1338	1F
Electric Parking Brake	√	√	※	√	1339-1356	
Multi Bus Gateway	√	√	※	√	※	
Engine2	√	√	√	√	※	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F, 54, 55, 56, 57
Steering Pad Switch	√	√	※	√	※	
ABS/VSC/TRC	√	√	√	√	1815-1989	1, 0A, 4, 0B, 0C, 0D, 0E, 36
Immobiliser	√	√	※	√	1990-2006	16, 17
Immobi	√	√	※	√	2015-2041	74, 75

Advanced Parking Guidance/Parking Assist Monitor	√	√	※	√	※	
Wiper	√	√	※	√	2046-2048	
Rear Console Switch	√	√	※	√	2049-2067	
Mirror R	√	√	※	√	※	
Mirror	√	√	※	√	2147-2176	
Rear Stabilizer	√	√	※	√	2206-2206	2C
Sliding Roof	√	√	※	√	2208-2208	
Sliding Sunshade	√	√	※	√	※	
Laser Cruise	√	√	※	√	※	22, 23, 24
Driver Door	√	√	※	√	※	
D-Door Motor	※	※	※	√	※	
Driver Seat	√	√	※	√	※	
Retractable Hardtop	√	√	※	√	※	
A/C	※	※	※	√	※	0F, 10
Air suspension	√	√	※	√	2581-2643	0B, 18
Radar cruise	√	√	※	√	※	22, 23, 24
Tire Pressure Monitor	√	√	※	√	※	0B, 20
Blind Spot Monitor Slave	√	√	※	√	※	
Blind Spot Monitor Master	√	√	※	√	※	34
Pre-Collision 2	※	※	※	√	2732-2738	13, 2E, 63
Pre-Collision	√	√	※	√	2739-2742	42, 43, 48, 49, 4A
Starting Control	√	√	※	√	※	
Front Stabilizer	√	√	※	√	2758-2758	
Tilt&Telescopic	√	√	√	√	※	
Mayday Gateway	√	√	※	√	※	
4WD	※	※	※	√	2838-2841	4, 2A
AFS	√	√	※	√	2890-2916	
Gateway CAN	√	√	※	√	※	13
Gateway V	√	√	※	√	※	13
Gateway	√	√	※	√	※	13
Battery	√	√	※	√	3036-3039	

In cruise control	√	√	※	√	※	
Remote Engine Starter	√	√	※	√	※	2D
Night View Engine	√	√	※	√	※	58, 59
Engine	√	√	√	√	3381-3584	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F, 54, 55, 56, 57
Engine and ECT	√	√	√	√	3752-4076	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F, 54, 55, 56, 57
RR-Door Motor	√	√	※	√	4569-4569	
Rear Right Door	√	√	※	√	※	
Rear Right Seat A/C	√	√	※	√	※	
Rear Right Seat	√	√	※	√	4599-4609	
Front Right Door	√	√	√	√	※	
Front Right Seat A/C	√	√	※	√	4623-4626	
Rain Sensor	√	√	※	√	※	
KDSS	√	√	√	√	4638-4641	65
Intuitive Parking Assist	√	√	※	√	4642-4645	
Smart Access	√	√	※	√	4646-4661	1A, 1B, 1C, 1D, 2F
Smart Key	※	※	※	√	4662-4711	1A, 1B, 1C, 1D, 2F
Center Console Switch	√	√	※	√	4726-4728	
Main Body	√	√	※	√	4729-4799	13, 14, 15, 50
Active Rear Wing	√	√	※	√	4800-4804	30
Main Switch	√	√	※	√	※	
Steering Lock	√	√	※	√	4888-4895	73
ECT	√	√	※	√	4906-5106	4
Combination Switch	√	√	※	√	※	
Combination Meter	√	√	※	√	5362-5572	

Rear Left Door	√	√	※	√	5574- 5598	
Rear Left Seat A/C	√	√	※	√	※	
Rear Left Seat	√	√	※	√	5625- 5635	
Front Left Seat A/C	√	√	※	√	※	
Parking Assist Camera	√	√	※	√	※	
LKA/LDA	√	√	※	√	※	
LKA/LDA (Sub)	√	√	※	√	※	
Radar Cruise1	√	√	※	√	※	
Radar Cruise2	√	√	※	√	※	
LH Door	√	√	※	√	※	
Advanced Parking Guidance/ICS/In tuitive P/A	√	√	※	√	※	
Panoramic view monitor	√	√	※	√	※	
PCS/LDA/RSA/LVN	√	√	※	√	5653- 5659	
Central Gateway	√	√	※	√	※	
Front Recognition Camera	√	√	※	√	5660	
Head Up Display	√	√	※	√	5661- 5665	
Road Sign Assist	√	√	※	√	5666	
TVD	√	√	※	√	5667- 5668	
PSD_LH	√	√	※	√	※	
PSD_RH	√	√	※	√	※	
Motor Generator	√	√	※	√	※	
Rear Motor Generator	√	√	※	√	※	
Restraint Control Module	√	√	※	√	※	
ABS/DSC/TCS	√	√	√	√	※	
Electronic- Controlled Power Steering	√	√	√	√	※	
SCBS	√	√	※	√	※	
Navigation Receiver	√	√	※	√	※	

TOYOTA(JAP) Function list V11.56

Notes:

√	Functions is fully supported and already existed in former software version.
*	Functions is fully supported and newly added in current software version.
#	Functions is partially supported , which means the functions is verified on some vehcile models or systems and it might supports other vehcle models or systems.
	Functions left with blank is not supported.

Module	Read Codes	Erase Codes	Freeze Frame	Live Data	Actuators	Special Function
Multi Bus Monitor No.1	√	√	※	√	※	
Body No.2	√	√	※	√	1-54	
Multi Bus Monitor No.2	√	√	※	√	※	
Body No.3	√	√	※	√	117-172	
Body No.4	√	√	※	√	229-288	
Body No.5	√	√	※	√	289-338	
ABS/VSC/TRAC	√	√	√	√	479-623	1, 0A, 4, 0B, 0C, 0D, 0E, 36, 6E
AHC	√	√	※	√	699-745	0B, 18
ASC	√	√	※	√	746-746	
ASG	√	√	※	√	※	31
DRS	※	※	※	√	※	32, 33, 35
E-ACM	√	√	※	√	752-752	
E-ACM	√	√	※	√	※	
EHPS	√	√	√	√	※	11, 12
EMPS	√	√	√	√	※	11, 12
EMS	√	√	※	√	770-794	
EV Battery	√	√	√	√	795-795	13
EV	√	√	√	√	※	
FC	√	√	※	√	809-811	
FCHV	√	√	※	√	812-812	
HL AutoLeveling	√	√	※	√	817-848	
HV Gateway	√	√	※	√	※	
P Master Switch	√	√	※	√	984-984	
PM2 Gateway	√	√	※	√	※	

SRS Airbag	✓	✓	※	✓	※	0B
Back Door	✓	✓	※	✓	※	
Back Door P/W	✓	✓	※	✓	1055-1057	
Accessory Gateway	※	※	※	✓	※	
Lane Departure Alert	✓	✓	※	✓	1058-1058	37, 38
Plug-in Control	※	※	※	✓	1059-1060	
Lane Keeping Assist	✓	✓	✓	✓	※	
Vehicle Proximity Notification System	✓	✓	※	✓	※	
Body	✓	✓	※	✓	1076-1139	13
Telematics	✓	✓	※	✓	※	5A, 5B
Passenger Door	✓	✓	※	✓	※	
Passenger Seat	※	※	※	✓	1307-1318	
Occupant Detection	✓	✓	※	✓	※	25, 26, 27, 28
Charging Control	✓	✓	※	✓	1319-1320	
Navigation System	✓	✓	※	✓	※	
Electric Power Control	✓	✓	※	✓	1321-1325	
Electric Propulsion Control System	✓	✓	※	✓	※	
Power Source Control	✓	✓	※	✓	1326-1338	1F
Electric Parking Brake	✓	✓	※	✓	1339-1356	
Multi Bus Gateway	✓	✓	※	✓	※	
Engine2	✓	✓	✓	✓	※	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F, 54, 55, 56, 57, 6C, 6D,
Steering Pad Switch	✓	✓	※	✓	※	

ABS/VSC/TRC	✓	✓	✓	✓	1815-1989	1, 0A, 4, 0B, 0C, 0D, 0E, 36
Immobiliser	✓	✓	※	✓	1990-2006, 2015-2041	16, 17
Advanced Parking Guidance/Parking Assist Monitor	✓	✓	※	✓	※	
Wiper	✓	✓	※	✓	2046-2048	
Rear Console Switch	✓	✓	※	✓	2049-2067	
Mirror R	✓	✓	※	✓	※	
Mirror	✓	✓	※	✓	2147-2176	
Rear Stabilizer	✓	✓	※	✓	2206-2206	2C
Sliding Roof	✓	✓	※	✓	2208-2208	
Sliding Sunshade	✓	✓	※	✓	※	
Laser Cruise	✓	✓	※	✓	※	
Driver Door	✓	✓	※	✓	※	
D-Door Motor	※	※	※	✓	※	
Driver Seat	✓	✓	※	✓	※	
Retractable Hardtop	✓	✓	※	✓	※	
A/C	※	※	※	✓	※	0F, 10
Air suspension	✓	✓	※	✓	2581-2643	0B, 18
Radar cruise	✓	✓	※	✓	※	22, 23, 24
Tire Pressure Monitor	✓	✓	※	✓	※	0B, 20
Blind Spot Monitor Slave	✓	✓	※	✓	※	34, 7E
Blind Spot Monitor Master	✓	✓	※	✓	※	34, 7E
Pre- Collision 2	※	※	※	✓	2732-2738	13, 2E, 63
Pre- Collision	✓	✓	※	✓	2739-2742	42, 43, 48, 49, 4A
Starting Control	✓	✓	※	✓	※	
Front Stabilizer	✓	✓	※	✓	2758-2758	
Tilt&Telescopic	✓	✓	✓	✓	※	
Mayday Gateway	✓	✓	※	✓	※	
4WD	※	※	※	✓	2838-2841	4, 2A
AFS	✓	✓	※	✓	2890-2916	2B
Gateway CAN	✓	✓	※	✓	※	
Gateway V	✓	✓	※	✓	※	
Gateway	✓	✓	※	✓	※	13

Battery	✓	✓	※	✓	3036-3039	13
In cruise control	✓	✓	※	✓	※	
Remote Engine Starter	✓	✓	※	✓	※	2D
Night View	✓	✓	※	✓	※	58, 59
Engine	✓	✓	✓	✓	3381-3584	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F, 54, 55, 56, 57, 6C, 6D,
Engine and ECT	✓	✓	✓	✓	3752-4076	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F, 54, 55, 56, 57, 6C, 6D,
RR-Door Motor	✓	✓	※	✓	4569-4569	
Rear Right Door	✓	✓	※	✓	※	
Rear Right Seat A/C	✓	✓	※	✓	※	
Rear Right Seat	✓	✓	※	✓	4599-4609	
Front Right Door	✓	✓	✓	✓	※	
Front Right Seat A/C	✓	✓	※	✓	4623-4626	
Rain Sensor	✓	✓	※	✓	※	
KDSS	✓	✓	✓	✓	4638-4641	65
Intuitive Parking Assist	✓	✓	※	✓	4642-4645	2B
Smart Access	✓	✓	※	✓	4646-4661	1A, 1B, 1C, 1D
Smart Key	※	※	※	✓	4662-4711	1A, 1B, 1C, 1D, 2F
Center Console Switch	✓	✓	※	✓	4726-4728	
Main Body	✓	✓	※	✓	4729-4799	13, 14, 15, 50

Active Rear Wing	✓	✓	※	✓	4800-4804	30
Main Switch	✓	✓	※	✓	※	
Steering Lock	✓	✓	※	✓	4888-4895	
ECT	✓	✓	※	✓	4906-5106	4
Combination Switch	✓	✓	※	✓	※	
Combination Meter	✓	✓	※	✓	5362-5572	
Rear Left Door	✓	✓	※	✓	5574-5598	
Rear Left Seat A/C	✓	✓	※	✓	※	
Rear Left Seat	✓	✓	※	✓	5625-5635	
Front Left Seat A/C	✓	✓	※	✓	※	
Body No. 2 (JZS, GS17#)	✓	✓	※	✓	55-85	
Body No. 2	✓	✓	※	✓	86-116	
Body No. 3 (GS, JZS, UZS)	✓	✓	※	✓	173-188	
Body No. 3 (Except GS, JZS, UZS)	✓	✓	※	✓	189-228	
Body No. 5	✓	✓	※	✓	※	
A/B	✓	✓	※	✓	※	
ABS- VSC	※	※	✓	✓	339-347	1, 0A, 4, 0B, 0C, 0D, 0E, 6E, A0, A1,
ABS- VSC- TRC	✓	✓	✓	✓	※	1, 0A, 4, 0B, 0C, 0D, 0E, 6E, A0, A1,
ABS/VSC	✓	✓	✓	✓	※	1, 0A, 4, 0B, 0C, 0D, 0E, 6E, A0, A1,
ACT RR seat headrest	✓	✓	※	✓	691-694	
ACT RL seat headrest	✓	✓	※	✓	695-698	
AMT	✓	✓	※	✓	※	69
CVT	✓	✓	※	✓	※	A6
EFI	✓	✓	※	✓	753-769	
EMPS (CAN brush / brushless)	✓	✓	✓	✓	※	
EMPS (EHPS system SIL ZZW)	✓	✓	✓	✓	※	

EMPS(Except SIL NHW11 brushless)	✓	✓	✓	✓	※	
EMPS(SIL NHW11 with brush)	✓	✓	✓	✓	※	
EMPS(SIL rack type)	✓	✓	✓	✓	※	
Back Guide Monitor IPA	✓	✓	※	✓	※	
ITC	✓	✓	※	✓	918-937	6A
KFS	✓	✓	※	✓	938-983	A3, A4, A5
PCB	✓	✓	※	✓	※	A9
Pre-crash seat back seat RL	✓	✓	※	✓	985-987	
Pre-crash seat back seat RR	✓	✓	※	✓	988-990	
Security	✓	✓	※	✓	1025- 1042	
Vehicle Control	✓	✓	※	✓	1064- 1075	
Body	✓	✓	※	✓	※	13
Body No. 3	✓	✓	※	✓	1189- 1239	
Body No. 5	✓	✓	※	✓	1240- 1269	
The motor- generator	✓	✓	※	※	※	
EPS	✓	✓	※	✓	※	
Engine (RH Bank)	✓	✓	✓	✓	1541- 1788	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3 A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C , 4D, 4E, 4F, 54, 5 5, 56, 57, 6C, 6D,
ABS	✓	✓	✓	✓	※	1, 0A, 4, 0B, 0C, 0 D, 0E, 36
Immobiliser(Internal Engine)	✓	✓	※	✓	※	16, 17
Grill Shutter	✓	✓	※	✓	※	
Back Door P/W	✓	✓	※	✓	※	
R DOOR	✓	✓	※	✓	※	
Mirror(Letf and Right)	✓	✓	※	✓	※	
Mayday Gateway	✓	✓	※	✓	2207- 2207	

Laser Cruise(Internal CAN Engine)	√	√	※	√	※	
Entry&Start	√	√	※	√	2334-2346	1A, 1B, 1C, 1D
Entry&Start(CAN)	※	※	※	√	2395-2422	1A, 1B, 1C, 1D
Entry&Start(SIL)	√	√	※	√	2423-2435	1A, 1B, 1C, 1D
eco IDLE	√	√	※	√	※	A7, A8
Movable pedal	√	√	※	√	※	
A/C	√	√	※	√	2446-2555	0F, 10
Air Suspension	√	√	※	√	2556-2580	0B, 18
Bluetooth Communication Module	√	√	※	√	2704-2704	7C, 7D
Radar Cruise(Internal SIL HV)	√	√	※	√	※	
Radar Cruise(Internal SIL Engine)	√	√	※	√	※	
Pre- Crash(SIL)	√	√	※	√	2754-2755	
HL AutoLeveling	√	√	※	√	2759-2793	
Panoramic View Monitor	※	※	※	√	※	
4WD(CAN)	※	※	※	√	2842-2846	4
Stop & Start	√	√	√	√	2865-2889	44, 45, 46, 47, 7A, 7B
Cruise Control(Internal CAN Engine)	√	√	※	√	※	
Cruise Control(Internal SIL2 Engine)	※	※	※	√	※	
Cruise Control(With built-in gasoline engine SIL)	√	√	※	√	※	
Cruise Control	√	√	※	√	※	
Night View Indicator	※	※	※	√	3050-3064	
Meter	√	√	※	√	3065-3298	AA, AB
Meter(SIL)	√	√	※	√	※	

Engine (SIL2)	✓	✓	✓	✓	3585-3751	1, 2, 3, 4, 5, 6, 7, 8, 9, 21, 29, 39, 3A, 3B, 3C, 3D, 3E, 3F, 40, 41, 4B, 4C, 4D, 4E, 4F, 54, 55, 56, 57, 6C, 6D
Wiper	✓	✓	※	✓	4627-4630	
Pre-Crash	※	※	※	✓	4631-4637	42, 43, 48, 49, 4A
KDSS	✓	✓	✓	✓	※	65
Diagnostic Recorder	※	※	※	✓	※	79
Intelligent Clearance Sonar	✓	✓	※	✓	※	
Active Headrest L	✓	✓	※	✓	※	
Active Headrest R	✓	✓	※	✓	※	
MASTER	✓	✓	※	✓	4813-4883	
A/T	✓	✓	※	✓	※	
ECT (SIL2)	✓	✓	※	✓	5272-5360	
Automatic High Beam	✓	✓	※	✓	5361-5361	
Mirror L	✓	✓	✓	✓	5599-5620	
Parking Assist Camera	✓	✓	※	✓	※	
LKA/LDA	✓	✓	※	✓	※	
LKA/LDA (Sub)	✓	✓	※	✓	※	
Radar Cruise1	✓	✓	※	✓	※	
Radar Cruise2	✓	✓	※	✓	※	
LH Door	✓	✓	※	✓	※	
Advanced Parking Guidance/ICS /Intuitive P/A	✓	✓	※	✓	※	
Panoramic view monitor	✓	✓	※	✓	※	
PCS/LDA/RSA/ LVN	✓	✓	※	✓	5653-5659	
Central Gateway	✓	✓	※	✓	※	
Front Recognition Camera	✓	✓	※	✓	5660	

Head Up Display	√	√	※	√	5661-5665	
Road Sign Assist	√	√	※	√	5666	
TVD	√	√	※	√	5667-5668	
PSD LH	√	√	※	√	※	
PSD RH	√	√	※	√	※	
Motor Generator	√	√	※	√	※	
Rear Motor Generator	√	√	※	√	※	
Restraint Control Module	√	√	※	√	※	
ABS/DSC/TCS	√	√	√	√	※	
Electronic-Controlled Power Steering	√	√	√	√	※	
SCBS	√	√	※	√	※	
Navigation Receiver	√	√	※	√	※	

Index	Actuators Name	Module
1	Bus Cut Relay No.1	Body No.2
2	Super Sonic Windshield Mirror	Body No.2
3	Security Horn	Body No.2
4	Security Indicator	Body No.2
5	Dimmer Signal	Body No.2
6	Rheostat Cancel Operation	Body No.2
7	Rheostat Operation	Body No.2
8	Interior Panel Relay	Body No.2
9	Passenger Buckle Light Output	Body No.2
10	Passenger Power Window Up/Down	Body No.2
11	Shock Detection Unlock	Body No.2
12	Open Door Warning Light	Body No.2
13	Head Light High	Body No.2
14	Headlight Relay	Body No.2
15	Head Light Cleaner	Body No.2
16	Illuminated Entry System	Body No.2
17	IG OFF P/W Control Permission Output	Body No.2
18	tuner power	Body No.2
19	Rear Buckle Light Output	Body No.2
20	Trunk and back-door open	Body No.2
21	Rear Room Light	Body No.2
22	Rear Washer Relay Operation	Body No.2
23	Rear Wiper Motor	Body No.2
24	Rear Defogger	Body No.2
25	Rear Fog Light Relay	Body No.2
26	Shift R Sign	Body No.2
27	Driver Buckle Light Output	Body No.2
28	Shoulder Belt Up/Down	Body No.2
29	Alter L Signal Output	Body No.2
30	Door Lock	Body No.2
31	License Light	Body No.2
32	Doom Relay Cut	Body No.2
33	Vehicle Horn	Body No.2
34	Front Fog Light Relay	Body No.2
35	Other ECU Power Cut	Body No.2
36	Relay of DRL	Body No.2
37	Intrusion Sensor Power	Body No.2
38	ALL Courtesy Output	Body No.2
39	Step Light Operation	Body No.2
40	Hazard	Body No.2
41	Taillight Relay	Body No.2
42	Wireless Buzzer	Body No.2
43	Wireless Buzzer (continuous sound)	Body No.2
44	Turn Light RH Relay Operation	Body No.2
45	RR Power Window Up/Down	Body No.2
46	Wiper Motor Lo	Body No.2
47	Wiper Motor Hi	Body No.2
48	Wiper Motor	Body No.2
49	Wiper Angle Control	Body No.2

50	Key Remainder Buzzer	Body No. 2
51	Center Console Light Operation	Body No. 2
52	bus cut relay No. 2	Body No. 2
53	Turn Light LH Relay Operation	Body No. 2
54	RL Power Window Up/Down	Body No. 2
55	Security Horn	Body No. 2 (JZS, GS17#)
56	Security Indicator	Body No. 2 (JZS, GS17#)
57	Rheostat Operation	Body No. 2 (JZS, GS17#)
58	ultrasonic mirror working	Body No. 2 (JZS, GS17#)
59	Passenger Buckle Light Output	Body No. 2 (JZS, GS17#)
60	Headlight Relay	Body No. 2 (JZS, GS17#)
61	Illuminated Entry System	Body No. 2 (JZS, GS17#)
62	power window working	Body No. 2 (JZS, GS17#)
63	tuner power	Body No. 2 (JZS, GS17#)
64	Rear Buckle Light Output	Body No. 2 (JZS, GS17#)
65	Trunk and back-door open	Body No. 2 (JZS, GS17#)
66	Rear Washer Relay Operation	Body No. 2 (JZS, GS17#)
67	Rear Fog Light Relay	Body No. 2 (JZS, GS17#)
68	shift lock (gate type only)	Body No. 2 (JZS, GS17#)
69	Driver Buckle Light Output	Body No. 2 (JZS, GS17#)
70	Alter L Signal Output	Body No. 2 (JZS, GS17#)
71	Vehicle Horn	Body No. 2 (JZS, GS17#)
72	Front Fog Light Relay	Body No. 2 (JZS, GS17#)
73	ALL Courtesy Output	Body No. 2 (JZS, GS17#)
74	Hazard	Body No. 2 (JZS, GS17#)
75	Taillight Relay	Body No. 2 (JZS, GS17#)
76	Wireless Buzzer (continuous sound)	Body No. 2 (JZS, GS17#)
77	Wireless Rock	Body No. 2 (JZS, GS17#)
78	Turn Light RH Relay Operation	Body No. 2 (JZS, GS17#)
79	Wiper Motor Lo	Body No. 2 (JZS, GS17#)
80	Wiper Motor Hi	Body No. 2 (JZS, GS17#)
81	Wiper Motor	Body No. 2 (JZS, GS17#)
82	Wiper Angle Control	Body No. 2 (JZS, GS17#)
83	Key Remainder Buzzer	Body No. 2 (JZS, GS17#)
84	bus cut relay No. 2	Body No. 2 (JZS, GS17#)
85	Turn Light LH Relay Operation	Body No. 2 (JZS, GS17#)
86	Security Horn	Body No. 2
87	Security Indicator	Body No. 2
88	Rheostat Operation	Body No. 2
89	ultrasonic mirror working	Body No. 2
90	Passenger Buckle Light Output	Body No. 2
91	Headlight Relay	Body No. 2
92	Illuminated Entry System	Body No. 2
93	power window working	Body No. 2
94	tuner power	Body No. 2
95	Rear Buckle Light Output	Body No. 2
96	Trunk and back-door open	Body No. 2
97	Rear Washer Relay Operation	Body No. 2
98	Rear Fog Light Relay	Body No. 2
99	shift lock (gate type only)	Body No. 2
100	Driver Buckle Light Output	Body No. 2

101	Alter L Signal Output	Body No. 2
102	Vehicle Horn	Body No. 2
103	Front Fog Light Relay	Body No. 2
104	ALL Courtesy Output	Body No. 2
105	Hazard	Body No. 2
106	Taillight Relay	Body No. 2
107	Wireless Buzzer (continuous sound)	Body No. 2
108	Wireless Rock	Body No. 2
109	Turn Light RH Relay Operation	Body No. 2
110	Wiper Motor Lo	Body No. 2
111	Wiper Motor Hi	Body No. 2
112	Wiper Motor	Body No. 2
113	Wiper Angle Control	Body No. 2
114	Key Remainder Buzzer	Body No. 2
115	bus cut relay No. 2	Body No. 2
116	Turn Light LH Relay Operation	Body No. 2
117	Buckle Light 2	Body No. 3
118	Cornering Light LH Operation	Body No. 3
119	Cornering Light RH Operation	Body No. 3
120	Rear Room Light LH	Body No. 3
121	Oil Film Washer Motor Operation	Body No. 3
122	Rear Room Light RH	Body No. 3
123	Shoulder Anchor Operation	Body No. 3
124	Buckle Light 1	Body No. 3
125	Clearance Light Operation	Body No. 3
126	Interior Light (Dim) Operation	Body No. 3
127	Interior Panel Relay	Body No. 3
128	HEAD Light (Low/High)	Body No. 3
129	Light Head (Low)	Body No. 3
130	Light Head (High)	Body No. 3
131	Backup Light	Body No. 3
132	Reverse Signal Control	Body No. 3
133	Illuminated Entry System	Body No. 3
134	Shift Light Operation	Body No. 3
135	High Mount Stop Light	Body No. 3
136	Rear Room Light	Body No. 3
137	Rear Defogger	Body No. 3
138	Rear Fog Light	Body No. 3
139	Rear Sunshade Operation	Body No. 3
140	Heater Relay	Body No. 3
141	Deck Lamp	Body No. 3
142	Alter L Signal Output	Body No. 3
143	Interior Light Operation	Body No. 3
144	Horn Relay Operation	Body No. 3
145	License Light	Body No. 3
146	Front Room Light	Body No. 3
147	Front Fog Light Relay	Body No. 3
148	Light Head HI DRL Operation	Body No. 3
149	Washer Motor Operation	Body No. 3
150	Fuel Lid Open	Body No. 3
151	Step Light Operation	Body No. 3

152	Stop Light	Body No. 3
153	Exterior Foot Light Operation	Body No. 3
154	Tail Light	Body No. 3
155	Luggage Light Control	Body No. 3
156	Trunk Lid Open	Body No. 3
157	Deck Light	Body No. 3
158	RH Stop Light	Body No. 3
159	RH Tail Light	Body No. 3
160	RH Rear Personal Light	Body No. 3
161	Wiper Motor Lo	Body No. 3
162	Wiper Motor Hi	Body No. 3
163	Wiper Angle Control	Body No. 3
164	Illuminated Relay Operation	Body No. 3
165	Center Console Light Operation	Body No. 3
166	Turn Light LH	Body No. 3
167	Turn Light RH	Body No. 3
168	Steering Light Operation	Body No. 3
169	LH Stop Light	Body No. 3
170	LH Tail Light	Body No. 3
171	LH Rear Personal Light	Body No. 3
172	Seat Light Operation	Body No. 3
173	Backup Light	Body No. 3 (GS, JZS, UZS)
174	Illuminated Entry System	Body No. 3 (GS, JZS, UZS)
175	High Mount Stop Light	Body No. 3 (GS, JZS, UZS)
176	Rear Fog Light	Body No. 3 (GS, JZS, UZS)
177	Deck Lamp	Body No. 3 (GS, JZS, UZS)
178	head lamp Lo relay	Body No. 3 (GS, JZS, UZS)
179	Front Fog Light Relay	Body No. 3 (GS, JZS, UZS)
180	Trunk Lid Open	Body No. 3 (GS, JZS, UZS)
181	RH Stop Light	Body No. 3 (GS, JZS, UZS)
182	RH Tail Light	Body No. 3 (GS, JZS, UZS)
183	RH Rear Personal Light	Body No. 3 (GS, JZS, UZS)
184	head lamp Hi relay	Body No. 3 (GS, JZS, UZS)
185	Illuminated Relay Operation	Body No. 3 (GS, JZS, UZS)
186	LH Stop Light	Body No. 3 (GS, JZS, UZS)
187	LH Tail Light	Body No. 3 (GS, JZS, UZS)
188	LH Rear Personal Light	Body No. 3 (GS, JZS, UZS)
189	Rear Room Light LH	Body No. 3 (Except GS, JZS, UZS)
190	Lh cornering lamps	Body No. 3 (Except GS, JZS, UZS)
191	Rear Room Light RH	Body No. 3 (Except GS, JZS, UZS)
192	Rh cornering lamps	Body No. 3 (Except GS, JZS, UZS)
193	Shoulder Anchor Operation	Body No. 3 (Except GS, JZS, UZS)
194	Buckle Light 1	Body No. 3 (Except GS, JZS, UZS)
195	buckle lighting	Body No. 3 (Except GS, JZS, UZS)
196	Clearance Light Operation	Body No. 3 (Except GS, JZS, UZS)
197	Interior Light (Dim) Operation	Body No. 3 (Except GS, JZS, UZS)
198	Interior Panel Relay	Body No. 3 (Except GS, JZS, UZS)
199	Light Head (High)	Body No. 3 (Except GS, JZS, UZS)
200	Backup Light	Body No. 3 (Except GS, JZS, UZS)

201	Reverse Signal Control	Body No. 3 (Except GS, JZS, UZS)
202	Shift Light Operation	Body No. 3 (Except GS, JZS, UZS)
203	High Mount Stop Light	Body No. 3 (Except GS, JZS, UZS)
204	Rear Fog Light	Body No. 3 (Except GS, JZS, UZS)
205	Rear Sunshade Operation	Body No. 3 (Except GS, JZS, UZS)
206	Alter L Signal Output	Body No. 3 (Except GS, JZS, UZS)
207	Interior Light Operation	Body No. 3 (Except GS, JZS, UZS)
208	Horn Relay Operation	Body No. 3 (Except GS, JZS, UZS)
209	License Light	Body No. 3 (Except GS, JZS, UZS)
210	Front Room Light	Body No. 3 (Except GS, JZS, UZS)
211	Front Fog Light Relay	Body No. 3 (Except GS, JZS, UZS)
212	Washer Motor Operation	Body No. 3 (Except GS, JZS, UZS)
213	Fuel Lid Open	Body No. 3 (Except GS, JZS, UZS)
214	Step Light Operation	Body No. 3 (Except GS, JZS, UZS)
215	Stop Light	Body No. 3 (Except GS, JZS, UZS)
216	Exterior Foot Light Operation	Body No. 3 (Except GS, JZS, UZS)
217	Tail Light	Body No. 3 (Except GS, JZS, UZS)
218	Luggage Light Control	Body No. 3 (Except GS, JZS, UZS)
219	Trunk Lid Open	Body No. 3 (Except GS, JZS, UZS)
220	oil slick up washer motor	Body No. 3 (Except GS, JZS, UZS)
221	Wiper Motor Lo	Body No. 3 (Except GS, JZS, UZS)
222	Wiper Motor Hi	Body No. 3 (Except GS, JZS, UZS)
223	Wiper Angle Control	Body No. 3 (Except GS, JZS, UZS)
224	Center Console Light Operation	Body No. 3 (Except GS, JZS, UZS)
225	Turn Light LH	Body No. 3 (Except GS, JZS, UZS)
226	Turn Light RH	Body No. 3 (Except GS, JZS, UZS)
227	Steering Light Operation	Body No. 3 (Except GS, JZS, UZS)

228	Seat Light Operation	Body No.3 (Except GS, JZS, UZS)
229	Buckle Light 2	Body No. 4
230	Cornering Light LH Operation	Body No. 4
231	Cornering Light RH Operation	Body No. 4
232	Rear Room Light LH	Body No. 4
233	Lh cornering lamps	Body No. 4
234	Oil Film Washer Motor Operation	Body No. 4
235	Rear Room Light RH	Body No. 4
236	RL seat buckle lighting	Body No. 4
237	RR seat buckle lighting	Body No. 4
238	Rh cornering lamps	Body No. 4
239	Shoulder Anchor Operation	Body No. 4
240	Driver Side Shoulder Anchor	Body No. 4
241	Buckle Light 1	Body No. 4
242	buckle lighting	Body No. 4
243	Clearance Light Operation	Body No. 4
244	Inside Handle Illumination	Body No. 4
245	Interior Panel Relay	Body No. 4
246	Light Head (Low)	Body No. 4
247	Light Head (High)	Body No. 4
248	Backup Light	Body No. 4
249	Reverse Signal Control	Body No. 4
250	Illuminated Entry System	Body No. 4
251	Shift Light Operation	Body No. 4
252	High Mount Stop Light	Body No. 4
253	Rear A/C Magnetic Valve	Body No. 4
254	Rear Room Light	Body No. 4
255	Tail Gate Panel Open	Body No. 4
256	Rear Defogger	Body No. 4
257	Rear Step Light	Body No. 4
258	Rear Fog Light	Body No. 4
259	Rear Wiper Lo	Body No. 4
260	Rear Sunshade Operation	Body No. 4
261	Heater Relay	Body No. 4
262	Driver Side Buckle Light	Body No. 4
263	Alter L Signal Output	Body No. 4
264	Horn Relay Operation	Body No. 4
265	License Light	Body No. 4
266	Front Room Light	Body No. 4
267	Front Passenger Side Shoulder Anchor	Body No. 4
268	Front Passenger Side Buckle Light	Body No. 4
269	Front Washer Nozzle Heater	Body No. 4
270	Front Fog Light Relay	Body No. 4
271	Light Head HI DRL Operation	Body No. 4
272	Washer Motor Operation	Body No. 4
273	Fuel Lid Open	Body No. 4
274	Step Light Operation	Body No. 4
275	Stop Light	Body No. 4
276	Tail Light	Body No. 4
277	Luggage Light Control	Body No. 4

278	Trunk Lid Open	Body No. 4
279	Deck Light	Body No. 4
280	oil slick up washer motor	Body No. 4
281	Wiper Motor Lo	Body No. 4
282	Wiper Motor Hi	Body No. 4
283	Wiper Angle Control	Body No. 4
284	Center Console Light Operation	Body No. 4
285	Turn Light LH	Body No. 4
286	Turn Light RH	Body No. 4
287	Steering Light Operation	Body No. 4
288	Seat Light Operation	Body No. 4
289	Buckle Light 2	Body No. 5
290	Cornering Light LH Operation	Body No. 5
291	Cornering Light RH Operation	Body No. 5
292	Rear Room Light LH	Body No. 5
293	Oil Film Washer Motor Operation	Body No. 5
294	Rear Room Light RH	Body No. 5
295	Shoulder Anchor Operation	Body No. 5
296	Buckle Light 1	Body No. 5
297	Security Horn	Body No. 5
298	Clearance Light Operation	Body No. 5
299	Interior Panel Relay	Body No. 5
300	Head Light HI DRL Operation	Body No. 5
301	Head Light Low	Body No. 5
302	Head Light High	Body No. 5
303	Light Head (Low)	Body No. 5
304	Light Head (High)	Body No. 5
305	Head Light Cleaner	Body No. 5
306	Backup Light	Body No. 5
307	Reverse Signal Control	Body No. 5
308	Shift Light Operation	Body No. 5
309	High Mount Stop Light	Body No. 5
310	Rear Room Light	Body No. 5
311	Rear Defogger Operation	Body No. 5
312	Rear Defogger	Body No. 5
313	Rear Fog Light	Body No. 5
314	Heater Relay	Body No. 5
315	Alter L Signal Output	Body No. 5
316	Horn Relay Operation	Body No. 5
317	License Light	Body No. 5
318	Front Room Light	Body No. 5
319	Front Fog Light Relay	Body No. 5
320	Light Head HI DRL Operation	Body No. 5
321	Washer Motor Operation	Body No. 5
322	Fuel Lid Open	Body No. 5
323	Step Light Operation	Body No. 5
324	Stop Light	Body No. 5
325	Tail Light	Body No. 5
326	Wireless Buzzer (continuous sound)	Body No. 5
327	Luggage Light Control	Body No. 5
328	Trunk Lid Open	Body No. 5

329	Deck Light	Body No. 5
330	Wiper Motor Lo	Body No. 5
331	Wiper Motor Hi	Body No. 5
332	Wiper Deicer	Body No. 5
333	Wiper Angle Control	Body No. 5
334	Center Console Light Operation	Body No. 5
335	Turn Light LH	Body No. 5
336	Turn Light RH	Body No. 5
337	Steering Light Operation	Body No. 5
338	Seat Light Operation	Body No. 5
339	ABS lamp	ABS- VSC
340	ABS solenoid	ABS- VSC
341	SLA current solenoid	ABS- VSC
342	SLR current solenoid	ABS- VSC
343	VSC- HB buzzer	ABS- VSC
344	SOL RELAY	ABS- VSC
345	Motor Relay	ABS- VSC
346	switching solenoid	ABS- VSC
347	BRAKE WRN LIGHT	ABS- VSC
348	4WD warning lamp	
349	ABS lamp	
350	ABS solenoid	
351	ABS MOT RELAY	
352	ARS actuator	
353	ARS warning lamp	
354	PPS Solenoid	
355	SLIP lamp	
356	TRC OFF lamp	
357	TRC motor relay	
358	VSC- HB buzzer	
359	VSC, TRC solenoid	
360	VSC lamp	
361	SOL RELAY	
362	sub-throttle	
363	stop lamp relay	
364	Pre-Charge Pump	
365	BRAKE WRN LIGHT	
366	4WD Warning Light	ABS- VSC- TRC
367	4WD warning lamp	ABS- VSC- TRC
368	A-TRC(TRAC) Indicator Light	ABS- VSC- TRC
369	ABS lamp	ABS- VSC- TRC
370	ABS solenoid	ABS- VSC- TRC
371	ABS MOT RELAY	ABS- VSC- TRC
372	ABS Warning Light	ABS- VSC- TRC
373	ARS actuator	ABS- VSC- TRC
374	ARS warning lamp	ABS- VSC- TRC
375	BH Operated Light	ABS- VSC- TRC
376	BH Standby Light	ABS- VSC- TRC
377	DAB Indicator Light	ABS- VSC- TRC
378	DSS Signal Buzzer	ABS- VSC- TRC
379	ECB Solenoid (SC1)	ABS- VSC- TRC

380	ECB Solenoid (SC2)	ABS- VSC- TRC
381	ECB Solenoid (SCC)	ABS- VSC- TRC
382	ECB Solenoid (SCSS)	ABS- VSC- TRC
383	ECB Solenoid (SLAFL) Valve Open	ABS- VSC- TRC
384	ECB Solenoid (SLAFL) Valve Close	ABS- VSC- TRC
385	ECB Solenoid (SLAFR) Valve Open	ABS- VSC- TRC
386	ECB Solenoid (SLAFR) Valve Close	ABS- VSC- TRC
387	ECB Solenoid (SLARL) Valve Open	ABS- VSC- TRC
388	ECB Solenoid (SLARL) Valve Close	ABS- VSC- TRC
389	ECB Solenoid (SLARR) Valve Open	ABS- VSC- TRC
390	ECB Solenoid (SLARR) Valve Close	ABS- VSC- TRC
391	ECB Solenoid (SLA) Valve Close	ABS- VSC- TRC
392	ECB Solenoid (SLRFL) Valve Open	ABS- VSC- TRC
393	ECB Solenoid (SLRFL) Valve Close	ABS- VSC- TRC
394	ECB Solenoid (SLRFR) Valve Open	ABS- VSC- TRC
395	ECB Solenoid (SLRFR) Valve Close	ABS- VSC- TRC
396	ECB Solenoid (SLRRL) Valve Open	ABS- VSC- TRC
397	ECB Solenoid (SLRRL) Valve Close	ABS- VSC- TRC
398	ECB Solenoid (SLRRR) Valve Open	ABS- VSC- TRC
399	ECB Solenoid (SLRRR) Valve Close	ABS- VSC- TRC
400	ECB Solenoid (SLR) Valve Close	ABS- VSC- TRC
401	ECB Solenoid (SMC/SRC/SCC)	ABS- VSC- TRC
402	ECB Solenoid (SMC1)	ABS- VSC- TRC
403	ECB Solenoid (SMC2)	ABS- VSC- TRC
404	ECB Solenoid (SMC)	ABS- VSC- TRC
405	ECB Solenoid (SRC)	ABS- VSC- TRC
406	ECB Solenoid (SSC)	ABS- VSC- TRC
407	ECB Warning Light	ABS- VSC- TRC
408	ESS lamp	ABS- VSC- TRC
409	ESS buzzer	ABS- VSC- TRC
410	H/B Motor Relay	ABS- VSC- TRC
411	HB buzzer	ABS- VSC- TRC
412	HB motor relay	ABS- VSC- TRC
413	PPS Solenoid	ABS- VSC- TRC
414	SCSS valve pattern	ABS- VSC- TRC
415	SLAFL (communication valve closed)	ABS- VSC- TRC
416	SLAFR (communication valve closed)	ABS- VSC- TRC
417	SLARL (communication valve closed)	ABS- VSC- TRC
418	SLARR (communication valve closed)	ABS- VSC- TRC
419	SLA current solenoid	ABS- VSC- TRC
420	SLIP lamp	ABS- VSC- TRC
421	SLRFL (communication valve closed)	ABS- VSC- TRC
422	SLRFR (communication valve closed)	ABS- VSC- TRC
423	SLRRL (communication valve closed)	ABS- VSC- TRC
424	SLRRR (communication valve closed)	ABS- VSC- TRC
425	SLR current solenoid	ABS- VSC- TRC
426	SS	ABS- VSC- TRC
427	TPMS Warning Light	ABS- VSC- TRC
428	TRC OFF lamp	ABS- VSC- TRC
429	TRC motor relay	ABS- VSC- TRC
430	VSC- HB buzzer	ABS- VSC- TRC

431	VSC/TRAC OFF Indicator Light	ABS- VSC- TRC
432	VSC/TRC(TRAC) Solenoid	ABS- VSC- TRC
433	VSC, TRC solenoid	ABS- VSC- TRC
434	VSC lamp	ABS- VSC- TRC
435	VSC OFF Indicator Light	ABS- VSC- TRC
436	Pump Check Pattern	ABS- VSC- TRC
437	VSC Warning Light	ABS- VSC- TRC
438	Stroke Simulator Cut Valve Pattern	ABS- VSC- TRC
439	Slip Indicator Light	ABS- VSC- TRC
440	Solenoid (SMC1)	ABS- VSC- TRC
441	Solenoid (SMC2)	ABS- VSC- TRC
442	Solenoid (SS)	ABS- VSC- TRC
443	SOL RELAY	ABS- VSC- TRC
444	Motor Relay	ABS- VSC- TRC
445	Power supply pattern drive 1	ABS- VSC- TRC
446	Power supply pattern drive 2	ABS- VSC- TRC
447	Power Supply Air Bleeding Pattern1	ABS- VSC- TRC
448	Power Supply Air Bleeding Pattern2	ABS- VSC- TRC
449	ECB Motor Relay	ABS- VSC- TRC
450	ECB Motor Relay2	ABS- VSC- TRC
451	ECB Main Relay	ABS- VSC- TRC
452	ECB Main Relay2	ABS- VSC- TRC
453	Buzzer	ABS- VSC- TRC
454	sub-throttle	ABS- VSC- TRC
455	Crawl Control Light	ABS- VSC- TRC
456	EBS relay	ABS- VSC- TRC
457	Motor Relay1	ABS- VSC- TRC
458	Motor Relay2	ABS- VSC- TRC
459	Drain System Air Bleeding Pattern	ABS- VSC- TRC
460	TRC(TRAC) OFF Indicator Light	ABS- VSC- TRC
461	Pre Crash Brake OFF Light	ABS- VSC- TRC
462	Tire Pressure Light	ABS- VSC- TRC
463	Stop light System Indicator Light	ABS- VSC- TRC
464	stop lamp relay	ABS- VSC- TRC
465	Downhill Assist Control Light	ABS- VSC- TRC
466	RR Wheel Air Bleeding Pattern	ABS- VSC- TRC
467	Pre-Charge Pump	ABS- VSC- TRC
468	Station blur cut relay	ABS- VSC- TRC
469	actuator operation confirmation	ABS- VSC- TRC
470	Actuator Air Bleeding Pattern	ABS- VSC- TRC
471	actuator patterns drive	ABS- VSC- TRC
472	brake warning lamp (yellow)	ABS- VSC- TRC
473	BRAKE WRN LIGHT	ABS- VSC- TRC
474	Brake Warning Light	ABS- VSC- TRC
475	brake control prohibition	ABS- VSC- TRC
476	Auto LSD light	ABS- VSC- TRC
477	Auto LSD Indicator Light	ABS- VSC- TRC
478	RL Wheel Air Bleeding Pattern	ABS- VSC- TRC
479	4WD Warning Light	ABS/VSC/TRAC
480	A-TRC(TRAC) Indicator Light	ABS/VSC/TRAC
481	ABS solenoid	ABS/VSC/TRAC

482	ABS Solenoid (SFLR & SFLH)	ABS/VSC/TRAC
483	ABS Solenoid (SFRH & SFLH)	ABS/VSC/TRAC
484	ABS Solenoid (SFRR & SFRH)	ABS/VSC/TRAC
485	ABS Solenoid (SRLR & SRLH)	ABS/VSC/TRAC
486	ABS Solenoid (SRRR & SRRH)	ABS/VSC/TRAC
487	ABS Solenoid (SRRH)	ABS/VSC/TRAC
488	ABS Solenoid (SRRR)	ABS/VSC/TRAC
489	ABS Solenoid (SFRH)	ABS/VSC/TRAC
490	ABS Solenoid (SFRR)	ABS/VSC/TRAC
491	ABS Solenoid (SRLH)	ABS/VSC/TRAC
492	ABS Solenoid (SRLR)	ABS/VSC/TRAC
493	ABS Solenoid (SFLH)	ABS/VSC/TRAC
494	ABS Solenoid (SFLR)	ABS/VSC/TRAC
495	ABS MOT RELAY	ABS/VSC/TRAC
496	ABS Warning Light	ABS/VSC/TRAC
497	ARS warning lamp	ABS/VSC/TRAC
498	ASR/TRAC Warning Light	ABS/VSC/TRAC
499	BH Operated Light	ABS/VSC/TRAC
500	BH Standby Light	ABS/VSC/TRAC
501	DAB Indicator Light	ABS/VSC/TRAC
502	DSS Signal Buzzer	ABS/VSC/TRAC
503	ECB Solenoid (SC1)	ABS/VSC/TRAC
504	ECB Solenoid (SC2)	ABS/VSC/TRAC
505	ECB Solenoid (SCC)	ABS/VSC/TRAC
506	ECB Solenoid (SCSS)	ABS/VSC/TRAC
507	ECB Solenoid (SLAFL) Valve Open	ABS/VSC/TRAC
508	ECB Solenoid (SLAFL) Valve Close	ABS/VSC/TRAC
509	ECB Solenoid (SLAFR) Valve Open	ABS/VSC/TRAC
510	ECB Solenoid (SLAFR) Valve Close	ABS/VSC/TRAC
511	ECB Solenoid (SLARL) Valve Open	ABS/VSC/TRAC
512	ECB Solenoid (SLARL) Valve Close	ABS/VSC/TRAC
513	ECB Solenoid (SLARR) Valve Open	ABS/VSC/TRAC
514	ECB Solenoid (SLARR) Valve Close	ABS/VSC/TRAC
515	ECB Solenoid (SLA) Valve Close	ABS/VSC/TRAC
516	ECB Solenoid (SLRFL) Valve Open	ABS/VSC/TRAC
517	ECB Solenoid (SLRFL) Valve Close	ABS/VSC/TRAC
518	ECB Solenoid (SLRFR) Valve Open	ABS/VSC/TRAC
519	ECB Solenoid (SLRFR) Valve Close	ABS/VSC/TRAC
520	ECB Solenoid (SLRRL) Valve Open	ABS/VSC/TRAC
521	ECB Solenoid (SLRRL) Valve Close	ABS/VSC/TRAC
522	ECB Solenoid (SLRRR) Valve Open	ABS/VSC/TRAC
523	ECB Solenoid (SLRRR) Valve Close	ABS/VSC/TRAC
524	ECB Solenoid (SLR) Valve Close	ABS/VSC/TRAC
525	ECB Solenoid (SMC/SRC/SCC)	ABS/VSC/TRAC
526	ECB Solenoid (SMC1)	ABS/VSC/TRAC
527	ECB Solenoid (SMC2)	ABS/VSC/TRAC
528	ECB Solenoid (SMC)	ABS/VSC/TRAC
529	ECB Solenoid (SRC)	ABS/VSC/TRAC
530	ECB Solenoid (SSC)	ABS/VSC/TRAC
531	ECB Warning Light	ABS/VSC/TRAC
532	ECB Control Invalid	ABS/VSC/TRAC

533	ECB Indicator Light	ABS/VSC/TRAC
534	ES Start Light	ABS/VSC/TRAC
535	ES Start Buzzer	ABS/VSC/TRAC
536	H/B Motor Relay	ABS/VSC/TRAC
537	PPS Solenoid	ABS/VSC/TRAC
538	TPMS Warning Light	ABS/VSC/TRAC
539	VSC/TRAC Solenoid (SMF)	ABS/VSC/TRAC
540	VSC/TRAC Solenoid (SMR)	ABS/VSC/TRAC
541	VSC/TRAC Solenoid (SPFL)	ABS/VSC/TRAC
542	VSC/TRAC Solenoid (SPFR)	ABS/VSC/TRAC
543	VSC/TRAC Solenoid (SRCF)	ABS/VSC/TRAC
544	VSC/TRAC Solenoid (SRCR)	ABS/VSC/TRAC
545	VSC/TRAC Solenoid (SRMF)	ABS/VSC/TRAC
546	VSC/TRAC Solenoid (SRMR)	ABS/VSC/TRAC
547	VSC/TRAC OFF Indicator Light	ABS/VSC/TRAC
548	VSC/TRC(TRAC) Solenoid	ABS/VSC/TRAC
549	VSC/TRC(TRAC) Solenoid (SRCF)	ABS/VSC/TRAC
550	VSC/TRC(TRAC) Solenoid (SRCR)	ABS/VSC/TRAC
551	VSC/TRC(TRAC) Solenoid (SRMF)	ABS/VSC/TRAC
552	VSC/TRC(TRAC) Solenoid (SRMR)	ABS/VSC/TRAC
553	VSC OFF Indicator Light	ABS/VSC/TRAC
554	Pump Check Pattern	ABS/VSC/TRAC
555	VSC Warning Light	ABS/VSC/TRAC
556	VSC H/B Warning Buzzer	ABS/VSC/TRAC
557	Stroke Simulator Cut Valve Pattern	ABS/VSC/TRAC
558	Slip Indicator Light	ABS/VSC/TRAC
559	Solenoid (SLA)	ABS/VSC/TRAC
560	Solenoid (SLR)	ABS/VSC/TRAC
561	SOL RELAY	ABS/VSC/TRAC
562	Motor Relay	ABS/VSC/TRAC
563	Power Supply Air Bleeding Pattern1	ABS/VSC/TRAC
564	Power Supply Air Bleeding Pattern2	ABS/VSC/TRAC
565	ECB Invalid	ABS/VSC/TRAC
566	ECB Motor Relay	ABS/VSC/TRAC
567	ECB Motor Relay2	ABS/VSC/TRAC
568	ECB Main Relay	ABS/VSC/TRAC
569	ECB Main Relay1	ABS/VSC/TRAC
570	ECB Main Relay2	ABS/VSC/TRAC
571	Buzzer	ABS/VSC/TRAC
572	sub-throttle	ABS/VSC/TRAC
573	Crawl Control Light	ABS/VSC/TRAC
574	EBS Relay	ABS/VSC/TRAC
575	Motor Relay1	ABS/VSC/TRAC
576	Motor Relay2	ABS/VSC/TRAC
577	Exhaust Brake Cut Relay	ABS/VSC/TRAC
578	Drain System Air Bleeding Pattern	ABS/VSC/TRAC
579	TRC(TRAC) OFF Indicator Light	ABS/VSC/TRAC
580	TRC(TRAC) Motor Relay	ABS/VSC/TRAC
581	Pre Crash Brake OFF Light	ABS/VSC/TRAC
582	Tire Pressure Warning Light	ABS/VSC/TRAC
583	Tire Pressure Light	ABS/VSC/TRAC

584	Stop Light Relay	ABS/VSC/TRAC
585	Stop light System Indicator Light	ABS/VSC/TRAC
586	Downhill Assist Control Light	ABS/VSC/TRAC
587	Accumulator pressure lowered to zero drive	ABS/VSC/TRAC
588	RR Wheel Air Bleeding Pattern	ABS/VSC/TRAC
589	Pre-Charge Pump	ABS/VSC/TRAC
590	Sports Mode Indicator Light	ABS/VSC/TRAC
591	Actuator Air Bleeding Pattern	ABS/VSC/TRAC
592	Brake Warning Light	ABS/VSC/TRAC
593	TRAC Solenoid (SA1 & SA2)	ABS/VSC/TRAC
594	TRAC Solenoid (SA1)	ABS/VSC/TRAC
595	TRAC Solenoid (SA2)	ABS/VSC/TRAC
596	TRAC Solenoid (SFLR & SFLH)	ABS/VSC/TRAC
597	TRAC Solenoid (SFRH & SFLH)	ABS/VSC/TRAC
598	TRAC Solenoid (SFRR & SFRH)	ABS/VSC/TRAC
599	TRAC Solenoid (SMC1)	ABS/VSC/TRAC
600	TRAC Solenoid (SMC2)	ABS/VSC/TRAC
601	TRAC Solenoid (SMFL)	ABS/VSC/TRAC
602	TRAC Solenoid (SMFR & SMFL)	ABS/VSC/TRAC
603	TRAC Solenoid (SMFR)	ABS/VSC/TRAC
604	TRAC Solenoid (SMF)	ABS/VSC/TRAC
605	TRAC Solenoid (SMR & SPFR)	ABS/VSC/TRAC
606	TRAC Solenoid (SMR)	ABS/VSC/TRAC
607	TRAC Solenoid (SPFL)	ABS/VSC/TRAC
608	TRAC Solenoid (SPFR)	ABS/VSC/TRAC
609	TRAC Solenoid (SRCF & SRCR)	ABS/VSC/TRAC
610	TRAC Solenoid (SRCF)	ABS/VSC/TRAC
611	TRAC Solenoid (SRCR)	ABS/VSC/TRAC
612	TRAC Solenoid (SRH)	ABS/VSC/TRAC
613	TRAC Solenoid (SRLR & SRLH)	ABS/VSC/TRAC
614	TRAC Solenoid (SRMF & SRMR)	ABS/VSC/TRAC
615	TRAC Solenoid (SRMF)	ABS/VSC/TRAC
616	TRAC Solenoid (SRMR)	ABS/VSC/TRAC
617	TRAC Solenoid (SRRR & SRRH)	ABS/VSC/TRAC
618	TRAC Solenoid (SS)	ABS/VSC/TRAC
619	TRAC Motor Relay	ABS/VSC/TRAC
620	Master Cut Valve1	ABS/VSC/TRAC
621	Master Cut Valve2	ABS/VSC/TRAC
622	Auto LSD Indicator Light	ABS/VSC/TRAC
623	RL Wheel Air Bleeding Pattern	ABS/VSC/TRAC
624	4WD lock indicator	ABS/VSC
625	4WD Auto mode indicator	ABS/VSC
626	4WD warning lamp	ABS/VSC
627	ABS warning lamp	ABS/VSC
628	ABS MOT RELAY	ABS/VSC
629	ARS warning lamp	ABS/VSC
630	AUTO LSD indicator	ABS/VSC
631	BH standby indicator	ABS/VSC
632	DAB Indicator Light	ABS/VSC
633	DAC indicator	ABS/VSC

634	ECB light	ABS/VSC
635	GH hold indicator	ABS/VSC
636	H/B Motor Relay	ABS/VSC
637	N / C valve 1	ABS/VSC
638	N / C valve 2	ABS/VSC
639	N / C valve	ABS/VSC
640	N / O valve	ABS/VSC
641	PB OFF indicator	ABS/VSC
642	PPS Solenoid	ABS/VSC
643	SAR1	ABS/VSC
644	SAR2	ABS/VSC
645	SM valve	ABS/VSC
646	SPFL	ABS/VSC
647	SPFR	ABS/VSC
648	SRC valve	ABS/VSC
649	SRM valve	ABS/VSC
650	SRM1	ABS/VSC
651	SRM2	ABS/VSC
652	TRC motor relay (TMR)	ABS/VSC
653	TRC OFF lamp	ABS/VSC
654	VSC OFF light	ABS/VSC
655	VSC- TRC OFF light	ABS/VSC
656	left front wheel holding solenoid (SFLH)	ABS/VSC
657	left front wheel pressure reduction solenoid (SFLR)	ABS/VSC
658	left rear wheel holding solenoid (SRLH)	ABS/VSC
659	left rear wheel pressure reduction solenoid (SRLR)	ABS/VSC
660	right front wheel holding solenoid (SFRH)	ABS/VSC
661	right front wheel vacuum solenoid (SFRR)	ABS/VSC
662	right rear wheel holding solenoid (SRRH)	ABS/VSC
663	right rear wheel pressure reduction solenoid (SRRR)	ABS/VSC
664	slip indicator	ABS/VSC
665	VSC warning lamp	ABS/VSC
666	SOL RELAY	ABS/VSC
667	Secondary system Aea unplug drive	ABS/VSC
668	Neutral return	ABS/VSC
669	Buzzer	ABS/VSC
670	maneuverability control indicator	ABS/VSC
671	EBS relay	ABS/VSC
672	Tire pressure monitor light	ABS/VSC
673	Motor	ABS/VSC
674	CRAWL CONTROL indicator	ABS/VSC
675	reservoir cut solenoid 1	ABS/VSC
676	reservoir cut solenoid 2	ABS/VSC
677	master cut solenoid 1	ABS/VSC

678	master cut solenoid 2	ABS/VSC
679	3-order system Aea unplug drive	ABS/VSC
680	stop lamp relay	ABS/VSC
681	Turning right	ABS/VSC
682	Pre-Charge Pump	ABS/VSC
683	Actuator drive (RR)	ABS/VSC
684	Actuator drive (FR)	ABS/VSC
685	Actuator drive (RL)	ABS/VSC
686	Actuator drive (FL)	ABS/VSC
687	brake lamp system indicator	ABS/VSC
688	brake inhibit bit relay	ABS/VSC
689	BRAKE WRN LIGHT	ABS/VSC
690	Turning left	ABS/VSC
691	Headrest Sensor	ACT RR seat headrest
692	Headrest Manual Backward	ACT RR seat headrest
693	Headrest Manual Forward	ACT RR seat headrest
694	Headrest Auto	ACT RR seat headrest
695	Headrest Sensor	ACT RL seat headrest
696	Headrest Manual Backward	ACT RL seat headrest
697	Headrest Manual Forward	ACT RL seat headrest
698	Headrest Auto	ACT RL seat headrest
699	FR Damper Test	AHC
700	FR Height	AHC
701	FR Solenoid	AHC
702	RL Solenoid	AHC
703	RR Damper Test	AHC
704	RR Solenoid	AHC
705	Low Pressure Tank Solenoid	AHC
706	Motor Relay	AHC
707	Rear gate valve	AHC
708	Rear Leveling Solenoid	AHC
709	Rear Wheel Up/Down	AHC
710	Rear Gate Solenoid	AHC
711	Exhaust Solenoid	AHC
712	Front Leveling Solenoid	AHC
713	Front Wheel Up/Down	AHC
714	Front Wheel Up by Accumulator	AHC
715	Front Gate Solenoid	AHC
716	Front gate valve	AHC
717	FR Gas Spring Switch Valve	AHC
718	Front Left Solenoid	AHC
719	Front Left Height Solenoid	AHC
720	Front Left Wheel Up/Down	AHC
721	FL Gas Spring Switch Valve	AHC
722	pump motor relay	AHC
723	Four-Wheel Damping Force Full Soft	AHC
724	Four-Wheel Damping Force Full Hard	AHC
725	Accumulator Solenoid	AHC
726	Accumulator valve	AHC
727	Rear Wheel Up by Accumulator	AHC
728	Rear Right Solenoid	AHC

729	RR Wheel Up/Down	AHC
730	RR Height	AHC
731	Rear Right Height Solenoid	AHC
732	Damper Step RR	AHC
733	Rear Right Wheel Up/Down	AHC
734	Front Right Solenoid	AHC
735	Front Right Height Solenoid	AHC
736	Damper Step FR	AHC
737	FR Wheel Up/Down	AHC
738	Main Relay	AHC
739	Rear Left Solenoid	AHC
740	Rear Left Height Solenoid	AHC
741	Damper Step RL	AHC
742	RL Wheel Up/Down	AHC
743	FL Solenoid	AHC
744	Damper Step FL	AHC
745	FL Wheel Up/Down	AHC
746	Sound	ASC
747	Activate the HPU Motor	ASG
748	Activate the Gear Position	ASG
749	Activate the Oil Cooler Motor	ASG
750	Activate the Clutch Stroke	ASG
751	Release the Gear Stuck	ASG
752	Check the E-ACM	E-ACM
753	A/C magnet clutch relay	EFI
754	Alternator C duty	EFI
755	Boost pressure VSV	EFI
756	C terminal Duty	EFI
757	ISC	EFI
758	Radiator fan	EFI
759	Rajifan (1 stage)	EFI
760	Rajifan (2 stage)	EFI
761	T terminal	EFI
762	VSV1	EFI
763	VSV2 ABV	EFI
764	VSV2	EFI
765	VSV all	EFI
766	VSV boost pressure	EFI
767	Terminal T	EFI
768	Purge VSV	EFI
769	fuel pump	EFI
770	FR Damper Test	EMS
771	FR Height	EMS
772	FR Solenoid	EMS
773	RL Solenoid	EMS
774	RR Damper Test	EMS
775	RR Solenoid	EMS
776	Low Pressure Tank Solenoid	EMS
777	Motor Relay	EMS
778	Rear Leveling Solenoid	EMS
779	Rear Gate Solenoid	EMS

780	Exhaust Solenoid	EMS
781	Front Leveling Solenoid	EMS
782	Front Gate Solenoid	EMS
783	Accumulator Solenoid	EMS
784	RR Wheel Up/Down	EMS
785	RR Height	EMS
786	Damper Step RR	EMS
787	Damper Step FR	EMS
788	FR Wheel Up/Down	EMS
789	Main Relay	EMS
790	Damper Step RL	EMS
791	RL Wheel Up/Down	EMS
792	FL Solenoid	EMS
793	Damper Step FL	EMS
794	FL Wheel Up/Down	EMS
795	Control the Cooling Fan	EV Battery
796	Electric Cooling Fan	EV
797	Activate the Water Pump	EV
798	CONT1	EV
799	CONT2	EV
800	CONT3	EV
801	Connect the TC and TE1	EV
802	Carrier Frequency	EV
803	Regenerative solenoid (SOLF) operation	EV
804	Regenerative solenoid (SOLL) operation	EV
805	Regenerative solenoid (SOLP) operation	EV
806	Regenerative solenoid (SOLR) operation	EV
807	Regenerative solenoid (RLY) operation	EV
808	Regenerative water pump operation	EV
809	Connect the TC and TE1	FC
810	Hydrogen Tank Shut Valve	FC
811	Fuel Cell Monitor Relay	FC
812	Connect the TC and TE1	FCHV
813	CRC Stroke Target	Free-Tronic
814	ACS Warning Buzzer	Free-Tronic
815	ACS Warning Lamp	Free-Tronic
816	ACS Motor Relay	Free-Tronic
817	AFS Alarm Display	HL AutoLeveling
818	AFS OFF Indicator	HL AutoLeveling
819	AHS	HL AutoLeveling
820	Headlight Low Beam	HL AutoLeveling
821	Headlight High Beam	HL AutoLeveling
822	Extra High Beam	HL AutoLeveling
823	Advice Display	HL AutoLeveling
824	Drive The Leveling Motor	HL AutoLeveling
825	Front Fog Light	HL AutoLeveling
826	Daytime Running Light	HL AutoLeveling
827	Clearance Light	HL AutoLeveling
828	Drive The Leveling Motor UP	HL AutoLeveling
829	Drive The Leveling Motor DOWN	HL AutoLeveling
830	Cornering Light	HL AutoLeveling

831	Meter Indicator	HL AutoLeveling
832	High Beam RH	HL AutoLeveling
833	Variable Shade Beam RH	HL AutoLeveling
834	Drive Swivel Motor RH RIGHT	HL AutoLeveling
835	Drive Swivel Motor RH LEFT	HL AutoLeveling
836	Drive Swivel Motor RH	HL AutoLeveling
837	Right Turn Signal Light	HL AutoLeveling
838	High Beam Indicator	HL AutoLeveling
839	Automatic High Beam Operation	HL AutoLeveling
840	Auto High Beam Warning Indicator	HL AutoLeveling
841	Auto High Beam Control Indicator	HL AutoLeveling
842	Variable Shade Beam LH/RH	HL AutoLeveling
843	High Beam LH	HL AutoLeveling
844	Variable Shade Beam LH	HL AutoLeveling
845	Drive Swivel Motor LH RIGHT	HL AutoLeveling
846	Drive Swivel Motor LH LEFT	HL AutoLeveling
847	Drive Swivel Motor LH	HL AutoLeveling
848	Left Turn Signal Light	HL AutoLeveling
849	Battery Check	HV Battery
850	Discharging Battery to Check Weak Cells	HV Battery
851	External Charger Relay	HV Battery
852	OFF Ave Cg Relay	HV Battery
853	Cooling Fan Lo	HV Battery
854	Cooling Fan Hi	HV Battery
855	Cooling Fan Speed	HV Battery
856	Cooling Fan Stop	HV Battery
857	Cooling Fan Mid	HV Battery
858	Control the Cooling Fan	HV Battery
859	Battery Check	
860	OFF Ave Cg Relay	
861	Cooling Fan Lo	
862	Cooling Fan Hi	
863	Cooling Fan Speed	
864	Cooling Fan Stop	
865	Cooling Fan Mid	
866	Discharging Battery to Check Weak Cells	HV
867	ROM RAM inspection	HV
868	Large amount of change in SOC	HV
869	SOC%	HV
870	(G) current F / B stop	HV
871	(G) power generation	HV
872	(M) (G) driven	HV
873	(M) current F / B stop	HV
874	(M) discharge / (G) power generation	HV
875	(M) regenerative	HV
876	T/M Cooler Oil Pump	HV
877	Charge (current size)	HV
878	Charge (current small)	HV
879	Current value 0A input	HV

880	Control the Shift Position	HV
881	Battery Charge	HV
882	motor running	HV
883	ON terminal TC	HV
884	Engine fixed drive	HV
885	Forcible Stop of Inverter Drive	HV
886	Discharge (current size)	HV
887	Discharge (current small)	HV
888	Activate the (Inverter) Water Pump	HV
889	Activate the Solenoid (SL1)	HV
890	Activate the Solenoid (SL2)	HV
891	Activate the solenoid (Line Pressure)	HV
892	Activate the Water Pump	HV
893	Activate the Oil Pump(1000rpm)	HV
894	Activate the Oil Pump(500rpm)	HV
895	Equalizing charge relay	HV
896	cooling fan air volume	HV
897	clutch test 1	HV
898	clutch test 2	HV
899	clutch test 3	HV
900	clutch test 4	HV
901	clutch test 5	HV
902	clutch test 6	HV
903	Connect the TC and TE1	HV
904	Inverter WP	HV
905	inverter WP drive	HV
906	Control the Cooling Fan	HV
907	External start charging	HV
908	Compression Test	HV
909	Active the Water Pump	HV
910	Discharging Battery to Check Weak Cells	HV battery
911	Onboard Charge Status	HV battery
912	damper position change	HV battery
913	Debt front relay	HV battery
914	OFF Ave Cg Relay	HV battery
915	Equalizing charge relay	HV battery
916	Control the Cooling Fan	HV battery
917	main relay drive	HV battery
918	E latch motor	ITC
919	Illuminating 2	ITC
920	power rating mirror drive motor recovery	ITC
921	power rating mirror drive motor store	ITC
922	security siren	ITC
923	Security Indicator Input	ITC
924	door unlock motor	ITC
925	Riawaiha motor	ITC
926	Buzzer	ITC
927	door lock motor	ITC
928	siren	ITC

929	Head Light	ITC
930	Front WI motor low-speed driving	ITC
931	Front WI motor driven at high speed	ITC
932	Room light	ITC
933	Tail Light	ITC
934	Right PSD signal	ITC
935	Turn Right light	ITC
936	Left PSD signal	ITC
937	Turn Left light	ITC
938	ACC relay	KFS
939	IG2 relay	KFS
940	after the seat cars indoor antenna outgoing	KFS
941	after the seat cars indoor antenna transmission (diagnostic)	KFS
942	all antenna transmission drive (factory inspection)	KFS
943	back-door vehicle outdoor antenna outgoing	KFS
944	back-door vehicle outdoor antenna transmission (diagnostic)	KFS
945	car indoor antenna (center) outgoing	KFS
946	car indoor antenna (front seat) outgoing	KFS
947	car indoor antenna (rear seat) outgoing	KFS
948	car outdoor antenna (back door) outgoing	KFS
949	car outdoor antenna (passenger seat) outgoing	KFS
950	door lock inversion control	KFS
951	door unlock control	KFS
952	front seat car indoor antenna outgoing	KFS
953	front seat car indoor antenna transmission (diagnostic)	KFS
954	green indicator lights	KFS
955	indoor antenna D oscillation drive	KFS
956	indoor antenna P oscillation drive	KFS
957	orange indicator lights	KFS
958	outdoor antenna D oscillation drive	KFS
959	outdoor antenna P oscillation drive	KFS
960	outdoor antenna back door oscillation drive	KFS
961	passenger seat car indoor antenna outgoing	KFS
962	passenger seat car outdoor antenna outgoing	KFS
963	passenger seat car outdoor antenna transmission (diagnostic)	KFS
964	security indicator control	KFS
965	Car outdoor antenna (driver's seat) outgoing	KFS
966	Imobianfu outgoing	KFS

967	Imobianfu outgoing (diagnostic)	KFS
968	window UP	KFS
969	window DOWN	KFS
970	IG1 relay	KFS
971	Lower Wind UP	KFS
972	Lower Wind Down	KFS
973	Driver's seat car indoor antenna transmission	KFS
974	Driver's seat car outdoor antenna transmission	KFS
975	Driver's seat car outdoor antenna transmission (diagnostic)	KFS
976	unlock control	KFS
977	door lock control	KFS
978	starter relay drive output request	KFS
979	Wireless communication test	KFS
980	Night Lighting	KFS
981	actuator reversal	KFS
982	Smart communication test	KFS
983	Toransuho Sunda communication test	KFS
984	Passenger Side Power Window	P Master Switch
985	Quick anteversion	Pre-crash seat back seat RL
986	Quick series	Pre-crash seat back seat RL
987	Seat Reclining	Pre-crash seat back seat RL
988	Quick anteversion	Pre-crash seat back seat RR
989	Quick series	Pre-crash seat back seat RR
990	Seat Reclining	Pre-crash seat back seat RR
991	Gear Position Indicator Output	SMT
992	Shift position ECT	SMT
993	Line Pressure Solenoid	SMT
994	Activate the Solenoid (ST)	SMT
995	Motor Relay Control	SMT
996	Target Gear Position Control	SMT
997	Target Select Stroke Control	SMT
998	Target Shift Stroke Control	SMT
999	release cylinder air vent	SMT
1000	lock-up SOL	SMT
1001	Reduced Accumulator Pressure	SMT
1002	Pre-Crash Safety Warning Buz	SMT
1003	Security Horn	
1004	Security Horn2	
1005	Security Indicator	
1006	P Transmitter	
1007	Pr-Seat Outside Transmitter	
1008	Headlight Relay	
1009	Over Head Tuner	

1010	Buzzer Response Sound	
1011	Buzzer For Accessory Output	
1012	Pager For Accessory Output	
1013	D Transmitter	
1014	Inside Luggage Tuner	
1015	Fr Transmitter	
1016	Front Fog Light Relay	
1017	Hazard	
1018	Taillight Relay	
1019	Luggage Transmitter	
1020	In Luggage Transmitter	
1021	Trunk Lid Open	
1022	Key Remained Buzzer	
1023	Rr Transmitter	
1024	Smart Indicator	
1025	Security Horn	Security
1026	Security Horn2	Security
1027	Security Indicator	Security
1028	P Transmitter	Security
1029	Pr-Seat Outside Transmitter	Security
1030	Headlight Relay	Security
1031	dome lamp	Security
1032	Buzzer Response Sound	Security
1033	D Transmitter	Security
1034	Vehicle Horn	Security
1035	Fr Transmitter	Security
1036	Front Fog Light Relay	Security
1037	Power For Tilt Sensor	Security
1038	Taillight Relay	Security
1039	Luggage Transmitter	Security
1040	In Luggage Transmitter	Security
1041	Rr Transmitter	Security
1042	Smart Indicator	Security
1043	PBD Open/Close	Back Door
1044	Backup Light	Back Door
1045	Power Window	Back Door
1046	PBD Buzzer	Back Door
1047	PBD Close SW Light	Back Door
1048	PBD Clutch	Back Door
1049	PBD Motor	Back Door
1050	Rear Wiper	Back Door
1051	Courtesy SW Signal	Back Door
1052	Door Lock	Back Door
1053	License Light	Back Door
1054	Latch Release	Back Door
1055	Back Door Power Window	Back Door P/W
1056	Rear Wiper Active	Back Door P/W
1057	Luggage Compartment Light	Back Door P/W
1058	LDA Buzzer	Lane Departure Alert
1059	Quick Charge Negative Relay	Plug-in Control
1060	Quick Charge Positive Relay	Plug-in Control

1061	Proximity Sound (Vehicle Stationary)	Vehicle Proximity Notification System
1062	Proximity Sound (Low Speed)	Vehicle Proximity Notification System
1063	Proximity Sound Indicator	Vehicle Proximity Notification System
1064	ESS lamp	Vehicle Control
1065	Blower Blast Delay Relay	Vehicle Control
1066	Cooler OFF Relay	Vehicle Control
1067	Exhaust Brake Lamp	Vehicle Control
1068	Starter ON Relay 1	Vehicle Control
1069	Starter ON Relay 2	Vehicle Control
1070	Stop&Start OFF Lamp	Vehicle Control
1071	Stop&Start Running Lamp	Vehicle Control
1072	Diagnostic Lamp	Vehicle Control
1073	Actuator Relay	Vehicle Control
1074	Brake Lock Valve Relay 1	Vehicle Control
1075	Brake Lock Valve Relay 2	Vehicle Control
1076	Bus Cut Relay No. 1	Body
1077	Operation permission P / W	Body
1078	Super Sonic Windshield Mirror	Body
1079	Security Horn	Body
1080	Security Horn2	Body
1081	Security Indicator	Body
1082	Dimmer Signal	Body
1083	Rheostat Cancel Operation	Body
1084	Rheostat Operation	Body
1085	ultrasonic mirror working	Body
1086	Interior Panel Relay	Body
1087	Passenger Buckle Light Output	Body
1088	Passenger Power Window Up/Down	Body
1089	Shock Detection Unlock	Body
1090	Open Door Warning Light	Body
1091	Head Light High	Body
1092	Headlight Relay	Body
1093	Head Light Cleaner	Body
1094	Illuminated Entry System	Body
1095	Map and Courtesy Light	Body
1096	IG OFF P/W Control Permission Output	Body
1097	tuner power	Body
1098	alternator L terminal output	Body
1099	shock sensing unlock	Body
1100	Rear Buckle Light Output	Body
1101	Trunk and back-door open	Body
1102	Rear Room Light	Body
1103	Rear Washer Relay Operation	Body
1104	Rear Wiper Motor	Body
1105	Rear Defogger	Body
1106	Rear Fog Light Relay	Body
1107	shift lock	Body
1108	Shift R Sign	Body
1109	Driver Buckle Light Output	Body

1110	Shoulder Belt Up/Down	Body
1111	Alter L Signal Output	Body
1112	Door Lock	Body
1113	License Light	Body
1114	Doom Relay Cut	Body
1115	Vehicle Horn	Body
1116	Front Fog Light Relay	Body
1117	Other ECU Power Cut	Body
1118	Relay of DRL	Body
1119	Intrusion Sensor Power	Body
1120	ALL Courtesy Output	Body
1121	Step Light Operation	Body
1122	Hazard	Body
1123	Taillight Relay	Body
1124	Wireless Buzzer	Body
1125	Wireless Buzzer (continuous sound)	Body
1126	wireless buzzer (lock)	Body
1127	display dimming	Body
1128	Turn Light RH Relay Operation	Body
1129	RR Power Window Up/Down	Body
1130	Wiper Motor Lo	Body
1131	Wiper Motor Hi	Body
1132	Wiper Motor	Body
1133	Wiper Angle Control	Body
1134	Key Remainder Buzzer	Body
1135	Center Console Light Operation	Body
1136	Self-powered siren	Body
1137	bus cut relay No.2	Body
1138	Turn Light LH Relay Operation	Body
1139	RL Power Window Up/Down	Body
1140	Security Horn	
1141	Security Horn2	
1142	Security Indicator	
1143	Dimmer Signal	
1144	Rheostat Cancel Operation	
1145	Interior Panel Relay	
1146	Passenger Buckle Light Output	
1147	Passenger Power Window Up/Down	
1148	Shock Detection Unlock	
1149	Open Door Warning Light	
1150	Head Light High	
1151	Headlight Relay	
1152	Head Light Cleaner	
1153	Illuminated Entry System	
1154	Map and Courtesy Light	
1155	IG OFF P/W Control Permission Output	
1156	Rear Buckle Light Output	
1157	Trunk and back-door open	
1158	Rear Room Light	
1159	Rear Washer Relay Operation	
1160	Rear Wiper Motor	

1161	Rear Defogger	
1162	Rear Fog Light Relay	
1163	Shift R Sign	
1164	Driver Buckle Light Output	
1165	Shoulder Belt Up/Down	
1166	Door Lock	
1167	License Light	
1168	Doom Relay Cut	
1169	Vehicle Horn	
1170	Front Fog Light Relay	
1171	Other ECU Power Cut	
1172	Relay of DRL	
1173	Intrusion Sensor Power	
1174	Step Light Operation	
1175	Hazard	
1176	Taillight Relay	
1177	Wireless Buzzer	
1178	Wireless Buzzer (continuous sound)	
1179	Turn Light RH Relay Operation	
1180	RR Power Window Up/Down	
1181	Wiper Motor Lo	
1182	Wiper Motor Hi	
1183	Wiper Motor	
1184	Wiper Angle Control	
1185	Key Remainder Buzzer	
1186	Center Console Light Operation	
1187	Turn Light LH Relay Operation	
1188	RL Power Window Up/Down	
1189	Rear Room Light LH	Body No. 3
1190	Lh cornering lamps	Body No. 3
1191	Rear Room Light RH	Body No. 3
1192	Rh cornering lamps	Body No. 3
1193	Shoulder Anchor Operation	Body No. 3
1194	Buckle Light 1	Body No. 3
1195	buckle lighting	Body No. 3
1196	Clearance Light Operation	Body No. 3
1197	Interior Light (Dim) Operation	Body No. 3
1198	Interior Panel Relay	Body No. 3
1199	Light Head (High)	Body No. 3
1200	Backup Light	Body No. 3
1201	Reverse Signal Control	Body No. 3
1202	Illuminated Entry System	Body No. 3
1203	Shift Light Operation	Body No. 3
1204	High Mount Stop Light	Body No. 3
1205	Rear Fog Light	Body No. 3
1206	Rear Sunshade Operation	Body No. 3
1207	Deck Lamp	Body No. 3
1208	Alter L Signal Output	Body No. 3
1209	head lamp Lo relay	Body No. 3
1210	Interior Light Operation	Body No. 3
1211	Horn Relay Operation	Body No. 3

1212	License Light	Body No. 3
1213	Front Room Light	Body No. 3
1214	Front Fog Light Relay	Body No. 3
1215	Washer Motor Operation	Body No. 3
1216	Fuel Lid Open	Body No. 3
1217	Step Light Operation	Body No. 3
1218	Stop Light	Body No. 3
1219	Exterior Foot Light Operation	Body No. 3
1220	Tail Light	Body No. 3
1221	Luggage Light Control	Body No. 3
1222	Trunk Lid Open	Body No. 3
1223	oil slick up washer motor	Body No. 3
1224	RH Stop Light	Body No. 3
1225	RH Tail Light	Body No. 3
1226	RH Rear Personal Light	Body No. 3
1227	Wiper Motor Lo	Body No. 3
1228	Wiper Motor Hi	Body No. 3
1229	Wiper Angle Control	Body No. 3
1230	head lamp Hi relay	Body No. 3
1231	Illuminated Relay Operation	Body No. 3
1232	Center Console Light Operation	Body No. 3
1233	Turn Light LH	Body No. 3
1234	Turn Light RH	Body No. 3
1235	Steering Light Operation	Body No. 3
1236	LH Stop Light	Body No. 3
1237	LH Tail Light	Body No. 3
1238	LH Rear Personal Light	Body No. 3
1239	Seat Light Operation	Body No. 3
1240	Rear Room Light LH	Body No. 5
1241	Lh cornering lamps	Body No. 5
1242	Rear Room Light RH	Body No. 5
1243	Rh cornering lamps	Body No. 5
1244	Shoulder Anchor Operation	Body No. 5
1245	Buckle Light 1	Body No. 5
1246	buckle lighting	Body No. 5
1247	Clearance Light Operation	Body No. 5
1248	Light Head (High)	Body No. 5
1249	Backup Light	Body No. 5
1250	Reverse Signal Control	Body No. 5
1251	High Mount Stop Light	Body No. 5
1252	Rear Fog Light	Body No. 5
1253	Rear washer motor	Body No. 5
1254	Horn Relay Operation	Body No. 5
1255	License Light	Body No. 5
1256	Front Room Light	Body No. 5
1257	Front Fog Light Relay	Body No. 5
1258	Washer Motor Operation	Body No. 5
1259	Fuel Lid Open	Body No. 5
1260	Step Light Operation	Body No. 5
1261	Stop Light	Body No. 5
1262	Tail Light	Body No. 5

1263	Luggage Light Control	Body No. 5
1264	Trunk Lid Open	Body No. 5
1265	oil slick up washer motor	Body No. 5
1266	Wiper Motor Lo	Body No. 5
1267	Wiper Motor Hi	Body No. 5
1268	Wiper Angle Control	Body No. 5
1269	Center Console Light Operation	Body No. 5
1270	Inside Handle Illumination	Passenger Door
1271	Power Window	Passenger Door
1272	Mirror Return	Passenger Door
1273	Mirror Heater	Passenger Door
1274	Mirror Up/Down	Passenger Door
1275	Mirror Right/Left	Passenger Door
1276	Mirror Fold/Return	Passenger Door
1277	Courtesy Lamp	Passenger Door
1278	Courtesy Light	Passenger Door
1279	Door Lock	Passenger Door
1280	Double Lock Unset	Passenger Door
1281	Foot Light	Passenger Door
1282	Mirror Fold	Passenger Door
1283	P Manual SW LED	Passenger Door
1284	Seat Memory Light	Passenger Door
1285	PSD Motor	Passenger Door
1286	PSD Buzzer	Passenger Door
1287	PSD Clutch	Passenger Door
1288	Inside Handle Illumination	Passenger Door
1289	Power Window	Passenger Door
1290	Mirror Return	Passenger Door
1291	Mirror Heater	Passenger Door
1292	Mirror Up/Down	Passenger Door
1293	Mirror Right/Left	Passenger Door
1294	Mirror Fold/Return	Passenger Door
1295	Memory Cancel Lamp	Passenger Door
1296	Courtesy Lamp	Passenger Door
1297	Courtesy Light	Passenger Door
1298	Door Lock	Passenger Door
1299	Release Actuator	Passenger Door
1300	Double Lock Unset	Passenger Door
1301	Foot Light	Passenger Door
1302	Ashtray Light	Passenger Door
1303	Mirror Fold	Passenger Door
1304	P Manual SW LED	Passenger Door
1305	Seat Memory Light	Passenger Door
1306	Power Window	P-Door Motor
1307	Side Support Operation	Passenger Seat
1308	Buzzer	Passenger Seat
1309	Rear Seat Lumbar Adjustment	Passenger Seat
1310	Ottoman	Passenger Seat
1311	Headrest Operation	Passenger Seat
1312	Pelvis Support Operation	Passenger Seat
1313	Front Vertical Operation	Passenger Seat

1314	Lifter Operation	Passenger Seat
1315	Lumbar Slide	Passenger Seat
1316	Cushion Length	Passenger Seat
1317	Seat Slide Operation	Passenger Seat
1318	Seat Reclining	Passenger Seat
1319	Charging Control	Charging Control
1320	Control the Voltage of Alternator	Charging Control
1321	Activate Power Cut Relay	Electric Power Control
1322	Clear Integrated Current for Factory Mode	Electric Power Control
1323	Request to Limit EPS	Electric Power Control
1324	Limit Load Level	Electric Power Control
1325	Request to Limit Air Suspension	Electric Power Control
1326	Engine Switch Signal	Power Source Control
1327	IGP Signal	Power Source Control
1328	Ignition1	Power Source Control
1329	Ignition2	Power Source Control
1330	Start Switch	Power Source Control
1331	IG1	Power Source Control
1332	IG2 Signal	Power Source Control
1333	P Supply for Steering Lock	Power Source Control
1334	Acc Switch (MPX)	Power Source Control
1335	Key Lock	Power Source Control
1336	Indicator for Lighting	Power Source Control
1337	Indicator Condition	Power Source Control
1338	ACC	Power Source Control
1339	PKB release SW	Electric Parking Brake
1340	Test Mode	Electric Parking Brake
1341	EPB Warning Light	Electric Parking Brake
1342	Buzzer	Electric Parking Brake
1343	Overheat Display	Electric Parking Brake
1344	Check Display	Electric Parking Brake
1345	Full Release Mode Activation	Electric Parking Brake
1346	Full Release Mode De-Activation	Electric Parking Brake
1347	Release Display	Electric Parking Brake
1348	Lock Display	Electric Parking Brake
1349	Not Avail Display	Electric Parking Brake
1350	P Range Display	Electric Parking Brake
1351	PKB lock SW	Electric Parking Brake
1352	PKB Light	Electric Parking Brake
1353	PKB Release1	Electric Parking Brake
1354	PKB Lock1	Electric Parking Brake
1355	Auto Switch	Electric Parking Brake
1356	Auto Light	Electric Parking Brake
1357	Clutch Adjust	Multi-Mode M/T
1358	Target Gear Position Control	Multi-Mode M/T
1359	Target Clutch Control	Multi-Mode M/T
1360	#1	Engine2
1361	#2	Engine2
1362	#3	Engine2

1363	#4	Engine2
1364	#5	Engine2
1365	#6	Engine2
1366	#7	Engine2
1367	#8	Engine2
1368	Control the ACM Inhibit	Engine2
1369	Activate the VVT System (Bank1)	Engine2
1370	Auto item 1	Engine2
1371	Control the C/D	Engine2
1372	Check Type Support B	Engine2
1373	HICM System Check	Engine2
1374	Manual item 1 and Check Type Support H	Engine2
1375	Manual item 10 and Check Type Support Y	Engine2
1376	Manual item 2 and Check Type Support G	Engine2
1377	Manual item 3 and Check Type Support F	Engine2
1378	Manual item 4 and Check Type Support E	Engine2
1379	Manual item 5 and Check Type Support D	Engine2
1380	Manual item 6 and Check Type Support C	Engine2
1381	Manual item 7 and Check Type Support J	Engine2
1382	Manual item 8 and Check Type Support I	Engine2
1383	Manual item 9 and Check Type Support X	Engine2
1384	Control the O/D Cut	Engine2
1385	Control the SCV Duty Ratio	Engine2
1386	Brake Ejector VSV Inspection	Engine2
1387	Control the VVT-iE Linear (Bank1)	Engine2
1388	Control the VVT-iE Linear (Bank2)	Engine2
1389	Control the VVT Exhaust Linear (Bank1)	Engine2
1390	Control the VVT Exhaust Linear (Bank2)	Engine2
1391	Control the VVT System (Bank1)	Engine2
1392	Control the VVT System (Bank2)	Engine2
1393	Control the VVT Linear (Bank1)	Engine2
1394	Control the VVT Linear (Bank2)	Engine2
1395	Test the Fuel Leak	Engine2
1396	Test the Turbo Charger Step Motor	Engine2
1397	Test the Turbo Charger Step Motor #2	Engine2
1398	Diesel Throttle Target Angle	Engine2
1399	Diesel Throttle Target Angle #2	Engine2
1400	Control the IAC Duty Ratio	Engine2
1401	Control the ISC Step Position	Engine2
1402	Fuel Cut Bank 2 for Idle	Engine2
1403	Control the Idle Fuel Cut Prohibit	Engine2
1404	Control the Shift Position	Engine2
1405	Control the Electric Cooling Fan	Engine2
1406	Control the EGR Step Position	Engine2
1407	Control the EGR System	Engine2
1408	Control the Line Pressure Up	Engine2
1409	Control the Supercharger	Engine2
1410	Control the Auto Oil Supply System	Engine2
1411	Activate the VSV for Evap (Purge)	Engine2
1412	Activate the EGR Valve Close	Engine2

1413	Activate the VN Turbo Open	Engine2
1414	Activate the DPF Rejuvenate (PM)	Engine2
1415	Activate the DPF Rejuvenate (S)	Engine2
1416	Activate the Solenoid (DS1)	Engine2
1417	Activate the Solenoid (DS2)	Engine2
1418	Activate the Solenoid (DSL)	Engine2
1419	Activate the Solenoid (DSU)	Engine2
1420	Activate the Solenoid (S1)	Engine2
1421	Activate the Solenoid (S2)	Engine2
1422	Activate the Solenoid (S3)	Engine2
1423	Activate the Solenoid (S4)	Engine2
1424	Activate the Solenoid (SB)	Engine2
1425	Activate the Solenoid (SL)	Engine2
1426	Activate the Solenoid (SL1)	Engine2
1427	Activate the Solenoid (SL2)	Engine2
1428	Activate the Solenoid (SL3)	Engine2
1429	Activate the Solenoid (SL4)	Engine2
1430	Activate the Solenoid (SL5)	Engine2
1431	Activate the Solenoid (SLC)	Engine2
1432	Activate the Solenoid (SLN)	Engine2
1433	Activate the Solenoid (SLS)	Engine2
1434	Activate the Solenoid (SLT)	Engine2
1435	Activate the Solenoid (SLU)	Engine2
1436	Activate the Solenoid (SR)	Engine2
1437	Activate the Solenoid (ST)	Engine2
1438	Activate the Solenoid(SC)	Engine2
1439	Activate the Solenoid(SLP)	Engine2
1440	Activate the Electric Water Pump	Engine2
1441	Activate the Slip Control System	Engine2
1442	Activate the VSV for EGR Cooler Bypass	Engine2
1443	Activate the ACC Cut Relay	Engine2
1444	Activate the LPG Solenoid Valve	Engine2
1445	Activate the Return Solenoid Valve	Engine2
1446	Activate the Emergency Solenoid Valve	Engine2
1447	Activate the VSV2 for Intake Control	Engine2
1448	Activate the Intank Fuel Pump Relay	Engine2
1449	Activate the VSV for Variable Intake Control	Engine2
1450	Activate the Air Pump Heater	Engine2
1451	Activate the Air Switching Valve	Engine2
1452	Activate the VALVEMATIC (ENG OFF)	Engine2
1453	Activate the VALVEMATIC (ENG ON)	Engine2
1454	Activate HCAC VSV	Engine2
1455	Activate the VSV for Exhaust Switching Valve	Engine2
1456	Activate the VSV for Exhaust Brake	Engine2
1457	Activate the Starter Relay	Engine2
1458	Activate the Air Pump	Engine2
1459	Activate the Fuel Pump2 Speed Control	Engine2
1460	Activate the Fuel Pump Speed Control	Engine2
1461	Activate the Fuel Return Pipe Valve	Engine2

1462	Activate the Fuel Route Switching Valve Relay	Engine2
1463	Activate the Fuel Filler Opener	Engine2
1464	Activate the Fuel Pressure Switching Valve	Engine2
1465	Activate the Fuel Vapor-Containment Valve	Engine2
1466	Activate the Water Pump	Engine2
1467	Activate the Water Flow Valve 3	Engine2
1468	Activate the Water Flow Valve 4	Engine2
1469	Activate the Water Flow Valve 5	Engine2
1470	Activate the Water Flow Valve 1	Engine2
1471	Activate the Water Flow Valve 2	Engine2
1472	Activate the Vacuum Pump	Engine2
1473	Activate the VSV for Secondary Air Control	Engine2
1474	Activate the VSV for EGR Cut	Engine2
1475	Activate the VSV for Fuel Pressure Up Control	Engine2
1476	Activate the VSV for AICS	Engine2
1477	Activate the VSV for A/C Idle Up Control	Engine2
1478	Activate the VSV for HCAC System	Engine2
1479	Activate the VSV for Air Bleed Control	Engine2
1480	Activate the VSV for Exhaust Gas Control	Engine2
1481	Activate the VSV for Intake Control	Engine2
1482	Activate the VSV for Purge Cut	Engine2
1483	Activate the VSV for Exhaust Shutter	Engine2
1484	Activate the VSV for Exhaust Bypass Control	Engine2
1485	Activate the VSV for Canister Control	Engine2
1486	Activate the VSV for Vent Valve	Engine2
1487	Activate the VSV for Turbo Pressure	Engine2
1488	Activate the VSV for Turbo Boost Control	Engine2
1489	Activate the VSV for Tank Bypass	Engine2
1490	Activate the VSV for Evap Control	Engine2
1491	Activate the VSV for Swirl Control Valve	Engine2
1492	Activate the VSV for Vapor Pressure	Engine2
1493	Activate the Brake Ejector VSV	Engine2
1494	HCAC VSV Check	Engine2
1495	Check the Imbalance Cylinder	Engine2
1496	Check the Cylinder Compression	Engine2
1497	Prohibit the Catalyst OT Misfire prevent F/C	Engine2
1498	Control the Purge Dilution Valve Duty Bank1	Engine2
1499	Control the Purge Dilution Valve Duty Bank2	Engine2
1500	Control the VVTL System (Bank1)	Engine2
1501	Control the VVTL System (Bank2)	Engine2

1502	Control the A/C Cut Signal	Engine2
1503	Control the SLS Pressure	Engine2
1504	Control the Regulator Shut Valve	Engine2
1505	Control the EGR Step Position #2	Engine2
1506	Control the Voltage of Alternator	Engine2
1507	Control the A/C Magnet Clutch	Engine2
1508	Control the Injection Volume for A/F Sensor(CNG)	Engine2
1509	Control the Injection Volume(CNG)	Engine2
1510	Control the All Cylinders Fuel Cut	Engine2
1511	Control the All Cylinders Fuel Cut(CNG)	Engine2
1512	Control the Select Cylinder Fuel Cut	Engine2
1513	Control the Select Cylinder Fuel Cut(CNG)	Engine2
1514	Connect the TC and TE1	Engine2
1515	Control the Target Fuel Pressure	Engine2
1516	Activate the VALVEMATIC after Warm Up	Engine2
1517	Activate the VALVEMATIC before Warm Up	Engine2
1518	Control the Injection Volume for A/F Sensor	Engine2
1519	Control the Injection Way	Engine2
1520	Control the Injection Volume	Engine2
1521	Control the Injection Timing #1	Engine2
1522	Control the Injection Timing #2	Engine2
1523	Control the Injection Timing #3	Engine2
1524	Control the Injection Timing #4	Engine2
1525	Control the Injection Timing #5	Engine2
1526	Control the Injection Timing #6	Engine2
1527	Control the Injection Timing #7	Engine2
1528	Control the Injection Timing #8	Engine2
1529	Control the Stratified Charge Combustion	Engine2
1530	Control the Stoichiometric Ratio Combustion	Engine2
1531	Control the Fuel Pump Duty	Engine2
1532	Control the Fuel Pump / Speed	Engine2
1533	fuel pressure relief valve open	Engine2
1534	Fuel Pressure Relief Valve Close	Engine2
1535	Control the Delivery Shut Valve	Engine2
1536	Activate the Lock Up	Engine2
1537	Control the Lock Up	Engine2
1538	Control the ETCS Open/Close Fast Speed	Engine2
1539	Control the ETCS Open/Close Slow Speed	Engine2
1540	Sub Fuel Tank VSV	Engine2
1541	A/C Magnetic Clutch Relay	Engine (RH Bank)
1542	AICV VSV	Engine (RH Bank)
1543	C/D Control Solenoid	Engine (RH Bank)
1544	CVT shift position	Engine (RH Bank)
1545	SOL CVT deceleration	Engine (RH Bank)
1546	SOL increased speed CVT	Engine (RH Bank)
1547	Check Type Support B	Engine (RH Bank)

1548	EGR Step	Engine (RH Bank)
1549	EGR number of steps	Engine (RH Bank)
1550	EGR System	Engine (RH Bank)
1551	HC Adsorber and Catalyst VSV	Engine (RH Bank)
1552	HICM System Check	Engine (RH Bank)
1553	Manual item 1 and Check Type Support H	Engine (RH Bank)
1554	Manual item 10 and Check Type Support Y	Engine (RH Bank)
1555	Manual item 2 and Check Type Support G	Engine (RH Bank)
1556	Manual item 3 and Check Type Support F	Engine (RH Bank)
1557	Manual item 4 and Check Type Support E	Engine (RH Bank)
1558	Manual item 5 and Check Type Support D	Engine (RH Bank)
1559	Manual item 6 and Check Type Support C	Engine (RH Bank)
1560	Manual item 7 and Check Type Support J	Engine (RH Bank)
1561	Manual item 8 and Check Type Support I	Engine (RH Bank)
1562	Manual item 9 and Check Type Support X	Engine (RH Bank)
1563	Fuel ho Nfu air vent	Engine (RH Bank)
1564	O / D cut SOL	Engine (RH Bank)
1565	Forced regeneration PM	Engine (RH Bank)
1566	S poisoning regeneration control	Engine (RH Bank)
1567	SB Solenoid	Engine (RH Bank)
1568	Control the SCV Duty Ratio	Engine (RH Bank)
1569	SCV VSV	Engine (RH Bank)
1570	SLS Solenoid	Engine (RH Bank)
1571	Driving SLS	Engine (RH Bank)
1572	TE1 (TC)	Engine (RH Bank)
1573	VN Turbo fully open	Engine (RH Bank)
1574	Brake Ejector VSV Inspection	Engine (RH Bank)
1575	VSV intake control	Engine (RH Bank)
1576	VSV intake passage control	Engine (RH Bank)
1577	VSV variable intake	Engine (RH Bank)
1578	VSV exhaust throttle	Engine (RH Bank)
1579	VSV three-way	Engine (RH Bank)
1580	VSV boost pressure control	Engine (RH Bank)
1581	Control the VVT-iE Linear (Bank1)	Engine (RH Bank)
1582	Control the VVT-iE Linear (Bank2)	Engine (RH Bank)
1583	VVTL-I NO.1 OCV	Engine (RH Bank)
1584	VVTL-I NO.2 OCV	Engine (RH Bank)
1585	VVTL Control (Bank 1)	Engine (RH Bank)
1586	VVTL Control (Bank 2)	Engine (RH Bank)
1587	VVT Control (Bank 1)	Engine (RH Bank)
1588	VVT Control (Bank 2)	Engine (RH Bank)
1589	Control the VVT Exhaust Linear (Bank1)	Engine (RH Bank)
1590	Control the VVT Exhaust Linear (Bank2)	Engine (RH Bank)
1591	Control the VVT System (Bank1)	Engine (RH Bank)
1592	Control the VVT System (Bank2)	Engine (RH Bank)
1593	Control the VVT Linear (Bank1)	Engine (RH Bank)
1594	Control the VVT Linear (Bank2)	Engine (RH Bank)
1595	SOL1 speed	Engine (RH Bank)
1596	Test the Fuel Leak	Engine (RH Bank)
1597	Test the Turbo Charger Step Motor	Engine (RH Bank)

1598	Diesel Throttle Target Angle	Engine (RH Bank)
1599	O/D Cut Solenoid	Engine (RH Bank)
1600	Sucha charger control	Engine (RH Bank)
1601	Ban F / C catalyst OT flame-out prevention	Engine (RH Bank)
1602	Open the filler neck	Engine (RH Bank)
1603	Control the IAC Duty Ratio	Engine (RH Bank)
1604	IAC Step	Engine (RH Bank)
1605	IAC Duty	Engine (RH Bank)
1606	Control the ISC Step Position	Engine (RH Bank)
1607	Fuel Cut Bank 2 for Idle	Engine (RH Bank)
1608	Control the Idle Fuel Cut Prohibit	Engine (RH Bank)
1609	idle-up	Engine (RH Bank)
1610	Idle Up VSV	Engine (RH Bank)
1611	Idle fuel cut bank 2	Engine (RH Bank)
1612	Shift position ECT	Engine (RH Bank)
1613	Control the Shift Position	Engine (RH Bank)
1614	The return side solenoid valve	Engine (RH Bank)
1615	Electrical Fan	Engine (RH Bank)
1616	Control the Electric Cooling Fan	Engine (RH Bank)
1617	electric water pump drive	Engine (RH Bank)
1618	Power Balance (#1 injection stop)	Engine (RH Bank)
1619	power balance (#2 injection stop)	Engine (RH Bank)
1620	Power Balance (#3 injection stop)	Engine (RH Bank)
1621	Power Balance (#4 injection stop)	Engine (RH Bank)
1622	Power Balance (#5 injection stop)	Engine (RH Bank)
1623	Power Balance (#6 injection stop)	Engine (RH Bank)
1624	Power Balance (#7 injection stop)	Engine (RH Bank)
1625	Power Balance (#8 injection stop)	Engine (RH Bank)
1626	ON terminal TC	Engine (RH Bank)
1627	Slip Control Solenoid	Engine (RH Bank)
1628	Air Bleed	Engine (RH Bank)
1629	Exhaust Gas Control VSV	Engine (RH Bank)
1630	Exhaust Bypass Valve	Engine (RH Bank)
1631	Control the EGR Step Position	Engine (RH Bank)
1632	EGR valve is fully closed	Engine (RH Bank)
1633	EGR cut VSV	Engine (RH Bank)
1634	Control the EGR System	Engine (RH Bank)
1635	Stratified combustion control force	Engine (RH Bank)
1636	Secondary Air VSV	Engine (RH Bank)
1637	The high-pressure fuel system inspection	Engine (RH Bank)
1638	Shut-off valve delivery	Engine (RH Bank)
1639	Shut-off valve regulator	Engine (RH Bank)
1640	Control the Line Pressure Up	Engine (RH Bank)
1641	Line Pressure Solenoid	Engine (RH Bank)
1642	Line Pressure Up Solenoid	Engine (RH Bank)
1643	slip control SOL	Engine (RH Bank)
1644	Shift	Engine (RH Bank)
1645	Supercharger Control Relay	Engine (RH Bank)
1646	Activate the EGR Valve Close	Engine (RH Bank)

1647	Activate the VN Turbo Open	Engine (RH Bank)
1648	Activate the DPF Rejuvenate (PM)	Engine (RH Bank)
1649	Activate the DPF Rejuvenate (S)	Engine (RH Bank)
1650	Activate the Solenoid (DS1)	Engine (RH Bank)
1651	Activate the Solenoid (DS2)	Engine (RH Bank)
1652	Activate the Solenoid (DSL)	Engine (RH Bank)
1653	Activate the Solenoid (DSU)	Engine (RH Bank)
1654	Activate the Solenoid (S1)	Engine (RH Bank)
1655	Activate the Solenoid (S2)	Engine (RH Bank)
1656	Activate the Solenoid (S3)	Engine (RH Bank)
1657	Activate the Solenoid (S4)	Engine (RH Bank)
1658	Activate the Solenoid (SB)	Engine (RH Bank)
1659	Activate the Solenoid (SL)	Engine (RH Bank)
1660	Activate the Solenoid (SL1)	Engine (RH Bank)
1661	Activate the Solenoid (SL2)	Engine (RH Bank)
1662	Activate the Solenoid (SL3)	Engine (RH Bank)
1663	Activate the Solenoid (SL4)	Engine (RH Bank)
1664	Activate the Solenoid (SL5)	Engine (RH Bank)
1665	Activate the Solenoid (SLC)	Engine (RH Bank)
1666	Activate the Solenoid (SLN)	Engine (RH Bank)
1667	Activate the Solenoid (SLS)	Engine (RH Bank)
1668	Activate the Solenoid (SLT)	Engine (RH Bank)
1669	Activate the Solenoid (SLU)	Engine (RH Bank)
1670	Activate the Solenoid (SR)	Engine (RH Bank)
1671	Activate the Solenoid (ST)	Engine (RH Bank)
1672	Activate the Solenoid(SC)	Engine (RH Bank)
1673	Activate the Solenoid(SLP)	Engine (RH Bank)
1674	Activate the Electric Water Pump	Engine (RH Bank)
1675	Activate the VSV for EGR Cooler Bypass	Engine (RH Bank)
1676	Activate the ACC Cut Relay	Engine (RH Bank)
1677	Activate the LPG Solenoid Valve	Engine (RH Bank)
1678	Activate the Return Solenoid Valve	Engine (RH Bank)
1679	Activate the Emergency Solenoid Valve	Engine (RH Bank)
1680	Activate the Intank Fuel Pump Relay	Engine (RH Bank)
1681	Activate the Air Pump Heater	Engine (RH Bank)
1682	Activate the Air Switching Valve	Engine (RH Bank)
1683	Active Control Mount	Engine (RH Bank)
1684	Activate the VALVEMATIC (ENG OFF)	Engine (RH Bank)
1685	Activate the VALVEMATIC (ENG ON)	Engine (RH Bank)
1686	Activate the VSV for Exhaust Switching Valve	Engine (RH Bank)
1687	Activate the VSV for Exhaust Brake	Engine (RH Bank)
1688	Activate the Starter Relay	Engine (RH Bank)
1689	Activate the Air Pump	Engine (RH Bank)
1690	Activate the Fuel Pump2 Speed Control	Engine (RH Bank)
1691	Activate the Fuel Pump Speed Control	Engine (RH Bank)
1692	Activate the Fuel Return Pipe Valve	Engine (RH Bank)
1693	Activate the Fuel Route Switching Valve Relay	Engine (RH Bank)
1694	Activate the Fuel Filler Opener	Engine (RH Bank)
1695	Activate the Fuel Vapor-Containment Valve	Engine (RH Bank)

1696	Activate the VSV for Secondary Air Control	Engine (RH Bank)
1697	Activate the VSV for EGR Cut	Engine (RH Bank)
1698	Activate the VSV for Intake Control	Engine (RH Bank)
1699	Activate the VSV for Exhaust Shutter	Engine (RH Bank)
1700	Activate the VSV for Evap Control	Engine (RH Bank)
1701	Activate the VSV for Swirl Control Valve	Engine (RH Bank)
1702	Activate the Brake Ejector VSV	Engine (RH Bank)
1703	Check the Cylinder Compression	Engine (RH Bank)
1704	SOL engagement pressure control	Engine (RH Bank)
1705	Emergency shut-off valve	Engine (RH Bank)
1706	Intake valve control switch	Engine (RH Bank)
1707	Intake Air Control VSV	Engine (RH Bank)
1708	Intake Control VSV1	Engine (RH Bank)
1709	Intake Control VSV2	Engine (RH Bank)
1710	Prohibit the Catalyst OT Misfire prevent F/C	Engine (RH Bank)
1711	purge blockade valve opening and closing	Engine (RH Bank)
1712	Purge Cut VSV	Engine (RH Bank)
1713	Control the Purge Dilution Valve Duty Bank1	Engine (RH Bank)
1714	Control the Purge Dilution Valve Duty Bank2	Engine (RH Bank)
1715	purge dilution valve bank 1	Engine (RH Bank)
1716	purge dilution valve bank 2	Engine (RH Bank)
1717	Purge VSV	Engine (RH Bank)
1718	Variable Intake VSV	Engine (RH Bank)
1719	A/C Cut Signal	Engine (RH Bank)
1720	A/F Control	Engine (RH Bank)
1721	Control the SLS Pressure	Engine (RH Bank)
1722	Control the Regulator Shut Valve	Engine (RH Bank)
1723	Control the Voltage of Alternator	Engine (RH Bank)
1724	Control the A/C Magnet Clutch	Engine (RH Bank)
1725	Control the Injection Volume(CNG)	Engine (RH Bank)
1726	Control the All Cylinders Fuel Cut	Engine (RH Bank)
1727	Control the All Cylinders Fuel Cut(CNG)	Engine (RH Bank)
1728	Control the Select Cylinder Fuel Cut	Engine (RH Bank)
1729	Control the Select Cylinder Fuel Cut(CNG)	Engine (RH Bank)
1730	Connect the TC and TE1	Engine (RH Bank)
1731	Target fuel pressure	Engine (RH Bank)
1732	Control the Target Fuel Pressure	Engine (RH Bank)
1733	Activate the VALVEMATIC after Warm Up	Engine (RH Bank)
1734	Activate the VALVEMATIC before Warm Up	Engine (RH Bank)
1735	Release Bleed	Engine (RH Bank)
1736	Exhaust valve control switch	Engine (RH Bank)
1737	exhaust bypass valve control	Engine (RH Bank)
1738	Switch injection method	Engine (RH Bank)
1739	Injector volume	Engine (RH Bank)

1740	Control the Injection Way	Engine (RH Bank)
1741	Control the Injection Volume	Engine (RH Bank)
1742	Control the Injection Timing #1	Engine (RH Bank)
1743	Control the Injection Timing #2	Engine (RH Bank)
1744	Control the Injection Timing #3	Engine (RH Bank)
1745	Control the Injection Timing #4	Engine (RH Bank)
1746	Control the Injection Timing #5	Engine (RH Bank)
1747	Control the Injection Timing #6	Engine (RH Bank)
1748	Control the Injection Timing #7	Engine (RH Bank)
1749	Control the Injection Timing #8	Engine (RH Bank)
1750	Starter relay	Engine (RH Bank)
1751	SOL forward-reverse switching	Engine (RH Bank)
1752	Force stoichiometric control	Engine (RH Bank)
1753	Driving AI (/ AP-ON open ASV)	Engine (RH Bank)
1754	Driving AI (/ AP-ON closed ASV)	Engine (RH Bank)
1755	Fuel injection timing (#1)	Engine (RH Bank)
1756	Fuel Pump	Engine (RH Bank)
1757	Fuel Pump Relay	Engine (RH Bank)
1758	Fuel Pump Duty	Engine (RH Bank)
1759	Control the Fuel Pump Duty	Engine (RH Bank)
1760	Control the Fuel Pump / Speed	Engine (RH Bank)
1761	FC IDL Prohibit	Engine (RH Bank)
1762	Fuel Press	Engine (RH Bank)
1763	fuel pressure relief valve open	Engine (RH Bank)
1764	Fuel Pressure Relief Valve Close	Engine (RH Bank)
1765	Fuel Pressure Up VSV	Engine (RH Bank)
1766	Fuel Shutoff Valve for Delivery Pipe	Engine (RH Bank)
1767	Activate the Lock Up	Engine (RH Bank)
1768	lock-up SOL	Engine (RH Bank)
1769	Lock Up Solenoid	Engine (RH Bank)
1770	Control the Lock Up	Engine (RH Bank)
1771	lock-up control SOL	Engine (RH Bank)
1772	lock-up control SOL (DSL)	Engine (RH Bank)
1773	lock-up control SOL (DSU)	Engine (RH Bank)
1774	lock-up control SOL (SL)	Engine (RH Bank)
1775	Required voltage power	Engine (RH Bank)
1776	Canister close valve	Engine (RH Bank)
1777	Canister Pressure Control VSV	Engine (RH Bank)
1778	SLS Press	Engine (RH Bank)
1779	Fuel Shutoff Valve for Press Regulator	Engine (RH Bank)
1780	tank bypass	Engine (RH Bank)
1781	Tank Pressure Bypass VSV	Engine (RH Bank)
1782	Boost Pressure Control VSV	Engine (RH Bank)
1783	Vapor Press VSV	Engine (RH Bank)
1784	Timing Solenoid	Engine (RH Bank)
1785	Control the ETCS Open/Close Fast Speed	Engine (RH Bank)
1786	Control the ETCS Open/Close Slow Speed	Engine (RH Bank)
1787	Automatic Oil Supply	Engine (RH Bank)
1788	Automatic lubrication oil	Engine (RH Bank)
1789	3rd sys. air bleed	ABS
1790	ABS MTR RLY	ABS

1791	ABS Warning Light	ABS
1792	DVS buzzer	ABS
1793	SAR1	ABS
1794	SAR2	ABS
1795	SMC1	ABS
1796	SMC2	ABS
1797	Slip IND	ABS
1798	TCS OFF lamp	ABS
1799	VSC lamp	ABS
1800	SOL RELAY	ABS
1801	2nd Sys. Air Bleeding	ABS
1802	SRRH	ABS
1803	SRRR	ABS
1804	SFRH	ABS
1805	SFRR	ABS
1806	Actuator drive(RR)	ABS
1807	Actuator drive(FR)	ABS
1808	Actuator drive(RL)	ABS
1809	Actuator drive(FL)	ABS
1810	Brake Warning Light	ABS
1811	SRLH	ABS
1812	SRLR	ABS
1813	SFLH	ABS
1814	SFLR	ABS
1815	3rd sys. air bleed	ABS/VSC/TRC
1816	4WD Warning Light	ABS/VSC/TRC
1817	A-TRC(TRAC) Indicator Light	ABS/VSC/TRC
1818	ABS MTR RLY	ABS/VSC/TRC
1819	ABS solenoid	ABS/VSC/TRC
1820	ABS Solenoid (SFLR & SFLH)	ABS/VSC/TRC
1821	ABS Solenoid (SFRH & SFLH)	ABS/VSC/TRC
1822	ABS Solenoid (SFRR & SFRH)	ABS/VSC/TRC
1823	ABS Solenoid (SRLR & SRLH)	ABS/VSC/TRC
1824	ABS Solenoid (SRRR & SRRH)	ABS/VSC/TRC
1825	ABS Solenoid (SRRH)	ABS/VSC/TRC
1826	ABS Solenoid (SRRR)	ABS/VSC/TRC
1827	ABS Solenoid (SFRH)	ABS/VSC/TRC
1828	ABS Solenoid (SFRR)	ABS/VSC/TRC
1829	ABS Solenoid (SRLH)	ABS/VSC/TRC
1830	ABS Solenoid (SRLR)	ABS/VSC/TRC
1831	ABS Solenoid (SFLH)	ABS/VSC/TRC
1832	ABS Solenoid (SFLR)	ABS/VSC/TRC
1833	ABS MOT RELAY	ABS/VSC/TRC
1834	ABS WARN LIGHT	ABS/VSC/TRC
1835	ABS Warning Light	ABS/VSC/TRC
1836	ARS warning lamp	ABS/VSC/TRC
1837	ASR/TRC Warning Light	ABS/VSC/TRC
1838	BH Operated Light	ABS/VSC/TRC
1839	BH Standby Light	ABS/VSC/TRC
1840	DAB Indicator Light	ABS/VSC/TRC
1841	DSS Signal Buzzer	ABS/VSC/TRC

1842	DVS buzzer	ABS/VSC/TRC
1843	ECB Solenoid (SC1)	ABS/VSC/TRC
1844	ECB Solenoid (SC2)	ABS/VSC/TRC
1845	ECB Solenoid (SCC)	ABS/VSC/TRC
1846	ECB Solenoid (SCSS)	ABS/VSC/TRC
1847	ECB Solenoid (SLAFL) Valve Open	ABS/VSC/TRC
1848	ECB Solenoid (SLAFL) Valve Close	ABS/VSC/TRC
1849	ECB Solenoid (SLAFR) Valve Open	ABS/VSC/TRC
1850	ECB Solenoid (SLAFR) Valve Close	ABS/VSC/TRC
1851	ECB Solenoid (SLARL) Valve Open	ABS/VSC/TRC
1852	ECB Solenoid (SLARL) Valve Close	ABS/VSC/TRC
1853	ECB Solenoid (SLARR) Valve Open	ABS/VSC/TRC
1854	ECB Solenoid (SLARR) Valve Close	ABS/VSC/TRC
1855	ECB Solenoid (SLA) Valve Close	ABS/VSC/TRC
1856	ECB Solenoid (SLRFL) Valve Open	ABS/VSC/TRC
1857	ECB Solenoid (SLRFL) Valve Close	ABS/VSC/TRC
1858	ECB Solenoid (SLRFR) Valve Open	ABS/VSC/TRC
1859	ECB Solenoid (SLRFR) Valve Close	ABS/VSC/TRC
1860	ECB Solenoid (SLRRL) Valve Open	ABS/VSC/TRC
1861	ECB Solenoid (SLRRL) Valve Close	ABS/VSC/TRC
1862	ECB Solenoid (SLRRR) Valve Open	ABS/VSC/TRC
1863	ECB Solenoid (SLRRR) Valve Close	ABS/VSC/TRC
1864	ECB Solenoid (SLR) Valve Close	ABS/VSC/TRC
1865	ECB Solenoid (SMC/SRC/SCC)	ABS/VSC/TRC
1866	ECB Solenoid (SMC1)	ABS/VSC/TRC
1867	ECB Solenoid (SMC2)	ABS/VSC/TRC
1868	ECB Solenoid (SMC)	ABS/VSC/TRC
1869	ECB Solenoid (SRC)	ABS/VSC/TRC
1870	ECB Solenoid (SSC)	ABS/VSC/TRC
1871	ECB Warning Light	ABS/VSC/TRC
1872	ECB Control Invalid	ABS/VSC/TRC
1873	ECB Indicator Light	ABS/VSC/TRC
1874	ES Start Light	ABS/VSC/TRC
1875	ES Start Buzzer	ABS/VSC/TRC
1876	H/B Motor Relay	ABS/VSC/TRC
1877	PPS Solenoid	ABS/VSC/TRC
1878	SAR1	ABS/VSC/TRC
1879	SAR2	ABS/VSC/TRC
1880	SFLR & SFLH	ABS/VSC/TRC
1881	SFRH & SFLH	ABS/VSC/TRC
1882	SFRR & SFRH	ABS/VSC/TRC
1883	SMC1	ABS/VSC/TRC
1884	SMC2	ABS/VSC/TRC
1885	SRLR & SRLH	ABS/VSC/TRC
1886	SRRH & SRRR	ABS/VSC/TRC
1887	Slip IND	ABS/VSC/TRC
1888	TCS OFF lamp	ABS/VSC/TRC
1889	TPMS Warning Light	ABS/VSC/TRC
1890	TRC motor relay	ABS/VSC/TRC
1891	VSC/TRC (TRAC) Solenoid	ABS/VSC/TRC
1892	VSC/TRC (TRAC) Solenoid (SRCF)	ABS/VSC/TRC

1893	VSC/TRC(TRAC) Solenoid (SRCR)	ABS/VSC/TRC
1894	VSC/TRC(TRAC) Solenoid (SRMF)	ABS/VSC/TRC
1895	VSC/TRC(TRAC) Solenoid (SRMR)	ABS/VSC/TRC
1896	VSC/TRC Solenoid (SMF)	ABS/VSC/TRC
1897	VSC/TRC Solenoid (SMR)	ABS/VSC/TRC
1898	VSC/TRC Solenoid (SPFL)	ABS/VSC/TRC
1899	VSC/TRC Solenoid (SPFR)	ABS/VSC/TRC
1900	VSC/TRC Solenoid (SRCF)	ABS/VSC/TRC
1901	VSC/TRC Solenoid (SRCR)	ABS/VSC/TRC
1902	VSC/TRC Solenoid (SRMF)	ABS/VSC/TRC
1903	VSC/TRC Solenoid (SRMR)	ABS/VSC/TRC
1904	VSC lamp	ABS/VSC/TRC
1905	VSC OFF Indicator Light	ABS/VSC/TRC
1906	Pump Check Pattern	ABS/VSC/TRC
1907	VSC Warning Light	ABS/VSC/TRC
1908	VSC H/B Warning Buzzer	ABS/VSC/TRC
1909	VSC/TRC OFF Indicator Light	ABS/VSC/TRC
1910	Stroke Simulator Cut Valve Pattern	ABS/VSC/TRC
1911	Slip Indicator Light	ABS/VSC/TRC
1912	Solenoid (SLA)	ABS/VSC/TRC
1913	Solenoid (SLR)	ABS/VSC/TRC
1914	SOL RELAY	ABS/VSC/TRC
1915	Motor Relay	ABS/VSC/TRC
1916	Power Supply Air Bleeding Pattern1	ABS/VSC/TRC
1917	Power Supply Air Bleeding Pattern2	ABS/VSC/TRC
1918	ECB Invalid	ABS/VSC/TRC
1919	ECB Motor Relay	ABS/VSC/TRC
1920	ECB Motor Relay2	ABS/VSC/TRC
1921	ECB Main Relay	ABS/VSC/TRC
1922	ECB Main Relay1	ABS/VSC/TRC
1923	ECB Main Relay2	ABS/VSC/TRC
1924	2nd Sys. Air Bleeding	ABS/VSC/TRC
1925	Buzzer	ABS/VSC/TRC
1926	sub-throttle	ABS/VSC/TRC
1927	Crawl Control Light	ABS/VSC/TRC
1928	EBS Relay	ABS/VSC/TRC
1929	Motor Relay1	ABS/VSC/TRC
1930	Motor Relay2	ABS/VSC/TRC
1931	Exhaust Brake Cut Relay	ABS/VSC/TRC
1932	Drain System Air Bleeding Pattern	ABS/VSC/TRC
1933	TRC(TRAC) OFF Indicator Light	ABS/VSC/TRC
1934	TRC Solenoid (SA1 & SA2)	ABS/VSC/TRC
1935	TRC Solenoid (SA1)	ABS/VSC/TRC
1936	TRC Solenoid (SA2)	ABS/VSC/TRC
1937	TRC Solenoid (SFLR & SFLH)	ABS/VSC/TRC
1938	TRC Solenoid (SFRH & SFLH)	ABS/VSC/TRC
1939	TRC Solenoid (SFRR & SFRH)	ABS/VSC/TRC
1940	TRC Solenoid (SMC1)	ABS/VSC/TRC
1941	TRC Solenoid (SMC2)	ABS/VSC/TRC
1942	TRC Solenoid (SMFL)	ABS/VSC/TRC
1943	TRC Solenoid (SMFR & SMFL)	ABS/VSC/TRC

1944	TRC Solenoid (SMFR)	ABS/VSC/TRC
1945	TRC Solenoid (SMF)	ABS/VSC/TRC
1946	TRC Solenoid (SMR & SPFR)	ABS/VSC/TRC
1947	TRC Solenoid (SMR)	ABS/VSC/TRC
1948	TRC Solenoid (SPFL)	ABS/VSC/TRC
1949	TRC Solenoid (SPFR)	ABS/VSC/TRC
1950	TRC Solenoid (SRCF & SRCR)	ABS/VSC/TRC
1951	TRC Solenoid (SRCF)	ABS/VSC/TRC
1952	TRC Solenoid (SRCR)	ABS/VSC/TRC
1953	TRC Solenoid (SRH)	ABS/VSC/TRC
1954	TRC Solenoid (SRLR & SRLH)	ABS/VSC/TRC
1955	TRC Solenoid (SRMF & SRMR)	ABS/VSC/TRC
1956	TRC Solenoid (SRMF)	ABS/VSC/TRC
1957	TRC Solenoid (SRMR)	ABS/VSC/TRC
1958	TRC Solenoid (SRRR & SRRH)	ABS/VSC/TRC
1959	TRC Solenoid (SS)	ABS/VSC/TRC
1960	TRC(TRAC) Motor Relay	ABS/VSC/TRC
1961	Pre Crash Brake OFF Light	ABS/VSC/TRC
1962	Tire Pressure Warning Light	ABS/VSC/TRC
1963	Tire Pressure Light	ABS/VSC/TRC
1964	Stop Light Relay	ABS/VSC/TRC
1965	Stop light System Indicator Light	ABS/VSC/TRC
1966	Downhill Assist Control Light	ABS/VSC/TRC
1967	Accumulator pressure lowered to zero drive	ABS/VSC/TRC
1968	SRRH	ABS/VSC/TRC
1969	RR Wheel Air Bleeding Pattern	ABS/VSC/TRC
1970	SRRR	ABS/VSC/TRC
1971	SFRH	ABS/VSC/TRC
1972	SFRR	ABS/VSC/TRC
1973	Pre-Charge Pump	ABS/VSC/TRC
1974	Sports Mode Indicator Light	ABS/VSC/TRC
1975	Actuator Air Bleeding Pattern	ABS/VSC/TRC
1976	Actuator drive(RR)	ABS/VSC/TRC
1977	Actuator drive(FR)	ABS/VSC/TRC
1978	Actuator drive(RL)	ABS/VSC/TRC
1979	Actuator drive(FL)	ABS/VSC/TRC
1980	BRAKE WRN LIGHT	ABS/VSC/TRC
1981	Brake Warning Light	ABS/VSC/TRC
1982	Master Cut Valve1	ABS/VSC/TRC
1983	Master Cut Valve2	ABS/VSC/TRC
1984	Auto LSD Indicator Light	ABS/VSC/TRC
1985	SRLH	ABS/VSC/TRC
1986	RL Wheel Air Bleeding Pattern	ABS/VSC/TRC
1987	SRLR	ABS/VSC/TRC
1988	SFLH	ABS/VSC/TRC
1989	SFLR	ABS/VSC/TRC
1990	Suteroku confirmation warning	Immobiliser
1991	Suteroku not release warning	Immobiliser
1992	caught warning	Immobiliser
1993	Security Indicators	Immobiliser

1994	Security Indicator	Immobiliser
1995	Not P-position Warning	Immobiliser
1996	Meter Buzzer	Immobiliser
1997	Meter Chime	Immobiliser
1998	non-shift P warning	Immobiliser
1999	Break Cable Warning	Immobiliser
2000	Antenna Coil Power	Immobiliser
2001	cable breakage warning	Immobiliser
2002	Meter Chime Continuously	Immobiliser
2003	meter chime (continuous)	Immobiliser
2004	Unmatch Key Warning	Immobiliser
2005	key difference warning	Immobiliser
2006	Stuck Steering Warning	Immobiliser
2007	Security Indicator	
2008	Not P-position Warning	
2009	Meter Buzzer	
2010	Meter Chime	
2011	Break Cable Warning	
2012	Meter Chime Continuously	
2013	Unmatch Key Warning	
2014	Stuck Steering Warning	
2015	Security Horn	Immobi
2016	Security Horn2	Immobi
2017	Security Indicator	Immobi
2018	P Transmitter	Immobi
2019	Pr-Seat Outside Transmitter	Immobi
2020	Headlight Relay	Immobi
2021	Over Head Tuner	Immobi
2022	Buzzer Response Sound	Immobi
2023	Buzzer For Accessory Output	Immobi
2024	Pager For Accessory Output	Immobi
2025	D Transmitter	Immobi
2026	Inside Luggage Tuner	Immobi
2027	Vehicle Horn	Immobi
2028	Fr Transmitter	Immobi
2029	Front Fog Light Relay	Immobi
2030	Power For Tilt Sensor	Immobi
2031	Power For Intrusion Sensor2	Immobi
2032	Power For Intrusion Sensor	Immobi
2033	Hazard	Immobi
2034	Tail Light	Immobi
2035	Taillight Relay	Immobi
2036	Luggage Transmitter	Immobi
2037	In Luggage Transmitter	Immobi
2038	Trunk Lid Open	Immobi
2039	Key Remained Buzzer	Immobi
2040	Rr Transmitter	Immobi
2041	Smart Indicator	Immobi
2042	Shutter Closing Operation Fixed Length	Grill Shutter
2043	Shutter Closing Operation Lock Detection	Grill Shutter

2044	Shutter Opening Operation Fixed Length	Grill Shutter
2045	Shutter Opening Operation Lock Detection	Grill Shutter
2046	Washer Motor Operation	Wiper
2047	Wiper Motor Lo	Wiper
2048	Wiper Motor Hi	Wiper
2049	unlocked position	Rear Console Switch
2050	Night Lighting	Rear Console Switch
2051	Audio / Heater IG	Rear Console Switch
2052	Audio / Heater Power Supply	Rear Console Switch
2053	R/L Selection SW Right Indicator Red	Rear Console Switch
2054	R/L Selection SW Right Indicator Full	Rear Console Switch
2055	R/L Selection SW Left Indicator Red	Rear Console Switch
2056	R/L Selection SW Left Indicator Full	Rear Console Switch
2057	Rear Right Seat A/C Indicator Red	Rear Console Switch
2058	Rear Right Seat A/C Indicator Full	Rear Console Switch
2059	Rear Right Seat A/C Level Indicator Red	Rear Console Switch
2060	Rear Right Seat A/C Level Indicator Full	Rear Console Switch
2061	Rear Right Seat A/C Auto Indicator Red	Rear Console Switch
2062	Rear Left Seat A/C Indicator Red	Rear Console Switch
2063	Rear Left Seat A/C Indicator Full	Rear Console Switch
2064	Rear Left Seat A/C Level Indicator Red	Rear Console Switch
2065	Rear Left Seat A/C Level Indicator Full	Rear Console Switch
2066	Rear Left Seat A/C Auto Indicator Red	Rear Console Switch
2067	Rear Left Seat A/C Auto Indicator Full	Rear Console Switch
2068	Backup Light	Back Door P/W
2069	Power Window	Back Door P/W
2070	PBD Buzzer	Back Door P/W
2071	PBD Motor	Back Door P/W
2072	Rear Wiper	Back Door P/W
2073	Courtesy SW Signal	Back Door P/W
2074	Door Lock	Back Door P/W
2075	License Light	Back Door P/W
2076	Latch Release	Back Door P/W
2077	PBD Open/Close	R DOOR
2078	PBD Buzzer	R DOOR
2079	PBD Close SW Light	R DOOR
2080	PBD Clutch	R DOOR
2081	PBD Motor	R DOOR
2082	Courtesy SW Signal	R DOOR
2083	Latch Release	R DOOR
2084	Interior Illumination Light	Mirror L
2085	Power Window SW LED	Mirror L
2086	Mirror Heater	Mirror L
2087	Mirror Up/Down	Mirror L
2088	Mirror Right/Left	Mirror L
2089	Mirror Fold/Return	Mirror L
2090	Inside Handle Light	Mirror L
2091	Courtesy Light	Mirror L

2092	Foot Light	Mirror L
2093	Ashtray Light	Mirror L
2094	Interior Illumination Light	
2095	Power Window SW LED	
2096	Mirror Heater	
2097	Mirror Up/Down	
2098	Mirror Right/Left	
2099	Mirror Fold/Return	
2100	Inside Handle Light	
2101	Courtesy Light	
2102	Foot Light	
2103	Ashtray Light	
2104	Interior Illumination Light	Mirror R
2105	P Mirror Right/Left	Mirror R
2106	Power Window SW LED	Mirror R
2107	Mirror Heater	Mirror R
2108	Mirror Up/Down	Mirror R
2109	P Mirror Up/Down	Mirror R
2110	Mirror Right/Left	Mirror R
2111	P Mirror Fold/Return	Mirror R
2112	Mirror Fold/Return	Mirror R
2113	D Mirror Heater	Mirror R
2114	D Mirror Right/Left	Mirror R
2115	D Foot Light	Mirror R
2116	P Foot Light	Mirror R
2117	Inside Handle Light	Mirror R
2118	Courtesy Light	Mirror R
2119	D Mirror Up/Down	Mirror R
2120	D Mirror Fold/Return	Mirror R
2121	Foot Light	Mirror R
2122	Ashtray Light	Mirror R
2123	P Mirror Right/Left	
2124	Mirror Heater	
2125	Mirror Up/Down	
2126	P Mirror Up/Down	
2127	Mirror Right/Left	
2128	P Mirror Fold/Return	
2129	Mirror Fold/Return	
2130	D Mirror Heater	
2131	D Mirror Right/Left	
2132	D Foot Light	
2133	P Foot Light	
2134	D Mirror Up/Down	
2135	D Mirror Fold/Return	
2136	Foot Light	
2137	Interior Illumination Light	
2138	Power Window SW LED	
2139	Mirror Heater	
2140	Mirror Up/Down	
2141	Mirror Right/Left	
2142	Mirror Fold/Return	

2143	Inside Handle Light	
2144	Courtesy Light	
2145	Foot Light	
2146	Ashtray Light	
2147	Inside Handle Illumination	Mirror
2148	Interior Illumination Light	Mirror
2149	P Mirror Right/Left	Mirror
2150	Power Window SW LED	Mirror
2151	Mirror Return	Mirror
2152	Mirror Heater	Mirror
2153	Mirror Up/Down	Mirror
2154	P Mirror Up/Down	Mirror
2155	Mirror Right/Left	Mirror
2156	P Mirror Fold/Return	Mirror
2157	Mirror Fold/Return	Mirror
2158	D Mirror Heater	Mirror
2159	D Mirror Right/Left	Mirror
2160	D Foot Light	Mirror
2161	P Foot Light	Mirror
2162	Inside Handle Light	Mirror
2163	Courtesy Light	Mirror
2164	Door Lock	Mirror
2165	Double Lock Unset	Mirror
2166	D Mirror Up/Down	Mirror
2167	D Mirror Fold/Return	Mirror
2168	Foot Light	Mirror
2169	Ashtray Light	Mirror
2170	RH Mirror Up/Down	Mirror
2171	RH Mirror Right/Left	Mirror
2172	Mirror Fold	Mirror
2173	Mirror Fold	Mirror
2174	LH Mirror Up/Down	Mirror
2175	LH Mirror Right/Left	Mirror
2176	Seat Memory Light	Mirror
2177	Inside Handle Illumination	
2178	Mirror Return	
2179	Mirror Heater	
2180	Mirror Up/Down	
2181	Mirror Right/Left	
2182	Courtesy Light	
2183	Door Lock	
2184	Double Lock Unset	
2185	Foot Light	
2186	RH Mirror Up/Down	
2187	RH Mirror Right/Left	
2188	Mirror Fold	
2189	LH Mirror Up/Down	
2190	LH Mirror Right/Left	
2191	Seat Memory Light	
2192	P Mirror Right/Left	Mirror(Letf and Right)
2193	Mirror Heater	Mirror(Letf and Right)

2194	Mirror Up/Down	Mirror(Letf and Right)
2195	P Mirror Up/Down	Mirror(Letf and Right)
2196	Mirror Right/Left	Mirror(Letf and Right)
2197	P Mirror Fold/Return	Mirror(Letf and Right)
2198	Mirror Fold/Return	Mirror(Letf and Right)
2199	D Mirror Heater	Mirror(Letf and Right)
2200	D Mirror Right/Left	Mirror(Letf and Right)
2201	D Foot Light	Mirror(Letf and Right)
2202	P Foot Light	Mirror(Letf and Right)
2203	D Mirror Up/Down	Mirror(Letf and Right)
2204	D Mirror Fold/Return	Mirror(Letf and Right)
2205	Foot Light	Mirror(Letf and Right)
2206	Stabilizer Check	Rear Stabilizer
2207	security camera power	Mayday Gateway
2208	Slide Roof	Sliding Roof
2209	Sliding Sunshade	Sliding Sunshade
2210	Discharging Battery to Check Weak Cells	Hybrid Control
2211	Inspection Mode -2WD Chassis-Dynamo	Hybrid Control
2212	Inspection Mode -2WD Inspection	Hybrid Control
2213	Inspection Mode -4WD Chassis-Dynamo	Hybrid Control
2214	Inspection Mode -4WD Inspection	Hybrid Control
2215	MG1 & MG2 Resolver Test	Hybrid Control
2216	MG1 Magnet Test	Hybrid Control
2217	MG1/MG2 Heated	Hybrid Control
2218	MG1 Open Control	Hybrid Control
2219	MG2 Open Control	Hybrid Control
2220	Motor Sensitive Mode	Hybrid Control
2221	ROM & RAM Check	Hybrid Control
2222	T/M Cooler Oil Pump	Hybrid Control
2223	Charge Request Low	Hybrid Control
2224	Charge Request High	Hybrid Control
2225	Charge & Discharge Large SOC	Hybrid Control
2226	Charge & Discharge Current Control	Hybrid Control
2227	Control the Shift Position	Hybrid Control
2228	Battery Charge	Hybrid Control
2229	Forcible Stop of Inverter Drive	Hybrid Control
2230	Discharge Request Low	Hybrid Control
2231	Discharge Request High	Hybrid Control
2232	Activate the (Inverter) Water Pump	Hybrid Control
2233	Activate the Solenoid (SL1)	Hybrid Control
2234	Activate the Solenoid (SL2)	Hybrid Control
2235	Activate the solenoid (Line Pressure)	Hybrid Control
2236	Activate the Water Pump	Hybrid Control
2237	Activate the Oil Pump(1000rpm)	Hybrid Control
2238	Activate the Oil Pump(500rpm)	Hybrid Control
2239	Connect the TC and TE1	Hybrid Control
2240	Motor Driving	Hybrid Control
2241	PWM Output Test	Hybrid Control
2242	Cranking Request	Hybrid Control
2243	Control the Cooling Fan	Hybrid Control

2244	Inspection Mode	Hybrid Control
2245	Compression Test	Hybrid Control
2246	Engine Output Test	Hybrid Control
2247	Regenerative Test	Hybrid Control
2248	MG1 & MG2 Resolver Test	
2249	MG1 Magnet Test	
2250	MG1/MG2 Heated	
2251	MG1 Open Control	
2252	MG2 Open Control	
2253	Motor Sensitive Mode	
2254	ROM & RAM Check	
2255	Charge Request Low	
2256	Charge Request High	
2257	Charge & Discharge Large SOC	
2258	Charge & Discharge Current Control	
2259	Discharge Request Low	
2260	Discharge Request High	
2261	Motor Driving	
2262	PWM Output Test	
2263	Cranking Request	
2264	Inspection Mode	
2265	Engine Output Test	
2266	Regenerative Test	
2267	Luggage Closer Close/Rtn Ini Pos	Retractable Hardtop
2268	PSD Motor	Driver Door
2269	PSD Buzzer	Driver Door
2270	PSD Clutch	Driver Door
2271	Inside Handle Illumination	Driver Door
2272	Power Window	Driver Door
2273	Mirror Return	Driver Door
2274	Mirror Heater	Driver Door
2275	Mirror Up/Down	Driver Door
2276	Mirror Right/Left	Driver Door
2277	Mirror Fold/Return	Driver Door
2278	Memory Cancel Lamp	Driver Door
2279	Courtesy Lamp	Driver Door
2280	Courtesy Light	Driver Door
2281	Door Lock	Driver Door
2282	Release Actuator	Driver Door
2283	Double Lock Unset	Driver Door
2284	Foot Light	Driver Door
2285	Ashtray Light	Driver Door
2286	RH Mirror Up/Down	Driver Door
2287	RH Mirror Right/Left	Driver Door
2288	Mirror Fold	Driver Door
2289	P Manual SW LED	Driver Door
2290	LH Mirror Up/Down	Driver Door
2291	LH Mirror Right/Left	Driver Door
2292	Seat Memory Light	Driver Door
2293	Power Window	D-Door Motor
2294	Side Support Operation	Driver Seat

2295	Buzzer	Driver Seat
2296	Rear Seat Lumbar Adjustment	Driver Seat
2297	Headrest Operation	Driver Seat
2298	Pelvis Support Operation	Driver Seat
2299	Front Vertical Operation	Driver Seat
2300	Lifter Operation	Driver Seat
2301	Lumbar Slide	Driver Seat
2302	Lumbar Lift	Driver Seat
2303	Cushion Length	Driver Seat
2304	Seat Slide Operation	Driver Seat
2305	Seat Reclining	Driver Seat
2306	2nd Gear Start Switch Activation	D-SEAT SW
2307	BSM Switch Indicator (Daytime)	D-SEAT SW
2308	BSM Switch Indicator (Night/ Stopped)	D-SEAT SW
2309	BSM Switch Indicator (Night/ Moving)	D-SEAT SW
2310	Steering Heater Active Request (Direct Line)	D-SEAT SW
2311	Crawl Indicator	D-SEAT SW
2312	Mirror Auto Indicator (Daytime)	D-SEAT SW
2313	Mirror Auto Indicator (Night Stopping)	D-SEAT SW
2314	Mirror Auto Indicator (Night Running)	D-SEAT SW
2315	Clearance Sonar Switch Activation	D-SEAT SW
2316	Clearance Sonar Indicator (Daytime)	D-SEAT SW
2317	Clearance Sonar Indicator (Night Stopping)	D-SEAT SW
2318	Clearance Sonar Indicator (Night Running)	D-SEAT SW
2319	Night Lighting	D-SEAT SW
2320	Off-road 1 Indicator (Daytime)	D-SEAT SW
2321	Off-road 1 Indicator (Nighttime)	D-SEAT SW
2322	Off-road 2 Indicator (Daytime)	D-SEAT SW
2323	Off-road 2 Indicator (Nighttime)	D-SEAT SW
2324	Off-road 3 Indicator (Daytime)	D-SEAT SW
2325	Off-road 3 Indicator (Nighttime)	D-SEAT SW
2326	Off-road 4 Indicator (Daytime)	D-SEAT SW
2327	Off-road 4 Indicator (Nighttime)	D-SEAT SW
2328	Off-road Switch Light	D-SEAT SW
2329	Off-road Guidance Indicator	D-SEAT SW
2330	Buzzer	Clearance sonar
2331	Rear Buzzer	Clearance sonar
2332	Front Buzzer	Clearance sonar
2333	Front/Rear Buzzer	Clearance sonar
2334	P-Seat Outside Transmitter	Entry&Start
2335	P-Seat Select	Entry&Start
2336	Pr-Seat Select	Entry&Start
2337	Pr-Seat Outside Transmitter	Entry&Start
2338	Overhead Tuner Power Supply On	Entry&Start
2339	Rr-Seat Inside Transmitter	Entry&Start
2340	D-Seat Outside Transmitter	Entry&Start
2341	D-Seat Select	Entry&Start
2342	Dr-Seat Select	Entry&Start
2343	Inside Luggage Tuner Power Supply On	Entry&Start

2344	Inside Trunk/Backdoor Transmitter	Entry&Start
2345	Fr-Seat Inside Transmitter	Entry&Start
2346	Outside Trunk/Backdoor Transmitter	Entry&Start
2347	Security Indicator	Entry&Start
2348	P-Seat Outside Transmitter	Entry&Start
2349	P-Seat Select	Entry&Start
2350	Pr-Seat Select	Entry&Start
2351	Pr-Seat Outside Transmitter	Entry&Start
2352	Power for P-Seat Sens	Entry&Start
2353	Overhead Tuner Power Supply On	Entry&Start
2354	Power/Engine SW Light	Entry&Start
2355	Rr-Seat Inside Transmitter	Entry&Start
2356	D-Seat Outside Transmitter	Entry&Start
2357	D-Seat Select	Entry&Start
2358	Dr-Seat Select	Entry&Start
2359	Power for D-Seat Sens	Entry&Start
2360	Inside Luggage Tuner Power Supply On	Entry&Start
2361	Inside Trunk/Backdoor Transmitter	Entry&Start
2362	Fr-Seat Inside Transmitter	Entry&Start
2363	Outside Trunk/Backdoor Transmitter	Entry&Start
2364	Wireless Buzzer	Entry&Start
2365	Back Door Select	Entry&Start
2366	Power SW Light	
2367	Security Horn	
2368	Security Horn2	
2369	Security Indicator	
2370	Power for PR-Seat Sens	
2371	P-Seat Outside Transmitter	
2372	P-Seat Select	
2373	Pr-Seat Select	
2374	Pr-Seat Outside Transmitter	
2375	Power for P-Seat Sens	
2376	Overhead Tuner Power Supply On	
2377	Power/Engine SW Light	
2378	Multi Channel SW	
2379	Immobiliser Indicator	
2380	Power for BDoor Sens	
2381	Rr-Seat Inside Transmitter	
2382	D-Seat Outside Transmitter	
2383	D-Seat Select	
2384	Dr-Seat Select	
2385	Power for DR-Seat Sens	
2386	Inside Luggage Tuner Power Supply On	
2387	Inside Trunk/Backdoor Transmitter	
2388	Fr-Seat Inside Transmitter	
2389	Power For Tilt Sensor	
2390	Power For Intrusion Sensor	
2391	Outside Trunk/Backdoor Transmitter	
2392	Tail Light	
2393	Wireless Buzzer Operation	
2394	Back Door Select	

2395	Power SW Light	Entry&Start (CAN)
2396	Security Horn	Entry&Start (CAN)
2397	Security Indicator	Entry&Start (CAN)
2398	Power for PR-Seat Sens	Entry&Start (CAN)
2399	P-Seat Outside Transmitter	Entry&Start (CAN)
2400	P-Seat Select	Entry&Start (CAN)
2401	Pr-Seat Select	Entry&Start (CAN)
2402	Pr-Seat Outside Transmitter	Entry&Start (CAN)
2403	Power for P-Seat Sens	Entry&Start (CAN)
2404	Overhead Tuner Power Supply On	Entry&Start (CAN)
2405	Power/Engine SW Light	Entry&Start (CAN)
2406	Multi Channel SW	Entry&Start (CAN)
2407	Immobiliser Indicator	Entry&Start (CAN)
2408	Rr-Seat Inside Transmitter	Entry&Start (CAN)
2409	D-Seat Outside Transmitter	Entry&Start (CAN)
2410	D-Seat Select	Entry&Start (CAN)
2411	Dr-Seat Select	Entry&Start (CAN)
2412	Power for DR-Seat Sens	Entry&Start (CAN)
2413	Inside Luggage Tuner Power Supply On	Entry&Start (CAN)
2414	Inside Trunk/Backdoor Transmitter	Entry&Start (CAN)
2415	Fr-Seat Inside Transmitter	Entry&Start (CAN)
2416	Power For Tilt Sensor	Entry&Start (CAN)
2417	Power For Intrusion Sensor	Entry&Start (CAN)
2418	Outside Trunk/Backdoor Transmitter	Entry&Start (CAN)
2419	Tail Light	Entry&Start (CAN)
2420	Wireless Buzzer Operation	Entry&Start (CAN)
2421	Back Door Select	Entry&Start (CAN)
2422	Self-powered siren	Entry&Start (CAN)
2423	P-Seat Outside Transmitter	Entry&Start (SIL)
2424	P-Seat Select	Entry&Start (SIL)
2425	Pr-Seat Select	Entry&Start (SIL)
2426	Pr-Seat Outside Transmitter	Entry&Start (SIL)
2427	Overhead Tuner Power Supply On	Entry&Start (SIL)
2428	Rr-Seat Inside Transmitter	Entry&Start (SIL)
2429	D-Seat Outside Transmitter	Entry&Start (SIL)
2430	D-Seat Select	Entry&Start (SIL)
2431	Dr-Seat Select	Entry&Start (SIL)
2432	Inside Luggage Tuner Power Supply On	Entry&Start (SIL)
2433	Inside Trunk/Backdoor Transmitter	Entry&Start (SIL)
2434	Fr-Seat Inside Transmitter	Entry&Start (SIL)
2435	Outside Trunk/Backdoor Transmitter	Entry&Start (SIL)
2436	Hill start solenoid output signal	eco IDLE
2437	T terminal	eco IDLE
2438	buzzer output signal	eco IDLE
2439	eco-run permit conditions (CVT ECU conditions)	eco IDLE
2440	eco-run permit conditions (EFI ECU conditions)	eco IDLE
2441	eco-run permit conditions (battery condition)	eco IDLE
2442	eco-run permit conditions (gradient conditions)	eco IDLE

2443	Signal starter drive	eco IDLE
2444	Luggage Closer Close/Rtn Ini Pos	Retractable Hardtop
2445	pedal	Movable pedal
2446	D_A / M (pulse)	A/C
2447	D blowout (pulse)	A/C
2448	HWD Relay	A/C
2449	M/H Bypass Cool Servo Pls	A/C
2450	M/H Bypass Hot Servo Pls	A/C
2451	P A / M (pulse)	A/C
2452	Rear A/M Servo Pulse(P)	A/C
2453	Room Temp Sensor(C)	A/C
2454	Room Temp Sensor(F)	A/C
2455	Air Outlet Damper	A/C
2456	Air Outlet Damper Position (P Side)	A/C
2457	Air Outlet Damper Position (Rear)	A/C
2458	Air Outlet Damper Position (D Side)	A/C
2459	Air Outlet Servomotor Step (P Side)	A/C
2460	Air Outlet Servomotor Step (D Side)	A/C
2461	Air Outlet Servo Pulse (P)	A/C
2462	Air Outlet Servo Pulse (D)	A/C
2463	Deicer Relay (Front)	A/C
2464	Dehumidification Magnetic Valve	A/C
2465	Dehumidification solenoid valves	A/C
2466	Defogger Relay (Rear)	A/C
2467	Defogger Switch (Rear)	A/C
2468	plasma cluster drive	A/C
2469	Low pressure solenoid valves	A/C
2470	Battery Magnetic Valve	A/C
2471	Batt Cool Down Servo Targ Pls	A/C
2472	Magnetic Valve Operation	A/C
2473	Magnetic Clutch Relay	A/C
2474	Electrical Fan	A/C
2475	Electric Heater3	A/C
2476	electric compressor rotation	A/C
2477	electric heater 3	A/C
2478	Electric Heater1	A/C
2479	Electric Heater2	A/C
2480	Electric Water Heater	A/C
2481	Active Test	A/C
2482	engine coolant	A/C
2483	Engine Coolant Temp Sensor(C)	A/C
2484	Engine Coolant Temp Sensor(F)	A/C
2485	Assist Fan	A/C
2486	oxygen-rich drive	A/C
2487	High pressure solenoid valves	A/C
2488	Blower Motor	A/C
2489	Blower Motor (Rear)	A/C
2490	Rear A / C indicator	A/C
2491	Rear A / C Magnet	A/C
2492	rear air purifier	A/C
2493	Rear Blower Motor	A/C

2494	rear blower air volume	A/C
2495	Rear Air Mix Servo Targ Pulse	A/C
2496	rear exhaust damper position	A/C
2497	Mirror Heater	A/C
2498	Ambient Temp Sensor(C)	A/C
2499	Ambient Temp Sensor(F)	A/C
2500	Air Mix Servo Targ Pulse(D)	A/C
2501	Air Mix Servo Targ Pulse(P)	A/C
2502	Viscous Heater	A/C
2503	Heater Active Level	A/C
2504	Heating Three-way Valve	A/C
2505	Foot A/O Servo Pulse(P)	A/C
2506	Foot A/O Servo Pulse(D)	A/C
2507	Air Inlet Damper Targ Pulse	A/C
2508	suction port (pulse)	A/C
2509	suction port (servo motor)	A/C
2510	Air Inlet Damper Position (Linear)	A/C
2511	Rear A/C Mag Valve	A/C
2512	Air Purifier Mode	A/C
2513	air sensor	A/C
2514	Air Mix Damper (P)	A/C
2515	Air Mix Damper (P Side)	A/C
2516	Air Mix Damper (Rear)	A/C
2517	Air Mix Damper (D)	A/C
2518	Air Mix Damper (D Side)	A/C
2519	Air Mix Servomotor Step (P Side)	A/C
2520	Air Mix Servomotor Step (D Side)	A/C
2521	Air Purifier(Clean)	A/C
2522	Air Purifier(Ion)	A/C
2523	Diffuse Pulse(R)	A/C
2524	Cool A/M Servo Pulse(P)	A/C
2525	Cool A/M Servo Pulse(D)	A/C
2526	Cool Air Bypass Pulse	A/C
2527	Cool Air Bypass Pls(P)	A/C
2528	Cool Air Bypass Damper (P Side)	A/C
2529	Cool Air Bypass Damper (D Side)	A/C
2530	electric water pump	A/C
2531	Ion Generator	A/C
2532	Face A/O Servo Pulse(P)	A/C
2533	Inside and Outside Change	A/C
2534	sensor shy	A/C
2535	inside and outside air switching	A/C
2536	Emission Pulse(R)	A/C
2537	Exhaust Damper Position (Rear)	A/C
2538	DEF A/O Servo Pulse(D)	A/C
2539	A/O Servo Pulse(Rr P)	A/C
2540	A/O Servo Pulse(F&R P)	A/C
2541	A/O Servo Pulse(F&R D)	A/C
2542	Face A/O Servo Pulse(D)	A/C
2543	bypass (pulse)	A/C
2544	Actuator Check	A/C

2545	Heat Exchange Shut Valve	A/C
2546	heat exchange shut valve drive	A/C
2547	Three-way valve drive heating	A/C
2548	Water Pump	A/C
2549	Compressor Target Speed	A/C
2550	compressor drive valve	A/C
2551	Solar Sensor	A/C
2552	Oxygen Drive	A/C
2553	viscous heater drive	A/C
2554	Evaporator Magnetic Valve	A/C
2555	Auto Switch	A/C
2556	Height control wheel FL	Air Suspension
2557	FR Solenoid	Air Suspension
2558	FR wheel height control	Air Suspension
2559	RL Solenoid	Air Suspension
2560	RL wheel height control	Air Suspension
2561	RR Solenoid	Air Suspension
2562	RR wheel height control	Air Suspension
2563	Low Pressure Tank Solenoid	Air Suspension
2564	Motor Relay	Air Suspension
2565	rear gate	Air Suspension
2566	rear vehicle height control	Air Suspension
2567	rear leveling	Air Suspension
2568	Rear damping force control	Air Suspension
2569	Exhaust Solenoid	Air Suspension
2570	front gate	Air Suspension
2571	front vehicle height control	Air Suspension
2572	front leveling	Air Suspension
2573	Front damping force control	Air Suspension
2574	accumulator	Air Suspension
2575	Max Damper Step RR	Air Suspension
2576	Max Damper Step FR	Air Suspension
2577	Main Relay Expectation	Air Suspension
2578	Max Damper Step RL	Air Suspension
2579	FL Solenoid	Air Suspension
2580	Max Damper Step FL	Air Suspension
2581	FL wheel spring switching valve	Air suspension
2582	Height control wheel FL	Air suspension
2583	FR Damper Test	Air suspension
2584	FR Height	Air suspension
2585	FR Solenoid	Air suspension
2586	FR wheel spring switching valve	Air suspension
2587	FR wheel height control	Air suspension
2588	RL Solenoid	Air suspension
2589	RL wheel height control	Air suspension
2590	RR Damper Test	Air suspension
2591	RR Solenoid	Air suspension
2592	RR wheel height control	Air suspension
2593	SLRG	Air suspension
2594	SLRL	Air suspension
2595	Low Pressure Tank Solenoid	Air suspension

2596	Motor Relay	Air suspension
2597	Rear gate valve	Air suspension
2598	Rear Leveling Solenoid	Air suspension
2599	Height control rear wheel	Air suspension
2600	Rear Wheel Up/Down	Air suspension
2601	rear wheel accumulator rise	Air suspension
2602	Rear Gate Solenoid	Air suspension
2603	Exhaust Solenoid	Air suspension
2604	Front Leveling Solenoid	Air suspension
2605	Height control front wheel	Air suspension
2606	Front Wheel Up/Down	Air suspension
2607	front wheel accumulator rise	Air suspension
2608	Front Wheel Up by Accumulator	Air suspension
2609	Front Gate Solenoid	Air suspension
2610	Front gate valve	Air suspension
2611	FR Gas Spring Switch Valve	Air suspension
2612	Front Left Solenoid	Air suspension
2613	Front Left Height Solenoid	Air suspension
2614	Front Left Wheel Up/Down	Air suspension
2615	FL Gas Spring Switch Valve	Air suspension
2616	pump motor relay	Air suspension
2617	Four-Wheel Damping Force Full Soft	Air suspension
2618	Four-Wheel Damping Force Full Hard	Air suspension
2619	Accumulator Solenoid	Air suspension
2620	Accumulator valve	Air suspension
2621	Rear Wheel Up by Accumulator	Air suspension
2622	High-wheeled vehicles solenoid RR	Air suspension
2623	Rear Right Solenoid	Air suspension
2624	RR Wheel Up/Down	Air suspension
2625	RR Height	Air suspension
2626	Rear Right Height Solenoid	Air suspension
2627	Damper Step RR	Air suspension
2628	Rear Right Wheel Up/Down	Air suspension
2629	Front Right Solenoid	Air suspension
2630	Front Right Height Solenoid	Air suspension
2631	Damper Step FR	Air suspension
2632	Solenoid wheel vehicle height FR	Air suspension
2633	FR Wheel Up/Down	Air suspension
2634	Main Relay	Air suspension
2635	Rear Left Solenoid	Air suspension
2636	Rear Left Height Solenoid	Air suspension
2637	Damper Step RL	Air suspension
2638	Solenoid wheel vehicle height RL	Air suspension
2639	RL Wheel Up/Down	Air suspension
2640	High-wheeled vehicles solenoid FL	Air suspension
2641	FL Solenoid	Air suspension
2642	Damper Step FL	Air suspension
2643	FL Wheel Up/Down	Air suspension
2644	Low Pressure Tank Solenoid	
2645	Motor Relay	
2646	Rear gate valve	

2647	Rear Leveling Solenoid	
2648	Rear Wheel Up/Down	
2649	Rear Gate Solenoid	
2650	Exhaust Solenoid	
2651	Front Wheel Up/Down	
2652	Front Wheel Up by Accumulator	
2653	Front gate valve	
2654	FR Gas Spring Switch Valve	
2655	Front Left Solenoid	
2656	Front Left Height Solenoid	
2657	Front Left Wheel Up/Down	
2658	FL Gas Spring Switch Valve	
2659	pump motor relay	
2660	Four-Wheel Damping Force Full Soft	
2661	Four-Wheel Damping Force Full Hard	
2662	Accumulator valve	
2663	Rear Wheel Up by Accumulator	
2664	Rear Right Solenoid	
2665	RR Wheel Up/Down	
2666	Rear Right Height Solenoid	
2667	Damper Step RR	
2668	Rear Right Wheel Up/Down	
2669	Front Right Solenoid	
2670	Front Right Height Solenoid	
2671	Damper Step FR	
2672	FR Wheel Up/Down	
2673	Rear Left Solenoid	
2674	Rear Left Height Solenoid	
2675	Damper Step RL	
2676	RL Wheel Up/Down	
2677	Damper Step FL	
2678	FL Wheel Up/Down	
2679	FR Damper Test	
2680	FR Height	
2681	FR Solenoid	
2682	RL Solenoid	
2683	RR Damper Test	
2684	RR Solenoid	
2685	Low Pressure Tank Solenoid	
2686	Motor Relay	
2687	Rear Leveling Solenoid	
2688	Rear Gate Solenoid	
2689	Exhaust Solenoid	
2690	Front Leveling Solenoid	
2691	Front Gate Solenoid	
2692	Accumulator Solenoid	
2693	RR Wheel Up/Down	
2694	RR Height	
2695	Damper Step RR	
2696	Damper Step FR	
2697	FR Wheel Up/Down	

2698	Main Relay	
2699	Damper Step RL	
2700	RL Wheel Up/Down	
2701	FL Solenoid	
2702	Damper Step FL	
2703	FL Wheel Up/Down	
2704	Bluetooth LED	Bluetooth Communication Module
2705	ABS W light	VSC
2706	ABS MOT RELAY	VSC
2707	DVS buzzer	VSC
2708	SAR1	VSC
2709	SAR2	VSC
2710	SMC1	VSC
2711	SMC2	VSC
2712	TCS OFF light	VSC
2713	VSC OFF light	VSC
2714	VSC light	VSC
2715	slip indicator	VSC
2716	SOL RELAY	VSC
2717	Solenoid SRRH	VSC
2718	Solenoid SRRR	VSC
2719	Solenoid SFRH	VSC
2720	Solenoid SFRR	VSC
2721	Solenoid SRLH	VSC
2722	Solenoid SRLR	VSC
2723	Solenoid SFLH	VSC
2724	Solenoid SFLR	VSC
2725	Secondary system Rihe Aea	VSC
2726	3-order system Rihe Aea	VSC
2727	Brake W light	VSC
2728	Actuator drive(RR)	VSC
2729	Actuator drive(FR)	VSC
2730	Actuator drive(RL)	VSC
2731	Actuator drive(FL)	VSC
2732	LKA Lane Out Alarm Buzzer	Pre-Collision 2
2733	PCS Approach Alarm Buzzer	Pre-Collision 2
2734	PCS Crash Alarm Buzzer	Pre-Collision 2
2735	Infrared Signal Status	Pre-Collision 2
2736	Radar Cruise Approach Alarm Buzzer	Pre-Collision 2
2737	Radar Cruise Stop Buzzer	Pre-Collision 2
2738	Face Direction Check	Pre-Collision 2
2739	Seat Belt Motor Backwards Operation	Pre-Collision
2740	Passenger Seat Belt Motor	Pre-Collision
2741	Driver Seat Belt Motor	Pre-Collision
2742	Driver and Passenger Seat Belt Motor	Pre-Collision
2743	LKA Lane Out Alarm Buzzer	Pre-Crash 2
2744	PCS Approach Alarm Buzzer	Pre-Crash 2
2745	PCS Crash Alarm Buzzer	Pre-Crash 2
2746	Infrared Signal Status	Pre-Crash 2
2747	Radar Cruise Approach Alarm Buzzer	Pre-Crash 2

2748	Radar Cruise Stop Buzzer	Pre-Crash 2
2749	Face Direction Check	Pre-Crash 2
2750	Seat Belt Motor Backwards Operation	Pre-Crash
2751	Passenger Seat Belt Motor	Pre-Crash
2752	Driver Seat Belt Motor	Pre-Crash
2753	Driver and Passenger Seat Belt Motor	Pre-Crash
2754	Passenger Seat Belt Motor	Pre-Crash(SIL)
2755	Driver Seat Belt Motor	Pre-Crash(SIL)
2756	Activate the ACC Cut Relay	Starting Control
2757	Activate the Starter Relay	Starting Control
2758	Stabilizer Check	Front Stabilizer
2759	AFS Alarm Display	HL AutoLeveling
2760	AFS OFF Indicator	HL AutoLeveling
2761	AHS	HL AutoLeveling
2762	ECU factory state initialization	HL AutoLeveling
2763	light ON / OFF1 times equivalent request	HL AutoLeveling
2764	light ON / OFF2 times equivalent request	HL AutoLeveling
2765	light ON / OFF3 times equivalent request	HL AutoLeveling
2766	light ON / OFF4 times equivalent request	HL AutoLeveling
2767	light ON / OFF5 times equivalent request	HL AutoLeveling
2768	actuator operation	HL AutoLeveling
2769	leveling motor down working	HL AutoLeveling
2770	leveling motor upward working	HL AutoLeveling
2771	vehicle height sensor factory for initialization	HL AutoLeveling
2772	Extra High Beam	HL AutoLeveling
2773	Advice Display	HL AutoLeveling
2774	Drive The Leveling Motor	HL AutoLeveling
2775	Drive The Leveling Motor UP	HL AutoLeveling
2776	Drive The Leveling Motor DOWN	HL AutoLeveling
2777	Meter warning run off light	HL AutoLeveling
2778	Meter Indicator	HL AutoLeveling
2779	High Beam RH	HL AutoLeveling
2780	Variable Shade Beam RH	HL AutoLeveling
2781	Drive Swivel Motor RH RIGHT	HL AutoLeveling
2782	Drive Swivel Motor RH LEFT	HL AutoLeveling
2783	Drive Swivel Motor RH	HL AutoLeveling
2784	High Beam Indicator	HL AutoLeveling
2785	Automatic High Beam Operation	HL AutoLeveling
2786	Auto High Beam Warning Indicator	HL AutoLeveling
2787	Auto High Beam Control Indicator	HL AutoLeveling
2788	Variable Shade Beam LH/RH	HL AutoLeveling
2789	High Beam LH	HL AutoLeveling
2790	Variable Shade Beam LH	HL AutoLeveling
2791	Drive Swivel Motor LH RIGHT	HL AutoLeveling
2792	Drive Swivel Motor LH LEFT	HL AutoLeveling
2793	Drive Swivel Motor LH	HL AutoLeveling

2794	Tilt Operation	Tilt&Telescopic
2795	Telesco Operation	Tilt&Telescopic
2796	Seat Belt Anchor Operation	Tilt&Telescopic
2797	Tilt Operation	Tilt&Telescopic
2798	Telesco Operation	Tilt&Telescopic
2799	Seat Belt Anchor Operation	Tilt&Telescopic
2800	SMT Warning Indicator Light Output	Sequential M/T
2801	Target Clutch Control (Stroke Value)	Sequential M/T
2802	Gear Position Indicator Output	Sequential M/T
2803	Warning Buzzer Output	Sequential M/T
2804	Clutch Solenoid Control	Sequential M/T
2805	Motor Relay Control	Sequential M/T
2806	Target Gear Position Control	Sequential M/T
2807	Target Select Stroke Control	Sequential M/T
2808	Target Shift Stroke Control	Sequential M/T
2809	Reduced Accumulator Pressure	Sequential M/T
2810	SMT Warning Indicator Light Output	
2811	Target Clutch Control (Stroke Value)	
2812	Gear Position Indicator Output	
2813	Warning Buzzer Output	
2814	Clutch Solenoid Control	
2815	Motor Relay Control	
2816	Target Gear Position Control	
2817	Target Select Stroke Control	
2818	Target Shift Stroke Control	
2819	Reduced Accumulator Pressure	
2820	Inside Handle Illumination	Driver Door
2821	Power Window	Driver Door
2822	Mirror Return	Driver Door
2823	Mirror Heater	Driver Door
2824	Mirror Up/Down	Driver Door
2825	Mirror Right/Left	Driver Door
2826	Mirror Fold/Return	Driver Door
2827	Courtesy Lamp	Driver Door
2828	Courtesy Light	Driver Door
2829	Door Lock	Driver Door
2830	Double Lock Unset	Driver Door
2831	Foot Light	Driver Door
2832	RH Mirror Up/Down	Driver Door
2833	RH Mirror Right/Left	Driver Door
2834	Mirror Fold	Driver Door
2835	LH Mirror Up/Down	Driver Door
2836	LH Mirror Right/Left	Driver Door
2837	Seat Memory Light	Driver Door
2838	4WD Warning Light	4WD
2839	4WD LOCK Light	4WD
2840	Slip Indicator Light	4WD
2841	4WD Auto Mode Light	4WD
2842	4WD Warning Light	4WD (CAN)
2843	4WD LOCK Light	4WD (CAN)
2844	Slip Indicator Light	4WD (CAN)

2845	4WD Auto Mode Light	4WD (CAN)
2846	LOCK light	4WD (CAN)
2847	AT Oil Pump (Lo)	Stop and Start
2848	AT Oil Pump (Hi)	Stop and Start
2849	Pinion Gear Plunger	Stop and Start
2850	Precondition (Control)	Stop and Start
2851	Starter Motor Drive Magnet Switch	Stop and Start
2852	Buzzer	Stop and Start
2853	Eco Run Permission (Battery)	Stop and Start
2854	Eco Run Permission (Engine ECU)	Stop and Start
2855	Eco Run Permission (Others)	Stop and Start
2856	Eco Run Permission (Outside Temp)	Stop and Start
2857	Starter	Stop and Start
2858	Start Cond (Hood Crtsy)	Stop and Start
2859	Precondition2 (Control)	Stop and Start
2860	Permit Cond (A/C)	Stop and Start
2861	Permit Cond (ABS)	Stop and Start
2862	Permit Cond (Battery)	Stop and Start
2863	Permit Cond (Engine)	Stop and Start
2864	Permit Cond (Amb Tmp)	Stop and Start
2865	AT Oil Pump (Lo)	Stop & Start
2866	AT Oil Pump (Hi)	Stop & Start
2867	Pinion Gear Plunger	Stop & Start
2868	Precondition (Control)	Stop & Start
2869	Starter Motor Drive Magnet Switch	Stop & Start
2870	engine hood	Stop & Start
2871	Buzzer	Stop & Start
2872	starter Force drive	Stop & Start
2873	starter power switching relay	Stop & Start
2874	Starter	Stop & Start
2875	Start Cond (Hood Crtsy)	Stop & Start
2876	Precondition2 (Control)	Stop & Start
2877	oil pump Lo drive	Stop & Start
2878	Control ABS: permit conditions	Stop & Start
2879	Control S & G: permit conditions	Stop & Start
2880	Outside air temperature: permit conditions	Stop & Start
2881	Permit Cond (A/C)	Stop & Start
2882	Permit Cond (ABS)	Stop & Start
2883	Permit Cond (Battery)	Stop & Start
2884	Permit Cond (Engine)	Stop & Start
2885	Permit Cond (Amb Tmp)	Stop & Start
2886	permit conditions: battery state	Stop & Start
2887	permit conditions: engine control	Stop & Start
2888	permit conditions: air conditioning	Stop & Start
2889	permit conditions: Li battery	Stop & Start
2890	AFS Alarm Display	AFS
2891	AFS OFF Indicator	AFS
2892	AHS	AFS
2893	CHECK HEADLIGHT Indicator	AFS
2894	Leveling motor up off	AFS

2895	Extra High Beam	AFS
2896	Advice Display	AFS
2897	Drive The Leveling Motor	AFS
2898	Drive The Leveling Motor UP	AFS
2899	Drive The Leveling Motor DOWN	AFS
2900	High Beam RH	AFS
2901	Variable Shade Beam RH	AFS
2902	Drive Swivel Motor RH RIGHT	AFS
2903	Drive Swivel Motor RH LEFT	AFS
2904	Drive Swivel Motor RH	AFS
2905	right swivel motor	AFS
2906	High Beam Indicator	AFS
2907	Automatic High Beam Operation	AFS
2908	Auto High Beam Warning Indicator	AFS
2909	Auto High Beam Control Indicator	AFS
2910	Variable Shade Beam LH/RH	AFS
2911	High Beam LH	AFS
2912	Variable Shade Beam LH	AFS
2913	Drive Swivel Motor LH RIGHT	AFS
2914	Drive Swivel Motor LH LEFT	AFS
2915	Drive Swivel Motor LH	AFS
2916	left swivel motor	AFS
2917	AFS Alarm Display	
2918	AFS OFF Indicator	
2919	AHS	
2920	Extra High Beam	
2921	Advice Display	
2922	Drive The Leveling Motor	
2923	Drive The Leveling Motor UP	
2924	Drive The Leveling Motor DOWN	
2925	High Beam RH	
2926	Variable Shade Beam RH	
2927	Drive Swivel Motor RH RIGHT	
2928	Drive Swivel Motor RH LEFT	
2929	Drive Swivel Motor RH	
2930	High Beam Indicator	
2931	Automatic High Beam Operation	
2932	Auto High Beam Warning Indicator	
2933	Auto High Beam Control Indicator	
2934	Variable Shade Beam LH/RH	
2935	High Beam LH	
2936	Variable Shade Beam LH	
2937	Drive Swivel Motor LH RIGHT	
2938	Drive Swivel Motor LH LEFT	
2939	Drive Swivel Motor LH	
2940	Security Horn	Gateway
2941	Security Horn2	Gateway
2942	Security Indicator	Gateway
2943	Dimmer Signal	Gateway
2944	Rheostat Cancel Operation	Gateway
2945	Interior Panel Relay	Gateway

2946	Passenger Buckle Light Output	Gateway
2947	Passenger Power Window Up/Down	Gateway
2948	Shock Detection Unlock	Gateway
2949	Open Door Warning Light	Gateway
2950	Head Light High	Gateway
2951	Headlight Relay	Gateway
2952	Head Light Cleaner	Gateway
2953	Illuminated Entry System	Gateway
2954	Map and Courtesy Light	Gateway
2955	IG OFF P/W Control Permission Output	Gateway
2956	Rear Buckle Light Output	Gateway
2957	Trunk and back-door open	Gateway
2958	Rear Room Light	Gateway
2959	Rear Washer Relay Operation	Gateway
2960	Rear Wiper Motor	Gateway
2961	Rear Defogger	Gateway
2962	Rear Fog Light Relay	Gateway
2963	Shift R Sign	Gateway
2964	Driver Buckle Light Output	Gateway
2965	Shoulder Belt Up/Down	Gateway
2966	Door Lock	Gateway
2967	License Light	Gateway
2968	Doom Relay Cut	Gateway
2969	Vehicle Horn	Gateway
2970	Front Fog Light Relay	Gateway
2971	Other ECU Power Cut	Gateway
2972	Relay of DRL	Gateway
2973	Intrusion Sensor Power	Gateway
2974	Step Light Operation	Gateway
2975	Hazard	Gateway
2976	Taillight Relay	Gateway
2977	Wireless Buzzer	Gateway
2978	Wireless Buzzer (continuous sound)	Gateway
2979	Turn Light RH Relay Operation	Gateway
2980	RR Power Window Up/Down	Gateway
2981	Wiper Motor Lo	Gateway
2982	Wiper Motor Hi	Gateway
2983	Wiper Motor	Gateway
2984	Wiper Angle Control	Gateway
2985	Key Remainder Buzzer	Gateway
2986	Center Console Light Operation	Gateway
2987	Turn Light LH Relay Operation	Gateway
2988	RL Power Window Up/Down	Gateway
2989	Security Horn	
2990	Security Indicator	
2991	Dimmer Signal	
2992	Rheostat Cancel Operation	
2993	Interior Panel Relay	
2994	Passenger Buckle Light Output	
2995	Passenger Power Window Up/Down	
2996	Shock Detection Unlock	

2997	Open Door Warning Light	
2998	Head Light High	
2999	Headlight Relay	
3000	Head Light Cleaner	
3001	Illuminated Entry System	
3002	IG OFF P/W Control Permission Output	
3003	Rear Buckle Light Output	
3004	Trunk and back-door open	
3005	Rear Room Light	
3006	Rear Washer Relay Operation	
3007	Rear Wiper Motor	
3008	Rear Defogger	
3009	Rear Fog Light Relay	
3010	Shift R Sign	
3011	Driver Buckle Light Output	
3012	Shoulder Belt Up/Down	
3013	Door Lock	
3014	License Light	
3015	Doom Relay Cut	
3016	Vehicle Horn	
3017	Front Fog Light Relay	
3018	Other ECU Power Cut	
3019	Relay of DRL	
3020	Intrusion Sensor Power	
3021	Step Light Operation	
3022	Hazard	
3023	Taillight Relay	
3024	Wireless Buzzer	
3025	Wireless Buzzer (continuous sound)	
3026	Turn Light RH Relay Operation	
3027	RR Power Window Up/Down	
3028	Wiper Motor Lo	
3029	Wiper Motor Hi	
3030	Wiper Motor	
3031	Wiper Angle Control	
3032	Key Remainder Buzzer	
3033	Center Console Light Operation	
3034	Turn Light LH Relay Operation	
3035	RL Power Window Up/Down	
3036	CHG relay operation	Battery
3037	PFAN	Battery
3038	Cooling fan No.1 operation	Battery
3039	Cooling fan No.1+2 operation	Battery
3040	TFT Check(White)	Night View
3041	TFT Check(Black)	Night View
3042	TFT Check(Green)	Night View
3043	Vehicle Speed Segment Display	Night View
3044	Navigation Segment Display	Night View
3045	IR Floodlight	Night View
3046	HUD Indicator	Night View
3047	Display Warning	Night View

3048	Night View System Operation	Night View
3049	Night View Indicator	Night View
3050	TFT inspection (white)	Night View Indicator
3051	TFT inspection (black)	Night View Indicator
3052	TFT inspection (green)	Night View Indicator
3053	IR Floodlight	Night View Indicator
3054	Simple Navi whole segment display	Night View Indicator
3055	HUD Indicator	Night View Indicator
3056	Camera reference image	Night View Indicator
3057	Reminder Frame	Night View Indicator
3058	Display Warning	Night View Indicator
3059	vehicle speed all-segment display	Night View Indicator
3060	Pedestrian Undetectable Ind	Night View Indicator
3061	Pedestrian Detection Frame	Night View Indicator
3062	Pedestrian Detectable Ind	Night View Indicator
3063	Night View System Operation	Night View Indicator
3064	Night View Indicator	Night View Indicator
3065	Indicat. 4LO	Meter
3066	4WD Warning Light	Meter
3067	Indicat. 4WD Lock	Meter
3068	Indicat. A/T P	Meter
3069	A/T Indicator Operation 3	Meter
3070	Indicat. Lamp ARS	Meter
3071	AFS OFF Indicator	Meter
3072	ASL Warning Indicator	Meter
3073	Indicat. ASL	Meter
3074	BSM Control Indicator	Meter
3075	Indicat. DABS	Meter
3076	Indicat. ECB	Meter
3077	ECB Indicator Light	Meter
3078	Indicat. Lamp ECT PWR	Meter
3079	EPB Auto OFF Indicator	Meter
3080	ETC indicator	Meter
3081	EV System Indicator	Meter
3082	EV Mode Indicator	Meter
3083	HV indicator	Meter
3084	HV Unit Hot Warning Indicator	Meter
3085	HV System Certification Mode Indicator	Meter
3086	ICS OFF Indicator	Meter
3087	Indicat. INTUITIVE P/A LCD	Meter
3088	Indicator 1	Meter
3089	Indicator 10	Meter
3090	Indicator 11	Meter
3091	Indicator 12	Meter
3092	Indicator 13	Meter
3093	Indicator 14	Meter
3094	Indicator 15	Meter
3095	Indicator 17	Meter
3096	KDSS Indicator	Meter
3097	LDA Warning Indicator	Meter
3098	LDA Warning Indicator (Right)	Meter

3099	LDA Warning Indicator (Left)	Meter
3100	LDA Control Indicator	Meter
3101	LDA Control Indicator (Right)	Meter
3102	LDA Control Indicator (Left)	Meter
3103	LED Head Lamp Warning	Meter
3104	Indicat. Navi CVT	Meter
3105	PPS Indicator	Meter
3106	Indicat. Ready (HV)	Meter
3107	Indicat. SIL (Up)	Meter
3108	Indicat. SIL (Down)	Meter
3109	Indicat. SIL	Meter
3110	SOC Warning Indicator	Meter
3111	SOC Gauge	Meter
3112	SPORT Indicator	Meter
3113	Indicat. TEMS Comfort	Meter
3114	VSC TRC Indicator	Meter
3115	Indicat. VSC OFF	Meter
3116	buzzer 1	Meter
3117	buzzer 2	Meter
3118	buzzer 3	Meter
3119	buzzer 4	Meter
3120	buzzer 5	Meter
3121	indicator 16	Meter
3122	indicator 18	Meter
3123	indicator 2	Meter
3124	indicator 3	Meter
3125	indicator 4	Meter
3126	indicator 5	Meter
3127	indicator 6	Meter
3128	indicator 7	Meter
3129	indicator 8	Meter
3130	indicator 9	Meter
3131	shift indicator 1	Meter
3132	shift indicator 2	Meter
3133	shift indicator 3	Meter
3134	Seat Belt Buzzer	Meter
3135	Maintenance Indicator	Meter
3136	Diesel Particulate Filter Warning	Meter
3137	Indicat. Lamp O/D OFF	Meter
3138	Vehicle Approach Warning OFF Indicator	Meter
3139	Vehicle Stop Indicator	Meter
3140	Indicat. Lamp VSC	Meter
3141	Indicat. Lamp VSC OFF	Meter
3142	Indicat. Lamp Doors All Open	Meter
3143	Indicat. Lamp Door	Meter
3144	Charge Warning Indicator	Meter
3145	Indicat. Lamp Charge	Meter
3146	Charging Indicator	Meter
3147	Slip Indicator Light	Meter
3148	Indicat. Lamp Headlamp Auto Level	Meter
3149	Reverse Buzzer	Meter

3150	Light Remained Buzzer	Meter
3151	CRAWL Warning Indicator	Meter
3152	Indicat. EPS	Meter
3153	Indicat. Lamp ECT SNOW	Meter
3154	Indicat. TEMS Sports	Meter
3155	Circuit Mode Indicator	Meter
3156	Volt Meter Operation	Meter
3157	Multi-Display	Meter
3158	Indicat. 2nd START	Meter
3159	Indicat. Lamp Hood Door Open	Meter
3160	Auxs Battery Charge Warning	Meter
3161	Indicat. Height High	Meter
3162	working	Meter
3163	Power Meter Operation	Meter
3164	Limited Power Indicator	Meter
3165	Fuel Consumption Meter Operation	Meter
3166	Indicat. Rr DIFF LOCK	Meter
3167	Indicat. Lamp Rr Light	Meter
3168	Indicat. Lamp Back Door Open	Meter
3169	Indicat. Lamp Rr FOG	Meter
3170	Rear seat belt	Meter
3171	Hybrid System Warning	Meter
3172	Indicat. Oil Pressure	Meter
3173	Indicat. Lamp Oil Level	Meter
3174	Indicat. Lamp Oil	Meter
3175	Laser Cruise at Constant-Speed	Meter
3176	Meter	Meter
3177	Indicat. Ride Mode	Meter
3178	Driver Side Door Open	Meter
3179	Driver Side Seat Belt	Meter
3180	Check Engine Warning	Meter
3181	Check Engine Indicator	Meter
3182	indicat ECD ON	Meter
3183	Indicat. Lamp ECONO	Meter
3184	Indicat. ECO MODE	Meter
3185	Warning Buzzer	Meter
3186	Ready Buzzer	Meter
3187	Air Conditioner Auto Indicator	Meter
3188	Air Suspension (N) Indicator	Meter
3189	Air Suspension (LO) Indicator	Meter
3190	Air Suspension (HI) Indicator	Meter
3191	Indicat. Ctr DIFF LOCK	Meter
3192	Radar Cruise Ready Indicator	Meter
3193	Indicat. Lamp L-Cruise Check	Meter
3194	Indicat. Lamp L-Cruise Ready	Meter
3195	Indicat. Laser Cruise Display	Meter
3196	Indicat. Radar Cruise	Meter
3197	Radar Cruise Indicator	Meter
3198	Indicat. Lamp Coolant Hot	Meter
3199	Indicat. Lamp Coolant Cool	Meter
3200	Coolant Temp LCD	Meter

3201	Indicat. ODO/TRIP Display	Meter
3202	Example 1	Meter
3203	Example 2	Meter
3204	Indicat. Compass Display	Meter
3205	Blind Spot Monitor Indicator	Meter
3206	HV System Indicator	Meter
3207	Indicat. CRAWL	Meter
3208	Indicat. Lamp Exhaust Temp	Meter
3209	Drift From The Lane	Meter
3210	Head Up Display Indicator	Meter
3211	Indicat. Lamp Airbag	Meter
3212	Indicat. Lamp Head	Meter
3213	Front Passenger Side Door Open	Meter
3214	Front Passenger Side SeatBelt	Meter
3215	Indicat. Precrash	Meter
3216	Indicat. Lamp Fr FOG	Meter
3217	Indicat. Lamp Fuel	Meter
3218	Fuel Meter Operation (CNG)	Meter
3219	Fuel Filter Indicator	Meter
3220	Fuel gauge	Meter
3221	Fuel Indicator (CNG)	Meter
3222	Daytime Running Lights OFF Indicator	Meter
3223	Brake Override Indicator	Meter
3224	Indicat. Lamp Brake	Meter
3225	Indicat. SET	Meter
3226	Indicat. Lamp Water Level	Meter
3227	Water temperature gauge	Meter
3228	Indicat. 4WD	Meter
3229	Speed Meter Operation	Meter
3230	Speed Buzzer	Meter
3231	Speedometer LCD	Meter
3232	Indicat. Tire Pressure Warning System	Meter
3233	Stop and Start OFF Indicator	Meter
3234	Stop and Start ON Indicator	Meter
3235	TOW HAUL Indicator	Meter
3236	Indicat. Lamp Tail	Meter
3237	Tail OFF Indicator	Meter
3238	Indicat. Tail Cancel	Meter
3239	Indicat. Lamp Washer	Meter
3240	Indicat. EV Mode	Meter
3241	Indicat. Hold	Meter
3242	Indicat. KEY	Meter
3243	Indicat. Headlamp Auto Leveling	Meter
3244	Indicat. ECONO	Meter
3245	Indicat. 4WD AUTO	Meter
3246	Indicat. Downhill Assist Control	Meter
3247	Indicat. Brake Hold	Meter
3248	Indicat. Auto LSD	Meter
3249	Shift-by-wire Warning	Meter
3250	Luggage Mode Indicator	Meter
3251	Indicat. Lamp Luggage Door Open	Meter

3252	Cruise Warning	Meter
3253	Indicat. Lamp Cruise	Meter
3254	CNG Mode Indicator	Meter
3255	Indicat. Night View	Meter
3256	Key Remained Buzzer	Meter
3257	Meter Display 1	Meter
3258	Meter Display 2	Meter
3259	Indicat. Lamp Engine	Meter
3260	Oil Pressure Meter Operation	Meter
3261	Indicat. Rear Door RH Open	Meter
3262	Rr Inner Wheel Control Warning	Meter
3263	Rr Inner Wheel Control Indicator	Meter
3264	Indicat. Lamp Turn R	Meter
3265	Indicat GLOW	Meter
3266	Indicat. Lamp Beam	Meter
3267	OFF Road Guidance Indicator	Meter
3268	Sports Shift Reject Buzzer	Meter
3269	Indicat. Sport (CVT Sport)	Meter
3270	Indicat. Clearance Sonar LCD	Meter
3271	Indicat. Timing Belt	Meter
3272	Smart System Warning	Meter
3273	Smart system indicator	Meter
3274	Smart Key	Meter
3275	Indicat. Main Battery (HV)	Meter
3276	Indicat. Main Battery (HV)	Meter
3277	Indicat. Lamp TRAC (TRC) OFF	Meter
3278	ACTIVE TRC Warning Indicator	Meter
3279	ACTIVE TRC Indicator	Meter
3280	Master warning	Meter
3281	Maintenance Required	Meter
3282	P Range Indicator	Meter
3283	Indicat. Park	Meter
3284	TachoMeter Operation	Meter
3285	Turn Signal (Right) Indicator	Meter
3286	Turn Signal (Left) Indicator	Meter
3287	A/T Oil Temperature Operation	Meter
3288	A/T Indicator Operation 1	Meter
3289	A/T Indicator Operation 2	Meter
3290	A/T Indicator Operation	Meter
3291	Indicat. A/T Shift LCD	Meter
3292	Automatic High Beam Indicator	Meter
3293	Indicat. Rear Door LH Open	Meter
3294	Indicat. Lamp Turn L	Meter
3295	Seatbelt Information Indicator	Meter
3296	Indicat. Lithium Charge	Meter
3297	Lithium Battery Hot Indicator	Meter
3298	Lithium Battery Check Indicator	Meter
3299	Indicat. Lamp ARS	Meter (SIL)
3300	AFS OFF Indicator	Meter (SIL)
3301	Indicat. DABS	Meter (SIL)
3302	Indicat. ECB	Meter (SIL)

3303	Indicat. Lamp ECT PWR	Meter (SIL)
3304	Indicat. Ready (HV)	Meter (SIL)
3305	Seat Belt Buzzer	Meter (SIL)
3306	Indicat. Lamp O/D OFF	Meter (SIL)
3307	Indicat. Lamp VSC	Meter (SIL)
3308	Indicat. Lamp VSC OFF	Meter (SIL)
3309	Indicat. Lamp Door	Meter (SIL)
3310	Indicat. Lamp Charge	Meter (SIL)
3311	Slip Indicator Light	Meter (SIL)
3312	Indicat. Lamp Headlamp Auto Level	Meter (SIL)
3313	Reverse Buzzer	Meter (SIL)
3314	Light Remained Buzzer	Meter (SIL)
3315	Indicat. EPS	Meter (SIL)
3316	Indicat. Lamp ECT SNOW	Meter (SIL)
3317	Indicat. TEMS Sports	Meter (SIL)
3318	Circuit Mode Indicator	Meter (SIL)
3319	Volt Meter Operation	Meter (SIL)
3320	Multi-Display	Meter (SIL)
3321	Indicat. Height High	Meter (SIL)
3322	Power Meter Operation	Meter (SIL)
3323	Fuel Consumption Meter Operation	Meter (SIL)
3324	Indicat. Lamp Rr Light	Meter (SIL)
3325	Indicat. Lamp Rr FOG	Meter (SIL)
3326	Indicat. Lamp Oil Level	Meter (SIL)
3327	Indicat. Lamp Oil	Meter (SIL)
3328	Laser Cruise at Constant-Speed	Meter (SIL)
3329	Driver Side Seat Belt	Meter (SIL)
3330	indicat ECD ON	Meter (SIL)
3331	Indicat. Lamp ECONO	Meter (SIL)
3332	Warning Buzzer	Meter (SIL)
3333	Ready Buzzer	Meter (SIL)
3334	Indicat. Lamp L-Cruise Check	Meter (SIL)
3335	Indicat. Lamp L-Cruise Ready	Meter (SIL)
3336	Indicat. Laser Cruise Display	Meter (SIL)
3337	Coolant Temp LCD	Meter (SIL)
3338	Indicat. ODO/TRIP Display	Meter (SIL)
3339	Indicat. Compass Display	Meter (SIL)
3340	Indicat. Lamp Exhaust Temp	Meter (SIL)
3341	Drift From The Lane	Meter (SIL)
3342	Indicat. Lamp Airbag	Meter (SIL)
3343	Indicat. Lamp Head	Meter (SIL)
3344	Front Passenger Side SeatBelt	Meter (SIL)
3345	Indicat. Precrash	Meter (SIL)
3346	Indicat. Lamp Fr FOG	Meter (SIL)
3347	Indicat. Lamp Fuel	Meter (SIL)
3348	Fuel gauge	Meter (SIL)
3349	Daytime Running Lights OFF Indicator	Meter (SIL)
3350	Indicat. Lamp Brake	Meter (SIL)
3351	Water temperature gauge	Meter (SIL)
3352	Indicat. 4WD	Meter (SIL)
3353	Speed Meter Operation	Meter (SIL)

3354	Speed Buzzer	Meter (SIL)
3355	Speedometer LCD	Meter (SIL)
3356	Indicat. Tire Pressure Warning System	Meter (SIL)
3357	Indicat. Lamp Tail	Meter (SIL)
3358	Indicat. Lamp Washer	Meter (SIL)
3359	Indicat. Lamp Cruise	Meter (SIL)
3360	Indicat. Night View	Meter (SIL)
3361	Key Remained Buzzer	Meter (SIL)
3362	Indicat. Lamp Engine	Meter (SIL)
3363	Oil Pressure Meter Operation	Meter (SIL)
3364	Indicat. Lamp Turn R	Meter (SIL)
3365	Indicat GLOW	Meter (SIL)
3366	Indicat. Lamp Beam	Meter (SIL)
3367	Sports Shift Reject Buzzer	Meter (SIL)
3368	Indicat. Clearance Sonar LCD	Meter (SIL)
3369	Smart Key	Meter (SIL)
3370	Indicat. Main Battery (HV)	Meter (SIL)
3371	Indicat. Lamp TRAC (TRC) OFF	Meter (SIL)
3372	Master warning	Meter (SIL)
3373	Maintenance Required	Meter (SIL)
3374	TachoMeter Operation	Meter (SIL)
3375	A/T Oil Temperature Operation	Meter (SIL)
3376	A/T Indicator Operation 1	Meter (SIL)
3377	A/T Indicator Operation 2	Meter (SIL)
3378	A/T Indicator Operation	Meter (SIL)
3379	Indicat. A/T Shift LCD	Meter (SIL)
3380	Indicat. Lamp Turn L	Meter (SIL)
3381	#1	Engine
3382	#2	Engine
3383	#3	Engine
3384	#4	Engine
3385	#5	Engine
3386	#6	Engine
3387	#7	Engine
3388	#8	Engine
3389	Control the ACM Inhibit	Engine
3390	Activate VSV for Tank Bypass and Canister Control	Engine
3391	Activate the VSV for Vent Valve and Vacuum Pump	Engine
3392	Activate the VVT System (Bank1)	Engine
3393	Control the C/D	Engine
3394	Check Type Support B	Engine
3395	Control the Cylinder Fuel Cut	Engine
3396	D-4S (A/F Control)	Engine
3397	D-4S (Fuel Cut)	Engine
3398	D-4S (Injection Volume)	Engine
3399	HICM System Check	Engine
3400	ISC Duty	Engine
3401	Injection Volume	Engine
3402	Manual item 1 and Check Type Support H	Engine

3403	Manual item 10 and Check Type Support Y	Engine
3404	Manual item 2 and Check Type Support G	Engine
3405	Manual item 3 and Check Type Support F	Engine
3406	Manual item 4 and Check Type Support E	Engine
3407	Manual item 5 and Check Type Support D	Engine
3408	Manual item 6 and Check Type Support C	Engine
3409	Manual item 7 and Check Type Support J	Engine
3410	Manual item 8 and Check Type Support I	Engine
3411	Manual item 9 and Check Type Support X	Engine
3412	Control the O/D Cut	Engine
3413	RDFN 1 stage	Engine
3414	RDFN 2 stage	Engine
3415	Control the SCV Duty Ratio	Engine
3416	TE1 (TC)	Engine
3417	VSV 1	Engine
3418	VSV 2	Engine
3419	Brake Ejector VSV Inspection	Engine
3420	VSV all	Engine
3421	Control the VVT-iE Linear (Bank1)	Engine
3422	Control the VVT-iE Linear (Bank2)	Engine
3423	Control the VVT Exhaust Linear (Bank1)	Engine
3424	Control the VVT Exhaust Linear (Bank2)	Engine
3425	Control the VVT System (Bank1)	Engine
3426	Control the VVT System (Bank2)	Engine
3427	Control the VVT Linear (Bank1)	Engine
3428	Control the VVT Linear (Bank2)	Engine
3429	Test the Fuel Leak	Engine
3430	Test the Turbo Charger Step Motor	Engine
3431	Test the Turbo Charger Step Motor #2	Engine
3432	Diesel Throttle Target Angle	Engine
3433	Diesel Throttle Target Angle #2	Engine
3434	Control the IAC Duty Ratio	Engine
3435	Control the ISC Step Position	Engine
3436	ISC Step	Engine
3437	Fuel Cut Bank 2 for Idle	Engine
3438	Control the Idle Fuel Cut Prohibit	Engine
3439	Control the Shift Position	Engine
3440	Control the Electric Cooling Fan	Engine
3441	Control the EGR Step Position	Engine
3442	Control the EGR System	Engine
3443	Control the Line Pressure Up	Engine
3444	Control the Supercharger	Engine
3445	Control the Auto Oil Supply System	Engine
3446	Activate the VSV for Evap (Purge)	Engine
3447	Activate the EGR Valve Close	Engine
3448	Activate the VN Turbo Open	Engine
3449	Activate the DPF Rejuvenate (PM)	Engine
3450	Activate the DPF Rejuvenate (S)	Engine
3451	Activate the Solenoid (DS1)	Engine
3452	Activate the Solenoid (DS2)	Engine

3453	Activate the Solenoid (DSL)	Engine
3454	Activate the Solenoid (DSU)	Engine
3455	Activate the Solenoid (S1)	Engine
3456	Activate the Solenoid (S2)	Engine
3457	Activate the Solenoid (S3)	Engine
3458	Activate the Solenoid (S4)	Engine
3459	Activate the Solenoid (SB)	Engine
3460	Activate the Solenoid (SL)	Engine
3461	Activate the Solenoid (SL1)	Engine
3462	Activate the Solenoid (SL2)	Engine
3463	Activate the Solenoid (SL3)	Engine
3464	Activate the Solenoid (SL4)	Engine
3465	Activate the Solenoid (SL5)	Engine
3466	Activate the Solenoid (SLC)	Engine
3467	Activate the Solenoid (SLN)	Engine
3468	Activate the Solenoid (SLS)	Engine
3469	Activate the Solenoid (SLT)	Engine
3470	Activate the Solenoid (SLU)	Engine
3471	Activate the Solenoid (SR)	Engine
3472	Activate the Solenoid (ST)	Engine
3473	Activate the Solenoid(SC)	Engine
3474	Activate the Solenoid(SLP)	Engine
3475	Activate the Electric Water Pump	Engine
3476	Activate the Slip Control System	Engine
3477	Activate the VSV for EGR Cooler Bypass	Engine
3478	Activate the ACC Cut Relay	Engine
3479	Activate the LPG Solenoid Valve	Engine
3480	Activate the Return Solenoid Valve	Engine
3481	Activate the Emergency Solenoid Valve	Engine
3482	Activate the VSV2 for Intake Control	Engine
3483	Activate the Intank Fuel Pump Relay	Engine
3484	Activate the VSV for Variable Intake Control	Engine
3485	Activate the Air Pump Heater	Engine
3486	Activate the Air Switching Valve	Engine
3487	Activate the VALVEMATIC (ENG OFF)	Engine
3488	Activate the VALVEMATIC (ENG ON)	Engine
3489	Activate HCAC VSV	Engine
3490	Activate the VSV for Exhaust Switching Valve	Engine
3491	Activate the VSV for Exhaust Brake	Engine
3492	Activate the Starter Cut Relay	Engine
3493	Activate the Starter Relay	Engine
3494	Activate the Air Pump	Engine
3495	Activate the Fuel Pump2 Speed Control	Engine
3496	Activate the Fuel Pump Speed Control	Engine
3497	Activate the Fuel Return Pipe Valve	Engine
3498	Activate the Fuel Route Switching Valve Relay	Engine
3499	Activate the Fuel Filler Opener	Engine
3500	Activate the Fuel Pressure Switching Valve	Engine

3501	Activate the Fuel Vapor-Containment Valve	Engine
3502	Activate the Water Pump	Engine
3503	Activate the Water Flow Valve 3	Engine
3504	Activate the Water Flow Valve 4	Engine
3505	Activate the Water Flow Valve 5	Engine
3506	Activate the Water Flow Valve 1	Engine
3507	Activate the Water Flow Valve 2	Engine
3508	Activate the Vacuum Pump	Engine
3509	Activate the VSV for Secondary Air Control	Engine
3510	Activate the VSV for EGR Cut	Engine
3511	Activate the VSV for Fuel Pressure Up Control	Engine
3512	Activate the VSV for AICS	Engine
3513	Activate the VSV for A/C Idle Up Control	Engine
3514	Activate the VSV for HCAC System	Engine
3515	Activate the VSV for Air Bleed Control	Engine
3516	Activate the VSV for Exhaust Gas Control	Engine
3517	Activate the VSV for Intake Control	Engine
3518	Activate the VSV for Purge Control	Engine
3519	Activate the VSV for Purge Cut	Engine
3520	Activate the VSV for Air Bypass Valve	Engine
3521	Activate the VSV for Exhaust Shutter	Engine
3522	Activate the VSV for Exhaust Bypass Control	Engine
3523	Activate the VSV for Canister Control	Engine
3524	Activate the VSV for Vent Valve	Engine
3525	Activate the VSV for Turbo Pressure	Engine
3526	Activate the VSV for Turbo Boost Control	Engine
3527	Activate the VSV for Tank Bypass	Engine
3528	Activate the VSV for Evap Control	Engine
3529	Activate the VSV for Swirl Control Valve	Engine
3530	Activate the VSV for Vapor Pressure	Engine
3531	Activate the Brake Ejector VSV	Engine
3532	HCAC VSV Check	Engine
3533	Check the Imbalance Cylinder	Engine
3534	Check the Cylinder Compression	Engine
3535	Prohibit the Catalyst OT Misfire prevent F/C	Engine
3536	Control the Purge Dilution Valve Duty Bank1	Engine
3537	Control the Purge Dilution Valve Duty Bank2	Engine
3538	Control the VVTL System (Bank1)	Engine
3539	Control the VVTL System (Bank2)	Engine
3540	Control the A/C Cut Signal	Engine
3541	A/F Control	Engine

3542	Control the SLS Pressure	Engine
3543	Control the ISC Value	Engine
3544	Control the Regulator Shut Valve	Engine
3545	Control the EGR Step Position #2	Engine
3546	Control the Voltage of Alternator	Engine
3547	Control the A/C Magnet Clutch	Engine
3548	Control the Injection Volume for A/F Sensor(CNG)	Engine
3549	Control the Target Engine Speed	Engine
3550	Control the Injection Volume(CNG)	Engine
3551	Control the All Cylinders Fuel Cut	Engine
3552	Control the All Cylinders Fuel Cut(CNG)	Engine
3553	Control the Select Cylinder Fuel Cut	Engine
3554	Control the Select Cylinder Fuel Cut(CNG)	Engine
3555	Connect the TC and TE1	Engine
3556	Control the Target Fuel Pressure	Engine
3557	Activate the VALVEMATIC after Warm Up	Engine
3558	Activate the VALVEMATIC before Warm Up	Engine
3559	Control the Injection Volume for A/F Sensor	Engine
3560	Control the Injection Way	Engine
3561	Control the Injection Volume	Engine
3562	Control the Injection Timing #1	Engine
3563	Control the Injection Timing #2	Engine
3564	Control the Injection Timing #3	Engine
3565	Control the Injection Timing #4	Engine
3566	Control the Injection Timing #5	Engine
3567	Control the Injection Timing #6	Engine
3568	Control the Injection Timing #7	Engine
3569	Control the Injection Timing #8	Engine
3570	Control the Cooling Fan	Engine
3571	Control the Stratified Charge Combustion	Engine
3572	Control the Stoichiometric Ratio Combustion	Engine
3573	Fuel Pump Relay	Engine
3574	Control the Fuel Pump Duty	Engine
3575	Control the Fuel Pump / Speed	Engine
3576	fuel pressure relief valve open	Engine
3577	Fuel Pressure Relief Valve Close	Engine
3578	EVAP VSV	Engine
3579	Control the Delivery Shut Valve	Engine
3580	Activate the Lock Up	Engine
3581	Control the Lock Up	Engine
3582	Control the ETCS Open/Close Fast Speed	Engine
3583	Control the ETCS Open/Close Slow Speed	Engine
3584	Sub Fuel Tank VSV	Engine
3585	Check Type Support B	Engine(SIL2)
3586	Control the Cylinder Fuel Cut	Engine(SIL2)
3587	D-4S (Fuel Cut)	Engine(SIL2)

3588	D-4S (Injection Volume)	Engine(SIL2)
3589	HICM System Check	Engine(SIL2)
3590	Injection Timing Select Cylinder	Engine(SIL2)
3591	Injection Timing Value	Engine(SIL2)
3592	Injection Volume	Engine(SIL2)
3593	Manual item 1 and Check Type Support H	Engine(SIL2)
3594	Manual item 10 and Check Type Support Y	Engine(SIL2)
3595	Manual item 2 and Check Type Support G	Engine(SIL2)
3596	Manual item 3 and Check Type Support F	Engine(SIL2)
3597	Manual item 4 and Check Type Support E	Engine(SIL2)
3598	Manual item 5 and Check Type Support D	Engine(SIL2)
3599	Manual item 6 and Check Type Support C	Engine(SIL2)
3600	Manual item 7 and Check Type Support J	Engine(SIL2)
3601	Manual item 8 and Check Type Support I	Engine(SIL2)
3602	Manual item 9 and Check Type Support X	Engine(SIL2)
3603	Fuel ho Nfu air vent	Engine(SIL2)
3604	0 / D cut SOL	Engine(SIL2)
3605	Pilot Injection Volume Select Cylinder	Engine(SIL2)
3606	Pilot Injection Volume Value	Engine(SIL2)
3607	Pilot Injection Volume	Engine(SIL2)
3608	Control the SCV Duty Ratio	Engine(SIL2)
3609	Brake Ejector VSV Inspection	Engine(SIL2)
3610	VSV intake passage control	Engine(SIL2)
3611	VSV variable intake	Engine(SIL2)
3612	VSV three-way	Engine(SIL2)
3613	VSV boost pressure control	Engine(SIL2)
3614	Control the VVT-iE Linear (Bank1)	Engine(SIL2)
3615	Control the VVT-iE Linear (Bank2)	Engine(SIL2)
3616	VVTL-I NO.1 OCV	Engine(SIL2)
3617	VVTL-I NO.2 OCV	Engine(SIL2)
3618	Control the VVT Exhaust Linear (Bank1)	Engine(SIL2)
3619	Control the VVT Exhaust Linear (Bank2)	Engine(SIL2)
3620	Control the VVT System (Bank1)	Engine(SIL2)
3621	Control the VVT System (Bank2)	Engine(SIL2)
3622	Control the VVT Linear (Bank1)	Engine(SIL2)
3623	Control the VVT Linear (Bank2)	Engine(SIL2)
3624	Test the Fuel Leak	Engine(SIL2)
3625	Test the Turbo Charger Step Motor	Engine(SIL2)
3626	Test the Turbo Charger Step Motor #2	Engine(SIL2)
3627	Diesel Throttle Target Angle	Engine(SIL2)
3628	Diesel Throttle Target Angle #2	Engine(SIL2)
3629	Sucha charger control	Engine(SIL2)
3630	Control the IAC Duty Ratio	Engine(SIL2)
3631	Control the ISC Step Position	Engine(SIL2)
3632	Fuel Cut Bank 2 for Idle	Engine(SIL2)
3633	Control the Idle Fuel Cut Prohibit	Engine(SIL2)
3634	idle-up	Engine(SIL2)
3635	Control the Shift Position	Engine(SIL2)
3636	Control the Electric Cooling Fan	Engine(SIL2)
3637	Control the EGR Step Position	Engine(SIL2)

3638	Control the EGR System	Engine(SIL2)
3639	Stratified combustion control force	Engine(SIL2)
3640	Shut-off valve delivery	Engine(SIL2)
3641	Shut-off valve regulator	Engine(SIL2)
3642	Control the Line Pressure Up	Engine(SIL2)
3643	slip control SOL	Engine(SIL2)
3644	Activate the EGR Valve Close	Engine(SIL2)
3645	Activate the VN Turbo Open	Engine(SIL2)
3646	Activate the DPF Rejuvenate (PM)	Engine(SIL2)
3647	Activate the DPF Rejuvenate (S)	Engine(SIL2)
3648	Activate the Solenoid (DS1)	Engine(SIL2)
3649	Activate the Solenoid (DS2)	Engine(SIL2)
3650	Activate the Solenoid (DSL)	Engine(SIL2)
3651	Activate the Solenoid (DSU)	Engine(SIL2)
3652	Activate the Solenoid (S1)	Engine(SIL2)
3653	Activate the Solenoid (S2)	Engine(SIL2)
3654	Activate the Solenoid (S3)	Engine(SIL2)
3655	Activate the Solenoid (S4)	Engine(SIL2)
3656	Activate the Solenoid (SB)	Engine(SIL2)
3657	Activate the Solenoid (SL)	Engine(SIL2)
3658	Activate the Solenoid (SL1)	Engine(SIL2)
3659	Activate the Solenoid (SL2)	Engine(SIL2)
3660	Activate the Solenoid (SL3)	Engine(SIL2)
3661	Activate the Solenoid (SL4)	Engine(SIL2)
3662	Activate the Solenoid (SL5)	Engine(SIL2)
3663	Activate the Solenoid (SLC)	Engine(SIL2)
3664	Activate the Solenoid (SLN)	Engine(SIL2)
3665	Activate the Solenoid (SLS)	Engine(SIL2)
3666	Activate the Solenoid (SLT)	Engine(SIL2)
3667	Activate the Solenoid (SLU)	Engine(SIL2)
3668	Activate the Solenoid (SR)	Engine(SIL2)
3669	Activate the Solenoid (ST)	Engine(SIL2)
3670	Activate the Solenoid(SC)	Engine(SIL2)
3671	Activate the Solenoid(SLP)	Engine(SIL2)
3672	Activate the Electric Water Pump	Engine(SIL2)
3673	Activate the VSV for EGR Cooler Bypass	Engine(SIL2)
3674	Activate the ACC Cut Relay	Engine(SIL2)
3675	Activate the LPG Solenoid Valve	Engine(SIL2)
3676	Activate the Return Solenoid Valve	Engine(SIL2)
3677	Activate the Emergency Solenoid Valve	Engine(SIL2)
3678	Activate the Intank Fuel Pump Relay	Engine(SIL2)
3679	Activate the Air Pump Heater	Engine(SIL2)
3680	Activate the Air Switching Valve	Engine(SIL2)
3681	Active Control Mount	Engine(SIL2)
3682	Activate the VALVEMATIC (ENG OFF)	Engine(SIL2)
3683	Activate the VALVEMATIC (ENG ON)	Engine(SIL2)
3684	Activate the VSV for Exhaust Switching Valve	Engine(SIL2)
3685	Activate the VSV for Exhaust Brake	Engine(SIL2)
3686	Activate the Starter Relay	Engine(SIL2)
3687	Activate the Air Pump	Engine(SIL2)

3688	Activate the Fuel Pump2 Speed Control	Engine(SIL2)
3689	Activate the Fuel Pump Speed Control	Engine(SIL2)
3690	Activate the Fuel Return Pipe Valve	Engine(SIL2)
3691	Activate the Fuel Route Switching Valve Relay	Engine(SIL2)
3692	Activate the Fuel Filler Opener	Engine(SIL2)
3693	Activate the Fuel Vapor-Containment Valve	Engine(SIL2)
3694	Activate the VSV for Secondary Air Control	Engine(SIL2)
3695	Activate the VSV for EGR Cut	Engine(SIL2)
3696	Activate the VSV for Intake Control	Engine(SIL2)
3697	Activate the VSV for Exhaust Shutter	Engine(SIL2)
3698	Activate the VSV for Evap Control	Engine(SIL2)
3699	Activate the VSV for Swirl Control Valve	Engine(SIL2)
3700	Activate the Brake Ejector VSV	Engine(SIL2)
3701	Check the Cylinder Compression	Engine(SIL2)
3702	SOL engagement pressure control	Engine(SIL2)
3703	Intake valve control switch	Engine(SIL2)
3704	Intake Control VSV2	Engine(SIL2)
3705	Prohibit the Catalyst OT Misfire prevent F/C	Engine(SIL2)
3706	Purge Cut VSV	Engine(SIL2)
3707	Control the Purge Dilution Valve Duty Bank1	Engine(SIL2)
3708	Control the Purge Dilution Valve Duty Bank2	Engine(SIL2)
3709	A/C Cut Signal	Engine(SIL2)
3710	Control the SLS Pressure	Engine(SIL2)
3711	Control the Regulator Shut Valve	Engine(SIL2)
3712	Control the Voltage of Alternator	Engine(SIL2)
3713	Control the A/C Magnet Clutch	Engine(SIL2)
3714	Control the Injection Volume(CNG)	Engine(SIL2)
3715	Control the All Cylinders Fuel Cut	Engine(SIL2)
3716	Control the All Cylinders Fuel Cut(CNG)	Engine(SIL2)
3717	Control the Select Cylinder Fuel Cut	Engine(SIL2)
3718	Control the Select Cylinder Fuel Cut(CNG)	Engine(SIL2)
3719	Connect the TC and TE1	Engine(SIL2)
3720	Control the Target Fuel Pressure	Engine(SIL2)
3721	Activate the VALVEMATIC after Warm Up	Engine(SIL2)
3722	Activate the VALVEMATIC before Warm Up	Engine(SIL2)
3723	Release Bleed	Engine(SIL2)
3724	Exhaust valve control switch	Engine(SIL2)
3725	exhaust bypass valve control	Engine(SIL2)
3726	Control the Injection Way	Engine(SIL2)
3727	Control the Injection Volume	Engine(SIL2)
3728	Injection Timing	Engine(SIL2)
3729	Control the Injection Timing #1	Engine(SIL2)
3730	Control the Injection Timing #2	Engine(SIL2)

3731	Control the Injection Timing #3	Engine(SIL2)
3732	Control the Injection Timing #4	Engine(SIL2)
3733	Control the Injection Timing #5	Engine(SIL2)
3734	Control the Injection Timing #6	Engine(SIL2)
3735	Control the Injection Timing #7	Engine(SIL2)
3736	Control the Injection Timing #8	Engine(SIL2)
3737	SOL forward-reverse switching	Engine(SIL2)
3738	Force stoichiometric control	Engine(SIL2)
3739	Control the Fuel Pump Duty	Engine(SIL2)
3740	Control the Fuel Pump / Speed	Engine(SIL2)
3741	fuel pressure relief valve open	Engine(SIL2)
3742	Fuel Pressure Relief Valve Close	Engine(SIL2)
3743	Fuel Pressure Up VSV	Engine(SIL2)
3744	Activate the Lock Up	Engine(SIL2)
3745	Control the Lock Up	Engine(SIL2)
3746	lock-up control SOL	Engine(SIL2)
3747	Canister close valve	Engine(SIL2)
3748	tank bypass	Engine(SIL2)
3749	Control the ETCS Open/Close Fast Speed	Engine(SIL2)
3750	Control the ETCS Open/Close Slow Speed	Engine(SIL2)
3751	Automatic lubrication oil	Engine(SIL2)
3752	#1	Engine and ECT
3753	#2	Engine and ECT
3754	#3	Engine and ECT
3755	#4	Engine and ECT
3756	#5	Engine and ECT
3757	#6	Engine and ECT
3758	#7	Engine and ECT
3759	#8	Engine and ECT
3760	A/C Magnetic Clutch Relay	Engine and ECT
3761	AICV VSV	Engine and ECT
3762	Control the ACM Inhibit	Engine and ECT
3763	Activate VSV for Tank Bypass and Canister Control	Engine and ECT
3764	Activate the VSV for Vent Valve and Vacuum Pump	Engine and ECT
3765	Activate the VVT System (Bank1)	Engine and ECT
3766	Actuator Test of Blow by Heater	Engine and ECT
3767	Actuator Test of FPC (Linear FPC) (EU6)	Engine and ECT
3768	Actuator Test of Swirl Flap (EU6)	Engine and ECT
3769	Control the C/D	Engine and ECT
3770	C/D Control Solenoid	Engine and ECT
3771	CVT shift position	Engine and ECT
3772	Check Type Support B	Engine and ECT
3773	Control the Cylinder Fuel Cut	Engine and ECT
3774	D-4S (A/F Control)	Engine and ECT
3775	D-4S (Fuel Cut)	Engine and ECT
3776	D-4S (Injection Volume)	Engine and ECT
3777	E-ABV Step	Engine and ECT
3778	EGR Step	Engine and ECT
3779	EGR number of steps	Engine and ECT

3780	Actuator Test of EGR-Valve	Engine and ECT
3781	Actuator Test of EGR Cooler Bypass Valve	Engine and ECT
3782	EGR System	Engine and ECT
3783	FC / FPC control	Engine and ECT
3784	Actuator Test of FPC(EU5)	Engine and ECT
3785	HC Adsorber and Catalyst VSV	Engine and ECT
3786	HICM System Check	Engine and ECT
3787	ISC number of steps	Engine and ECT
3788	Injection Timing Select Cylinder	Engine and ECT
3789	Injection Timing Value	Engine and ECT
3790	Injection Volume	Engine and ECT
3791	Manual item 1 and Check Type Support H	Engine and ECT
3792	Manual item 10 and Check Type Support Y	Engine and ECT
3793	Manual item 2 and Check Type Support G	Engine and ECT
3794	Manual item 3 and Check Type Support F	Engine and ECT
3795	Manual item 4 and Check Type Support E	Engine and ECT
3796	Manual item 5 and Check Type Support D	Engine and ECT
3797	Manual item 6 and Check Type Support C	Engine and ECT
3798	Manual item 7 and Check Type Support J	Engine and ECT
3799	Manual item 8 and Check Type Support I	Engine and ECT
3800	Manual item 9 and Check Type Support X	Engine and ECT
3801	Fuel ho Nfu air vent	Engine and ECT
3802	0 / D cut SOL	Engine and ECT
3803	Control the O/D Cut	Engine and ECT
3804	Forced regeneration PM	Engine and ECT
3805	Pilot Injection Volume Select Cylinder	Engine and ECT
3806	Pilot Injection Volume Value	Engine and ECT
3807	Pilot Injection Volume	Engine and ECT
3808	SB Solenoid	Engine and ECT
3809	Control the SCV Duty Ratio	Engine and ECT
3810	SCV VSV	Engine and ECT
3811	SLS Solenoid	Engine and ECT
3812	TE1 (TC)	Engine and ECT
3813	Tank Pressure Bypass VSV and Canister Pressure Control VSV	Engine and ECT
3814	VN turbo motor inspection	Engine and ECT
3815	Brake Ejector VSV Inspection	Engine and ECT
3816	VSV intake control	Engine and ECT
3817	VSV intake passage control	Engine and ECT
3818	VSV variable intake	Engine and ECT
3819	VSV three-way	Engine and ECT
3820	VSV boost pressure control	Engine and ECT
3821	Control the VVT-iE Linear (Bank1)	Engine and ECT
3822	Control the VVT-iE Linear (Bank2)	Engine and ECT
3823	VVTL-I NO.1 OCV	Engine and ECT
3824	VVTL-I NO.2 OCV	Engine and ECT
3825	VVTL Control (Bank 1)	Engine and ECT
3826	VVTL Control (Bank 2)	Engine and ECT
3827	Control VVT	Engine and ECT
3828	VVT Control (Bank 1)	Engine and ECT

3829	VVT Control (Bank 2)	Engine and ECT
3830	Control the VVT Exhaust Linear (Bank1)	Engine and ECT
3831	Control the VVT Exhaust Linear (Bank2)	Engine and ECT
3832	Control the VVT System (Bank1)	Engine and ECT
3833	Control the VVT System (Bank2)	Engine and ECT
3834	Control the VVT Linear (Bank1)	Engine and ECT
3835	Control the VVT Linear (Bank2)	Engine and ECT
3836	Vent Value and Vacuum Pump	Engine and ECT
3837	Test the Fuel Leak	Engine and ECT
3838	Test the Turbo Charger Step Motor	Engine and ECT
3839	Test the Turbo Charger Step Motor #2	Engine and ECT
3840	diesel throttle	Engine and ECT
3841	Diesel Throttle Target Angle	Engine and ECT
3842	Diesel Throttle Target Angle #2	Engine and ECT
3843	O/D Cut Solenoid	Engine and ECT
3844	Sucha charger control	Engine and ECT
3845	atmospheric pressure introduction valve	Engine and ECT
3846	Control the IAC Duty Ratio	Engine and ECT
3847	IAC Step	Engine and ECT
3848	IACV Motor	Engine and ECT
3849	IAC Duty Ratio	Engine and ECT
3850	IAC Duty	Engine and ECT
3851	Control the ISC Step Position	Engine and ECT
3852	Test of Idle Control	Engine and ECT
3853	Fuel Cut Bank 2 for Idle	Engine and ECT
3854	Control the Idle Fuel Cut Prohibit	Engine and ECT
3855	idle-up	Engine and ECT
3856	Idle Up VSV	Engine and ECT
3857	Shift position ECT	Engine and ECT
3858	Control the Shift Position	Engine and ECT
3859	Fan Motor	Engine and ECT
3860	Control the Electric Cooling Fan	Engine and ECT
3861	ON terminal TC	Engine and ECT
3862	Slip Control Solenoid	Engine and ECT
3863	Air Bleed	Engine and ECT
3864	Exhaust Gas Control VSV	Engine and ECT
3865	Exhaust Bypass Valve	Engine and ECT
3866	Control the EGR Step Position	Engine and ECT
3867	EGR cut VSV	Engine and ECT
3868	Control the EGR System	Engine and ECT
3869	Stratified combustion control force	Engine and ECT
3870	Actuator Test of Fan Low Speed	Engine and ECT
3871	Actuator Test of Fan High Speed	Engine and ECT
3872	Secondary Air VSV	Engine and ECT
3873	The high-pressure fuel system inspection	Engine and ECT
3874	Shut-off valve delivery	Engine and ECT
3875	Shut-off valve regulator	Engine and ECT
3876	Control the Line Pressure Up	Engine and ECT
3877	Line Pressure Solenoid	Engine and ECT

3878	Line Pressure Up Solenoid	Engine and ECT
3879	slip control SOL	Engine and ECT
3880	Shift	Engine and ECT
3881	Vent Valve	Engine and ECT
3882	Control the Supercharger	Engine and ECT
3883	Supercharger Control Relay	Engine and ECT
3884	Control the Auto Oil Supply System	Engine and ECT
3885	Activate the VSV for Evap (Purge)	Engine and ECT
3886	Activate the EGR Valve Close	Engine and ECT
3887	Activate the VN Turbo Open	Engine and ECT
3888	Activate the DPF Rejuvenate (PM)	Engine and ECT
3889	Activate the DPF Rejuvenate (S)	Engine and ECT
3890	Activate the Solenoid (DS1)	Engine and ECT
3891	Activate the Solenoid (DS2)	Engine and ECT
3892	Activate the Solenoid (DSL)	Engine and ECT
3893	Activate the Solenoid (DSU)	Engine and ECT
3894	Activate the Solenoid (S1)	Engine and ECT
3895	Activate the Solenoid (S2)	Engine and ECT
3896	Activate the Solenoid (S3)	Engine and ECT
3897	Activate the Solenoid (S4)	Engine and ECT
3898	Activate the Solenoid (SB)	Engine and ECT
3899	Activate the Solenoid (SL)	Engine and ECT
3900	Activate the Solenoid (SL1)	Engine and ECT
3901	Activate the Solenoid (SL2)	Engine and ECT
3902	Activate the Solenoid (SL3)	Engine and ECT
3903	Activate the Solenoid (SL4)	Engine and ECT
3904	Activate the Solenoid (SL5)	Engine and ECT
3905	Activate the Solenoid (SLC)	Engine and ECT
3906	Activate the Solenoid (SLN)	Engine and ECT
3907	Activate the Solenoid (SLS)	Engine and ECT
3908	Activate the Solenoid (SLT)	Engine and ECT
3909	Activate the Solenoid (SLU)	Engine and ECT
3910	Activate the Solenoid (SR)	Engine and ECT
3911	Activate the Solenoid (ST)	Engine and ECT
3912	Activate the Solenoid(SC)	Engine and ECT
3913	Activate the Solenoid(SLP)	Engine and ECT
3914	Activate the Electric Water Pump	Engine and ECT
3915	Activate the Slip Control System	Engine and ECT
3916	Activate the VSV for EGR Cooler Bypass	Engine and ECT
3917	Activate the ACC Cut Relay	Engine and ECT
3918	Activate the LPG Solenoid Valve	Engine and ECT
3919	Activate the Return Solenoid Valve	Engine and ECT
3920	Activate the Emergency Solenoid Valve	Engine and ECT
3921	Activate the VSV2 for Intake Control	Engine and ECT
3922	Activate the Intank Fuel Pump Relay	Engine and ECT
3923	Activate the VSV for Variable Intake Control	Engine and ECT
3924	Activate the Air Pump Heater	Engine and ECT
3925	Activate the Air Switching Valve	Engine and ECT
3926	Active Control Mount	Engine and ECT
3927	Activate the VALVEMATIC (ENG OFF)	Engine and ECT

3928	Activate the VALVEMATIC (ENG ON)	Engine and ECT
3929	Activate HCAC VSV	Engine and ECT
3930	Activate the VSV for Exhaust Switching Valve	Engine and ECT
3931	Activate the VSV for Exhaust Brake	Engine and ECT
3932	Activate the Starter Cut Relay	Engine and ECT
3933	Activate the Starter Relay	Engine and ECT
3934	Activate the Air Pump	Engine and ECT
3935	Activate the Fuel Pump2 Speed Control	Engine and ECT
3936	Activate the Fuel Pump Speed Control	Engine and ECT
3937	Activate the Fuel Return Pipe Valve	Engine and ECT
3938	Activate the Fuel Route Switching Valve Relay	Engine and ECT
3939	Activate the Fuel Filler Opener	Engine and ECT
3940	Activate the Fuel Pressure Switching Valve	Engine and ECT
3941	Activate the Fuel Vapor-Containment Valve	Engine and ECT
3942	Activate the Water Pump	Engine and ECT
3943	Activate the Water Flow Valve 3	Engine and ECT
3944	Activate the Water Flow Valve 4	Engine and ECT
3945	Activate the Water Flow Valve 5	Engine and ECT
3946	Activate the Water Flow Valve 1	Engine and ECT
3947	Activate the Water Flow Valve 2	Engine and ECT
3948	Activate the Vacuum Pump	Engine and ECT
3949	Activate the VSV for Secondary Air Control	Engine and ECT
3950	Activate the VSV for EGR Cut	Engine and ECT
3951	Activate the VSV for Fuel Pressure Up Control	Engine and ECT
3952	Activate the VSV for AICS	Engine and ECT
3953	Activate the VSV for A/C Idle Up Control	Engine and ECT
3954	Activate the VSV for HCAC System	Engine and ECT
3955	Activate the VSV for Air Bleed Control	Engine and ECT
3956	Activate the VSV for Exhaust Gas Control	Engine and ECT
3957	Activate the VSV for Intake Control	Engine and ECT
3958	Activate the VSV for Purge Cut	Engine and ECT
3959	Activate the VSV for Exhaust Shutter	Engine and ECT
3960	Activate the VSV for Exhaust Bypass Control	Engine and ECT
3961	Activate the VSV for Canister Control	Engine and ECT
3962	Activate the VSV for Vent Valve	Engine and ECT
3963	Activate the VSV for Turbo Pressure	Engine and ECT
3964	Activate the VSV for Turbo Boost Control	Engine and ECT
3965	Activate the VSV for Tank Bypass	Engine and ECT
3966	Activate the VSV for Evap Control	Engine and ECT
3967	Activate the VSV for Swirl Control Valve	Engine and ECT
3968	Activate the VSV for Vapor Pressure	Engine and ECT

3969	Activate the Brake Ejector VSV	Engine and ECT
3970	Actuator Test of Metering Unit	Engine and ECT
3971	heater relay No, 1	Engine and ECT
3972	heater relay No, 2	Engine and ECT
3973	heater relay No, 3	Engine and ECT
3974	heater control inspection	Engine and ECT
3975	HCAC VSV Check	Engine and ECT
3976	Check the Imbalance Cylinder	Engine and ECT
3977	Check the Cylinder Compression	Engine and ECT
3978	SOL engagement pressure control	Engine and ECT
3979	Actuator Test of Throttle Valve	Engine and ECT
3980	Emergency shut-off valve	Engine and ECT
3981	Intake valve control switch	Engine and ECT
3982	Intake Air Control VSV	Engine and ECT
3983	Intake Control VSV1	Engine and ECT
3984	Intake Control VSV2	Engine and ECT
3985	Prohibit the Catalyst OT Misfire prevent F/C	Engine and ECT
3986	Purge Cut VSV	Engine and ECT
3987	Control the Purge Dilution Valve Duty Bank1	Engine and ECT
3988	Control the Purge Dilution Valve Duty Bank2	Engine and ECT
3989	Purge VSV	Engine and ECT
3990	Control the VVTL System (Bank1)	Engine and ECT
3991	Control the VVTL System (Bank2)	Engine and ECT
3992	Variable Intake VSV	Engine and ECT
3993	A/C Cut Signal	Engine and ECT
3994	Control the A/C Cut Signal	Engine and ECT
3995	A/F Control	Engine and ECT
3996	Control the SLS Pressure	Engine and ECT
3997	Control the Regulator Shut Valve	Engine and ECT
3998	Control the EGR Step Position #2	Engine and ECT
3999	Control Bank 2 VVT	Engine and ECT
4000	Control the Voltage of Alternator	Engine and ECT
4001	Control the A/C Magnet Clutch	Engine and ECT
4002	Control the Injection Volume for A/F Sensor(CNG)	Engine and ECT
4003	Control the Target Engine Speed	Engine and ECT
4004	Control the Injection Volume(CNG)	Engine and ECT
4005	Control the All Cylinders Fuel Cut	Engine and ECT
4006	Control the All Cylinders Fuel Cut(CNG)	Engine and ECT
4007	Control the Select Cylinder Fuel Cut	Engine and ECT
4008	Control the Select Cylinder Fuel Cut(CNG)	Engine and ECT
4009	Connect the TC and TE1	Engine and ECT
4010	communication pipe shut-off valve	Engine and ECT
4011	Control the Target Fuel Pressure	Engine and ECT
4012	Activate the VALVEMATIC after Warm Up	Engine and ECT
4013	Activate the VALVEMATIC before Warm Up	Engine and ECT
4014	Release Bleed	Engine and ECT

4015	Exhaust valve control switch	Engine and ECT
4016	exhaust bypass valve control	Engine and ECT
4017	Ekibure VSV	Engine and ECT
4018	Injector volume	Engine and ECT
4019	Control the Injection Volume for A/F Sensor	Engine and ECT
4020	injection stop (#1)	Engine and ECT
4021	injection stop (#2)	Engine and ECT
4022	injection stop (#3)	Engine and ECT
4023	injection stop (#4)	Engine and ECT
4024	Control the Injection Way	Engine and ECT
4025	Control the Injection Volume	Engine and ECT
4026	Injection Timing	Engine and ECT
4027	Control the Injection Timing #1	Engine and ECT
4028	Control the Injection Timing #2	Engine and ECT
4029	Control the Injection Timing #3	Engine and ECT
4030	Control the Injection Timing #4	Engine and ECT
4031	Control the Injection Timing #5	Engine and ECT
4032	Control the Injection Timing #6	Engine and ECT
4033	Control the Injection Timing #7	Engine and ECT
4034	Control the Injection Timing #8	Engine and ECT
4035	belt clamping pressure control SOL	Engine and ECT
4036	SOL forward-reverse switching	Engine and ECT
4037	Force stoichiometric control	Engine and ECT
4038	Control the Stratified Charge Combustion	Engine and ECT
4039	Control the Stoichiometric Ratio Combustion	Engine and ECT
4040	Fuel injection timing (#1)	Engine and ECT
4041	Fuel Pump	Engine and ECT
4042	Fuel Pump Relay	Engine and ECT
4043	Control the Fuel Pump Duty	Engine and ECT
4044	Control the Fuel Pump / Speed	Engine and ECT
4045	Actuator Test of Fuel Heater	Engine and ECT
4046	FC IDL Prohibit	Engine and ECT
4047	Fuel Press	Engine and ECT
4048	fuel pressure relief valve open	Engine and ECT
4049	Fuel Pressure Relief Valve Close	Engine and ECT
4050	Fuel Pressure Up VSV	Engine and ECT
4051	Control the Delivery Shut Valve	Engine and ECT
4052	Fuel Shutoff Valve for Delivery Pipe	Engine and ECT
4053	Activate the Lock Up	Engine and ECT
4054	lock-up SOL	Engine and ECT
4055	Lock Up Solenoid	Engine and ECT
4056	Control the Lock Up	Engine and ECT
4057	lock-up control SOL	Engine and ECT
4058	Required voltage power	Engine and ECT
4059	Canister close valve	Engine and ECT
4060	Canister Pressure Control VSV	Engine and ECT
4061	Actuator Test of Glow Plug for External GCU (LIN)	Engine and ECT
4062	Actuator Test of Turbo Charger	Engine and ECT

4063	SLS Press	Engine and ECT
4064	Fuel Shutoff Valve for Press Regulator	Engine and ECT
4065	Actuator Test of Pressure Control Valve	Engine and ECT
4066	tank bypass	Engine and ECT
4067	Tank Pressure Bypass VSV	Engine and ECT
4068	Boost Pressure Control VSV	Engine and ECT
4069	Vacuum Pump	Engine and ECT
4070	Vapor Press VSV	Engine and ECT
4071	Timing Solenoid	Engine and ECT
4072	Control the ETCS Open/Close Fast Speed	Engine and ECT
4073	Control the ETCS Open/Close Slow Speed	Engine and ECT
4074	Sub Fuel Tank VSV	Engine and ECT
4075	Automatic Oil Supply	Engine and ECT
4076	Automatic lubrication oil	Engine and ECT
4077	Control the ACM Inhibit	
4078	Activate the VSV for Vent Value and Vacuum Pump	
4079	Activate the VVT System (Bank1)	
4080	Auto item 1	
4081	Control the C/D	
4082	Control the Cylinder Fuel Cut	
4083	D-4S (A/F Control)	
4084	D-4S (Fuel Cut)	
4085	D-4S (Injection Volume)	
4086	HICM System Check	
4087	Injection Timing Select Cylinder	
4088	Injection Timing Value	
4089	Injection Volume	
4090	Manual item 1 and Check Type Support H	
4091	Manual item 10 and Check Type Support Y	
4092	Manual item 2 and Check Type Support G	
4093	Manual item 3 and Check Type Support F	
4094	Manual item 4 and Check Type Support E	
4095	Manual item 5 and Check Type Support D	
4096	Manual item 6 and Check Type Support C	
4097	Manual item 7 and Check Type Support J	
4098	Manual item 8 and Check Type Support I	
4099	Manual item 9 and Check Type Support X	
4100	Control the O/D Cut	
4101	Pilot Injection Volume Select Cylinder	
4102	Pilot Injection Volume Value	
4103	Pilot Injection Volume	
4104	Control the SCV Duty Ratio	
4105	Brake Ejector VSV Inspection	
4106	Control the VVT-iE Linear (Bank1)	
4107	Control the VVT-iE Linear (Bank2)	
4108	Control the VVT Exhaust Linear (Bank1)	
4109	Control the VVT Exhaust Linear (Bank2)	
4110	Control the VVT System (Bank1)	
4111	Control the VVT System (Bank2)	

4112	Control the VVT Linear (Bank1)	
4113	Control the VVT Linear (Bank2)	
4114	Test the Fuel Leak	
4115	Test the Turbo Charger Step Motor	
4116	Test the Turbo Charger Step Motor #2	
4117	Diesel Throttle Target Angle	
4118	Diesel Throttle Target Angle #2	
4119	Control the IAC Duty Ratio	
4120	Control the ISC Step Position	
4121	Fuel Cut Bank 2 for Idle	
4122	Control the Idle Fuel Cut Prohibit	
4123	Control the Shift Position	
4124	Control the Electric Cooling Fan	
4125	Control the EGR Step Position	
4126	Control the EGR System	
4127	Control the Line Pressure Up	
4128	Control the Supercharger	
4129	Control the Auto Oil Supply System	
4130	Activate the VSV for Evap (Purge)	
4131	Activate the EGR Valve Close	
4132	Activate the VN Turbo Open	
4133	Activate the DPF Rejuvenate (PM)	
4134	Activate the DPF Rejuvenate (S)	
4135	Activate the Solenoid (DS1)	
4136	Activate the Solenoid (DS2)	
4137	Activate the Solenoid (DSL)	
4138	Activate the Solenoid (DSU)	
4139	Activate the Solenoid (S1)	
4140	Activate the Solenoid (S2)	
4141	Activate the Solenoid (S3)	
4142	Activate the Solenoid (S4)	
4143	Activate the Solenoid (SB)	
4144	Activate the Solenoid (SL)	
4145	Activate the Solenoid (SL1)	
4146	Activate the Solenoid (SL2)	
4147	Activate the Solenoid (SL3)	
4148	Activate the Solenoid (SL4)	
4149	Activate the Solenoid (SL5)	
4150	Activate the Solenoid (SLC)	
4151	Activate the Solenoid (SLN)	
4152	Activate the Solenoid (SLS)	
4153	Activate the Solenoid (SLT)	
4154	Activate the Solenoid (SLU)	
4155	Activate the Solenoid (SR)	
4156	Activate the Solenoid (ST)	
4157	Activate the Solenoid(SC)	
4158	Activate the Solenoid(SLP)	
4159	Activate the Electric Water Pump	
4160	Activate the Slip Control System	
4161	Activate the VSV for EGR Cooler Bypass	
4162	Activate the ACC Cut Relay	

4163	Activate the LPG Solenoid Valve	
4164	Activate the Return Solenoid Valve	
4165	Activate the Emergency Solenoid Valve	
4166	Activate the VSV2 for Intake Control	
4167	Activate the Intank Fuel Pump Relay	
4168	Activate the VSV for Variable Intake Control	
4169	Activate the Air Pump Heater	
4170	Activate the Air Switching Valve	
4171	Activate the VALVEMATIC(ENG OFF)	
4172	Activate the VALVEMATIC(ENG ON)	
4173	Activate HCAC VSV	
4174	Activate the VSV for Exhaust Switching Valve	
4175	Activate the VSV for Exhaust Brake	
4176	Activate the Starter Relay	
4177	Activate the Air Pump	
4178	Activate the Fuel Pump2 Speed Control	
4179	Activate the Fuel Pump Speed Control	
4180	Activate the Fuel Return Pipe Valve	
4181	Activate the Fuel Route Switching Valve Relay	
4182	Activate the Fuel Filler Opener	
4183	Activate the Fuel Pressure Switching Valve	
4184	Activate the Fuel Vapor-Containment Valve	
4185	Activate the Water Pump	
4186	Activate the Water Flow Valve 3	
4187	Activate the Water Flow Valve 4	
4188	Activate the Water Flow Valve 5	
4189	Activate the Water Flow Valve 1	
4190	Activate the Water Flow Valve 2	
4191	Activate the Vacuum Pump	
4192	Activate the VSV for Secondary Air Control	
4193	Activate the VSV for EGR Cut	
4194	Activate the VSV for Fuel Pressure Up Control	
4195	Activate the VSV for AICS	
4196	Activate the VSV for A/C Idle Up Control	
4197	Activate the VSV for HCAC System	
4198	Activate the VSV for Air Bleed Control	
4199	Activate the VSV for Exhaust Gas Control	
4200	Activate the VSV for Intake Control	
4201	Activate the VSV for Purge Cut	
4202	Activate the VSV for Exhaust Shutter	
4203	Activate the VSV for Exhaust Bypass Control	
4204	Activate the VSV for Canister Control	

4205	Activate the VSV for Vent Valve	
4206	Activate the VSV for Turbo Pressure	
4207	Activate the VSV for Turbo Boost Control	
4208	Activate the VSV for Tank Bypass	
4209	Activate the VSV for Evap Control	
4210	Activate the VSV for Swirl Control Valve	
4211	Activate the VSV for Vapor Pressure	
4212	Activate the Brake Ejector VSV	
4213	HCAC VSV Check	
4214	Check the Cylinder Compression	
4215	Prohibit the Catalyst OT Misfire prevent F/C	
4216	Control the Purge Dilution Valve Duty Bank1	
4217	Control the Purge Dilution Valve Duty Bank2	
4218	Control the VVTL System (Bank1)	
4219	Control the VVTL System (Bank2)	
4220	Control the A/C Cut Signal	
4221	A/F Control	
4222	Control the SLS Pressure	
4223	Control the Regulator Shut Valve	
4224	Control the EGR Step Position #2	
4225	Control the Voltage of Alternator	
4226	Control the A/C Magnet Clutch	
4227	Control the Injection Volume for A/F Sensor(CNG)	
4228	Control the Injection Volume(CNG)	
4229	Control the All Cylinders Fuel Cut	
4230	Control the All Cylinders Fuel Cut(CNG)	
4231	Control the Select Cylinder Fuel Cut	
4232	Control the Select Cylinder Fuel Cut(CNG)	
4233	Connect the TC and TE1	
4234	Control the Target Fuel Pressure	
4235	Activate the VALVEMATIC after Warm Up	
4236	Activate the VALVEMATIC before Warm Up	
4237	Control the Injection Volume for A/F Sensor	
4238	Control the Injection Way	
4239	Control the Injection Volume	
4240	Injection Timing	
4241	Control the Injection Timing #1	
4242	Control the Injection Timing #2	
4243	Control the Injection Timing #3	
4244	Control the Injection Timing #4	
4245	Control the Injection Timing #5	
4246	Control the Injection Timing #6	
4247	Control the Injection Timing #7	

4248	Control the Injection Timing #8	
4249	Control the Stratified Charge Combustion	
4250	Control the Stoichiometric Ratio Combustion	
4251	Control the Fuel Pump Duty	
4252	Control the Fuel Pump / Speed	
4253	fuel pressure relief valve open	
4254	Fuel Pressure Relief Valve Close	
4255	Control the Delivery Shut Valve	
4256	Activate the Lock Up	
4257	Control the Lock Up	
4258	Control the ETCS Open/Close Fast Speed	
4259	Control the ETCS Open/Close Slow Speed	
4260	Sub Fuel Tank VSV	
4261	A/C Magnetic Clutch Relay	
4262	C/D Control Solenoid	
4263	E-ABV Step	
4264	EGR Step	
4265	EGR System	
4266	HC Adsorber and Catalyst VSV	
4267	SCV VSV	
4268	TE1 (TC)	
4269	VVTL Control (Bank 1)	
4270	VVTL Control (Bank 2)	
4271	VVT Control (Bank 1)	
4272	VVT Control (Bank 2)	
4273	O/D Cut Solenoid	
4274	DPNR Reju(PM)	
4275	DPNR Reju(S)	
4276	IAC Step	
4277	IACV Motor	
4278	IAC Duty	
4279	Idle Up VSV	
4280	Control the Electric Cooling Fan	
4281	Slip Control Solenoid	
4282	Air Bleed	
4283	Exhaust Gas Control VSV	
4284	Exhaust Bypass Valve	
4285	Step Motor for Turbocharger Test	
4286	EGR Valve Close VSV	
4287	EGR POSITION	
4288	Secondary Air VSV	
4289	Line Pressure Up Solenoid	
4290	Shift	
4291	Supercharger Control Relay	
4292	Activate the ACC Cut Relay	
4293	Active Control Mount	
4294	Activate the Starter Relay	
4295	Heater Relay #1	
4296	Heater Relay #2	

4297	Heater Relay #3	
4298	Heater System Test	
4299	Intake Air Control VSV	
4300	Intake Control VSV1	
4301	Intake Control VSV2	
4302	Purge Cut VSV	
4303	Purge VSV (Alone)	
4304	Purge VSV	
4305	Variable Intake VSV	
4306	A/C Cut Signal	
4307	A/F Control	
4308	Injector volume	
4309	Injector Cut #1	
4310	Injector Cut #2	
4311	Injector Cut #3	
4312	Injector Cut #4	
4313	Fuel Pump	
4314	Fuel Pump Relay	
4315	FC IDL Prohibit	
4316	Fuel Leak Test	
4317	Fuel Pressure Up VSV	
4318	Fuel Shutoff Valve for Delivery Pipe	
4319	Lock Up Solenoid	
4320	Canister Pressure Control VSV	
4321	Turbo Pressure Sensor VSV	
4322	Fuel Shutoff Valve for Press Regulator	
4323	Tank Pressure Bypass VSV	
4324	Boost Pressure Control VSV	
4325	Vapor Pressure VSV	
4326	Timing Solenoid	
4327	Automatic Oil Supply	
4328	A/C Magnetic Clutch Relay	
4329	AICV VSV	
4330	C/D Control Solenoid	
4331	E-ABV Step	
4332	EGR Step	
4333	EGR System	
4334	HC Adsorber and Catalyst VSV	
4335	SB Solenoid	
4336	SCV VSV	
4337	SLS Solenoid	
4338	TE1 (TC)	
4339	VVTL Control (Bank 1)	
4340	VVTL Control (Bank 2)	
4341	VVT Control (Bank 1)	
4342	VVT Control (Bank 2)	
4343	O/D Cut Solenoid	
4344	IAC Step	
4345	IACV Motor	
4346	IAC Duty	
4347	Idle Up VSV	

4348	Fan Motor	
4349	Slip Control Solenoid	
4350	Air Bleed	
4351	Exhaust Gas Control VSV	
4352	Exhaust Bypass Valve	
4353	Secondary Air VSV	
4354	Line Pressure Up Solenoid	
4355	Shift	
4356	Vent Valve	
4357	Supercharger Control Relay	
4358	Active Control Mount	
4359	Intake Air Control VSV	
4360	Intake Control VSV1	
4361	Intake Control VSV2	
4362	Purge Cut VSV	
4363	Purge VSV	
4364	Variable Intake VSV	
4365	A/C Cut Signal	
4366	A/F Control	
4367	Injector volume	
4368	Fuel Pump	
4369	Fuel Pump Relay	
4370	FC IDL Prohibit	
4371	Fuel Press	
4372	Fuel Pressure Up VSV	
4373	Fuel Shutoff Valve for Delivery Pipe	
4374	Lock Up Solenoid	
4375	Canister Pressure Control VSV	
4376	SLS Press	
4377	Fuel Shutoff Valve for Press Regulator	
4378	Tank Pressure Bypass VSV	
4379	Boost Pressure Control VSV	
4380	Vacuum Pump	
4381	Vapor Press VSV	
4382	Timing Solenoid	
4383	Sub Fuel Tank VSV	
4384	Automatic Oil Supply	
4385	Control the ACM Inhibit	
4386	Activate the VSV for Vent Valve and Vacuum Pump	
4387	Activate the VVT System (Bank1)	
4388	Auto item 1	
4389	Control the C/D	
4390	Control the Cylinder Fuel Cut	
4391	D-4S (A/F Control)	
4392	D-4S (Fuel Cut)	
4393	D-4S (Injection Volume)	
4394	HICM System Check	
4395	Injection Timing Select Cylinder	
4396	Injection Timing Value	
4397	Injection Volume	

4398	Manual item 1 and Check Type Support H	
4399	Manual item 10 and Check Type Support Y	
4400	Manual item 2 and Check Type Support G	
4401	Manual item 3 and Check Type Support F	
4402	Manual item 4 and Check Type Support E	
4403	Manual item 5 and Check Type Support D	
4404	Manual item 6 and Check Type Support C	
4405	Manual item 7 and Check Type Support J	
4406	Manual item 8 and Check Type Support I	
4407	Manual item 9 and Check Type Support X	
4408	Control the O/D Cut	
4409	Pilot Injection Volume Select Cylinder	
4410	Pilot Injection Volume Value	
4411	Pilot Injection Volume	
4412	Control the SCV Duty Ratio	
4413	Brake Ejector VSV Inspection	
4414	Control the VVT-iE Linear (Bank1)	
4415	Control the VVT-iE Linear (Bank2)	
4416	Control the VVT Exhaust Linear (Bank1)	
4417	Control the VVT Exhaust Linear (Bank2)	
4418	Control the VVT System (Bank1)	
4419	Control the VVT System (Bank2)	
4420	Control the VVT Linear (Bank1)	
4421	Control the VVT Linear (Bank2)	
4422	Test the Fuel Leak	
4423	Test the Turbo Charger Step Motor	
4424	Test the Turbo Charger Step Motor #2	
4425	Diesel Throttle Target Angle	
4426	Diesel Throttle Target Angle #2	
4427	Control the IAC Duty Ratio	
4428	Control the ISC Step Position	
4429	Fuel Cut Bank 2 for Idle	
4430	Control the Idle Fuel Cut Prohibit	
4431	Control the Shift Position	
4432	Control the Electric Cooling Fan	
4433	Control the EGR Step Position	
4434	Control the EGR System	
4435	Control the Line Pressure Up	
4436	Control the Supercharger	
4437	Control the Auto Oil Supply System	
4438	Activate the VSV for Evap (Purge)	
4439	Activate the EGR Valve Close	
4440	Activate the VN Turbo Open	
4441	Activate the DPF Rejuvenate (PM)	
4442	Activate the DPF Rejuvenate (S)	
4443	Activate the Solenoid (DS1)	
4444	Activate the Solenoid (DS2)	
4445	Activate the Solenoid (DSL)	
4446	Activate the Solenoid (DSU)	
4447	Activate the Solenoid (S1)	

4448	Activate the Solenoid (S2)	
4449	Activate the Solenoid (S3)	
4450	Activate the Solenoid (S4)	
4451	Activate the Solenoid (SB)	
4452	Activate the Solenoid (SL)	
4453	Activate the Solenoid (SL1)	
4454	Activate the Solenoid (SL2)	
4455	Activate the Solenoid (SL3)	
4456	Activate the Solenoid (SL4)	
4457	Activate the Solenoid (SL5)	
4458	Activate the Solenoid (SLC)	
4459	Activate the Solenoid (SLN)	
4460	Activate the Solenoid (SLS)	
4461	Activate the Solenoid (SLT)	
4462	Activate the Solenoid (SLU)	
4463	Activate the Solenoid (SR)	
4464	Activate the Solenoid (ST)	
4465	Activate the Solenoid(SC)	
4466	Activate the Solenoid(SLP)	
4467	Activate the Electric Water Pump	
4468	Activate the Slip Control System	
4469	Activate the VSV for EGR Cooler Bypass	
4470	Activate the ACC Cut Relay	
4471	Activate the LPG Solenoid Valve	
4472	Activate the Return Solenoid Valve	
4473	Activate the Emergency Solenoid Valve	
4474	Activate the VSV2 for Intake Control	
4475	Activate the Intank Fuel Pump Relay	
4476	Activate the VSV for Variable Intake Control	
4477	Activate the Air Pump Heater	
4478	Activate the Air Switching Valve	
4479	Activate the VALVEMATIC(ENG OFF)	
4480	Activate the VALVEMATIC(ENG ON)	
4481	Activate HCAC VSV	
4482	Activate the VSV for Exhaust Switching Valve	
4483	Activate the VSV for Exhaust Brake	
4484	Activate the Starter Relay	
4485	Activate the Air Pump	
4486	Activate the Fuel Pump2 Speed Control	
4487	Activate the Fuel Pump Speed Control	
4488	Activate the Fuel Return Pipe Valve	
4489	Activate the Fuel Route Switching Valve Relay	
4490	Activate the Fuel Filler Opener	
4491	Activate the Fuel Pressure Switching Valve	
4492	Activate the Fuel Vapor-Containment Valve	
4493	Activate the Water Pump	
4494	Activate the Water Flow Valve 3	

4495	Activate the Water Flow Valve 4	
4496	Activate the Water Flow Valve 5	
4497	Activate the Water Flow Valve 1	
4498	Activate the Water Flow Valve 2	
4499	Activate the Vacuum Pump	
4500	Activate the VSV for Secondary Air Control	
4501	Activate the VSV for EGR Cut	
4502	Activate the VSV for Fuel Pressure Up Control	
4503	Activate the VSV for AICS	
4504	Activate the VSV for A/C Idle Up Control	
4505	Activate the VSV for HCAC System	
4506	Activate the VSV for Air Bleed Control	
4507	Activate the VSV for Exhaust Gas Control	
4508	Activate the VSV for Intake Control	
4509	Activate the VSV for Purge Cut	
4510	Activate the VSV for Exhaust Shutter	
4511	Activate the VSV for Exhaust Bypass Control	
4512	Activate the VSV for Canister Control	
4513	Activate the VSV for Vent Valve	
4514	Activate the VSV for Turbo Pressure	
4515	Activate the VSV for Turbo Boost Control	
4516	Activate the VSV for Tank Bypass	
4517	Activate the VSV for Evap Control	
4518	Activate the VSV for Swirl Control Valve	
4519	Activate the VSV for Vapor Pressure	
4520	Activate the Brake Ejector VSV	
4521	HCAC VSV Check	
4522	Check the Cylinder Compression	
4523	Prohibit the Catalyst OT Misfire prevent F/C	
4524	Control the Purge Dilution Valve Duty Bank1	
4525	Control the Purge Dilution Valve Duty Bank2	
4526	Control the VVTL System (Bank1)	
4527	Control the VVTL System (Bank2)	
4528	Control the A/C Cut Signal	
4529	A/F Control	
4530	Control the SLS Pressure	
4531	Control the Regulator Shut Valve	
4532	Control the EGR Step Position #2	
4533	Control the Voltage of Alternator	
4534	Control the A/C Magnet Clutch	
4535	Control the Injection Volume for A/F Sensor(CNG)	

4536	Control the Injection Volume (CNG)	
4537	Control the All Cylinders Fuel Cut	
4538	Control the All Cylinders Fuel Cut (CNG)	
4539	Control the Select Cylinder Fuel Cut	
4540	Control the Select Cylinder Fuel Cut (CNG)	
4541	Connect the TC and TE1	
4542	Control the Target Fuel Pressure	
4543	Activate the VALVEMATIC after Warm Up	
4544	Activate the VALVEMATIC before Warm Up	
4545	Control the Injection Volume for A/F Sensor	
4546	Control the Injection Way	
4547	Control the Injection Volume	
4548	Injection Timing	
4549	Control the Injection Timing #1	
4550	Control the Injection Timing #2	
4551	Control the Injection Timing #3	
4552	Control the Injection Timing #4	
4553	Control the Injection Timing #5	
4554	Control the Injection Timing #6	
4555	Control the Injection Timing #7	
4556	Control the Injection Timing #8	
4557	Control the Stratified Charge Combustion	
4558	Control the Stoichiometric Ratio Combustion	
4559	Control the Fuel Pump Duty	
4560	Control the Fuel Pump / Speed	
4561	fuel pressure relief valve open	
4562	Fuel Pressure Relief Valve Close	
4563	Control the Delivery Shut Valve	
4564	Activate the Lock Up	
4565	Control the Lock Up	
4566	Control the ETCS Open/Close Fast Speed	
4567	Control the ETCS Open/Close Slow Speed	
4568	Sub Fuel Tank VSV	
4569	Power Window	RR-Door Motor
4570	PSD Close	Rear Right Door
4571	PSD Open	Rear Right Door
4572	PSD Open Signal	Rear Right Door
4573	PSD Motor	Rear Right Door
4574	PSD Buzzer	Rear Right Door
4575	PSD Clutch	Rear Right Door
4576	Inside Handle Illumination	Rear Right Door
4577	Power Window	Rear Right Door
4578	Rear Door Sunshade Up	Rear Right Door
4579	Rear Door Sunshade Down	Rear Right Door
4580	Mirror Heater	Rear Right Door
4581	Mirror Up/Down	Rear Right Door
4582	Mirror Right/Left	Rear Right Door

4583	Mirror Fold/Return	Rear Right Door
4584	Memory Cancel Lamp	Rear Right Door
4585	Memory Cancel Light	Rear Right Door
4586	Courtesy Lamp	Rear Right Door
4587	Courtesy Light	Rear Right Door
4588	Door Lock	Rear Right Door
4589	Release Actuator	Rear Right Door
4590	Double Lock Unset	Rear Right Door
4591	Foot Light	Rear Right Door
4592	Ashtray Light	Rear Right Door
4593	P Manual SW LED	Rear Right Door
4594	Seat Memory Light	Rear Right Door
4595	Cool air	Rear Right Seat A/C
4596	Warm air	Rear Right Seat A/C
4597	Airflow	Rear Right Seat A/C
4598	Seat Heater Target Temperature	Rear Right Seat A/C
4599	Neckrest Operation	Rear Right Seat
4600	refreshing sheet	Rear Right Seat
4601	Buzzer	Rear Right Seat
4602	Rear Seat Lumbar Adjustment	Rear Right Seat
4603	Slide sheet	Rear Right Seat
4604	Ottoman	Rear Right Seat
4605	Headrest Operation	Rear Right Seat
4606	Refreshing ECU	Rear Right Seat
4607	Necklace To	Rear Right Seat
4608	Seat Slide Operation	Rear Right Seat
4609	Seat Reclining	Rear Right Seat
4610	Interior Illumination Light	Front Right Door
4611	Power Window SW LED	Front Right Door
4612	Mirror Return	Front Right Door
4613	Mirror Heater	Front Right Door
4614	Mirror Up/Down	Front Right Door
4615	Mirror Right/Left	Front Right Door
4616	Mirror Fold/Return	Front Right Door
4617	P Foot Light	Front Right Door
4618	Inside Handle Light	Front Right Door
4619	Courtesy Light	Front Right Door
4620	Foot Light	Front Right Door
4621	Ashtray Light	Front Right Door
4622	Mirror Fold	Front Right Door
4623	Cool air	Front Right Seat A/C
4624	Warm air	Front Right Seat A/C
4625	Airflow	Front Right Seat A/C
4626	Seat Heater Target Temperature	Front Right Seat A/C
4627	Washer Motor Operation	Wiper
4628	oil slick up washer motor	Wiper
4629	Wiper Motor Lo	Wiper
4630	Wiper Motor Hi	Wiper
4631	LKA Lane Out Alarm Buzzer	Pre-Crash
4632	PCS Approach Alarm Buzzer	Pre-Crash
4633	PCS Crash Alarm Buzzer	Pre-Crash

4634	Infrared Signal Status	Pre-Crash
4635	Radar Cruise Approach Alarm Buzzer	Pre-Crash
4636	Radar Cruise Stop Buzzer	Pre-Crash
4637	Face Direction Check	Pre-Crash
4638	accumulator valve (upper chamber)	KDSS
4639	accumulator valve (lower chamber)	KDSS
4640	Accumulator Valve (Upside)	KDSS
4641	Accumulator Valve (Downside)	KDSS
4642	Buzzer	Intuitive Parking Assist
4643	Rear Buzzer	Intuitive Parking Assist
4644	Front Buzzer	Intuitive Parking Assist
4645	Front/Rear Buzzer	Intuitive Parking Assist
4646	Security Indicator	Smart Access
4647	P-Seat Outside Transmitter	Smart Access
4648	P-Seat Select	Smart Access
4649	Pr-Seat Select	Smart Access
4650	Pr-Seat Outside Transmitter	Smart Access
4651	Overhead Tuner Power Supply On	Smart Access
4652	Rr-Seat Inside Transmitter	Smart Access
4653	D-Seat Outside Transmitter	Smart Access
4654	D-Seat Select	Smart Access
4655	Dr-Seat Select	Smart Access
4656	Inside Luggage Tuner Power Supply On	Smart Access
4657	Inside Trunk/Backdoor Transmitter	Smart Access
4658	Fr-Seat Inside Transmitter	Smart Access
4659	Outside Trunk/Backdoor Transmitter	Smart Access
4660	Wireless Buzzer	Smart Access
4661	Back Door Select	Smart Access
4662	Power SW Light	Smart Key
4663	Security Horn	Smart Key
4664	Security Horn2	Smart Key
4665	Security Indicator	Smart Key
4666	Power for PR-Seat Sens	Smart Key
4667	P-Seat Outside Transmitter	Smart Key
4668	P-Seat Select	Smart Key
4669	Pr-Seat Select	Smart Key
4670	P Transmitter	Smart Key
4671	Pr-Seat Outside Transmitter	Smart Key
4672	Power for P-Seat Sens	Smart Key
4673	Headlight Relay	Smart Key
4674	Over Head Tuner	Smart Key
4675	Overhead Tuner Power Supply On	Smart Key
4676	Power/Engine SW Light	Smart Key
4677	Multi Channel SW	Smart Key
4678	Immobiliser Indicator	Smart Key
4679	Buzzer Response Sound	Smart Key
4680	Buzzer For Accessory Output	Smart Key
4681	Pager For Accessory Output	Smart Key
4682	Power for BDoor Sens	Smart Key
4683	Rr-Seat Inside Transmitter	Smart Key
4684	D-Seat Outside Transmitter	Smart Key

4685	D-Seat Select	Smart Key
4686	Dr-Seat Select	Smart Key
4687	D Transmitter	Smart Key
4688	Power for DR-Seat Sens	Smart Key
4689	Power for D-Seat Sens	Smart Key
4690	Inside Luggage Tuner	Smart Key
4691	Inside Luggage Tuner Power Supply On	Smart Key
4692	Inside Trunk/Backdoor Transmitter	Smart Key
4693	Fr Transmitter	Smart Key
4694	Fr-Seat Inside Transmitter	Smart Key
4695	Front Fog Light Relay	Smart Key
4696	Power For Tilt Sensor	Smart Key
4697	Power For Intrusion Sensor	Smart Key
4698	Outside Trunk/Backdoor Transmitter	Smart Key
4699	Hazard	Smart Key
4700	Tail Light	Smart Key
4701	Taillight Relay	Smart Key
4702	Wireless Buzzer	Smart Key
4703	Wireless Buzzer Operation	Smart Key
4704	Luggage Transmitter	Smart Key
4705	In Luggage Transmitter	Smart Key
4706	Trunk Lid Open	Smart Key
4707	Back Door Select	Smart Key
4708	Key Remained Buzzer	Smart Key
4709	Rr Transmitter	Smart Key
4710	Smart Indicator	Smart Key
4711	Self-powered siren	Smart Key
4712	C / P clutch relay	Mild HV
4713	AT oil pump	Mild HV
4714	DC / DC drive	Mild HV
4715	MG no-load drive	Mild HV
4716	engine-driven	Mild HV
4717	Buzzer	Mild HV
4718	accessory drive	Mild HV
4719	starter drive	Mild HV
4720	Control ABS: permit conditions	Mild HV
4721	Outside air temperature: permit conditions	Mild HV
4722	permit conditions: A / C control	Mild HV
4723	permit conditions: MHV control	Mild HV
4724	permit conditions: battery state	Mild HV
4725	permit conditions: engine control	Mild HV
4726	Rear Seat A/C Indicator Reduced	Center Console Switch
4727	Rear Seat A/C Indicator Full	Center Console Switch
4728	Night Lighting	Center Console Switch
4729	LH Courtesy Light	Main Body
4730	RH Courtesy Light	Main Body
4731	Security Horn	Main Body
4732	Security Horn2	Main Body
4733	Security Indicator	Main Body
4734	Day/Night Time Signal	Main Body

4735	Dimmer Signal	Main Body
4736	Side Mirror Foot Light	Main Body
4737	Ceiling Light	Main Body
4738	Door Open/Close State	Main Body
4739	Door Lock/Unlock Status Lamp	Main Body
4740	Inside Handle Illumination	Main Body
4741	Relay for Interior Light Auto Cut Function	Main Body
4742	Interior Panel Relay	Main Body
4743	Passenger Courtesy Lamp	Main Body
4744	Shock Detection Unlock	Main Body
4745	Head Light High	Main Body
4746	Headlight Relay	Main Body
4747	Head Light Cleaner	Main Body
4748	Reverse Gear Signal	Main Body
4749	Light Relay	Main Body
4750	Illuminated Entry System	Main Body
4751	IG OFF P/W Control Permission Output	Main Body
4752	Power Running Board Forced Retracting	Main Body
4753	P Supply for Steering Lock	Main Body
4754	Trunk and back-door open	Main Body
4755	Rear personal light	Main Body
4756	Glass Hatch Open	Main Body
4757	Rear Wiper Power Supply	Main Body
4758	Rear Defogger	Main Body
4759	Mirror Return	Main Body
4760	Mirror Heater	Main Body
4761	Rear Fog Light Relay	Main Body
4762	Rear Wiper Washer Motor Relay	Main Body
4763	shift lock	Main Body
4764	Cargo Light	Main Body
4765	Driver Courtesy Lamp	Main Body
4766	Fr Foot Light	Main Body
4767	Door Lock	Main Body
4768	D-Door Unlock	Main Body
4769	Interior Illumination Light1	Main Body
4770	Interior Illumination Light2	Main Body
4771	Vehicle Horn	Main Body
4772	Front Fog Light Relay	Main Body
4773	Power For Tilt Sensor	Main Body
4774	Fuel Lid Opener	Main Body
4775	Fuel Lid Lock	Main Body
4776	Daytime Running Light	Main Body
4777	Power For Intrusion Sensor2	Main Body
4778	Power For Intrusion Sensor	Main Body
4779	Double Lock Set	Main Body
4780	Double Lock Unset	Main Body
4781	Foot Light	Main Body
4782	Hazard	Main Body
4783	Taillight Relay	Main Body
4784	Wireless Buzzer	Main Body

4785	Advanced Illumination System	Main Body
4786	Turn Light RH Relay Operation	Main Body
4787	RH Mirror Up/Down	Main Body
4788	RH Mirror Right/Left	Main Body
4789	Key Ring Light	Main Body
4790	Key Lock	Main Body
4791	Mirror Fold	Main Body
4792	Indicator for Lighting	Main Body
4793	Indicator Condition	Main Body
4794	Cent Consol Spot LGT	Main Body
4795	Parking Brake Signal	Main Body
4796	Automatic High Beam Operation	Main Body
4797	Turn Light LH Relay Operation	Main Body
4798	LH Mirror Up/Down	Main Body
4799	LH Mirror Right/Left	Main Body
4800	Wing and Deflector Extend/Fold	Active Rear Wing
4801	Wing Extend	Active Rear Wing
4802	Wing Fold	Active Rear Wing
4803	Manual SW Indicator	Active Rear Wing
4804	Wing Angle	Active Rear Wing
4805	Headrest Sensor	Active Headrest L
4806	Headrest Manual Backward	Active Headrest L
4807	Headrest Manual Forward	Active Headrest L
4808	Headrest Auto	Active Headrest L
4809	Headrest Sensor	Active Headrest R
4810	Headrest Manual Backward	Active Headrest R
4811	Headrest Manual Forward	Active Headrest R
4812	Headrest Auto	Active Headrest R
4813	LH Courtesy Light	MASTER
4814	Operation permission P / W	MASTER
4815	RH Courtesy Light	MASTER
4816	Security Horn	MASTER
4817	Security Horn2	MASTER
4818	Security Indicator	MASTER
4819	Dimmer Signal	MASTER
4820	Side Mirror Foot Light	MASTER
4821	Ceiling Light	MASTER
4822	Door Open/Close State	MASTER
4823	Door Lock/Unlock Status Lamp	MASTER
4824	Inside Handle Illumination	MASTER
4825	Relay for Interior Light Auto Cut Function	MASTER
4826	Interior Panel Relay	MASTER
4827	Passenger Courtesy Lamp	MASTER
4828	Head Light High	MASTER
4829	Headlight Relay	MASTER
4830	Head Light Cleaner	MASTER
4831	Reverse Gear Signal	MASTER
4832	Light Relay	MASTER
4833	Illuminated Entry System	MASTER

4834	IG OFF P/W Control Permission Output	MASTER
4835	Power Running Board Forced Retracting	MASTER
4836	P Supply for Steering Lock	MASTER
4837	shock sensing unlock	MASTER
4838	Trunk and back-door open	MASTER
4839	Rear personal light	MASTER
4840	Rear Wiper Power Supply	MASTER
4841	Rear Defogger	MASTER
4842	Mirror Return	MASTER
4843	Mirror Heater	MASTER
4844	Rear Fog Light Relay	MASTER
4845	shift lock	MASTER
4846	Cargo Light	MASTER
4847	Driver Courtesy Lamp	MASTER
4848	Fr Foot Light	MASTER
4849	Door Lock	MASTER
4850	D-Door Unlock	MASTER
4851	Interior Illumination Light1	MASTER
4852	Interior Illumination Light2	MASTER
4853	Vehicle Horn	MASTER
4854	Front Fog Light Relay	MASTER
4855	Power For Tilt Sensor	MASTER
4856	All seats courtesy SW signal	MASTER
4857	Fuel Lid Opener	MASTER
4858	Fuel Lid Lock	MASTER
4859	Daytime Running Light	MASTER
4860	Power For Intrusion Sensor2	MASTER
4861	Power For Intrusion Sensor	MASTER
4862	Double Lock Set	MASTER
4863	Double Lock Unset	MASTER
4864	Foot Light	MASTER
4865	Hazard	MASTER
4866	Taillight Relay	MASTER
4867	Wireless Buzzer	MASTER
4868	Advanced Illumination System	MASTER
4869	Turn Light RH Relay Operation	MASTER
4870	RH Mirror Up/Down	MASTER
4871	RH Mirror Right/Left	MASTER
4872	down the high beam bulb light lighting output	MASTER
4873	Key Ring Light	MASTER
4874	Key Lock	MASTER
4875	Mirror Fold	MASTER
4876	Indicator for Lighting	MASTER
4877	Indicator Condition	MASTER
4878	Cent Consol Spot LGT	MASTER
4879	Parking Brake Signal	MASTER
4880	Automatic High Beam Operation	MASTER
4881	Turn Light LH Relay Operation	MASTER
4882	LH Mirror Up/Down	MASTER
4883	LH Mirror Right/Left	MASTER

4884	Passenger Side Power Window	Main Switch
4885	Driver Side Power Window	Main Switch
4886	Rear Power Window RH	Main Switch
4887	Rear Power Window LH	Main Switch
4888	Security Indicator	Steering Lock
4889	Not P-position Warning	Steering Lock
4890	Meter Buzzer	Steering Lock
4891	Meter Chime	Steering Lock
4892	Break Cable Warning	Steering Lock
4893	Meter Chime Continuously	Steering Lock
4894	Unmatch Key Warning	Steering Lock
4895	Stuck Steering Warning	Steering Lock
4896	solenoid No.1	A/T
4897	solenoid No.2	A/T
4898	solenoid No.3	A/T
4899	Control the SR Solenoid	A/T
4900	Control the DSU Solenoid	A/T
4901	Control the SL Solenoid	A/T
4902	Control the SL1 Solenoid	A/T
4903	Control the SL2 Solenoid	A/T
4904	Control the SL3 Solenoid	A/T
4905	Lock Up Solenoid Status	A/T
4906	#1	ECT
4907	#2	ECT
4908	#3	ECT
4909	#4	ECT
4910	#5	ECT
4911	#6	ECT
4912	#7	ECT
4913	#8	ECT
4914	Control the ACM Inhibit	ECT
4915	Activate the VVT System (Bank1)	ECT
4916	Control the C/D	ECT
4917	CVT shift position	ECT
4918	Control the Cylinder Fuel Cut	ECT
4919	D-4S (A/F Control)	ECT
4920	D-4S (Fuel Cut)	ECT
4921	D-4S (Injection Volume)	ECT
4922	HICM System Check	ECT
4923	Injection Volume	ECT
4924	Control the O/D Cut	ECT
4925	Control the SCV Duty Ratio	ECT
4926	Brake Ejector VSV Inspection	ECT
4927	Control the VVT-iE Linear (Bank1)	ECT
4928	Control the VVT-iE Linear (Bank2)	ECT
4929	Control the VVT Exhaust Linear (Bank1)	ECT
4930	Control the VVT Exhaust Linear (Bank2)	ECT
4931	Control the VVT System (Bank1)	ECT
4932	Control the VVT System (Bank2)	ECT
4933	Control the VVT Linear (Bank1)	ECT
4934	Control the VVT Linear (Bank2)	ECT

4935	Test the Fuel Leak	ECT
4936	Test the Turbo Charger Step Motor	ECT
4937	Diesel Throttle Target Angle	ECT
4938	Gear Position Indicator Output	ECT
4939	Control the IAC Duty Ratio	ECT
4940	Control the ISC Step Position	ECT
4941	Fuel Cut Bank 2 for Idle	ECT
4942	Control the Idle Fuel Cut Prohibit	ECT
4943	Shift position ECT	ECT
4944	Control the Shift Position	ECT
4945	Control the Electric Cooling Fan	ECT
4946	Control the EGR Step Position	ECT
4947	Control the EGR System	ECT
4948	Control the Line Pressure Up	ECT
4949	Line Pressure Solenoid	ECT
4950	Control the Supercharger	ECT
4951	Control the Auto Oil Supply System	ECT
4952	Activate the VSV for Evap (Purge)	ECT
4953	Activate the EGR Valve Close	ECT
4954	Activate the VN Turbo Open	ECT
4955	Activate the DPF Rejuvenate (PM)	ECT
4956	Activate the DPF Rejuvenate (S)	ECT
4957	Activate the Solenoid (DS1)	ECT
4958	Activate the Solenoid (DS2)	ECT
4959	Activate the Solenoid (DSL)	ECT
4960	Activate the Solenoid (DSU)	ECT
4961	Activate the Solenoid (S1)	ECT
4962	Activate the Solenoid (S2)	ECT
4963	Activate the Solenoid (S3)	ECT
4964	Activate the Solenoid (S4)	ECT
4965	Activate the Solenoid (SB)	ECT
4966	Activate the Solenoid (SL)	ECT
4967	Activate the Solenoid (SL1)	ECT
4968	Activate the Solenoid (SL2)	ECT
4969	Activate the Solenoid (SL3)	ECT
4970	Activate the Solenoid (SL4)	ECT
4971	Activate the Solenoid (SL5)	ECT
4972	Activate the Solenoid (SLC)	ECT
4973	Activate the Solenoid (SLN)	ECT
4974	Activate the Solenoid (SLS)	ECT
4975	Activate the Solenoid (SLT)	ECT
4976	Activate the Solenoid (SLU)	ECT
4977	Activate the Solenoid (SR)	ECT
4978	Activate the Solenoid (ST)	ECT
4979	Activate the Solenoid(SC)	ECT
4980	Activate the Solenoid(SLP)	ECT
4981	Activate the Electric Water Pump	ECT
4982	Activate the Slip Control System	ECT
4983	Activate the VSV for EGR Cooler Bypass	ECT
4984	Activate the ACC Cut Relay	ECT
4985	Activate the LPG Solenoid Valve	ECT

4986	Activate the Return Solenoid Valve	ECT
4987	Activate the Emergency Solenoid Valve	ECT
4988	Activate the VSV2 for Intake Control	ECT
4989	Activate the Intank Fuel Pump Relay	ECT
4990	Activate the VSV for Variable Intake Control	ECT
4991	Activate the Air Pump Heater	ECT
4992	Activate the Air Switching Valve	ECT
4993	Activate the VALVEMATIC (ENG OFF)	ECT
4994	Activate the VALVEMATIC (ENG ON)	ECT
4995	Activate HCAC VSV	ECT
4996	Activate the VSV for Exhaust Switching Valve	ECT
4997	Activate the VSV for Exhaust Brake	ECT
4998	Activate the Starter Cut Relay	ECT
4999	Activate the Starter Relay	ECT
5000	Activate the Air Pump	ECT
5001	Activate the Fuel Pump2 Speed Control	ECT
5002	Activate the Fuel Pump Speed Control	ECT
5003	Activate the Fuel Return Pipe Valve	ECT
5004	Activate the Fuel Route Switching Valve Relay	ECT
5005	Activate the Fuel Filler Opener	ECT
5006	Activate the Fuel Pressure Switching Valve	ECT
5007	Activate the Fuel Vapor-Containment Valve	ECT
5008	Activate the Water Pump	ECT
5009	Activate the Water Flow Valve 3	ECT
5010	Activate the Water Flow Valve 4	ECT
5011	Activate the Water Flow Valve 5	ECT
5012	Activate the Water Flow Valve 1	ECT
5013	Activate the Water Flow Valve 2	ECT
5014	Activate the Vacuum Pump	ECT
5015	Activate the VSV for Secondary Air Control	ECT
5016	Activate the VSV for EGR Cut	ECT
5017	Activate the VSV for Fuel Pressure Up Control	ECT
5018	Activate the VSV for AICS	ECT
5019	Activate the VSV for A/C Idle Up Control	ECT
5020	Activate the VSV for HCAC System	ECT
5021	Activate the VSV for Air Bleed Control	ECT
5022	Activate the VSV for Exhaust Gas Control	ECT
5023	Activate the VSV for Intake Control	ECT
5024	Activate the VSV for Purge Cut	ECT
5025	Activate the VSV for Exhaust Shutter	ECT
5026	Activate the VSV for Exhaust Bypass Control	ECT
5027	Activate the VSV for Canister Control	ECT

5028	Activate the VSV for Vent Valve	ECT
5029	Activate the VSV for Turbo Pressure	ECT
5030	Activate the VSV for Turbo Boost Control	ECT
5031	Activate the VSV for Tank Bypass	ECT
5032	Activate the VSV for Evap Control	ECT
5033	Activate the VSV for Swirl Control Valve	ECT
5034	Activate the VSV for Vapor Pressure	ECT
5035	Activate the Brake Ejector VSV	ECT
5036	HCAC VSV Check	ECT
5037	Check the Imbalance Cylinder	ECT
5038	Check the Cylinder Compression	ECT
5039	Prohibit the Catalyst OT Misfire prevent F/C	ECT
5040	Control the Purge Dilution Valve Duty Bank1	ECT
5041	Control the Purge Dilution Valve Duty Bank2	ECT
5042	Control the VVTL System (Bank1)	ECT
5043	Control the VVTL System (Bank2)	ECT
5044	Control the A/C Cut Signal	ECT
5045	A/F Control	ECT
5046	Control the SLS Pressure	ECT
5047	Control the SR Solenoid	ECT
5048	Control the DSU Solenoid	ECT
5049	Control the SL Solenoid	ECT
5050	Control the SL1 Solenoid	ECT
5051	Control the SL2 Solenoid	ECT
5052	Control the SL3 Solenoid	ECT
5053	Control the Regulator Shut Valve	ECT
5054	Control the EGR Step Position #2	ECT
5055	Control the Voltage of Alternator	ECT
5056	Control the A/C Magnet Clutch	ECT
5057	Control the Injection Volume for A/F Sensor (CNG)	ECT
5058	Control the Target Engine Speed	ECT
5059	Control the Injection Volume (CNG)	ECT
5060	Control the Cylinder#1 Fuel Cut	ECT
5061	Control the Cylinder#2 Fuel Cut	ECT
5062	Control the Cylinder#3 Fuel Cut	ECT
5063	Control the Cylinder#4 Fuel Cut	ECT
5064	Control the Cylinder#5 Fuel Cut	ECT
5065	Control the Cylinder#6 Fuel Cut	ECT
5066	Control the Cylinder#7 Fuel Cut	ECT
5067	Control the Cylinder#8 Fuel Cut	ECT
5068	Control the All Cylinders Fuel Cut	ECT
5069	Control the All Cylinders Fuel Cut (CNG)	ECT
5070	Control the Select Cylinder Fuel Cut	ECT
5071	Control the Select Cylinder Fuel Cut (CNG)	ECT

5072	Connect the TC and TE1	ECT
5073	Motor Relay Control	ECT
5074	Target Gear Position Control	ECT
5075	Control the Target Fuel Pressure	ECT
5076	Target Select Stroke Control	ECT
5077	Target Shift Stroke Control	ECT
5078	Activate the VALVEMATIC after Warm Up	ECT
5079	Activate the VALVEMATIC before Warm Up	ECT
5080	Control the Injection Volume for A/F Sensor	ECT
5081	Control the Injection Way	ECT
5082	Control the Injection Volume	ECT
5083	Control the Injection Timing #1	ECT
5084	Control the Injection Timing #2	ECT
5085	Control the Injection Timing #3	ECT
5086	Control the Injection Timing #4	ECT
5087	Control the Injection Timing #5	ECT
5088	Control the Injection Timing #6	ECT
5089	Control the Injection Timing #7	ECT
5090	Control the Injection Timing #8	ECT
5091	Control the Stratified Charge Combustion	ECT
5092	Control the Stoichiometric Ratio Combustion	ECT
5093	Control the Fuel Pump Duty	ECT
5094	Control the Fuel Pump / Speed	ECT
5095	fuel pressure relief valve open	ECT
5096	Fuel Pressure Relief Valve Close	ECT
5097	release cylinder air vent	ECT
5098	Control the Delivery Shut Valve	ECT
5099	Activate the Lock Up	ECT
5100	lock-up SOL	ECT
5101	Control the Lock Up	ECT
5102	Reduced Accumulator Pressure	ECT
5103	Pre-Crash Safety Warning Buz	ECT
5104	Control the ETCS Open/Close Fast Speed	ECT
5105	Control the ETCS Open/Close Slow Speed	ECT
5106	Sub Fuel Tank VSV	ECT
5107	Control the ACM Inhibit	
5108	Activate the VVT System (Bank1)	
5109	Control the C/D	
5110	HICM System Check	
5111	Control the O/D Cut	
5112	Control the SCV Duty Ratio	
5113	Brake Ejector VSV Inspection	
5114	Control the VVT-iE Linear (Bank1)	
5115	Control the VVT-iE Linear (Bank2)	
5116	Control the VVT Exhaust Linear (Bank1)	
5117	Control the VVT Exhaust Linear (Bank2)	
5118	Control the VVT System (Bank1)	
5119	Control the VVT System (Bank2)	
5120	Control the VVT Linear (Bank1)	

5121	Control the VVT Linear (Bank2)	
5122	Test the Fuel Leak	
5123	Test the Turbo Charger Step Motor	
5124	Diesel Throttle Target Angle	
5125	Control the IAC Duty Ratio	
5126	Control the ISC Step Position	
5127	Fuel Cut Bank 2 for Idle	
5128	Control the Idle Fuel Cut Prohibit	
5129	Control the Shift Position	
5130	Control the Electric Cooling Fan	
5131	Control the EGR Step Position	
5132	Control the EGR System	
5133	Control the Line Pressure Up	
5134	Control the Supercharger	
5135	Control the Auto Oil Supply System	
5136	Activate the VSV for Evap (Purge)	
5137	Activate the EGR Valve Close	
5138	Activate the VN Turbo Open	
5139	Activate the DPF Rejuvenate (PM)	
5140	Activate the DPF Rejuvenate (S)	
5141	Activate the Solenoid (DS1)	
5142	Activate the Solenoid (DS2)	
5143	Activate the Solenoid (DSL)	
5144	Activate the Solenoid (DSU)	
5145	Activate the Solenoid (S1)	
5146	Activate the Solenoid (S2)	
5147	Activate the Solenoid (S3)	
5148	Activate the Solenoid (S4)	
5149	Activate the Solenoid (SB)	
5150	Activate the Solenoid (SL)	
5151	Activate the Solenoid (SL1)	
5152	Activate the Solenoid (SL2)	
5153	Activate the Solenoid (SL3)	
5154	Activate the Solenoid (SL4)	
5155	Activate the Solenoid (SL5)	
5156	Activate the Solenoid (SLC)	
5157	Activate the Solenoid (SLN)	
5158	Activate the Solenoid (SLS)	
5159	Activate the Solenoid (SLT)	
5160	Activate the Solenoid (SLU)	
5161	Activate the Solenoid (SR)	
5162	Activate the Solenoid (ST)	
5163	Activate the Solenoid(SC)	
5164	Activate the Solenoid(SLP)	
5165	Activate the Electric Water Pump	
5166	Activate the Slip Control System	
5167	Activate the VSV for EGR Cooler Bypass	
5168	Activate the ACC Cut Relay	
5169	Activate the LPG Solenoid Valve	
5170	Activate the Return Solenoid Valve	
5171	Activate the Emergency Solenoid Valve	

5172	Activate the VSV2 for Intake Control	
5173	Activate the Intank Fuel Pump Relay	
5174	Activate the VSV for Variable Intake Control	
5175	Activate the Air Pump Heater	
5176	Activate the Air Switching Valve	
5177	Activate the VALVEMATIC (ENG OFF)	
5178	Activate the VALVEMATIC (ENG ON)	
5179	Activate HCAC VSV	
5180	Activate the VSV for Exhaust Switching Valve	
5181	Activate the VSV for Exhaust Brake	
5182	Activate the Starter Relay	
5183	Activate the Air Pump	
5184	Activate the Fuel Pump2 Speed Control	
5185	Activate the Fuel Pump Speed Control	
5186	Activate the Fuel Return Pipe Valve	
5187	Activate the Fuel Route Switching Valve Relay	
5188	Activate the Fuel Filler Opener	
5189	Activate the Fuel Pressure Switching Valve	
5190	Activate the Fuel Vapor-Containment Valve	
5191	Activate the Water Pump	
5192	Activate the Water Flow Valve 3	
5193	Activate the Water Flow Valve 4	
5194	Activate the Water Flow Valve 5	
5195	Activate the Water Flow Valve 1	
5196	Activate the Water Flow Valve 2	
5197	Activate the Vacuum Pump	
5198	Activate the VSV for Secondary Air Control	
5199	Activate the VSV for EGR Cut	
5200	Activate the VSV for Fuel Pressure Up Control	
5201	Activate the VSV for AICS	
5202	Activate the VSV for A/C Idle Up Control	
5203	Activate the VSV for HCAC System	
5204	Activate the VSV for Air Bleed Control	
5205	Activate the VSV for Exhaust Gas Control	
5206	Activate the VSV for Intake Control	
5207	Activate the VSV for Purge Cut	
5208	Activate the VSV for Exhaust Shutter	
5209	Activate the VSV for Exhaust Bypass Control	
5210	Activate the VSV for Canister Control	
5211	Activate the VSV for Vent Valve	
5212	Activate the VSV for Turbo Pressure	

5213	Activate the VSV for Turbo Boost Control	
5214	Activate the VSV for Tank Bypass	
5215	Activate the VSV for Evap Control	
5216	Activate the VSV for Swirl Control Valve	
5217	Activate the VSV for Vapor Pressure	
5218	Activate the Brake Ejector VSV	
5219	HCAC VSV Check	
5220	Check the Cylinder Compression	
5221	Prohibit the Catalyst OT Misfire prevent F/C	
5222	Control the Purge Dilution Valve Duty Bank1	
5223	Control the Purge Dilution Valve Duty Bank2	
5224	Control the VVTL System (Bank1)	
5225	Control the VVTL System (Bank2)	
5226	Control the A/C Cut Signal	
5227	Control the SLS Pressure	
5228	Control the Regulator Shut Valve	
5229	Control the EGR Step Position #2	
5230	Control the Voltage of Alternator	
5231	Control the A/C Magnet Clutch	
5232	Control the Injection Volume for A/F Sensor(CNG)	
5233	Control the Injection Volume(CNG)	
5234	Control the Cylinder#1 Fuel Cut	
5235	Control the Cylinder#2 Fuel Cut	
5236	Control the Cylinder#3 Fuel Cut	
5237	Control the Cylinder#4 Fuel Cut	
5238	Control the Cylinder#5 Fuel Cut	
5239	Control the Cylinder#6 Fuel Cut	
5240	Control the Cylinder#7 Fuel Cut	
5241	Control the Cylinder#8 Fuel Cut	
5242	Control the All Cylinders Fuel Cut	
5243	Control the All Cylinders Fuel Cut(CNG)	
5244	Control the Select Cylinder Fuel Cut(CNG)	
5245	Connect the TC and TE1	
5246	Control the Target Fuel Pressure	
5247	Activate the VALVEMATIC after Warm Up	
5248	Activate the VALVEMATIC before Warm Up	
5249	Control the Injection Volume for A/F Sensor	
5250	Control the Injection Way	
5251	Control the Injection Volume	
5252	Control the Injection Timing #1	
5253	Control the Injection Timing #2	
5254	Control the Injection Timing #3	
5255	Control the Injection Timing #4	

5256	Control the Injection Timing #5	
5257	Control the Injection Timing #6	
5258	Control the Injection Timing #7	
5259	Control the Injection Timing #8	
5260	Control the Stratified Charge Combustion	
5261	Control the Stoichiometric Ratio Combustion	
5262	Control the Fuel Pump Duty	
5263	Control the Fuel Pump / Speed	
5264	fuel pressure relief valve open	
5265	Fuel Pressure Relief Valve Close	
5266	Control the Delivery Shut Valve	
5267	Activate the Lock Up	
5268	Control the Lock Up	
5269	Control the ETCS Open/Close Fast Speed	
5270	Control the ETCS Open/Close Slow Speed	
5271	Sub Fuel Tank VSV	
5272	CVT shift position	ECT (SIL2)
5273	HICM System Check	ECT (SIL2)
5274	Brake Ejector VSV Inspection	ECT (SIL2)
5275	Control the VVT-iE Linear (Bank1)	ECT (SIL2)
5276	Control the VVT-iE Linear (Bank2)	ECT (SIL2)
5277	Test the Turbo Charger Step Motor	ECT (SIL2)
5278	Diesel Throttle Target Angle	ECT (SIL2)
5279	Control the ISC Step Position	ECT (SIL2)
5280	Fuel Cut Bank 2 for Idle	ECT (SIL2)
5281	Control the Shift Position	ECT (SIL2)
5282	Control the EGR Step Position	ECT (SIL2)
5283	Control the Line Pressure Up	ECT (SIL2)
5284	Activate the EGR Valve Close	ECT (SIL2)
5285	Activate the VN Turbo Open	ECT (SIL2)
5286	Activate the DPF Rejuvenate (PM)	ECT (SIL2)
5287	Activate the DPF Rejuvenate (S)	ECT (SIL2)
5288	Activate the Solenoid (DS1)	ECT (SIL2)
5289	Activate the Solenoid (DS2)	ECT (SIL2)
5290	Activate the Solenoid (DSL)	ECT (SIL2)
5291	Activate the Solenoid (DSU)	ECT (SIL2)
5292	Activate the Solenoid (S1)	ECT (SIL2)
5293	Activate the Solenoid (S2)	ECT (SIL2)
5294	Activate the Solenoid (S3)	ECT (SIL2)
5295	Activate the Solenoid (S4)	ECT (SIL2)
5296	Activate the Solenoid (SB)	ECT (SIL2)
5297	Activate the Solenoid (SL)	ECT (SIL2)
5298	Activate the Solenoid (SL1)	ECT (SIL2)
5299	Activate the Solenoid (SL2)	ECT (SIL2)
5300	Activate the Solenoid (SL3)	ECT (SIL2)
5301	Activate the Solenoid (SL4)	ECT (SIL2)
5302	Activate the Solenoid (SL5)	ECT (SIL2)
5303	Activate the Solenoid (SLC)	ECT (SIL2)
5304	Activate the Solenoid (SLN)	ECT (SIL2)

5305	Activate the Solenoid (SLS)	ECT (SIL2)
5306	Activate the Solenoid (SLT)	ECT (SIL2)
5307	Activate the Solenoid (SLU)	ECT (SIL2)
5308	Activate the Solenoid (SR)	ECT (SIL2)
5309	Activate the Solenoid (ST)	ECT (SIL2)
5310	Activate the Solenoid(SC)	ECT (SIL2)
5311	Activate the Solenoid(SLP)	ECT (SIL2)
5312	Activate the Electric Water Pump	ECT (SIL2)
5313	Activate the Slip Control System	ECT (SIL2)
5314	Activate the VSV for EGR Cooler Bypass	ECT (SIL2)
5315	Activate the LPG Solenoid Valve	ECT (SIL2)
5316	Activate the Return Solenoid Valve	ECT (SIL2)
5317	Activate the Emergency Solenoid Valve	ECT (SIL2)
5318	Activate the Intank Fuel Pump Relay	ECT (SIL2)
5319	Activate the Air Pump Heater	ECT (SIL2)
5320	Activate the VALVEMATIC(ENG OFF)	ECT (SIL2)
5321	Activate the VALVEMATIC(ENG ON)	ECT (SIL2)
5322	Activate the VSV for Exhaust Switching Valve	ECT (SIL2)
5323	Activate the VSV for Exhaust Brake	ECT (SIL2)
5324	Activate the Fuel Pump2 Speed Control	ECT (SIL2)
5325	Activate the Fuel Return Pipe Valve	ECT (SIL2)
5326	Activate the Fuel Route Switching Valve Relay	ECT (SIL2)
5327	Activate the Fuel Filler Opener	ECT (SIL2)
5328	Activate the Fuel Vapor-Containment Valve	ECT (SIL2)
5329	Activate the VSV for EGR Cut	ECT (SIL2)
5330	Activate the VSV for Exhaust Shutter	ECT (SIL2)
5331	Activate the Brake Ejector VSV	ECT (SIL2)
5332	Check the Cylinder Compression	ECT (SIL2)
5333	Prohibit the Catalyst OT Misfire prevent F/C	ECT (SIL2)
5334	Control the Purge Dilution Valve Duty Bank1	ECT (SIL2)
5335	Control the Purge Dilution Valve Duty Bank2	ECT (SIL2)
5336	Control the SLS Pressure	ECT (SIL2)
5337	Control the Regulator Shut Valve	ECT (SIL2)
5338	Control the Voltage of Alternator	ECT (SIL2)
5339	Control the Injection Volume(CNG)	ECT (SIL2)
5340	Control the Cylinder#1 Fuel Cut	ECT (SIL2)
5341	Control the Cylinder#2 Fuel Cut	ECT (SIL2)
5342	Control the Cylinder#3 Fuel Cut	ECT (SIL2)
5343	Control the Cylinder#4 Fuel Cut	ECT (SIL2)
5344	Control the Cylinder#5 Fuel Cut	ECT (SIL2)
5345	Control the Cylinder#6 Fuel Cut	ECT (SIL2)
5346	Control the Cylinder#7 Fuel Cut	ECT (SIL2)
5347	Control the Cylinder#8 Fuel Cut	ECT (SIL2)
5348	Control the All Cylinders Fuel Cut	ECT (SIL2)
5349	Control the All Cylinders Fuel Cut (CNG)	ECT (SIL2)

5350	Control the Select Cylinder Fuel Cut (CNG)	ECT (SIL2)
5351	Connect the TC and TE1	ECT (SIL2)
5352	Activate the VALVEMATIC after Warm Up	ECT (SIL2)
5353	Activate the VALVEMATIC before Warm Up	ECT (SIL2)
5354	Control the Injection Way	ECT (SIL2)
5355	Control the Fuel Pump Duty	ECT (SIL2)
5356	Control the Fuel Pump / Speed	ECT (SIL2)
5357	fuel pressure relief valve open	ECT (SIL2)
5358	Fuel Pressure Relief Valve Close	ECT (SIL2)
5359	Activate the Lock Up	ECT (SIL2)
5360	Control the Lock Up	ECT (SIL2)
5361	Automatic High Beam	Automatic High Beam
5362	Indicat. 4LO	Combination Meter
5363	4WD Warning Light	Combination Meter
5364	Indicat. 4WD Lock	Combination Meter
5365	Indicat. A/T P	Combination Meter
5366	A/T Indicator Operation 3	Combination Meter
5367	Indicat. Lamp ARS	Combination Meter
5368	AFS OFF Indicator	Combination Meter
5369	ASL Warning Indicator	Combination Meter
5370	Indicat. ASL	Combination Meter
5371	BSM Control Indicator	Combination Meter
5372	Indicat. DABS	Combination Meter
5373	Indicat. ECB	Combination Meter
5374	ECB Indicator Light	Combination Meter
5375	Indicat. Lamp ECT PWR	Combination Meter
5376	EPB Auto OFF Indicator	Combination Meter
5377	EV System Indicator	Combination Meter
5378	EV Mode Indicator	Combination Meter
5379	HV Unit Hot Warning Indicator	Combination Meter
5380	HV System Certification Mode Indicator	Combination Meter
5381	ICS OFF Indicator	Combination Meter
5382	Indicat. INTUITIVE P/A LCD	Combination Meter
5383	Indicat. Ready (EV)	Combination Meter
5384	KDSS Indicator	Combination Meter
5385	LDA Warning Indicator	Combination Meter
5386	LDA Warning Indicator (Right)	Combination Meter
5387	LDA Warning Indicator (Left)	Combination Meter
5388	LDA Control Indicator	Combination Meter
5389	LDA Control Indicator (Right)	Combination Meter
5390	LDA Control Indicator (Left)	Combination Meter
5391	LED Head Lamp Warning	Combination Meter
5392	Indicat. MMT E Mode	Combination Meter
5393	Indicat. MMT M Mode	Combination Meter
5394	Indicat. Navi CVT	Combination Meter
5395	PPS Indicator	Combination Meter
5396	Indicat. Ready (HV)	Combination Meter
5397	Indicat. SIL (Up)	Combination Meter
5398	Indicat. SIL (Down)	Combination Meter
5399	Indicat. SIL	Combination Meter

5400	SOC Warning Indicator	Combination Meter
5401	SOC Gauge	Combination Meter
5402	SPORT Indicator	Combination Meter
5403	Indicat. TEMS Comfort	Combination Meter
5404	VSC TRC Indicator	Combination Meter
5405	Indicat. VSC OFF	Combination Meter
5406	Seat Belt Buzzer	Combination Meter
5407	Maintenance Indicator	Combination Meter
5408	Indicat. Lamp T.C. Oil Temperature	Combination Meter
5409	Diesel Particulate Filter Warning	Combination Meter
5410	Indicat. Lamp O/D OFF	Combination Meter
5411	Vehicle Approach Warning OFF Indicator	Combination Meter
5412	Vehicle Stop Indicator	Combination Meter
5413	Indicat. Lamp VSC	Combination Meter
5414	Indicat. Lamp VSC OFF	Combination Meter
5415	Indicat. Lamp Doors All Open	Combination Meter
5416	Indicat. Lamp Door	Combination Meter
5417	Charge Warning Indicator	Combination Meter
5418	Indicat. Lamp Charge	Combination Meter
5419	Charging Indicator	Combination Meter
5420	Slip Indicator Light	Combination Meter
5421	Indicat. Lamp Headlamp Auto Level	Combination Meter
5422	Reverse Buzzer	Combination Meter
5423	Light Remained Buzzer	Combination Meter
5424	CRAWL Warning Indicator	Combination Meter
5425	Indicat. EPS	Combination Meter
5426	Indicat. Lamp ECT SNOW	Combination Meter
5427	Indicat. TEMS Sports	Combination Meter
5428	Circuit Mode Indicator	Combination Meter
5429	Volt Meter Operation	Combination Meter
5430	Multi-Display	Combination Meter
5431	Indicat. 2nd START	Combination Meter
5432	Indicat. Lamp Hood Door Open	Combination Meter
5433	Auxs Battery Charge Warning	Combination Meter
5434	Indicat. Height High	Combination Meter
5435	Power Meter Operation	Combination Meter
5436	Limited Power Indicator	Combination Meter
5437	Indicat. Over Speed	Combination Meter
5438	Fuel Consumption Meter Operation	Combination Meter
5439	Indicat. Rr DIFF LOCK	Combination Meter
5440	Indicat. Lamp Rr Light	Combination Meter
5441	Indicat. Lamp Back Door Open	Combination Meter
5442	Indicat. Lamp Rr FOG	Combination Meter
5443	Rear seat belt	Combination Meter
5444	Hybrid System Warning	Combination Meter
5445	Indicat. Oil Pressure	Combination Meter
5446	Indicat. Lamp Oil Level	Combination Meter
5447	Indicat. Lamp Oil	Combination Meter
5448	Laser Cruise at Constant-Speed	Combination Meter
5449	Indicat. Ride Mode	Combination Meter
5450	Driver Side Door Open	Combination Meter

5451	Driver Side Seat Belt	Combination Meter
5452	Check Engine Warning	Combination Meter
5453	Check Engine Indicator	Combination Meter
5454	indicat ECD ON	Combination Meter
5455	Indicat. Lamp ECONO	Combination Meter
5456	Indicat. ECO MODE	Combination Meter
5457	Warning Buzzer	Combination Meter
5458	Ready Buzzer	Combination Meter
5459	Indicator. VGRS	Combination Meter
5460	Air Conditioner Auto Indicator	Combination Meter
5461	Air Suspension (N) Indicator	Combination Meter
5462	Air Suspension (LO) Indicator	Combination Meter
5463	Air Suspension (HI) Indicator	Combination Meter
5464	Indicat. Ctr DIFF LOCK	Combination Meter
5465	Radar Cruise Ready Indicator	Combination Meter
5466	Indicat. Lamp L-Cruise Check	Combination Meter
5467	Indicat. Lamp L-Cruise Ready	Combination Meter
5468	Indicat. Laser Cruise Display	Combination Meter
5469	Indicat. Radar Cruise	Combination Meter
5470	Radar Cruise Indicator	Combination Meter
5471	Indicat. Lamp Coolant Hot	Combination Meter
5472	Indicat. Lamp Coolant Cool	Combination Meter
5473	Coolant Temp LCD	Combination Meter
5474	Indicat. ODO/TRIP Display	Combination Meter
5475	Indicat. Compass Display	Combination Meter
5476	Blind Spot Monitor Indicator	Combination Meter
5477	HV System Indicator	Combination Meter
5478	Indicat. CRAWL	Combination Meter
5479	Indicat. Lamp Exhaust Temp	Combination Meter
5480	Drift From The Lane	Combination Meter
5481	Head Up Display Indicator	Combination Meter
5482	Indicat. Lamp Airbag	Combination Meter
5483	Indicat. Lamp Head	Combination Meter
5484	Front Passenger Side Door Open	Combination Meter
5485	Front Passenger Side SeatBelt	Combination Meter
5486	Indicat. Precrash	Combination Meter
5487	Indicat. Lamp Fr FOG	Combination Meter
5488	Indicat. Lamp Fuel	Combination Meter
5489	Fuel Meter Operation (CNG)	Combination Meter
5490	Fuel Meter Operation	Combination Meter
5491	Fuel Filter Indicator	Combination Meter
5492	Fuel Indicator (CNG)	Combination Meter
5493	Daytime Running Lights OFF Indicator	Combination Meter
5494	Brake Override Indicator	Combination Meter
5495	Indicat. Lamp Brake	Combination Meter
5496	Indicat. SET	Combination Meter
5497	Indicat. Lamp Water Level	Combination Meter
5498	Water Temperature Meter Operation	Combination Meter
5499	Indicat. 4WD	Combination Meter
5500	Speed Meter Operation	Combination Meter
5501	Speed Buzzer	Combination Meter

5502	Speedometer LCD	Combination Meter
5503	Indicat. Tire Pressure Warning System	Combination Meter
5504	Go to Dealer Indicator	Combination Meter
5505	Stop and Start OFF Indicator	Combination Meter
5506	Stop and Start ON Indicator	Combination Meter
5507	TOW HAUL Indicator	Combination Meter
5508	Indicat. Lamp Tail	Combination Meter
5509	Tail OFF Indicator	Combination Meter
5510	Indicat. Tail Cancel	Combination Meter
5511	Indicat. Lamp Washer	Combination Meter
5512	Indicat. EV Mode	Combination Meter
5513	Indicat. Hold	Combination Meter
5514	Indicat. KEY	Combination Meter
5515	Indicat. Headlamp Auto Leveling	Combination Meter
5516	Indicat. ECONO	Combination Meter
5517	Indicat. 4WD AUTO	Combination Meter
5518	Indicat. Downhill Assist Control	Combination Meter
5519	Indicat. Brake Hold	Combination Meter
5520	Indicat. Auto LSD	Combination Meter
5521	Shift-by-wire Warning	Combination Meter
5522	Luggage Mode Indicator	Combination Meter
5523	Indicat. Lamp Luggage Door Open	Combination Meter
5524	Cruise Warning	Combination Meter
5525	Indicat. Lamp Cruise	Combination Meter
5526	CNG Mode Indicator	Combination Meter
5527	Indicat. Night View	Combination Meter
5528	Key Remained Buzzer	Combination Meter
5529	Meter Display 1	Combination Meter
5530	Meter Display 2	Combination Meter
5531	Engine(HV E/G Nonstop Mode)	Combination Meter
5532	Indicat. Lamp Engine	Combination Meter
5533	Oil Pressure Meter Operation	Combination Meter
5534	Indicat. Rear Door RH Open	Combination Meter
5535	Rr Inner Wheel Control Warning	Combination Meter
5536	Rr Inner Wheel Control Indicator	Combination Meter
5537	Indicat. Lamp Turn R	Combination Meter
5538	Indicat GLOW	Combination Meter
5539	Indicat. Lamp Beam	Combination Meter
5540	OFF Road Guidance Indicator	Combination Meter
5541	Sports Shift Reject Buzzer	Combination Meter
5542	Indicat. Sport(CVT Sport)	Combination Meter
5543	Indicat. Clearance Sonar LCD	Combination Meter
5544	Indicat. Timing Belt	Combination Meter
5545	Indicat. SET	Combination Meter
5546	Smart System Warning	Combination Meter
5547	Smart system indicator	Combination Meter
5548	Smart Key	Combination Meter
5549	Indicat. Main Battery (HV)	Combination Meter
5550	Indicat. Main Battery (HV)	Combination Meter
5551	Indicat. Lamp TRAC(TRC) OFF	Combination Meter
5552	ACTIVE TRC Warning Indicator	Combination Meter

5553	ACTIVE TRC Indicator	Combination Meter
5554	Master warning	Combination Meter
5555	Maintenance Required	Combination Meter
5556	P Range Indicator	Combination Meter
5557	Indicat. Park	Combination Meter
5558	TachoMeter Operation	Combination Meter
5559	Turn Signal (Right) Indicator	Combination Meter
5560	Turn Signal (Left) Indicator	Combination Meter
5561	A/T Oil Temperature Operation	Combination Meter
5562	A/T Indicator Operation 1	Combination Meter
5563	A/T Indicator Operation 2	Combination Meter
5564	A/T Indicator Operation	Combination Meter
5565	Indicat. A/T Shift LCD	Combination Meter
5566	Automatic High Beam Indicator	Combination Meter
5567	Indicat. Rear Door LH Open	Combination Meter
5568	Indicat. Lamp Turn L	Combination Meter
5569	Seatbelt Information Indicator	Combination Meter
5570	Indicat. Lithium Charge	Combination Meter
5571	Lithium Battery Hot Indicator	Combination Meter
5572	Lithium Battery Check Indicator	Combination Meter
5573	Power Window	RL-Door Motor
5574	PSD Close	Rear Left Door
5575	PSD Open	Rear Left Door
5576	PSD Open Signal	Rear Left Door
5577	PSD Motor	Rear Left Door
5578	PSD Buzzer	Rear Left Door
5579	PSD Clutch	Rear Left Door
5580	Inside Handle Illumination	Rear Left Door
5581	Power Window	Rear Left Door
5582	Rear Door Sunshade Up	Rear Left Door
5583	Rear Door Sunshade Down	Rear Left Door
5584	Mirror Heater	Rear Left Door
5585	Mirror Up/Down	Rear Left Door
5586	Mirror Right/Left	Rear Left Door
5587	Mirror Fold/Return	Rear Left Door
5588	Memory Cancel Lamp	Rear Left Door
5589	Memory Cancel Light	Rear Left Door
5590	Courtesy Lamp	Rear Left Door
5591	Courtesy Light	Rear Left Door
5592	Door Lock	Rear Left Door
5593	Release Actuator	Rear Left Door
5594	Double Lock Unset	Rear Left Door
5595	Foot Light	Rear Left Door
5596	Ashtray Light	Rear Left Door
5597	P Manual SW LED	Rear Left Door
5598	Seat Memory Light	Rear Left Door
5599	D seat foot lamp	Mirror L
5600	P seat foot lamp	Mirror L
5601	Interior Illumination Light	Mirror L
5602	P Mirror Right/Left	Mirror L

5603	Power Window SW LED	Mirror L
5604	Mirror Return	Mirror L
5605	Mirror Heater	Mirror L
5606	Mirror Up/Down	Mirror L
5607	P Mirror Up/Down	Mirror L
5608	Mirror Right/Left	Mirror L
5609	P Mirror Fold/Return	Mirror L
5610	Mirror Fold/Return	Mirror L
5611	D Mirror Heater	Mirror L
5612	D Mirror Right/Left	Mirror L
5613	P Foot Light	Mirror L
5614	Inside Handle Light	Mirror L
5615	Courtesy Light	Mirror L
5616	D Mirror Up/Down	Mirror L
5617	D Mirror Fold/Return	Mirror L
5618	Foot Light	Mirror L
5619	Ashtray Light	Mirror L
5620	Mirror Fold	Mirror L
5621	Cool air	Rear Left Seat A/C
5622	Warm air	Rear Left Seat A/C
5623	Airflow	Rear Left Seat A/C
5624	Seat Heater Target Temperature	Rear Left Seat A/C
5625	Neckrest Operation	Rear Left Seat
5626	refreshing sheet	Rear Left Seat
5627	Buzzer	Rear Left Seat
5628	Rear Seat Lumbar Adjustment	Rear Left Seat
5629	Slide sheet	Rear Left Seat
5630	Ottoman	Rear Left Seat
5631	Headrest Operation	Rear Left Seat
5632	Refreshing ECU	Rear Left Seat
5633	Necklace To	Rear Left Seat
5634	Seat Slide Operation	Rear Left Seat
5635	Seat Reclining	Rear Left Seat
5636	Interior Illumination Light	Front Left Door
5637	Power Window SW LED	Front Left Door
5638	Mirror Return	Front Left Door
5639	Mirror Heater	Front Left Door
5640	Mirror Up/Down	Front Left Door
5641	Mirror Right/Left	Front Left Door
5642	Mirror Fold/Return	Front Left Door
5643	P Foot Light	Front Left Door
5644	Inside Handle Light	Front Left Door
5645	Courtesy Light	Front Left Door
5646	Foot Light	Front Left Door
5647	Ashtray Light	Front Left Door
5648	Mirror Fold	Front Left Door
5649	Cool air	Front Left Seat A/C
5650	Warm air	Front Left Seat A/C
5651	Airflow	Front Left Seat A/C
5652	Seat Heater Target Temperature	Front Left Seat A/C
5653	PCS Buzzer Request	PCS/LDA/RSA/LVN

5654	Automatic High Beam	PCS/LDA/RSA/LVN
5655	Meter Buzzer Request	PCS/LDA/RSA/LVN
5656	LVN Indicator	PCS/LDA/RSA/LVN
5657	LVN Buzzer Request	PCS/LDA/RSA/LVN
5658	LVN HMI Request	PCS/LDA/RSA/LVN
5659	RSA Simple Display Request	PCS/LDA/RSA/LVN
5660	PCS Buzzer	Front Recognition Camera
5661	Color Test Screen	Head Up Display
5662	Main Indicator	Head Up Display
5663	Navigation Indicator	Head Up Display
5664	Display Brightness	Head Up Display
5665	Display Position	Head Up Display
5666	RSA Simple Display Request	Road Sign Assist
5667	RH Motor	TVD
5668	LH Motor	TVD

Code	Function
1	Check mode
2	VIN
3	Electric Throttle Learning
4	
5	HICM Resistance Learning Value
6	Chassis Dynamometer Mode
7	A/T Code Reset
8	CVT oil pressure Calibration
9	Deceleration Sensor Zero Point
0A	Air bleeding
0B	Signal Check
0C	Test Mode
0D	ECB-R Utility
0E	ECB Utility
0F	Refrigerant Gas Volume Check
10	Servo motor initialization
11	Abnormal Operation History
12	Torque Sensor Adjustment
13	Initialization
14	Wireless Code Erasure
15	Wireless Code Registrat
16	Transponder Code Registration
17	Transponder Code Erasure
18	Height Offset
19	Steering Angle Adjust
1A	Communica Check(Key Diag Mode)
1B	ECU Communication ID
1C	Key Code Erasure
1D	Key Code Registration
1E	Steering Initialization
1F	Auto Power OFF Cancel
20	ID Registration
21	Learning Value Reset
22	Beam Axis Misalignment Reading
23	Beam Axis Adjustment
24	Laser/Radar Cruise Initialization
25	ECU Exchange
26	Sensitivity Check
27	Zero Point Calibration & Sensitivity
28	Zero Point Calibration
29	Fuel Density Learning Value Reset
2A	Control mode change
2B	Steering Sensor Initialization
2C	Stabilizer System Check
2D	Trouble Factor Code Clear
2E	Recog ECU H Temp Hist Reset
2F	Smart Code Reset

30	Rear Wing Zero Point Calibration
31	ASG System Initial Learning
32	Activate Rear Steering Motor
33	DRS Off-center Correction
34	BSM Master Abnormal History
35	DRS Neutral Memorization
36	VSC Sensor Neutral Memorization
37	Recognition Camera/Target
38	Recognition Camera Axis Adjust
39	A/T Code Registration
3A	Injector Compensation
3B	Supply Pump Initialization
3C	Catalyst Record Clear
3D	DPF Deterioration Record Clear
3E	A/F Sensor Compensation Reset
3F	Crank Time Compensation Reset
40	Pilot Quantity Learning Values
41	i-ART Learning Value Reset
42	Left Front Side Radar Optical Axis
43	Right Front Side Radar Optical Axis
44	Number of Times the Starter
45	Air Conditioning Information
46	Acceleration Sensor Zero Point
47	Acceleration Sensor Zero Point
48	Camera/Target Position Memory
49	Camera Axis Adjust
4A	Rear Radar Optical Axis
4B	Engine Control Values Initialization
4C	G Sensor Zero Point Learning
4D	CVT Hydraulic Pump Bleed
4E	Wide Inter-cylinder Correction
4F	Shift Control Synchronization
50	Wireless Door Lock Diagnosis
51	Auto Registration Closure
52	Key Number Change
53	Key Number Registration
54	Pressure Discharge Value Check
55	Pilot Quantity Learning Value Clear
56	Pilot Quantity Learning
57	Learning Value Confirmation
58	Camera Auto Adjustment
59	Camera Manual Adjustment
5A	Auxiliary Battery Exchange
5B	DCM Mode Setting
5C	ASG System Initial Learning
5D	HV Batt Cell Low Volt READY ON
5E	Temporary Vehicle Start Up
5F	B1 Air Bleeding
60	Grill Shutter Control Mode

61	Second Air Bleeding
62	Sensor Check Function
63	Rear Radar Sensor Check
64	Starter Actuation Count Utility
65	Sensor adjustment
66	Battery Discharge
67	System Calibration
68	Wireless Diagnosis Mode
69	AMT Setting Change
6A	ITC initialization parameters
6B	Height Sensor Initialization
6C	Supply Pump Learning Value
6D	A/T unit corrected(initialization)
6E	Electronic control brake support
6F	Normal Battery Stack Average
70	battery status info update
71	battery diagnosis
72	prediagnosis battery charge
73	Inter-ECU ID Registration
74	Key Registration
75	Key No.New Registration
76	Pilot Quantity Learning(Detail)
77	Parts Exchange
78	Pressure Release
79	Diagnosis recorder information
7A	ECU exchange
7B	Starter exchange
7C	Reset the Mobile Information
7D	Bluetooth Communication Module
7E	BSM Master Beam Axis Inspection
7F	ECB 2.5 Utility
80	Reclined Position Storage
81	Battery Pack Malfunction Fail-Safe
82	Remote door lock setting
83	Vehicle Mileage Write
84	Engine Oil Pressure Control Check
85	Differential Pressure Learning
86	Swirl Valve Learning Value Reset
87	O2 Sensor Learning Value Reset
88	Idle Speed Adjustment
89	DPF Rejuvenation Timing Reset
8A	Air Flow Meter Learning Value
8B	Upstream Turbine Pressure
8C	NOx Storage Catalyst Learning
8D	Fuel PCV Compensation Value
8E	EGR Learning Value Reset
8F	DPF History Information Reset
90	Glow Control Unit Inspection
91	Learning Values Confirmation

92	Supply Pump Learning Value reset
93	Switch Oil Maintenance Display
94	iMT Installation Information Reset
95	Switch Battery Type
96	Deceleration Sensor Zero Point
97	CVT Oil Pressure Calibration
98	ATF Thermal Degradation Estimate
99	VSC/TR(A)C/4WD Control
9A	4WD Control Prevention Mode
9B	Map Information
9C	Video Device Connection Check
9D	Remote Engine Starter ID
9E	Remote Engine Starter Initial
9F	Blower Motor Brush Wear Amount
A0	2nd Sys. Air Bleeding
A1	3rd Sys. Air Bleeding
A2	Return to Normal Mode
A3	Antenna Communication Check
A4	Key Status
A5	Key Free ECU Parameter Change
A6	CVT ECU Initial Learning
A7	Initial learning
A8	Starter operating times
A9	Laser Beam Axis Adjustment
AA	Meter Specification Reset
AB	Seat Belt Reminder Setting
AC	Deceleration Sensor Zero Point
AD	Oil Pump Air Bleeding
AE	Total Number of Engine Starts
AF	Integrated Current Value
B0	Reset A/C Information

V11.56 add special function code: AC-B0

Ford Function List V10.31

Notes:

✓	Functions is fully supported and already existed in former software version.
*	Functions is fully supported and newly added in current software version.
#	Functions is partially supported , which means the functions is verified on some vehcile models or systems and it might supports other vehcle models or systems.
	Functions left with blank is not supported.

Year	Mode	Capacity	EngineType	Module	Read Codes	Erase Codes	Live Data	Active Test	Special Function
2005	(A1105)	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2005	(A1105)	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2005	(A1105)	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2005	(A1105)	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2005	(A1105)	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2005	(A1105)	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2005	(A1105)	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2005	(A1105)	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2005	(A1105)	3. 0L	4V	4X4	✓	✓	✓	✓	
2005	(A1105)	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2005	(A1105) Escape/Tribute/Maverick/Mariner	3. 0L	4V	GEM	✓	✓	✓	✓	F042, F04E, F04F, F050, F051, F056, F057, F058, F059
2005	(A1105) Escape/Tribute/Maverick/Mariner	3. 0L	4V	GEM	✓	✓	✓	✓	F042, F04E, F04F, F050, F051, F056, F057, F058, F059, F090
2005	(A1105) Escape/Tribute/Maverick/Mariner	3. 0L	4V	IC	✓	✓	✓	✓	0005, F040, F043, F04D, F052, F053, F054, F055
2005	(A1105)	3. 0L	4V	PAM	✓	✓	✓	✓	
2005	(A1105)	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 00C5
2005	(A1105)	3. 0L	4V	RCM	✓	✓	✓	✓	000C
1997	626 / 626 WAGON / TELSTAR	1. 8L	FP	PCM	✓	✓	✓	✓	0025
1997	626 / 626 WAGON / TELSTAR	2. 0L	FS	ABS	✓	✓	✓	✓	
1997	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	
1997	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	0025
1997	626 / 626 WAGON / TELSTAR	2. 0L	RF-T	PCM	✓	✓	✓	✓	
1997	626 / 626 WAGON / TELSTAR	2. 5L	KL	PCM	✓	✓	✓	✓	
1998	626 / 626 WAGON / TELSTAR	2. 0L	FS	ABS/TCS	✓	✓	✓	✓	
1998	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	0025
1998	626 / 626 WAGON / TELSTAR	2. 5L	KL	ABS/TCS	✓	✓	✓	✓	
1998	626 / 626 WAGON / TELSTAR	2. 5L	KL	PCM	✓	✓	✓	✓	0025
1999	626 / 626 WAGON / TELSTAR	1. 8L	FP	ABS	✓	✓	✓	✓	
1999	626 / 626 WAGON / TELSTAR	1. 8L	FP	PCM	✓	✓	✓	✓	
1999	626 / 626 WAGON / TELSTAR	2. 0L	FS	ABS	✓	✓	✓	✓	
1999	626 / 626 WAGON / TELSTAR	2. 0L	FS	ABS/TCS	✓	✓	✓	✓	
1999	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	
1999	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	0025
1999	626 / 626 WAGON / TELSTAR	2. 0L	RF-T	ABS	✓	✓	✓	✓	
1999	626 / 626 WAGON / TELSTAR	2. 0L	RF-T	PCM	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	1. 8L	FP	ABS/TCS	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	1. 8L	FP	PCM	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	2. 0L	FS	ABS/TCS	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	0025
2000	626 / 626 WAGON / TELSTAR	2. 0L	RF-T	ABS	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	2. 0L	RF-T	PCM	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	2. 5L	KL	ABS/TCS	✓	✓	✓	✓	
2000	626 / 626 WAGON / TELSTAR	2. 5L	KL	PCM	✓	✓	✓	✓	0025
2001	626 / 626 WAGON / TELSTAR	2. 0L	FS	ABS/TCS	✓	✓	✓	✓	
2001	626 / 626 WAGON / TELSTAR	2. 0L	FS	PCM	✓	✓	✓	✓	0025
2001	626 / 626 WAGON / TELSTAR	2. 5L	KL	ABS/TCS	✓	✓	✓	✓	
2001	626 / 626 WAGON / TELSTAR	2. 5L	KL	PCM	✓	✓	✓	✓	0025
1996	AEROSTAR	3. 0L	Other	PCM	✓	✓	✓	✓	0025
1996	AEROSTAR	4. 0L	Other	PCM	✓	✓	✓	✓	0025
1997	AEROSTAR	3. 0L	Other	PCM	✓	✓	✓	✓	0025
1997	AEROSTAR	4. 0L	Other	PCM	✓	✓	✓	✓	0025
1996	Aspire	1. 3L	Other	PCM	✓	✓	✓	✓	
1997	Aspire	1. 3L	Other	PCM	✓	✓	✓	✓	
1997	Aspire	1. 5L	Other	PCM	✓	✓	✓	✓	0025
2003	Aviator	4. 6L	4V	4X4	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Aviator	4. 6L	4V	DCSM	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	DSM	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	EATC	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	IC	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	NAV	✓	✓	✓	✓	0016
2003	Aviator	4. 6L	4V	PAM	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Aviator	4. 6L	4V	PCSM	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	RCM	✓	✓	✓	✓	000C
2003	Aviator	4. 6L	4V	TPM	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	VAPS	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	VEMS	✓	✓	✓	✓	
2003	Aviator	4. 6L	4V	VSM	✓	✓	✓	✓	
2004	Aviator	4. 6L	4V	4X4	✓	✓	✓	✓	
2004	Aviator	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2004	Aviator	4. 6L	4V	DCSM	✓	✓	✓	✓	
2004	Aviator	4. 6L	4V	DSM	✓	✓	✓	✓	

2004	Aviator	4.6L	4V	EATC	✓	✓	✓	✓	
2004	Aviator	4.6L	4V	IC	✓	✓	✓	✓	
2004	Aviator	4.6L	4V	NAV	✓	✓	✓	✓	0016
2004	Aviator	4.6L	4V	PAM	✓	✓	✓	✓	
2004	Aviator	4.6L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Aviator	4.6L	4V	PSCM	✓	✓	✓	✓	
2004	Aviator	4.6L	4V	RCM	✓	✓	✓	✓	000C
2004	Aviator	4.6L	4V	TPM	✓	✓	✓	✓	
2004	Aviator	4.6L	4V	VAPS	✓	✓	✓	✓	
2004	Aviator	4.6L	4V	VSM	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	4X4	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2005	Aviator	4.6L	4V	DCSM	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	DSM	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	EATC	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	IC	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	NAV	✓	✓	✓	✓	0016
2005	Aviator	4.6L	4V	PAM	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Aviator	4.6L	4V	PSCM	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	RCM	✓	✓	✓	✓	000C
2005	Aviator	4.6L	4V	TPM	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	VAPS	✓	✓	✓	✓	
2005	Aviator	4.6L	4V	VSM	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	ABS	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	FCDIM	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	IPC	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	PSCM	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	RFA	✓	✓	✓	✓	
2008.75	B-Max	1.25L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	ABS	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	FCDIM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	IPC	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	PSCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	RFA	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2008.75	B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	FCDIM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2008.75	B-Max	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	

2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓		
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓		
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓		
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓		
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓		
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓		
2008.75	B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓		
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D7, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00FE, 0101, 0118
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00D7, 00DC
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00DC
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF
2012.75	B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	APIM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	BCMii	✓	✓	✓	✓	00FE, 0101, 0118
2012.75	B-Max	1.4L	DURATEC 16V	DDM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	FCDIM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	FDSM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	GPSM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	GWM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	IPC	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	00BC
2012.75	B-Max	1.4L	DURATEC 16V	PDM	✓	✓	✓	✓	
2012.75	B-Max	1.4L	DURATEC 16V	PSCM	✓	✓	✓	✓	00D7, 00DC
2012.75	B-Max	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	00EF
2012.75	B-Max	1.4L	DURATEC 16V	RFA	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D7, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 00D9, 00DB, 00E8, 0119

2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	00FE, 0101, 0118
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	FDSM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	GPSM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	GWM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00BD
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00D7, 00DC
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00DC
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF
2012.75	B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	APIM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	00FE, 0101, 0118
2012.75	B-Max	1.6L	DURATEC VCT	DDM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	FCDIM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	FDSM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	GPSM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	GWM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	00BC
2012.75	B-Max	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	00D7, 00DC
2012.75	B-Max	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	00EF
2012.75	B-Max	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2012.75	B-Max	1.6L	DURATEC VCT	TCM	✓	✓	✓	✓	0117
2012.75	B-Max	1.6L	TDCi ECO II	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D7, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.6L	TDCi ECO II	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2012.75	B-Max	1.6L	TDCi ECO II	ACM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	APIM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	BCMii	✓	✓	✓	✓	00FE, 0101, 0118
2012.75	B-Max	1.6L	TDCi ECO II	DDM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	FCDIM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	FDSM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	GPSM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	GWM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	HVAC	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	IPC	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00BD
2012.75	B-Max	1.6L	TDCi ECO II	PDM	✓	✓	✓	✓	
2012.75	B-Max	1.6L	TDCi ECO II	PSCM	✓	✓	✓	✓	00D7, 00DC
2012.75	B-Max	1.6L	TDCi ECO II	PSCM	✓	✓	✓	✓	00DC
2012.75	B-Max	1.6L	TDCi ECO II	RCM	✓	✓	✓	✓	00EF
2012.75	B-Max	1.6L	TDCi ECO II	RFA	✓	✓	✓	✓	
1996	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.2L	F2	PCM	✓	✓	✓	✓	
1996	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	PCM	✓	✓	✓	✓	
1999	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.2L	F2	PCM	✓	✓	✓	✓	
1999	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	ABS	✓	✓	✓	✓	
1999	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	PCM	✓	✓	✓	✓	
2001	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	ABS	✓	✓	✓	✓	
2001	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	PCM	✓	✓	✓	✓	

2001	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	ABS	✓	✓	✓	✓	
2001	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	PCM	✓	✓	✓	✓	
2002	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL	ABS	✓	✓	✓	✓	
2002	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	ABS	✓	✓	✓	✓	
2002	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 9L	W9	ABS	✓	✓	✓	✓	
2005	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	ABS	✓	✓	✓	✓	
2005	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	PCM	✓	✓	✓	✓	
2005	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	TCM	✓	✓	✓	✓	
Other	B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 2L	F2	PCM	✓	✓	✓	✓	
1999	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	ABS	✓	✓	✓	✓	
1999	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	PCM	✓	✓	✓	✓	
1999	BONGO / BONGO BRAWNY / SPECTRON	2. 2L	R2	ABS	✓	✓	✓	✓	
1999	BONGO / BONGO BRAWNY / SPECTRON	2. 2L	R2	PCM	✓	✓	✓	✓	
2002	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	ABS/TCS	✓	✓	✓	✓	
2002	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	PCM	✓	✓	✓	✓	
2002	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	TCM	✓	✓	✓	✓	
2003	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	ABS/TCS	✓	✓	✓	✓	
2003	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	PCM	✓	✓	✓	✓	
2003	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	TCM	✓	✓	✓	✓	
2004	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	ABS/TCS	✓	✓	✓	✓	
2004	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	PCM	✓	✓	✓	✓	
2004	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	TCM	✓	✓	✓	✓	
2007	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	ABS/TCS	✓	✓	✓	✓	
2007	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	PCM	✓	✓	✓	✓	0055, 0056, 005C
2007	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	PCM	✓	✓	✓	✓	0055, 005C
2007	BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	TCM	✓	✓	✓	✓	
2010	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	ABS	✓	✓	✓	✓	
2010	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	IC	✓	✓	✓	✓	
2010	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	PCM	✓	✓	✓	✓	
2010	BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	TCM	✓	✓	✓	✓	
1997	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	ABS	✓	✓	✓	✓	
1997	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	PCM	✓	✓	✓	✓	
1998	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	ABS	✓	✓	✓	✓	
1998	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	PCM	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	1. 8L	F8	ABS	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	1. 8L	F8	PCM	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	ABS	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	PCM	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 2L	R2	ABS	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 2L	R2	PCM	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 5L	WL	ABS	✓	✓	✓	✓	
1999	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 5L	WL	PCM	✓	✓	✓	✓	
2002	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	ABS/TCS	✓	✓	✓	✓	
2002	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	PCM	✓	✓	✓	✓	
2002	BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	TCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 2L	F2	ABS/TCS	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 2L	F2	PCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 2L	F2	RCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL	ABS/TCS	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL	PCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL	RCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL-CD	ABS/TCS	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL-CD	PCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL-CD	PCM	✓	✓	✓	✓	0055
2007	BT-50 / Ranger	2. 5L	WL-CD	RCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL-CD	TCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 5L	WL-CD	TCM	✓	✓	✓	✓	00C5, 00CE
2007	BT-50 / Ranger	2. 6L	G6	ABS/TCS	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 6L	G6	PCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	2. 6L	G6	RCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	3. 0L	WE-CD	ABS/TCS	✓	✓	✓	✓	
2007	BT-50 / Ranger	3. 0L	WE-CD	PCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	3. 0L	WE-CD	PCM	✓	✓	✓	✓	0055, 0092
2007	BT-50 / Ranger	3. 0L	WE-CD	RCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	3. 0L	WE-CD	TCM	✓	✓	✓	✓	

2007	BT-50 / Ranger	3.0L	WE-CD	TCM	✓	✓	✓	✓	00C5, 00CE
2007	BT-50 / Ranger	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2007	BT-50 / Ranger	4.0L	V6 SOHC	ESOF	✓	✓	✓	✓	
2007	BT-50 / Ranger	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	
2007	BT-50 / Ranger	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2012	BT-50 / Ranger	2.5L	L5	PCM	✓	✓	✓	✓	
2001	Bantam	1.3L	Zetec Rocam	PCM	✓	✓	✓	✓	
2001	Bantam	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	
2006	Bantam	1.3L	Zetec Rocam	PCM	✓	✓	✓	✓	
2006	Bantam	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	
2009. 25	Bantam	1.4L	Duratorq Turbo Diesel Common Rail Injection	TC	✓	✓	✓	✓	
2009. 25	Bantam	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2009. 25	Bantam	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	ABS/TCS	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	DSM	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	EATC	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	GEM	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	HEC	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	LTM	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	PAM	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	PCM	✓	✓	✓	✓	0025
2002	Blackwood	5.4L	4V	RAP	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	RASM	✓	✓	✓	✓	
2002	Blackwood	5.4L	4V	RCM	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	ABS/TCS	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	DSM	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	EATC	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	GEM	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	HEC	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	LTM	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	PAM	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	PCM	✓	✓	✓	✓	0025
2003	Blackwood	5.4L	4V	RAP	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	RASM	✓	✓	✓	✓	
2003	Blackwood	5.4L	4V	RCM	✓	✓	✓	✓	
2012	Blue Bird C-Class Vision	6.8L	3V	PCM	✓	✓	✓	✓	0067
1996	Bronco	5.0L	Other	PCM	✓	✓	✓	✓	0025
1996	Bronco	5.8L	Other	PCM	✓	✓	✓	✓	0025
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	ABS	✓	✓	✓	✓	0012, 010A
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	ACM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	APIM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	BCM#1	✓	✓	✓	✓	00D5
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	BECM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	DACM-C	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	DCDC	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	DDM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	FCDIM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	FCIM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	GPSM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	GWM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	HVAC	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	IPC	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	IPM-B	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	PAM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	PCM	✓	✓	✓	✓	0025, 0095
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	PDM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	PSCM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	RCM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	RFA	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	RGTM	✓	✓	✓	✓	013D

2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	SASM	✓	✓	✓	✓	
2013	C-MAX	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	✓	✓	✓	✓	013C
2013	C-MAX	2.0L	PHEV	ABS	✓	✓	✓	✓	0012, 010A
2013	C-MAX	2.0L	PHEV	ACCM#2	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	ACM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	APIM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	BCM#1	✓	✓	✓	✓	00D5
2013	C-MAX	2.0L	PHEV	BECM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	DACM-C	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	DCDC	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	DDM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	FCDIM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	FCIM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	GFM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	GPSM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	GWM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	HVAC	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	IPC	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	IPM-B	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	OCSM	✓	✓	✓	✓	000C
2013	C-MAX	2.0L	PHEV	PAM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	PCM	✓	✓	✓	✓	0025
2013	C-MAX	2.0L	PHEV	PDM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	PSCM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	RCM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	RFA	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	RGTM	✓	✓	✓	✓	013D
2013	C-MAX	2.0L	PHEV	SASM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	SOBDM	✓	✓	✓	✓	
2013	C-MAX	2.0L	PHEV	SOBDM-C	✓	✓	✓	✓	013C
2013	C-MAX	2.0L	PHEV	TCU#1	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	ABS	✓	✓	✓	✓	0012, 010A
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	ACM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	APIM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	BCM#1	✓	✓	✓	✓	00D5, 0101, 020F
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	BECM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	DACM-C	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	DCDC	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	DDM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	FCDIM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	FCIM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	GPSM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	GWM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	HVAC	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	IPC	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	IPM-B	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	PAM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	PCM	✓	✓	✓	✓	0025
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	PDM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	PSCM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	RCM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	RFA	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	RGTM	✓	✓	✓	✓	013D
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	SASM	✓	✓	✓	✓	
2014	C-MAX	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	✓	✓	✓	✓	013C
2014	C-MAX	2.0L	PHEV	ABS	✓	✓	✓	✓	0012, 010A
2014	C-MAX	2.0L	PHEV	ACCM#2	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	ACM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	APIM	✓	✓	✓	✓	

2014	C-MAX	2.0L	PHEV	BCM#1	✓	✓	✓	✓	00D5, 0101, 020F
2014	C-MAX	2.0L	PHEV	BECM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	DACM-C	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	DCDC	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	DDM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	FCDIM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	FCIM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	GFM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	GPSM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	GWM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	HVAC	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	IPC	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	IPM-B	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	OCSM	✓	✓	✓	✓	000C
2014	C-MAX	2.0L	PHEV	PAM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	PCM	✓	✓	✓	✓	0025
2014	C-MAX	2.0L	PHEV	PDM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	PSCM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	RCM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	RFA	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	RGTM	✓	✓	✓	✓	013D
2014	C-MAX	2.0L	PHEV	SASM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	SOBDM	✓	✓	✓	✓	
2014	C-MAX	2.0L	PHEV	SOBDM-C	✓	✓	✓	✓	013C
2014	C-MAX	2.0L	PHEV	TCU#1	✓	✓	✓	✓	
1997	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	1.8L	FP	PCM	✓	✓	✓	✓	
1997	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	FS	PCM	✓	✓	✓	✓	
1997	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	RF	PCM	✓	✓	✓	✓	
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	1.8L	FP	ABS	✓	✓	✓	✓	
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	1.8L	FP	PCM	✓	✓	✓	✓	
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	FS	ABS	✓	✓	✓	✓	
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	FS	PCM	✓	✓	✓	✓	
1999	CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.5L	KL	ABS	✓	✓	✓	✓	
2006	CF/LCF	4.5L	Direct Injection -	ABS	✓	✓	✓	✓	
2006	CF/LCF	4.5L	Direct Injection -	ABS	✓	✓	✓	✓	0008
2006	CF/LCF	4.5L	Direct Injection -	TCM	✓	✓	✓	✓	
2007	CF/LCF	4.5L	Direct Injection -	ABS	✓	✓	✓	✓	0008
2007	CF/LCF	4.5L	Direct Injection -	TCM	✓	✓	✓	✓	
2008	CF/LCF	4.5L	Direct Injection -	ABS	✓	✓	✓	✓	
2008	CF/LCF	4.5L	Direct Injection -	ABS	✓	✓	✓	✓	0008
2008	CF/LCF	4.5L	Direct Injection -	TCM	✓	✓	✓	✓	
2009	CF/LCF	4.5L	Direct Injection -	ABS	✓	✓	✓	✓	0008
2009	CF/LCF	4.5L	Direct Injection -	TCM	✓	✓	✓	✓	
2004	Cargo	7.3L	ECOTORQ	PCM	✓	✓	✓	✓	
2009	Cargo	Other	ISBe	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	Cargo	Other	ISCe	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	Cargo	Other	Mechanical	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Cargo	Other	ISBe	HEC	✓	✓	✓	✓	
2012	Cargo	Other	ISBe	RKE	✓	✓	✓	✓	
2012	Cargo	Other	ISBe	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3, 012F, 0130
2012	Cargo	Other	ISCe	HEC	✓	✓	✓	✓	
2012	Cargo	Other	ISCe	RKE	✓	✓	✓	✓	
2012	Cargo	Other	ISCe	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3, 012F, 0130
2012	Cargo	Other	Mechanical	HEC	✓	✓	✓	✓	
2012	Cargo	Other	Mechanical	RKE	✓	✓	✓	✓	
2012	Cargo	Other	Mechanical	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3, 012F, 0130
1995	Continental	4.6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1995	Continental	4.6L	4V	ACM	✓	✓	✓	✓	
1995	Continental	4.6L	4V	CPM	✓	✓	✓	✓	
1995	Continental	4.6L	4V	DDM	✓	✓	✓	✓	
1995	Continental	4.6L	4V	DSM	✓	✓	✓	✓	
1995	Continental	4.6L	4V	EATC	✓	✓	✓	✓	
1995	Continental	4.6L	4V	LCM	✓	✓	✓	✓	
1995	Continental	4.6L	4V	PCM	✓	✓	✓	✓	0025
1995	Continental	4.6L	4V	VDM	✓	✓	✓	✓	
1995	Continental	4.6L	4V	VIC	✓	✓	✓	✓	
1996	Continental	4.6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1996	Continental	4.6L	4V	ACM	✓	✓	✓	✓	
1996	Continental	4.6L	4V	CPM	✓	✓	✓	✓	
1996	Continental	4.6L	4V	DDM	✓	✓	✓	✓	
1996	Continental	4.6L	4V	DSM	✓	✓	✓	✓	
1996	Continental	4.6L	4V	EATC	✓	✓	✓	✓	
1996	Continental	4.6L	4V	IAB	✓	✓	✓	✓	
1996	Continental	4.6L	4V	LCM	✓	✓	✓	✓	
1996	Continental	4.6L	4V	PCM	✓	✓	✓	✓	0025
1996	Continental	4.6L	4V	RESCU	✓	✓	✓	✓	
1996	Continental	4.6L	4V	VDM	✓	✓	✓	✓	
1996	Continental	4.6L	4V	VIC	✓	✓	✓	✓	

1997	Continental	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1997	Continental	4. 6L	4V	ACM	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	CPM	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	DDM	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	DSM	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	EATC	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	IAB	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	LCM	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	PCM	✓	✓	✓	✓	0025
1997	Continental	4. 6L	4V	RESCU	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	VDM	✓	✓	✓	✓	
1997	Continental	4. 6L	4V	VIC	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1998	Continental	4. 6L	4V	ACM	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	CPM	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	DDM	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	DSM	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	EATC	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	ECS	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	LCM	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	NGSC	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	PCM	✓	✓	✓	✓	0025
1998	Continental	4. 6L	4V	RESCU	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	VDM	✓	✓	✓	✓	
1998	Continental	4. 6L	4V	VIC	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1999	Continental	4. 6L	4V	ACM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	CPM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	DDM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	DSM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	EATC	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	LCM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	NGSC	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	PCM	✓	✓	✓	✓	0025
1999	Continental	4. 6L	4V	RCM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	RESCU	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	VDM	✓	✓	✓	✓	
1999	Continental	4. 6L	4V	VIC	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2000	Continental	4. 6L	4V	ACM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	CPM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	DDM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	DSM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	EATC	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	LCM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	NGSC	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	PCM	✓	✓	✓	✓	0025
2000	Continental	4. 6L	4V	RCM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	RESCU	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	VDM	✓	✓	✓	✓	
2000	Continental	4. 6L	4V	VIC	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2002	Continental	4. 6L	4V	ACM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	CPM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	DDM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	DSM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	EATC	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	LCM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	NGSC	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	PCM	✓	✓	✓	✓	0025
2002	Continental	4. 6L	4V	RCM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	VDM	✓	✓	✓	✓	
2002	Continental	4. 6L	4V	VIC	✓	✓	✓	✓	
1996	Contour	2. 0L	GFP	ABS/TCS	✓	✓	✓	✓	
1996	Contour	2. 0L	GFP	PCM	✓	✓	✓	✓	0025
1996	Contour	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1996	Contour	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
1996	Contour	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1996	Contour	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1997	Contour	2. 0L	GFP	ABS/TCS	✓	✓	✓	✓	
1997	Contour	2. 0L	GFP	PCM	✓	✓	✓	✓	0025
1997	Contour	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1997	Contour	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
1997	Contour	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1997	Contour	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1998	Contour	2. 0L	GFP	ABS/TCS	✓	✓	✓	✓	
1998	Contour	2. 0L	GFP	ABS/TCS	✓	✓	✓	✓	0008
1998	Contour	2. 0L	GFP	CSM	✓	✓	✓	✓	
1998	Contour	2. 0L	GFP	PATS	✓	✓	✓	✓	
1998	Contour	2. 0L	GFP	PCM	✓	✓	✓	✓	
1998	Contour	2. 0L	GFP	PCM	✓	✓	✓	✓	0025
1998	Contour	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1998	Contour	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
1998	Contour	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1998	Contour	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1998	Contour	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
1998	Contour	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1998	Contour	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
1998	Contour	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	

1998	Contour	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
1998	Contour	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1998	Contour	2.5L	HO	ABS/TCS	✓	✓	✓	✓	
1998	Contour	2.5L	HO	ABS/TCS	✓	✓	✓	✓	0008
1998	Contour	2.5L	HO	CSM	✓	✓	✓	✓	
1998	Contour	2.5L	HO	PATS	✓	✓	✓	✓	
1998	Contour	2.5L	HO	PCM	✓	✓	✓	✓	
1998	Contour	2.5L	HO	PCM	✓	✓	✓	✓	0025
1999	Contour	2.0L	GFP	ABS/TCS	✓	✓	✓	✓	0008
1999	Contour	2.0L	GFP	CSM	✓	✓	✓	✓	
1999	Contour	2.0L	GFP	PCM	✓	✓	✓	✓	
1999	Contour	2.0L	GFP	RCM	✓	✓	✓	✓	
1999	Contour	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
1999	Contour	2.0L	Zetec	CSM	✓	✓	✓	✓	
1999	Contour	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
1999	Contour	2.0L	Zetec	RCM	✓	✓	✓	✓	
1999	Contour	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
1999	Contour	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1999	Contour	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1999	Contour	2.5L	Duratec-VE	RCM	✓	✓	✓	✓	
1999	Contour	2.5L	HO	ABS/TCS	✓	✓	✓	✓	0008
1999	Contour	2.5L	HO	CSM	✓	✓	✓	✓	
1999	Contour	2.5L	HO	PCM	✓	✓	✓	✓	
1999	Contour	2.5L	HO	PCM	✓	✓	✓	✓	0025
1999	Contour	2.5L	HO	RCM	✓	✓	✓	✓	
2000	Contour	2.0L	GFP	ABS/TCS	✓	✓	✓	✓	0008
2000	Contour	2.0L	GFP	CSM	✓	✓	✓	✓	
2000	Contour	2.0L	GFP	PCM	✓	✓	✓	✓	
2000	Contour	2.0L	GFP	RCM	✓	✓	✓	✓	
2000	Contour	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2000	Contour	2.0L	Zetec	CSM	✓	✓	✓	✓	
2000	Contour	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2000	Contour	2.0L	Zetec	RCM	✓	✓	✓	✓	
2000	Contour	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
2000	Contour	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
2000	Contour	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2000	Contour	2.5L	Duratec-VE	RCM	✓	✓	✓	✓	
2000	Contour	2.5L	HO	ABS/TCS	✓	✓	✓	✓	0008
2000	Contour	2.5L	HO	CSM	✓	✓	✓	✓	
2000	Contour	2.5L	HO	PCM	✓	✓	✓	✓	0008
2000	Contour	2.5L	HO	PCM	✓	✓	✓	✓	0025
2000	Contour	2.5L	HO	RCM	✓	✓	✓	✓	
1994	Cougar	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1994	Cougar	4.6L	2V	HEC	✓	✓	✓	✓	
1994	Cougar	4.6L	2V	PCM	✓	✓	✓	✓	0025
1995	Cougar	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1995	Cougar	4.6L	2V	HEC	✓	✓	✓	✓	
1995	Cougar	4.6L	2V	PCM	✓	✓	✓	✓	0025
1996	Cougar	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1996	Cougar	3.8L	Other	HEC	✓	✓	✓	✓	
1996	Cougar	3.8L	Other	PCM	✓	✓	✓	✓	0025
1996	Cougar	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1996	Cougar	4.6L	2V	HEC	✓	✓	✓	✓	
1996	Cougar	4.6L	2V	PCM	✓	✓	✓	✓	0025
1997	Cougar	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1997	Cougar	3.8L	Other	HEC	✓	✓	✓	✓	
1997	Cougar	3.8L	Other	PCM	✓	✓	✓	✓	0025
1997	Cougar	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1997	Cougar	4.6L	2V	HEC	✓	✓	✓	✓	
1997	Cougar	4.6L	2V	PCM	✓	✓	✓	✓	0025
1998.75	Cougar	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1998.75	Cougar	2.0L	Zetec	CSM	✓	✓	✓	✓	
1998.75	Cougar	2.0L	Zetec	HEC	✓	✓	✓	✓	
1998.75	Cougar	2.0L	Zetec	IAB	✓	✓	✓	✓	
1998.75	Cougar	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
1998.75	Cougar	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1998.75	Cougar	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1998.75	Cougar	2.5L	Duratec-VE	HEC	✓	✓	✓	✓	
1998.75	Cougar	2.5L	Duratec-VE	IAB	✓	✓	✓	✓	
1998.75	Cougar	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1999	Cougar	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
1999	Cougar	2.0L	Zetec	CSM	✓	✓	✓	✓	
1999	Cougar	2.0L	Zetec	HEC	✓	✓	✓	✓	
1999	Cougar	2.0L	Zetec	IAB	✓	✓	✓	✓	
1999	Cougar	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
1999	Cougar	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
1999	Cougar	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1999	Cougar	2.5L	Duratec-VE	HEC	✓	✓	✓	✓	
1999	Cougar	2.5L	Duratec-VE	IAB	✓	✓	✓	✓	
1999	Cougar	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1999.75	Cougar	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
1999.75	Cougar	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1999.75	Cougar	2.5L	Duratec-VE	HEC	✓	✓	✓	✓	
1999.75	Cougar	2.5L	Duratec-VE	IAB	✓	✓	✓	✓	
1999.75	Cougar	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2000	Cougar	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2000	Cougar	2.0L	Zetec	CSM	✓	✓	✓	✓	
2000	Cougar	2.0L	Zetec	HEC	✓	✓	✓	✓	
2000	Cougar	2.0L	Zetec	IAB	✓	✓	✓	✓	

2000	Cougar	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
2000	Cougar	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
2000	Cougar	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
2000	Cougar	2. 5L	Duratec-VE	HEC	✓	✓	✓	✓	
2000	Cougar	2. 5L	Duratec-VE	IAB	✓	✓	✓	✓	
2000	Cougar	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2000. 5	Cougar	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	
2000. 5	Cougar	2. 0L	Zetec	CSM	✓	✓	✓	✓	
2000. 5	Cougar	2. 0L	Zetec	HEC	✓	✓	✓	✓	
2000. 5	Cougar	2. 0L	Zetec	IAB	✓	✓	✓	✓	
2000. 5	Cougar	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
2000. 5	Cougar	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
2000. 5	Cougar	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
2000. 5	Cougar	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
2000. 5	Cougar	2. 5L	Duratec-VE	HEC	✓	✓	✓	✓	
2000. 5	Cougar	2. 5L	Duratec-VE	IAB	✓	✓	✓	✓	
2000. 5	Cougar	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2001	Cougar	2. 5L	Duratec-VE	ABS	✓	✓	✓	✓	
2001	Cougar	2. 5L	Duratec-VE	IC	✓	✓	✓	✓	
2001	Cougar	2. 5L	Duratec-VE	MC	✓	✓	✓	✓	
2001	Cougar	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	
2001	Cougar	2. 5L	Duratec-VE	REM	✓	✓	✓	✓	
2002	Cougar	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2002	Cougar	2. 0L	Zetec	CSM	✓	✓	✓	✓	
2002	Cougar	2. 0L	Zetec	HEC	✓	✓	✓	✓	
2002	Cougar	2. 0L	Zetec	IAB	✓	✓	✓	✓	
2002	Cougar	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
2002	Cougar	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
2002	Cougar	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
2002	Cougar	2. 5L	Duratec-VE	HEC	✓	✓	✓	✓	
2002	Cougar	2. 5L	Duratec-VE	IAB	✓	✓	✓	✓	
2002	Cougar	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1995	Crown Victoria	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1995	Crown Victoria	4. 6L	2V	DDM	✓	✓	✓	✓	
1995	Crown Victoria	4. 6L	2V	DSM	✓	✓	✓	✓	
1995	Crown Victoria	4. 6L	2V	EATC	✓	✓	✓	✓	
1995	Crown Victoria	4. 6L	2V	LCM	✓	✓	✓	✓	
1995	Crown Victoria	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1995	Crown Victoria	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1995	Crown Victoria	4. 6L	Other	PCM	✓	✓	✓	✓	0025
1996	Crown Victoria	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1996	Crown Victoria	4. 6L	2V	DDM	✓	✓	✓	✓	
1996	Crown Victoria	4. 6L	2V	DSM	✓	✓	✓	✓	
1996	Crown Victoria	4. 6L	2V	EATC	✓	✓	✓	✓	
1996	Crown Victoria	4. 6L	2V	IAB	✓	✓	✓	✓	
1996	Crown Victoria	4. 6L	2V	LCM	✓	✓	✓	✓	
1996	Crown Victoria	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1996	Crown Victoria	4. 6L	2V NGV	ABS/TCS	✓	✓	✓	✓	0008
1996	Crown Victoria	4. 6L	2V NGV	DDM	✓	✓	✓	✓	
1996	Crown Victoria	4. 6L	2V NGV	DSM	✓	✓	✓	✓	
1996	Crown Victoria	4. 6L	2V NGV	FIM	✓	✓	✓	✓	
1996	Crown Victoria	4. 6L	2V NGV	IAB	✓	✓	✓	✓	
1996	Crown Victoria	4. 6L	2V NGV	LCM	✓	✓	✓	✓	
1996	Crown Victoria	4. 6L	2V NGV	PCM	✓	✓	✓	✓	
1997	Crown Victoria	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1997	Crown Victoria	4. 6L	2V	DDM	✓	✓	✓	✓	
1997	Crown Victoria	4. 6L	2V	DSM	✓	✓	✓	✓	
1997	Crown Victoria	4. 6L	2V	EATC	✓	✓	✓	✓	
1997	Crown Victoria	4. 6L	2V	IAB	✓	✓	✓	✓	
1997	Crown Victoria	4. 6L	2V	LCM	✓	✓	✓	✓	
1997	Crown Victoria	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1997	Crown Victoria	4. 6L	2V NGV	ABS/TCS	✓	✓	✓	✓	0008
1997	Crown Victoria	4. 6L	2V NGV	DDM	✓	✓	✓	✓	
1997	Crown Victoria	4. 6L	2V NGV	DSM	✓	✓	✓	✓	
1997	Crown Victoria	4. 6L	2V NGV	FIM	✓	✓	✓	✓	
1997	Crown Victoria	4. 6L	2V NGV	IAB	✓	✓	✓	✓	
1997	Crown Victoria	4. 6L	2V NGV	LCM	✓	✓	✓	✓	
1997	Crown Victoria	4. 6L	2V NGV	PCM	✓	✓	✓	✓	
1998	Crown Victoria	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1998	Crown Victoria	4. 6L	2V	DDM	✓	✓	✓	✓	
1998	Crown Victoria	4. 6L	2V	EATC	✓	✓	✓	✓	
1998	Crown Victoria	4. 6L	2V	ECS	✓	✓	✓	✓	
1998	Crown Victoria	4. 6L	2V	LCM	✓	✓	✓	✓	
1998	Crown Victoria	4. 6L	2V	PATS	✓	✓	✓	✓	
1998	Crown Victoria	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1998	Crown Victoria	4. 6L	2V NGV	ABS/TCS	✓	✓	✓	✓	0008
1998	Crown Victoria	4. 6L	2V NGV	DDM	✓	✓	✓	✓	
1998	Crown Victoria	4. 6L	2V NGV	EATC	✓	✓	✓	✓	
1998	Crown Victoria	4. 6L	2V NGV	ECS	✓	✓	✓	✓	
1998	Crown Victoria	4. 6L	2V NGV	FIM	✓	✓	✓	✓	
1998	Crown Victoria	4. 6L	2V NGV	LCM	✓	✓	✓	✓	
1998	Crown Victoria	4. 6L	2V NGV	PATS	✓	✓	✓	✓	
1998	Crown Victoria	4. 6L	2V NGV	PCM	✓	✓	✓	✓	
1998	Crown Victoria	4. 6L	2V NGV	PCM	✓	✓	✓	✓	0028, 0031, 0033
1999	Crown Victoria	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1999	Crown Victoria	4. 6L	2V	DDM	✓	✓	✓	✓	
1999	Crown Victoria	4. 6L	2V	EATC	✓	✓	✓	✓	
1999	Crown Victoria	4. 6L	2V	ECS	✓	✓	✓	✓	
1999	Crown Victoria	4. 6L	2V	LCM	✓	✓	✓	✓	

2007	Crown Victoria	4.6L	2V	FSSM	✓	✓	✓	✓	
2007	Crown Victoria	4.6L	2V	IC	✓	✓	✓	✓	0005
2007	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	
2007	Crown Victoria	4.6L	2V	MC	✓	✓	✓	✓	
2007	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Crown Victoria	4.6L	2V	RCM	✓	✓	✓	✓	000C
2007	Crown Victoria	4.6L	2V	VDM	✓	✓	✓	✓	0005, 0013, 0014
2008	Crown Victoria	4.6L	2V	ABS	✓	✓	✓	✓	0008
2008	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	0005, 0042, F044, F04C, F06A
2008	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	0042
2008	Crown Victoria	4.6L	2V	FSSM	✓	✓	✓	✓	
2008	Crown Victoria	4.6L	2V	HVAC	✓	✓	✓	✓	
2008	Crown Victoria	4.6L	2V	IC	✓	✓	✓	✓	0005
2008	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	F042, F043
2008	Crown Victoria	4.6L	2V	MC	✓	✓	✓	✓	
2008	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Crown Victoria	4.6L	2V	RCM	✓	✓	✓	✓	000C
2008	Crown Victoria	4.6L	2V	VDM	✓	✓	✓	✓	0005, 0013, 0014
2009	Crown Victoria	4.6L	2V	ABS	✓	✓	✓	✓	0008
2009	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	0042
2009	Crown Victoria	4.6L	2V	FSSM	✓	✓	✓	✓	
2009	Crown Victoria	4.6L	2V	HVAC	✓	✓	✓	✓	
2009	Crown Victoria	4.6L	2V	IC	✓	✓	✓	✓	
2009	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	
2009	Crown Victoria	4.6L	2V	MC	✓	✓	✓	✓	
2009	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Crown Victoria	4.6L	2V	RCM	✓	✓	✓	✓	000C
2009	Crown Victoria	4.6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2010	Crown Victoria	4.6L	2V	ABS	✓	✓	✓	✓	0008
2010	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	0042
2010	Crown Victoria	4.6L	2V	FSSM	✓	✓	✓	✓	
2010	Crown Victoria	4.6L	2V	HVAC	✓	✓	✓	✓	
2010	Crown Victoria	4.6L	2V	IC	✓	✓	✓	✓	
2010	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	
2010	Crown Victoria	4.6L	2V	MC	✓	✓	✓	✓	
2010	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2010	Crown Victoria	4.6L	2V	RCM	✓	✓	✓	✓	000C
2010	Crown Victoria	4.6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2011	Crown Victoria	4.6L	2V	ABS	✓	✓	✓	✓	0008
2011	Crown Victoria	4.6L	2V	DDM	✓	✓	✓	✓	0042
2011	Crown Victoria	4.6L	2V	FSSM	✓	✓	✓	✓	
2011	Crown Victoria	4.6L	2V	HVAC	✓	✓	✓	✓	
2011	Crown Victoria	4.6L	2V	IC	✓	✓	✓	✓	
2011	Crown Victoria	4.6L	2V	LCM	✓	✓	✓	✓	
2011	Crown Victoria	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Crown Victoria	4.6L	2V	RCM	✓	✓	✓	✓	000C
2011	Crown Victoria	4.6L	2V	VDM	✓	✓	✓	✓	0013, 0014
1996	DEMIO / FESTIVA MINI WAGON	1.3L	B3	ABS	✓	✓	✓	✓	
1996	DEMIO / FESTIVA MINI WAGON	1.3L	B3	PCM	✓	✓	✓	✓	
1996	DEMIO / FESTIVA MINI WAGON	1.5L	B5	ABS	✓	✓	✓	✓	
1999	DEMIO / FESTIVA MINI WAGON	1.3L	B3	ABS	✓	✓	✓	✓	
1999	DEMIO / FESTIVA MINI WAGON	1.3L	B3	PCM	✓	✓	✓	✓	
1999	DEMIO / FESTIVA MINI WAGON	1.5L	B5	ABS	✓	✓	✓	✓	
2000	DEMIO / FESTIVA MINI WAGON	1.3L	B3	ABS/TCS	✓	✓	✓	✓	
2000	DEMIO / FESTIVA MINI WAGON	1.3L	B3	PCM	✓	✓	✓	✓	
Other	DEMIO / FESTIVA MINI WAGON	1.3L	B3	PCM	✓	✓	✓	✓	
1995	E-Series	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008
1995	E-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	
1995	E-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1996	E-Series	4.9L	GFP	ABS/TCS	✓	✓	✓	✓	0008
1996	E-Series	4.9L	GFP	PCM	✓	✓	✓	✓	
1996	E-Series	4.9L	Other	ABS/TCS	✓	✓	✓	✓	0008
1996	E-Series	4.9L	Other	PCM	✓	✓	✓	✓	0025
1996	E-Series	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1996	E-Series	5.0L	Other	PCM	✓	✓	✓	✓	0025
1996	E-Series	5.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
1996	E-Series	5.8L	Other	PCM	✓	✓	✓	✓	0025
1996	E-Series	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008
1996	E-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	
1996	E-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1996	E-Series	7.5L	Other	ABS/TCS	✓	✓	✓	✓	0008
1996	E-Series	7.5L	Other	PCM	✓	✓	✓	✓	0025
1997	E-Series	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	E-Series	4.2L	Other	ECS	✓	✓	✓	✓	
1997	E-Series	4.2L	Other	PCM	✓	✓	✓	✓	0025
1997	E-Series	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	E-Series	4.6L	Other	ECS	✓	✓	✓	✓	
1997	E-Series	4.6L	Other	PCM	✓	✓	✓	✓	0025
1997	E-Series	5.4L	NGV	ABS/TCS	✓	✓	✓	✓	0008
1997	E-Series	5.4L	NGV	ECS	✓	✓	✓	✓	

2002	E-Series	7.3L	Direct Injection -	ECS	✓	✓	✓	✓	
2002	E-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	E-Series	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
2003	E-Series	4.2L	Other	ECS	✓	✓	✓	✓	
2003	E-Series	4.2L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	E-Series	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	E-Series	4.6L	2V	ECS	✓	✓	✓	✓	
2003	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	E-Series	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2003	E-Series	5.4L	Other	AFCM	✓	✓	✓	✓	
2003	E-Series	5.4L	Other	ECS	✓	✓	✓	✓	
2003	E-Series	5.4L	Other	FIM	✓	✓	✓	✓	
2003	E-Series	5.4L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	E-Series	6.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
2003	E-Series	6.8L	Other	ECS	✓	✓	✓	✓	
2003	E-Series	6.8L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	E-Series	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008
2003	E-Series	7.3L	Direct Injection -	ECS	✓	✓	✓	✓	
2003	E-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	E-Series	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	E-Series	4.6L	2V	IC	✓	✓	✓	✓	
2004	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	E-Series	4.6L	2V	RAP	✓	✓	✓	✓	
2004	E-Series	4.6L	2V	RCM	✓	✓	✓	✓	
2004	E-Series	5.4L	2V	ABS/TCS	✓	✓	✓	✓	
2004	E-Series	5.4L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	E-Series	5.4L	2V	AFCM	✓	✓	✓	✓	
2004	E-Series	5.4L	2V	IC	✓	✓	✓	✓	
2004	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	
2004	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	E-Series	5.4L	2V	RAP	✓	✓	✓	✓	
2004	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	
2004	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	
2004	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	
2004	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2004	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2004	E-Series	6.0L	Direct Injection -	RAP	✓	✓	✓	✓	
2004	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓	✓	
2004	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2004	E-Series	6.8L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	E-Series	6.8L	2V	IC	✓	✓	✓	✓	
2004	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	E-Series	6.8L	2V	RAP	✓	✓	✓	✓	
2004	E-Series	6.8L	2V	RCM	✓	✓	✓	✓	
2005	E-Series	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2005	E-Series	4.6L	2V	IC	✓	✓	✓	✓	
2005	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	
2005	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	E-Series	4.6L	2V	RAP	✓	✓	✓	✓	
2005	E-Series	4.6L	2V	RCM	✓	✓	✓	✓	
2005	E-Series	5.4L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2005	E-Series	5.4L	2V	IC	✓	✓	✓	✓	
2005	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	
2005	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	E-Series	5.4L	2V	RAP	✓	✓	✓	✓	
2005	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008, 001B
2005	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	0005
2005	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2005	E-Series	6.0L	Direct Injection -	RAP	✓	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓	✓	
2005	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2005	E-Series	6.8L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2005	E-Series	6.8L	2V	IC	✓	✓	✓	✓	
2005	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	
2005	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	E-Series	6.8L	2V	RAP	✓	✓	✓	✓	
2005	E-Series	6.8L	2V	RCM	✓	✓	✓	✓	
2006	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2006	E-Series	4.6L	2V	ABS/TCS	✓	✓	✓	✓	001B
2006	E-Series	4.6L	2V	IC	✓	✓	✓	✓	0005, F027, F066, F067
2006	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025
2006	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	E-Series	4.6L	2V	RAP	✓	✓	✓	✓	
2006	E-Series	4.6L	2V	RCM	✓	✓	✓	✓	
2006	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0008, 0012
2006	E-Series	5.4L	2V	ABS/TCS	✓	✓	✓	✓	001B
2006	E-Series	5.4L	2V	IC	✓	✓	✓	✓	0005
2006	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025
2006	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	E-Series	5.4L	2V	RAP	✓	✓	✓	✓	

2006	E-Series	5.4L	2V	RCM	✓	✓	✓		
2006	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	
2006	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	0008, 0012
2006	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	
2006	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	001B
2006	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	
2006	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	0005, F027, F066, F067
2006	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2006	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	E-Series	6.0L	Direct Injection -	RAP	✓	✓	✓	✓	
2006	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓		
2006	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2006	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0008, 0012
2006	E-Series	6.8L	2V	ABS/TCS	✓	✓	✓	✓	001B
2006	E-Series	6.8L	2V	IC	✓	✓	✓	✓	
2006	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025
2006	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	E-Series	6.8L	2V	RAP	✓	✓	✓	✓	
2006	E-Series	6.8L	2V	RCM	✓	✓	✓		
2007	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2007	E-Series	4.6L	2V	ABS/TCS	✓	✓	✓	✓	001B
2007	E-Series	4.6L	2V	IC	✓	✓	✓	✓	
2007	E-Series	4.6L	2V	PAM	✓	✓	✓	✓	
2007	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025
2007	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	E-Series	4.6L	2V	RCM	✓	✓	✓		
2007	E-Series	4.6L	2V	VSM	✓	✓	✓	✓	
2007	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0008, 0012
2007	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0012
2007	E-Series	5.4L	2V	ABS/TCS	✓	✓	✓	✓	001B
2007	E-Series	5.4L	2V	IC	✓	✓	✓	✓	
2007	E-Series	5.4L	2V	IC	✓	✓	✓	✓	0005, F066, F067
2007	E-Series	5.4L	2V	PAM	✓	✓	✓	✓	
2007	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	
2007	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025
2007	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	E-Series	5.4L	2V	RCM	✓	✓	✓		
2007	E-Series	5.4L	2V	VSM	✓	✓	✓	✓	
2007	E-Series	5.4L	2V	VSM	✓	✓	✓	✓	F044
2007	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	
2007	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	0008, 0012
2007	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	
2007	E-Series	6.0L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	001B
2007	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	
2007	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	0005
2007	E-Series	6.0L	Direct Injection -	PAM	✓	✓	✓	✓	
2007	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2007	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓		
2007	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2007	E-Series	6.0L	Direct Injection -	VSM	✓	✓	✓	✓	
2007	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0008, 0012
2007	E-Series	6.8L	2V	ABS/TCS	✓	✓	✓	✓	001B
2007	E-Series	6.8L	2V	IC	✓	✓	✓	✓	
2007	E-Series	6.8L	2V	PAM	✓	✓	✓	✓	
2007	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025
2007	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	E-Series	6.8L	2V	RCM	✓	✓	✓		
2007	E-Series	6.8L	2V	VSM	✓	✓	✓	✓	
2008	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2008	E-Series	4.6L	2V	IC	✓	✓	✓	✓	
2008	E-Series	4.6L	2V	PAM	✓	✓	✓	✓	
2008	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0008, 0012, 0025, 0042
2008	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	E-Series	4.6L	2V	RCM	✓	✓	✓		
2008	E-Series	4.6L	2V	VSM	✓	✓	✓	✓	0042
2008	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0008, 0012
2008	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0012
2008	E-Series	5.4L	2V	IC	✓	✓	✓	✓	
2008	E-Series	5.4L	2V	IC	✓	✓	✓	✓	0005, F027, F066
2008	E-Series	5.4L	2V	PAM	✓	✓	✓	✓	
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0005, 0008, 0008, 0012, 0025, 0042, F022, F044
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0005, 0008, 0012, 0025, 0042, F022, F044
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0005, 0012, 0042, F022, F044
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	
2008	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	0005, F022
2008	E-Series	5.4L	2V	VSM	✓	✓	✓	✓	
2008	E-Series	5.4L	2V	VSM	✓	✓	✓	✓	0042, F044

2008	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	0008, 0012
2008	E-Series	6.0L	Direct Injection -	IC	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	PAM	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	0008, 0012, 0042
2008	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	VSM	✓	✓	✓	✓	
2008	E-Series	6.0L	Direct Injection -	VSM	✓	✓	✓	✓	0042
2008	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0008, 0012
2008	E-Series	6.8L	2V	IC	✓	✓	✓	✓	
2008	E-Series	6.8L	2V	PAM	✓	✓	✓	✓	
2008	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0008, 0012, 0025, 0042
2008	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	E-Series	6.8L	2V	RCM	✓	✓	✓	✓	
2008	E-Series	6.8L	2V	VSM	✓	✓	✓	✓	0042
2009	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0012
2009	E-Series	4.6L	2V	ACM	✓	✓	✓	✓	
2009	E-Series	4.6L	2V	ACM	✓	✓	✓	✓	
2009	E-Series	4.6L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	E-Series	4.6L	2V	IPC	✓	✓	✓	✓	
2009	E-Series	4.6L	2V	PAM	✓	✓	✓	✓	
2009	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0012
2009	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0067
2009	E-Series	4.6L	2V	RCM	✓	✓	✓	✓	
2009	E-Series	4.6L	2V	TBC	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0012
2009	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	E-Series	5.4L	2V	IPC	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	PAM	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012, 0025
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0028, 0031, 0033
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0067
2009	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	
2009	E-Series	5.4L	2V	TBC	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	0005, 0008, 0012
2009	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	0017, 0018
2009	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	0017, 0018
2009	E-Series	6.0L	Direct Injection -	GEM / SJB	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection - Turbo	GEM / SJB	✓	✓	✓	✓	0042, F03C, F042, F049, F04B, F04C, F068, F069, F06A
2009	E-Series	6.0L	Direct Injection -	IPC	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	PAM	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0005, 0008, 0012, 0017, 0018
2009	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2009	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	TBC	✓	✓	✓	✓	
2009	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0012
2009	E-Series	6.8L	2V	ACM	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	ACM	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	E-Series	6.8L	2V	IPC	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	PAM	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0012
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0028, 0031, 0033
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2009	E-Series	6.8L	2V	RCM	✓	✓	✓	✓	
2009	E-Series	6.8L	2V	TBC	✓	✓	✓	✓	
2010	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0012
2010	E-Series	4.6L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	4.6L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	4.6L	2V	APIM	✓	✓	✓	✓	0019

2010	E-Series	4.6L	2V	GEM / SJB	✓	✓	✓	✓	0042, F03C, F042, F049, F04B, F04C, F068, F069, F06A
2010	E-Series	4.6L	2V	GPSM	✓	✓	✓	✓	
2010	E-Series	4.6L	2V	IPC	✓	✓	✓	✓	
2010	E-Series	4.6L	2V	PAM	✓	✓	✓	✓	
2010	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0012, 0017, 0018
2010	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0067
2010	E-Series	4.6L	2V	RCM	✓	✓	✓	✓	
2010	E-Series	4.6L	2V	SDARS	✓	✓	✓	✓	
2010	E-Series	4.6L	2V	TBC	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	E-Series	5.4L	2V	ABS	✓	✓	✓	✓	0012
2010	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	5.4L	2V	APIM	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	APIM	✓	✓	✓	✓	0019
2010	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓	0042
2010	E-Series	5.4L	2V	GPSM	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	IPC	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	PAM	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012, 0017, 0018
2010	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012, 0017, 0018, 0025, 0028, 0031, 0033
2010	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012, 0025
2010	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025
2010	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0067
2010	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	SDARS	✓	✓	✓	✓	
2010	E-Series	5.4L	2V	TBC	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	6.0L	Direct Injection -	APIM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	APIM	✓	✓	✓	✓	0019
2010	E-Series	6.0L	Direct Injection -	GEM / SJB	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection - Turbo	GEM / SJB	✓	✓	✓	✓	0042, F03C, F042, F049, F04B, F04C, F068, F069, F06A
2010	E-Series	6.0L	Direct Injection -	GPSM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	IPC	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	PAM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	PCM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0005, 0008, 0012, 0017, 0018
2010	E-Series	6.0L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2010	E-Series	6.0L	Direct Injection -	RCM	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	SDARS	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	TBC	✓	✓	✓	✓	
2010	E-Series	6.0L	Direct Injection -	TCM	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0005, 0012
2010	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0012
2010	E-Series	6.8L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	6.8L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	E-Series	6.8L	2V	APIM	✓	✓	✓	✓	0019
2010	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓	0042, F03C, F042, F049, F04B, F04C, F068, F069, F06A
2010	E-Series	6.8L	2V	GPSM	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	IPC	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	PAM	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0005, 0012, 0017, 0018
2010	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0012, 0017, 0018, 0025, 0028, 0031, 0033
2010	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	E-Series	6.8L	2V	RCM	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	SDARS	✓	✓	✓	✓	
2010	E-Series	6.8L	2V	TBC	✓	✓	✓	✓	
2011	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2011	E-Series	4.6L	2V	ABS	✓	✓	✓	✓	0012
2011	E-Series	4.6L	2V	ACM	✓	✓	✓	✓	0017, 0018
2011	E-Series	4.6L	2V	ACM	✓	✓	✓	✓	0017, 0018
2011	E-Series	4.6L	2V	APIM	✓	✓	✓	✓	0019
2011	E-Series	4.6L	2V	GEM / SJB	✓	✓	✓	✓	0042
2011	E-Series	4.6L	2V	GPSM	✓	✓	✓	✓	
2011	E-Series	4.6L	2V	IPC	✓	✓	✓	✓	
2011	E-Series	4.6L	2V	PAM	✓	✓	✓	✓	
2011	E-Series	4.6L	2V	PCM	✓	✓	✓	✓	0012, 0017, 0018

2012	E-Series	6. 8L	2V	PCM	✓	✓	✓	✓	0025
2012	E-Series	6. 8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	E-Series	6. 8L	2V	RCM	✓	✓	✓	✓	
2012	E-Series	6. 8L	2V	SDARS	✓	✓	✓	✓	
2012	E-Series	6. 8L	2V	TBC	✓	✓	✓	✓	
2012	E-Series	Other	Other	ABS	✓	✓	✓	✓	
2012	E-Series	Other	Other	ACM	✓	✓	✓	✓	
2012	E-Series	Other	Other	ACM	✓	✓	✓	✓	
2012	E-Series	Other	Other	APIM	✓	✓	✓	✓	
2012	E-Series	Other	Other	GEM / SJB	✓	✓	✓	✓	0042
2012	E-Series	Other	Other	GPSM	✓	✓	✓	✓	
2012	E-Series	Other	Other	IPC	✓	✓	✓	✓	
2012	E-Series	Other	Other	PAM	✓	✓	✓	✓	
2012	E-Series	Other	Other	PCM	✓	✓	✓	✓	
2012	E-Series	Other	Other	RCM	✓	✓	✓	✓	
2012	E-Series	Other	Other	SDARS	✓	✓	✓	✓	
2012	E-Series	Other	Other	TBC	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	ABS	✓	✓	✓	✓	0012
2013	E-Series	4. 6L	2V	ABS	✓	✓	✓	✓	0012
2013	E-Series	4. 6L	2V	ACM	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	ACM	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	APIM	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	GEM / SJB	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	GPSM	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	IPC	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	PAM	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2013	E-Series	4. 6L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0028, 0031, 0033
2013	E-Series	4. 6L	2V	RCM	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	SDARS	✓	✓	✓	✓	
2013	E-Series	4. 6L	2V	TBC	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	ABS	✓	✓	✓	✓	0012
2013	E-Series	5. 4L	2V	ABS	✓	✓	✓	✓	0012
2013	E-Series	5. 4L	2V	ACM	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	ACM	✓	✓	✓	✓	0017, 0018
2013	E-Series	5. 4L	2V	ACM	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	ACM	✓	✓	✓	✓	0017, 0018
2013	E-Series	5. 4L	2V	APIM	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	GEM / SJB	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	GPSM	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	IPC	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	IPC	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	PAM	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2013	E-Series	5. 4L	2V	PCM	✓	✓	✓	✓	0012, 0025
2013	E-Series	5. 4L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0028, 0028, 0031, 0031, 0033, 0033, 0067
2013	E-Series	5. 4L	2V	PCM	✓	✓	✓	✓	0025
2013	E-Series	5. 4L	2V	RCM	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	SDARS	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	TBC	✓	✓	✓	✓	
2013	E-Series	5. 4L	2V	TBC	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	ABS	✓	✓	✓	✓	0012
2013	E-Series	6. 8L	2V	ABS	✓	✓	✓	✓	0012
2013	E-Series	6. 8L	2V	ACM	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	ACM	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	APIM	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	GEM / SJB	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	GPSM	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	IPC	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	IPC	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	PAM	✓	✓	✓	✓	0025
2013	E-Series	6. 8L	2V	PCM	✓	✓	✓	✓	0012, 0025
2013	E-Series	6. 8L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0025, 0028, 0031, 0033
2013	E-Series	6. 8L	2V	PCM	✓	✓	✓	✓	0025
2013	E-Series	6. 8L	2V	RCM	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	SDARS	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	TBC	✓	✓	✓	✓	
2013	E-Series	6. 8L	2V	TBC	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	ABS	✓	✓	✓	✓	0012
2014	E-Series	4. 6L	2V	ACM	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	APIM	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	GEM / SJB	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	GPSM	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	IPC	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	PAM	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0028, 0031, 0033
2014	E-Series	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	E-Series	4. 6L	2V	RCM	✓	✓	✓	✓	
2014	E-Series	4. 6L	2V	TBC	✓	✓	✓	✓	
2014	E-Series	5. 4L	2V	ABS	✓	✓	✓	✓	0012
2014	E-Series	5. 4L	2V	ACM	✓	✓	✓	✓	

2014	E-Series	5.4L	2V	ACM	✓	✓	✓	✓	0017, 0018
2014	E-Series	5.4L	2V	APIM	✓	✓	✓	✓	
2014	E-Series	5.4L	2V	APIM	✓	✓	✓	✓	0019
2014	E-Series	5.4L	2V	GEM / SJB	✓	✓	✓	✓	
2014	E-Series	5.4L	2V	GPSM	✓	✓	✓	✓	
2014	E-Series	5.4L	2V	IPC	✓	✓	✓	✓	
2014	E-Series	5.4L	2V	PAM	✓	✓	✓	✓	
2014	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0025, 0028, 0028, 0031, 0031, 0033, 0033, 0067
2014	E-Series	5.4L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	E-Series	5.4L	2V	RCM	✓	✓	✓	✓	
2014	E-Series	5.4L	2V	TBC	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	ABS	✓	✓	✓	✓	0012
2014	E-Series	6.8L	2V	ACM	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	APIM	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	GEM / SJB	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	GPSM	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	IPC	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	PAM	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0012, 0025, 0025, 0028, 0031, 0033
2014	E-Series	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	E-Series	6.8L	2V	RCM	✓	✓	✓	✓	
2014	E-Series	6.8L	2V	TBC	✓	✓	✓	✓	
2006	E-Series Shuttle Bus	6.8L	H2ICE	ABS/TCS	✓	✓	✓	✓	
2006	E-Series Shuttle Bus	6.8L	H2ICE	AFCM	✓	✓	✓	✓	
2006	E-Series Shuttle Bus	6.8L	H2ICE	EMM	✓	✓	✓	✓	
2006	E-Series Shuttle Bus	6.8L	H2ICE	IC	✓	✓	✓	✓	
2006	E-Series Shuttle Bus	6.8L	H2ICE	PCM	✓	✓	✓	✓	
2006	E-Series Shuttle Bus	6.8L	H2ICE	RCM	✓	✓	✓	✓	
2003.25	EcoSport	1.0L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008, 000B
2003.25	EcoSport	1.0L	Zetec Rocam	GEM	✓	✓	✓	✓	
2003.25	EcoSport	1.0L	Zetec Rocam	IC	✓	✓	✓	✓	
2003.25	EcoSport	1.0L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2003.25	EcoSport	1.0L	Zetec Rocam	RCM	✓	✓	✓	✓	
2003.25	EcoSport	1.0L	Zetec Rocam	RKE	✓	✓	✓	✓	
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 000B
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2003.25	EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2003.25	EcoSport	1.6L	FFV	GEM	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	FFV	IC	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2003.25	EcoSport	1.6L	FFV	RCM	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	FFV	RKE	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008, 000B
2003.25	EcoSport	1.6L	Zetec Rocam	GEM	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2003.25	EcoSport	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2003.25	EcoSport	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2003.25	EcoSport	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 000B
2003.25	EcoSport	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2003.25	EcoSport	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2003.25	EcoSport	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2003.25	EcoSport	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2003.25	EcoSport	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2006	EcoSport	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2006	EcoSport	1.6L	FFV	GEM	✓	✓	✓	✓	
2006	EcoSport	1.6L	FFV	IC	✓	✓	✓	✓	
2006	EcoSport	1.6L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2006	EcoSport	1.6L	FFV	RCM	✓	✓	✓	✓	
2006	EcoSport	1.6L	FFV	RKE	✓	✓	✓	✓	
2006	EcoSport	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 000B
2006	EcoSport	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	EcoSport	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	EcoSport	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	EcoSport	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006	EcoSport	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2007	EcoSport	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 000B
2007	EcoSport	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	EcoSport	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	EcoSport	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007	EcoSport	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2009	EcoSport	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2009	EcoSport	1.6L	FFV	IC	✓	✓	✓	✓	
2009	EcoSport	1.6L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2009	EcoSport	1.6L	FFV	RCM	✓	✓	✓	✓	

2009	EcoSport	1.6L	FFV	RKE	✓	✓	✓	✓	
2009	EcoSport	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2009	EcoSport	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	EcoSport	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	EcoSport	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2009	EcoSport	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2009	EcoSport	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2009	EcoSport	2.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
2009	EcoSport	2.0L	FFV	IC	✓	✓	✓	✓	
2009	EcoSport	2.0L	FFV	IC	✓	✓	✓	✓	
2009	EcoSport	2.0L	FFV	PCM	✓	✓	✓	✓	0025
2009	EcoSport	2.0L	FFV	PCM	✓	✓	✓	✓	0025, 00C5
2009	EcoSport	2.0L	FFV	RCM	✓	✓	✓	✓	
2009	EcoSport	2.0L	FFV	RKE	✓	✓	✓	✓	
2009	EcoSport	2.0L	FFV	TCM	✓	✓	✓	✓	0070, 00C5
2009	EcoSport	2.0L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2009	EcoSport	2.0L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	EcoSport	2.0L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	EcoSport	2.0L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2009	EcoSport	2.0L	Zetec Rocam	RCM	✓	✓	✓	✓	
2009	EcoSport	2.0L	Zetec Rocam	RKE	✓	✓	✓	✓	
2009	EcoSport	2.0L	Zetec Rocam	TCM	✓	✓	✓	✓	0070, 00C5
2011	EcoSport	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	000B
2011	EcoSport	1.6L	FFV	IC	✓	✓	✓	✓	
2011	EcoSport	1.6L	FFV	IC	✓	✓	✓	✓	
2011	EcoSport	1.6L	FFV	PCM	✓	✓	✓	✓	012E
2011	EcoSport	1.6L	FFV	RCM	✓	✓	✓	✓	
2011	EcoSport	1.6L	FFV	RKE	✓	✓	✓	✓	
2011	EcoSport	1.6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	EcoSport	2.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2011	EcoSport	2.0L	FFV	IC	✓	✓	✓	✓	
2011	EcoSport	2.0L	FFV	IC	✓	✓	✓	✓	
2011	EcoSport	2.0L	FFV	PCM	✓	✓	✓	✓	0025, 00C5
2011	EcoSport	2.0L	FFV	PCM	✓	✓	✓	✓	00C5
2011	EcoSport	2.0L	FFV	RCM	✓	✓	✓	✓	
2011	EcoSport	2.0L	FFV	RKE	✓	✓	✓	✓	
2011	EcoSport	2.0L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	EcoSport	2.0L	FFV	TCM	✓	✓	✓	✓	0070, 00C5
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	BCM#1	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0025, 0090, 0092, 0098, 0099, 009A, 00AF, 00B0, 00B2, 00B8, 00BD
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2012	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	TBM	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	ABS	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	ACM	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	APIM	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	BCM#1	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	DDM	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	FCDIM	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	HVAC	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	IPC	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	PCM	✓	✓	✓	✓	0025
2012	EcoSport	1.5L	TivCT	PSCM	✓	✓	✓	✓	00CB, 00CC
2012	EcoSport	1.5L	TivCT	RCM	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	RFA	✓	✓	✓	✓	
2012	EcoSport	1.5L	TivCT	TCM	✓	✓	✓	✓	0117, 0158
2012	EcoSport	1.6L	Sigma	ABS	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	ACM	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	APIM	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	BCM#1	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	DDM	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	FCDIM	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	HVAC	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	IPC	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	PCM	✓	✓	✓	✓	
2012	EcoSport	1.6L	Sigma	PSCM	✓	✓	✓	✓	00CB, 00CC
2012	EcoSport	1.6L	Sigma	RCM	✓	✓	✓	✓	

2012	EcoSport	1. 6L	Sigma	RFA	✓	✓	✓	✓	
2012	EcoSport	1. 6L	Sigma	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	EcoSport	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	BCM#1	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	FCDIM	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2012	EcoSport	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0067
2012	EcoSport	2. 0L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	00CB, 00CC
2012	EcoSport	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2012	EcoSport	2. 0L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	EcoSport	2. 0L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D2, 00D3
2012	EcoSport	Other	Other	ABS	✓	✓	✓	✓	
2012	EcoSport	Other	Other	ACM	✓	✓	✓	✓	
2012	EcoSport	Other	Other	APIM	✓	✓	✓	✓	
2012	EcoSport	Other	Other	BCM#1	✓	✓	✓	✓	
2012	EcoSport	Other	Other	DDM	✓	✓	✓	✓	
2012	EcoSport	Other	Other	FCDIM	✓	✓	✓	✓	
2012	EcoSport	Other	Other	HVAC	✓	✓	✓	✓	
2012	EcoSport	Other	Other	IPC	✓	✓	✓	✓	
2012	EcoSport	Other	Other	PSCM	✓	✓	✓	✓	
2012	EcoSport	Other	Other	RCM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	ABS	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	ACM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	APIM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	BCM#1	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	DDM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	FCDIM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	GPSM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	HVAC	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	IPC	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	PCM	✓	✓	✓	✓	0025
2013	EcoSport	2. 0L	DURATEC	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	EcoSport	2. 0L	DURATEC	PSCM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	RCM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	RFA	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	TBM	✓	✓	✓	✓	
2013	EcoSport	2. 0L	DURATEC	TBM	✓	✓	✓	✓	00D2, 00D3
2013	EcoSport	2. 0L	DURATEC	TCM	✓	✓	✓	✓	0117, 0158
2014	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	

2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓		
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	0101
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	EcoSport	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	ABS	✓	✓	✓	✓	00E8
2014	EcoSport	1.5L	DURATEC VCT	ACM	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	APIM	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	BCMii	✓	✓	✓	✓	0101
2014	EcoSport	1.5L	DURATEC VCT	GPSM	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	IPC	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	PCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	PSCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	RCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	RFA	✓	✓	✓	✓	
2014	EcoSport	1.5L	DURATEC VCT	TCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	00E8
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	APIM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	0101
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	GPSM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	
2014	EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2008	Econovan	2.0L	OHC	IC	✓	✓	✓	✓	
2008	Econovan	2.0L	OHC	PCM	✓	✓	✓	✓	
2007	Edge	3.5L	4V	4X4	✓	✓	✓	✓	
2007	Edge	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2007	Edge	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Edge	3.5L	4V	DSM	✓	✓	✓	✓	
2007	Edge	3.5L	4V	EATC	✓	✓	✓	✓	
2007	Edge	3.5L	4V	GEM	✓	✓	✓	✓	001A
2007	Edge	3.5L	4V	IC	✓	✓	✓	✓	
2007	Edge	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2007	Edge	3.5L	4V	PAM	✓	✓	✓	✓	
2007	Edge	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Edge	3.5L	4V	RCM	✓	✓	✓	✓	
2007	Edge	3.5L	4V	RETM	✓	✓	✓	✓	
2007	Edge	3.5L	4V	SASM	✓	✓	✓	✓	
2007	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0019
2007	Edge	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3

2008	Edge	3.5L	4V	4X4	✓	✓	✓	✓	
2008	Edge	3.5L	4V	ABS	✓	✓	✓	✓	0005
2008	Edge	3.5L	4V	ABS	✓	✓	✓	✓	0005, 0012
2008	Edge	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0019
2008	Edge	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Edge	3.5L	4V	DSM	✓	✓	✓	✓	0005, F041
2008	Edge	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C
2008	Edge	3.5L	4V	HVAC	✓	✓	✓	✓	
2008	Edge	3.5L	4V	IC	✓	✓	✓	✓	0005, F027, F047, F04A
2008	Edge	3.5L	4V	LTM	✓	✓	✓	✓	
2008	Edge	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Edge	3.5L	4V	PAM	✓	✓	✓	✓	0005
2008	Edge	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Edge	3.5L	4V	RCM	✓	✓	✓	✓	0005
2008	Edge	3.5L	4V	RETM	✓	✓	✓	✓	0005, F04D
2008	Edge	3.5L	4V	SASM	✓	✓	✓	✓	
2008	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0005, 0019
2008	Edge	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	Edge	3.5L	4V	4X4	✓	✓	✓	✓	
2009	Edge	3.5L	4V	ABS	✓	✓	✓	✓	
2009	Edge	3.5L	4V	ABS	✓	✓	✓	✓	0005, 0012
2009	Edge	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0019
2009	Edge	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0019
2009	Edge	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Edge	3.5L	4V	DSM	✓	✓	✓	✓	
2009	Edge	3.5L	4V	DSM	✓	✓	✓	✓	0005
2009	Edge	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Edge	3.5L	4V	HVAC	✓	✓	✓	✓	
2009	Edge	3.5L	4V	IC	✓	✓	✓	✓	
2009	Edge	3.5L	4V	IC	✓	✓	✓	✓	0005
2009	Edge	3.5L	4V	LTM	✓	✓	✓	✓	
2009	Edge	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2009	Edge	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Edge	3.5L	4V	PAM	✓	✓	✓	✓	
2009	Edge	3.5L	4V	PAM	✓	✓	✓	✓	0005
2009	Edge	3.5L	4V	PCM	✓	✓	✓	✓	0025
2009	Edge	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Edge	3.5L	4V	RCM	✓	✓	✓	✓	
2009	Edge	3.5L	4V	RCM	✓	✓	✓	✓	0005
2009	Edge	3.5L	4V	RETM	✓	✓	✓	✓	
2009	Edge	3.5L	4V	SASM	✓	✓	✓	✓	
2009	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0005
2009	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0005, 0019
2009	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0019
2009	Edge	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Edge	3.5L	4V	4X4	✓	✓	✓	✓	
2010	Edge	3.5L	4V	ABS	✓	✓	✓	✓	0012
2010	Edge	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0019
2010	Edge	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0019
2010	Edge	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Edge	3.5L	4V	DSM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	DSM	✓	✓	✓	✓	0005
2010	Edge	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Edge	3.5L	4V	GPSM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	HVAC	✓	✓	✓	✓	
2010	Edge	3.5L	4V	IC	✓	✓	✓	✓	
2010	Edge	3.5L	4V	LTM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	Edge	3.5L	4V	PAM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	PAM	✓	✓	✓	✓	0005
2010	Edge	3.5L	4V	PCM	✓	✓	✓	✓	0025
2010	Edge	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2010	Edge	3.5L	4V	RCM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	RETM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	SASM	✓	✓	✓	✓	
2010	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0005, 0019
2010	Edge	3.5L	4V	SDARS	✓	✓	✓	✓	0019
2010	Edge	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Edge	3.5L	TivCT	ABS	✓	✓	✓	✓	0008, 0012
2011	Edge	3.5L	TivCT	ACM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	APIM	✓	✓	✓	✓	00D6
2011	Edge	3.5L	TivCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	Edge	3.5L	TivCT	C-CM	✓	✓	✓	✓	0046
2011	Edge	3.5L	TivCT	DSCM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	DSM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	DSP	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	FCDIM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	FCIM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	FLM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	GPSM	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	HUD	✓	✓	✓	✓	
2011	Edge	3.5L	TivCT	HVAC	✓	✓	✓	✓	

2011	Edge	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2011	Edge	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	PCM	✓	✓	✓	✓	0067, 0095
2011	Edge	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2011	Edge	3.5L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Edge	3.5L	TiVCT	TPM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2011	Edge	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	APIM	✓	✓	✓	✓	00D6
2011	Edge	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 0042, 00D4, 00D5, 00FE
2011	Edge	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	Edge	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2011	Edge	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2011	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2011	Edge	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	PCM	✓	✓	✓	✓	0067, 0095
2011	Edge	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2011	Edge	3.7L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Edge	3.7L	TiVCT	TPM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2012	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	

2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0095
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TBM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	0028, 0031, 0033
2012	Edge	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TPM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	Edge	3. 5L	TiVCT	ACM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	APIM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	Edge	3. 5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2012	Edge	3. 5L	TiVCT	DCSM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	DSM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	DSP	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	FCDIM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	FCIM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	FLM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	GPSM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	HUD	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	HVAC	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	IPC	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	LTM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2012	Edge	3. 5L	TiVCT	PAM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2012	Edge	3. 5L	TiVCT	RCM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	RFA	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	SCCM	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	SOD-L	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	SOD-R	✓	✓	✓	✓	
2012	Edge	3. 5L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Edge	3. 5L	TiVCT	TPM	✓	✓	✓	✓	
2012	Edge	3. 7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	Edge	3. 7L	TiVCT	ACM	✓	✓	✓	✓	

2012	Edge	3.7L	TiVCT	APIM	✓	✓	✓		
2012	Edge	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	Edge	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2012	Edge	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2012	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2012	Edge	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2012	Edge	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2012	Edge	3.7L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Edge	3.7L	TiVCT	TPM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015

2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	0015
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0095, 0108
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TBM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2013	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	0028, 0031, 0033
2013	Edge	3.5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	Edge	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Edge	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Edge	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	FLM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	Edge	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	Edge	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	Edge	3.5L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2013	Edge	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	Edge	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Edge	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Edge	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	Edge	3.7L	TiVCT	LTM	✓	✓	✓	✓	

2013	Edge	3. 7L	TiVCT	OCSM	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	Edge	3. 7L	TiVCT	PAM	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2013	Edge	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	Edge	3. 7L	TiVCT	RCM	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	RFA	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	RLCM-A	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	RTM	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	Edge	3. 7L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00CE
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Edge	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	

2014	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2014	Edge	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2014	Edge	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112
2014	Edge	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Edge	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	FLM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	Edge	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Edge	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Edge	3.5L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2014	Edge	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2014	Edge	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112
2014	Edge	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Edge	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	Edge	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Edge	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Edge	3.7L	TiVCT	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2014	Edge	Other	Other	ABS	✓	✓	✓	✓	
2014	Edge	Other	Other	ACM	✓	✓	✓	✓	
2014	Edge	Other	Other	APIM	✓	✓	✓	✓	
2014	Edge	Other	Other	BCM#1	✓	✓	✓	✓	
2014	Edge	Other	Other	C-CM	✓	✓	✓	✓	
2014	Edge	Other	Other	DCSM	✓	✓	✓	✓	
2014	Edge	Other	Other	DSM	✓	✓	✓	✓	
2014	Edge	Other	Other	DSP	✓	✓	✓	✓	
2014	Edge	Other	Other	FCDIM	✓	✓	✓	✓	
2014	Edge	Other	Other	FCIM	✓	✓	✓	✓	
2014	Edge	Other	Other	FLM	✓	✓	✓	✓	
2014	Edge	Other	Other	GPSM	✓	✓	✓	✓	
2014	Edge	Other	Other	HUD	✓	✓	✓	✓	
2014	Edge	Other	Other	HVAC	✓	✓	✓	✓	
2014	Edge	Other	Other	IPC	✓	✓	✓	✓	
2014	Edge	Other	Other	LTM	✓	✓	✓	✓	
2014	Edge	Other	Other	OCSM	✓	✓	✓	✓	
2014	Edge	Other	Other	PAM	✓	✓	✓	✓	
2014	Edge	Other	Other	RCM	✓	✓	✓	✓	
2014	Edge	Other	Other	RFA	✓	✓	✓	✓	
2014	Edge	Other	Other	RLCM-A	✓	✓	✓	✓	
2014	Edge	Other	Other	RTM	✓	✓	✓	✓	
2014	Edge	Other	Other	SCCM	✓	✓	✓	✓	
2014	Edge	Other	Other	SOD-L	✓	✓	✓	✓	

2001	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓	
2002	Escape / Tribute / Maverick	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2002	Escape / Tribute / Maverick	2.0L	Zetec	GEM	✓	✓	✓	✓	
2002	Escape / Tribute / Maverick	2.0L	Zetec	IC	✓	✓	✓	✓	
2002	Escape / Tribute / Maverick	2.0L	Zetec	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Escape / Tribute / Maverick	2.0L	Zetec	RCM	✓	✓	✓	✓	
2002	Escape / Tribute / Maverick	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2002	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓	
2002	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓	
2002	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2003	Escape / Tribute / Maverick	2.0L	Zetec	GEM	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	2.0L	Zetec	IC	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	2.0L	Zetec	PAM	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	2.0L	Zetec	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Escape / Tribute / Maverick	2.0L	Zetec	RCM	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	3.0L	4V	PAM	✓	✓	✓	✓	
2003	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2004	Escape / Tribute / Maverick	2.0L	Zetec	GEM	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	2.0L	Zetec	IC	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	2.0L	Zetec	PAM	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	2.0L	Zetec	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Escape / Tribute / Maverick	2.0L	Zetec	RCM	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2004	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	3.0L	4V	PAM	✓	✓	✓	✓	
2004	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2006	Escape / Tribute / Maverick	3.0L	4V	4X4	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	3.0L	4V	ABS	✓	✓	✓	✓	0005, 0008
2006	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓	F042, F04E, F04F, F050, F051, F056, F057, F058, F059
2006	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓	F042, F04E, F04F, F050, F051, F056, F057, F058, F059, F090
2006	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓	0005, F040, F043, F04D, F052, F053, F054, F055
2006	Escape / Tribute / Maverick	3.0L	4V	PAM	✓	✓	✓	✓	
2006	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓	000C
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2007	Escape / Tribute / Maverick	3.0L	4V	4X4	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	3.0L	4V	ABS	✓	✓	✓	✓	0008
2007	Escape / Tribute / Maverick	3.0L	4V	GEM	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	3.0L	4V	IC	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	3.0L	4V	PAM	✓	✓	✓	✓	
2007	Escape / Tribute / Maverick	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Escape / Tribute / Maverick	3.0L	4V	RCM	✓	✓	✓	✓	000C
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0005, 0101

2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0108
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	013D
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D5, 0101
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	

2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓		
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0108
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓		
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓		013D
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓		
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	ABS	✓	✓	✓	✓	0012
2013	Escape/Kuga	2.5L	IVCT	ACM	✓	✓	✓	✓	0017
2013	Escape/Kuga	2.5L	IVCT	APIM	✓	✓	✓	✓	0019
2013	Escape/Kuga	2.5L	IVCT	BCM#1	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	BCM#1	✓	✓	✓	✓	00D5, 0101
2013	Escape/Kuga	2.5L	IVCT	DDM	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	DSM	✓	✓	✓	✓	00F2
2013	Escape/Kuga	2.5L	IVCT	DSP	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	FCDIM	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	FCIM	✓	✓	✓		
2013	Escape/Kuga	2.5L	IVCT	GPSM	✓	✓	✓		
2013	Escape/Kuga	2.5L	IVCT	HCM	✓	✓	✓		
2013	Escape/Kuga	2.5L	IVCT	HVAC	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	IPC	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	IPM-B	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	OCSM	✓	✓	✓	✓	000C
2013	Escape/Kuga	2.5L	IVCT	PAM	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2013	Escape/Kuga	2.5L	IVCT	PDM	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	Escape/Kuga	2.5L	IVCT	RCM	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	RFA	✓	✓	✓		
2013	Escape/Kuga	2.5L	IVCT	RGTM	✓	✓	✓		013D
2013	Escape/Kuga	2.5L	IVCT	SASM	✓	✓	✓		
2013	Escape/Kuga	2.5L	IVCT	SOD-L	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	SOD-R	✓	✓	✓	✓	
2013	Escape/Kuga	2.5L	IVCT	TRM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	

2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D5, 0101
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	013D
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Escape/Kuga	1.6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D5, 0101
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	

2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓		013D
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓		
2014	Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	ABS	✓	✓	✓	✓	0012
2014	Escape/Kuga	2.5L	IVCT	ACM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	APIM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	BCM#1	✓	✓	✓	✓	00D5, 0101
2014	Escape/Kuga	2.5L	IVCT	DDM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	DSM	✓	✓	✓	✓	00F2
2014	Escape/Kuga	2.5L	IVCT	DSP	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	FCDIM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	FCIM	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	GPSM	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	HCM	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	HVAC	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	IPC	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	OCSM	✓	✓	✓	✓	000C
2014	Escape/Kuga	2.5L	IVCT	PAM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Escape/Kuga	2.5L	IVCT	PDM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Escape/Kuga	2.5L	IVCT	RCM	✓	✓	✓	✓	
2014	Escape/Kuga	2.5L	IVCT	RFA	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	RGTM	✓	✓	✓		013D
2014	Escape/Kuga	2.5L	IVCT	SASM	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	SOD-L	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	SOD-R	✓	✓	✓		
2014	Escape/Kuga	2.5L	IVCT	TRM	✓	✓	✓	✓	
1992	Escort	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1992	Escort	1.8L	Zetec	CSM	✓	✓	✓	✓	
1992	Escort	1.8L	Zetec	HEC	✓	✓	✓	✓	
1992	Escort	1.8L	Zetec	PATS	✓	✓	✓	✓	
1992	Escort	1.8L	Zetec	PCM	✓	✓	✓	✓	0025
1993	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1993	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1993	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1993	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1993	Escort	1.6L	Zetec	PCM	✓	✓	✓	✓	0025
1993.5	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	

1993.5	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1993.5	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1993.5	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1993.5	Escort	1.6L	Zetec	PCM	✓	✓	✓	✓	0025
1994	Escort	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1994	Escort	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓	✓	
1994	Escort	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓	
1994	Escort	1.4L	1.4 PT-E SFI	PATS			✓	✓	
1994	Escort	1.4L	1.4 PT-E SFI	PATS	✓	✓	✓	✓	
1994	Escort	1.4L	1.4 PT-E SFI	PCM	✓	✓	✓	✓	
1994	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1994	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1994	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1994	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1994	Escort	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1994	Escort	1.8L	Zetec	CSM	✓	✓	✓	✓	
1994	Escort	1.8L	Zetec	HEC	✓	✓	✓	✓	
1994	Escort	1.8L	Zetec	PATS	✓	✓	✓	✓	
1994.5	Escort	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1994.5	Escort	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓	✓	
1994.5	Escort	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓	
1994.5	Escort	1.4L	1.4 PT-E SFI	PATS			✓	✓	
1994.5	Escort	1.4L	1.4 PT-E SFI	PATS	✓	✓	✓	✓	
1994.5	Escort	1.4L	1.4 PT-E SFI	PCM	✓	✓	✓	✓	
1994.5	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1994.5	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1994.5	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1994.5	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1994.75	Escort	2.0L	DOHC Cosworth	ABS/TCS	✓	✓	✓	✓	
1994.75	Escort	2.0L	DOHC Cosworth	PATS	✓	✓	✓	✓	
1994.75	Escort	2.0L	DOHC Cosworth	PCM	✓	✓	✓	✓	
1995	Escort	1.4L	1.4 PT-E SFI	ABS	✓	✓	✓	✓	
1995	Escort	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1995	Escort	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓	✓	
1995	Escort	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓	
1995	Escort	1.4L	1.4 PT-E SFI	PATS			✓	✓	
1995	Escort	1.4L	1.4 PT-E SFI	PCM	✓	✓	✓	✓	
1995	Escort	1.6L	Zetec	ABS	✓	✓	✓	✓	
1995	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1995	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1995	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1995	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1995	Escort	1.8L	Zetec	ABS	✓	✓	✓	✓	
1995	Escort	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1995	Escort	1.8L	Zetec	CSM	✓	✓	✓	✓	
1995	Escort	1.8L	Zetec	HEC	✓	✓	✓	✓	
1995	Escort	1.8L	Zetec	PATS	✓	✓	✓	✓	
1995	Escort	2.0L	DOHC Cosworth	ABS	✓	✓	✓	✓	
1995	Escort	2.0L	DOHC Cosworth	ABS/TCS	✓	✓	✓	✓	
1995	Escort	2.0L	DOHC Cosworth	PATS	✓	✓	✓	✓	
1995	Escort	2.0L	DOHC Cosworth	PCM	✓	✓	✓	✓	
1995.5	Escort	1.3L	Endura-E	ABS	✓	✓	✓	✓	
1995.5	Escort	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1995.5	Escort	1.3L	Endura-E	CSM	✓	✓	✓	✓	
1995.5	Escort	1.3L	Endura-E	HEC	✓	✓	✓	✓	
1995.5	Escort	1.3L	Endura-E	PATS	✓	✓	✓	✓	
1995.5	Escort	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1995.5	Escort	1.6L	Zetec	ABS	✓	✓	✓	✓	
1995.5	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1995.5	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1995.5	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1995.5	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1995.5	Escort	1.6L	Zetec	PCM	✓	✓	✓	✓	0025
1995.5	Escort	1.8L	Zetec	ABS	✓	✓	✓	✓	
1995.5	Escort	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1995.5	Escort	1.8L	Zetec	CSM	✓	✓	✓	✓	
1995.5	Escort	1.8L	Zetec	HEC	✓	✓	✓	✓	
1995.5	Escort	1.8L	Zetec	PATS	✓	✓	✓	✓	
1996	Escort	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1996	Escort	1.3L	Endura-E	CSM	✓	✓	✓	✓	
1996	Escort	1.3L	Endura-E	HEC	✓	✓	✓	✓	
1996	Escort	1.3L	Endura-E	PATS	✓	✓	✓	✓	
1996	Escort	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1996	Escort	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1996	Escort	1.6L	Zetec	CSM	✓	✓	✓	✓	
1996	Escort	1.6L	Zetec	HEC	✓	✓	✓	✓	
1996	Escort	1.6L	Zetec	PATS	✓	✓	✓	✓	
1996	Escort	1.6L	Zetec	PCM	✓	✓	✓	✓	0025
1996	Escort	1.8L	Endura-DE	ABS/TCS	✓	✓	✓	✓	
1996	Escort	1.8L	Endura-DE	CSM	✓	✓	✓	✓	
1996	Escort	1.8L	Endura-DE	HEC	✓	✓	✓	✓	
1996	Escort	1.8L	Endura-DE	PATS	✓	✓	✓	✓	
1996	Escort	1.8L	Endura-DE	PCM			✓	✓	
1996	Escort	1.8L	Endura-DE	PCM	✓	✓	✓	✓	
1996	Escort	1.8L	Endura-DE	PCM	✓	✓	✓	✓	
1996	Escort	1.8L	Other	ABS/TCS	✓	✓	✓	✓	
1996	Escort	1.8L	Other	CSM	✓	✓	✓	✓	
1996	Escort	1.8L	Other	HEC	✓	✓	✓	✓	
1996	Escort	1.8L	Other	PATS	✓	✓	✓	✓	

1996	Escort	1. 8L	Other	PCM	✓	✓	✓		
1996	Escort	1. 8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1996	Escort	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1996	Escort	1. 8L	Zetec	HEC	✓	✓	✓	✓	
1996	Escort	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1996	Escort	1. 8L	Zetec	PCM	✓	✓	✓	✓	0025
1996	Escort	1. 9L	Other	ABS/TCS	✓	✓	✓	✓	
1996	Escort	1. 9L	Other	PATS	✓	✓	✓	✓	
1996	Escort	1. 9L	Other	PCM	✓	✓	✓	✓	0025
1996. 5	Escort	1. 6L	Zetec	ABS	✓	✓	✓	✓	
1996. 5	Escort	1. 6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1996. 5	Escort	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1996. 5	Escort	1. 6L	Zetec	HEC	✓	✓	✓	✓	
1996. 5	Escort	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1997	Escort	1. 3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1997	Escort	1. 3L	Endura-E	CSM	✓	✓	✓	✓	
1997	Escort	1. 3L	Endura-E	HEC	✓	✓	✓	✓	
1997	Escort	1. 3L	Endura-E	PATS	✓	✓	✓	✓	
1997	Escort	1. 3L	Endura-E	PCM	✓	✓	✓	✓	0025
1997	Escort	1. 6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1997	Escort	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1997	Escort	1. 6L	Zetec	HEC	✓	✓	✓	✓	
1997	Escort	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1997	Escort	1. 6L	Zetec	PCM	✓	✓	✓	✓	0025
1997	Escort	1. 8L	Endura-DE	ABS/TCS	✓	✓	✓	✓	
1997	Escort	1. 8L	Endura-DE	CSM	✓	✓	✓	✓	
1997	Escort	1. 8L	Endura-DE	HEC	✓	✓	✓	✓	
1997	Escort	1. 8L	Endura-DE	PATS	✓	✓	✓	✓	
1997	Escort	1. 8L	Endura-DE	PCM	✓	✓	✓	✓	
1997	Escort	1. 8L	Endura-DE	PCM	✓	✓	✓	✓	
1997	Escort	1. 8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1997	Escort	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1997	Escort	1. 8L	Zetec	HEC	✓	✓	✓	✓	
1997	Escort	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1997	Escort	1. 8L	Zetec	PCM	✓	✓	✓	✓	0025
1997	Escort	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
1997	Escort	2. 0L	SPI	PATS	✓	✓	✓	✓	
1997	Escort	2. 0L	SPI	PCM	✓	✓	✓	✓	0025
1997	Escort	2. 0L	SPI	RAP	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	ABS	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	ABS/TCS	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	CSM	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	HEC	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	PATS	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	PCM	✓	✓	✓	✓	
1997. 5	Escort	1. 8L	Endura-DE	PCM	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	ABS	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	CSM	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	HEC	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	PATS	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	PATS	✓	✓	✓	✓	
1997. 75	Escort	1. 4L	1. 4 PT-E SFI	PCM	✓	✓	✓	✓	
1997. 75	Escort	1. 6L	Zetec	ABS	✓	✓	✓	✓	
1997. 75	Escort	1. 6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1997. 75	Escort	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1997. 75	Escort	1. 6L	Zetec	HEC	✓	✓	✓	✓	
1997. 75	Escort	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1997. 75	Escort	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1997. 75	Escort	1. 8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1997. 75	Escort	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1997. 75	Escort	1. 8L	Zetec	HEC	✓	✓	✓	✓	
1997. 75	Escort	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1997. 75	Escort	1. 8L	Zetec	PCM	✓	✓	✓	✓	0025
1998	Escort	1. 3L	Endura-E	ABS	✓	✓	✓	✓	
1998	Escort	1. 3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1998	Escort	1. 3L	Endura-E	CSM	✓	✓	✓	✓	
1998	Escort	1. 3L	Endura-E	HEC	✓	✓	✓	✓	
1998	Escort	1. 3L	Endura-E	PATS	✓	✓	✓	✓	
1998	Escort	1. 3L	Endura-E	PCM	✓	✓	✓	✓	0025
1998	Escort	1. 4L	1. 4 PT-E SFI	ABS	✓	✓	✓	✓	
1998	Escort	1. 4L	1. 4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1998	Escort	1. 4L	1. 4 PT-E SFI	CSM	✓	✓	✓	✓	
1998	Escort	1. 4L	1. 4 PT-E SFI	HEC	✓	✓	✓	✓	
1998	Escort	1. 4L	1. 4 PT-E SFI	PATS	✓	✓	✓	✓	
1998	Escort	1. 4L	1. 4 PT-E SFI	PATS	✓	✓	✓	✓	
1998	Escort	1. 4L	1. 4 PT-E SFI	PCM	✓	✓	✓	✓	
1998	Escort	1. 6L	Zetec	ABS	✓	✓	✓	✓	
1998	Escort	1. 6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1998	Escort	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1998	Escort	1. 6L	Zetec	HEC	✓	✓	✓	✓	
1998	Escort	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1998	Escort	1. 6L	Zetec	PCM	✓	✓	✓	✓	0025
1998	Escort	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1998	Escort	1. 8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1998	Escort	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1998	Escort	1. 8L	Zetec	HEC	✓	✓	✓	✓	
1998	Escort	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1998	Escort	1. 8L	Zetec	PCM	✓	✓	✓	✓	0025

1998	Escort	2. 0L	SPI	ABS	✓	✓	✓	✓	0008
1998	Escort	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
1998	Escort	2. 0L	SPI	ECS	✓	✓	✓	✓	
1998	Escort	2. 0L	SPI	PATS	✓	✓	✓	✓	
1998	Escort	2. 0L	SPI	PCM	✓	✓	✓	✓	0008, 0025
1998	Escort	2. 0L	SPI	RAP	✓	✓	✓	✓	
1998	Escort	2. 0L	Zetec	ABS	✓	✓	✓	✓	0008
1998	Escort	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1998	Escort	2. 0L	Zetec	ECS	✓	✓	✓	✓	
1998	Escort	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1998	Escort	2. 0L	Zetec	PCM	✓	✓	✓	✓	0008, 0025
1998	Escort	2. 0L	Zetec	RAP	✓	✓	✓	✓	
1999	Escort	2. 0L	SPI	ABS	✓	✓	✓	✓	0008
1999	Escort	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
1999	Escort	2. 0L	SPI	ECS	✓	✓	✓	✓	
1999	Escort	2. 0L	SPI	PATS	✓	✓	✓	✓	
1999	Escort	2. 0L	SPI	PCM	✓	✓	✓	✓	0008, 0025
1999	Escort	2. 0L	SPI	PCM	✓	✓	✓	✓	0025
1999	Escort	2. 0L	SPI	RAP	✓	✓	✓	✓	
1999	Escort	2. 0L	Zetec	ABS	✓	✓	✓	✓	0008
1999	Escort	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1999	Escort	2. 0L	Zetec	ECS	✓	✓	✓	✓	
1999	Escort	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1999	Escort	2. 0L	Zetec	PCM	✓	✓	✓	✓	0008, 0025
1999	Escort	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
1999	Escort	2. 0L	Zetec	RAP	✓	✓	✓	✓	
2000	Escort	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
2000	Escort	2. 0L	SPI	ECS	✓	✓	✓	✓	
2000	Escort	2. 0L	SPI	PATS	✓	✓	✓	✓	
2000	Escort	2. 0L	SPI	PCM	✓	✓	✓	✓	0025
2000	Escort	2. 0L	SPI	RAP	✓	✓	✓	✓	
2000	Escort	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	
2000	Escort	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2000	Escort	2. 0L	Zetec	ECS	✓	✓	✓	✓	
2000	Escort	2. 0L	Zetec	PATS	✓	✓	✓	✓	
2000	Escort	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
2000	Escort	2. 0L	Zetec	RAP	✓	✓	✓	✓	
2000. 5	Escort	1. 6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2000. 5	Escort	1. 6L	Zetec Rocam	CSM	✓	✓	✓	✓	
2000. 5	Escort	1. 6L	Zetec Rocam	HEC	✓	✓	✓	✓	
2000. 5	Escort	1. 6L	Zetec Rocam	PATS	✓	✓	✓	✓	
2000. 5	Escort	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2002	Escort	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
2002	Escort	2. 0L	SPI	ECS	✓	✓	✓	✓	
2002	Escort	2. 0L	SPI	PATS	✓	✓	✓	✓	
2002	Escort	2. 0L	SPI	PCM	✓	✓	✓	✓	0025
2002	Escort	2. 0L	SPI	RAP	✓	✓	✓	✓	
2002	Escort	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2002	Escort	2. 0L	Zetec	ECS	✓	✓	✓	✓	
2002	Escort	2. 0L	Zetec	PATS	✓	✓	✓	✓	
2002	Escort	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
2002	Escort	2. 0L	Zetec	RAP	✓	✓	✓	✓	
2003	Escort	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2003	Escort	2. 0L	Zetec	ECS	✓	✓	✓	✓	
2003	Escort	2. 0L	Zetec	PATS	✓	✓	✓	✓	
2003	Escort	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
2003	Escort	2. 0L	Zetec	RAP	✓	✓	✓	✓	
Other	Escort	1. 6L	PT-E	ABS/TCS	✓	✓	✓	✓	
Other	Escort	1. 6L	PT-E	CSM	✓	✓	✓	✓	
Other	Escort	1. 6L	PT-E	HEC	✓	✓	✓	✓	
Other	Escort	1. 6L	PT-E	PATS	✓	✓	✓	✓	
Other	Escort	1. 6L	PT-E	PCM	✓	✓	✓	✓	
Other	Escort	1. 8L	Endura-DE	ABS/TCS	✓	✓	✓	✓	
Other	Escort	1. 8L	Endura-DE	CSM	✓	✓	✓	✓	
Other	Escort	1. 8L	Endura-DE	HEC	✓	✓	✓	✓	
Other	Escort	1. 8L	Endura-DE	PATS	✓	✓	✓	✓	
Other	Escort	1. 8L	Endura-DE	PCM	✓	✓	✓	✓	
Other	Escort	1. 8L	Endura-DE	PCM	✓	✓	✓	✓	
2007	Everest / Endeavour	2. 5L	WL-CD	ABS/TCS	✓	✓	✓	✓	
2007	Everest / Endeavour	2. 5L	WL-CD	PCM	✓	✓	✓	✓	
2007	Everest / Endeavour	2. 5L	WL-CD	PCM	✓	✓	✓	✓	0055
2007	Everest / Endeavour	2. 5L	WL-CD	PCM	✓	✓	✓	✓	0055, 00CE
2007	Everest / Endeavour	2. 5L	WL-CD	RCM	✓	✓	✓	✓	
2007	Everest / Endeavour	2. 5L	WL-CD	TCM	✓	✓	✓	✓	
2007	Everest / Endeavour	2. 5L	WL-CD	TCM	✓	✓	✓	✓	00C5, 00CE
2007	Everest / Endeavour	2. 6L	G6	ABS/TCS	✓	✓	✓	✓	
2007	Everest / Endeavour	2. 6L	G6	PCM	✓	✓	✓	✓	
2007	Everest / Endeavour	2. 6L	G6	RCM	✓	✓	✓	✓	
2007	Everest / Endeavour	3. 0L	WE-CD	ABS/TCS	✓	✓	✓	✓	
2007	Everest / Endeavour	3. 0L	WE-CD	PCM	✓	✓	✓	✓	
2007	Everest / Endeavour	3. 0L	WE-CD	PCM	✓	✓	✓	✓	0055
2007	Everest / Endeavour	3. 0L	WE-CD	PCM	✓	✓	✓	✓	0055, 00CE
2007	Everest / Endeavour	3. 0L	WE-CD	RCM	✓	✓	✓	✓	
2007	Everest / Endeavour	3. 0L	WE-CD	TCM	✓	✓	✓	✓	
2007	Everest / Endeavour	3. 0L	WE-CD	TCM	✓	✓	✓	✓	00C5
2007	Everest / Endeavour	3. 0L	WE-CD	TCM	✓	✓	✓	✓	00C5, 00CE
2000	Excursion	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Excursion	5. 4L	Other	ECS	✓	✓	✓	✓	
2000	Excursion	5. 4L	Other	GEM	✓	✓	✓	✓	

2005	Excursion	6. 8L	2V	RCM	✓	✓	✓	✓	
2005	Excursion	6. 8L	2V	VSM	✓	✓	✓	✓	
1997	Expedition	4. 6L	Other	4WAS	✓	✓	✓	✓	
1997	Expedition	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Expedition	4. 6L	Other	GEM	✓	✓	✓	✓	
1997	Expedition	4. 6L	Other	IAB	✓	✓	✓	✓	
1997	Expedition	4. 6L	Other	PATS	✓	✓	✓	✓	
1997	Expedition	4. 6L	Other	PCM	✓	✓	✓	✓	0025
1997	Expedition	4. 6L	Other	RAP	✓	✓	✓	✓	
1997	Expedition	5. 4L	Other	4WAS	✓	✓	✓	✓	
1997	Expedition	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Expedition	5. 4L	Other	GEM	✓	✓	✓	✓	
1997	Expedition	5. 4L	Other	IAB	✓	✓	✓	✓	
1997	Expedition	5. 4L	Other	PATS	✓	✓	✓	✓	
1997	Expedition	5. 4L	Other	PCM	✓	✓	✓	✓	0025
1997	Expedition	5. 4L	Other	RAP	✓	✓	✓	✓	
1998	Expedition	4. 6L	Other	4WAS	✓	✓	✓	✓	
1998	Expedition	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Expedition	4. 6L	Other	GEM	✓	✓	✓	✓	
1998	Expedition	4. 6L	Other	IAB	✓	✓	✓	✓	
1998	Expedition	4. 6L	Other	PATS	✓	✓	✓	✓	
1998	Expedition	4. 6L	Other	PCM	✓	✓	✓	✓	0025
1998	Expedition	4. 6L	Other	RAP	✓	✓	✓	✓	
1998	Expedition	4. 6L	Other	RCC	✓	✓	✓	✓	
1998	Expedition	5. 4L	Other	4WAS	✓	✓	✓	✓	
1998	Expedition	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Expedition	5. 4L	Other	GEM	✓	✓	✓	✓	
1998	Expedition	5. 4L	Other	IAB	✓	✓	✓	✓	
1998	Expedition	5. 4L	Other	PATS	✓	✓	✓	✓	
1998	Expedition	5. 4L	Other	PCM	✓	✓	✓	✓	0025
1998	Expedition	5. 4L	Other	RAP	✓	✓	✓	✓	
1998	Expedition	5. 4L	Other	RCC	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	4WAS	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	4WAS	✓	✓	✓	✓	000E
1999	Expedition	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Expedition	4. 6L	Other	EATC	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	GEM	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	HEC	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	PCM	✓	✓	✓	✓	0025
1999	Expedition	4. 6L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1999	Expedition	4. 6L	Other	RAP	✓	✓	✓	✓	
1999	Expedition	4. 6L	Other	RCM	✓	✓	✓	✓	
1999	Expedition	5. 4L	Other	4WAS	✓	✓	✓	✓	
1999	Expedition	5. 4L	Other	4WAS	✓	✓	✓	✓	000E
1999	Expedition	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Expedition	5. 4L	Other	EATC	✓	✓	✓	✓	
1999	Expedition	5. 4L	Other	GEM	✓	✓	✓	✓	
1999	Expedition	5. 4L	Other	HEC	✓	✓	✓	✓	
1999	Expedition	5. 4L	Other	PCM	✓	✓	✓	✓	0025
1999	Expedition	5. 4L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1999	Expedition	5. 4L	Other	RAP	✓	✓	✓	✓	
1999	Expedition	5. 4L	Other	RCM	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	4WAS	✓	✓	✓	✓	000E
2000	Expedition	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Expedition	4. 6L	Other	DSM	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	EATC	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	GEM	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	HEC	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	PAM	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	PCM	✓	✓	✓	✓	0025
2000	Expedition	4. 6L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Expedition	4. 6L	Other	RAP	✓	✓	✓	✓	
2000	Expedition	4. 6L	Other	RCM	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	4WAS	✓	✓	✓	✓	000E
2000	Expedition	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Expedition	5. 4L	Other	DSM	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	EATC	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	GEM	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	HEC	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	PAM	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Expedition	5. 4L	Other	RAP	✓	✓	✓	✓	
2000	Expedition	5. 4L	Other	RCM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	4X4	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	Expedition	4. 6L	2V	DCSM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	DSM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	EATC	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	HEC	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	PAM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	PAM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Expedition	4. 6L	2V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2003	Expedition	4. 6L	2V	PCSM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2003	Expedition	4. 6L	2V	TPM	✓	✓	✓	✓	
2003	Expedition	4. 6L	2V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2003	Expedition	4. 6L	2V	VSM	✓	✓	✓	✓	

2007	Expedition	5. 4L	3V	GEM	✓	✓	✓	✓	F03C, F042, F049, F05C, F060, F068, F069, F06A
2007	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	F041, F044, F04A, F04D, F06B, F06E
2007	Expedition	5. 4L	3V	LTM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	PAM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0016, 0016, 0016, 0017, 0017, 0017, 0018, 0018, 0018, 0019, 00C5, F04D, F05A, F05A
2007	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0016, 0016, 0016, 0017, 0017, 0017, 0018, 0018, 0018, 0019, F04D, F05A, F05A
2007	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 00C5
2007	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	F022, F05D
2007	Expedition	5. 4L	3V	RCU	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	RCU	✓	✓	✓	✓	F05A
2007	Expedition	5. 4L	3V	RETM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	RETM	✓	✓	✓	✓	F04D, F05A
2007	Expedition	5. 4L	3V	SDARS	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	SDARS	✓	✓	✓	✓	0019
2007	Expedition	5. 4L	3V	TCM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	TCM	✓	✓	✓	✓	00CE
2007	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	
2007	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2008	Expedition	5. 4L	3V	4X4	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2008	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2008	Expedition	5. 4L	3V	DCSM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	DSM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	DSM	✓	✓	✓	✓	0005
2008	Expedition	5. 4L	3V	DSP	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	HVAC	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	0005
2008	Expedition	5. 4L	3V	LTM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	PAM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	PAM	✓	✓	✓	✓	0005
2008	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0019
2008	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 00C5
2008	Expedition	5. 4L	3V	PRB	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	0005
2008	Expedition	5. 4L	3V	RCU	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	RETM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	RETM	✓	✓	✓	✓	0005
2008	Expedition	5. 4L	3V	SDARS	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2008	Expedition	5. 4L	3V	TCM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	TCM	✓	✓	✓	✓	00CE
2008	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	
2008	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2009	Expedition	5. 4L	3V	4X4	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012, 0067
2009	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Expedition	5. 4L	3V	APIM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Expedition	5. 4L	3V	DCSM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	DSM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	DSP	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	Expedition	5. 4L	3V	HVAC	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	IC	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	LTM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	PAM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	PCM	✓	✓	✓	✓	0067
2009	Expedition	5. 4L	3V	PRB	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	RCM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	RCU	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	RETM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	SDARS	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	TCM	✓	✓	✓	✓	
2009	Expedition	5. 4L	3V	TCM	✓	✓	✓	✓	00CE
2009	Expedition	5. 4L	3V	VDM	✓	✓	✓	✓	

2012	Expedition	5.4L	3V	PRB	✓	✓	✓	✓	
2012	Expedition	5.4L	3V	RCM	✓	✓	✓	✓	
2012	Expedition	5.4L	3V	RCU	✓	✓	✓	✓	
2012	Expedition	5.4L	3V	RCU	✓	✓	✓	✓	
2012	Expedition	5.4L	3V	RETM	✓	✓	✓	✓	
2012	Expedition	5.4L	3V	SDARS	✓	✓	✓	✓	
2012	Expedition	5.4L	3V	TCCM	✓	✓	✓	✓	
2012	Expedition	5.4L	3V	VDM	✓	✓	✓	✓	
2012	Expedition	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2013	Expedition	5.4L	3V	ABS	✓	✓	✓	✓	0012
2013	Expedition	5.4L	3V	ACM	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2013	Expedition	5.4L	3V	APIM	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	APIM	✓	✓	✓	✓	0019
2013	Expedition	5.4L	3V	DCSM	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	DSM	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	DSP	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2013	Expedition	5.4L	3V	GPSM	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	HVAC	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	IC	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	LTM	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	PAM	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0018, 0025, 0028, 0028, 0031, 0031, 0033, 0067, 0108
2013	Expedition	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033
2013	Expedition	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	Expedition	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2013	Expedition	5.4L	3V	PRB	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	RCM	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	RCU	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	SDARS	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	TBC	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	TCCM	✓	✓	✓	✓	
2013	Expedition	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2013	Expedition	Other	Other	ABS	✓	✓	✓	✓	
2013	Expedition	Other	Other	ACM	✓	✓	✓	✓	
2013	Expedition	Other	Other	APIM	✓	✓	✓	✓	
2013	Expedition	Other	Other	DCSM	✓	✓	✓	✓	
2013	Expedition	Other	Other	DSM	✓	✓	✓	✓	
2013	Expedition	Other	Other	DSP	✓	✓	✓	✓	
2013	Expedition	Other	Other	GEM / SJB	✓	✓	✓	✓	
2013	Expedition	Other	Other	GPSM	✓	✓	✓	✓	
2013	Expedition	Other	Other	HVAC	✓	✓	✓	✓	
2013	Expedition	Other	Other	IC	✓	✓	✓	✓	
2013	Expedition	Other	Other	LTM	✓	✓	✓	✓	
2013	Expedition	Other	Other	PAM	✓	✓	✓	✓	
2013	Expedition	Other	Other	PCM	✓	✓	✓	✓	
2013	Expedition	Other	Other	PCM	✓	✓	✓	✓	
2013	Expedition	Other	Other	PRB	✓	✓	✓	✓	
2013	Expedition	Other	Other	RCM	✓	✓	✓	✓	
2013	Expedition	Other	Other	RCU	✓	✓	✓	✓	
2013	Expedition	Other	Other	SDARS	✓	✓	✓	✓	
2013	Expedition	Other	Other	TBC	✓	✓	✓	✓	
2013	Expedition	Other	Other	TCCM	✓	✓	✓	✓	
2013	Expedition	Other	Other	VDM	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	ABS	✓	✓	✓	✓	0012
2014	Expedition	5.4L	3V	ACM	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2014	Expedition	5.4L	3V	APIM	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	APIM	✓	✓	✓	✓	0019
2014	Expedition	5.4L	3V	DCSM	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	DSM	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	DSP	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2014	Expedition	5.4L	3V	GPSM	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	HVAC	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	IC	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	LTM	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	PAM	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0018, 0025, 0028, 0028, 0031, 0031, 0033, 0067, 0108
2014	Expedition	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033
2014	Expedition	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Expedition	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2014	Expedition	5.4L	3V	PRB	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	RCM	✓	✓	✓	✓	

2014	Expedition	5.4L	3V	RCU	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	SDARS	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	TBC	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	TCCM	✓	✓	✓	✓	
2014	Expedition	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2007	Expedition EL	5.4L	3V	4X4	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2007	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Expedition EL	5.4L	3V	DCSM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	DSM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	DSP	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	EATC	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	GEM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	IC	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	LTM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	PAM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Expedition EL	5.4L	3V	RCM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	RCU	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	RET	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	SDARS	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	SDARS	✓	✓	✓	✓	0019
2007	Expedition EL	5.4L	3V	TCM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	TCM	✓	✓	✓	✓	00CE
2007	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓	
2007	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2008	Expedition EL	5.4L	3V	4X4	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2008	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Expedition EL	5.4L	3V	DCSM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	DSM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	DSP	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	HVAC	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	IC	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	LTM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	PAM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Expedition EL	5.4L	3V	PRB	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	RCM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	RCU	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	RET	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	SDARS	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	SDARS	✓	✓	✓	✓	0019
2008	Expedition EL	5.4L	3V	TCM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	TCM	✓	✓	✓	✓	00CE
2008	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓	
2008	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2009	Expedition EL	5.4L	3V	4X4	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012, 0067
2009	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	0016
2009	Expedition EL	5.4L	3V	APIM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Expedition EL	5.4L	3V	DCSM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	DSM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	DSP	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	Expedition EL	5.4L	3V	HVAC	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	IC	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	LTM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	PAM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	PCM	✓	✓	✓	✓	0067
2009	Expedition EL	5.4L	3V	PRB	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	RCM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	RCU	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	RET	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	SDARS	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	TCM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓	
2009	Expedition EL	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2010	Expedition EL	5.4L	3V	4X4	✓	✓	✓	✓	
2010	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	
2010	Expedition EL	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2010	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	
2010	Expedition EL	5.4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2010	Expedition EL	5.4L	3V	APIM	✓	✓	✓	✓	
2010	Expedition EL	5.4L	3V	APIM	✓	✓	✓	✓	0019, 001C

2013	Expedition EL	5. 4L	3V	LTM	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	PAM	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2013	Expedition EL	5. 4L	3V	PRB	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	RCM	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	RCU	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	SDARS	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	TBC	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	TCCM	✓	✓	✓	✓	
2013	Expedition EL	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2013	Expedition EL	Other	Other	ABS	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	ACM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	APIM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	DCSM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	DSM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	DSP	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	GEM / SJB	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	GPSM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	HVAC	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	IC	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	LTM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	PAM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	PCM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	PRB	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	RCM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	RCU	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	SDARS	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	TBC	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	TCCM	✓	✓	✓	✓	
2013	Expedition EL	Other	Other	VDM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	ABS	✓	✓	✓	✓	0012
2014	Expedition EL	5. 4L	3V	ACM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2014	Expedition EL	5. 4L	3V	APIM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	APIM	✓	✓	✓	✓	0019
2014	Expedition EL	5. 4L	3V	DCSM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	DSM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	DSP	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2014	Expedition EL	5. 4L	3V	GPSM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	HVAC	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	IC	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	LTM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	PAM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2014	Expedition EL	5. 4L	3V	PRB	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	RCM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	RCU	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	SDARS	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	TBC	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	TCCM	✓	✓	✓	✓	
2014	Expedition EL	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
1996	Explorer	4. 0L	Other	ABS/TCS	✓	✓	✓	✓	
1996	Explorer	4. 0L	Other	ARC	✓	✓	✓	✓	
1996	Explorer	4. 0L	Other	EATC	✓	✓	✓	✓	
1996	Explorer	4. 0L	Other	GEM	✓	✓	✓	✓	0203
1996	Explorer	4. 0L	Other	IAB	✓	✓	✓	✓	
1996	Explorer	4. 0L	Other	PCM	✓	✓	✓	✓	0025
1996	Explorer	4. 0L	Other	RAP	✓	✓	✓	✓	
1996	Explorer	4. 0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1996	Explorer	4. 0L	V6 OHV	ARC	✓	✓	✓	✓	
1996	Explorer	4. 0L	V6 OHV	EATC	✓	✓	✓	✓	
1996	Explorer	4. 0L	V6 OHV	GEM	✓	✓	✓	✓	0203
1996	Explorer	4. 0L	V6 OHV	IAB	✓	✓	✓	✓	
1996	Explorer	4. 0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1996	Explorer	4. 0L	V6 OHV	RAP	✓	✓	✓	✓	
1996	Explorer	5. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1996	Explorer	5. 0L	Other	EATC	✓	✓	✓	✓	
1996	Explorer	5. 0L	Other	GEM	✓	✓	✓	✓	0203
1996	Explorer	5. 0L	Other	IAB	✓	✓	✓	✓	
1996	Explorer	5. 0L	Other	PCM	✓	✓	✓	✓	0025
1996	Explorer	5. 0L	Other	RAP	✓	✓	✓	✓	
1997	Explorer	4. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Explorer	4. 0L	Other	ARC	✓	✓	✓	✓	
1997	Explorer	4. 0L	Other	EATC	✓	✓	✓	✓	
1997	Explorer	4. 0L	Other	GEM	✓	✓	✓	✓	0203
1997	Explorer	4. 0L	Other	IAB	✓	✓	✓	✓	
1997	Explorer	4. 0L	Other	PCM	✓	✓	✓	✓	0025
1997	Explorer	4. 0L	Other	RAP	✓	✓	✓	✓	
1997	Explorer	4. 0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	0008
1997	Explorer	4. 0L	V6 OHV	ARC	✓	✓	✓	✓	
1997	Explorer	4. 0L	V6 OHV	EATC	✓	✓	✓	✓	
1997	Explorer	4. 0L	V6 OHV	GEM	✓	✓	✓	✓	0203
1997	Explorer	4. 0L	V6 OHV	IAB	✓	✓	✓	✓	
1997	Explorer	4. 0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1997	Explorer	4. 0L	V6 OHV	RAP	✓	✓	✓	✓	

1997	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
1997	Explorer	4.0L	V6 SOHC	ARC	✓	✓	✓		
1997	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓		
1997	Explorer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
1997	Explorer	4.0L	V6 SOHC	IAB	✓	✓	✓		
1997	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
1997	Explorer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
1997	Explorer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Explorer	5.0L	Other	ARC	✓	✓	✓		
1997	Explorer	5.0L	Other	ARC	✓	✓	✓		000E
1997	Explorer	5.0L	Other	EATC	✓	✓	✓		
1997	Explorer	5.0L	Other	GEM	✓	✓	✓	✓	0203
1997	Explorer	5.0L	Other	IAB	✓	✓	✓		
1997	Explorer	5.0L	Other	PCM	✓	✓	✓	✓	0025
1997	Explorer	5.0L	Other	RAP	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Explorer	4.0L	Other	ARC	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	DSM	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	EATC	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	GEM	✓	✓	✓	✓	0203
1998	Explorer	4.0L	Other	IAB	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	PAM	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	PATS	✓	✓	✓	✓	
1998	Explorer	4.0L	Other	PCM	✓	✓	✓	✓	0025
1998	Explorer	4.0L	Other	RAP	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	0008
1998	Explorer	4.0L	V6 OHV	ARC	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	DSM	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	EATC	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	GEM	✓	✓	✓	✓	0203
1998	Explorer	4.0L	V6 OHV	IAB	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	PAM	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	PATS	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1998	Explorer	4.0L	V6 OHV	RAP	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
1998	Explorer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
1998	Explorer	4.0L	V6 SOHC	IAB	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓	
1998	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
1998	Explorer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Explorer	5.0L	Other	ARC	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	DSM	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	EATC	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	GEM	✓	✓	✓	✓	0203
1998	Explorer	5.0L	Other	IAB	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	PAM	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	PATS	✓	✓	✓	✓	
1998	Explorer	5.0L	Other	PCM	✓	✓	✓	✓	0025
1998	Explorer	5.0L	Other	RAP	✓	✓	✓	✓	
1999	Explorer	4.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Explorer	4.0L	Other	ARC	✓	✓	✓	✓	000E
1999	Explorer	4.0L	Other	DSM	✓	✓	✓	✓	
1999	Explorer	4.0L	Other	EATC	✓	✓	✓	✓	
1999	Explorer	4.0L	Other	GEM	✓	✓	✓	✓	0203
1999	Explorer	4.0L	Other	PAM	✓	✓	✓	✓	
1999	Explorer	4.0L	Other	PATS	✓	✓	✓	✓	
1999	Explorer	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025
1999	Explorer	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
1999	Explorer	4.0L	Other	RAP	✓	✓	✓	✓	
1999	Explorer	4.0L	Other	RCM	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	0008
1999	Explorer	4.0L	V6 OHV	ARC	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	DSM	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	EATC	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	GEM	✓	✓	✓	✓	0203
1999	Explorer	4.0L	V6 OHV	PAM	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	PATS	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1999	Explorer	4.0L	V6 OHV	RAP	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 OHV	RCM	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
1999	Explorer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓	000E
1999	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
1999	Explorer	4.0L	V6 SOHC	MC	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓	
1999	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
1999	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
1999	Explorer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	

1999	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
1999	Explorer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Explorer	5.0L	Other	ARC	✓	✓	✓	✓	000E
1999	Explorer	5.0L	Other	DSM	✓	✓	✓	✓	
1999	Explorer	5.0L	Other	EATC	✓	✓	✓	✓	
1999	Explorer	5.0L	Other	GEM	✓	✓	✓	✓	0005, 0203
1999	Explorer	5.0L	Other	GEM	✓	✓	✓	✓	0203
1999	Explorer	5.0L	Other	PAM	✓	✓	✓	✓	
1999	Explorer	5.0L	Other	PATS	✓	✓	✓	✓	
1999	Explorer	5.0L	Other	PCM	✓	✓	✓	✓	0005, 0008, 0025, 0028, 0031, 0033
1999	Explorer	5.0L	Other	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
1999	Explorer	5.0L	Other	RAP	✓	✓	✓	✓	
1999	Explorer	5.0L	Other	RAP	✓	✓	✓	✓	0005, F044
1999	Explorer	5.0L	Other	RCM	✓	✓	✓	✓	
2000	Explorer	4.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Explorer	4.0L	Other	ARC	✓	✓	✓	✓	000E
2000	Explorer	4.0L	Other	DSM	✓	✓	✓	✓	
2000	Explorer	4.0L	Other	EATC	✓	✓	✓	✓	
2000	Explorer	4.0L	Other	GEM	✓	✓	✓	✓	0203
2000	Explorer	4.0L	Other	PAM	✓	✓	✓	✓	
2000	Explorer	4.0L	Other	PATS	✓	✓	✓	✓	
2000	Explorer	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025
2000	Explorer	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2000	Explorer	4.0L	Other	RAP	✓	✓	✓	✓	
2000	Explorer	4.0L	Other	RCM	✓	✓	✓	✓	
2000	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2000	Explorer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓	000E
2000	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2000	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2000	Explorer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
2000	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2000	Explorer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓	
2000	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2000	Explorer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
2000	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2000	Explorer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0005, 0008
2000	Explorer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Explorer	5.0L	Other	ARC	✓	✓	✓	✓	000E
2000	Explorer	5.0L	Other	DSM	✓	✓	✓	✓	
2000	Explorer	5.0L	Other	EATC	✓	✓	✓	✓	
2000	Explorer	5.0L	Other	GEM	✓	✓	✓	✓	0005, 0203
2000	Explorer	5.0L	Other	GEM	✓	✓	✓	✓	0203
2000	Explorer	5.0L	Other	PAM	✓	✓	✓	✓	
2000	Explorer	5.0L	Other	PATS	✓	✓	✓	✓	
2000	Explorer	5.0L	Other	PCM	✓	✓	✓	✓	0005, 0008, 0025, 0028, 0031, 0033
2000	Explorer	5.0L	Other	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2000	Explorer	5.0L	Other	RAP	✓	✓	✓	✓	
2000	Explorer	5.0L	Other	RAP	✓	✓	✓	✓	0005, F044
2000	Explorer	5.0L	Other	RCM	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2002	Explorer	4.0L	V6 SOHC	CSM	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
2002	Explorer	4.0L	V6 SOHC	IC	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2002	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	4X4	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2002	Explorer	4.6L	2V	CSM	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	DSM	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	EATC	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	GEM	✓	✓	✓	✓	0203
2002	Explorer	4.6L	2V	IC	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	PAM	✓	✓	✓	✓	
2002	Explorer	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Explorer	4.6L	2V	RCM	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2002.5	Explorer	4.0L	V6 SOHC	CSM	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	HEC	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2002.5	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002.5	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2002.5	Explorer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓	
2002.5	Explorer	4.6L	2V	4X4	✓	✓	✓	✓	
2002.5	Explorer	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2002.5	Explorer	4.6L	2V	CSM	✓	✓	✓	✓	
2002.5	Explorer	4.6L	2V	DSM	✓	✓	✓	✓	

2002.5	Explorer	4.6L	2V	EATC	✓	✓	✓	✓	
2002.5	Explorer	4.6L	2V	HEC	✓	✓	✓	✓	
2002.5	Explorer	4.6L	2V	PAM	✓	✓	✓	✓	
2002.5	Explorer	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002.5	Explorer	4.6L	2V	RCM	✓	✓	✓	✓	000C
2002.5	Explorer	4.6L	2V	TPM	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2003	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	HEC	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2003	Explorer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓	
2003	Explorer	4.0L	V6 SOHC	VSM	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	4X4	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	Explorer	4.6L	2V	DSM	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	EATC	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	HEC	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	PAM	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Explorer	4.6L	2V	RCM	✓	✓	✓	✓	000C
2003	Explorer	4.6L	2V	TPM	✓	✓	✓	✓	
2003	Explorer	4.6L	2V	VSM	✓	✓	✓	✓	
2004	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2004	Explorer	4.0L	V6 SOHC	ABS	✓	✓	✓	✓	0008, 0012
2004	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2004	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	0005
2004	Explorer	4.0L	V6 SOHC	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054, F071, F072
2004	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2004	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2004	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2004	Explorer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓	0005
2004	Explorer	4.0L	V6 SOHC	VSM	✓	✓	✓	✓	
2004	Explorer	4.6L	2V	4X4	✓	✓	✓	✓	
2004	Explorer	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2004	Explorer	4.6L	2V	DSM	✓	✓	✓	✓	
2004	Explorer	4.6L	2V	EATC	✓	✓	✓	✓	0005
2004	Explorer	4.6L	2V	IC	✓	✓	✓	✓	0005
2004	Explorer	4.6L	2V	PAM	✓	✓	✓	✓	
2004	Explorer	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Explorer	4.6L	2V	RCM	✓	✓	✓	✓	000C
2004	Explorer	4.6L	2V	TPM	✓	✓	✓	✓	0005
2004	Explorer	4.6L	2V	VSM	✓	✓	✓	✓	
2005	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2005	Explorer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	0111
2005	Explorer	4.0L	V6 SOHC	ABS	✓	✓	✓	✓	0005, 0008, 0012
2005	Explorer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2005	Explorer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2005	Explorer	4.0L	V6 SOHC	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054, F071, F072
2005	Explorer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2005	Explorer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Explorer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2005	Explorer	4.0L	V6 SOHC	TPM	✓	✓	✓	✓	0005
2005	Explorer	4.0L	V6 SOHC	VSM	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	4X4	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2005	Explorer	4.6L	2V	DSM	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	EATC	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	IC	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	PAM	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Explorer	4.6L	2V	RCM	✓	✓	✓	✓	000C
2005	Explorer	4.6L	2V	TPM	✓	✓	✓	✓	
2005	Explorer	4.6L	2V	VSM	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	4X4	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2006	Explorer	4.0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2006	Explorer	4.0L	2V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F05A, F073
2006	Explorer	4.0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2006	Explorer	4.0L	2V	DSM	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	EATC	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	GEM	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2006	Explorer	4.0L	2V	IC	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	IC	✓	✓	✓	✓	F027, F040, F044, F04D, F054, F06B
2006	Explorer	4.0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2006	Explorer	4.0L	2V	PAM	✓	✓	✓	✓	
2006	Explorer	4.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Explorer	4.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5

2006	Explorer	4. 0L	2V	PRB	✓	✓	✓	✓	
2006	Explorer	4. 0L	2V	RCM	✓	✓	✓	✓	
2006	Explorer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2006	Explorer	4. 0L	2V	RETM	✓	✓	✓	✓	
2006	Explorer	4. 0L	2V	RETM	✓	✓	✓	✓	F04D, F05A
2006	Explorer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005, 0019
2006	Explorer	4. 0L	2V	SDARS	✓	✓	✓	✓	0019
2006	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	0111
2006	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2006	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2006	Explorer	4. 6L	3V	DSM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	EATC	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	EATC	✓	✓	✓	✓	0005
2006	Explorer	4. 6L	3V	GEM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	GEM	✓	✓	✓	✓	0005
2006	Explorer	4. 6L	3V	IC	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2006	Explorer	4. 6L	3V	PAM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2006	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 00C5
2006	Explorer	4. 6L	3V	PRB	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	RCM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	RCM	✓	✓	✓	✓	0005
2006	Explorer	4. 6L	3V	RETM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	RETM	✓	✓	✓	✓	0005
2006	Explorer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2006	Explorer	4. 6L	3V	TCM	✓	✓	✓	✓	
2006	Explorer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2007	Explorer	4. 0L	2V	4X4	✓	✓	✓	✓	
2007	Explorer	4. 0L	2V	ABS	✓	✓	✓	✓	
2007	Explorer	4. 0L	2V	ACM	✓	✓	✓	✓	0005, 0008, 0012
2007	Explorer	4. 0L	2V	DSM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F05A, F073
2007	Explorer	4. 0L	2V	EATC	✓	✓	✓	✓	F041, F074, F075
2007	Explorer	4. 0L	2V	GEM	✓	✓	✓	✓	
2007	Explorer	4. 0L	2V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2007	Explorer	4. 0L	2V	IC	✓	✓	✓	✓	F027, F040, F044, F04D, F054, F06B
2007	Explorer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Explorer	4. 0L	2V	PAM	✓	✓	✓	✓	
2007	Explorer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Explorer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Explorer	4. 0L	2V	PRB	✓	✓	✓	✓	
2007	Explorer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Explorer	4. 0L	2V	RETM	✓	✓	✓	✓	F04D, F05A
2007	Explorer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	0111
2007	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2007	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F04D, F05A, F073
2007	Explorer	4. 6L	3V	DSM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	EATC	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	EATC	✓	✓	✓	✓	0005
2007	Explorer	4. 6L	3V	GEM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2007	Explorer	4. 6L	3V	IC	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	IC	✓	✓	✓	✓	F044
2007	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Explorer	4. 6L	3V	PAM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2007	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2007	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Explorer	4. 6L	3V	PRB	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	RCM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Explorer	4. 6L	3V	RETM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	RETM	✓	✓	✓	✓	0005, F04D, F05A
2007	Explorer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Explorer	4. 6L	3V	TCM	✓	✓	✓	✓	
2007	Explorer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2008	Explorer	4. 0L	2V	4X4	✓	✓	✓	✓	
2008	Explorer	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2008	Explorer	4. 0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012

2008	Explorer	4. 0L	2V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F05A, F073
2008	Explorer	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2008	Explorer	4. 0L	2V	DSM	✓	✓	✓	✓	F041, F074, F075
2008	Explorer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2008	Explorer	4. 0L	2V	HVAC	✓	✓	✓	✓	
2008	Explorer	4. 0L	2V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2008	Explorer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Explorer	4. 0L	2V	PAM	✓	✓	✓	✓	
2008	Explorer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Explorer	4. 0L	2V	PRB	✓	✓	✓	✓	
2008	Explorer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2008	Explorer	4. 0L	2V	RETM	✓	✓	✓	✓	F04D, F05A
2008	Explorer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005
2008	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	0111
2008	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2008	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Explorer	4. 6L	3V	APIM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2008	Explorer	4. 6L	3V	DSM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	DSM	✓	✓	✓	✓	F041, F074, F075
2008	Explorer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2008	Explorer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042, F042, F044, F04C
2008	Explorer	4. 6L	3V	HVAC	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	IC	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2008	Explorer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Explorer	4. 6L	3V	PAM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0028, 0031, 0031, 0031, 0033, 0033, 0033, 00C5
2008	Explorer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2008	Explorer	4. 6L	3V	PRB	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	RCM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	RCM	✓	✓	✓	✓	F022, F05D
2008	Explorer	4. 6L	3V	RETM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	RETM	✓	✓	✓	✓	F05A
2008	Explorer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	TCM	✓	✓	✓	✓	
2008	Explorer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2009	Explorer	4. 0L	2V	4X4	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2009	Explorer	4. 0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2009	Explorer	4. 0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	Explorer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Explorer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0018
2009	Explorer	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2009	Explorer	4. 0L	2V	DSM	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	DSM	✓	✓	✓	✓	0005, F041, F074, F075
2009	Explorer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2009	Explorer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	Explorer	4. 0L	2V	HVAC	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	HVAC	✓	✓	✓	✓	0005
2009	Explorer	4. 0L	2V	IC	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	IC	✓	✓	✓	✓	0005, F044
2009	Explorer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Explorer	4. 0L	2V	PAM	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Explorer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Explorer	4. 0L	2V	PRB	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	RCM	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Explorer	4. 0L	2V	RETM	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	RETM	✓	✓	✓	✓	F04D, F05A, F076
2009	Explorer	4. 0L	2V	SDARS	✓	✓	✓	✓	
2009	Explorer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005
2009	Explorer	4. 6L	3V	4X4	✓	✓	✓	✓	
2009	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	
2009	Explorer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2009	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2009	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	Explorer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0018
2009	Explorer	4. 6L	3V	APIM	✓	✓	✓	✓	
2009	Explorer	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Explorer	4. 6L	3V	DSM	✓	✓	✓	✓	
2009	Explorer	4. 6L	3V	DSM	✓	✓	✓	✓	0005, F041, F074, F075

2009	Explorer	4.6L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2009	Explorer	4.6L	3V	HVAC	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	HVAC	✓	✓	✓	✓	0005
2009	Explorer	4.6L	3V	IC	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2009	Explorer	4.6L	3V	OCSM	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Explorer	4.6L	3V	PAM	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	PCM	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2009	Explorer	4.6L	3V	PRB	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	RCM	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Explorer	4.6L	3V	RETM	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	RETM	✓	✓	✓	✓	F04D, F05A, F076
2009	Explorer	4.6L	3V	SDARS	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	TCM	✓	✓	✓	✓	
2009	Explorer	4.6L	3V	TCM	✓	✓	✓	✓	00CE
2010	Explorer	4.0L	2V	4X4	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	4X4	✓	✓	✓	✓	0111
2010	Explorer	4.0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	Explorer	4.0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2010	Explorer	4.0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0018
2010	Explorer	4.0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2010	Explorer	4.0L	2V	DSM	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	GEM / SJB	✓	✓	✓	✓	0042
2010	Explorer	4.0L	2V	GPSM	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	HVAC	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	IC	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Explorer	4.0L	2V	PAM	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	PCM	✓	✓	✓	✓	0025
2010	Explorer	4.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Explorer	4.0L	2V	PRB	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	RCM	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	RETM	✓	✓	✓	✓	
2010	Explorer	4.0L	2V	SDARS	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	4X4	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	ABS	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Explorer	4.6L	3V	ACM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2010	Explorer	4.6L	3V	ACM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0018
2010	Explorer	4.6L	3V	APIM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2010	Explorer	4.6L	3V	DSM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	DSM	✓	✓	✓	✓	0005, F041, F074, F075
2010	Explorer	4.6L	3V	GEM / SJB	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2010	Explorer	4.6L	3V	GPSM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	HVAC	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	HVAC	✓	✓	✓	✓	0005
2010	Explorer	4.6L	3V	IC	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2010	Explorer	4.6L	3V	OCSM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Explorer	4.6L	3V	PAM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	PCM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2010	Explorer	4.6L	3V	PRB	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	RCM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	RETM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	RETM	✓	✓	✓	✓	F04D, F05A, F076
2010	Explorer	4.6L	3V	SDARS	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	TCM	✓	✓	✓	✓	
2010	Explorer	4.6L	3V	TCM	✓	✓	✓	✓	00CE
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM	✓	✓	✓	✓	

2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D5, 00FE
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	CLM#1	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2011	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TPM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2011	Explorer	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	ATCM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	Explorer	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2011	Explorer	3.5L	TiVCT	CLM#1	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	DSM	✓	✓	✓	✓	

2011	Explorer	3.5L	TiVCT	DSP	✓	✓	✓		
2011	Explorer	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	FLM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	HSWM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C
2011	Explorer	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	PCM	✓	✓	✓	✓	0067, 0095
2011	Explorer	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2011	Explorer	3.5L	TiVCT	TPM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM#1	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C

2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0095
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2012	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TPM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	Explorer	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	ATCM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	Explorer	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2012	Explorer	3.5L	TiVCT	CLM#1	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	FLM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	GPMS	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C
2012	Explorer	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	PCM	✓	✓	✓	✓	0067, 0095
2012	Explorer	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2012	Explorer	3.5L	TiVCT	TPM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ATCM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE

2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	CLM#1	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0095
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	

2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2013	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	0028, 0031, 0033
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ATCM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	CLM#1	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108

2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	ABS	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	Explorer	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	ATCM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Explorer	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Explorer	3.5L	TiVCT	CLM#1	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	FLM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	GFM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	HSWM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2013	Explorer	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	Explorer	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2013	Explorer	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Explorer	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	Explorer	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	ATCM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Explorer	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Explorer	3.7L	TiVCT	CLM#1	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	GFM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2013	Explorer	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	Explorer	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095
2013	Explorer	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	RTM	✓	✓	✓	✓	

2013	Explorer	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Explorer	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ATCM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CLM#1	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00CE, 0108
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	

2014	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Explorer	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ATCM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	CLM#1	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FLM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	

2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RLCM-A	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Explorer	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2014	Explorer	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	ATCM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Explorer	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Explorer	3.5L	TiVCT	CLM#1	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	FLM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	GFM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	HSWM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	Explorer	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Explorer	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Explorer	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	RLCM-A	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Explorer	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2014	Explorer	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	ATCM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Explorer	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Explorer	3.7L	TiVCT	CLM#1	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	GFM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	Explorer	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Explorer	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Explorer	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	RLCM-A	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Explorer	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Explorer	Other	Other	ABS	✓	✓	✓	✓	
2014	Explorer	Other	Other	ACM	✓	✓	✓	✓	
2014	Explorer	Other	Other	APIM	✓	✓	✓	✓	
2014	Explorer	Other	Other	ATCM	✓	✓	✓	✓	
2014	Explorer	Other	Other	BCM#1	✓	✓	✓	✓	

2004	Explorer SportTrac	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2005	Explorer SportTrac	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2005	Explorer SportTrac	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2005	Explorer SportTrac	4.0L	V6 SOHC	HEC	✓	✓	✓	✓	
2005	Explorer SportTrac	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Explorer SportTrac	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
2005	Explorer SportTrac	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2007	Explorer SportTrac	4.0L	2V	4X4	✓	✓	✓	✓	
2007	Explorer SportTrac	4.0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2007	Explorer SportTrac	4.0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Explorer SportTrac	4.0L	2V	EATC	✓	✓	✓	✓	
2007	Explorer SportTrac	4.0L	2V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2007	Explorer SportTrac	4.0L	2V	IC	✓	✓	✓	✓	F027, F040, F044, F04D, F054, F06B
2007	Explorer SportTrac	4.0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Explorer SportTrac	4.0L	2V	PAM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Explorer SportTrac	4.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Explorer SportTrac	4.0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Explorer SportTrac	4.0L	2V	RETM	✓	✓	✓	✓	F04D, F05A
2007	Explorer SportTrac	4.0L	2V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Explorer SportTrac	4.6L	3V	4X4	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	4X4	✓	✓	✓	✓	0111
2007	Explorer SportTrac	4.6L	3V	ABS	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2007	Explorer SportTrac	4.6L	3V	ACM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Explorer SportTrac	4.6L	3V	EATC	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	EATC	✓	✓	✓	✓	0005
2007	Explorer SportTrac	4.6L	3V	GEM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	GEM	✓	✓	✓	✓	0005
2007	Explorer SportTrac	4.6L	3V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2007	Explorer SportTrac	4.6L	3V	IC	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	IC	✓	✓	✓	✓	F044
2007	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Explorer SportTrac	4.6L	3V	PAM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	PAM	✓	✓	✓	✓	0005
2007	Explorer SportTrac	4.6L	3V	PCM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2007	Explorer SportTrac	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Explorer SportTrac	4.6L	3V	RCM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	RCM	✓	✓	✓	✓	0005
2007	Explorer SportTrac	4.6L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Explorer SportTrac	4.6L	3V	RETM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	RETM	✓	✓	✓	✓	0005
2007	Explorer SportTrac	4.6L	3V	RETM	✓	✓	✓	✓	0005, F04D, F05A
2007	Explorer SportTrac	4.6L	3V	SDARS	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Explorer SportTrac	4.6L	3V	TCM	✓	✓	✓	✓	
2007	Explorer SportTrac	4.6L	3V	TCM	✓	✓	✓	✓	00CE
2008	Explorer SportTrac	4.0L	2V	4X4	✓	✓	✓	✓	
2008	Explorer SportTrac	4.0L	2V	4X4	✓	✓	✓	✓	0111
2008	Explorer SportTrac	4.0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2008	Explorer SportTrac	4.0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Explorer SportTrac	4.0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2008	Explorer SportTrac	4.0L	2V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2008	Explorer SportTrac	4.0L	2V	HVAC	✓	✓	✓	✓	
2008	Explorer SportTrac	4.0L	2V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2008	Explorer SportTrac	4.0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Explorer SportTrac	4.0L	2V	PAM	✓	✓	✓	✓	
2008	Explorer SportTrac	4.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Explorer SportTrac	4.0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2008	Explorer SportTrac	4.0L	2V	RETM	✓	✓	✓	✓	F04D, F05A
2008	Explorer SportTrac	4.0L	2V	SDARS	✓	✓	✓	✓	0005
2008	Explorer SportTrac	4.6L	3V	4X4	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	4X4	✓	✓	✓	✓	0111
2008	Explorer SportTrac	4.6L	3V	ABS	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2008	Explorer SportTrac	4.6L	3V	ACM	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Explorer SportTrac	4.6L	3V	APIM	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2008	Explorer SportTrac	4.6L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2008	Explorer SportTrac	4.6L	3V	GEM / SJB	✓	✓	✓	✓	0042, F042, F044, F04C
2008	Explorer SportTrac	4.6L	3V	HVAC	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	IC	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2008	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Explorer SportTrac	4.6L	3V	PAM	✓	✓	✓	✓	
2008	Explorer SportTrac	4.6L	3V	PCM	✓	✓	✓	✓	

2008	Explorer SportTrac	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0028, 0031, 0031, 0031, 0033, 0033, 0033, 00C5
2008	Explorer SportTrac	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2008	Explorer SportTrac	4. 6L	3V	RCM	✓	✓	✓	✓	
2008	Explorer SportTrac	4. 6L	3V	RCM	✓	✓	✓	✓	F022, F05D
2008	Explorer SportTrac	4. 6L	3V	RETM	✓	✓	✓	✓	
2008	Explorer SportTrac	4. 6L	3V	RETM	✓	✓	✓	✓	F05A
2008	Explorer SportTrac	4. 6L	3V	SDARS	✓	✓	✓	✓	
2008	Explorer SportTrac	4. 6L	3V	TCM	✓	✓	✓	✓	
2008	Explorer SportTrac	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2009	Explorer SportTrac	4. 0L	2V	4X4	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2009	Explorer SportTrac	4. 0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	Explorer SportTrac	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Explorer SportTrac	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0018
2009	Explorer SportTrac	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2009	Explorer SportTrac	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2009	Explorer SportTrac	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	Explorer SportTrac	4. 0L	2V	HVAC	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	HVAC	✓	✓	✓	✓	0005
2009	Explorer SportTrac	4. 0L	2V	IC	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	IC	✓	✓	✓	✓	0005, F044
2009	Explorer SportTrac	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Explorer SportTrac	4. 0L	2V	PAM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Explorer SportTrac	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Explorer SportTrac	4. 0L	2V	RCM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Explorer SportTrac	4. 0L	2V	RETM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	SDARS	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 0L	2V	SDARS	✓	✓	✓	✓	0005
2009	Explorer SportTrac	4. 6L	3V	4X4	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	ABS	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2009	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2009	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0018
2009	Explorer SportTrac	4. 6L	3V	APIM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Explorer SportTrac	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2009	Explorer SportTrac	4. 6L	3V	HVAC	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	HVAC	✓	✓	✓	✓	0005
2009	Explorer SportTrac	4. 6L	3V	IC	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2009	Explorer SportTrac	4. 6L	3V	OCSM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Explorer SportTrac	4. 6L	3V	PAM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2009	Explorer SportTrac	4. 6L	3V	PCM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2009	Explorer SportTrac	4. 6L	3V	RCM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Explorer SportTrac	4. 6L	3V	RETM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	SDARS	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	TCM	✓	✓	✓	✓	
2009	Explorer SportTrac	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2010	Explorer SportTrac	4. 0L	2V	4X4	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2010	Explorer SportTrac	4. 0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	Explorer SportTrac	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2010	Explorer SportTrac	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0018
2010	Explorer SportTrac	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2010	Explorer SportTrac	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0042
2010	Explorer SportTrac	4. 0L	2V	GPSM	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	HVAC	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	IC	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Explorer SportTrac	4. 0L	2V	PAM	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	PCM	✓	✓	✓	✓	0025
2010	Explorer SportTrac	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Explorer SportTrac	4. 0L	2V	RCM	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	RETM	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 0L	2V	SDARS	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 6L	3V	4X4	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 6L	3V	ABS	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2010	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	
2010	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2010	Explorer SportTrac	4. 6L	3V	ACM	✓	✓	✓	✓	

2010	Explorer SportTrac	4.6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0018
2010	Explorer SportTrac	4.6L	3V	APIM	✓	✓	✓		
2010	Explorer SportTrac	4.6L	3V	APIM	✓	✓	✓		0019, 001C
2010	Explorer SportTrac	4.6L	3V	GEM / SJB	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2010	Explorer SportTrac	4.6L	3V	GPSM	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	HVAC	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	HVAC	✓	✓	✓	✓	0005
2010	Explorer SportTrac	4.6L	3V	IC	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2010	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Explorer SportTrac	4.6L	3V	PAM	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	PAM	✓	✓	✓	✓	0005
2010	Explorer SportTrac	4.6L	3V	PCM	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2010	Explorer SportTrac	4.6L	3V	RCM	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	RET	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	SDARS	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	TCM	✓	✓	✓	✓	
2010	Explorer SportTrac	4.6L	3V	TCM	✓	✓	✓	✓	00CE
1997	F-150	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	F-150	4.2L	Other	GEM	✓	✓	✓	✓	
1997	F-150	4.2L	Other	IAB	✓	✓	✓	✓	
1997	F-150	4.2L	Other	PCM	✓	✓	✓	✓	0025
1997	F-150	4.2L	Other	RAP	✓	✓	✓	✓	
1997	F-150	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	F-150	4.6L	Other	GEM	✓	✓	✓	✓	
1997	F-150	4.6L	Other	IAB	✓	✓	✓	✓	
1997	F-150	4.6L	Other	PCM	✓	✓	✓	✓	0025
1997	F-150	4.6L	Other	RAP	✓	✓	✓	✓	
1997	F-150	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	F-150	5.4L	Other	GEM	✓	✓	✓	✓	
1997	F-150	5.4L	Other	IAB	✓	✓	✓	✓	
1997	F-150	5.4L	Other	PCM	✓	✓	✓	✓	0025
1997	F-150	5.4L	Other	RAP	✓	✓	✓	✓	
1998	F-150	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	F-150	4.2L	Other	GEM	✓	✓	✓	✓	
1998	F-150	4.2L	Other	IAB	✓	✓	✓	✓	
1998	F-150	4.2L	Other	PCM	✓	✓	✓	✓	0025
1998	F-150	4.2L	Other	RAP	✓	✓	✓	✓	
1998	F-150	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	F-150	4.6L	Other	GEM	✓	✓	✓	✓	
1998	F-150	4.6L	Other	IAB	✓	✓	✓	✓	
1998	F-150	4.6L	Other	PCM	✓	✓	✓	✓	0025
1998	F-150	4.6L	Other	RAP	✓	✓	✓	✓	
1998	F-150	5.4L	BIF	ABS/TCS	✓	✓	✓	✓	0008
1998	F-150	5.4L	BIF	AFCM	✓	✓	✓	✓	
1998	F-150	5.4L	BIF	GEM	✓	✓	✓	✓	
1998	F-150	5.4L	BIF	IAB	✓	✓	✓	✓	
1998	F-150	5.4L	BIF	PCM	✓	✓	✓	✓	
1998	F-150	5.4L	BIF	RAP	✓	✓	✓	✓	
1998	F-150	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	F-150	5.4L	Other	GEM	✓	✓	✓	✓	
1998	F-150	5.4L	Other	IAB	✓	✓	✓	✓	
1998	F-150	5.4L	Other	PCM	✓	✓	✓	✓	0025
1998	F-150	5.4L	Other	RAP	✓	✓	✓	✓	
1999	F-150	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-150	4.2L	Other	GEM	✓	✓	✓	✓	
1999	F-150	4.2L	Other	IAB	✓	✓	✓	✓	
1999	F-150	4.2L	Other	IC	✓	✓	✓	✓	
1999	F-150	4.2L	Other	PCM	✓	✓	✓	✓	0025
1999	F-150	4.2L	Other	RAP	✓	✓	✓	✓	
1999	F-150	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-150	4.6L	Other	GEM	✓	✓	✓	✓	
1999	F-150	4.6L	Other	IAB	✓	✓	✓	✓	
1999	F-150	4.6L	Other	IC	✓	✓	✓	✓	
1999	F-150	4.6L	Other	PCM	✓	✓	✓	✓	0025
1999	F-150	4.6L	Other	RAP	✓	✓	✓	✓	
1999	F-150	5.4L	BIF	ABS/TCS	✓	✓	✓	✓	0008
1999	F-150	5.4L	BIF	AFCM	✓	✓	✓	✓	
1999	F-150	5.4L	BIF	GEM	✓	✓	✓	✓	
1999	F-150	5.4L	BIF	IAB	✓	✓	✓	✓	
1999	F-150	5.4L	BIF	IC	✓	✓	✓	✓	
1999	F-150	5.4L	BIF	PCM	✓	✓	✓	✓	
1999	F-150	5.4L	BIF	RAP	✓	✓	✓	✓	
1999	F-150	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-150	5.4L	Other	GEM	✓	✓	✓	✓	
1999	F-150	5.4L	Other	IAB	✓	✓	✓	✓	
1999	F-150	5.4L	Other	IC	✓	✓	✓	✓	
1999	F-150	5.4L	Other	PCM	✓	✓	✓	✓	0025
1999	F-150	5.4L	Other	RAP	✓	✓	✓	✓	
2000	F-150	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	F-150	4.2L	Other	GEM	✓	✓	✓	✓	
2000	F-150	4.2L	Other	IAB	✓	✓	✓	✓	

2000	F-150	4. 2L	Other	IC	✓	✓	✓	✓	
2000	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025
2000	F-150	4. 2L	Other	RAP	✓	✓	✓	✓	
2000	F-150	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	
2000	F-150	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	F-150	4. 6L	Other	GEM	✓	✓	✓	✓	
2000	F-150	4. 6L	Other	IAB	✓	✓	✓	✓	
2000	F-150	4. 6L	Other	IC	✓	✓	✓	✓	
2000	F-150	4. 6L	Other	PCM	✓	✓	✓	✓	0025
2000	F-150	4. 6L	Other	RAP	✓	✓	✓	✓	
2000	F-150	5. 4L	BIF	ABS/TCS	✓	✓	✓	✓	0008
2000	F-150	5. 4L	BIF	AFCM	✓	✓	✓	✓	
2000	F-150	5. 4L	BIF	GEM	✓	✓	✓	✓	
2000	F-150	5. 4L	BIF	IAB	✓	✓	✓	✓	
2000	F-150	5. 4L	BIF	IC	✓	✓	✓	✓	
2000	F-150	5. 4L	BIF	PCM	✓	✓	✓	✓	
2000	F-150	5. 4L	BIF	PCM	✓	✓	✓	✓	0025
2000	F-150	5. 4L	BIF	RAP	✓	✓	✓	✓	
2000	F-150	5. 4L	NGV	ABS/TCS	✓	✓	✓	✓	0008
2000	F-150	5. 4L	NGV	ABS/TCS	✓	✓	✓	✓	0008, 001B
2000	F-150	5. 4L	NGV	FIM	✓	✓	✓	✓	
2000	F-150	5. 4L	NGV	GEM	✓	✓	✓	✓	
2000	F-150	5. 4L	NGV	IAB	✓	✓	✓	✓	
2000	F-150	5. 4L	NGV	IC	✓	✓	✓	✓	
2000	F-150	5. 4L	NGV	PCM	✓	✓	✓	✓	
2000	F-150	5. 4L	NGV	PCM	✓	✓	✓	✓	0025
2000	F-150	5. 4L	NGV	RAP	✓	✓	✓	✓	
2000	F-150	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	F-150	5. 4L	Other	GEM	✓	✓	✓	✓	
2000	F-150	5. 4L	Other	IAB	✓	✓	✓	✓	
2000	F-150	5. 4L	Other	IC	✓	✓	✓	✓	
2000	F-150	5. 4L	Other	PCM	✓	✓	✓	✓	0025
2000	F-150	5. 4L	Other	RAP	✓	✓	✓	✓	
2002	F-150	4. 2L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	F-150	4. 2L	Other	GEM	✓	✓	✓	✓	
2002	F-150	4. 2L	Other	IC	✓	✓	✓	✓	
2002	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025
2002	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	F-150	4. 2L	Other	RAP	✓	✓	✓	✓	
2002	F-150	4. 2L	Other	RCM	✓	✓	✓	✓	
2002	F-150	4. 6L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	F-150	4. 6L	Other	GEM	✓	✓	✓	✓	
2002	F-150	4. 6L	Other	IC	✓	✓	✓	✓	
2002	F-150	4. 6L	Other	PCM	✓	✓	✓	✓	0025
2002	F-150	4. 6L	Other	RAP	✓	✓	✓	✓	
2002	F-150	4. 6L	Other	RCM	✓	✓	✓	✓	
2002	F-150	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	F-150	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008, 001B
2002	F-150	5. 4L	Other	AFCM	✓	✓	✓	✓	
2002	F-150	5. 4L	Other	FIM	✓	✓	✓	✓	
2002	F-150	5. 4L	Other	GEM	✓	✓	✓	✓	
2002	F-150	5. 4L	Other	IC	✓	✓	✓	✓	
2002	F-150	5. 4L	Other	PCM	✓	✓	✓	✓	0025
2002	F-150	5. 4L	Other	RAP	✓	✓	✓	✓	
2002	F-150	5. 4L	Other	RCM	✓	✓	✓	✓	
2003	F-150	4. 2L	Other	ABS/TCS	✓	✓	✓	✓	0008
2003	F-150	4. 2L	Other	GEM	✓	✓	✓	✓	
2003	F-150	4. 2L	Other	IC	✓	✓	✓	✓	
2003	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025
2003	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	F-150	4. 2L	Other	RAP	✓	✓	✓	✓	
2003	F-150	4. 2L	Other	RCM	✓	✓	✓	✓	
2003	F-150	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	F-150	4. 6L	2V	GEM	✓	✓	✓	✓	
2003	F-150	4. 6L	2V	IC	✓	✓	✓	✓	
2003	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025
2003	F-150	4. 6L	2V	RAP	✓	✓	✓	✓	
2003	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	
2003	F-150	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2003	F-150	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008, 001B
2003	F-150	5. 4L	Other	AFCM	✓	✓	✓	✓	
2003	F-150	5. 4L	Other	FIM	✓	✓	✓	✓	
2003	F-150	5. 4L	Other	GEM	✓	✓	✓	✓	
2003	F-150	5. 4L	Other	IC	✓	✓	✓	✓	
2003	F-150	5. 4L	Other	PCM	✓	✓	✓	✓	0008, 001B, 0025
2003	F-150	5. 4L	Other	PCM	✓	✓	✓	✓	0025
2003	F-150	5. 4L	Other	RAP	✓	✓	✓	✓	
2003	F-150	5. 4L	Other	RCM	✓	✓	✓	✓	
2004	F-150	4. 2L	Other	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	F-150	4. 2L	Other	GEM	✓	✓	✓	✓	
2004	F-150	4. 2L	Other	IC	✓	✓	✓	✓	
2004	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025
2004	F-150	4. 2L	Other	RAP	✓	✓	✓	✓	
2004	F-150	4. 2L	Other	RCM	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	4X4	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0008, 000B
2004	F-150	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	EATC	✓	✓	✓	✓	

2004	F-150	4. 6L	2V	GEM	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	IC	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025
2004	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	F-150	4. 6L	2V	RAP	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	
2004	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2004	F-150	4. 6L	2V	VSM	✓	✓	✓	✓	
2004	F-150	5. 4L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2004	F-150	5. 4L	2V	AFCM	✓	✓	✓	✓	
2004	F-150	5. 4L	2V	FIM	✓	✓	✓	✓	
2004	F-150	5. 4L	2V	GEM	✓	✓	✓	✓	
2004	F-150	5. 4L	2V	IC	✓	✓	✓	✓	
2004	F-150	5. 4L	2V	PCM	✓	✓	✓	✓	0025
2004	F-150	5. 4L	2V	RAP	✓	✓	✓	✓	
2004	F-150	5. 4L	2V	RCM	✓	✓	✓	✓	
2004	F-150	5. 4L	3V	4X4	✓	✓	✓	✓	
2004	F-150	5. 4L	3V	4X4	✓	✓	✓	✓	0143
2004	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008, 000B
2004	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 000B
2004	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	
2004	F-150	5. 4L	3V	EATC	✓	✓	✓	✓	
2004	F-150	5. 4L	3V	IC	✓	✓	✓	✓	
2004	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2004	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	0025
2004	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2004	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2004	F-150	5. 4L	3V	VSM	✓	✓	✓	✓	
2004	F-150	Other	Other	4X4	✓	✓	✓	✓	
2004	F-150	Other	Other	ABS	✓	✓	✓	✓	
2004	F-150	Other	Other	DSM	✓	✓	✓	✓	
2004	F-150	Other	Other	EATC	✓	✓	✓	✓	
2004	F-150	Other	Other	IC	✓	✓	✓	✓	
2004	F-150	Other	Other	PAM	✓	✓	✓	✓	
2004	F-150	Other	Other	PCM	✓	✓	✓	✓	
2004	F-150	Other	Other	RCM	✓	✓	✓	✓	
2004	F-150	Other	Other	VSM	✓	✓	✓	✓	
2005	F-150	4. 2L	2V	4X4	✓	✓	✓	✓	
2005	F-150	4. 2L	2V	ABS	✓	✓	✓	✓	0005, 0008, 000B
2005	F-150	4. 2L	2V	DSM	✓	✓	✓	✓	
2005	F-150	4. 2L	2V	EATC	✓	✓	✓	✓	
2005	F-150	4. 2L	2V	IC	✓	✓	✓	✓	F071
2005	F-150	4. 2L	2V	PAM	✓	✓	✓	✓	
2005	F-150	4. 2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	F-150	4. 2L	2V	RCM	✓	✓	✓	✓	000C
2005	F-150	4. 2L	2V	VSM	✓	✓	✓	✓	
2005	F-150	4. 2L	Other	ABS/TCS	✓	✓	✓	✓	0008, 001B
2005	F-150	4. 2L	Other	GEM	✓	✓	✓	✓	
2005	F-150	4. 2L	Other	IC	✓	✓	✓	✓	
2005	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025
2005	F-150	4. 2L	Other	RAP	✓	✓	✓	✓	
2005	F-150	4. 2L	Other	RCM	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	4X4	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0008, 000B
2005	F-150	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2005	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	EATC	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	GEM	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	IC	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025
2005	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	F-150	4. 6L	2V	RAP	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	
2005	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2005	F-150	4. 6L	2V	VSM	✓	✓	✓	✓	
2005	F-150	5. 4L	3V	4X4	✓	✓	✓	✓	
2005	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008, 000B
2005	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 000B
2005	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	
2005	F-150	5. 4L	3V	EATC	✓	✓	✓	✓	
2005	F-150	5. 4L	3V	IC	✓	✓	✓	✓	F071
2005	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2005	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	0025
2005	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2005	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2005	F-150	5. 4L	3V	VSM	✓	✓	✓	✓	
2006	F-150	4. 2L	2V	4X4	✓	✓	✓	✓	
2006	F-150	4. 2L	2V	ABS	✓	✓	✓	✓	0005, 0008, 000B
2006	F-150	4. 2L	2V	DSM	✓	✓	✓	✓	
2006	F-150	4. 2L	2V	EATC	✓	✓	✓	✓	
2006	F-150	4. 2L	2V	IC	✓	✓	✓	✓	
2006	F-150	4. 2L	2V	PAM	✓	✓	✓	✓	
2006	F-150	4. 2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	F-150	4. 2L	2V	RCM	✓	✓	✓	✓	000C
2006	F-150	4. 2L	2V	VSM	✓	✓	✓	✓	

2006	F-150	4. 2L	Other	ABS/TCS	✓	✓	✓	✓	
2006	F-150	4. 2L	Other	GEM	✓	✓	✓	✓	
2006	F-150	4. 2L	Other	IC	✓	✓	✓	✓	
2006	F-150	4. 2L	Other	PCM	✓	✓	✓	✓	0025
2006	F-150	4. 2L	Other	RAP	✓	✓	✓	✓	
2006	F-150	4. 2L	Other	RCM	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	4X4	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0008, 000B
2006	F-150	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	EATC	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	GEM	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	IC	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025
2006	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	F-150	4. 6L	2V	RAP	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	
2006	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2006	F-150	4. 6L	2V	VSM	✓	✓	✓	✓	
2006	F-150	5. 4L	3V	4X4	✓	✓	✓	✓	
2006	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 000B
2006	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	000B
2006	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	
2006	F-150	5. 4L	3V	EATC	✓	✓	✓	✓	
2006	F-150	5. 4L	3V	IC	✓	✓	✓	✓	
2006	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2006	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	0025
2006	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2006	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2006	F-150	5. 4L	3V	VSM	✓	✓	✓	✓	
2007	F-150	4. 2L	2V	4X4	✓	✓	✓	✓	
2007	F-150	4. 2L	2V	ABS	✓	✓	✓	✓	0008
2007	F-150	4. 2L	2V	DSM	✓	✓	✓	✓	
2007	F-150	4. 2L	2V	EATC	✓	✓	✓	✓	
2007	F-150	4. 2L	2V	IC	✓	✓	✓	✓	
2007	F-150	4. 2L	2V	PAM	✓	✓	✓	✓	
2007	F-150	4. 2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	F-150	4. 2L	2V	RCM	✓	✓	✓	✓	000C
2007	F-150	4. 2L	2V	VSM	✓	✓	✓	✓	
2007	F-150	4. 6L	2V	4X4	✓	✓	✓	✓	
2007	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0008
2007	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2007	F-150	4. 6L	2V	EATC	✓	✓	✓	✓	
2007	F-150	4. 6L	2V	IC	✓	✓	✓	✓	0005, F071, F077
2007	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2007	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2007	F-150	4. 6L	2V	VSM	✓	✓	✓	✓	
2007	F-150	5. 4L	3V	4X4	✓	✓	✓	✓	
2007	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005
2007	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2007	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	
2007	F-150	5. 4L	3V	EATC	✓	✓	✓	✓	
2007	F-150	5. 4L	3V	IC	✓	✓	✓	✓	0005
2007	F-150	5. 4L	3V	IC	✓	✓	✓	✓	0005, F044, F071
2007	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2007	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	0025
2007	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2007	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2007	F-150	5. 4L	3V	VSM	✓	✓	✓	✓	
2008	F-150	4. 2L	2V	4X4	✓	✓	✓	✓	
2008	F-150	4. 2L	2V	ABS	✓	✓	✓	✓	0008
2008	F-150	4. 2L	2V	DSM	✓	✓	✓	✓	
2008	F-150	4. 2L	2V	HVAC	✓	✓	✓	✓	
2008	F-150	4. 2L	2V	IC	✓	✓	✓	✓	
2008	F-150	4. 2L	2V	PAM	✓	✓	✓	✓	
2008	F-150	4. 2L	2V	PCM	✓	✓	✓	✓	0025
2008	F-150	4. 2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	F-150	4. 2L	2V	RCM	✓	✓	✓	✓	000C
2008	F-150	4. 2L	2V	RETm	✓	✓	✓	✓	0018
2008	F-150	4. 2L	2V	VSM	✓	✓	✓	✓	
2008	F-150	4. 6L	2V	4X4	✓	✓	✓	✓	
2008	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0008
2008	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2008	F-150	4. 6L	2V	HVAC	✓	✓	✓	✓	
2008	F-150	4. 6L	2V	IC	✓	✓	✓	✓	0005, F071, F077
2008	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2008	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2008	F-150	4. 6L	2V	RETm	✓	✓	✓	✓	0018
2008	F-150	4. 6L	2V	VSM	✓	✓	✓	✓	
2008	F-150	5. 4L	3V	4X4	✓	✓	✓	✓	
2008	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2008	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	

2008	F-150	5. 4L	3V	HVAC	✓	✓	✓	✓	
2008	F-150	5. 4L	3V	IC	✓	✓	✓	✓	0005, F044, F071
2008	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2008	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	0025
2008	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2008	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2008	F-150	5. 4L	3V	RETm	✓	✓	✓	✓	
2008	F-150	5. 4L	3V	RETm	✓	✓	✓	✓	0018
2008	F-150	5. 4L	3V	VSM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	F-150	4. 6L	2V	ACM	✓	✓	✓	✓	0017, 0018
2009	F-150	4. 6L	2V	APIM	✓	✓	✓	✓	0019, 001C
2009	F-150	4. 6L	2V	DCSM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	DSP	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	FCIM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	FDIM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	F-150	4. 6L	2V	HVAC	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	IC	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2009	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0067
2009	F-150	4. 6L	2V	PRB	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	TBC	✓	✓	✓	✓	
2009	F-150	4. 6L	2V	TCCM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	ABS	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2009	F-150	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	ACM	✓	✓	✓	✓	0017, 0018
2009	F-150	4. 6L	3V	APIM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	F-150	4. 6L	3V	DCSM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	DSM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	DSP	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	FCIM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	FDIM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	F-150	4. 6L	3V	HVAC	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	IC	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	OCSM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2009	F-150	4. 6L	3V	PAM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	PCM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	PCM	✓	✓	✓	✓	0067
2009	F-150	4. 6L	3V	PRB	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	RCM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	TBC	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	TCCM	✓	✓	✓	✓	
2009	F-150	4. 6L	3V	TCM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2009	F-150	5. 4L	3V	ACM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2009	F-150	5. 4L	3V	APIM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	F-150	5. 4L	3V	DCSM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	DSP	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	FCIM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	FDIM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	F-150	5. 4L	3V	HVAC	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	IC	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	OCSM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2009	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 00C5
2009	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0067
2009	F-150	5. 4L	3V	PRB	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	TBC	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	TCCM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	TCM	✓	✓	✓	✓	
2009	F-150	5. 4L	3V	TCM	✓	✓	✓	✓	00CE
2010	F-150	4. 6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	F-150	4. 6L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	F-150	4. 6L	2V	APIM	✓	✓	✓	✓	0019, 001C
2010	F-150	4. 6L	2V	DCSM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	DSM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	DSP	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	FCIM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	FDIM	✓	✓	✓	✓	

2010	F-150	4. 6L	2V	GEM / SJB	✓	✓	✓	✓	0042
2010	F-150	4. 6L	2V	GPSM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	HVAC	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	IC	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	ILCM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2010	F-150	4. 6L	2V	PAM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	F-150	4. 6L	2V	PRB	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	RCM	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	TBC	✓	✓	✓	✓	
2010	F-150	4. 6L	2V	TCCM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	ABS	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2010	F-150	4. 6L	3V	ACM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	ACM	✓	✓	✓	✓	0017, 0018
2010	F-150	4. 6L	3V	APIM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2010	F-150	4. 6L	3V	DCSM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	DSM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	DSP	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	FCIM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	FDIM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2010	F-150	4. 6L	3V	GPSM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	HVAC	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	IC	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	ILCM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	OCSM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2010	F-150	4. 6L	3V	PAM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	PCM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	PCM	✓	✓	✓	✓	0067
2010	F-150	4. 6L	3V	PRB	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	RCM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	TBC	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	TCCM	✓	✓	✓	✓	
2010	F-150	4. 6L	3V	TCM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2010	F-150	5. 4L	3V	ACM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2010	F-150	5. 4L	3V	APIM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2010	F-150	5. 4L	3V	DCSM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	DSM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	DSP	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	FCIM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	FDIM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2010	F-150	5. 4L	3V	GPSM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	HVAC	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	IC	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	ILCM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	OCSM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2010	F-150	5. 4L	3V	PAM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 00C5
2010	F-150	5. 4L	3V	PRB	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	RCM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	TBC	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	TCCM	✓	✓	✓	✓	
2010	F-150	5. 4L	3V	TCM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	F-150	6. 2L	2V	ACM	✓	✓	✓	✓	0017, 0018
2010	F-150	6. 2L	2V	APIM	✓	✓	✓	✓	0019, 001C
2010	F-150	6. 2L	2V	DCSM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	DSM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	DSP	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	FCIM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	FDIM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	GEM / SJB	✓	✓	✓	✓	0042
2010	F-150	6. 2L	2V	GPSM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	HVAC	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	IC	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	ILCM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2010	F-150	6. 2L	2V	PAM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	F-150	6. 2L	2V	PRB	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	RCM	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	TBC	✓	✓	✓	✓	
2010	F-150	6. 2L	2V	TCCM	✓	✓	✓	✓	

2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019, 001C
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	0005
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	0005
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	0005
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	0005
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0095
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PRB	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	0005, 00CB
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	0005
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	TBC	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	TCCM	✓	✓	✓	✓	
2011	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	TPM	✓	✓	✓	✓	

2011	F-150	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2011	F-150	3.7L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2011	F-150	3.7L	TiVCT	APIM	✓	✓	✓	✓	0019, 001C
2011	F-150	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	F-150	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	DSM	✓	✓	✓	✓	0005
2011	F-150	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	FDIM	✓	✓	✓	✓	0005
2011	F-150	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	HVAC	✓	✓	✓	✓	0005
2011	F-150	3.7L	TiVCT	I LCM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	IPC	✓	✓	✓	✓	0005
2011	F-150	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2011	F-150	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2011	F-150	3.7L	TiVCT	PRB	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	PSCM	✓	✓	✓	✓	0005, 00CB
2011	F-150	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	SCCM	✓	✓	✓	✓	0005
2011	F-150	3.7L	TiVCT	TBC	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	TCCM	✓	✓	✓	✓	
2011	F-150	3.7L	TiVCT	TPM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2011	F-150	5.0L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2011	F-150	5.0L	TiVCT	APIM	✓	✓	✓	✓	0019, 001C
2011	F-150	5.0L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	F-150	5.0L	TiVCT	DCSM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	DSM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	DSP	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	FCIM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	FDIM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	GPSM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	HVAC	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	I LCM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	IPC	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2011	F-150	5.0L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2011	F-150	5.0L	TiVCT	PAM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	PCM	✓	✓	✓	✓	0067, 0095
2011	F-150	5.0L	TiVCT	PRB	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2011	F-150	5.0L	TiVCT	RCM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	SCCM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	TBC	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	TCCM	✓	✓	✓	✓	
2011	F-150	5.0L	TiVCT	TPM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	ABS	✓	✓	✓	✓	0008, 0012
2011	F-150	6.2L	2V	ACM	✓	✓	✓	✓	0017, 0018
2011	F-150	6.2L	2V	APIM	✓	✓	✓	✓	0019, 001C
2011	F-150	6.2L	2V	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	F-150	6.2L	2V	DCSM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	DSM	✓	✓	✓	✓	0005
2011	F-150	6.2L	2V	DSP	✓	✓	✓	✓	
2011	F-150	6.2L	2V	FCIM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	FDIM	✓	✓	✓	✓	0005
2011	F-150	6.2L	2V	GPSM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	HVAC	✓	✓	✓	✓	0005
2011	F-150	6.2L	2V	I LCM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	IPC	✓	✓	✓	✓	0005
2011	F-150	6.2L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2011	F-150	6.2L	2V	PAM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2011	F-150	6.2L	2V	PRB	✓	✓	✓	✓	
2011	F-150	6.2L	2V	PSCM	✓	✓	✓	✓	0005, 00CB
2011	F-150	6.2L	2V	RCM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	SCCM	✓	✓	✓	✓	0005
2011	F-150	6.2L	2V	TBC	✓	✓	✓	✓	
2011	F-150	6.2L	2V	TCCM	✓	✓	✓	✓	
2011	F-150	6.2L	2V	TPM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019, 001C
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	

2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IILCM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PRB	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TBC	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM	✓	✓	✓	✓	
2012	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	TPM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	F-150	3.7L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2012	F-150	3.7L	TiVCT	APIM	✓	✓	✓	✓	0019, 001C
2012	F-150	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112
2012	F-150	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	FDIM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	IILCM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2012	F-150	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095
2012	F-150	3.7L	TiVCT	PRB	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2012	F-150	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	TBC	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	TCCM	✓	✓	✓	✓	
2012	F-150	3.7L	TiVCT	TPM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	F-150	5.0L	TiVCT	ABS	✓	✓	✓	✓	0012
2012	F-150	5.0L	TiVCT	ACM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2012	F-150	5.0L	TiVCT	APIM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	APIM	✓	✓	✓	✓	0019, 001C
2012	F-150	5.0L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	F-150	5.0L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5
2012	F-150	5.0L	TiVCT	DCSM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	DSM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	DSP	✓	✓	✓	✓	

2012	F-150	5.0L	TiVCT	FCIM	✓	✓	✓		
2012	F-150	5.0L	TiVCT	FDIM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	GPSM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	HVAC	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	ILCM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	IPC	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2012	F-150	5.0L	TiVCT	PAM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2012	F-150	5.0L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095
2012	F-150	5.0L	TiVCT	PRB	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2012	F-150	5.0L	TiVCT	RCM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	SCCM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	TBC	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	TCCM	✓	✓	✓	✓	
2012	F-150	5.0L	TiVCT	TPM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	ABS	✓	✓	✓	✓	0008, 0012
2012	F-150	6.2L	2V	ACM	✓	✓	✓	✓	0017, 0018
2012	F-150	6.2L	2V	APIM	✓	✓	✓	✓	0019, 001C
2012	F-150	6.2L	2V	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	F-150	6.2L	2V	DCSM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	DSM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	DSP	✓	✓	✓	✓	
2012	F-150	6.2L	2V	FCIM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	FDIM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	GPSM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	HVAC	✓	✓	✓	✓	
2012	F-150	6.2L	2V	ILCM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	IPC	✓	✓	✓	✓	
2012	F-150	6.2L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2012	F-150	6.2L	2V	PAM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2012	F-150	6.2L	2V	PRB	✓	✓	✓	✓	
2012	F-150	6.2L	2V	PSCM	✓	✓	✓	✓	00CB
2012	F-150	6.2L	2V	RCM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	SCCM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	TBC	✓	✓	✓	✓	
2012	F-150	6.2L	2V	TCCM	✓	✓	✓	✓	
2012	F-150	6.2L	2V	TPM	✓	✓	✓	✓	
2012	F-150	Other	Other	ABS	✓	✓	✓	✓	
2012	F-150	Other	Other	ACM	✓	✓	✓	✓	
2012	F-150	Other	Other	BCM#1	✓	✓	✓	✓	0112
2012	F-150	Other	Other	DCSM	✓	✓	✓	✓	
2012	F-150	Other	Other	DSM	✓	✓	✓	✓	
2012	F-150	Other	Other	DSP	✓	✓	✓	✓	
2012	F-150	Other	Other	FCIM	✓	✓	✓	✓	
2012	F-150	Other	Other	FDIM	✓	✓	✓	✓	
2012	F-150	Other	Other	HVAC	✓	✓	✓	✓	
2012	F-150	Other	Other	ILCM	✓	✓	✓	✓	
2012	F-150	Other	Other	IPC	✓	✓	✓	✓	
2012	F-150	Other	Other	OCSM	✓	✓	✓	✓	
2012	F-150	Other	Other	PAM	✓	✓	✓	✓	
2012	F-150	Other	Other	PRB	✓	✓	✓	✓	
2012	F-150	Other	Other	PSCM	✓	✓	✓	✓	
2012	F-150	Other	Other	RCM	✓	✓	✓	✓	
2012	F-150	Other	Other	SCCM	✓	✓	✓	✓	
2012	F-150	Other	Other	TBC	✓	✓	✓	✓	
2012	F-150	Other	Other	TCCM	✓	✓	✓	✓	
2012	F-150	Other	Other	TPM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	

2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PRB	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	TBC	✓	✓	✓	✓	
2013	F-150	3.5L	EcoBoost – Gas Turbocharged Direct Injection	TCCM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	ABS	✓	✓	✓	✓	0012
2013	F-150	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	APIM	✓	✓	✓	✓	0019, 001C
2013	F-150	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112
2013	F-150	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	FDIM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	F-150	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	F-150	3.7L	TiVCT	PRB	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2013	F-150	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	TBC	✓	✓	✓	✓	
2013	F-150	3.7L	TiVCT	TCCM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	ABS	✓	✓	✓	✓	0012
2013	F-150	5.0L	TiVCT	ACM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	APIM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE
2013	F-150	5.0L	TiVCT	DCSM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	DSM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	DSP	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	FCIM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	FDIM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	GPSM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	IPC	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	F-150	5.0L	TiVCT	PAM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	PCM	✓	✓	✓	✓	0025
2013	F-150	5.0L	TiVCT	PRB	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2013	F-150	5.0L	TiVCT	RCM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	RTM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	SCCM	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	TBC	✓	✓	✓	✓	
2013	F-150	5.0L	TiVCT	TCCM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	ABS	✓	✓	✓	✓	0012
2013	F-150	6.2L	2V	ACM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	APIM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	F-150	6.2L	2V	DCSM	✓	✓	✓	✓	
2013	F-150	6.2L	2V	DSM	✓	✓	✓	✓	

2013	F-150	6. 2L	2V	DSP	✓	✓	✓	✓	
2013	F-150	6. 2L	2V	FCDIM	✓	✓	✓	✓	
2013	F-150	6. 2L	2V	FCIM	✓	✓	✓	✓	
2013	F-150	6. 2L	2V	FDIM	✓	✓	✓	✓	
2013	F-150	6. 2L	2V	GPSM	✓	✓	✓	✓	
2013	F-150	6. 2L	2V	IPC	✓	✓	✓	✓	
2013	F-150	6. 2L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2013	F-150	6. 2L	2V	PAM	✓	✓	✓	✓	
2013	F-150	6. 2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2013	F-150	6. 2L	2V	PRB	✓	✓	✓	✓	
2013	F-150	6. 2L	2V	PSCM	✓	✓	✓	✓	00CB
2013	F-150	6. 2L	2V	RCM	✓	✓	✓	✓	
2013	F-150	6. 2L	2V	RTM	✓	✓	✓	✓	
2013	F-150	6. 2L	2V	SCCM	✓	✓	✓	✓	
2013	F-150	6. 2L	2V	TBC	✓	✓	✓	✓	
2013	F-150	6. 2L	2V	TCCM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	PRB	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	TBC	✓	✓	✓	✓	
2014	F-150	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	TCCM	✓	✓	✓	✓	
2014	F-150	3. 7L	TiVCT	ABS	✓	✓	✓	✓	0012
2014	F-150	3. 7L	TiVCT	ACM	✓	✓	✓	✓	
2014	F-150	3. 7L	TiVCT	APIM	✓	✓	✓	✓	
2014	F-150	3. 7L	TiVCT	BCM#1	✓	✓	✓	✓	0112
2014	F-150	3. 7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	F-150	3. 7L	TiVCT	DSM	✓	✓	✓	✓	
2014	F-150	3. 7L	TiVCT	DSP	✓	✓	✓	✓	

2014	F-150	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	FDIM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	F-150	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	F-150	3.7L	TiVCT	PRB	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	TBC	✓	✓	✓	✓	
2014	F-150	3.7L	TiVCT	TCCM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	ABS	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	ABS	✓	✓	✓	✓	0012
2014	F-150	5.0L	TiVCT	ACM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	APIM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	F-150	5.0L	TiVCT	DCSM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	DSM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	DSP	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	FCIM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	FDIM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	GPSM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	IPC	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	F-150	5.0L	TiVCT	PAM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	PCM	✓	✓	✓	✓	0025
2014	F-150	5.0L	TiVCT	PRB	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	PSCM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	RCM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	RTM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	SCCM	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	TBC	✓	✓	✓	✓	
2014	F-150	5.0L	TiVCT	TCCM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	ABS	✓	✓	✓	✓	0012
2014	F-150	6.2L	2V	ACM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	APIM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	F-150	6.2L	2V	DCSM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	DSM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	DSP	✓	✓	✓	✓	
2014	F-150	6.2L	2V	FCDIM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	FCIM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	FDIM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	GPSM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	IPC	✓	✓	✓	✓	
2014	F-150	6.2L	2V	OCSM	✓	✓	✓	✓	000C, 0015
2014	F-150	6.2L	2V	PAM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2014	F-150	6.2L	2V	PRB	✓	✓	✓	✓	
2014	F-150	6.2L	2V	PSCM	✓	✓	✓	✓	00CB
2014	F-150	6.2L	2V	RCM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	RTM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	SCCM	✓	✓	✓	✓	
2014	F-150	6.2L	2V	TBC	✓	✓	✓	✓	
2014	F-150	6.2L	2V	TCCM	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	GEM	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	HEC	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	PCM	✓	✓	✓	✓	0025
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	RAP	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	4.6L	Other	RCM	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	GEM	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	HEC	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	PCM	✓	✓	✓	✓	0025
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	RAP	✓	✓	✓	✓	
2001	F-150 SuperCrew (4 full size doors)	5.4L	Other	RCM	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	EATC	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	GEM	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	HEC	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	PCM	✓	✓	✓	✓	0025
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	RAP	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	4.6L	Other	RCM	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	EATC	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	GEM	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	HEC	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	PCM	✓	✓	✓	✓	0025
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	RAP	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	5.4L	Other	RCM	✓	✓	✓	✓	
2002	F-150 SuperCrew (4 full size doors)	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	EATC	✓	✓	✓	✓	

2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	GEM	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	HEC	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	PCM	✓	✓	✓	✓	0025
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	RAP	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	4.6L	2V	RCM	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	EATC	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	GEM	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	HEC	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	PCM	✓	✓	✓	✓	0025
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	RAP	✓	✓	✓	✓	
2003	F-150 SuperCrew (4 full size doors)	5.4L	2V	RCM	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	4X4	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	ABS/TCS	✓	✓	✓	✓	0008
2006	F-250	3.9L	Cummins Diesel	GEM	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	HEC	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	OTC	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	PAM	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	RCM	✓	✓	✓	✓	
2006	F-250	3.9L	Cummins Diesel	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
1997	F-250 Light Duty	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	F-250 Light Duty	4.6L	Other	GEM	✓	✓	✓	✓	
1997	F-250 Light Duty	4.6L	Other	IAB	✓	✓	✓	✓	
1997	F-250 Light Duty	4.6L	Other	PCM	✓	✓	✓	✓	0025
1997	F-250 Light Duty	4.6L	Other	RAP	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	NGV	ABS/TCS	✓	✓	✓	✓	0008
1997	F-250 Light Duty	5.4L	NGV	FIM	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	NGV	GEM	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	NGV	IAB	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	NGV	PCM	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	NGV	RAP	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	F-250 Light Duty	5.4L	Other	GEM	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	Other	IAB	✓	✓	✓	✓	
1997	F-250 Light Duty	5.4L	Other	PCM	✓	✓	✓	✓	0025
1997	F-250 Light Duty	5.4L	Other	RAP	✓	✓	✓	✓	
1998	F-250 Light Duty	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	F-250 Light Duty	4.6L	Other	GEM	✓	✓	✓	✓	
1998	F-250 Light Duty	4.6L	Other	IAB	✓	✓	✓	✓	
1998	F-250 Light Duty	4.6L	Other	PCM	✓	✓	✓	✓	0025
1998	F-250 Light Duty	5.4L	BIF	ABS/TCS	✓	✓	✓	✓	0008
1998	F-250 Light Duty	5.4L	BIF	AFCM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	BIF	GEM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	BIF	IAB	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	BIF	PCM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	BIF	PCM	✓	✓	✓	✓	0025
1998	F-250 Light Duty	5.4L	BIF	RAP	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	NGV	ABS/TCS	✓	✓	✓	✓	0008
1998	F-250 Light Duty	5.4L	NGV	FIM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	NGV	GEM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	NGV	IAB	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	NGV	PCM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	NGV	RAP	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	F-250 Light Duty	5.4L	Other	GEM	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	Other	IAB	✓	✓	✓	✓	
1998	F-250 Light Duty	5.4L	Other	PCM	✓	✓	✓	✓	0025
1998	F-250 Light Duty	5.4L	Other	RAP	✓	✓	✓	✓	
1999	F-250 Light Duty	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-250 Light Duty	4.2L	Other	GEM	✓	✓	✓	✓	
1999	F-250 Light Duty	4.2L	Other	IC	✓	✓	✓	✓	
1999	F-250 Light Duty	4.2L	Other	PCM	✓	✓	✓	✓	0025
1999	F-250 Light Duty	4.2L	Other	RAP	✓	✓	✓	✓	
1999	F-250 Light Duty	4.2L	Other	RCM	✓	✓	✓	✓	
1999	F-250 Light Duty	4.6L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-250 Light Duty	4.6L	Other	GEM	✓	✓	✓	✓	
1999	F-250 Light Duty	4.6L	Other	IC	✓	✓	✓	✓	
1999	F-250 Light Duty	4.6L	Other	PCM	✓	✓	✓	✓	0025
1999	F-250 Light Duty	4.6L	Other	RAP	✓	✓	✓	✓	
1999	F-250 Light Duty	4.6L	Other	RCM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	BIF	ABS/TCS	✓	✓	✓	✓	0008
1999	F-250 Light Duty	5.4L	BIF	AFCM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	BIF	GEM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	BIF	IC	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	BIF	PCM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	BIF	RAP	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	BIF	RCM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	NGV	ABS/TCS	✓	✓	✓	✓	0008
1999	F-250 Light Duty	5.4L	NGV	FIM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	NGV	GEM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	NGV	IC	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	NGV	PCM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	NGV	RAP	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	NGV	RCM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-250 Light Duty	5.4L	Other	GEM	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	Other	IC	✓	✓	✓	✓	
1999	F-250 Light Duty	5.4L	Other	PCM	✓	✓	✓	✓	0025

2013	F-650 / F-750	6.7L	Cummins Diesel	APIM	✓	✓	✓	✓	
2013	F-650 / F-750	6.7L	Cummins Diesel	GEM / SJB	✓	✓	✓	✓	
2013	F-650 / F-750	6.7L	Cummins Diesel	HVAC	✓	✓	✓	✓	
2013	F-650 / F-750	6.7L	Cummins Diesel	IPC	✓	✓	✓	✓	
2013	F-650 / F-750	6.8L	3V	ACM	✓	✓	✓	✓	0005
2013	F-650 / F-750	6.8L	3V	APIM	✓	✓	✓	✓	
2013	F-650 / F-750	6.8L	3V	GEM / SJB	✓	✓	✓	✓	
2013	F-650 / F-750	6.8L	3V	HVAC	✓	✓	✓	✓	
2013	F-650 / F-750	6.8L	3V	IPC	✓	✓	✓	✓	
2013	F-650 / F-750	6.8L	3V	PCM	✓	✓	✓	✓	0025
2013	F-650 / F-750	Other	Other	ACM	✓	✓	✓	✓	
2013	F-650 / F-750	Other	Other	APIM	✓	✓	✓	✓	
2013	F-650 / F-750	Other	Other	HVAC	✓	✓	✓	✓	
2013	F-650 / F-750	Other	Other	IPC	✓	✓	✓	✓	
2014	F-650 / F-750	6.8L	3V	ACM	✓	✓	✓	✓	
2014	F-650 / F-750	6.8L	3V	APIM	✓	✓	✓	✓	
2014	F-650 / F-750	6.8L	3V	HVAC	✓	✓	✓	✓	
2014	F-650 / F-750	6.8L	3V	IPC	✓	✓	✓	✓	
1994	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	
1994	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1995	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	
1995	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1996	F-Series	4.9L	GFP	PCM	✓	✓	✓	✓	
1996	F-Series	4.9L	Other	PCM	✓	✓	✓	✓	0025
1996	F-Series	5.0L	Other	PCM	✓	✓	✓	✓	0025
1996	F-Series	5.8L	Other	PCM	✓	✓	✓	✓	0025
1996	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	
1996	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1996	F-Series	7.5L	Other	PCM	✓	✓	✓	✓	0025
1997	F-Series	5.8L	Other	PCM	✓	✓	✓	✓	0025
1997	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	
1997	F-Series	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1997	F-Series	7.5L	Other	PCM	✓	✓	✓	✓	0025
1999	F-Series Super Duty	5.4L	BIF	ABS/TCS	✓	✓	✓	✓	0008
1999	F-Series Super Duty	5.4L	BIF	AFCM	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	BIF	ECS	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	BIF	GEM	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	BIF	OTC	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	BIF	PCM	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-Series Super Duty	5.4L	Other	ECS	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	Other	GEM	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	Other	OTC	✓	✓	✓	✓	
1999	F-Series Super Duty	5.4L	Other	PCM	✓	✓	✓	✓	0025
1999	F-Series Super Duty	6.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	F-Series Super Duty	6.8L	Other	ECS	✓	✓	✓	✓	
1999	F-Series Super Duty	6.8L	Other	GEM	✓	✓	✓	✓	
1999	F-Series Super Duty	6.8L	Other	OTC	✓	✓	✓	✓	
1999	F-Series Super Duty	6.8L	Other	PCM	✓	✓	✓	✓	0025
1999	F-Series Super Duty	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008
1999	F-Series Super Duty	7.3L	Direct Injection -	ECS	✓	✓	✓	✓	
1999	F-Series Super Duty	7.3L	Direct Injection -	GEM	✓	✓	✓	✓	
1999	F-Series Super Duty	7.3L	Direct Injection -	OTC	✓	✓	✓	✓	
1999	F-Series Super Duty	7.3L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
1999	F-Series Super Duty	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025
1999	F-Series Super Duty	7.3L	Direct Injection -	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	F-Series Super Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	F-Series Super Duty	5.4L	Other	ECS	✓	✓	✓	✓	
2000	F-Series Super Duty	5.4L	Other	GEM	✓	✓	✓	✓	
2000	F-Series Super Duty	5.4L	Other	OTC	✓	✓	✓	✓	
2000	F-Series Super Duty	5.4L	Other	PATS	✓	✓	✓	✓	
2000	F-Series Super Duty	5.4L	Other	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2000	F-Series Super Duty	6.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	F-Series Super Duty	6.8L	Other	AFCM	✓	✓	✓	✓	
2000	F-Series Super Duty	6.8L	Other	ECS	✓	✓	✓	✓	
2000	F-Series Super Duty	6.8L	Other	GEM	✓	✓	✓	✓	
2000	F-Series Super Duty	6.8L	Other	OTC	✓	✓	✓	✓	
2000	F-Series Super Duty	6.8L	Other	PATS	✓	✓	✓	✓	
2000	F-Series Super Duty	6.8L	Other	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2000	F-Series Super Duty	7.3L	Direct Injection -	ABS/TCS	✓	✓	✓	✓	0008
2000	F-Series Super Duty	7.3L	Direct Injection -	ECS	✓	✓	✓	✓	
2000	F-Series Super Duty	7.3L	Direct Injection -	GEM	✓	✓	✓	✓	
2000	F-Series Super Duty	7.3L	Direct Injection -	OTC	✓	✓	✓	✓	
2000	F-Series Super Duty	7.3L	Direct Injection -	PATS	✓	✓	✓	✓	
2000	F-Series Super Duty	7.3L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2001	F-Series Super Duty	4.2L	Other	ABS/TCS	✓	✓	✓	✓	0008
2001	F-Series Super Duty	4.2L	Other	ECS	✓	✓	✓	✓	
2001	F-Series Super Duty	4.2L	Other	GEM	✓	✓	✓	✓	
2001	F-Series Super Duty	4.2L	Other	OTC	✓	✓	✓	✓	
2001	F-Series Super Duty	4.2L	Other	PAM	✓	✓	✓	✓	
2001	F-Series Super Duty	4.2L	Other	PCM	✓	✓	✓	✓	0025
2001	F-Series Super Duty	4.2L	Other	RCM	✓	✓	✓	✓	
2001	F-Series Super Duty	5.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
2001	F-Series Super Duty	5.4L	Other	ECS	✓	✓	✓	✓	
2001	F-Series Super Duty	5.4L	Other	GEM	✓	✓	✓	✓	

2008	F-Series Super Duty	5.4L	3V	PAM	✓	✓	✓	✓	
2008	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓	0025
2008	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	F-Series Super Duty	5.4L	3V	RCM	✓	✓	✓	✓	
2008	F-Series Super Duty	5.4L	3V	RETM	✓	✓	✓	✓	
2008	F-Series Super Duty	5.4L	3V	SDARS	✓	✓	✓	✓	0019
2008	F-Series Super Duty	5.4L	3V	TBC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0005, F046, F084
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F05A, F07A, F07F
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	0005
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	0042
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F05C, F06A, F080, F081
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	HVAC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	IC	✓	✓	✓	✓	F027, F04D, F07E, F082, F083
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PAM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0047, 0048, 0058, 00A2, 00A3
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0025, 0047, 0048, 0058, 00A2, 00A3
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0047, 0048, 0058, 00A2, 00A3
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	0005, F022
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓	✓	0005, F04D, F05A
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0005, 0019, F07F
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0019
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	00CE
2008	F-Series Super Duty	6.8L	2V	4X4	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	ABS	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	F-Series Super Duty	6.8L	2V	DSM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	GEM / SJB	✓	✓	✓	✓	0042
2008	F-Series Super Duty	6.8L	2V	HVAC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	IC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	PAM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	PCM	✓	✓	✓	✓	0025
2008	F-Series Super Duty	6.8L	2V	RCM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	RETM	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	2V	SDARS	✓	✓	✓	✓	0019
2008	F-Series Super Duty	6.8L	2V	TBC	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	3V	4X4	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓	
2008	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	F-Series Super Duty	6.8L	3V	DSM	✓	✓	✓	✓	

2008	F-Series Super Duty	6. 8L	3V	GEM / SJB	✓	✓	✓	✓	0042
2008	F-Series Super Duty	6. 8L	3V	HVAC	✓	✓	✓	✓	
2008	F-Series Super Duty	6. 8L	3V	IC	✓	✓	✓	✓	
2008	F-Series Super Duty	6. 8L	3V	PAM	✓	✓	✓	✓	
2008	F-Series Super Duty	6. 8L	3V	PCM	✓	✓	✓	✓	0025
2008	F-Series Super Duty	6. 8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	F-Series Super Duty	6. 8L	3V	RCM	✓	✓	✓	✓	
2008	F-Series Super Duty	6. 8L	3V	RETM	✓	✓	✓	✓	
2008	F-Series Super Duty	6. 8L	3V	SDARS	✓	✓	✓	✓	0019
2008	F-Series Super Duty	6. 8L	3V	TBC	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	4X4	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	ABS	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	ACM	✓	✓	✓	✓	0016
2009	F-Series Super Duty	5. 4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	F-Series Super Duty	5. 4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	F-Series Super Duty	5. 4L	3V	APIM	✓	✓	✓	✓	001C
2009	F-Series Super Duty	5. 4L	3V	DSM	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	DSM	✓	✓	✓	✓	0005, F041
2009	F-Series Super Duty	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	F-Series Super Duty	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C, F05C, F065, F06A, F080, F081, F0B0
2009	F-Series Super Duty	5. 4L	3V	HVAC	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	IC	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	PAM	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2009	F-Series Super Duty	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	F-Series Super Duty	5. 4L	3V	RCM	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	RCM	✓	✓	✓	✓	0005, F022
2009	F-Series Super Duty	5. 4L	3V	RETM	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	RETM	✓	✓	✓	✓	0005, F04D, F05A
2009	F-Series Super Duty	5. 4L	3V	SDARS	✓	✓	✓	✓	
2009	F-Series Super Duty	5. 4L	3V	SDARS	✓	✓	✓	✓	0005, F07F
2009	F-Series Super Duty	5. 4L	3V	TBC	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	4X4	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0005
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0005, F046, F084
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0005, 0016
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0016
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	AHCM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	APIM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	APIM	✓	✓	✓	✓	0019, 001C
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	CDIM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	0005
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	0042
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	HVAC	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	IC	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PAM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0047, 0048, 0058, 00A2, 00A3
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0025, 0047, 0048, 0058, 00A2, 00A3
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0047, 0048, 0058, 00A2, 00A3
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	
2009	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	0005

2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	0005, F022
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓		
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓		0005
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓		0005, F04D, F05A
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0005
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0005, 0019
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0005, 0019, F07F
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TBC	✓	✓	✓	✓	
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	
2009	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	00CE
2009	F-Series Super Duty	6.8L	3V	4X4	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓	0016
2009	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	F-Series Super Duty	6.8L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	F-Series Super Duty	6.8L	3V	DSM	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	F-Series Super Duty	6.8L	3V	HVAC	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	IC	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	PAM	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓	0025
2009	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	F-Series Super Duty	6.8L	3V	RCM	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	RETM	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	SDARS	✓	✓	✓	✓	
2009	F-Series Super Duty	6.8L	3V	TBC	✓	✓	✓	✓	
2010	F-Series Super Duty	5.4L	3V	4X4	✓	✓	✓	✓	
2010	F-Series Super Duty	5.4L	3V	ABS	✓	✓	✓	✓	0005
2010	F-Series Super Duty	5.4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2010	F-Series Super Duty	5.4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2010	F-Series Super Duty	5.4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2010	F-Series Super Duty	5.4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2010	F-Series Super Duty	5.4L	3V	DSM	✓	✓	✓	✓	0005, F041
2010	F-Series Super Duty	5.4L	3V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C, F05C, F065, F06A, F080, F081, F080
2010	F-Series Super Duty	5.4L	3V	GPSM	✓	✓	✓	✓	
2010	F-Series Super Duty	5.4L	3V	HVAC	✓	✓	✓	✓	
2010	F-Series Super Duty	5.4L	3V	IC	✓	✓	✓	✓	0005, F027, F04D, F07E
2010	F-Series Super Duty	5.4L	3V	PAM	✓	✓	✓	✓	0005
2010	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓	0025
2010	F-Series Super Duty	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	F-Series Super Duty	5.4L	3V	RCM	✓	✓	✓	✓	0005, F022
2010	F-Series Super Duty	5.4L	3V	RETM	✓	✓	✓	✓	0005, F04D, F05A
2010	F-Series Super Duty	5.4L	3V	SDARS	✓	✓	✓	✓	0005, F07F
2010	F-Series Super Duty	5.4L	3V	TBC	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	4X4	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0005
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0016, 0017, 0018
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0017, 0018
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	AHCM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	APIM	✓	✓	✓	✓	0019, 001C
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	CDIM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	0005
2010	F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	

2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	GEM / SJB	✓	✓	✓	✓	0042
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	GPSM	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	HVAC	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	IC	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PAM	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0047, 0048, 0058, 00A2, 00A3
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0025, 0047, 0048, 0058, 00A2, 00A3
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0047, 0048, 0058, 00A2, 00A3
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	0005
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	0005, F022
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓		
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓		0005
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	RETM	✓	✓	✓		0005, F04D, F05A
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0005
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓	✓	0005, 0019, F07F
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	TBC	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	00CE
2010	F-Series Super Duty	6. 8L	3V	4X4	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 8L	3V	ABS	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 8L	3V	ABS	✓	✓	✓	✓	0008
2010	F-Series Super Duty	6. 8L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2010	F-Series Super Duty	6. 8L	3V	ACM	✓	✓	✓	✓	0017, 0018
2010	F-Series Super Duty	6. 8L	3V	APIM	✓	✓	✓	✓	0019, 001C
2010	F-Series Super Duty	6. 8L	3V	DSM	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 8L	3V	GEM / SJB	✓	✓	✓	✓	0042
2010	F-Series Super Duty	6. 8L	3V	GPSM	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 8L	3V	HVAC	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 8L	3V	IC	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 8L	3V	PAM	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 8L	3V	PCM	✓	✓	✓	✓	0025
2010	F-Series Super Duty	6. 8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	F-Series Super Duty	6. 8L	3V	RCM	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 8L	3V	RETM	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 8L	3V	SDARS	✓	✓	✓	✓	
2010	F-Series Super Duty	6. 8L	3V	TBC	✓	✓	✓	✓	
2011	F-Series Super Duty	6. 2L	2V	ABS	✓	✓	✓	✓	0008
2011	F-Series Super Duty	6. 2L	2V	ACM	✓	✓	✓	✓	0017, 0018
2011	F-Series Super Duty	6. 2L	2V	APIM	✓	✓	✓	✓	0019
2011	F-Series Super Duty	6. 2L	2V	BCM#1	✓	✓	✓	✓	0042, 00D4
2011	F-Series Super Duty	6. 2L	2V	DCSM	✓	✓	✓	✓	
2011	F-Series Super Duty	6. 2L	2V	DSM	✓	✓	✓	✓	
2011	F-Series Super Duty	6. 2L	2V	GPSM	✓	✓	✓	✓	
2011	F-Series Super Duty	6. 2L	2V	HVAC	✓	✓	✓	✓	
2011	F-Series Super Duty	6. 2L	2V	IPC	✓	✓	✓	✓	
2011	F-Series Super Duty	6. 2L	2V	PAM	✓	✓	✓	✓	
2011	F-Series Super Duty	6. 2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2011	F-Series Super Duty	6. 2L	2V	RCM	✓	✓	✓	✓	
2011	F-Series Super Duty	6. 2L	2V	SCCM	✓	✓	✓	✓	
2011	F-Series Super Duty	6. 2L	2V	SDARS	✓	✓	✓	✓	
2011	F-Series Super Duty	6. 2L	2V	TBC	✓	✓	✓	✓	
2011	F-Series Super Duty	6. 2L	2V	TCCM	✓	✓	✓	✓	
2011	F-Series Super Duty	6. 2L	2V	TPM	✓	✓	✓	✓	
2011	F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0008
2011	F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0005, 0008
2011	F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0008
2011	F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	0008, 0012
2011	F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0005, 0017, 0018

2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	SDARS	✓	✓	✓		0005
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TBC	✓	✓	✓		
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TBC	✓	✓	✓	✓	
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TCCM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	00CE
2012	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TPM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓	0008
2012	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓	0017, 0018
2012	F-Series Super Duty	6.8L	3V	APIM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	APIM	✓	✓	✓	✓	0019
2012	F-Series Super Duty	6.8L	3V	BCM#1	✓	✓	✓	✓	0042, 00D4
2012	F-Series Super Duty	6.8L	3V	BCM#1	✓	✓	✓	✓	00D4
2012	F-Series Super Duty	6.8L	3V	DCSM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	DSM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	GPSM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	HVAC	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	IPC	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	PAM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓	0025
2012	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095
2012	F-Series Super Duty	6.8L	3V	RCM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	SCCM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	TBC	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	TCCM	✓	✓	✓	✓	
2012	F-Series Super Duty	6.8L	3V	TPM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	ABS	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	ACM	✓	✓	✓	✓	0017, 0018
2013	F-Series Super Duty	6.2L	2V	APIM	✓	✓	✓	✓	0019
2013	F-Series Super Duty	6.2L	2V	BCM#1	✓	✓	✓	✓	00D4, 00FE
2013	F-Series Super Duty	6.2L	2V	BCM#1	✓	✓	✓	✓	00D4, 00FE, 0112
2013	F-Series Super Duty	6.2L	2V	DCSM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	DSM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	DSP	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	FCDIM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	FCIM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	GPSM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	HSWM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	IPC	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	PAM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	PCM	✓	✓	✓	✓	0025
2013	F-Series Super Duty	6.2L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	F-Series Super Duty	6.2L	2V	RCM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	RTM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	SCCM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	TBC	✓	✓	✓	✓	
2013	F-Series Super Duty	6.2L	2V	TCCM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	ABS	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	ACM	✓	✓	✓	✓	0017, 0018
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	AHCM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	APIM	✓	✓	✓	✓	0019
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	BCM#1	✓	✓	✓	✓	00D4, 00FE
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	CDIM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	DCSM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	DSM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	DSP	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	FCDIM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	FCIM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	GPCM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	GPSM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	HSWM	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	IPC	✓	✓	✓	✓	
2013	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	PAM	✓	✓	✓	✓	

2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0058, 0059, 0091, 009C, 009D, 009E, 009F, 00A0, 00CE
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	RCM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	RTM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	SCCM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TBC	✓	✓	✓	✓	
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TCCM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	TCM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	ABS	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	ACM	✓	✓	✓	✓	0017, 0018
2014	F-Series Super Duty	6.8L	3V	APIM	✓	✓	✓	✓	0019
2014	F-Series Super Duty	6.8L	3V	BCM#1	✓	✓	✓	✓	00D4, 00FE, 0112
2014	F-Series Super Duty	6.8L	3V	DCSM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	DSM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	DSP	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	FCDIM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	FCIM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	GPSM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	HSWM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	IPC	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	PAM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	F-Series Super Duty	6.8L	3V	RCM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	RTM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	SCCM	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	TBC	✓	✓	✓	✓	
2014	F-Series Super Duty	6.8L	3V	TCCM	✓	✓	✓	✓	
2009	F350/4000	3.9L	Cummins Diesel	4X4	✓	✓	✓	✓	
2009	F350/4000	3.9L	Cummins Diesel	GEM	✓	✓	✓	✓	
2009	F350/4000	3.9L	Cummins Diesel	TBM	✓	✓	✓	✓	
1998	FAMILIA / LASER	1.3L	B3	ABS	✓	✓	✓	✓	
1998	FAMILIA / LASER	1.3L	B3	PCM	✓	✓	✓	✓	
1998	FAMILIA / LASER	1.5L	ZL	ABS	✓	✓	✓	✓	
1998	FAMILIA / LASER	1.5L	ZL	PCM	✓	✓	✓	✓	
1998	FAMILIA / LASER	1.8L	FP	ABS	✓	✓	✓	✓	
1998	FAMILIA / LASER	1.8L	FP	PCM	✓	✓	✓	✓	
1998	FAMILIA / LASER	2.0L	RF	ABS	✓	✓	✓	✓	
1998	FAMILIA / LASER	2.0L	RF	PCM	✓	✓	✓	✓	
1999	FAMILIA / LASER	2.0L	FS	ABS	✓	✓	✓	✓	
1999	FAMILIA / LASER	2.0L	FS	PCM	✓	✓	✓	✓	
2000	FAMILIA / LASER	1.5L	ZL	ABS	✓	✓	✓	✓	
2000	FAMILIA / LASER	1.5L	ZL	ABS/TCS	✓	✓	✓	✓	
2000	FAMILIA / LASER	1.5L	ZL	PCM	✓	✓	✓	✓	
2000	FAMILIA / LASER	2.0L	FS	ABS	✓	✓	✓	✓	
2000	FAMILIA / LASER	2.0L	FS	PCM	✓	✓	✓	✓	
2002	FAMILIA / LASER	1.5L	ZL	ABS/TCS	✓	✓	✓	✓	
2002	FAMILIA / LASER	1.5L	ZL	PCM	✓	✓	✓	✓	
2002	FAMILIA / LASER	2.0L	FS	ABS/TCS	✓	✓	✓	✓	
2002	FAMILIA / LASER	2.0L	FS	PCM	✓	✓	✓	✓	
2010.25	FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2010.25	FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2010.25	FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2010.25	FIGO	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2010.25	FIGO	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008
2010.25	FIGO	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2010.25	FIGO	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2010.25	FIGO	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2010.25	FIGO	1 19L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008
2010.25	FIGO	1 19L	DURATEC 16V	IC	✓	✓	✓	✓	
2010.25	FIGO	1 19L	DURATEC 16V	PCM	✓	✓	✓	✓	
2010.25	FIGO	1 19L	DURATEC 16V	RCM	✓	✓	✓	✓	
2011.25	FIGO	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2011.25	FIGO	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008
2011.25	FIGO	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2011.25	FIGO	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2011.25	FIGO	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2011.25	FIGO	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2011.25	FIGO	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2011.25	FIGO	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008
2011.25	FIGO	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2011.25	FIGO	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2011.25	FIGO	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2011.25	FIGO	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2011.25	FIGO	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2011.25	FIGO	Other	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2011.25	FIGO	Other	DURATEC 16V	GEM	✓	✓	✓	✓	
2011.25	FIGO	Other	DURATEC 16V	IC	✓	✓	✓	✓	
2011.25	FIGO	Other	DURATEC 16V	RCM	✓	✓	✓	✓	

2005	FORD GT	5.4L	4V	ABS/TCS	✓	✓	✓	✓	0008
2005	FORD GT	5.4L	4V	AFCM	✓	✓	✓	✓	
2005	FORD GT	5.4L	4V	GEM	✓	✓	✓	✓	
2005	FORD GT	5.4L	4V	IC	✓	✓	✓	✓	
2005	FORD GT	5.4L	4V	PATS	✓	✓	✓	✓	
2005	FORD GT	5.4L	4V	PCM	✓	✓	✓	✓	0025
2005	FORD GT	5.4L	4V	RCM	✓	✓	✓	✓	
2006	FORD GT	5.4L	4V	ABS/TCS	✓	✓	✓	✓	
2006	FORD GT	5.4L	4V	AFCM	✓	✓	✓	✓	
2006	FORD GT	5.4L	4V	GEM	✓	✓	✓	✓	
2006	FORD GT	5.4L	4V	IC	✓	✓	✓	✓	
2006	FORD GT	5.4L	4V	PATS	✓	✓	✓	✓	
2006	FORD GT	5.4L	4V	PCM	✓	✓	✓	✓	0025
2006	FORD GT	5.4L	4V	RCM	✓	✓	✓	✓	
1997	FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	PCM	✓	✓	✓	✓	
1999	FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	PCM	✓	✓	✓	✓	
1999	FRIENDEE / FRED A / BONGO FRIENDEE	2.5L	WL T	PCM	✓	✓	✓	✓	
2002	FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	PCM	✓	✓	✓	✓	
2002	FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	TCM	✓	✓	✓	✓	
2003	Fairlane / LTD	4.0L	DOHC VCT	ABS/TCS	✓	✓	✓	✓	0008
2003	Fairlane / LTD	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2003	Fairlane / LTD	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0005, 0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2003	Fairlane / LTD	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	0005, 003A
2003	Fairlane / LTD	4.0L	DOHC VCT	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2003	Fairlane / LTD	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2003	Fairlane / LTD	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	0005, 0025, 003A
2003	Fairlane / LTD	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	
2003	Fairlane / LTD	5.4L	3V	ABS/TCS	✓	✓	✓	✓	0008
2003	Fairlane / LTD	5.4L	3V	ACM	✓	✓	✓	✓	0040
2003	Fairlane / LTD	5.4L	3V	BEM	✓	✓	✓	✓	0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2003	Fairlane / LTD	5.4L	3V	HIM	✓	✓	✓	✓	003A
2003	Fairlane / LTD	5.4L	3V	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2003	Fairlane / LTD	5.4L	3V	PAM	✓	✓	✓	✓	0005
2003	Fairlane / LTD	5.4L	3V	PCM	✓	✓	✓	✓	0025, 003A
2003	Fairlane / LTD	5.4L	3V	RCM	✓	✓	✓	✓	
2006	Fairlane / LTD	4.0L	DOHC VCT	ABS	✓	✓	✓	✓	0005, 0008
2006	Fairlane / LTD	4.0L	DOHC VCT	ABS/TCS	✓	✓	✓	✓	0008
2006	Fairlane / LTD	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2006	Fairlane / LTD	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0005, 0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2006	Fairlane / LTD	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	0005, 003A
2006	Fairlane / LTD	4.0L	DOHC VCT	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2006	Fairlane / LTD	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2006	Fairlane / LTD	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	0025
2006	Fairlane / LTD	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	
2006	Fairlane / LTD	4.0L	DOHC VCT	TCM	✓	✓	✓	✓	
2006	Fairlane / LTD	5.4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2006	Fairlane / LTD	5.4L	3V	ABS/TCS	✓	✓	✓	✓	0008
2006	Fairlane / LTD	5.4L	3V	ACM	✓	✓	✓	✓	0040
2006	Fairlane / LTD	5.4L	3V	BEM	✓	✓	✓	✓	0005, 0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2006	Fairlane / LTD	5.4L	3V	HIM	✓	✓	✓	✓	0005, 003A
2006	Fairlane / LTD	5.4L	3V	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2006	Fairlane / LTD	5.4L	3V	PAM	✓	✓	✓	✓	0005
2006	Fairlane / LTD	5.4L	3V	PCM	✓	✓	✓	✓	0005, 0025, 003A
2006	Fairlane / LTD	5.4L	3V	RCM	✓	✓	✓	✓	
2006	Fairlane / LTD	5.4L	3V	TCM	✓	✓	✓	✓	
Other	Fairlane / LTD	4.0L	Other	ABS	✓	✓	✓	✓	0008
Other	Fairlane / LTD	4.0L	Other	ABS/TCS	✓	✓	✓	✓	
Other	Fairlane / LTD	4.0L	Other	ACM	✓	✓	✓	✓	
Other	Fairlane / LTD	4.0L	Other	BEM	✓	✓	✓	✓	
Other	Fairlane / LTD	4.0L	Other	IAB	✓	✓	✓	✓	
Other	Fairlane / LTD	4.0L	Other	IC	✓	✓	✓	✓	0005, F012, F013
Other	Fairlane / LTD	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025
Other	Fairlane / LTD	4.0L	Other	PCM	✓	✓	✓	✓	0025
Other	Fairlane / LTD	4.0L	Other	RCM	✓	✓	✓	✓	
Other	Fairlane / LTD	5.0L	Other	ABS	✓	✓	✓	✓	0008
Other	Fairlane / LTD	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
Other	Fairlane / LTD	5.0L	Other	ACM	✓	✓	✓	✓	
Other	Fairlane / LTD	5.0L	Other	BEM	✓	✓	✓	✓	
Other	Fairlane / LTD	5.0L	Other	IAB	✓	✓	✓	✓	
Other	Fairlane / LTD	5.0L	Other	IC	✓	✓	✓	✓	0005, F012, F013
Other	Fairlane / LTD	5.0L	Other	PCM	✓	✓	✓	✓	0025
Other	Fairlane / LTD	5.0L	Other	RCM	✓	✓	✓	✓	
2003	Fairmont	4.0L	DOHC VCT	ABS/TCS	✓	✓	✓	✓	0008

2003	Fairmont	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2003	Fairmont	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0005, 0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2003	Fairmont	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	0005, 003A
2003	Fairmont	4.0L	DOHC VCT	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2003	Fairmont	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2003	Fairmont	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	0005, 0025, 003A
2003	Fairmont	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	
2003	Fairmont	5.4L	3V	ABS/TCS	✓	✓	✓	✓	0008
2003	Fairmont	5.4L	3V	ACM	✓	✓	✓	✓	0040
2003	Fairmont	5.4L	3V	BEM	✓	✓	✓	✓	0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2003	Fairmont	5.4L	3V	HIM	✓	✓	✓	✓	003A
2003	Fairmont	5.4L	3V	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2003	Fairmont	5.4L	3V	PAM	✓	✓	✓	✓	
2003	Fairmont	5.4L	3V	PCM	✓	✓	✓	✓	0025, 003A
2003	Fairmont	5.4L	3V	RCM	✓	✓	✓	✓	
2006	Fairmont	4.0L	DOHC VCT	ABS	✓	✓	✓	✓	0005, 0008
2006	Fairmont	4.0L	DOHC VCT	ABS/TCS	✓	✓	✓	✓	0008
2006	Fairmont	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2006	Fairmont	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0005, 0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2006	Fairmont	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	0005, 003A
2006	Fairmont	4.0L	DOHC VCT	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2006	Fairmont	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2006	Fairmont	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	0025
2006	Fairmont	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	
2006	Fairmont	4.0L	DOHC VCT	TCM	✓	✓	✓	✓	
2006	Fairmont	5.4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2006	Fairmont	5.4L	3V	ABS/TCS	✓	✓	✓	✓	0008
2006	Fairmont	5.4L	3V	ACM	✓	✓	✓	✓	0040
2006	Fairmont	5.4L	3V	BEM	✓	✓	✓	✓	0005, 0035, F002, F003, F004, F005, F007, F008, F009, F00A, F00D, F00E, F010, F011
2006	Fairmont	5.4L	3V	HIM	✓	✓	✓	✓	0005, 003A
2006	Fairmont	5.4L	3V	IC	✓	✓	✓	✓	0044, 005F, 0061, F006, F00B, F00C, F00F
2006	Fairmont	5.4L	3V	PAM	✓	✓	✓	✓	0005
2006	Fairmont	5.4L	3V	PCM	✓	✓	✓	✓	0005, 0025, 003A
2006	Fairmont	5.4L	3V	RCM	✓	✓	✓	✓	
2006	Fairmont	5.4L	3V	TCM	✓	✓	✓	✓	
Other	Fairmont	4.0L	Other	ABS	✓	✓	✓	✓	0008
Other	Fairmont	4.0L	Other	ABS/TCS	✓	✓	✓	✓	
Other	Fairmont	4.0L	Other	ACM	✓	✓	✓	✓	
Other	Fairmont	4.0L	Other	BEM	✓	✓	✓	✓	
Other	Fairmont	4.0L	Other	IAB	✓	✓	✓	✓	
Other	Fairmont	4.0L	Other	IC	✓	✓	✓	✓	0005, F012, F013
Other	Fairmont	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025
Other	Fairmont	4.0L	Other	PCM	✓	✓	✓	✓	0025
Other	Fairmont	4.0L	Other	RCM	✓	✓	✓	✓	
Other	Fairmont	5.0L	Other	ABS	✓	✓	✓	✓	0008
Other	Fairmont	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
Other	Fairmont	5.0L	Other	ACM	✓	✓	✓	✓	
Other	Fairmont	5.0L	Other	BEM	✓	✓	✓	✓	
Other	Fairmont	5.0L	Other	IAB	✓	✓	✓	✓	
Other	Fairmont	5.0L	Other	IC	✓	✓	✓	✓	0005, F012, F013
Other	Fairmont	5.0L	Other	PCM	✓	✓	✓	✓	0025
Other	Fairmont	5.0L	Other	RCM	✓	✓	✓	✓	
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0005, F024
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BEM	✓	✓	✓	✓	0035
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BEM	✓	✓	✓	✓	0035, 0005
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2011	Falcon	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	0005

2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HIM	✓	✓	✓	✓	
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HIM	✓	✓	✓	✓	0005
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	F020
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	0005
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	Falcon	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Falcon	4.0L	DOHC VCT	ABS	✓	✓	✓	✓	00CA, 0012
2011	Falcon	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0017
2011	Falcon	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0017, 0005, F024
2011	Falcon	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0035
2011	Falcon	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0035, 0005
2011	Falcon	4.0L	DOHC VCT	FDIM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	FDIM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT	IPC	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	IPC	✓	✓	✓	✓	F020
2011	Falcon	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	0025
2011	Falcon	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT	TCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Falcon	4.0L	DOHC VCT LPG	ACM	✓	✓	✓	✓	0017
2011	Falcon	4.0L	DOHC VCT LPG	ACM	✓	✓	✓	✓	0017, 0005, F024
2011	Falcon	4.0L	DOHC VCT LPG	BEM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT LPG	BEM	✓	✓	✓	✓	0035
2011	Falcon	4.0L	DOHC VCT LPG	FDIM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	FDIM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT LPG	HIM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	HIM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT LPG	IPC	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	IPC	✓	✓	✓	✓	F020
2011	Falcon	4.0L	DOHC VCT LPG	PAM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	PAM	✓	✓	✓	✓	0005
2011	Falcon	4.0L	DOHC VCT LPG	PCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	PCM	✓	✓	✓	✓	0025
2011	Falcon	4.0L	DOHC VCT LPG	RCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	RCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	TCM	✓	✓	✓	✓	
2011	Falcon	4.0L	DOHC VCT LPG	TCM	✓	✓	✓	✓	
2011	Falcon	5.0L	4V	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Falcon	5.0L	4V	ACM	✓	✓	✓	✓	0017, 0005, F024
2011	Falcon	5.0L	4V	BEM	✓	✓	✓	✓	0035, 0005
2011	Falcon	5.0L	4V	FDIM	✓	✓	✓	✓	0005
2011	Falcon	5.0L	4V	HIM	✓	✓	✓	✓	0005
2011	Falcon	5.0L	4V	IPC	✓	✓	✓	✓	F020
2011	Falcon	5.0L	4V	PAM	✓	✓	✓	✓	0005
2011	Falcon	5.0L	4V	PCM	✓	✓	✓	✓	0025
2011	Falcon	5.0L	4V	RCM	✓	✓	✓	✓	
2011	Falcon	5.0L	4V	TCM	✓	✓	✓	✓	
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	ABS/TCS	✓	✓	✓	✓	0008
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0035, 0005, F002, F004, F005, F007, F008, F009, F00A, F011, F003, F00D, F00E, F010
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	003A, 0005
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	IC	✓	✓	✓	✓	005F, 0044, 0061, F00B, F00C, F006, F00F
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	0025
2003	Falcon Forte S / Futura / XR / XT	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	

Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	IC	✓	✓	✓	✓	0005, F012, F013
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	PCM	✓	✓	✓	✓	0008, 0025
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	PCM	✓	✓	✓	✓	0025
Other	Falcon Forte S / Futura / XR / XT	4.0L	Other	RCM	✓	✓	✓	✓	
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	ABS	✓	✓	✓	✓	0008
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	ACM	✓	✓	✓	✓	
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	BEM	✓	✓	✓	✓	
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	IAB	✓	✓	✓	✓	
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	IC	✓	✓	✓	✓	0005, F012, F013
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	PCM	✓	✓	✓	✓	0025
Other	Falcon Forte S / Futura / XR / XT	5.0L	Other	RCM	✓	✓	✓	✓	
Other	Festiva	1.5L	Other	PCM	✓	✓	✓	✓	0025
Other	Festiva Sedan	1.5L	Other	PCM	✓	✓	✓	✓	
2002	Fiesta	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3
2002	Fiesta	1.25L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F020
2002	Fiesta	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fiesta	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fiesta	1.3L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta	1.3L	DURATEC 8V	GEM	✓	✓	✓	✓	
2002	Fiesta	1.3L	DURATEC 8V	IC	✓	✓	✓	✓	
2002	Fiesta	1.3L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2002	Fiesta	1.3L	DURATEC 8V	RCM	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0012
2002	Fiesta	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3
2002	Fiesta	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F020
2002	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fiesta	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	
2002	Fiesta	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	003F
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0012
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2002	Fiesta	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2002	Fiesta	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002	Fiesta	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2002	Fiesta	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2002	Fiesta	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fiesta	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fiesta	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2002	Fiesta	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	0070
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0096, 0097, 0099, 009A, 00AD, 00AE
2002	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fiesta	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓	
2006	Fiesta	1.25L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fiesta	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fiesta	1.25L	DURATEC 16V	IC	✓	✓	✓	✓	
2006	Fiesta	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fiesta	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fiesta	1.25L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fiesta	1.3L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta	1.3L	DURATEC 8V	ACM	✓	✓	✓	✓	
2006	Fiesta	1.3L	DURATEC 8V	EATC	✓	✓	✓	✓	
2006	Fiesta	1.3L	DURATEC 8V	GEM	✓	✓	✓	✓	
2006	Fiesta	1.3L	DURATEC 8V	IC	✓	✓	✓	✓	
2006	Fiesta	1.3L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2006	Fiesta	1.3L	DURATEC 8V	RCM	✓	✓	✓	✓	
2006	Fiesta	1.3L	DURATEC 8V	SRM	✓	✓	✓	✓	

2006	Fiesta	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2006	Fiesta	1.4L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fiesta	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3, FOB6
2006	Fiesta	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	F020, F063, FOB5, FOB7
2006	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fiesta	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fiesta	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fiesta	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	003F
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F02D, F030, FOA2, FOB3, FOB6
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F02D, F030, FOA2, FOB3, FOB6, FOB7
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F020, F063, FOB5, FOB7
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F063, FOB5, FOB7
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2006	Fiesta	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	
2006	Fiesta	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fiesta	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fiesta	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2006	Fiesta	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fiesta	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fiesta	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0096, 0097, 0099, 009A, 00AD, 00AE
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.25L	DURATEC 16V	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.25L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.25L	DURATEC 16V	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.25L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.25L	DURATEC 16V	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	00BC
2008.75	Fiesta	1.25L	DURATEC 16V	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.25L	DURATEC 16V	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.25L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.3L	BZ	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.3L	BZ	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	IPC	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	PCM	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.3L	BZ	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.3L	BZ	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.3L	BZ	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	DURATEC 16V	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	DURATEC 16V	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.4L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	DURATEC 16V	IPC	✓	✓	✓	✓	F020

2008.75	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025, 00BC
2008.75	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	00BC
2008.75	Fiesta	1.4L	DURATEC 16V	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.4L	DURATEC 16V	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	00BC
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00B9, 00BD
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00F0
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.5L	BZ	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.5L	BZ	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.5L	BZ	PCM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.5L	BZ	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.5L	BZ	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	BZ	SRM	✓	✓	✓	✓	

2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0099, 009A, 00B4, 00BC
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	ABS	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.5L	TivCT	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	FCDIM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.5L	TivCT	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	IPC	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	PCM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	PSCM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.5L	TivCT	RCM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.5L	TivCT	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	TCM	✓	✓	✓	✓	
2008.75	Fiesta	1.5L	TivCT	TCM	✓	✓	✓	✓	0117
2008.75	Fiesta	1.5L	TivCT	TCM	✓	✓	✓	✓	0117, 0158
2008.75	Fiesta	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	DURATEC VCT	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	0025, 00BC
2008.75	Fiesta	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 00AA, 00B0, 00B1
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	00E9

2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	F020
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00B9, 00BD
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00F0
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TDCi ECO II	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.6L	TDCi ECO II	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TDCi ECO II	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TDCi ECO II	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.6L	TDCi ECO II	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TDCi ECO II	IPC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TDCi ECO II	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00BD, 00C3
2008.75	Fiesta	1.6L	TDCi ECO II	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.6L	TDCi ECO II	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.6L	TDCi ECO II	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TDCi ECO II	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	ABS	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 00E8, 0119
2008.75	Fiesta	1.6L	TivCT	ACM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	BCMii	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	FCDIM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	FCDIM	✓	✓	✓	✓	00E9
2008.75	Fiesta	1.6L	TivCT	HVAC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	IPC	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	PCM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	PSCM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2008.75	Fiesta	1.6L	TivCT	RCM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	RCM	✓	✓	✓	✓	00F0, 0102
2008.75	Fiesta	1.6L	TivCT	RFA	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	SRM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	TCM	✓	✓	✓	✓	
2008.75	Fiesta	1.6L	TivCT	TCM	✓	✓	✓	✓	0117
2011	Fiesta	1.6L	Sigma	ABS	✓	✓	✓	✓	0008, 0012
2011	Fiesta	1.6L	Sigma	ACM	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	APIM	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	BCM#1	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	FCDIM	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	GPSM	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	IPC	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	OCSM	✓	✓	✓	✓	000C
2011	Fiesta	1.6L	Sigma	PCM	✓	✓	✓	✓	0025, 0096, 0097, 009A, 012B, 020A
2011	Fiesta	1.6L	Sigma	PSCM	✓	✓	✓	✓	00CB, 00CC, 011E
2011	Fiesta	1.6L	Sigma	RCM	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	RCM	✓	✓	✓	✓	000C
2011	Fiesta	1.6L	Sigma	RFA	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Fiesta	1.6L	Sigma	TCM	✓	✓	✓	✓	
2011	Fiesta	1.6L	Sigma	VSM	✓	✓	✓	✓	0042
2011	Fiesta	1.6L	TivCT	ABS	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	ABS	✓	✓	✓	✓	0008, 0012
2011	Fiesta	1.6L	TivCT	ACM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	APIM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	BCM#1	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	FCDIM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	GPSM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	IPC	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	OCSM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	OCSM	✓	✓	✓	✓	000C
2011	Fiesta	1.6L	TivCT	PCM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	PSCM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	PSCM	✓	✓	✓	✓	00CB, 00CC, 011E
2011	Fiesta	1.6L	TivCT	RCM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TivCT	RCM	✓	✓	✓	✓	000C
2011	Fiesta	1.6L	TivCT	RFA	✓	✓	✓	✓	

2011	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	0117
2011	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	0117, 0158
2011	Fiesta	1.6L	TiVCT	VSM	✓	✓	✓	✓	
2011	Fiesta	1.6L	TiVCT	VSM	✓	✓	✓	✓	0042
2012	Fiesta	1.6L	Sigma	ABS	✓	✓	✓	✓	0008, 0012
2012	Fiesta	1.6L	Sigma	ACM	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	APIM	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	BCM#1	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	FCDIM	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	GPSM	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	IPC	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	OCSM	✓	✓	✓	✓	000C
2012	Fiesta	1.6L	Sigma	PCM	✓	✓	✓	✓	0025, 0096, 0097, 009A, 012B, 020A
2012	Fiesta	1.6L	Sigma	PSCM	✓	✓	✓	✓	00CB, 00CC, 011E
2012	Fiesta	1.6L	Sigma	RCM	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	RFA	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Fiesta	1.6L	Sigma	TCM	✓	✓	✓	✓	
2012	Fiesta	1.6L	Sigma	VSM	✓	✓	✓	✓	0042
2012	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	Fiesta	1.6L	TiVCT	ACM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	APIM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	BCM#1	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	FCDIM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	GPSM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	IPC	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	OCSM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	OCSM	✓	✓	✓	✓	000C
2012	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓	0025, 0095
2012	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓	00CB, 00CC
2012	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓	00CB, 00CC, 011E
2012	Fiesta	1.6L	TiVCT	RCM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	RCM	✓	✓	✓	✓	000C
2012	Fiesta	1.6L	TiVCT	RFA	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	
2012	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	0117, 0158
2012	Fiesta	1.6L	TiVCT	VSM	✓	✓	✓	✓	0042
2013	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	0012
2013	Fiesta	1.6L	TiVCT	ACM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	APIM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	BCM#1	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	IPC	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	OCSM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓	0095
2013	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓	00CB, 00CC, 011E
2013	Fiesta	1.6L	TiVCT	RCM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	RFA	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	0117, 0158
2013	Fiesta	1.6L	TiVCT	VSM	✓	✓	✓	✓	
2013	Fiesta	1.6L	TiVCT	VSM	✓	✓	✓	✓	0042
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	

2013.25	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2013.25	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.0L	GTDI FGEC	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.0L	GTDI FGEC	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	PCM	✓	✓	✓	✓	00BC, 0115
2013.25	Fiesta	1.0L	GTDI FGEC	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.0L	GTDI FGEC	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.0L	GTDI FGEC	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	GTDI FGEC	TCM	✓	✓	✓	✓	0117
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.0L	Gasoline_Direct_injection	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.25L	DURATEC 16V	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	00BC
2013.25	Fiesta	1.25L	DURATEC 16V	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.25L	DURATEC 16V	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.25L	DURATEC 16V	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.4L	DURATEC 16V	FDSM	✓	✓	✓	✓	

2013.25	Fiesta	1.4L	DURATEC 16V	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	00BC
2013.25	Fiesta	1.4L	DURATEC 16V	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.4L	DURATEC 16V	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.4L	DURATEC 16V	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.5L	DURATEC 16V	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.5L	DURATEC 16V	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	DURATEC 16V	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.5L	DURATEC 16V	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.5L	DURATEC 16V	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00BD
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.5L	TivCT	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.5L	TivCT	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TivCT	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.5L	TivCT	RCM	✓	✓	✓	✓	00EF, 00F0, 0102

2013.25	Fiesta	1.5L	TiVCT	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	TiVCT	TCM	✓	✓	✓	✓	0117, 0158
2013.25	Fiesta	1.5L	Zetec-SE	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.5L	Zetec-SE	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.5L	Zetec-SE	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.5L	Zetec-SE	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.5L	Zetec-SE	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.5L	Zetec-SE	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.6L	DURATEC VCT	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	00BC
2013.25	Fiesta	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	DURATEC VCT	TCM	✓	✓	✓	✓	0117
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00BD
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119

2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.6L	TDCi ECO II	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	FCDIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.6L	TDCi ECO II	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00AF, 00B0, 00B1, 00B2, 00B8, 00BD
2013.25	Fiesta	1.6L	TDCi ECO II	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TDCi ECO II	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.6L	TDCi ECO II	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.6L	TDCi ECO II	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	002B, 002C, 0054, 00D9, 00DB, 0119
2013.25	Fiesta	1.6L	TiVCT	ACM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	APIM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	BCMii	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	DDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	FCDIM	✓	✓	✓	✓	00E9
2013.25	Fiesta	1.6L	TiVCT	FDSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	GPSM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	HVAC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	IPC	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	PDM	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓	00D7, 00D8, 00DA, 00DC
2013.25	Fiesta	1.6L	TiVCT	RCM	✓	✓	✓	✓	00EF, 00F0, 0102
2013.25	Fiesta	1.6L	TiVCT	RFA	✓	✓	✓	✓	
2013.25	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 010A
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	

2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓		
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Fiesta	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 010A
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓		
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Fiesta	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012, 010A
2014	Fiesta	1.6L	TiVCT	ACM	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	APIM	✓	✓	✓	✓	

2014	Fiesta	1.6L	TiVCT	BCM#1	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	DDM	✓	✓	✓		
2014	Fiesta	1.6L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	IPC	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Fiesta	1.6L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2014	Fiesta	1.6L	TiVCT	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Fiesta	1.6L	TiVCT	RCM	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	RFA	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	
2014	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	0117
2014	Fiesta	1.6L	TiVCT	TCM	✓	✓	✓	✓	0117, 0158
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0025
2006.25	Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006.25	Fiesta / Ikon	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006.25	Fiesta / Ikon	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
1992	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	ABS/TCS	✓	✓	✓		
1992	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	CSM	✓	✓	✓		
1992	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	HEC	✓	✓	✓	✓	
1994	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓		
1994	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓		
1994	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓	
1994.5	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓		
1994.5	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓		
1994.5	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓	
1994.5	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	ABS/TCS	✓	✓	✓		
1994.5	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	CSM	✓	✓	✓		
1994.5	Fiesta / Mazda 121 / Bantam	1.8L	Zetec	HEC	✓	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	ABS/TCS	✓	✓	✓		
1996	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	CSM	✓	✓	✓		
1996	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	HEC	✓	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1996	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	ABS/TCS	✓	✓	✓		
1996	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	CSM	✓	✓	✓		
1996	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	HEC	✓	✓	✓	✓	
1996	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1996	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	ABS/TCS	✓	✓	✓		
1996	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	CSM	✓	✓	✓		
1996	Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	HEC	✓	✓	✓	✓	
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	ABS/TCS	✓	✓	✓		
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	CSM	✓	✓	✓		
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	ECS	✓	✓	✓		
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	HEC	✓	✓	✓	✓	
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	FATS	✓	✓	✓	✓	
1996.25	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	PCM			✓	✓	
1996.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓		
1996.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	CSM	✓	✓	✓		
1996.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
1996.5	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1996.75	Fiesta / Mazda 121 / Bantam	1.0L	HCS	ABS/TCS	✓	✓	✓		
1996.75	Fiesta / Mazda 121 / Bantam	1.0L	HCS	CSM	✓	✓	✓		
1996.75	Fiesta / Mazda 121 / Bantam	1.0L	HCS	HEC	✓	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.0L	HCS	PCM	✓	✓	✓	✓	0025
1996.75	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	ABS/TCS	✓	✓	✓		
1996.75	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	CSM	✓	✓	✓		
1996.75	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	HEC	✓	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1996.75	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓		
1996.75	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	CSM	✓	✓	✓		
1996.75	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
1996.75	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1997	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓		
1997	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	CSM	✓	✓	✓		
1997	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
1997	Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1997.5	Fiesta / Mazda 121 / Bantam	1.0L	HCS	ABS/TCS	✓	✓	✓		
1997.5	Fiesta / Mazda 121 / Bantam	1.0L	HCS	CSM	✓	✓	✓		

2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	ABS/TCS	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	CSM	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	ECS	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	HEC	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.4L	PT-E	PCM	✓	✓	✓	✓	
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	ABS/TCS	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	CSM	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	ECS	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	GEM	✓	✓	✓	✓	
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	HEC	✓	✓	✓	✓	
2000	Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	PCM	✓	✓	✓	✓	0025
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	ABS/TCS	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	CSM	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	ECS	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	FIP	✓	✓	✓		
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	GEM	✓	✓	✓	✓	
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	HEC	✓	✓	✓	✓	
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	PATS	✓	✓	✓	✓	
2000	Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	PCM	✓	✓	✓	✓	
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	ABS/TCS	✓	✓	✓		
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	CSM	✓	✓	✓		
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	GEM	✓	✓	✓	✓	
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	HEC	✓	✓	✓	✓	
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	PATS	✓	✓	✓	✓	
2001	Fiesta / Mazda 121 / Bantam	1.6L	Other	PCM	✓	✓	✓	✓	
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	ABS/TCS	✓	✓	✓		
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	CSM	✓	✓	✓		
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	ECS	✓	✓	✓		
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	HEC	✓	✓	✓	✓	
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	PATS	✓	✓	✓	✓	
Other	Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	PCM			✓	✓	
2002	Fiesta 3-Door	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3
2002	Fiesta 3-Door	1.25L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F020
2002	Fiesta 3-Door	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fiesta 3-Door	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.3L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	1.3L	DURATEC 8V	GEM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.3L	DURATEC 8V	IC	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.3L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2002	Fiesta 3-Door	1.3L	DURATEC 8V	RCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0012
2002	Fiesta 3-Door	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3
2002	Fiesta 3-Door	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F020
2002	Fiesta 3-Door	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fiesta 3-Door	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	003F
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0012
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2002	Fiesta 3-Door	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025, 0070
2002	Fiesta 3-Door	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	0070
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0096, 0097, 0099, 009A, 00AD, 00AE

2002	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2002	Fiesta 3-Door	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.25L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.25L	DURATEC 16V	IC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fiesta 3-Door	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.25L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.3L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	1.3L	DURATEC 8V	ACM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.3L	DURATEC 8V	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.3L	DURATEC 8V	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.3L	DURATEC 8V	IC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.3L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2006	Fiesta 3-Door	1.3L	DURATEC 8V	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.3L	DURATEC 8V	SRM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2006	Fiesta 3-Door	1.4L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, F0A2, F0B3, F0B6
2006	Fiesta 3-Door	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	F020, F063, F0B5, F0B7
2006	Fiesta 3-Door	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fiesta 3-Door	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fiesta 3-Door	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	003F
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F02D, F030, F0A2, F0B3, F0B6
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F02D, F030, F0A2, F0B3, F0B6, F0B7
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F020, F063, F0B5, F0B7
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F063, F0B5, F0B7
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2006	Fiesta 3-Door	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	F02D, F030, F0A2, F0B3, F0B6, F0B7
2006	Fiesta 3-Door	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	F020, F063, F0B5
2006	Fiesta 3-Door	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fiesta 3-Door	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025, 0070
2006	Fiesta 3-Door	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fiesta 3-Door	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0096, 0097, 0099, 009A, 00AD, 00AE

2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006	Fiesta 3-Door	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	4X4	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	ABS	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	ABS	✓	✓	✓	✓	0005, 0008
2006	Five Hundred	3.0L	4V	ACM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2006	Five Hundred	3.0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2006	Five Hundred	3.0L	4V	DSM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	DSM	✓	✓	✓	✓	0005
2006	Five Hundred	3.0L	4V	EATC	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	GEM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	GEM	✓	✓	✓	✓	0005
2006	Five Hundred	3.0L	4V	IC	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	IC	✓	✓	✓	✓	0005
2006	Five Hundred	3.0L	4V	PAM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	PAM	✓	✓	✓	✓	006C
2006	Five Hundred	3.0L	4V	PCM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	PCM	✓	✓	✓	✓	0025
2006	Five Hundred	3.0L	4V	RCM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	RCM	✓	✓	✓	✓	0005, 000C, 006D
2006	Five Hundred	3.0L	4V	RETM	✓	✓	✓	✓	
2006	Five Hundred	3.0L	4V	TCM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	4X4	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	ABS	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	ABS	✓	✓	✓	✓	0008
2007	Five Hundred	3.0L	4V	ACM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Five Hundred	3.0L	4V	DSM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	EATC	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	GEM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	IC	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	PAM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	PAM	✓	✓	✓	✓	006C
2007	Five Hundred	3.0L	4V	PCM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	PCM	✓	✓	✓	✓	0025
2007	Five Hundred	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0037
2007	Five Hundred	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2007	Five Hundred	3.0L	4V	RCM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	RCM	✓	✓	✓	✓	000C
2007	Five Hundred	3.0L	4V	RETM	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	SDARS	✓	✓	✓	✓	
2007	Five Hundred	3.0L	4V	SDARS	✓	✓	✓	✓	0019
2007	Five Hundred	3.0L	4V	TCM	✓	✓	✓	✓	
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	4X4	✓	✓	✓	✓	
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	ABS	✓	✓	✓	✓	0005, 0008
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	DSM	✓	✓	✓	✓	0005
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	EATC	✓	✓	✓	✓	
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	GEM	✓	✓	✓	✓	
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	IC	✓	✓	✓	✓	
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	PAM	✓	✓	✓	✓	006C
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	PCM	✓	✓	✓	✓	0025
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	RCM	✓	✓	✓	✓	000C
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	RETM	✓	✓	✓	✓	
2005	Five Hundred (MY05) / Montego (MY05)	3.0L	4V	TCM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	4X4	✓	✓	✓	✓	
2009	Flex	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2009	Flex	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2009	Flex	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Flex	3.5L	4V	DCSM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	DSM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	DSP	✓	✓	✓	✓	
2009	Flex	3.5L	4V	FCIM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	FDIM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Flex	3.5L	4V	HVAC	✓	✓	✓	✓	
2009	Flex	3.5L	4V	IC	✓	✓	✓	✓	
2009	Flex	3.5L	4V	LTM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2009	Flex	3.5L	4V	PAM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	PCM	✓	✓	✓	✓	0025
2009	Flex	3.5L	4V	RCM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	RETM	✓	✓	✓	✓	
2009	Flex	3.5L	4V	SECM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	4X4	✓	✓	✓	✓	0108
2010	Flex	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2010	Flex	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018

2010	Flex	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Flex	3.5L	4V	C-CM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	DCSM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	DDM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	DSM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	DSP	✓	✓	✓	✓	
2010	Flex	3.5L	4V	FCIM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	FDIM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Flex	3.5L	4V	GPSM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	HCM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	HCM-2	✓	✓	✓	✓	
2010	Flex	3.5L	4V	HUD	✓	✓	✓	✓	
2010	Flex	3.5L	4V	HVAC	✓	✓	✓	✓	
2010	Flex	3.5L	4V	IC	✓	✓	✓	✓	
2010	Flex	3.5L	4V	ILCM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	LTM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Flex	3.5L	4V	PAM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	PCM	✓	✓	✓	✓	0025
2010	Flex	3.5L	4V	PSCM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	RCM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	RETM	✓	✓	✓	✓	
2010	Flex	3.5L	4V	SASM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0018
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019, 001C
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	0005
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC	✓	✓	✓	✓	0005
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015

2010	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0005
2010	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2010	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	4X4	✓	✓	✓	✓	0108
2011	Flex	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2011	Flex	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Flex	3.5L	4V	ACM	✓	✓	✓	✓	0018
2011	Flex	3.5L	4V	APIM	✓	✓	✓	✓	0019
2011	Flex	3.5L	4V	C-CM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	DCSM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	DDM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	DSM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	DSP	✓	✓	✓	✓	
2011	Flex	3.5L	4V	FCIM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	FDIM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Flex	3.5L	4V	GPSM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	HCM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	HCM-2	✓	✓	✓	✓	
2011	Flex	3.5L	4V	HUD	✓	✓	✓	✓	
2011	Flex	3.5L	4V	HVAC	✓	✓	✓	✓	
2011	Flex	3.5L	4V	IC	✓	✓	✓	✓	
2011	Flex	3.5L	4V	ILCM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	LTM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Flex	3.5L	4V	PAM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Flex	3.5L	4V	PSCM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	RCM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	RETM	✓	✓	✓	✓	
2011	Flex	3.5L	4V	SASM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	

2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IC	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IHCM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2011	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	4X4	✓	✓	✓	✓	0108
2012	Flex	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2012	Flex	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2012	Flex	3.5L	4V	APIM	✓	✓	✓	✓	0019
2012	Flex	3.5L	4V	DCSM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	DDM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	DSM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	DSP	✓	✓	✓	✓	
2012	Flex	3.5L	4V	FCIM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	FDIM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Flex	3.5L	4V	GPSM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	HCM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	HCM-2	✓	✓	✓	✓	
2012	Flex	3.5L	4V	HVAC	✓	✓	✓	✓	
2012	Flex	3.5L	4V	IC	✓	✓	✓	✓	
2012	Flex	3.5L	4V	IHCM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	LTM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	Flex	3.5L	4V	PAM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2012	Flex	3.5L	4V	PSCM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	RCM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	RETM	✓	✓	✓	✓	
2012	Flex	3.5L	4V	SASM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	

2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IC	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2012	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2012	Flex	Other	Other	4X4	✓	✓	✓	✓	
2012	Flex	Other	Other	ABS	✓	✓	✓	✓	
2012	Flex	Other	Other	ACM	✓	✓	✓	✓	
2012	Flex	Other	Other	APIM	✓	✓	✓	✓	
2012	Flex	Other	Other	DCSM	✓	✓	✓	✓	
2012	Flex	Other	Other	DDM	✓	✓	✓	✓	
2012	Flex	Other	Other	DSM	✓	✓	✓	✓	
2012	Flex	Other	Other	DSP	✓	✓	✓	✓	
2012	Flex	Other	Other	FCIM	✓	✓	✓	✓	
2012	Flex	Other	Other	FDIM	✓	✓	✓	✓	
2012	Flex	Other	Other	GEM / SJB	✓	✓	✓	✓	0042
2012	Flex	Other	Other	GPSM	✓	✓	✓	✓	
2012	Flex	Other	Other	HCM	✓	✓	✓	✓	
2012	Flex	Other	Other	HCM-2	✓	✓	✓	✓	
2012	Flex	Other	Other	HVAC	✓	✓	✓	✓	
2012	Flex	Other	Other	IC	✓	✓	✓	✓	
2012	Flex	Other	Other	ILCM	✓	✓	✓	✓	
2012	Flex	Other	Other	LTM	✓	✓	✓	✓	
2012	Flex	Other	Other	OCSM	✓	✓	✓	✓	
2012	Flex	Other	Other	PAM	✓	✓	✓	✓	
2012	Flex	Other	Other	PSCM	✓	✓	✓	✓	
2012	Flex	Other	Other	RCM	✓	✓	✓	✓	
2012	Flex	Other	Other	RETM	✓	✓	✓	✓	
2012	Flex	Other	Other	SASM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046

2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	ABS	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2013	Flex	3.5L	TiVCT	APIM	✓	✓	✓	✓	0019
2013	Flex	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Flex	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Flex	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	DDM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	HCM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	Flex	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108

2013	Flex	3.5L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0108
2013	Flex	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	RACM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Flex	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPMS	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	

2014	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Flex	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	ABS	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Flex	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Flex	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	DDM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	HCM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	LTM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	Flex	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0108
2014	Flex	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	RACM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Flex	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Flex	Other	Other	ABS	✓	✓	✓	✓	
2014	Flex	Other	Other	ACM	✓	✓	✓	✓	
2014	Flex	Other	Other	APIM	✓	✓	✓	✓	
2014	Flex	Other	Other	BCM#1	✓	✓	✓	✓	
2014	Flex	Other	Other	C-CM	✓	✓	✓	✓	
2014	Flex	Other	Other	DCSM	✓	✓	✓	✓	
2014	Flex	Other	Other	DDM	✓	✓	✓	✓	
2014	Flex	Other	Other	DSM	✓	✓	✓	✓	
2014	Flex	Other	Other	DSP	✓	✓	✓	✓	
2014	Flex	Other	Other	FCDIM	✓	✓	✓	✓	
2014	Flex	Other	Other	FCIM	✓	✓	✓	✓	
2014	Flex	Other	Other	GPSM	✓	✓	✓	✓	
2014	Flex	Other	Other	HCM	✓	✓	✓	✓	
2014	Flex	Other	Other	HUD	✓	✓	✓	✓	
2014	Flex	Other	Other	HVAC	✓	✓	✓	✓	
2014	Flex	Other	Other	IPC	✓	✓	✓	✓	
2014	Flex	Other	Other	LTM	✓	✓	✓	✓	
2014	Flex	Other	Other	OCSM	✓	✓	✓	✓	
2014	Flex	Other	Other	PAM	✓	✓	✓	✓	
2014	Flex	Other	Other	PSCM	✓	✓	✓	✓	
2014	Flex	Other	Other	RACM	✓	✓	✓	✓	
2014	Flex	Other	Other	RCM	✓	✓	✓	✓	
2014	Flex	Other	Other	RFA	✓	✓	✓	✓	
2014	Flex	Other	Other	RTM	✓	✓	✓	✓	
2014	Flex	Other	Other	SCCM	✓	✓	✓	✓	
2014	Flex	Other	Other	SOD-L	✓	✓	✓	✓	
2014	Flex	Other	Other	SOD-R	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	CSM	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	GSM	✓	✓	✓	✓	0008, 0012
1999	Focus	1.4L	Zetec-SE	CTM	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	ECS	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	MC	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	PATS	✓	✓	✓	✓	
1999	Focus	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1999	Focus	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec	CSM	✓	✓	✓	✓	0008, 0012
1999	Focus	1.6L	Zetec	CTM	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec	ECS	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec	HEC	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec	PATS	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec	PCM	✓	✓	✓	✓	0025
1999	Focus	1.6L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec-SE	CSM	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec-SE	CTM	✓	✓	✓	✓	0008, 0012
1999	Focus	1.6L	Zetec-SE	ECS	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec-SE	HEC	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec-SE	MC	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec-SE	PATS	✓	✓	✓	✓	
1999	Focus	1.6L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1999	Focus	1.8L	Endura DI	ABS/TCS	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	CSM	✓	✓	✓	✓	

1999	Focus	1.8L	Endura DI	CSM	✓	✓	✓	✓	0008, 0012
1999	Focus	1.8L	Endura DI	CTM	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	ECS	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	FFH	✓	✓	✓	✓	00CF
1999	Focus	1.8L	Endura DI	FIP	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	HEC	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	MC	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	PATS	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	PCM	✓	✓	✓	✓	
1999	Focus	1.8L	Endura DI	PCM	✓	✓	✓	✓	0008, 0012, 0032
1999	Focus	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	AFCM	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	CSM	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	CSM	✓	✓	✓	✓	0008, 0012
1999	Focus	1.8L	Zetec	CTM	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	CTM	✓	✓	✓	✓	0008
1999	Focus	1.8L	Zetec	ECS	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	HEC	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	MC	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	PATS	✓	✓	✓	✓	
1999	Focus	1.8L	Zetec	PCM	✓	✓	✓	✓	0025
1999	Focus	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	GSM	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	CSM	✓	✓	✓	✓	0008, 0012
1999	Focus	2.0L	Zetec	CTM	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	CTM	✓	✓	✓	✓	0005
1999	Focus	2.0L	Zetec	ECS	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	HEC	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	HEC	✓	✓	✓	✓	0005
1999	Focus	2.0L	Zetec	MC	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	PATS	✓	✓	✓	✓	
1999	Focus	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2000	Focus	2.0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
2000	Focus	2.0L	SPI	GSM	✓	✓	✓	✓	
2000	Focus	2.0L	SPI	CSM	✓	✓	✓	✓	0008, 0012
2000	Focus	2.0L	SPI	CTM	✓	✓	✓	✓	
2000	Focus	2.0L	SPI	ECS	✓	✓	✓	✓	
2000	Focus	2.0L	SPI	HEC	✓	✓	✓	✓	
2000	Focus	2.0L	SPI	PCM	✓	✓	✓	✓	0025
2000	Focus	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2000	Focus	2.0L	Zetec	CSM	✓	✓	✓	✓	
2000	Focus	2.0L	Zetec	CSM	✓	✓	✓	✓	0008, 0012
2000	Focus	2.0L	Zetec	CTM	✓	✓	✓	✓	
2000	Focus	2.0L	Zetec	CTM	✓	✓	✓	✓	0005
2000	Focus	2.0L	Zetec	ECS	✓	✓	✓	✓	
2000	Focus	2.0L	Zetec	HEC	✓	✓	✓	✓	
2000	Focus	2.0L	Zetec	HEC	✓	✓	✓	✓	0005
2000	Focus	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	0012
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CTM	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ECS	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MC	✓	✓	✓	✓	
2001.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	1.4L	Zetec-SE	EATC	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	ECS	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	GEM	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	HCM	✓	✓	✓	✓	0032
2002	Focus	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	MC	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	PATS	✓	✓	✓	✓	
2002	Focus	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
2002	Focus	1.4L	Zetec-SE	RCM	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	1.6L	Zetec	EATC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec	ECS	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec	GEM	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec	HCM	✓	✓	✓	✓	0032
2002	Focus	1.6L	Zetec	HEC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec	MC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec	PCM	✓	✓	✓	✓	0025
2002	Focus	1.6L	Zetec	RCM	✓	✓	✓	✓	

2002	Focus	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	1.6L	Zetec Rocam	EATC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec Rocam	ECS	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec Rocam	GEM	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec Rocam	HCM	✓	✓	✓	✓	0032
2002	Focus	1.6L	Zetec Rocam	HEC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec Rocam	MC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2002	Focus	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	1.6L	Zetec-SE	EATC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	ECS	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	GEM	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	HCM	✓	✓	✓	✓	0032
2002	Focus	1.6L	Zetec-SE	HEC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	MC	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	PATS	✓	✓	✓	✓	
2002	Focus	1.6L	Zetec-SE	PCM	✓	✓	✓	✓	0025
2002	Focus	1.6L	Zetec-SE	RCM	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0012
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ECS	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F02D, F02F, F030, F03A, F09E, FOA1, FOA4
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	0005
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MC	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0005
2002	Focus	1.8L	Endura DI	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	1.8L	Endura DI	EATC	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	ECS	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	FFH	✓	✓	✓	✓	00CF
2002	Focus	1.8L	Endura DI	FIP	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	GEM	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	HCM	✓	✓	✓	✓	0032
2002	Focus	1.8L	Endura DI	HEC	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	MC	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	PATS	✓	✓	✓	✓	
2002	Focus	1.8L	Endura DI	PCM	✓	✓	✓	✓	0008, 0012, 0032
2002	Focus	1.8L	Endura DI	RCM	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	1.8L	Zetec	AFCM	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	EATC	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	ECS	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	GEM	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	HCM	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	HCM	✓	✓	✓	✓	0032
2002	Focus	1.8L	Zetec	HEC	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	MC	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	PCM	✓	✓	✓	✓	
2002	Focus	1.8L	Zetec	PCM	✓	✓	✓	✓	0025
2002	Focus	1.8L	Zetec	RCM	✓	✓	✓	✓	
2002	Focus	2.0L	SPI	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	2.0L	SPI	EATC	✓	✓	✓	✓	
2002	Focus	2.0L	SPI	ECS	✓	✓	✓	✓	
2002	Focus	2.0L	SPI	GEM	✓	✓	✓	✓	
2002	Focus	2.0L	SPI	HCM	✓	✓	✓	✓	0032
2002	Focus	2.0L	SPI	HEC	✓	✓	✓	✓	
2002	Focus	2.0L	SPI	MC	✓	✓	✓	✓	
2002	Focus	2.0L	SPI	PCM	✓	✓	✓	✓	0025
2002	Focus	2.0L	SPI	RCM	✓	✓	✓	✓	
2002	Focus	2.0L	ZETEC ST	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	2.0L	ZETEC ST	EATC	✓	✓	✓	✓	

2002	Focus	2. 0L	ZETEC ST	ECS	✓	✓	✓	✓	
2002	Focus	2. 0L	ZETEC ST	GEM	✓	✓	✓	✓	
2002	Focus	2. 0L	ZETEC ST	HCM	✓	✓	✓	✓	0032
2002	Focus	2. 0L	ZETEC ST	HEC	✓	✓	✓	✓	
2002	Focus	2. 0L	ZETEC ST	MC	✓	✓	✓	✓	
2002	Focus	2. 0L	ZETEC ST	PCM	✓	✓	✓	✓	0025
2002	Focus	2. 0L	ZETEC ST	RCM	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Focus	2. 0L	Zetec	EATC	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	ECS	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	GEM	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	GEM	✓	✓	✓	✓	0005, F02D, F02F, F030, F03A, F09E, F0A1, F0A4
2002	Focus	2. 0L	Zetec	HCM	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	HCM	✓	✓	✓	✓	0032
2002	Focus	2. 0L	Zetec	HEC	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	HEC	✓	✓	✓	✓	0005
2002	Focus	2. 0L	Zetec	MC	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
2002	Focus	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025, F020
2002	Focus	2. 0L	Zetec	RCM	✓	✓	✓	✓	
2002	Focus	2. 0L	Zetec	RCM	✓	✓	✓	✓	0005
2003	Focus	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008, 0012
2003	Focus	2. 0L	SPI	GEM	✓	✓	✓	✓	
2003	Focus	2. 0L	SPI	HEC	✓	✓	✓	✓	
2003	Focus	2. 0L	SPI	PCM	✓	✓	✓	✓	0025
2003	Focus	2. 0L	SPI	RCM	✓	✓	✓	✓	
2003	Focus	2. 0L	ZETEC ST	ABS/TCS	✓	✓	✓	✓	0008, 0012
2003	Focus	2. 0L	ZETEC ST	GEM	✓	✓	✓	✓	
2003	Focus	2. 0L	ZETEC ST	HEC	✓	✓	✓	✓	
2003	Focus	2. 0L	ZETEC ST	PCM	✓	✓	✓	✓	0025
2003	Focus	2. 0L	ZETEC ST	RCM	✓	✓	✓	✓	
2003	Focus	2. 0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008, 0012
2003	Focus	2. 0L	Zetec	GEM	✓	✓	✓	✓	
2003	Focus	2. 0L	Zetec	HEC	✓	✓	✓	✓	
2003	Focus	2. 0L	Zetec	PCM	✓	✓	✓	✓	0025
2003	Focus	2. 0L	Zetec	RCM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2003. 25	Focus	1. 4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	CDP	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	EATC	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2003. 25	Focus	1. 4L	DURATEC 16V	GDM	✓	✓	✓	✓	0100
2003. 25	Focus	1. 4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2003. 25	Focus	1. 4L	DURATEC 16V	IC	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	NAV	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	PAM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	RETM	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	RKE	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	RL DCU	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	RR DCU	✓	✓	✓	✓	
2003. 25	Focus	1. 4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	ABS	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2003. 25	Focus	1. 6L	DURATEC 16V	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 00E8
2003. 25	Focus	1. 6L	DURATEC 16V	ACM	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2003. 25	Focus	1. 6L	DURATEC 16V	CDP	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	CDP	✓	✓	✓	✓	0005
2003. 25	Focus	1. 6L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	D DCU	✓	✓	✓	✓	F026
2003. 25	Focus	1. 6L	DURATEC 16V	EATC	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2003. 25	Focus	1. 6L	DURATEC 16V	FFH	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2003. 25	Focus	1. 6L	DURATEC 16V	GDM	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	GDM	✓	✓	✓	✓	0005
2003. 25	Focus	1. 6L	DURATEC 16V	GDM	✓	✓	✓	✓	0005, 0100
2003. 25	Focus	1. 6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2003. 25	Focus	1. 6L	DURATEC 16V	HCM	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	HCM	✓	✓	✓	✓	0005, 0155, 0156
2003. 25	Focus	1. 6L	DURATEC 16V	IC	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	IC	✓	✓	✓	✓	F01E, F020, F028, F032, F03E
2003. 25	Focus	1. 6L	DURATEC 16V	NAV	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	PAM	✓	✓	✓	✓	
2003. 25	Focus	1. 6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005

2003.25	Focus	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2003.25	Focus	1.6L	DURATEC 16V	P_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	P_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	F027, F031
2003.25	Focus	1.6L	DURATEC 16V	RETM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	RETM	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	DURATEC 16V	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	RL_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	1.6L	DURATEC 16V	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	RR_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2003.25	Focus	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	0070, 00C5
2003.25	Focus	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB
2003.25	Focus	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	D_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	EATC	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	1.6L	DURATEC VCT	GDM	✓	✓	✓	✓	0100
2003.25	Focus	1.6L	DURATEC VCT	GEM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2003.25	Focus	1.6L	DURATEC VCT	IC	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	NAV	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	0025
2003.25	Focus	1.6L	DURATEC VCT	P_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	RETM	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	RKE	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00E8
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	0005, 006B, 0094, 00A1
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0005, 0100
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0005, 0155, 0156
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	

2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F01E, F020, F028, F032, F03E
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0096, 0097, 0098, 0099, 009A
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	F027, F031
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	F026
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	F026
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F038, F039
2003.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2003.25	Focus	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	0005
2003.25	Focus	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2003.25	Focus	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2003.25	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2003.25	Focus	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2003.25	Focus	1.8L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	0005
2003.25	Focus	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F027, F031
2003.25	Focus	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	RL_DCU	✓	✓	✓	✓	0005
2003.25	Focus	1.8L	DURATEC-HE / I4	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	RR_DCU	✓	✓	✓	✓	0005
2003.25	Focus	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2003.25	Focus	1.8L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	

2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 00B4
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2003.25	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8
2003.25	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2003.25	Focus	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02A, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2003.25	Focus	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0005, 0155, 0156
2003.25	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2003.25	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2003.25	Focus	2.0L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F027, F031
2003.25	Focus	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	RL_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	2.0L	DURATEC-HE / I4	RR_DCU	✓	✓	✓	✓	0005, F026
2003.25	Focus	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2003.25	Focus	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0070, 00C5
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	0005, 006B, 0094, 00A1
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0005, 0100

2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	F027, F031
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F039, F03F
2003.25	Focus	2.5L	15	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2003.25	Focus	2.5L	15	ACM	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	ACM	✓	✓	✓	✓	0005
2003.25	Focus	2.5L	15	CDP	✓	✓	✓	✓	0005
2003.25	Focus	2.5L	15	D_DCU	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	EATC	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	EATC	✓	✓	✓	✓	0005
2003.25	Focus	2.5L	15	EPS	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	FFH	✓	✓	✓	✓	002D, 002F
2003.25	Focus	2.5L	15	GDM	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	GEM	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	HCM	✓	✓	✓	✓	0155, 0156
2003.25	Focus	2.5L	15	IC	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	MC	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	NAV	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	PAM	✓	✓	✓	✓	0005
2003.25	Focus	2.5L	15	PCM	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	P_DCU	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	RCM	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	RETM	✓	✓	✓	✓	0005
2003.25	Focus	2.5L	15	RKE	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	RL_DCU	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	RR_DCU	✓	✓	✓	✓	
2003.25	Focus	2.5L	15	SRM	✓	✓	✓	✓	
2003.5	Focus	2.3L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 0012
2003.5	Focus	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2003.5	Focus	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2003.5	Focus	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2003.5	Focus	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2004	Focus	2.0L	SPI	ABS/TCS	✓	✓	✓	✓	0008, 0012
2004	Focus	2.0L	SPI	GEM	✓	✓	✓	✓	
2004	Focus	2.0L	SPI	HEC	✓	✓	✓	✓	
2004	Focus	2.0L	SPI	PCM	✓	✓	✓	✓	0025
2004	Focus	2.0L	SPI	RCM	✓	✓	✓	✓	
2004	Focus	2.0L	ZETEC ST	ABS/TCS	✓	✓	✓	✓	0008, 0012
2004	Focus	2.0L	ZETEC ST	GEM	✓	✓	✓	✓	
2004	Focus	2.0L	ZETEC ST	HEC	✓	✓	✓	✓	
2004	Focus	2.0L	ZETEC ST	PCM	✓	✓	✓	✓	0025
2004	Focus	2.0L	ZETEC ST	RCM	✓	✓	✓	✓	
2004	Focus	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008, 0012
2004	Focus	2.0L	Zetec	GEM	✓	✓	✓	✓	
2004	Focus	2.0L	Zetec	HEC	✓	✓	✓	✓	
2004	Focus	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2004	Focus	2.0L	Zetec	RCM	✓	✓	✓	✓	
2004	Focus	2.3L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008, 0012
2004	Focus	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2004	Focus	2.3L	DURATEC-HE / I4	HEC	✓	✓	✓	✓	
2004	Focus	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2004	Focus	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2004	Focus	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2005	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2005	Focus	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2005	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2005	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2005	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2005	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2005	Focus	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2005	Focus	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2005	Focus	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2005	Focus	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025

2005	Focus	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2005.5	Focus	2. 0L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2005.5	Focus	2. 0L	DURATEC 16V	EATC	✓	✓	✓	✓	
2005.5	Focus	2. 0L	DURATEC 16V	GEM	✓	✓	✓	✓	
2005.5	Focus	2. 0L	DURATEC 16V	HCM	✓	✓	✓	✓	0032
2005.5	Focus	2. 0L	DURATEC 16V	IC	✓	✓	✓	✓	
2005.5	Focus	2. 0L	DURATEC 16V	MC	✓	✓	✓	✓	
2005.5	Focus	2. 0L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2005.5	Focus	2. 0L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2006	Focus	2. 0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2006	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2006	Focus	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2006	Focus	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Focus	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Focus	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	Focus	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2007	Focus	1. 6L	FFV	ABS/TCS	✓	✓	✓	✓	0012
2007	Focus	1. 6L	FFV	GEM	✓	✓	✓	✓	
2007	Focus	1. 6L	FFV	IC	✓	✓	✓	✓	
2007	Focus	1. 6L	FFV	PCM	✓	✓	✓	✓	0025
2007	Focus	1. 6L	FFV	RCM	✓	✓	✓	✓	
2007	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2007	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2007	Focus	2. 0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2007	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2007	Focus	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2007	Focus	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007	Focus	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	Focus	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	Focus	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2007.5	Focus	1. 4L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8
2007.5	Focus	1. 4L	DURATEC 16V	ACM	✓	✓	✓	✓	011A
2007.5	Focus	1. 4L	DURATEC 16V	CDP	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2007.5	Focus	1. 4L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	1. 4L	DURATEC 16V	GDM	✓	✓	✓	✓	0100
2007.5	Focus	1. 4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	HCM	✓	✓	✓	✓	0156
2007.5	Focus	1. 4L	DURATEC 16V	IC	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	NAV	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2007.5	Focus	1. 4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	RETM	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	RKE	✓	✓	✓	✓	
2007.5	Focus	1. 4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8
2007.5	Focus	1. 6L	DURATEC 16V	ACM	✓	✓	✓	✓	011A
2007.5	Focus	1. 6L	DURATEC 16V	CDP	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2007.5	Focus	1. 6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	1. 6L	DURATEC 16V	GDM	✓	✓	✓	✓	0100
2007.5	Focus	1. 6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	HCM	✓	✓	✓	✓	0156
2007.5	Focus	1. 6L	DURATEC 16V	IC	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	NAV	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2007.5	Focus	1. 6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	RETM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	RKE	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2007.5	Focus	1. 6L	DURATEC VCT	ACM	✓	✓	✓	✓	0005
2007.5	Focus	1. 6L	DURATEC VCT	CDP	✓	✓	✓	✓	0005
2007.5	Focus	1. 6L	DURATEC VCT	D DCU	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC VCT	EATC	✓	✓	✓	✓	0005
2007.5	Focus	1. 6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	1. 6L	DURATEC VCT	GDM	✓	✓	✓	✓	0100
2007.5	Focus	1. 6L	DURATEC VCT	GEM	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	1. 6L	DURATEC VCT	IC	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC VCT	NAV	✓	✓	✓	✓	
2007.5	Focus	1. 6L	DURATEC VCT	PAM	✓	✓	✓	✓	0005

2007.5	Focus	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2007.5	Focus	1.6L	DURATEC VCT	P DCU	✓	✓	✓	✓	
2007.5	Focus	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2007.5	Focus	1.6L	DURATEC VCT	RETM	✓	✓	✓	✓	0005
2007.5	Focus	1.6L	DURATEC VCT	RKE	✓	✓	✓	✓	
2007.5	Focus	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	D_DCUI	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0096, 0097, 0098, 0099, 009A, 020A
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	P_DCUI	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2007.5	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 00DD, 00DE, 00E8
2007.5	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	DURATEC-HE / I4	D DCUI	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	D_DCUI	✓	✓	✓	✓	0005, F026
2007.5	Focus	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2007.5	Focus	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	F026, F02D, F02E, F02F, F032, F035, F03A, F03B, F03C
2007.5	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0005, 0155, 0156
2007.5	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	F028, F032, F03E
2007.5	Focus	1.8L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007.5	Focus	1.8L	DURATEC-HE / I4	P DCUI	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	P_DCUI	✓	✓	✓	✓	0005, F026
2007.5	Focus	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	F027, F031
2007.5	Focus	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	0005

2007.5	Focus	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2007.5	Focus	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	F037, F038, F039
2007.5	Focus	1.8L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 00B4
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2007.5	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2007.5	Focus	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007.5	Focus	2.0L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2007.5	Focus	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0070, 00C5
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1

2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0098, 0099, 00AB
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2007.5	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus	2.5L	15	ACM	✓	✓	✓	✓	0005
2007.5	Focus	2.5L	15	CDP	✓	✓	✓	✓	0005
2007.5	Focus	2.5L	15	D DCU	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	EATC	✓	✓	✓	✓	0005
2007.5	Focus	2.5L	15	EPS	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus	2.5L	15	GDM	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	GEM	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus	2.5L	15	IC	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	MC	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	NAV	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	PAM	✓	✓	✓	✓	0005
2007.5	Focus	2.5L	15	PCM	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	P DCU	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	RCM	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	RETM	✓	✓	✓	✓	0005
2007.5	Focus	2.5L	15	RKE	✓	✓	✓	✓	
2007.5	Focus	2.5L	15	SRM	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2008	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005, 0017, 0018, F021, F05A, F078, F079, F07A, F07B, F07C, F07D
2008	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2008	Focus	2.0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2008	Focus	2.0L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	0005, F05A, F078
2008	Focus	2.0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2008	Focus	2.0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F042, F04B, F04C
2008	Focus	2.0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F027
2008	Focus	2.0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2008	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2008	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	F022, F05D
2008	Focus	2.0L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2008	Focus	2.0L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	F062
2008.25	Focus	1.4L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	CDP	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	CMR	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	EATC	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	EPS	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	PAM	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2008.25	Focus	1.4L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	00EA
2008.25	Focus	1.4L	DURATEC 16V	RETM	✓	✓	✓	✓	
2008.25	Focus	1.4L	DURATEC 16V	RKE	✓	✓	✓	✓	

2008.25	Focus	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC 16V	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	CDP	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	CMR	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC 16V	D_DCU	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	EPS	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus	1.6L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F03E
2008.25	Focus	1.6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2008.25	Focus	1.6L	DURATEC 16V	P_DCU	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus	1.6L	DURATEC 16V	RETM	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2008.25	Focus	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	0070, 00C5
2008.25	Focus	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	CMR	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC VCT	D_DCU	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC VCT	EATC	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	EPS	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	1.6L	DURATEC VCT	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	1.6L	DURATEC VCT	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008.25	Focus	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	0025
2008.25	Focus	1.6L	DURATEC VCT	P_DCU	✓	✓	✓	✓	
2008.25	Focus	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus	1.6L	DURATEC VCT	RETM	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	RKE	✓	✓	✓	✓	0005
2008.25	Focus	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	F037, F038, F039
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0096, 0097, 0098, 0099, 009A, 020A
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EA
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2008.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	

2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	0005, 011A
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	D_DCU	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	EATC	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	EPS	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	EPS	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	FFH	✓	✓	✓	✓	002D, 002F
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	GEM	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	GEM	✓	✓	✓	✓	F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0155, 0156
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	IC	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0097, 0098, 0099, 009A, 00B0, 00B1, 00BA
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	P_DCU	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EA
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EA, F027, F031
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	RETM	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	RETM	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	RKE	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	RKE	✓	✓	✓	✓	0005
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	F037, F038, F039
2008. 25	Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	

2008.25	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8
2008.25	Focus	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	0005, F026
2008.25	Focus	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0005, 0155, 0156
2008.25	Focus	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008.25	Focus	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F020
2008.25	Focus	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008.25	Focus	1.8L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	0005, F026
2008.25	Focus	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, 00EA, F027, F031
2008.25	Focus	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2008.25	Focus	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	F037, F038, F039
2008.25	Focus	1.8L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	0005, 006B
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 00B4
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005
2008.25	Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F038, F039
2008.25	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	

2008.25	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	F020
2008.25	Focus	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008.25	Focus	2.0L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, 00EA
2008.25	Focus	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EA
2008.25	Focus	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0070, 00C5
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DC	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DC	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 00AB
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DC	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DC	✓	✓	✓	✓	0005
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0005, 00EA

2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EA
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2008.25	Focus	2.5L	Duratec RS	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	2.5L	Duratec RS	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 00EB, 00EC
2008.25	Focus	2.5L	Duratec RS	ACM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	CDP	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	CMR	✓	✓	✓	✓	
2008.25	Focus	2.5L	Duratec RS	D DCU	✓	✓	✓	✓	
2008.25	Focus	2.5L	Duratec RS	EATC	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	EPS	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	2.5L	Duratec RS	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus	2.5L	Duratec RS	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	2.5L	Duratec RS	IC	✓	✓	✓	✓	0005, 0113, F01E, F020, F028, F032, F036, F03E
2008.25	Focus	2.5L	Duratec RS	MC	✓	✓	✓	✓	
2008.25	Focus	2.5L	Duratec RS	PAM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	PCM	✓	✓	✓	✓	
2008.25	Focus	2.5L	Duratec RS	P DCU	✓	✓	✓	✓	
2008.25	Focus	2.5L	Duratec RS	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus	2.5L	Duratec RS	RETM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	RKE	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	Duratec RS	SRM	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus	2.5L	I5	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 0030, 00DD, 00DE
2008.25	Focus	2.5L	I5	ACM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	ACM	✓	✓	✓	✓	011A
2008.25	Focus	2.5L	I5	CDP	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	CDP	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	CMR	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	D DCU	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	EATC	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	EPS	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus	2.5L	I5	GEM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus	2.5L	I5	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus	2.5L	I5	HCM	✓	✓	✓	✓	0156
2008.25	Focus	2.5L	I5	IC	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	IC	✓	✓	✓	✓	0005, 0113, F01E, F020, F028, F032, F036, F03E
2008.25	Focus	2.5L	I5	MC	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	PAM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	PCM	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	P DCU	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	RCM	✓	✓	✓	✓	0005, 00EA
2008.25	Focus	2.5L	I5	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus	2.5L	I5	RETM	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	RETM	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	RKE	✓	✓	✓	✓	0005
2008.25	Focus	2.5L	I5	SRM	✓	✓	✓	✓	
2008.25	Focus	2.5L	I5	SRM	✓	✓	✓	✓	F037, F038, F039
2009	Focus	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 0012
2009	Focus	1.6L	FFV	EATC	✓	✓	✓	✓	
2009	Focus	1.6L	FFV	GEM	✓	✓	✓	✓	
2009	Focus	1.6L	FFV	HCM	✓	✓	✓	✓	0032
2009	Focus	1.6L	FFV	IC	✓	✓	✓	✓	
2009	Focus	1.6L	FFV	MC	✓	✓	✓	✓	
2009	Focus	1.6L	FFV	PCM	✓	✓	✓	✓	0025
2009	Focus	1.6L	FFV	RCM	✓	✓	✓	✓	
2009	Focus	1.6L	OHC	ABS/TCS	✓	✓	✓	✓	0012
2009	Focus	1.6L	OHC	EATC	✓	✓	✓	✓	
2009	Focus	1.6L	OHC	GEM	✓	✓	✓	✓	
2009	Focus	1.6L	OHC	HCM	✓	✓	✓	✓	0032
2009	Focus	1.6L	OHC	IC	✓	✓	✓	✓	
2009	Focus	1.6L	OHC	MC	✓	✓	✓	✓	
2009	Focus	1.6L	OHC	PCM	✓	✓	✓	✓	0025
2009	Focus	1.6L	OHC	RCM	✓	✓	✓	✓	
2009	Focus	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012

2009	Focus	2. 0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2009	Focus	2. 0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2009	Focus	2. 0L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2009	Focus	2. 0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2009	Focus	2. 0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2009	Focus	2. 0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2009	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2009	Focus	2. 0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C
2009	Focus	2. 0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2009	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2009	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00EB, 00EC
2010	Focus	1. 6L	FFV	ACM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	D DCU	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	EATC	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	EPS	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	GEM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	HCM	✓	✓	✓	✓	0155
2010	Focus	1. 6L	FFV	IC	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	PAM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	PCM	✓	✓	✓	✓	0025, 0096, 0097, 009A, 00AB, 020A
2010	Focus	1. 6L	FFV	PCM	✓	✓	✓	✓	0096, 0097, 009A, 00AB, 020A
2010	Focus	1. 6L	FFV	P DCU	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	RCM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	RKE	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	SRM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Focus	1. 6L	FFV	TCM	✓	✓	✓	✓	
2010	Focus	1. 6L	FFV	TCM	✓	✓	✓	✓	0070, 00C5
2010	Focus	1. 6L	Sigma	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00EB, 00EC
2010	Focus	1. 6L	Sigma	ACM	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	D DCU	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	EATC	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	EPS	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	GEM	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	HCM	✓	✓	✓	✓	0155
2010	Focus	1. 6L	Sigma	IC	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	PAM	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	PCM	✓	✓	✓	✓	0096, 0097, 009A, 00AB, 020A
2010	Focus	1. 6L	Sigma	P DCU	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	RCM	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	RKE	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	SRM	✓	✓	✓	✓	
2010	Focus	1. 6L	Sigma	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Focus	1. 6L	Sigma	TCM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00EB, 00EC
2010	Focus	2. 0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018, F021, F05A, F078, F079, F07A, F07B, F07C, F07D
2010	Focus	2. 0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2010	Focus	2. 0L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	F05A, F078
2010	Focus	2. 0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F042, F04B, F04C
2010	Focus	2. 0L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155
2010	Focus	2. 0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F027
2010	Focus	2. 0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2010	Focus	2. 0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2010	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0096, 0097, 009A
2010	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0096, 0097, 009A
2010	Focus	2. 0L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2010	Focus	2. 0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	
2010	Focus	2. 0L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Focus	2. 0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	ABS	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00EB, 00EC

2010	Focus	2. 0L	FFV	ACM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	D DCU	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	EATC	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	EPS	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	GEM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	HCM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	HCM	✓	✓	✓	✓	0155
2010	Focus	2. 0L	FFV	IC	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	PAM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	PCM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	PCM	✓	✓	✓	✓	0025, 0096, 0097, 009A, 00AB, 020A
2010	Focus	2. 0L	FFV	PCM	✓	✓	✓	✓	0096, 0097, 009A, 00AB, 020A
2010	Focus	2. 0L	FFV	P DCU	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	RCM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	RKE	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	SRM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	TBM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Focus	2. 0L	FFV	TCM	✓	✓	✓	✓	
2010	Focus	2. 0L	FFV	TCM	✓	✓	✓	✓	0070, 00C5
2011	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0012
2011	Focus	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2011	Focus	2. 0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2011	Focus	2. 0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018, F021, F05A, F078, F079, F07A, F07B, F07C, F07D
2011	Focus	2. 0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2011	Focus	2. 0L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2011	Focus	2. 0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2011	Focus	2. 0L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	F05A, F078
2011	Focus	2. 0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2011	Focus	2. 0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F042, F04B, F04C
2011	Focus	2. 0L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	
2011	Focus	2. 0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2011	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2011	Focus	2. 0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F027
2011	Focus	2. 0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2011	Focus	2. 0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2011	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2011	Focus	2. 0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	0140
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011. 25	Focus	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	F020

2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	0141
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0102
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2011.25	Focus	1.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011.25	Focus	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	AHCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	AHCM	✓	✓	✓	✓	00CF
2011.25	Focus	1.6L	DURATEC VCT	APIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	00D5
2011.25	Focus	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	00D5, 0101
2011.25	Focus	1.6L	DURATEC VCT	CCMii	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	CCMii	✓	✓	✓	✓	00F9
2011.25	Focus	1.6L	DURATEC VCT	DDM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	DDM	✓	✓	✓	✓	00FB, 0140
2011.25	Focus	1.6L	DURATEC VCT	DDM	✓	✓	✓	✓	0140
2011.25	Focus	1.6L	DURATEC VCT	DSP	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	FCDIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	FCIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	FDSM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	GPSM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0032
2011.25	Focus	1.6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	F020
2011.25	Focus	1.6L	DURATEC VCT	IPM-A	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	1.6L	DURATEC VCT	IPM-B	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	00BC, 0116, 0117
2011.25	Focus	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	0116
2011.25	Focus	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	00FC, 0141
2011.25	Focus	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	0141
2011.25	Focus	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	0102
2011.25	Focus	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	SASM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	SOD-L	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	SOD-R	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	TCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	DURATEC VCT	TCM	✓	✓	✓	✓	0117
2011.25	Focus	1.6L	DURATEC VCT	TRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	

2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	00D5
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	0140
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	DSP	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FCIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	FDSM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	GPSM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-B	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00B1, 00B3, 00B7, 00B9, 00BC, 00BD, 00C1, 00C3
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	0141
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0102
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 0119
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	00FB, 0140
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	0140
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	

2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓		0032
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	00FC, 0141
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	0141
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0102
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SRM	✓	✓	✓		
2011.25	Focus	1.6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	ABS	✓	✓	✓		002B, 002C, 0053, 00D9, 00DB, 00ES, 0119
2011.25	Focus	1.6L	TDCi ECO III	ACM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	AHCM	✓	✓	✓	✓	00CF
2011.25	Focus	1.6L	TDCi ECO III	APIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	BCMii	✓	✓	✓		00D5
2011.25	Focus	1.6L	TDCi ECO III	BCMii	✓	✓	✓		00D5, 0101
2011.25	Focus	1.6L	TDCi ECO III	BCMii	✓	✓	✓	✓	00D5, 0101
2011.25	Focus	1.6L	TDCi ECO III	CCMii	✓	✓	✓	✓	00F9
2011.25	Focus	1.6L	TDCi ECO III	DDM	✓	✓	✓	✓	0140
2011.25	Focus	1.6L	TDCi ECO III	DSP	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	FCDIM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	FCIM	✓	✓	✓		
2011.25	Focus	1.6L	TDCi ECO III	FDSM	✓	✓	✓		
2011.25	Focus	1.6L	TDCi ECO III	GPSM	✓	✓	✓		
2011.25	Focus	1.6L	TDCi ECO III	HCM	✓	✓	✓		0032
2011.25	Focus	1.6L	TDCi ECO III	HVAC	✓	✓	✓		
2011.25	Focus	1.6L	TDCi ECO III	IPC	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	1.6L	TDCi ECO III	IPM-B	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	PAM	✓	✓	✓	✓	

2011.25	Focus	1.6L	TDCi ECO III	PCM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	PCM	✓	✓	✓	✓	0098, 00AF, 00B0, 00B2, 00B8, 00BD, 00C3
2011.25	Focus	1.6L	TDCi ECO III	PDM	✓	✓	✓	✓	0141
2011.25	Focus	1.6L	TDCi ECO III	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	1.6L	TDCi ECO III	RCM	✓	✓	✓	✓	0102
2011.25	Focus	1.6L	TDCi ECO III	RFA	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	SASM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	SOD-L	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	SOD-R	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	SRM	✓	✓	✓	✓	
2011.25	Focus	1.6L	TDCi ECO III	TRM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	00D5
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	0140
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	DSP	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FCIM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	FDSM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	GPSP	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPM-B	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1, 00E7, 0115, 0116, 013B
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1, 00E7
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	009A
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	0141
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0102
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011.25	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	

2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓		00D5
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓		00D5, 0101
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	0140
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓		0032
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ICM#1	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	0141
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0102
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SRM	✓	✓	✓		
2011.25	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2011.25	Focus	2.0L	Gasoline Direct injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119

2011.25	Focus	2.0L	Gasoline Direct injection	ACM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	AHCM	√	√	√	√	00CF
2011.25	Focus	2.0L	Gasoline Direct injection	APIM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	BCMii	√	√	√	√	00D5, 0101
2011.25	Focus	2.0L	Gasoline Direct injection	CCMii	√	√	√	√	00F9
2011.25	Focus	2.0L	Gasoline Direct injection	DDM	√	√	√	√	0140
2011.25	Focus	2.0L	Gasoline Direct injection	DSP	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	FCDIM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	FCIM	√	√	√		
2011.25	Focus	2.0L	Gasoline Direct injection	FDSM	√	√	√		
2011.25	Focus	2.0L	Gasoline Direct injection	GPSM	√	√	√		
2011.25	Focus	2.0L	Gasoline Direct injection	HCM	√	√	√		0032
2011.25	Focus	2.0L	Gasoline Direct injection	HVAC	√	√	√		
2011.25	Focus	2.0L	Gasoline Direct injection	IPC	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	IPM-A	√	√	√	√	00E5
2011.25	Focus	2.0L	Gasoline Direct injection	IPM-B	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	PAM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	PCM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	PDM	√	√	√	√	0141
2011.25	Focus	2.0L	Gasoline Direct injection	PSCM	√	√	√	√	00DC, 00DF, 00E0, 00E1
2011.25	Focus	2.0L	Gasoline Direct injection	RCM	√	√	√	√	0102
2011.25	Focus	2.0L	Gasoline Direct injection	RFA	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	SASM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	SOD-L	√	√	√		
2011.25	Focus	2.0L	Gasoline Direct injection	SOD-R	√	√	√		
2011.25	Focus	2.0L	Gasoline Direct injection	SRM	√	√	√		
2011.25	Focus	2.0L	Gasoline Direct injection	TCM	√	√	√	√	0117
2011.25	Focus	2.0L	Gasoline Direct injection	TRM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	ABS	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	ABS	√	√	√	√	002B, 002C, 0053, 00D9, 00DB, 00E8, 0119
2011.25	Focus	2.0L	Gasoline Direct injection	ACM	√	√	√		
2011.25	Focus	2.0L	Gasoline Direct injection	ACM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	AHCM	√	√	√		00CF
2011.25	Focus	2.0L	Gasoline Direct injection	AHCM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	AHCM	√	√	√	√	00CF
2011.25	Focus	2.0L	Gasoline Direct injection	APIM	√	√	√		
2011.25	Focus	2.0L	Gasoline Direct injection	APIM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	BCMii	√	√	√		
2011.25	Focus	2.0L	Gasoline Direct injection	BCMii	√	√	√		00D5
2011.25	Focus	2.0L	Gasoline Direct injection	BCMii	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	BCMii	√	√	√	√	00D5, 0101
2011.25	Focus	2.0L	Gasoline Direct injection	CCMii	√	√	√	√	
2011.25	Focus	2.0L	Gasoline Direct injection	CCMii	√	√	√	√	00F9
2011.25	Focus	2.0L	Gasoline Direct injection	DDM	√	√	√	√	

2011.25	Focus	2.0L	Gasoline_Direct_injection	DDM	√	√	√	√	0140
2011.25	Focus	2.0L	Gasoline_Direct_injection	DSP	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	FCDIM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	FCIM	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	FDSM	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	GPSM	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	HCM	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	HCM	√	√	√		0032
2011.25	Focus	2.0L	Gasoline_Direct_injection	HVAC	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	IPC	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	IPC	√	√	√	√	F020
2011.25	Focus	2.0L	Gasoline_Direct_injection	IPM-A	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	IPM-A	√	√	√	√	00E5
2011.25	Focus	2.0L	Gasoline_Direct_injection	IPM-B	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	PAM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	PCM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	PCM	√	√	√	√	0067, 00BC, 0115
2011.25	Focus	2.0L	Gasoline_Direct_injection	PCM	√	√	√	√	0067, 00BC, 0115, 0116
2011.25	Focus	2.0L	Gasoline_Direct_injection	PCM	√	√	√	√	0067, 00BC, 0115, 0117
2011.25	Focus	2.0L	Gasoline_Direct_injection	PDM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	PDM	√	√	√	√	0141
2011.25	Focus	2.0L	Gasoline_Direct_injection	PSCM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	PSCM	√	√	√	√	00DC, 00DF, 00E0, 00E1
2011.25	Focus	2.0L	Gasoline_Direct_injection	PSCM	√	√	√	√	00DC, 00DF, 00E1
2011.25	Focus	2.0L	Gasoline_Direct_injection	RCM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	RCM	√	√	√	√	0102
2011.25	Focus	2.0L	Gasoline_Direct_injection	RFA	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	SASM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	SOD-L	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	SOD-R	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	SRM	√	√	√		
2011.25	Focus	2.0L	Gasoline_Direct_injection	TCM	√	√	√	√	
2011.25	Focus	2.0L	Gasoline_Direct_injection	TCM	√	√	√	√	0117
2011.25	Focus	2.0L	Gasoline_Direct_injection	TRM	√	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injection	ABS	√	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injection	ABS	√	√	√	√	0012
2012	Focus	2.0L	Gasoline_Direct_injection	ACM	√	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injection	ACM	√	√	√	√	0005
2012	Focus	2.0L	Gasoline_Direct_injection	APIM	√	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injection	BCM#1	√	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injection	BCM#1	√	√	√	√	00D5, 0101
2012	Focus	2.0L	Gasoline_Direct_injection	DDM	√	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injection	DDM	√	√	√	√	
2012	Focus	2.0L	Gasoline_Direct_injection	DSP	√	√	√		

2012	Focus	2.0L	Gasoline_Direct_injection	FCDIM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	FCIM	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	GPSM	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	HVAC	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	IPC	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	IPM-B	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	OCSM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	OCSM	✓	✓	✓	✓	000C
2012	Focus	2.0L	Gasoline_Direct_injection	PAM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	PCM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	PCM	✓	✓	✓	✓	0025, 0067, 0095
2012	Focus	2.0L	Gasoline_Direct_injection	PCM	✓	✓	✓	✓	0067, 0095
2012	Focus	2.0L	Gasoline_Direct_injection	PDM	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	PDM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	PSCM	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	PSCM	✓	✓	✓		00CB, 00CC
2012	Focus	2.0L	Gasoline_Direct_injection	PSCM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2012	Focus	2.0L	Gasoline_Direct_injection	RCM	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	RCM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	RFA	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	RFA	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	SASM	✓	✓	✓		
2012	Focus	2.0L	Gasoline_Direct_injection	SASM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	TCM	✓	✓	✓	✓	
2012	Focus	2.0L	Gasoline_Direct_injection	TCM	✓	✓	✓	✓	0117, 0158
2012	Focus	23kWh	Battery Electric Vehicle	ABS	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	ABS	✓	✓	✓	✓	0012
2012	Focus	23kWh	Battery Electric Vehicle	ABS	✓	✓	✓	✓	0012, 010A
2012	Focus	23kWh	Battery Electric Vehicle	ACC#2	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	ACM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	APIM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	BCCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	BCM#1	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	BCM#1	✓	✓	✓	✓	0101
2012	Focus	23kWh	Battery Electric Vehicle	BECM	✓	✓	✓		
2012	Focus	23kWh	Battery Electric Vehicle	BECM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	DCDC	✓	✓	✓		
2012	Focus	23kWh	Battery Electric Vehicle	DCDC	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	DDM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	DDM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	DSP	✓	✓	✓		
2012	Focus	23kWh	Battery Electric Vehicle	DSP	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	FCDIM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	FCIM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	GFM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	GPSM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	GWM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	HCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	HVAC	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	IPC	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	IPM-B	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	OCSM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2012	Focus	23kWh	Battery Electric Vehicle	PAM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	PCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	PCM	✓	✓	✓	✓	0095
2012	Focus	23kWh	Battery Electric Vehicle	PDM	✓	✓	✓		
2012	Focus	23kWh	Battery Electric Vehicle	PDM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	PSCM	✓	✓	✓		
2012	Focus	23kWh	Battery Electric Vehicle	PSCM	✓	✓	✓		00CB, 00CC
2012	Focus	23kWh	Battery Electric Vehicle	PSCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicle	RCM	✓	✓	✓		

2012	Focus	23kWh	Battery Electric Vehicl	RCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	RFA	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	RFA	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	SASM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	SASM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	SOBDM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	SOBDM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	TCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	TCM	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	TCU#1	✓	✓	✓	✓	
2012	Focus	23kWh	Battery Electric Vehicl	TCU#1	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D5, 0101
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ICM#1	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0095
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	ABS	✓	✓	✓	✓	0012
2013	Focus	2.0L	Gasoline_Direct_injection	ACM	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	APIM	✓	✓	✓	✓	
2013	Focus	2.0L	Gasoline_Direct_injection	BCM#1	✓	✓	✓	✓	00D5, 0101
2013	Focus	2.0L	Gasoline_Direct_injection	DDM	✓	✓	✓	✓	

2013	Focus	2.0L	Gasoline_Direct_injection	DSP	√	√	√	√	
2013	Focus	2.0L	Gasoline_Direct_injection	FCDIM	√	√	√	√	
2013	Focus	2.0L	Gasoline_Direct_injection	FCIM	√	√	√	√	
2013	Focus	2.0L	Gasoline_Direct_injection	GPSM	√	√	√	√	
2013	Focus	2.0L	Gasoline_Direct_injection	HVAC	√	√	√	√	
2013	Focus	2.0L	Gasoline_Direct_injection	IPC	√	√	√	√	
2013	Focus	2.0L	Gasoline_Direct_injection	IPM-B	√	√	√	√	
2013	Focus	2.0L	Gasoline_Direct_injection	OCSM	√	√	√	√	000C
2013	Focus	2.0L	Gasoline_Direct_injection	PAM	√	√	√	√	
2013	Focus	2.0L	Gasoline_Direct_injection	PCM	√	√	√	√	0025
2013	Focus	2.0L	Gasoline_Direct_injection	PDM	√	√	√		
2013	Focus	2.0L	Gasoline_Direct_injection	PSCM	√	√	√		00CB, 00CC
2013	Focus	2.0L	Gasoline_Direct_injection	RCM	√	√	√		
2013	Focus	2.0L	Gasoline_Direct_injection	RFA	√	√	√		
2013	Focus	2.0L	Gasoline_Direct_injection	SASM	√	√	√		
2013	Focus	2.0L	Gasoline_Direct_injection	TCM	√	√	√	√	0117, 0158
2013	Focus	23kWh	Battery Electric Vehicle	ABS	√	√	√	√	0012, 010A
2013	Focus	23kWh	Battery Electric Vehicle	ACCM#2	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	ACM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	APIM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	BCM#1	√	√	√	√	00D5, 0101
2013	Focus	23kWh	Battery Electric Vehicle	BCMii	√	√	√	√	0101
2013	Focus	23kWh	Battery Electric Vehicle	BECM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	DCDC	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	DDM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	DDM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	DSP	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	FCDIM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	FCIM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	GFM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	GPSM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	GWM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	HCM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	HVAC	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	IPC	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	IPM-B	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	OCSM	√	√	√	√	000C
2013	Focus	23kWh	Battery Electric Vehicle	PAM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	PCM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	PDM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	PDM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	PSCM	√	√	√	√	00CB, 00CC
2013	Focus	23kWh	Battery Electric Vehicle	PSCM	√	√	√	√	00CB, 00CC
2013	Focus	23kWh	Battery Electric Vehicle	RCM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	RCM	√	√	√	√	00EF
2013	Focus	23kWh	Battery Electric Vehicle	RFA	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	RFA	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	SASM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	SASM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	SOBDM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	TCM	√	√	√	√	
2013	Focus	23kWh	Battery Electric Vehicle	TCU#1	√	√	√	√	
2013	Focus	Other	Other	ABS	√	√	√	√	
2013	Focus	Other	Other	ACM	√	√	√	√	
2013	Focus	Other	Other	APIM	√	√	√	√	
2013	Focus	Other	Other	BCM#1	√	√	√	√	
2013	Focus	Other	Other	BCM#1	√	√	√	√	00D5, 0101
2013	Focus	Other	Other	DDM	√	√	√	√	
2013	Focus	Other	Other	DSP	√	√	√	√	
2013	Focus	Other	Other	FCDIM	√	√	√	√	
2013	Focus	Other	Other	FCIM	√	√	√	√	
2013	Focus	Other	Other	GPSM	√	√	√	√	
2013	Focus	Other	Other	HVAC	√	√	√	√	
2013	Focus	Other	Other	IPC	√	√	√	√	
2013	Focus	Other	Other	IPM-B	√	√	√	√	
2013	Focus	Other	Other	OCSM	√	√	√	√	
2013	Focus	Other	Other	PAM	√	√	√	√	
2013	Focus	Other	Other	PDM	√	√	√	√	
2013	Focus	Other	Other	PSCM	√	√	√	√	00CB, 00CC
2013	Focus	Other	Other	RCM	√	√	√	√	
2013	Focus	Other	Other	RFA	√	√	√	√	
2013	Focus	Other	Other	SASM	√	√	√	√	

2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	√	√	√	√	0012
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	√	√	√		
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	√	√	√		
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	√	√	√	√	00D5, 0101
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	√	√	√		
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	√	√	√	√	
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	√	√	√	√	
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	√	√	√	√	
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	√	√	√	√	
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	√	√	√		
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	√	√	√	√	
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ICM#1	√	√	√	√	
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	√	√	√	√	
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	√	√	√	√	
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	√	√	√	√	000C
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	√	√	√	√	
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	√	√	√	√	0025
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	√	√	√		
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	√	√	√		00CB, 00CC
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	√	√	√		
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	√	√	√		
2014	Focus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	√	√	√		
2014	Focus	2.0L	Gasoline_Direct_injection	ABS	√	√	√	√	0012
2014	Focus	2.0L	Gasoline_Direct_injection	ACM	√	√	√		
2014	Focus	2.0L	Gasoline_Direct_injection	APIM	√	√	√		
2014	Focus	2.0L	Gasoline_Direct_injection	BCM#1	√	√	√	√	00D5, 0101
2014	Focus	2.0L	Gasoline_Direct_injection	DDM	√	√	√		
2014	Focus	2.0L	Gasoline_Direct_injection	DSP	√	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	FCDIM	√	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	FCIM	√	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	GPSM	√	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	HVAC	√	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	IPC	√	√	√	√	
2014	Focus	2.0L	Gasoline_Direct_injection	IPM-B	√	√	√	√	

2014	Focus	2. 0L	Gasoline_Direct_injection	OCSM	✓	✓	✓	✓	000C
2014	Focus	2. 0L	Gasoline_Direct_injection	PAM	✓	✓	✓	✓	
2014	Focus	2. 0L	Gasoline_Direct_injection	PCM	✓	✓	✓	✓	0025
2014	Focus	2. 0L	Gasoline_Direct_injection	PDM	✓	✓	✓		
2014	Focus	2. 0L	Gasoline_Direct_injection	PSCM	✓	✓	✓		00CB, 00CC
2014	Focus	2. 0L	Gasoline_Direct_injection	RCM	✓	✓	✓		
2014	Focus	2. 0L	Gasoline_Direct_injection	RFA	✓	✓	✓		
2014	Focus	2. 0L	Gasoline_Direct_injection	SASM	✓	✓	✓		
2014	Focus	2. 0L	Gasoline_Direct_injection	TCM	✓	✓	✓	✓	0117, 0158
2014	Focus	23kWh	Battery Electric Vehicle	ABS	✓	✓	✓	✓	0012, 010A
2014	Focus	23kWh	Battery Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	ACM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	APIM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	BCM#1	✓	✓	✓	✓	00D5, 0101
2014	Focus	23kWh	Battery Electric Vehicle	BECM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	DCDC	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	DDM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	DSP	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	FCDIM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	FCIM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	GFM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	GPSM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	GWM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	HCM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	HVAC	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	IPC	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	IPM-B	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2014	Focus	23kWh	Battery Electric Vehicle	PAM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	PCM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	PDM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	PSCM	✓	✓	✓	✓	00CB, 00CC
2014	Focus	23kWh	Battery Electric Vehicle	RCM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	RFA	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	SASM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	SOBDM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	TCM	✓	✓	✓	✓	
2014	Focus	23kWh	Battery Electric Vehicle	TCU#1	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 6L	DA	FACM	6E	0x0007 A120	✓	✓	✓
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	CDP	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	EATC	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	EPB	✓	✓	✓	✓	001F
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	GDM	✓	✓	✓	✓	0100
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	IC	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	NAV	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	PAM	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	RETM	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	RKE	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	RL DCU	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	RR DCU	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	CDP	✓	✓	✓	✓	0005
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	EATC	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	EPB	✓	✓	✓	✓	001F
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	GDM	✓	✓	✓	✓	0005, 0100
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	IC	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	NAV	✓	✓	✓	✓	
2002. 75	Focus C-MAX	1. 6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005

2002.75	Focus C-MAX	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002.75	Focus C-MAX	1.6L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	F027, F031
2002.75	Focus C-MAX	1.6L	DURATEC 16V	RETM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	DURATEC 16V	RL DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC 16V	RR DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2002.75	Focus C-MAX	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB
2002.75	Focus C-MAX	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	D DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	EATC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	EPB	✓	✓	✓	✓	001F
2002.75	Focus C-MAX	1.6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	1.6L	DURATEC VCT	GDM	✓	✓	✓	✓	0100
2002.75	Focus C-MAX	1.6L	DURATEC VCT	GEM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	1.6L	DURATEC VCT	IC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	NAV	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	0025
2002.75	Focus C-MAX	1.6L	DURATEC VCT	P DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	RETM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	RKE	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	RL DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	RR DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00E8
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	001F
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	0005, 006B, 0094, 00A1
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002F
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0005, 0100
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	

2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0096, 0097, 0098, 0099, 009A
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0096, 0097, 0098, 0099, 009A, 020A
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	F027, F031
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F038, F039
2002.75	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	EPB	✓	✓	✓	✓	001F
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002F
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F027, F031
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RL_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	RR_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00E8
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	001F
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	

2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 00B4
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	EPB	✓	✓	✓	✓	001F
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02A, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F027, F031
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RL_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	RR_DCU	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0070, 00C5
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	0005, F026
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	0005, 001F, F0B8
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	0005, 006B, 0094, 00A1
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0005, 0100
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F01E, F020, F028, F032, F03E
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	0005, F026

2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	F027, F031
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RL_DCU	✓	✓	✓	✓	F026
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RR_DCU	✓	✓	✓	✓	F026
2002.75	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F039, F03F
2007.5	Focus C-MAX	1.4L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8
2007.5	Focus C-MAX	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	011A
2007.5	Focus C-MAX	1.4L	DURATEC 16V	CDP	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.4L	DURATEC 16V	EPB	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	1.4L	DURATEC 16V	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	RETM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 00DD, 00DE, 00E8
2007.5	Focus C-MAX	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	011A
2007.5	Focus C-MAX	1.6L	DURATEC 16V	CDP	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC 16V	EPB	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	1.6L	DURATEC 16V	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	RETM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2007.5	Focus C-MAX	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC VCT	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	EATC	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC VCT	EPB	✓	✓	✓	✓	001F
2007.5	Focus C-MAX	1.6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	1.6L	DURATEC VCT	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	1.6L	DURATEC VCT	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	1.6L	DURATEC VCT	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	RETM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.6L	DURATEC VCT	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	001F
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1

2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0096, 0097, 0098, 0099, 009A, 020A
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	EPB	✓	✓	✓	✓	001F
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	001F
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002F
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 00B4
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005

2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	EPB	✓	✓	✓	✓	001F
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	0005
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPB	✓	✓	✓	✓	001F
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0098, 0099, 00AB
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2007.5	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus C-MAX	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC 16V	CDP	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC 16V	CMR	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC 16V	D_DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC 16V	EPS	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus C-MAX	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus C-MAX	1.6L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus C-MAX	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2008.25	Focus C-MAX	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F03E
2008.25	Focus C-MAX	1.6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025

2008. 25	Focus C-MAX	1. 6L	DURATEC 16V	P DCU	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 6L	DURATEC 16V	RCM	✓	✓	✓	✓	00EA, F027, F031
2008. 25	Focus C-MAX	1. 6L	DURATEC 16V	RETM	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 6L	DURATEC 16V	RKE	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 6L	DURATEC 16V	TCM	✓	✓	✓	✓	0070, 00C5
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	ACM	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	CDP	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	CMR	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	D DCU	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	EATC	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	EPS	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	IC	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	PAM	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	P DCU	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	RCM	✓	✓	✓	✓	00EA, F027, F031
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	RETM	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	RKE	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, 00EA, F027, F031
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002F
2008. 25	Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F034, F035, F03A, F03B, F03C, F03D
2008. 25	Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2008. 25	Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F03E
2008. 25	Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 00B4
2008. 25	Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	P_DC	✓	✓	✓	✓	
2008. 25	Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EA, F027, F031
2008. 25	Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005
2008. 25	Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008. 25	Focus C-MAX	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2008. 25	Focus C-MAX	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008. 25	Focus C-MAX	2. 0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC

2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F031, F032, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F03E
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F01E, F028, F032, F03E
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	0005
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 00AB
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EA
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2008.25	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	

2008. 25	Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	00FB, 0140
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	00FC, 0141
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0102
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	00FD, 013D
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	F026
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	F026
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	ABS	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8
2011	Focus C-MAX	1. 6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	AHCM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	AHCM	✓	✓	✓	✓	00CF
2011	Focus C-MAX	1. 6L	DURATEC VCT	APIM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	BCMii	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	DDM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	DDM	✓	✓	✓	✓	00FB, 0140
2011	Focus C-MAX	1. 6L	DURATEC VCT	FCDIM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	FDSM	✓	✓	✓	✓	
2011	Focus C-MAX	1. 6L	DURATEC VCT	HCM	✓	✓	✓	✓	

2011	Focus C-MAX	1.6L	DURATEC VCT	HCM	✓	✓	✓		0032
2011	Focus C-MAX	1.6L	DURATEC VCT	HVAC	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	F020
2011	Focus C-MAX	1.6L	DURATEC VCT	IPM-A	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	IPM-A	✓	✓	✓	✓	00E5
2011	Focus C-MAX	1.6L	DURATEC VCT	IPM-B	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	PCM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	00BC, 0116, 0117
2011	Focus C-MAX	1.6L	DURATEC VCT	PDM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	00FC, 0141
2011	Focus C-MAX	1.6L	DURATEC VCT	PSCM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011	Focus C-MAX	1.6L	DURATEC VCT	RCM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	0102
2011	Focus C-MAX	1.6L	DURATEC VCT	RFA	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	RGTM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	RGTM	✓	✓	✓	✓	00FD, 013D
2011	Focus C-MAX	1.6L	DURATEC VCT	SASM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	SASM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	SOD-L	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	SOD-L	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	SOD-R	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	SOD-R	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	SRM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	DURATEC VCT	TRM	✓	✓	✓		
2011	Focus C-MAX	1.6L	DURATEC VCT	TRM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓		002B, 002C, 0053, 00D9, 00DB, 00E8
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓		00CF
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	00FB, 0140
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	FDSM	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓		0032
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓		
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-B	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00B1, 00B3, 00B9, 00BC, 00BD, 00C1, 00C3, 00E7
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	00FC, 0141
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0102
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	

2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	RGTM	√	√	√	√	00FD, 013D
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SASM	√	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	√	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	√	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	√	√	√	√	
2011	Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	TRM	√	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	√	√	√	√	002B, 002C, 0053, 00D9, 00DB, 00E8
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	√	√	√		
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	√	√	√		00CF
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM	√	√	√		
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	√	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM	√	√	√	√	00FB, 0140
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	√	√	√		
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	√	√	√		
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM	√	√	√		0032
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	√	√	√		
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC	√	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	√	√	√	√	00E5
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-B	√	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PAM	√	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PCM	√	√	√	√	009A, 00BC, 00C3, 0114
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PDM	√	√	√	√	00FC, 0141
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	√	√	√	√	00DC, 00DF, 00E0, 00E1
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM	√	√	√	√	0102
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA	√	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM	√	√	√	√	00FD, 013D
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM	√	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L	√	√	√	√	F026
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R	√	√	√	√	F026
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM	√	√	√	√	
2011	Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TRM	√	√	√	√	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	√	√	√		

2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 002C, 0053, 00D9, 00DB, 00E8
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓		00CF
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	00FB, 0140
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	FDSM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓		0032
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPM-B	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1, 00E7, 0116, 013B
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	00FC, 0141
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	00DC, 00DF, 00E0, 00E1
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0102
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	00FD, 013D
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓		F026
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓		F026
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓		

2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓		
2011	Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	CDP	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	D_DCU	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	FTCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	GDM	✓	✓	✓	✓	0005, 0100
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	NAV	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	P_DCU	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	
2006.75	Focus Cabriolet	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	D_DCU	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	FTCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	0100
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02A, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	P_DCU	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0070
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8, 00EB, 00EC
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	0005, 006B, 0094, 00A1
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	FACM	✓	✓	✓	✓	006B, 0094, 00A1
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002D, 002F
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	FTCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0005, 0100
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	

2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F026, F02D, F02E, F02F, F030, F032, F035, F03A, F03B, F03C, F03D
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F01E, F020, F028, F032, F03E
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2006.75	Focus Cabriolet	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	ABS	✓	✓	✓	✓	0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	CDP	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	D DCU	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	EPS	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	FTCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	PAM	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	P_DCU	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	RKE	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 002A, 002C, 0030, 00DD, 00DE, 00E8
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	D DCU	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	EATC	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	EPS	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	FTCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F032, F033, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	IC	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	P_DCU	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	RKE	✓	✓	✓	✓	
2008.25	Focus Cabriolet	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002C, 0030, 00DD, 00DE, 00E8, 00EB, 00EC
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	002D, 002F
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	FTCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	

2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F02D, F02E, F02F, F030, F031, F032, F034, F035, F03A, F03B, F03C, F03D
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	F020
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	RKE	✓	✓	✓	✓	0005
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2008.25	Focus Cabriolet	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	ABS	✓	✓	✓	✓	0012, 0029, 002A, 002C, 0054
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	ABS	✓	✓	✓	✓	0012, 0029, 002A, 002C, 0054
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	D DCU	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	EATC	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	GEM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	HCM	✓	✓	✓	✓	0155, 0156
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	IC	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	PAM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	PCM	✓	✓	✓	✓	00C5
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	P DCU	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	RCM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	RL DCU	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.6L	BZ	RR DCU	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0012, 0029, 002A, 002C, 0054
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0012, 0029, 002A, 002C, 0054
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0155, 0156
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F029, F032, F03E, F03F, F040
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F027, F031
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	RL DCU	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	RR DCU	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	1.8L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0012, 0029, 002A, 002C, 0054
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0012, 0029, 002A, 002C, 0054
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	D DCU	✓	✓	✓	✓	0005, F026
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	EPS	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F025, F026, F02A, F02B, F02C, F02D, F02E, F02F, F030, F032, F035, F03A
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0005, 0155, 0156
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F029, F032, F03E, F03F, F040
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	P DCU	✓	✓	✓	✓	0005, F026
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F027, F031
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	RL DCU	✓	✓	✓	✓	0005, F026
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	RR DCU	✓	✓	✓	✓	0005, F026
2005	Focus VIN = LFA / LVS / AFA / PE1 /	2.0L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2005	Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0012, 0029, 002A, 0054

2007	Freestyle	3.0L	4V	ABS	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	ABS	✓	✓	✓	✓	0008
2007	Freestyle	3.0L	4V	ACM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Freestyle	3.0L	4V	DSM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	EATC	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	GEM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	IC	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	PAM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	PAM	✓	✓	✓	✓	006C
2007	Freestyle	3.0L	4V	PCM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	PCM	✓	✓	✓	✓	0025, 00C5
2007	Freestyle	3.0L	4V	RCM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	RCM	✓	✓	✓	✓	000C
2007	Freestyle	3.0L	4V	RCM	✓	✓	✓	✓	000C, 006D
2007	Freestyle	3.0L	4V	RETM	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	SDARS	✓	✓	✓	✓	
2007	Freestyle	3.0L	4V	SDARS	✓	✓	✓	✓	0019
2007	Freestyle	3.0L	4V	TCM	✓	✓	✓	✓	
2002	Fusion	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fusion	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3
2002	Fusion	1.25L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F020
2002	Fusion	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fusion	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fusion	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0012
2002	Fusion	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	0005, F02D, F030, FOA2, FOB3
2002	Fusion	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	0005, F020
2002	Fusion	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fusion	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	
2002	Fusion	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	003F
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0012
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2002	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2002	Fusion	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	
2002	Fusion	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fusion	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	
2002	Fusion	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	
2002	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	
2002	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2002	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025, 0070
2002	Fusion	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2002	Fusion	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2002	Fusion	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	0070
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0096, 0097, 0099, 009A, 00AD, 00AE
2002	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fusion	1.25L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fusion	1.25L	DURATEC 16V	ACM	✓	✓	✓	✓	
2006	Fusion	1.25L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fusion	1.25L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fusion	1.25L	DURATEC 16V	IC	✓	✓	✓	✓	
2006	Fusion	1.25L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fusion	1.25L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fusion	1.25L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fusion	1.4L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fusion	1.4L	DURATEC 16V	ACM	✓	✓	✓	✓	
2006	Fusion	1.4L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fusion	1.4L	DURATEC 16V	GEM	✓	✓	✓	✓	
2006	Fusion	1.4L	DURATEC 16V	IC	✓	✓	✓	✓	
2006	Fusion	1.4L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fusion	1.4L	DURATEC 16V	RCM	✓	✓	✓	✓	

2006	Fusion	1.4L	DURATEC 16V	SRM	✓	✓	✓	✓	
2006	Fusion	1.4L	DURATEC 16V	TCM	✓	✓	✓	✓	003F
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	0005
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F02D, F030, FOA2, FOB3, FOB6, FOB7
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F020, F063, FOB5
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F020, F063, FOB5, FOB7
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2006	Fusion	1.6L	DURATEC 16V	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fusion	1.6L	DURATEC 16V	ACM	✓	✓	✓	✓	0005
2006	Fusion	1.6L	DURATEC 16V	EATC	✓	✓	✓	✓	
2006	Fusion	1.6L	DURATEC 16V	GEM	✓	✓	✓	✓	F02D, F030, FOA2, FOB3, FOB6, FOB7
2006	Fusion	1.6L	DURATEC 16V	IC	✓	✓	✓	✓	F020, F063, FOB5
2006	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025
2006	Fusion	1.6L	DURATEC 16V	PCM	✓	✓	✓	✓	0025, 0070
2006	Fusion	1.6L	DURATEC 16V	RCM	✓	✓	✓	✓	
2006	Fusion	1.6L	DURATEC 16V	SRM	✓	✓	✓	✓	F037, F038, F039
2006	Fusion	1.6L	DURATEC 16V	TCM	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008, 0012
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0096, 0097, 0099, 009A, 00AD, 00AE
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006	Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2006	Fusion	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2006	Fusion	2.3L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	F044, F048, F04C, F057, F085
2006	Fusion	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2006	Fusion	2.3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2006	Fusion	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	Fusion	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2006	Fusion	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2006	Fusion	2.3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	
2006	Fusion	2.3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2006	Fusion	2.3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	ABS	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	ABS	✓	✓	✓	✓	0008
2006	Fusion	3.0L	4V	ACM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2006	Fusion	3.0L	4V	EATC	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	GEM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	IC	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	OCSM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2006	Fusion	3.0L	4V	PCM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2006	Fusion	3.0L	4V	RCM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	TBM	✓	✓	✓	✓	
2006	Fusion	3.0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2006	Fusion	3.0L	4V	TCM	✓	✓	✓	✓	
2007	Fusion	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2007	Fusion	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2007	Fusion	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008

2007	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0016, 0017, 0018, F05A
2007	Fusion	2. 3L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	F044, F048, F04C, F057, F085
2007	Fusion	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005
2007	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2007	Fusion	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Fusion	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	0019
2007	Fusion	2. 3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	
2007	Fusion	2. 3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2007	Fusion	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	4X4	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	ABS	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2007	Fusion	3. 0L	4V	ACM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Fusion	3. 0L	4V	EATC	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	GEM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	IC	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	IC	✓	✓	✓	✓	0005
2007	Fusion	3. 0L	4V	OCSM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2007	Fusion	3. 0L	4V	PCM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2007	Fusion	3. 0L	4V	RCM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	RCM	✓	✓	✓	✓	0005
2007	Fusion	3. 0L	4V	SDARS	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	SDARS	✓	✓	✓	✓	0019
2007	Fusion	3. 0L	4V	TBM	✓	✓	✓	✓	
2007	Fusion	3. 0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2007	Fusion	3. 0L	4V	TCM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2008	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0016, 0017, 0018, F05A, F062, F07A
2008	Fusion	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2008	Fusion	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2008	Fusion	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F044, F048, F04C, F057, F085, F086
2008	Fusion	2. 3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	F027
2008	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2008	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Fusion	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2008	Fusion	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	F022, F05D
2008	Fusion	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	
2008	Fusion	2. 3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2008	Fusion	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	4X4	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	ABS	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2008	Fusion	3. 0L	4V	ACM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Fusion	3. 0L	4V	APIM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Fusion	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2008	Fusion	3. 0L	4V	HVAC	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	IC	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	OCSM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2008	Fusion	3. 0L	4V	PAM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	PCM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2008	Fusion	3. 0L	4V	RCM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	SDARS	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	TBM	✓	✓	✓	✓	
2008	Fusion	3. 0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3

2008	Fusion	3. 0L	4V	TCM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2009	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F05A, F062, F07A
2009	Fusion	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2009	Fusion	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0005, 0042, F044, F048, F04C, F057, F085, F086
2009	Fusion	2. 3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F027
2009	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Fusion	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2009	Fusion	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2009	Fusion	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Fusion	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	0005
2009	Fusion	2. 3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	
2009	Fusion	2. 3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	Fusion	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	4X4	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	ABS	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2009	Fusion	3. 0L	4V	ACM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Fusion	3. 0L	4V	APIM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Fusion	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Fusion	3. 0L	4V	HVAC	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	IC	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	OCSM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2009	Fusion	3. 0L	4V	PAM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	PCM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2009	Fusion	3. 0L	4V	RCM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	SDARS	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	TBM	✓	✓	✓	✓	
2009	Fusion	3. 0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	Fusion	3. 0L	4V	TCM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Fusion	2. 5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2010	Fusion	2. 5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	Fusion	2. 5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2010	Fusion	2. 5L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2010	Fusion	2. 5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	0005
2010	Fusion	2. 5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	0005, F062
2010	Fusion	2. 5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2010	Fusion	2. 5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C
2010	Fusion	2. 5L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	0005
2010	Fusion	2. 5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Fusion	2. 5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2010	Fusion	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	Fusion	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2010	Fusion	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0067
2010	Fusion	2. 5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	0005
2010	Fusion	2. 5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005
2010	Fusion	2. 5L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	
2010	Fusion	2. 5L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Fusion	2. 5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2010	Fusion	2. 5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2010	Fusion	2. 5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2010	Fusion	2. 5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	Fusion	2. 5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Fusion	2. 5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Fusion	2. 5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	

2010	Fusion	2.5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓		
2010	Fusion	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓		0005
2010	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓		
2010	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	0005
2010	Fusion	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Fusion	2.5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	Fusion	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	0005
2010	Fusion	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Fusion	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2010	Fusion	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	0005
2010	Fusion	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	0005
2010	Fusion	2.5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2010	Fusion	2.5L	HEV / ATKINSON 4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Fusion	2.5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	4X4	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	ABS	✓	✓	✓	✓	0008, 0012
2010	Fusion	3.0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Fusion	3.0L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Fusion	3.0L	4V	DSP	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	FCIM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	FCIM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	FDIM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Fusion	3.0L	4V	GPSM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	HVAC	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	IPC	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	Fusion	3.0L	4V	PAM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	PCM	✓	✓	✓	✓	0067
2010	Fusion	3.0L	4V	PSCM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	RCM	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	SOD-L	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	SOD-R	✓	✓	✓	✓	
2010	Fusion	3.0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Fusion	3.5L	4V	4X4	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2010	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	0018
2010	Fusion	3.5L	4V	APIM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Fusion	3.5L	4V	DSP	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	FCIM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	FCIM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	FDIM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	FDIM	✓	✓	✓	✓	0005, F062
2010	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C, F08A
2010	Fusion	3.5L	4V	GPSM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	HVAC	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	IPC	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Fusion	3.5L	4V	PAM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	PAM	✓	✓	✓	✓	0005
2010	Fusion	3.5L	4V	PCM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037
2010	Fusion	3.5L	4V	PSCM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	RCM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	RCM	✓	✓	✓	✓	0005
2010	Fusion	3.5L	4V	SOD-L	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	SOD-R	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	TBM	✓	✓	✓	✓	
2010	Fusion	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2010	Fusion	3.5L	4V	TCM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2011	Fusion	2.5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2011	Fusion	2.5L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019
2011	Fusion	2.5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2011	Fusion	2.5L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	

2011	Fusion	2.5L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2011	Fusion	2.5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2011	Fusion	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0067
2011	Fusion	2.5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	
2011	Fusion	2.5L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Fusion	2.5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Fusion	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0018
2011	Fusion	2.5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019
2011	Fusion	2.5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Fusion	2.5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Fusion	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Fusion	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2011	Fusion	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2011	Fusion	2.5L	HEV / ATKINSON 4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Fusion	2.5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	4X4	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	ABS	✓	✓	✓	✓	0008, 0012
2011	Fusion	3.0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Fusion	3.0L	4V	APIM	✓	✓	✓	✓	0019
2011	Fusion	3.0L	4V	DSP	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	FCIM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	FCIM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	FDIM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Fusion	3.0L	4V	GPSM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	HVAC	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	IPC	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Fusion	3.0L	4V	PAM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	PCM	✓	✓	✓	✓	0067
2011	Fusion	3.0L	4V	PSCM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	RCM	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	SOD-L	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	SOD-R	✓	✓	✓	✓	
2011	Fusion	3.0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Fusion	3.5L	4V	4X4	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2011	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Fusion	3.5L	4V	APIM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	APIM	✓	✓	✓	✓	0019
2011	Fusion	3.5L	4V	DSP	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	FCIM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	FCIM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	FDIM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Fusion	3.5L	4V	GPSM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	HVAC	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	IPC	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Fusion	3.5L	4V	PAM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	PCM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037
2011	Fusion	3.5L	4V	PSCM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	RCM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	SOD-L	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	SOD-R	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	TBM	✓	✓	✓	✓	
2011	Fusion	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Fusion	3.5L	4V	TCM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2012	Fusion	2.5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	

2012	Fusion	2.5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2012	Fusion	2.5L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019
2012	Fusion	2.5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2012	Fusion	2.5L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C
2012	Fusion	2.5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2012	Fusion	2.5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0067
2012	Fusion	2.5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	
2012	Fusion	2.5L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Fusion	2.5L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D3
2012	Fusion	2.5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2012	Fusion	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0018
2012	Fusion	2.5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019
2012	Fusion	2.5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Fusion	2.5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	Fusion	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2012	Fusion	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2012	Fusion	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2012	Fusion	2.5L	HEV / ATKINSON 4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Fusion	2.5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	4X4	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	ABS	✓	✓	✓	✓	0008, 0012
2012	Fusion	3.0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2012	Fusion	3.0L	4V	APIM	✓	✓	✓	✓	0019
2012	Fusion	3.0L	4V	DSP	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	FCIM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	FCIM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	FDIM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Fusion	3.0L	4V	GPSM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	HVAC	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	IPC	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	Fusion	3.0L	4V	PAM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	PCM	✓	✓	✓	✓	0067
2012	Fusion	3.0L	4V	PSCM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	RCM	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	SOD-L	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	SOD-R	✓	✓	✓	✓	
2012	Fusion	3.0L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Fusion	3.5L	4V	4X4	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2012	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2012	Fusion	3.5L	4V	ACM	✓	✓	✓	✓	0018
2012	Fusion	3.5L	4V	APIM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	APIM	✓	✓	✓	✓	0019
2012	Fusion	3.5L	4V	DSP	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	FCIM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	FCIM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	FDIM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Fusion	3.5L	4V	GPSM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	HVAC	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	IPC	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	Fusion	3.5L	4V	PAM	✓	✓	✓	✓	

2012	Fusion	3.5L	4V	PCM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037
2012	Fusion	3.5L	4V	PSCM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	RCM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	SOD-L	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	SOD-R	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	TBM	✓	✓	✓	✓	
2012	Fusion	3.5L	4V	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2012	Fusion	3.5L	4V	TCM	✓	✓	✓	✓	
2012	Fusion	Other	Other	4X4	✓	✓	✓	✓	
2012	Fusion	Other	Other	ABS	✓	✓	✓	✓	
2012	Fusion	Other	Other	ACM	✓	✓	✓	✓	
2012	Fusion	Other	Other	APIM	✓	✓	✓	✓	
2012	Fusion	Other	Other	DSP	✓	✓	✓	✓	
2012	Fusion	Other	Other	FCIM	✓	✓	✓	✓	
2012	Fusion	Other	Other	FCIM	✓	✓	✓	✓	
2012	Fusion	Other	Other	FDIM	✓	✓	✓	✓	
2012	Fusion	Other	Other	GEM / SJB	✓	✓	✓	✓	0042
2012	Fusion	Other	Other	GPSM	✓	✓	✓	✓	
2012	Fusion	Other	Other	HVAC	✓	✓	✓	✓	
2012	Fusion	Other	Other	IPC	✓	✓	✓	✓	
2012	Fusion	Other	Other	OCSM	✓	✓	✓	✓	
2012	Fusion	Other	Other	PAM	✓	✓	✓	✓	
2012	Fusion	Other	Other	PSCM	✓	✓	✓	✓	
2012	Fusion	Other	Other	RCM	✓	✓	✓	✓	
2012	Fusion	Other	Other	SOD-L	✓	✓	✓	✓	
2012	Fusion	Other	Other	SOD-R	✓	✓	✓	✓	
2012	Fusion	Other	Other	TBM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DCDC	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E

2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0108
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067, 0108
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SCM-G	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SCM-H	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓		✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓		0008, 0012, 00F5, 010A, 020C
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓		
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓		
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓		00D4, 00D5, 00FE, 0112
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓		00D4, 00D5, 0112
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓		0046
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046

2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓		
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓		
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM	✓	✓	✓		
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓		
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0108
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0108
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	

2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-G	√	√	√	√	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-H	√	√	√	√	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	√	√	√	√	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	√	√	√	√	
2013	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	ABS	√	√	√	√	0012, 00F5, 010A, 020C
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	ACCM#2	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	ACM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	APIM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	BCM#1	√	√	√	√	00D4, 00D5, 00FE, 0112
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	BECM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	C-CM	√	√	√	√	0046
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DACM-C	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DCDC	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DDM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DSM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	DSP	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	FCDIM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	FCIM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	GPSM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	GWM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	HUD	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	IPC	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	IPM-A	√	√	√	√	013E
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	OCSM	√	√	√	√	000C
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	PAM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	PCM	√	√	√	√	0025, 0028, 0031, 0033, 0108
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	PDM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	PSCM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	RACM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	RCM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	RTM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SCCM	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SCM-E	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	√	√	√	√	013C
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SOD-L	√	√	√	√	
2013	Fusion	2.0L	Full Hybrid Electric Vehicle	SOD-R	√	√	√	√	
2013	Fusion	2.0L	HEV / ATKINSON 4V	ABS	√	√	√	√	
2013	Fusion	2.0L	HEV / ATKINSON 4V	ACCM#2	√	√	√	√	
2013	Fusion	2.0L	HEV / ATKINSON 4V	ACM	√	√	√	√	
2013	Fusion	2.0L	HEV / ATKINSON 4V	APIM	√	√	√	√	
2013	Fusion	2.0L	HEV / ATKINSON 4V	BCM#1	√	√	√	√	00D4, 00D5, 00FE
2013	Fusion	2.0L	HEV / ATKINSON 4V	BECM	√	√	√	√	
2013	Fusion	2.0L	HEV / ATKINSON 4V	C-CM	√	√	√	√	
2013	Fusion	2.0L	HEV / ATKINSON 4V	DACM-C	√	√	√	√	
2013	Fusion	2.0L	HEV / ATKINSON 4V	DCDC	√	√	√	√	
2013	Fusion	2.0L	HEV / ATKINSON 4V	DDM	√	√	√	√	

2013	Fusion	2. 0L	HEV / ATKINSON 4V	DSM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	FCDIM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	GFM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	GWM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	HCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	HSWM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	HUD	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	IPM-A	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0108
2013	Fusion	2. 0L	HEV / ATKINSON 4V	PDM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	RACM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	RGTM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	RTM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SCCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SCM-E	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SCM-G	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SCM-H	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SOBDM-C	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2013	Fusion	2. 0L	HEV / ATKINSON 4V	VDM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	ABS	✓	✓	✓	✓	00F5, 010A, 020C
2013	Fusion	2. 0L	PHEV	ABS	✓	✓	✓	✓	0012, 00F5, 010A, 020C
2013	Fusion	2. 0L	PHEV	ACCM#2	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	ACCM#2	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	ACM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	ACM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	APIM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	APIM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	Fusion	2. 0L	PHEV	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	Fusion	2. 0L	PHEV	BECM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	C-CM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	C-CM	✓	✓	✓	✓	0046
2013	Fusion	2. 0L	PHEV	DACM-C	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	DCDC	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	DDM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	DSM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	DSP	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	FCDIM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	FCIM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	GFM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	GPSM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	GWM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	HCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	HSWM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	HUD	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	HUD	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	IPC	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	IPM-A	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	IPM-A	✓	✓	✓	✓	013E
2013	Fusion	2. 0L	PHEV	OCSM	✓	✓	✓	✓	000C
2013	Fusion	2. 0L	PHEV	PAM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2013	Fusion	2. 0L	PHEV	PDM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	PSCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	RACM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	RCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	RGTM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	RTM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SCCM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SCM-E	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SCM-G	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SCM-H	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SOBDM	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SOBDM-C	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SOBDM-C	✓	✓	✓	✓	013C
2013	Fusion	2. 0L	PHEV	SOD-L	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	SOD-R	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	TCL#1	✓	✓	✓	✓	
2013	Fusion	2. 0L	PHEV	VDM	✓	✓	✓	✓	
2013	Fusion	2. 5L	IVCT	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2013	Fusion	2. 5L	IVCT	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2013	Fusion	2. 5L	IVCT	ACM	✓	✓	✓	✓	
2013	Fusion	2. 5L	IVCT	ACM	✓	✓	✓	✓	
2013	Fusion	2. 5L	IVCT	APIM	✓	✓	✓	✓	
2013	Fusion	2. 5L	IVCT	APIM	✓	✓	✓	✓	
2013	Fusion	2. 5L	IVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 0112

2013	Fusion	2.5L	IVCT	BCM#1	√	√	√	√	00D4, 00D5, 00FE, 0112
2013	Fusion	2.5L	IVCT	C-CM	√	√	√	√	0046
2013	Fusion	2.5L	IVCT	C-CM	√	√	√	√	0046
2013	Fusion	2.5L	IVCT	DACM-C	√	√	√	√	
2013	Fusion	2.5L	IVCT	DACM-C	√	√	√	√	
2013	Fusion	2.5L	IVCT	DDM	√	√	√	√	
2013	Fusion	2.5L	IVCT	DDM	√	√	√	√	
2013	Fusion	2.5L	IVCT	DSM	√	√	√	√	
2013	Fusion	2.5L	IVCT	DSP	√	√	√	√	
2013	Fusion	2.5L	IVCT	FCDIM	√	√	√	√	
2013	Fusion	2.5L	IVCT	FCIM	√	√	√	√	
2013	Fusion	2.5L	IVCT	GFM	√	√	√	√	
2013	Fusion	2.5L	IVCT	GPSM	√	√	√	√	
2013	Fusion	2.5L	IVCT	GWM	√	√	√	√	
2013	Fusion	2.5L	IVCT	HCM	√	√	√	√	
2013	Fusion	2.5L	IVCT	HSWM	√	√	√	√	
2013	Fusion	2.5L	IVCT	HUD	√	√	√	√	
2013	Fusion	2.5L	IVCT	HUD	√	√	√	√	
2013	Fusion	2.5L	IVCT	IPC	√	√	√	√	
2013	Fusion	2.5L	IVCT	IPM-A	√	√	√	√	013E
2013	Fusion	2.5L	IVCT	OCSM	√	√	√	√	
2013	Fusion	2.5L	IVCT	OCSM	√	√	√	√	000C
2013	Fusion	2.5L	IVCT	PAM	√	√	√	√	
2013	Fusion	2.5L	IVCT	PCM	√	√	√	√	0025, 0028, 0031, 0033, 0067, 0108
2013	Fusion	2.5L	IVCT	PCM	√	√	√	√	0025, 0028, 0031, 0033, 0108
2013	Fusion	2.5L	IVCT	PDM	√	√	√	√	
2013	Fusion	2.5L	IVCT	PSCM	√	√	√	√	
2013	Fusion	2.5L	IVCT	RACM	√	√	√	√	
2013	Fusion	2.5L	IVCT	RCM	√	√	√	√	
2013	Fusion	2.5L	IVCT	RGTM	√	√	√	√	
2013	Fusion	2.5L	IVCT	RTM	√	√	√	√	
2013	Fusion	2.5L	IVCT	SCCM	√	√	√	√	
2013	Fusion	2.5L	IVCT	SCM-E	√	√	√	√	
2013	Fusion	2.5L	IVCT	SCM-G	√	√	√	√	
2013	Fusion	2.5L	IVCT	SCM-H	√	√	√	√	
2013	Fusion	2.5L	IVCT	SOD-L	√	√	√	√	
2013	Fusion	2.5L	IVCT	SOD-R	√	√	√	√	
2013	Fusion	2.5L	IVCT	VDM	√	√	√	√	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	√	√	√	√	0008, 0012, 00F5, 010A, 020C
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	√	√	√	√	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	√	√	√	√	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	√	√	√	√	0042, 00D4, 00D5, 00FE, 0112, 020F
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	√	√	√	√	0046
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C	√	√	√	√	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DCDC	√	√	√	√	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	√	√	√	√	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	√	√	√	√	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	√	√	√	√	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	√	√	√	√	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	√	√	√	√	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	√	√	√	√	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	GWM	√	√	√	√	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	√	√	√	√	
2014	Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	√	√	√	√	

2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0108
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Fusion	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112, 020F
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E

2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Fusion	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112, 020F
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	

2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	√	√	√	√	0025, 0028, 0031, 0033, 0108
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	√	√	√	√	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	√	√	√	√	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	√	√	√	√	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	√	√	√	√	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	√	√	√	√	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	√	√	√	√	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	√	√	√	√	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	√	√	√	√	
2014	Fusion	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	ABS	√	√	√	√	0012, 00F5, 010A, 020C
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	ACCM#2	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	ACM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	APIM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	BCM#1	√	√	√	√	0042, 00D4, 00D5, 00FE, 0112, 020F
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	BECM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	C-CM	√	√	√	√	0046
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DACM-C	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DCDC	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DDM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DSM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	DSP	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	FCDIM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	FCIM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	GPSM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	GWM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	HUD	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	IPC	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	IPM-A	√	√	√	√	013E
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	OCSM	√	√	√	√	000C
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PAM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PCM	√	√	√	√	0025, 0028, 0031, 0033, 0108
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PCM	√	√	√	√	0025, 0108
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PDM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	PSCM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	RACM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	RCM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	RTM	√	√	√	√	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SCCM	√	√	√	√	

2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SCM-E	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	✓	✓	✓	✓	013C
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SOD-L	✓	✓	✓	✓	
2014	Fusion	2.0L	Full Hybrid Electric Vehicle	SOD-R	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	ABS	✓	✓	✓	✓	0012, 00F5, 010A, 020C
2014	Fusion	2.0L	PHEV	ACCM#2	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	ACM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	APIM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112, 020F
2014	Fusion	2.0L	PHEV	BECM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	C-CM	✓	✓	✓	✓	0046
2014	Fusion	2.0L	PHEV	DACM-C	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	DCDC	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	DDM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	DSM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	DSP	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	FCDIM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	FCIM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	GFM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	GPSM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	GWM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	HUD	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	IPC	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	IPM-A	✓	✓	✓	✓	013E
2014	Fusion	2.0L	PHEV	OCSM	✓	✓	✓	✓	000C
2014	Fusion	2.0L	PHEV	PAM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	PCM	✓	✓	✓	✓	0025, 0108
2014	Fusion	2.0L	PHEV	PDM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	PSCM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	RACM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	RCM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	RTM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	SCCM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	SCM-E	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	SOBDM	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	SOBDM-C	✓	✓	✓	✓	013C
2014	Fusion	2.0L	PHEV	SOD-L	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	SOD-R	✓	✓	✓	✓	
2014	Fusion	2.0L	PHEV	TCU#1	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2014	Fusion	2.5L	IVCT	ACM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	APIM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112, 020F
2014	Fusion	2.5L	IVCT	C-CM	✓	✓	✓	✓	0046
2014	Fusion	2.5L	IVCT	DACM-C	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	DDM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	DSM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	DSP	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	FCDIM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	FCIM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	GPSM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	GWM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	HUD	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	IPC	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	IPM-A	✓	✓	✓	✓	013E
2014	Fusion	2.5L	IVCT	OCSM	✓	✓	✓	✓	000C
2014	Fusion	2.5L	IVCT	PAM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Fusion	2.5L	IVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Fusion	2.5L	IVCT	PCM	✓	✓	✓	✓	0025, 0108
2014	Fusion	2.5L	IVCT	PDM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	PSCM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	RACM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	RCM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	RTM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	SCCM	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	SCM-E	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	SOD-L	✓	✓	✓	✓	
2014	Fusion	2.5L	IVCT	SOD-R	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	

2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0092, 0098, 0099, 009A, 00AB, 00AC, 00B4, 00C1, 020A
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0102
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	00CF
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	00AC
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0102
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RGTM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RHVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020

2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0092, 0098, 0099, 009A, 00AB, 00AC, 00B4, 00C1, 020A
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	0102
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	0121, 0122, 0123, 0124, 0125
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C, 0132, 0153
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00A5, 00AA, 00AF, 00B0, 00B1, 00B2, 00B8, 00B9, 00BB, 00C1
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	00CF

2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	F020
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RGTM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RHVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0121, 0122, 0123, 0124, 0125
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0121, 0123
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2006.5	GALAXY\S-Max	2.5L	I5	ACM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	AHCM	✓	✓	✓	✓	00CF
2006.5	GALAXY\S-Max	2.5L	I5	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2006.5	GALAXY\S-Max	2.5L	I5	CCMii	✓	✓	✓	✓	00F9
2006.5	GALAXY\S-Max	2.5L	I5	CDP	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	DDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	GDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	HCM	✓	✓	✓	✓	0032
2006.5	GALAXY\S-Max	2.5L	I5	HVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	IPC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	NAV	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	PAM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2006.5	GALAXY\S-Max	2.5L	I5	PCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	PDM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	PSCM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	RCM	✓	✓	✓	✓	0102
2006.5	GALAXY\S-Max	2.5L	I5	RFA	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	RGTM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	RHVAC	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	SASM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	SRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	TRM	✓	✓	✓	✓	
2006.5	GALAXY\S-Max	2.5L	I5	VDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	0005
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	DABM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8

2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00B1, 00B3, 00B7, 00B9, 00BC, 00BD, 00C1, 00C3
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	CDP	✓	✓	✓	✓	0005
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	CMR	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	DABM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	NAV	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	

2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF, 0102
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	00CF
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	DABM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	DSM	✓	✓	✓	✓	00F2
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	IPM-A	✓	✓	✓	✓	00E5
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	00AC
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RGTM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	RHVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	DABM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	

2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0092, 0098, 0099, 009A, 00AB, 00AC, 00B4, 00C1, 020A
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	0121, 0122, 0123, 0124, 0125
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	00CF
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C, 0132
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	00F9
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	0005
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DABM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓	✓	00F2
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	

2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0032
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	F020
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-A	✓	✓	✓	✓	00E5
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	NAV	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1, 013B
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	009A
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 0102
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	0102
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 0102
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RHVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RHVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓	✓	F026

2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓		F026
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓		
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓		
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓		
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓		
2010. 5	GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	011B, 011C
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	CDP	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	CMR	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DABM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	NAV	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	

2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF, 0102
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	DABM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00A5, 00AA, 00AF, 00B0, 00B1, 00B2, 00B8, 00B9, 00BB, 00C1
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	

2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	F026
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	00CF
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	00CF
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C, 0132
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	00F9
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DABM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓	✓	00F2
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0032
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-A	✓	✓	✓	✓	00E5
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	NAV	✓	✓	✓	✓	
2010. 5	GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	

2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0092, 0099, 009A, 00B2, 00B8, 00BE
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 0102
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	0102
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	RHVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8, 0129
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	00CF
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	DABM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	DSM	✓	✓	✓	✓	00F2
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	IPM-A	✓	✓	✓	✓	00E5
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RGTM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	RHVAC	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	F026
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0121, 0122, 0123, 0124, 0125
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2010.5	GALAXY\S-Max	2.3L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	CCM	✓	✓	✓	✓	
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	CJB	✓	✓	✓	✓	
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	IC	✓	✓	✓	✓	
1995.5	Galaxy	2.0L	2.0 DOHC SFI (8V)	PATS	✓	✓	✓	✓	

2001	Galaxy	1.9L	EDC 1.9	PAM	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	PATS	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	PCM	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	RADIO	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	RCC	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	RCM	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	RHID	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	RNS	✓	✓	✓	✓	
2001	Galaxy	1.9L	EDC 1.9	TCM	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	ABS	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	CCM	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	CJB	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	IC	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	LHID	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	MFSW	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	PAM	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	PATS	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	PCM	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	RADIO	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	RCC	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	RCM	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	RHID	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	RNS	✓	✓	✓	✓	
2001	Galaxy	2.8L	2.8 CD-V6	TCM	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	ABS	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	CCM	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	CJB	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	IC	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	PATS	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	PCM	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	RCM	✓	✓	✓	✓	
Other	Galaxy	1.9L	EDC 1.9	TCM	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	ABS	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	CCM	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	CJB	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	IC	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	PATS	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	PCM	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	RCM	✓	✓	✓	✓	
Other	Galaxy	2.8L	2.8 CD-V6	TCM	✓	✓	✓	✓	
1991.5	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓	
1991.5	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓	
1991.5	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓	
1991.5	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	
1991.5	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	0025
1991.5	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓	
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓	
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓	
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓	
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	0025
1993.75	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓	
1995	Granada / Scorpio	2.0L	Other	ABS/TCS	✓	✓	✓	✓	
1995	Granada / Scorpio	2.0L	Other	GEM	✓	✓	✓	✓	
1995	Granada / Scorpio	2.0L	Other	PATS			✓	✓	
1995	Granada / Scorpio	2.0L	Other	PATS	✓	✓	✓	✓	
1995	Granada / Scorpio	2.0L	Other	PCM	✓	✓	✓	✓	0025
1995	Granada / Scorpio	2.0L	Other	RCM	✓	✓	✓	✓	
1995	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓	
1995	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓	
1995	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓	
1995	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	
1995	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	0025
1995	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	GEM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	PATS			✓	✓	
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1995.25	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	RCM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	ABS/TCS	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	GEM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	PATS			✓	✓	
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	PATS	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	PCM	✓	✓	✓	✓	0025
1995.25	Granada / Scorpio	2.0L	DOHC SFI (16V)	RCM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	0025
1995.25	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓	
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	ABS/TCS	✓	✓	✓	✓	
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	GEM	✓	✓	✓	✓	
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	PATS			✓	✓	
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	PATS	✓	✓	✓	✓	
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓	0025
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓	0025, 0025
1996.75	Granada / Scorpio	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓	
1997	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	

1997	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	GEM	✓	✓	✓	✓	
1997	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	PATS	✓		✓	✓	
1997	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1997	Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	RCM	✓		✓	✓	
1997	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓	
1997	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓	
1997	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓	
1997	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	
1997	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	0025
1997	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓	
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	ABS/TCS	✓	✓	✓	✓	
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	GEM	✓	✓	✓	✓	
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	PATS	✓		✓	✓	
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	PATS	✓	✓	✓	✓	
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓	0025
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓	0025, 0025
1998	Granada / Scorpio	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓	
1998	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓	
1998	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓	
1998	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓	
1998	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	
1998	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	0025
1998	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓	
1998.25	Granada / Scorpio	2.3L	DOHC SFI (16V)	ABS/TCS	✓	✓	✓	✓	
1998.25	Granada / Scorpio	2.3L	DOHC SFI (16V)	GEM	✓	✓	✓	✓	
1998.25	Granada / Scorpio	2.3L	DOHC SFI (16V)	PATS	✓	✓	✓	✓	
1998.25	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓	0025
1998.25	Granada / Scorpio	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓	0025, 0025
1998.25	Granada / Scorpio	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓	
1998.25	Granada / Scorpio	2.9L	2.9 V6 24V	ABS/TCS	✓	✓	✓	✓	
1998.25	Granada / Scorpio	2.9L	2.9 V6 24V	GEM	✓	✓	✓	✓	
1998.25	Granada / Scorpio	2.9L	2.9 V6 24V	PATS	✓	✓	✓	✓	
1998.25	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	
1998.25	Granada / Scorpio	2.9L	2.9 V6 24V	PCM	✓	✓	✓	✓	0025
1998.25	Granada / Scorpio	2.9L	2.9 V6 24V	RCM	✓	✓	✓	✓	
Other	Granada / Scorpio	2.5L	Other	ABS/TCS	✓	✓	✓	✓	
Other	Granada / Scorpio	2.5L	Other	GEM	✓	✓	✓	✓	
Other	Granada / Scorpio	2.5L	Other	PATS	✓		✓	✓	
Other	Granada / Scorpio	2.5L	Other	PATS	✓	✓		Other	
Other	Granada / Scorpio	2.5L	Other	PCM	✓	✓	✓	✓	
Other	Granada / Scorpio	2.5L	Other	RCM	✓	✓	✓	✓	
1995	Grand Marquis	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1995	Grand Marquis	4.6L	2V	DDM	✓	✓	✓		
1995	Grand Marquis	4.6L	2V	DSM	✓	✓	✓		
1995	Grand Marquis	4.6L	2V	EATC	✓	✓	✓		
1995	Grand Marquis	4.6L	2V	LCM	✓	✓	✓		
1995	Grand Marquis	4.6L	2V	PCM	✓	✓	✓	✓	0025
1996	Grand Marquis	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1996	Grand Marquis	4.6L	2V	DDM	✓	✓	✓	✓	
1996	Grand Marquis	4.6L	2V	DSM	✓	✓	✓	✓	
1996	Grand Marquis	4.6L	2V	EATC	✓	✓	✓	✓	
1996	Grand Marquis	4.6L	2V	IAB	✓	✓	✓	✓	
1996	Grand Marquis	4.6L	2V	LCM	✓	✓	✓	✓	
1996	Grand Marquis	4.6L	2V	PCM	✓	✓	✓	✓	0025
1996	Grand Marquis	4.6L	2V NGV	ABS/TCS	✓	✓	✓	✓	0008
1996	Grand Marquis	4.6L	2V NGV	DDM	✓	✓	✓	✓	
1996	Grand Marquis	4.6L	2V NGV	DSM	✓	✓	✓	✓	
1996	Grand Marquis	4.6L	2V NGV	FIM	✓	✓	✓	✓	
1996	Grand Marquis	4.6L	2V NGV	IAB	✓	✓	✓	✓	
1996	Grand Marquis	4.6L	2V NGV	LCM	✓	✓	✓	✓	
1996	Grand Marquis	4.6L	2V NGV	PCM	✓	✓	✓	✓	
1997	Grand Marquis	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1997	Grand Marquis	4.6L	2V	DDM	✓	✓	✓	✓	
1997	Grand Marquis	4.6L	2V	DSM	✓	✓	✓	✓	
1997	Grand Marquis	4.6L	2V	EATC	✓	✓	✓	✓	
1997	Grand Marquis	4.6L	2V	IAB	✓	✓	✓	✓	
1997	Grand Marquis	4.6L	2V	LCM	✓	✓	✓	✓	
1997	Grand Marquis	4.6L	2V	PCM	✓	✓	✓	✓	0025
1998	Grand Marquis	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1998	Grand Marquis	4.6L	2V	DDM	✓	✓	✓	✓	
1998	Grand Marquis	4.6L	2V	EATC	✓	✓	✓	✓	
1998	Grand Marquis	4.6L	2V	ECS	✓	✓	✓	✓	
1998	Grand Marquis	4.6L	2V	IAB	✓	✓	✓	✓	
1998	Grand Marquis	4.6L	2V	LCM	✓	✓	✓	✓	
1998	Grand Marquis	4.6L	2V	PATS	✓	✓	✓	✓	
1998	Grand Marquis	4.6L	2V	PCM	✓	✓	✓	✓	0025
1999	Grand Marquis	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1999	Grand Marquis	4.6L	2V	DDM	✓	✓	✓	✓	
1999	Grand Marquis	4.6L	2V	EATC	✓	✓	✓	✓	
1999	Grand Marquis	4.6L	2V	ECS	✓	✓	✓	✓	
1999	Grand Marquis	4.6L	2V	LCM	✓	✓	✓	✓	
1999	Grand Marquis	4.6L	2V	PATS	✓	✓	✓	✓	
1999	Grand Marquis	4.6L	2V	PCM	✓	✓	✓	✓	0025
2000	Grand Marquis	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
2000	Grand Marquis	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2000	Grand Marquis	4.6L	2V	DDM	✓	✓	✓	✓	
2000	Grand Marquis	4.6L	2V	EATC	✓	✓	✓	✓	
2000	Grand Marquis	4.6L	2V	ECS	✓	✓	✓	✓	

2010	Grand Marquis	4. 6L	2V	ABS	✓	✓	✓	✓	0008
2010	Grand Marquis	4. 6L	2V	DDM	✓	✓	✓	✓	0042
2010	Grand Marquis	4. 6L	2V	HVAC	✓	✓	✓	✓	
2010	Grand Marquis	4. 6L	2V	IC	✓	✓	✓	✓	
2010	Grand Marquis	4. 6L	2V	LCM	✓	✓	✓	✓	
2010	Grand Marquis	4. 6L	2V	MC	✓	✓	✓	✓	
2010	Grand Marquis	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Grand Marquis	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2010	Grand Marquis	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2010	Grand Marquis	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2011	Grand Marquis	4. 6L	2V	ABS	✓	✓	✓	✓	0008
2011	Grand Marquis	4. 6L	2V	DDM	✓	✓	✓	✓	0042
2011	Grand Marquis	4. 6L	2V	HVAC	✓	✓	✓	✓	
2011	Grand Marquis	4. 6L	2V	IC	✓	✓	✓	✓	
2011	Grand Marquis	4. 6L	2V	LCM	✓	✓	✓	✓	
2011	Grand Marquis	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Grand Marquis	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2011	Grand Marquis	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
1999. 75	Ikon	1. 6L	Zetec Rocam	ECS	✓	✓	✓	✓	
1999. 75	Ikon	1. 6L	Zetec Rocam	HEC	✓	✓	✓	✓	
1999. 75	Ikon	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	
1999. 75	Ikon	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2000. 25	Ikon	1. 8L	Endura-DE	PCM			✓	✓	
2000. 5	Ikon	1. 3L	HCS	PCM	✓	✓	✓	✓	0025
2001	Ikon	1. 6L	Other	ECS	✓	✓	✓	✓	
2001	Ikon	1. 6L	Other	HEC	✓	✓	✓	✓	
2001	Ikon	1. 6L	Other	PCM	✓	✓	✓	✓	
2003	Ikon	1. 3L	Zetec Rocam	PCM	✓	✓	✓	✓	
2003	Ikon	1. 3L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2003	Ikon	1. 6L	Zetec Rocam	ECS	✓	✓	✓	✓	
2003	Ikon	1. 6L	Zetec Rocam	HEC	✓	✓	✓	✓	
2003	Ikon	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	
2003	Ikon	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2003. 25	Ikon	1. 3L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008
2003. 25	Ikon	1. 3L	Zetec Rocam	CSM	✓	✓	✓	✓	
2003. 25	Ikon	1. 3L	Zetec Rocam	ECS	✓	✓	✓	✓	
2003. 25	Ikon	1. 3L	Zetec Rocam	GEM	✓	✓	✓	✓	
2003. 25	Ikon	1. 3L	Zetec Rocam	PCM	✓	✓	✓	✓	
2003. 25	Ikon	1. 3L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2003. 25	Ikon	1. 6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2003. 25	Ikon	1. 6L	Zetec Rocam	CSM	✓	✓	✓	✓	
2003. 25	Ikon	1. 6L	Zetec Rocam	ECS	✓	✓	✓	✓	
2003. 25	Ikon	1. 6L	Zetec Rocam	GEM	✓	✓	✓	✓	
2003. 25	Ikon	1. 6L	Zetec Rocam	HEC	✓	✓	✓	✓	
2003. 25	Ikon	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	
2003. 25	Ikon	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2003. 25	Ikon	1. 6L	Zetec Rocam	TCM	✓	✓	✓	✓	
2009. 25	Ikon	1. 4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	0005
2009. 25	Ikon	1. 4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0025
2009	KA	1. 2L	DURATEC 8V	ABS	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	BCMii	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	CTMii	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	EATC	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	EPS	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	IPC	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	PAM	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	PCM	✓	✓	✓	✓	
2009	KA	1. 2L	DURATEC 8V	RCM	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	CTMii	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2009	KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2009	KA	Other	Other	ABS	✓	✓	✓	✓	
2009	KA	Other	Other	BCMii	✓	✓	✓	✓	
2009	KA	Other	Other	CTMii	✓	✓	✓	✓	
2009	KA	Other	Other	EATC	✓	✓	✓	✓	
2009	KA	Other	Other	EPS	✓	✓	✓	✓	
2009	KA	Other	Other	IPC	✓	✓	✓	✓	
2009	KA	Other	Other	PAM	✓	✓	✓	✓	
2009	KA	Other	Other	PCM	✓	✓	✓	✓	
2009	KA	Other	Other	RCM	✓	✓	✓	✓	
1997	Ka	1. 3L	Endura-E	ABS/TCS	✓	✓	✓	✓	

1997	Ka	1.3L	Endura-E	CSM	✓	✓	✓		
1997	Ka	1.3L	Endura-E	PATS	✓	✓	✓		
1997	Ka	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1997.5	Ka	1.0L	HCS	ABS/TCS	✓	✓	✓	✓	
1997.5	Ka	1.0L	HCS	CSM	✓	✓	✓		
1997.5	Ka	1.0L	HCS	PATS	✓	✓	✓		
1997.5	Ka	1.0L	HCS	PCM	✓	✓	✓	✓	0025
1997.5	Ka	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1997.5	Ka	1.3L	Endura-E	GSM	✓	✓	✓		
1997.5	Ka	1.3L	Endura-E	PATS	✓	✓	✓		
1997.5	Ka	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1998.5	Ka	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1998.5	Ka	1.3L	Endura-E	CSM	✓	✓	✓		
1998.5	Ka	1.3L	Endura-E	PATS	✓	✓	✓		
1998.5	Ka	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1999	Ka	1.0L	HCS	ABS/TCS	✓	✓	✓	✓	
1999	Ka	1.0L	HCS	CSM	✓	✓	✓		
1999	Ka	1.0L	HCS	ECS	✓	✓	✓		
1999	Ka	1.0L	HCS	PCM	✓	✓	✓	✓	0025
1999	Ka	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
1999	Ka	1.3L	Endura-E	CSM	✓	✓	✓		
1999	Ka	1.3L	Endura-E	ECS	✓	✓	✓		
1999	Ka	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
1999.75	Ka	1.0L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
1999.75	Ka	1.0L	Zetec Rocam	CSM	✓	✓	✓		
1999.75	Ka	1.0L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2000	Ka	1.3L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	
2000	Ka	1.3L	DURATEC 8V	CSM	✓	✓	✓		
2000	Ka	1.3L	DURATEC 8V	ECS	✓	✓	✓		
2000	Ka	1.3L	DURATEC 8V	GEM	✓	✓	✓	✓	
2000	Ka	1.3L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2000	Ka	1.3L	Endura-E	ABS/TCS	✓	✓	✓	✓	
2000	Ka	1.3L	Endura-E	CSM	✓	✓	✓		
2000	Ka	1.3L	Endura-E	ECS	✓	✓	✓		
2000	Ka	1.3L	Endura-E	GEM	✓	✓	✓	✓	
2000	Ka	1.3L	Endura-E	PCM	✓	✓	✓	✓	0025
2000	Ka	1.6L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	
2000	Ka	1.6L	DURATEC 8V	CSM	✓	✓	✓		
2000	Ka	1.6L	DURATEC 8V	ECS	✓	✓	✓		
2000	Ka	1.6L	DURATEC 8V	GEM	✓	✓	✓	✓	
2000	Ka	1.6L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2001.5	Ka	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2001.5	Ka	1.6L	Zetec Rocam	CSM	✓	✓	✓		
2001.5	Ka	1.6L	Zetec Rocam	ECS	✓	✓	✓		
2001.5	Ka	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓		0005, 0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓		
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓		011A
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	AWD	✓	✓	✓	✓	0005
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	D_DCU	✓	✓	✓	✓	
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0005
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	EPS	✓	✓	✓	✓	0005
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	002F, 0090, 0092, 0098, 0099, 00AB, 00AC, 00B4, 00C1
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	0005, F025, F026, F02B, F02D, F02E, F02F, F030, F032, F034, F035, F03A, F03D
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0155, 0156
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	0005
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 00AB, 00AC, 00B4, 00C1
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	P_DCU	✓	✓	✓	✓	
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EA, F027, F031
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	0005
2008.5	Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	0005

2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	011D
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0005, 0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0005, 0008, 0029, 002A, 002B, 002C, 00DD, 00DE, 00E8
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓		
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓		0005, 011A
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓		011A
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	011A
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AWD	✓	✓	✓		0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AWD	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AWD	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓		
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	D_DCU	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	EATC	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	EPS	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	EPS	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	FFH	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	FFH	✓	✓	✓	✓	002D, 002F
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	FFH	✓	✓	✓	✓	002F
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	GEM	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	GEM	✓	✓	✓	✓	F025, F026, F02B, F02D, F02E, F02F, F030, F032, F034, F035, F03A
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	GEM	✓	✓	✓	✓	F025, F026, F02B, F02D, F02E, F02F, F030, F032, F034, F035, F03A, F03D
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0155, 0156
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IC	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F032, F036, F03E
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IC	✓	✓	✓	✓	0005, F01E, F028, F032, F036, F03E
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	

2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1, 00E7, 013B
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	P_DCU	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EA
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EA, F027, F031
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RETM	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RETM	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RKE	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RKE	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	011D
2008. 5	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 0030, 00D9, 00DD, 00DE, 00E8
2008. 5	Kuga	2. 5L	15	ABS	✓	✓	✓	✓	0005, 0008, 0029, 002A, 002B, 002C, 0030, 00DD, 00DE, 00E8
2008. 5	Kuga	2. 5L	15	ACM	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	ACM	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	ACM	✓	✓	✓	✓	0005, 011A
2008. 5	Kuga	2. 5L	15	ACM	✓	✓	✓	✓	011A
2008. 5	Kuga	2. 5L	15	ACM	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	ACM	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	AWD	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	CMR	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	D DCU	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	EATC	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	EPS	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	FFH	✓	✓	✓	✓	002F
2008. 5	Kuga	2. 5L	15	GEM	✓	✓	✓	✓	0005, F025, F026, F02B, F02D, F02E, F02F, F030, F032, F034, F035, F03A, F03D
2008. 5	Kuga	2. 5L	15	HCM	✓	✓	✓	✓	0155, 0156
2008. 5	Kuga	2. 5L	15	IC	✓	✓	✓	✓	0005, F01E, F020, F028, F031, F032, F036, F03E
2008. 5	Kuga	2. 5L	15	PAM	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	PCM	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	P_DCU	✓	✓	✓	✓	
2008. 5	Kuga	2. 5L	15	RCM	✓	✓	✓	✓	0005, 00EA, F027
2008. 5	Kuga	2. 5L	15	RETM	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	RKE	✓	✓	✓	✓	0005
2008. 5	Kuga	2. 5L	15	SRM	✓	✓	✓	✓	011D
2008. 5	Kuga	2. 5L	15	TCM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012, 00E8
2013. 25	Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017
2013. 25	Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2013. 25	Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013. 25	Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5, 0101

2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	0046
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	0140
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	0141
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CB, 00CC
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	013D
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	ABS	✓	✓	✓	✓	0012, 00E8
2013. 25	Kuga	1. 6L	GTDI FGEC	ACM	✓	✓	✓	✓	0017
2013. 25	Kuga	1. 6L	GTDI FGEC	AHCM	✓	✓	✓	✓	00CF
2013. 25	Kuga	1. 6L	GTDI FGEC	APIM	✓	✓	✓	✓	0019
2013. 25	Kuga	1. 6L	GTDI FGEC	BCMii	✓	✓	✓	✓	00D5, 0101
2013. 25	Kuga	1. 6L	GTDI FGEC	CCMii	✓	✓	✓	✓	0046
2013. 25	Kuga	1. 6L	GTDI FGEC	DDM	✓	✓	✓	✓	0140
2013. 25	Kuga	1. 6L	GTDI FGEC	FCDIM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	FDSM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	GPSM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	HCM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	HVAC	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	IPC	✓	✓	✓	✓	F020
2013. 25	Kuga	1. 6L	GTDI FGEC	IPM-A	✓	✓	✓	✓	00E5
2013. 25	Kuga	1. 6L	GTDI FGEC	IPM-B	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	PAM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	PCM	✓	✓	✓	✓	00BC, 0108
2013. 25	Kuga	1. 6L	GTDI FGEC	PDM	✓	✓	✓	✓	0141
2013. 25	Kuga	1. 6L	GTDI FGEC	PSCM	✓	✓	✓	✓	00CB, 00CC
2013. 25	Kuga	1. 6L	GTDI FGEC	RCM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	RFA	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	RGTM	✓	✓	✓	✓	013D
2013. 25	Kuga	1. 6L	GTDI FGEC	SASM	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	SOD-L	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	SOD-R	✓	✓	✓	✓	
2013. 25	Kuga	1. 6L	GTDI FGEC	TRM	✓	✓	✓	✓	

2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0012, 00E8
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	0017
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	00CF
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	APTM	✓	✓	✓	✓	0019
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	00D5, 0101
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	0046
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	0140
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	FDSM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	GPSM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-A	✓	✓	✓	✓	00E5
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-B	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00B0, 00B1, 00B3, 00B8, 00B9, 00BC, 00BF, 00C1, 00E7, 0108, 0115, 013B
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	0141
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00CB, 00CC
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓	✓	013D
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓	✓	
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓		0005, 0012, 00E8
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017

2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	0005, 00CF
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	0005, 00D5, 0101
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	0046
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	0005, 0140
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	0005, 00E5
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0067, 0108
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	0005, 0141
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	0005, 00CB, 00CC
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	0005, 013D
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	0005
2013. 25	Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	0005
1996	LASER / 323 / TIERRA	1. 3L	B3	ABS	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 3L	B3	PCM	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 5L	Z5	ABS	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 5L	Z5	PCM	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 6L	B6	ABS	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 6L	B6	PCM	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 8L	BP	ABS	✓	✓	✓	✓	
1996	LASER / 323 / TIERRA	1. 8L	BP	PCM	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 3L	B3	ABS	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 3L	B3	PCM	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 5L	ZL	ABS	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 5L	ZL	PCM	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 6L	ZM	ABS	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 6L	ZM	PCM	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 8L	FP	ABS	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	1. 8L	FP	PCM	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	2. 0L	RF	ABS	✓	✓	✓	✓	
1998	LASER / 323 / TIERRA	2. 0L	RF	PCM	✓	✓	✓	✓	

1998	LASER / 323 / TIERRA	2. 0L	RF-T	PCM	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 3L	B3	ABS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 3L	B3	ABS/TCS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 3L	B3	PCM	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 6L	ZM	ABS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 6L	ZM	ABS/TCS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 6L	ZM	PCM	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 8L	FP	ABS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	1. 8L	FP	PCM	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	2. 0L	FS	ABS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	2. 0L	FS	ABS/TCS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	2. 0L	FS	PCM	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	2. 0L	RF-T	ABS	✓	✓	✓	✓	
2000	LASER / 323 / TIERRA	2. 0L	RF-T	PCM	✓	✓	✓	✓	
2001	LASER / 323 / TIERRA	1. 3L	B3	ABS	✓	✓	✓	✓	
2001	LASER / 323 / TIERRA	1. 3L	B3	PCM	✓	✓	✓	✓	
2001	LASER / 323 / TIERRA	2. 0L	FS	ABS	✓	✓	✓	✓	
2001	LASER / 323 / TIERRA	2. 0L	FS	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 3L	B3	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 3L	B3	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 3L	Other	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 5L	Other	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 5L	Z5	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 5L	Z5	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 5L	ZL	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 5L	ZL	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 6L	B6	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 6L	B6	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 6L	Other	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 6L	ZM	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 6L	ZM	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 8L	BP	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 8L	BP	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 8L	FP	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 8L	FP	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	1. 8L	Other	PCM	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	2. 0L	RF	ABS	✓	✓	✓	✓	
Other	LASER / 323 / TIERRA	2. 0L	RF	PCM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	LS	3. 0L	Other	ACM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	CPM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	DDM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	DSM	✓	✓	✓	✓	0011
2000	LS	3. 0L	Other	EATC	✓	✓	✓	✓	
2000	LS	3. 0L	Other	GEM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	HEC	✓	✓	✓	✓	
2000	LS	3. 0L	Other	MC	✓	✓	✓	✓	
2000	LS	3. 0L	Other	PCM	✓	✓	✓	✓	0025
2000	LS	3. 0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C7
2000	LS	3. 0L	Other	RCM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	REM	✓	✓	✓	✓	
2000	LS	3. 0L	Other	RESCU	✓	✓	✓	✓	
2000	LS	3. 0L	Other	SCLM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	LS	3. 9L	Other	ACM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	CPM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	DDM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	DSM	✓	✓	✓	✓	0011
2000	LS	3. 9L	Other	EATC	✓	✓	✓	✓	
2000	LS	3. 9L	Other	GEM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	HEC	✓	✓	✓	✓	
2000	LS	3. 9L	Other	MC	✓	✓	✓	✓	
2000	LS	3. 9L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C7
2000	LS	3. 9L	Other	RCM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	REM	✓	✓	✓	✓	
2000	LS	3. 9L	Other	RESCU	✓	✓	✓	✓	
2002	LS	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	LS	3. 0L	Other	ACM	✓	✓	✓	✓	
2002	LS	3. 0L	Other	CPM	✓	✓	✓	✓	
2002	LS	3. 0L	Other	DDM	✓	✓	✓	✓	
2002	LS	3. 0L	Other	DSM	✓	✓	✓	✓	0011
2002	LS	3. 0L	Other	EATC	✓	✓	✓	✓	
2002	LS	3. 0L	Other	GEM	✓	✓	✓	✓	
2002	LS	3. 0L	Other	HEC	✓	✓	✓	✓	
2002	LS	3. 0L	Other	MC	✓	✓	✓	✓	
2002	LS	3. 0L	Other	PCM	✓	✓	✓	✓	0025
2002	LS	3. 0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C7
2002	LS	3. 0L	Other	RCM	✓	✓	✓	✓	
2002	LS	3. 0L	Other	REM	✓	✓	✓	✓	
2002	LS	3. 0L	Other	RESCU	✓	✓	✓	✓	
2002	LS	3. 0L	Other	SCLM	✓	✓	✓	✓	
2002	LS	3. 9L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	LS	3. 9L	Other	ACM	✓	✓	✓	✓	
2002	LS	3. 9L	Other	CPM	✓	✓	✓	✓	
2002	LS	3. 9L	Other	DDM	✓	✓	✓	✓	
2002	LS	3. 9L	Other	DSM	✓	✓	✓	✓	0011

2002	LS	3.9L	Other	EATC	✓	✓	✓	✓	
2002	LS	3.9L	Other	GEM	✓	✓	✓	✓	
2002	LS	3.9L	Other	HEC	✓	✓	✓	✓	
2002	LS	3.9L	Other	MC	✓	✓	✓	✓	
2002	LS	3.9L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C7
2002	LS	3.9L	Other	RCM	✓	✓	✓	✓	
2002	LS	3.9L	Other	REM	✓	✓	✓	✓	
2002	LS	3.9L	Other	RESCU	✓	✓	✓	✓	
2003	LS	3.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2003	LS	3.0L	Other	ACM	✓	✓	✓	✓	
2003	LS	3.0L	Other	DCSM	✓	✓	✓	✓	
2003	LS	3.0L	Other	DDM	✓	✓	✓	✓	
2003	LS	3.0L	Other	DSM	✓	✓	✓	✓	0011
2003	LS	3.0L	Other	EATC	✓	✓	✓	✓	
2003	LS	3.0L	Other	EPB	✓	✓	✓	✓	
2003	LS	3.0L	Other	GEM	✓	✓	✓	✓	
2003	LS	3.0L	Other	HEC	✓	✓	✓	✓	00C7
2003	LS	3.0L	Other	MC	✓	✓	✓	✓	
2003	LS	3.0L	Other	NAV	✓	✓	✓	✓	
2003	LS	3.0L	Other	PAM	✓	✓	✓	✓	
2003	LS	3.0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	LS	3.0L	Other	PCSM	✓	✓	✓	✓	
2003	LS	3.0L	Other	RCM	✓	✓	✓	✓	000C
2003	LS	3.0L	Other	REM	✓	✓	✓	✓	
2003	LS	3.0L	Other	SCLM	✓	✓	✓	✓	
2003	LS	3.0L	Other	VEMS	✓	✓	✓	✓	
2003	LS	3.9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	LS	3.9L	4V	ACM	✓	✓	✓	✓	
2003	LS	3.9L	4V	DCSM	✓	✓	✓	✓	
2003	LS	3.9L	4V	DDM	✓	✓	✓	✓	
2003	LS	3.9L	4V	DSM	✓	✓	✓	✓	0011
2003	LS	3.9L	4V	EATC	✓	✓	✓	✓	
2003	LS	3.9L	4V	EPB	✓	✓	✓	✓	
2003	LS	3.9L	4V	GEM	✓	✓	✓	✓	
2003	LS	3.9L	4V	HEC	✓	✓	✓	✓	00C7
2003	LS	3.9L	4V	MC	✓	✓	✓	✓	
2003	LS	3.9L	4V	NAV	✓	✓	✓	✓	
2003	LS	3.9L	4V	PAM	✓	✓	✓	✓	
2003	LS	3.9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	LS	3.9L	4V	PCSM	✓	✓	✓	✓	
2003	LS	3.9L	4V	RCM	✓	✓	✓	✓	000C
2003	LS	3.9L	4V	REM	✓	✓	✓	✓	
2003	LS	3.9L	4V	SCLM	✓	✓	✓	✓	
2003	LS	3.9L	4V	VEMS	✓	✓	✓	✓	
2004	LS	3.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2004	LS	3.0L	Other	ACM	✓	✓	✓	✓	
2004	LS	3.0L	Other	DCSM	✓	✓	✓	✓	
2004	LS	3.0L	Other	DDM	✓	✓	✓	✓	
2004	LS	3.0L	Other	DSM	✓	✓	✓	✓	0011
2004	LS	3.0L	Other	EATC	✓	✓	✓	✓	
2004	LS	3.0L	Other	EPB	✓	✓	✓	✓	
2004	LS	3.0L	Other	GEM	✓	✓	✓	✓	
2004	LS	3.0L	Other	HEC	✓	✓	✓	✓	
2004	LS	3.0L	Other	MC	✓	✓	✓	✓	
2004	LS	3.0L	Other	NAV	✓	✓	✓	✓	
2004	LS	3.0L	Other	PAM	✓	✓	✓	✓	
2004	LS	3.0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	LS	3.0L	Other	PCSM	✓	✓	✓	✓	
2004	LS	3.0L	Other	RCM	✓	✓	✓	✓	000C
2004	LS	3.0L	Other	REM	✓	✓	✓	✓	
2004	LS	3.0L	Other	SCLM	✓	✓	✓	✓	
2004	LS	3.9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2004	LS	3.9L	4V	ACM	✓	✓	✓	✓	
2004	LS	3.9L	4V	DCSM	✓	✓	✓	✓	
2004	LS	3.9L	4V	DDM	✓	✓	✓	✓	
2004	LS	3.9L	4V	DSM	✓	✓	✓	✓	0011
2004	LS	3.9L	4V	EATC	✓	✓	✓	✓	
2004	LS	3.9L	4V	EPB	✓	✓	✓	✓	
2004	LS	3.9L	4V	GEM	✓	✓	✓	✓	
2004	LS	3.9L	4V	HEC	✓	✓	✓	✓	
2004	LS	3.9L	4V	MC	✓	✓	✓	✓	
2004	LS	3.9L	4V	NAV	✓	✓	✓	✓	
2004	LS	3.9L	4V	PAM	✓	✓	✓	✓	
2004	LS	3.9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	LS	3.9L	4V	PCSM	✓	✓	✓	✓	
2004	LS	3.9L	4V	RCM	✓	✓	✓	✓	000C
2004	LS	3.9L	4V	REM	✓	✓	✓	✓	
2004	LS	3.9L	4V	SCLM	✓	✓	✓	✓	
2005	LS	3.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2005	LS	3.0L	Other	ACM	✓	✓	✓	✓	
2005	LS	3.0L	Other	DCSM	✓	✓	✓	✓	
2005	LS	3.0L	Other	DDM	✓	✓	✓	✓	
2005	LS	3.0L	Other	DSM	✓	✓	✓	✓	0011
2005	LS	3.0L	Other	EATC	✓	✓	✓	✓	
2005	LS	3.0L	Other	EPB	✓	✓	✓	✓	
2005	LS	3.0L	Other	GEM	✓	✓	✓	✓	
2005	LS	3.0L	Other	HEC	✓	✓	✓	✓	
2005	LS	3.0L	Other	MC	✓	✓	✓	✓	

2005	LS	3.0L	Other	NAV	✓	✓	✓	✓	0016
2005	LS	3.0L	Other	PAM	✓	✓	✓	✓	
2005	LS	3.0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	LS	3.0L	Other	PCSM	✓	✓	✓	✓	
2005	LS	3.0L	Other	RCM	✓	✓	✓	✓	000C
2005	LS	3.0L	Other	REM	✓	✓	✓	✓	
2005	LS	3.0L	Other	SCLM	✓	✓	✓	✓	
2005	LS	3.9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2005	LS	3.9L	4V	ACM	✓	✓	✓	✓	
2005	LS	3.9L	4V	DCSM	✓	✓	✓	✓	
2005	LS	3.9L	4V	DDM	✓	✓	✓	✓	
2005	LS	3.9L	4V	DSM	✓	✓	✓	✓	0011
2005	LS	3.9L	4V	EATC	✓	✓	✓	✓	
2005	LS	3.9L	4V	EPB	✓	✓	✓	✓	
2005	LS	3.9L	4V	GEM	✓	✓	✓	✓	
2005	LS	3.9L	4V	HEC	✓	✓	✓	✓	
2005	LS	3.9L	4V	MC	✓	✓	✓	✓	
2005	LS	3.9L	4V	NAV	✓	✓	✓	✓	0016
2005	LS	3.9L	4V	PAM	✓	✓	✓	✓	
2005	LS	3.9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	LS	3.9L	4V	PCSM	✓	✓	✓	✓	
2005	LS	3.9L	4V	RCM	✓	✓	✓	✓	000C
2005	LS	3.9L	4V	REM	✓	✓	✓	✓	
2005	LS	3.9L	4V	SCLM	✓	✓	✓	✓	
2006	LS	3.9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2006	LS	3.9L	4V	ACM	✓	✓	✓	✓	
2006	LS	3.9L	4V	DCSM	✓	✓	✓	✓	
2006	LS	3.9L	4V	DDM	✓	✓	✓	✓	
2006	LS	3.9L	4V	DSM	✓	✓	✓	✓	0011
2006	LS	3.9L	4V	EATC	✓	✓	✓	✓	
2006	LS	3.9L	4V	EPB	✓	✓	✓	✓	
2006	LS	3.9L	4V	GEM	✓	✓	✓	✓	
2006	LS	3.9L	4V	HEC	✓	✓	✓	✓	
2006	LS	3.9L	4V	MC	✓	✓	✓	✓	
2006	LS	3.9L	4V	NAV	✓	✓	✓	✓	0016
2006	LS	3.9L	4V	PAM	✓	✓	✓	✓	
2006	LS	3.9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	LS	3.9L	4V	PCSM	✓	✓	✓	✓	
2006	LS	3.9L	4V	RCM	✓	✓	✓	✓	000C
2006	LS	3.9L	4V	REM	✓	✓	✓	✓	
2006	LS	3.9L	4V	SCLM	✓	✓	✓	✓	
Other	Liata	1.6L	Other	PCM	✓	✓	✓	✓	
Other	Liata	1.8L	Other	PCM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	ABS	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	ABS	✓	✓	✓	✓	001E
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	EATC	✓	✓	✓	✓	0020
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	EPS	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	GEM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	GEM	✓	✓	✓	✓	0021
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	IC	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	LPSDM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	PCM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	PCM	✓	✓	✓	✓	00C5
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	RCM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	RKE	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	RPSDM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	ABS	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	ABS	✓	✓	✓	✓	0005
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	ABS	✓	✓	✓	✓	001E
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	EATC	✓	✓	✓	✓	0020
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	EPS	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	GEM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	GEM	✓	✓	✓	✓	0021
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	IC	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	PCM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	PCM	✓	✓	✓	✓	00C5

2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RCM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RKE	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	ABS	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	ABS	✓	✓	✓	✓	001E
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	EATC	✓	✓	✓	✓	0020
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	FFH	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	FFH	✓	✓	✓	✓	002F
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	GEM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	GEM	✓	✓	✓	✓	0021
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	IC	✓	✓	✓		
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	PCM	✓	✓	✓	✓	0055, 0056, 005C
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	PCM	✓	✓	✓	✓	0055, 005C
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	RCM	✓	✓	✓	✓	
2005	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	RF-T	RKE	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	ABS	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	EATC	✓	✓	✓	✓	0020
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	EPS	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	IC	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	LPSDM	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	PCM	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	RCM	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	RKE	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	RPSDM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1. 8L	L8	TCM	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	ABS	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	ABS	✓	✓	✓	✓	0005, 001E
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	EATC	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	EATC	✓	✓	✓	✓	0020
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	EPS	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	EPS	✓	✓	✓	✓	0005
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	GEM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	GEM	✓	✓	✓	✓	0005, 0021
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	IC	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	IC	✓	✓	✓		0005, F022, F05D, FOA8, FOA9, FOAA
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	LPSDM	✓	✓	✓		
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	PCM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	PCM	✓	✓	✓	✓	00C5
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RCM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RCM	✓	✓	✓	✓	0005
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RKE	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RKE	✓	✓	✓	✓	0005, F093, F094, F095
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	RPSDM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	TCM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2. 0L	LF	TCM	✓	✓	✓	✓	00C5

2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	ABS	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	ABS	✓	✓	✓	✓	001E
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	EATC	✓	✓	✓	✓	0020
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	FFH	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	FFH	✓	✓	✓	✓	002F
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	GEM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	GEM	✓	✓	✓	✓	0021
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	IC	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	LPSDM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	PCM	✓	✓	✓	✓	0055, 0056, 005C
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	PCM	✓	✓	✓	✓	0055, 005C
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	RCM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	RKE	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	RPSDM	✓	✓	✓	✓	
2007	MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	TCM	✓	✓	✓	✓	
1998	MILLENNIA / EUNOS 800	2.0L	KF	ABS	✓	✓	✓	✓	
1998	MILLENNIA / EUNOS 800	2.3L	KJ	ABS	✓	✓	✓	✓	
1998	MILLENNIA / EUNOS 800	2.5L	KL	ABS	✓	✓	✓	✓	
2000	MILLENNIA / EUNOS 800	2.0L	KF	ABS	✓	✓	✓	✓	
2000	MILLENNIA / EUNOS 800	2.3L	KJ	ABS	✓	✓	✓	✓	
2000	MILLENNIA / EUNOS 800	2.5L	KL	ABS	✓	✓	✓	✓	
2002	MILLENNIA / EUNOS 800	2.5L	KL	ABS/TCS	✓	✓	✓	✓	
2002	MILLENNIA / EUNOS 800	2.5L	KL	PCM	✓	✓	✓	✓	
2009	MKS	3.7L	4V	4X4	✓	✓	✓	✓	
2009	MKS	3.7L	4V	ABS	✓	✓	✓	✓	0005, 0008
2009	MKS	3.7L	4V	ACM	✓	✓	✓	✓	0005, 0017, 0018
2009	MKS	3.7L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	MKS	3.7L	4V	C-CM	✓	✓	✓	✓	0046
2009	MKS	3.7L	4V	DCSM	✓	✓	✓	✓	0005
2009	MKS	3.7L	4V	DDM	✓	✓	✓	✓	
2009	MKS	3.7L	4V	DDM	✓	✓	✓	✓	0005
2009	MKS	3.7L	4V	DSM	✓	✓	✓	✓	F041, F087
2009	MKS	3.7L	4V	DSP	✓	✓	✓	✓	0005
2009	MKS	3.7L	4V	FCIM	✓	✓	✓	✓	
2009	MKS	3.7L	4V	FDIM	✓	✓	✓	✓	0005, F05A, F07F
2009	MKS	3.7L	4V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F04B, F04C, F05F, F088, F089, F08A
2009	MKS	3.7L	4V	HCM	✓	✓	✓	✓	
2009	MKS	3.7L	4V	HCM-2	✓	✓	✓	✓	0005
2009	MKS	3.7L	4V	HD LVL	✓	✓	✓	✓	
2009	MKS	3.7L	4V	HVAC	✓	✓	✓	✓	
2009	MKS	3.7L	4V	IPC	✓	✓	✓	✓	0005
2009	MKS	3.7L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	MKS	3.7L	4V	PAM	✓	✓	✓	✓	
2009	MKS	3.7L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	MKS	3.7L	4V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	MKS	3.7L	4V	RFA	✓	✓	✓	✓	
2009	MKS	3.7L	4V	SECM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019, 001C
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	

2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HD_LVL	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IHCM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2010	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2010	MKS	3.7L	4V	4X4	✓	✓	✓	✓	0108
2010	MKS	3.7L	4V	ABS	✓	✓	✓	✓	0008
2010	MKS	3.7L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	MKS	3.7L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	MKS	3.7L	4V	C-CM	✓	✓	✓	✓	0046
2010	MKS	3.7L	4V	DCSM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	DDM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	DSM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	DSP	✓	✓	✓	✓	
2010	MKS	3.7L	4V	FCIM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	FDIM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	MKS	3.7L	4V	GPSM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	HCM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	HCM-2	✓	✓	✓	✓	
2010	MKS	3.7L	4V	HD_LVL	✓	✓	✓	✓	
2010	MKS	3.7L	4V	HUD	✓	✓	✓	✓	
2010	MKS	3.7L	4V	HVAC	✓	✓	✓	✓	
2010	MKS	3.7L	4V	IHCM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	IPC	✓	✓	✓	✓	
2010	MKS	3.7L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	MKS	3.7L	4V	PAM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	PCM	✓	✓	✓	✓	0025
2010	MKS	3.7L	4V	PSCM	✓	✓	✓	✓	

2010	MKS	3.7L	4V	RCM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	RETM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	RFA	✓	✓	✓	✓	
2010	MKS	3.7L	4V	SASM	✓	✓	✓	✓	
2010	MKS	3.7L	4V	SOD-L	✓	✓	✓	✓	
2010	MKS	3.7L	4V	SOD-R	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HD_LVL	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	

2011	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2011	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2011	MKS	3.7L	4V	4X4	✓	✓	✓	✓	0108
2011	MKS	3.7L	4V	ABS	✓	✓	✓	✓	0008
2011	MKS	3.7L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	MKS	3.7L	4V	APIM	✓	✓	✓	✓	0019
2011	MKS	3.7L	4V	C-CM	✓	✓	✓	✓	0046
2011	MKS	3.7L	4V	DCSM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	DDM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	DSM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	DSP	✓	✓	✓	✓	
2011	MKS	3.7L	4V	FCIM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	FDIM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	MKS	3.7L	4V	GPSM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	HCM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	HCM-2	✓	✓	✓	✓	
2011	MKS	3.7L	4V	HD_LVL	✓	✓	✓	✓	
2011	MKS	3.7L	4V	HUD	✓	✓	✓	✓	
2011	MKS	3.7L	4V	HVAC	✓	✓	✓	✓	
2011	MKS	3.7L	4V	ILCM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	IPC	✓	✓	✓	✓	
2011	MKS	3.7L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	MKS	3.7L	4V	PAM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	MKS	3.7L	4V	PSCM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	RCM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	RFA	✓	✓	✓	✓	
2011	MKS	3.7L	4V	SASM	✓	✓	✓	✓	
2011	MKS	3.7L	4V	SOD-L	✓	✓	✓	✓	
2011	MKS	3.7L	4V	SOD-R	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HD_LVL	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	

2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2012	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2012	MKS	3.7L	4V	4X4	✓	✓	✓	✓	0108
2012	MKS	3.7L	4V	ABS	✓	✓	✓	✓	0008
2012	MKS	3.7L	4V	ACM	✓	✓	✓	✓	0017, 0018
2012	MKS	3.7L	4V	APIM	✓	✓	✓	✓	0019
2012	MKS	3.7L	4V	C-CM	✓	✓	✓	✓	0046
2012	MKS	3.7L	4V	DCSM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	DDM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	DSM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	DSP	✓	✓	✓	✓	
2012	MKS	3.7L	4V	FCIM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	FDIM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	MKS	3.7L	4V	GPSM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	HCM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	HCM-2	✓	✓	✓	✓	
2012	MKS	3.7L	4V	HD LVL	✓	✓	✓	✓	
2012	MKS	3.7L	4V	HUD	✓	✓	✓	✓	
2012	MKS	3.7L	4V	HVAC	✓	✓	✓	✓	
2012	MKS	3.7L	4V	ILCM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	IPC	✓	✓	✓	✓	
2012	MKS	3.7L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	MKS	3.7L	4V	PAM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2012	MKS	3.7L	4V	PSCM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	RCM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	RFA	✓	✓	✓	✓	
2012	MKS	3.7L	4V	SASM	✓	✓	✓	✓	
2012	MKS	3.7L	4V	SOD-L	✓	✓	✓	✓	
2012	MKS	3.7L	4V	SOD-R	✓	✓	✓	✓	
2012	MKS	Other	Other	4X4	✓	✓	✓	✓	
2012	MKS	Other	Other	ABS	✓	✓	✓	✓	
2012	MKS	Other	Other	ACM	✓	✓	✓	✓	
2012	MKS	Other	Other	APIM	✓	✓	✓	✓	
2012	MKS	Other	Other	C-CM	✓	✓	✓	✓	
2012	MKS	Other	Other	DCSM	✓	✓	✓	✓	
2012	MKS	Other	Other	DDM	✓	✓	✓	✓	
2012	MKS	Other	Other	DSM	✓	✓	✓	✓	
2012	MKS	Other	Other	DSP	✓	✓	✓	✓	
2012	MKS	Other	Other	FCIM	✓	✓	✓	✓	
2012	MKS	Other	Other	FDIM	✓	✓	✓	✓	
2012	MKS	Other	Other	GEM / SJB	✓	✓	✓	✓	0042
2012	MKS	Other	Other	GPSM	✓	✓	✓	✓	
2012	MKS	Other	Other	HCM	✓	✓	✓	✓	
2012	MKS	Other	Other	HCM-2	✓	✓	✓	✓	
2012	MKS	Other	Other	HD LVL	✓	✓	✓	✓	
2012	MKS	Other	Other	HUD	✓	✓	✓	✓	
2012	MKS	Other	Other	HVAC	✓	✓	✓	✓	
2012	MKS	Other	Other	ILCM	✓	✓	✓	✓	
2012	MKS	Other	Other	IPC	✓	✓	✓	✓	
2012	MKS	Other	Other	OCSM	✓	✓	✓	✓	
2012	MKS	Other	Other	PAM	✓	✓	✓	✓	
2012	MKS	Other	Other	PSCM	✓	✓	✓	✓	
2012	MKS	Other	Other	RCM	✓	✓	✓	✓	
2012	MKS	Other	Other	RFA	✓	✓	✓	✓	
2012	MKS	Other	Other	SASM	✓	✓	✓	✓	
2012	MKS	Other	Other	SOD-L	✓	✓	✓	✓	

2012	MKS	Other	Other	SOD-R	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0018
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	

2013	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2013	MKS	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	ACM	✓	✓	✓	✓	0018
2013	MKS	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	MKS	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	MKS	3.7L	TiVCT	DACM-C	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	HCM-2	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2013	MKS	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	MKS	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	MKS	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	MKS	3.7L	TiVCT	VDM	✓	✓	✓	✓	000E
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	

2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	MKS	3.5L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2014	MKS	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	APT	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	MKS	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	MKS	3.7L	TiVCT	DACM-C	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	HCM-2	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	MKS	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	MKS	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0108
2014	MKS	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	MKS	3.7L	TiVCT	VDM	✓	✓	✓	✓	000E
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018

2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019, 001C
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	0005
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	0005
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2010	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2010	MKT	3.7L	4V	4X4	✓	✓	✓	✓	0108
2010	MKT	3.7L	4V	ABS	✓	✓	✓	✓	0008, 0012
2010	MKT	3.7L	4V	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	MKT	3.7L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	MKT	3.7L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	MKT	3.7L	4V	C-CM	✓	✓	✓	✓	0046

2010	MKT	3.7L	4V	DCSM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	DDM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	DSM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	DSP	✓	✓	✓	✓	
2010	MKT	3.7L	4V	FCIM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	FDIM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	MKT	3.7L	4V	HCM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	HCM-2	✓	✓	✓	✓	
2010	MKT	3.7L	4V	HUD	✓	✓	✓	✓	
2010	MKT	3.7L	4V	HVAC	✓	✓	✓	✓	
2010	MKT	3.7L	4V	ILCM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	IPC	✓	✓	✓	✓	
2010	MKT	3.7L	4V	LTM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	MKT	3.7L	4V	PAM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	PCM	✓	✓	✓	✓	0025
2010	MKT	3.7L	4V	PCSM-2	✓	✓	✓	✓	
2010	MKT	3.7L	4V	PSCM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	RCM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	RCM	✓	✓	✓	✓	0005
2010	MKT	3.7L	4V	RETm	✓	✓	✓	✓	
2010	MKT	3.7L	4V	RFA	✓	✓	✓	✓	
2010	MKT	3.7L	4V	RHVAC	✓	✓	✓	✓	
2010	MKT	3.7L	4V	SASM	✓	✓	✓	✓	
2010	MKT	3.7L	4V	SOD-L	✓	✓	✓	✓	
2010	MKT	3.7L	4V	SOD-R	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015

2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2011	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2011	MKT	3.7L	4V	4X4	✓	✓	✓	✓	0108
2011	MKT	3.7L	4V	ABS	✓	✓	✓	✓	0008, 0012
2011	MKT	3.7L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	MKT	3.7L	4V	APIM	✓	✓	✓	✓	0019
2011	MKT	3.7L	4V	C-CM	✓	✓	✓	✓	0046
2011	MKT	3.7L	4V	DCSM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	DDM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	DSM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	DSP	✓	✓	✓	✓	
2011	MKT	3.7L	4V	FCIM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	FDIM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	GEM / SJB	✓	✓	✓	✓	
2011	MKT	3.7L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	MKT	3.7L	4V	GPSM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	HCM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	HCM-2	✓	✓	✓	✓	
2011	MKT	3.7L	4V	HUD	✓	✓	✓	✓	
2011	MKT	3.7L	4V	HVAC	✓	✓	✓	✓	
2011	MKT	3.7L	4V	ILCM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	IPC	✓	✓	✓	✓	
2011	MKT	3.7L	4V	LTM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	MKT	3.7L	4V	PAM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	MKT	3.7L	4V	PCSM-2	✓	✓	✓	✓	
2011	MKT	3.7L	4V	PSCM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	RCM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	RETM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	RFA	✓	✓	✓	✓	
2011	MKT	3.7L	4V	RHVAC	✓	✓	✓	✓	
2011	MKT	3.7L	4V	SASM	✓	✓	✓	✓	
2011	MKT	3.7L	4V	SOD-L	✓	✓	✓	✓	
2011	MKT	3.7L	4V	SOD-R	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	

2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓		
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2012	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2012	MKT	3.7L	4V	4X4	✓	✓	✓	✓	0108
2012	MKT	3.7L	4V	ABS	✓	✓	✓	✓	0008, 0012
2012	MKT	3.7L	4V	ACM	✓	✓	✓	✓	0017, 0018
2012	MKT	3.7L	4V	APIM	✓	✓	✓	✓	0019
2012	MKT	3.7L	4V	C-CM	✓	✓	✓	✓	0046
2012	MKT	3.7L	4V	DCSM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	DDM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	DSM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	DSP	✓	✓	✓	✓	
2012	MKT	3.7L	4V	FCIM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	FDIM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	GEM / SJB	✓	✓	✓	✓	
2012	MKT	3.7L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	MKT	3.7L	4V	GPSM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	HCM	✓	✓	✓	✓	
2012	MKT	3.7L	4V	HCM-2	✓	✓	✓	✓	
2012	MKT	3.7L	4V	HUD	✓	✓	✓	✓	
2012	MKT	3.7L	4V	HVAC	✓	✓	✓	✓	

2012	MKT	3. 7L	4V	IHCM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	IPC	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	LTM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	MKT	3. 7L	4V	PAM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2012	MKT	3. 7L	4V	PCSM-2	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	PSCM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	RCM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	RETM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	RFA	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	RHVAC	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	SASM	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	SOD-L	✓	✓	✓	✓	
2012	MKT	3. 7L	4V	SOD-R	✓	✓	✓	✓	
2012	MKT	Other	Other	4X4	✓	✓	✓	✓	
2012	MKT	Other	Other	ABS	✓	✓	✓	✓	
2012	MKT	Other	Other	ACM	✓	✓	✓	✓	
2012	MKT	Other	Other	APIM	✓	✓	✓	✓	
2012	MKT	Other	Other	C-CM	✓	✓	✓	✓	
2012	MKT	Other	Other	DCSM	✓	✓	✓	✓	
2012	MKT	Other	Other	DDM	✓	✓	✓	✓	
2012	MKT	Other	Other	DSM	✓	✓	✓	✓	
2012	MKT	Other	Other	DSP	✓	✓	✓	✓	
2012	MKT	Other	Other	FCIM	✓	✓	✓	✓	
2012	MKT	Other	Other	FDIM	✓	✓	✓	✓	
2012	MKT	Other	Other	GEM / SJB	✓	✓	✓	✓	0042
2012	MKT	Other	Other	GPSM	✓	✓	✓	✓	
2012	MKT	Other	Other	HCM	✓	✓	✓	✓	
2012	MKT	Other	Other	HCM-2	✓	✓	✓	✓	
2012	MKT	Other	Other	HUD	✓	✓	✓	✓	
2012	MKT	Other	Other	HVAC	✓	✓	✓	✓	
2012	MKT	Other	Other	IHCM	✓	✓	✓	✓	
2012	MKT	Other	Other	IPC	✓	✓	✓	✓	
2012	MKT	Other	Other	LTM	✓	✓	✓	✓	
2012	MKT	Other	Other	OCSM	✓	✓	✓	✓	
2012	MKT	Other	Other	PAM	✓	✓	✓	✓	
2012	MKT	Other	Other	PCSM-2	✓	✓	✓	✓	
2012	MKT	Other	Other	PSCM	✓	✓	✓	✓	
2012	MKT	Other	Other	RCM	✓	✓	✓	✓	
2012	MKT	Other	Other	RETM	✓	✓	✓	✓	
2012	MKT	Other	Other	RFA	✓	✓	✓	✓	
2012	MKT	Other	Other	RHVAC	✓	✓	✓	✓	
2012	MKT	Other	Other	SASM	✓	✓	✓	✓	
2012	MKT	Other	Other	SOD-L	✓	✓	✓	✓	
2012	MKT	Other	Other	SOD-R	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	

2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	

2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2013	MKT	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2013	MKT	3.7L	TiVCT	APIM	✓	✓	✓	✓	0019
2013	MKT	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	MKT	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	MKT	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2013	MKT	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	MKT	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	MKT	3.7L	TiVCT	PCSM-2	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	RHVAC	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2013	MKT	3.7L	TiVCT	SCCM	✓	✓	✓	✓	

2013	MKT	3. 7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	MKT	3. 7L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	MKT	3. 7L	TiVCT	VDM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	MKT	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	

2014	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	MKT	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	LTM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCSM-2	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	

2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	MKT	3.5L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2014	MKT	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	MKT	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	MKT	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	MKT	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	MKT	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0108
2014	MKT	3.7L	TiVCT	PCSM-2	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	RHVAC	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	MKT	3.7L	TiVCT	VDM	✓	✓	✓	✓	
2014	MKT	Other	Other	ABS	✓	✓	✓	✓	
2014	MKT	Other	Other	ACM	✓	✓	✓	✓	
2014	MKT	Other	Other	APIM	✓	✓	✓	✓	
2014	MKT	Other	Other	BCM#1	✓	✓	✓	✓	
2014	MKT	Other	Other	C-CM	✓	✓	✓	✓	
2014	MKT	Other	Other	DCSM	✓	✓	✓	✓	
2014	MKT	Other	Other	DDM	✓	✓	✓	✓	
2014	MKT	Other	Other	DSM	✓	✓	✓	✓	
2014	MKT	Other	Other	DSP	✓	✓	✓	✓	
2014	MKT	Other	Other	FCIM	✓	✓	✓	✓	
2014	MKT	Other	Other	GPSM	✓	✓	✓	✓	
2014	MKT	Other	Other	HCM	✓	✓	✓	✓	
2014	MKT	Other	Other	HSWM	✓	✓	✓	✓	
2014	MKT	Other	Other	HUD	✓	✓	✓	✓	
2014	MKT	Other	Other	HVAC	✓	✓	✓	✓	
2014	MKT	Other	Other	IPC	✓	✓	✓	✓	
2014	MKT	Other	Other	IPM-A	✓	✓	✓	✓	
2014	MKT	Other	Other	LTM	✓	✓	✓	✓	
2014	MKT	Other	Other	OCSM	✓	✓	✓	✓	
2014	MKT	Other	Other	PAM	✓	✓	✓	✓	
2014	MKT	Other	Other	PCSM-2	✓	✓	✓	✓	
2014	MKT	Other	Other	PSCM	✓	✓	✓	✓	
2014	MKT	Other	Other	RACM	✓	✓	✓	✓	
2014	MKT	Other	Other	RCM	✓	✓	✓	✓	
2014	MKT	Other	Other	RFA	✓	✓	✓	✓	
2014	MKT	Other	Other	RHVAC	✓	✓	✓	✓	
2014	MKT	Other	Other	RTM	✓	✓	✓	✓	
2014	MKT	Other	Other	SCCM	✓	✓	✓	✓	
2014	MKT	Other	Other	SOD-L	✓	✓	✓	✓	
2014	MKT	Other	Other	SOD-R	✓	✓	✓	✓	
2014	MKT	Other	Other	VDM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	4X4	✓	✓	✓	✓	
2007	MKX	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2007	MKX	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	MKX	3.5L	4V	DCSM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	DSM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	DSP	✓	✓	✓	✓	
2007	MKX	3.5L	4V	EATC	✓	✓	✓	✓	
2007	MKX	3.5L	4V	GEM	✓	✓	✓	✓	001A
2007	MKX	3.5L	4V	HCM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	IC	✓	✓	✓	✓	

2007	MKX	3.5L	4V	LTM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2007	MKX	3.5L	4V	PAM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	MKX	3.5L	4V	RCM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	RETM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	SASM	✓	✓	✓	✓	
2007	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0019
2008	MKX	3.5L	4V	4X4	✓	✓	✓	✓	
2008	MKX	3.5L	4V	ABS	✓	✓	✓	✓	0005
2008	MKX	3.5L	4V	ABS	✓	✓	✓	✓	0005, 0012
2008	MKX	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2008	MKX	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	MKX	3.5L	4V	DCSM	✓	✓	✓	✓	
2008	MKX	3.5L	4V	DSM	✓	✓	✓	✓	0005
2008	MKX	3.5L	4V	DSP	✓	✓	✓	✓	0005
2008	MKX	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C
2008	MKX	3.5L	4V	HCM	✓	✓	✓	✓	
2008	MKX	3.5L	4V	HVAC	✓	✓	✓	✓	
2008	MKX	3.5L	4V	IC	✓	✓	✓	✓	0005, F027, F047, F04A
2008	MKX	3.5L	4V	LTM	✓	✓	✓	✓	
2008	MKX	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	MKX	3.5L	4V	PAM	✓	✓	✓	✓	0005
2008	MKX	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	MKX	3.5L	4V	RCM	✓	✓	✓	✓	0005
2008	MKX	3.5L	4V	RETM	✓	✓	✓	✓	0005, F04D
2008	MKX	3.5L	4V	SASM	✓	✓	✓	✓	
2008	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0005, 0019
2009	MKX	3.5L	4V	4X4	✓	✓	✓	✓	
2009	MKX	3.5L	4V	ABS	✓	✓	✓	✓	
2009	MKX	3.5L	4V	ABS	✓	✓	✓	✓	0005, 0012
2009	MKX	3.5L	4V	ACM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0019
2009	MKX	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0019
2009	MKX	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	MKX	3.5L	4V	APIM	✓	✓	✓	✓	001C
2009	MKX	3.5L	4V	DCSM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	DCSM	✓	✓	✓	✓	0005
2009	MKX	3.5L	4V	DSM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	DSM	✓	✓	✓	✓	0005
2009	MKX	3.5L	4V	DSP	✓	✓	✓	✓	
2009	MKX	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	MKX	3.5L	4V	HCM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	HVAC	✓	✓	✓	✓	
2009	MKX	3.5L	4V	IC	✓	✓	✓	✓	
2009	MKX	3.5L	4V	IC	✓	✓	✓	✓	0005
2009	MKX	3.5L	4V	LTM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2009	MKX	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	MKX	3.5L	4V	PAM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	PAM	✓	✓	✓	✓	0005
2009	MKX	3.5L	4V	PCM	✓	✓	✓	✓	0025
2009	MKX	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	MKX	3.5L	4V	RCM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	RCM	✓	✓	✓	✓	0005
2009	MKX	3.5L	4V	RETM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	SASM	✓	✓	✓	✓	
2009	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0005
2009	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0005, 0019
2009	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0019
2010	MKX	3.5L	4V	4X4	✓	✓	✓	✓	
2010	MKX	3.5L	4V	ABS	✓	✓	✓	✓	0012
2010	MKX	3.5L	4V	ACM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0019
2010	MKX	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0019
2010	MKX	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	MKX	3.5L	4V	DCSM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	DCSM	✓	✓	✓	✓	0005
2010	MKX	3.5L	4V	DSM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	DSM	✓	✓	✓	✓	0005
2010	MKX	3.5L	4V	DSP	✓	✓	✓	✓	
2010	MKX	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	MKX	3.5L	4V	GPSM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	HCM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	HVAC	✓	✓	✓	✓	
2010	MKX	3.5L	4V	IC	✓	✓	✓	✓	
2010	MKX	3.5L	4V	LTM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	MKX	3.5L	4V	PAM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	PAM	✓	✓	✓	✓	0005
2010	MKX	3.5L	4V	PCM	✓	✓	✓	✓	0025
2010	MKX	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5

2010	MKX	3.5L	4V	RCM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	RETM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	SASM	✓	✓	✓	✓	
2010	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	
2010	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0005, 0019
2010	MKX	3.5L	4V	SDARS	✓	✓	✓	✓	0019
2011	MKX	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2011	MKX	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	APIM	✓	✓	✓	✓	00D6
2011	MKX	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 0042, 00D4, 00D5, 00FE
2011	MKX	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2011	MKX	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2011	MKX	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2011	MKX	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2011	MKX	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	PCM	✓	✓	✓	✓	0067, 0095
2011	MKX	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2011	MKX	3.7L	TiVCT	TPM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2012	MKX	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2012	MKX	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2012	MKX	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2012	MKX	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2012	MKX	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095
2012	MKX	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2012	MKX	3.7L	TiVCT	TPM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	MKX	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	MKX	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	MKX	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	MKX	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108

2013	MKX	3.7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	MKX	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	MKX	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2014	MKX	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE, 0112
2014	MKX	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	MKX	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	FLM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	LTM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2014	MKX	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	MKX	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	MKX	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	MKX	Other	Other	ABS	✓	✓	✓	✓	
2014	MKX	Other	Other	ACM	✓	✓	✓	✓	
2014	MKX	Other	Other	APIM	✓	✓	✓	✓	
2014	MKX	Other	Other	BCM#1	✓	✓	✓	✓	
2014	MKX	Other	Other	C-CM	✓	✓	✓	✓	
2014	MKX	Other	Other	DCSM	✓	✓	✓	✓	
2014	MKX	Other	Other	DSM	✓	✓	✓	✓	
2014	MKX	Other	Other	DSP	✓	✓	✓	✓	
2014	MKX	Other	Other	FCDIM	✓	✓	✓	✓	
2014	MKX	Other	Other	FCIM	✓	✓	✓	✓	
2014	MKX	Other	Other	FLM	✓	✓	✓	✓	
2014	MKX	Other	Other	GPSM	✓	✓	✓	✓	
2014	MKX	Other	Other	HCM	✓	✓	✓	✓	
2014	MKX	Other	Other	HSWM	✓	✓	✓	✓	
2014	MKX	Other	Other	HUD	✓	✓	✓	✓	
2014	MKX	Other	Other	HVAC	✓	✓	✓	✓	
2014	MKX	Other	Other	IPC	✓	✓	✓	✓	
2014	MKX	Other	Other	LTM	✓	✓	✓	✓	
2014	MKX	Other	Other	OCSM	✓	✓	✓	✓	
2014	MKX	Other	Other	PAM	✓	✓	✓	✓	
2014	MKX	Other	Other	RCM	✓	✓	✓	✓	
2014	MKX	Other	Other	RFA	✓	✓	✓	✓	
2014	MKX	Other	Other	RTM	✓	✓	✓	✓	
2014	MKX	Other	Other	SCCM	✓	✓	✓	✓	
2014	MKX	Other	Other	SOD-L	✓	✓	✓	✓	
2014	MKX	Other	Other	SOD-R	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	

2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GSM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-G	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-H	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRCM	✓	✓	✓	✓	
2013	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS	✓	✓	✓	✓	0012, 00F5, 010A, 020C
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM	✓	✓	✓	✓	

2013	MKZ	2.0L	Full Hybrid Electric Vehicle	APIM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	BECM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	C-CM	✓	✓	✓	✓	0046
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DACM-C	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DCDC	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DDM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DSM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	DSP	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	FCDIM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	FCIM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	GFM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	GPSM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	GSM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	GWM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	HCM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	HSWM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	HUD	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	IPC	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	IPM-A	✓	✓	✓	✓	013E
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	PAM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	PDM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	PSCM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	RACM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	RCM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	RGTM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	RTM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SCCM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-E	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-G	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SCM-H	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SOBDM-C	✓	✓	✓	✓	013C
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-L	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	SOD-R	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	TRCM	✓	✓	✓	✓	
2013	MKZ	2.0L	Full Hybrid Electric Vehicle	VDM	✓	✓	✓	✓	000E
2013	MKZ	3.7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012, 00F5, 010A, 020C
2013	MKZ	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2013	MKZ	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	MKZ	3.7L	TiVCT	DACM-C	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	GFM	✓	✓	✓	✓	

2013	MKZ	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	GSM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	GWM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	HCM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2013	MKZ	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	MKZ	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2013	MKZ	3.7L	TiVCT	PDM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	RGTM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	SCM-E	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	SCM-G	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	SCM-H	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	TRCM	✓	✓	✓	✓	
2013	MKZ	3.7L	TiVCT	VDM	✓	✓	✓	✓	000E
2013	MKZ	Other	Other	ABS	✓	✓	✓	✓	
2013	MKZ	Other	Other	ACM	✓	✓	✓	✓	
2013	MKZ	Other	Other	APIM	✓	✓	✓	✓	
2013	MKZ	Other	Other	BCM#1	✓	✓	✓	✓	
2013	MKZ	Other	Other	C-CM	✓	✓	✓	✓	
2013	MKZ	Other	Other	DACM-C	✓	✓	✓	✓	
2013	MKZ	Other	Other	DDM	✓	✓	✓	✓	
2013	MKZ	Other	Other	DSM	✓	✓	✓	✓	
2013	MKZ	Other	Other	DSP	✓	✓	✓	✓	
2013	MKZ	Other	Other	FCDIM	✓	✓	✓	✓	
2013	MKZ	Other	Other	FCIM	✓	✓	✓	✓	
2013	MKZ	Other	Other	GFM	✓	✓	✓	✓	
2013	MKZ	Other	Other	GPSM	✓	✓	✓	✓	
2013	MKZ	Other	Other	GSM	✓	✓	✓	✓	
2013	MKZ	Other	Other	GWM	✓	✓	✓	✓	
2013	MKZ	Other	Other	HCM	✓	✓	✓	✓	
2013	MKZ	Other	Other	HSWM	✓	✓	✓	✓	
2013	MKZ	Other	Other	HUD	✓	✓	✓	✓	
2013	MKZ	Other	Other	IPC	✓	✓	✓	✓	
2013	MKZ	Other	Other	IPM-A	✓	✓	✓	✓	
2013	MKZ	Other	Other	OCSM	✓	✓	✓	✓	
2013	MKZ	Other	Other	PAM	✓	✓	✓	✓	
2013	MKZ	Other	Other	PDM	✓	✓	✓	✓	
2013	MKZ	Other	Other	PSCM	✓	✓	✓	✓	
2013	MKZ	Other	Other	RACM	✓	✓	✓	✓	
2013	MKZ	Other	Other	RCM	✓	✓	✓	✓	
2013	MKZ	Other	Other	RGTM	✓	✓	✓	✓	
2013	MKZ	Other	Other	RTM	✓	✓	✓	✓	
2013	MKZ	Other	Other	SCCM	✓	✓	✓	✓	
2013	MKZ	Other	Other	SCM-E	✓	✓	✓	✓	
2013	MKZ	Other	Other	SCM-G	✓	✓	✓	✓	
2013	MKZ	Other	Other	SCM-H	✓	✓	✓	✓	
2013	MKZ	Other	Other	SOD-L	✓	✓	✓	✓	
2013	MKZ	Other	Other	SOD-R	✓	✓	✓	✓	
2013	MKZ	Other	Other	TRCM	✓	✓	✓	✓	
2013	MKZ	Other	Other	VDM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 0012, 010A, 020C
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112, 020F
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DACM-C	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	

2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GSM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GWM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-G	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-H	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRCM	✓	✓	✓	✓	
2014	MKZ	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	000E
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	ABS	✓	✓	✓	✓	0012, 010A, 020C
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2014	MKZ	2.0L	Full Hybrid Electric Vehicle	ACM	✓	✓	✓	✓	

2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	APIM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112, 020F
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	BECM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	C-CM	✓	✓	✓	✓	0046
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	DACM-C	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	DCDC	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	DDM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	DSM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	DSP	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	FCDIM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	FCIM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	GFM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	GPSM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	GSM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	GWM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	HCM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	HSWM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	HUD	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	IPC	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	IPM-A	✓	✓	✓	✓	013E
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	PAM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	PDM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	PSCM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	RACM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	RCM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	RGTM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	RTM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SCCM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SCM-E	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SCM-G	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SCM-H	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SOBDM-C	✓	✓	✓	✓	013C
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SOD-L	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	SOD-R	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	TRCM	✓	✓	✓	✓	
2014	MKZ	2. 0L	Full Hybrid Electric Vehicle	VDM	✓	✓	✓	✓	000E
2014	MKZ	3. 7L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012, 010A, 020C
2014	MKZ	3. 7L	TiVCT	ACM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	APIM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112, 020F
2014	MKZ	3. 7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	MKZ	3. 7L	TiVCT	DACM-C	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	DDM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	DSM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	DSP	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	GFM	✓	✓	✓	✓	

2014	MKZ	3. 7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	GSM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	GWM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	HCM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	HSWM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	HUD	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	IPC	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	MKZ	3. 7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	MKZ	3. 7L	TiVCT	PAM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	MKZ	3. 7L	TiVCT	PDM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	PSCM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	RACM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	RCM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	RGTM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	RTM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	SCM-E	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	SCM-G	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	SCM-H	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	TRCM	✓	✓	✓	✓	
2014	MKZ	3. 7L	TiVCT	VDM	✓	✓	✓	✓	000E
2007. 25	MONDEO	1. 6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007. 25	MONDEO	1. 6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 6L	DURATEC VCT	AHCM	✓	✓	✓	✓	00CF
2007. 25	MONDEO	1. 6L	DURATEC VCT	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2007. 25	MONDEO	1. 6L	DURATEC VCT	CCMii	✓	✓	✓	✓	00F9
2007. 25	MONDEO	1. 6L	DURATEC VCT	CDP	✓	✓	✓	✓	
2007. 25	MONDEO	1. 6L	DURATEC VCT	CMR	✓	✓	✓	✓	
2007. 25	MONDEO	1. 6L	DURATEC VCT	DDM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 6L	DURATEC VCT	DSM	✓	✓	✓	✓	00F2
2007. 25	MONDEO	1. 6L	DURATEC VCT	HCM	✓	✓	✓	✓	0032
2007. 25	MONDEO	1. 6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2007. 25	MONDEO	1. 6L	DURATEC VCT	IPC	✓	✓	✓	✓	
2007. 25	MONDEO	1. 6L	DURATEC VCT	PAM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 6L	DURATEC VCT	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007. 25	MONDEO	1. 6L	DURATEC VCT	PCM	✓	✓	✓	✓	0025, 00BC
2007. 25	MONDEO	1. 6L	DURATEC VCT	PDM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 6L	DURATEC VCT	PSCM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 6L	DURATEC VCT	RCM	✓	✓	✓	✓	00EF, 0102
2007. 25	MONDEO	1. 6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2007. 25	MONDEO	1. 6L	DURATEC VCT	SASM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 6L	DURATEC VCT	TRM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 6L	DURATEC VCT	VDM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0092, 0098, 0099, 009A, 00AB, 00AC, 00B4, 00C1
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2007. 25	MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102

2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2007.25	MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	2.0L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2007.25	MONDEO	2.0L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2007.25	MONDEO	2.0L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.0L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.0L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	F020
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	00AC
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2007.25	MONDEO	2.0L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	F020
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0092, 0098, 0099, 009A, 00AB, 00AC, 00B4, 00C1
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8

2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011C
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011C, 0132
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011C, 0132, 0153
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓		0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	009A
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓		00EF, 0102
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓		0102
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 0102

2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓		
2007.25	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	011C
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CDP	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF

2007.25	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	BCMii	✓	✓	✓	✓	0132, 0153
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CDP	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	IPC	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RCM	✓	✓	✓	✓	00EF, 0102
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	TCM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.0L	Ecoboost GTDI Chinese market only	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C, 0132, 0153
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	

2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00A5, 00AA, 00AF, 00B0, 00B1, 00B2, 00B8, 00B9, 00C1
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	2.3L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2007.25	MONDEO	2.3L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.3L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.3L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00AC
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	00AC
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2007.25	MONDEO	2.3L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	0121, 0122, 0123, 0124, 0125
2007.25	MONDEO	2.3L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.3L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2007.25	MONDEO	2.5L	15	ACM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	AHCM	✓	✓	✓	✓	00CF
2007.25	MONDEO	2.5L	15	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2007.25	MONDEO	2.5L	15	CCMii	✓	✓	✓	✓	00F9
2007.25	MONDEO	2.5L	15	CDP	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	CMR	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	DDM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	DSM	✓	✓	✓	✓	00F2
2007.25	MONDEO	2.5L	15	HCM	✓	✓	✓	✓	0032
2007.25	MONDEO	2.5L	15	HVAC	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	IPC	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	PAM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	PBM	✓	✓	✓	✓	00F3, 00F4, 00F5, 00F6, 00F7
2007.25	MONDEO	2.5L	15	PCM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	PDM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	PSCM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	RCM	✓	✓	✓	✓	00EF, 0102
2007.25	MONDEO	2.5L	15	RFA	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	SASM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	SRM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	TRM	✓	✓	✓	✓	
2007.25	MONDEO	2.5L	15	VDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	1.6L	DURATEC VCT	ACM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	AHCM	✓	✓	✓	✓	00CF
2011	MONDEO	1.6L	DURATEC VCT	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2011	MONDEO	1.6L	DURATEC VCT	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	1.6L	DURATEC VCT	CDP	✓	✓	✓	✓	

2011	MONDEO	1.6L	DURATEC VCT	CMR	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	DABM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	DDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	1.6L	DURATEC VCT	HCM	✓	✓	✓	✓	0032
2011	MONDEO	1.6L	DURATEC VCT	HVAC	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	IPC	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	1.6L	DURATEC VCT	PAM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	PBM	✓	✓	✓	✓	00F3, 00F4, 00F5, 00F6, 00F7
2011	MONDEO	1.6L	DURATEC VCT	PCM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	PDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	PSCM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	1.6L	DURATEC VCT	RFA	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	RGTM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	RHVAC	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	SASM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	SOD-L	✓	✓	✓	✓	00BC, F026
2011	MONDEO	1.6L	DURATEC VCT	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	1.6L	DURATEC VCT	SRM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	TRM	✓	✓	✓	✓	
2011	MONDEO	1.6L	DURATEC VCT	VDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C, 0132, 0153
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	DABM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00F3, 00F4, 00F5, 00F6
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00B1, 00B7, 00B9, 00BC, 00BD, 00C1, 00C3
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2011	MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	

2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	AHCM	✓	✓	✓		00CF
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	CDP	✓	✓	✓	✓	0005
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	CMR	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DABM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	F020
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PBM	✓	✓	✓	✓	00F3, 00F4, 00F5, 00F6, 00F7
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 00C3, 0114
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓		
2011	MONDEO	1.6L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓		
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓		0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓		
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓		00CF
2011	MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153

2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	DABM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0092, 0098, 0099, 009A, 00AB, 00AC, 00B4, 00C1
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓		00CF
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011C, 0132
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011C, 0132, 0153
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	0005
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DABM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓		00F2

2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	F020
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓		0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0090, 0092, 0098, 0099, 009A, 00A4, 00B0, 00B1, 00B3, 00B7, 00B8, 00B9, 00BC, 00BF, 00C1
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	009A
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓		00EF, 0102
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓		0102
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RHVAC	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓		F026

2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓		F026
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓		
2011	MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓		
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓		0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓		
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓		00CF
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	011C, 0132, 0153
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	CDP	✓	✓	✓	✓	0005
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	CMR	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DABM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	F020
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F7
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 0114
2011	MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	

2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RGTM	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SRM	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TCM	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2011	MONDEO	2.0L	EcoBoost – Gas Turbocharged Direct Injection	VDM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	ACM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	AHCM	✓	✓	✓	✓	00CF
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	BCMii	✓	✓	✓	✓	0132, 0153
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CDP	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	CMR	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DABM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DDM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	HVAC	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	IPC	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PAM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PCM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PDM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	PSCM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RFA	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RGTM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SASM	✓	✓	✓	✓	
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2.0L	Ecoboost GTDI Chinese market only	SRM	✓	✓	✓	✓	

2011	MONDEO	2. 0L	Ecoboost GTDI Chinese market only	TCM	✓	✓	✓	✓	
2011	MONDEO	2. 0L	Ecoboost GTDI Chinese market only	TRM	✓	✓	✓		
2011	MONDEO	2. 0L	Ecoboost GTDI Chinese market only	VDM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C, 0132, 0153
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	CMR	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	DABM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6, 00F7, 00F8
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PSCM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RFA	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RGTM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	VDM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓		00CF
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C, 0132
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CDP	✓	✓	✓	✓	

2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CMR	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DABM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓		00F2
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PBM	✓	✓	✓	✓	00F3, 00F4, 00F5, 00F6
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PBM	✓	✓	✓	✓	00F3, 00F4, 00F5, 00F7
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	0092, 0099, 009A, 00B2, 00B8, 00BE
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	0102
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	RFA	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	RGTM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	SRM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	TCM	✓	✓	✓	✓	
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓		
2011	MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	VDM	✓	✓	✓		

2011	MONDEO	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓		0008, 002B, 0053, 0054, 00D9, 00E2, 00E8
2011	MONDEO	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓		
2011	MONDEO	2. 3L	DURATEC-HE / I4	AHCM	✓	✓	✓		00CF
2011	MONDEO	2. 3L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011B, 011C, 0132, 0153
2011	MONDEO	2. 3L	DURATEC-HE / I4	CCMii	✓	✓	✓	✓	00F9
2011	MONDEO	2. 3L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	0005
2011	MONDEO	2. 3L	DURATEC-HE / I4	CMR	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	DABM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	DDM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	DSM	✓	✓	✓	✓	00F2
2011	MONDEO	2. 3L	DURATEC-HE / I4	HCM	✓	✓	✓	✓	0032
2011	MONDEO	2. 3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	F020
2011	MONDEO	2. 3L	DURATEC-HE / I4	IPM-A	✓	✓	✓	✓	00E5
2011	MONDEO	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	PBM	✓	✓	✓	✓	00EE, 00F3, 00F4, 00F5, 00F6
2011	MONDEO	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	00AC
2011	MONDEO	2. 3L	DURATEC-HE / I4	PDM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	00EF, 0102
2011	MONDEO	2. 3L	DURATEC-HE / I4	RFA	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	RGTM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	RHVAC	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	SASM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	F026
2011	MONDEO	2. 3L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	F026
2011	MONDEO	2. 3L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2011	MONDEO	2. 3L	DURATEC-HE / I4	VDM	✓	✓	✓	✓	
2003	Marauder	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	
2003	Marauder	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Marauder	4. 6L	4V	DDM	✓	✓	✓	✓	
2003	Marauder	4. 6L	4V	EATC	✓	✓	✓	✓	
2003	Marauder	4. 6L	4V	LCM	✓	✓	✓	✓	
2003	Marauder	4. 6L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Marauder	4. 6L	4V	RASM	✓	✓	✓	✓	
2003	Marauder	4. 6L	4V	RCM	✓	✓	✓	✓	000C
2003	Marauder	4. 6L	4V	VAPS	✓	✓	✓	✓	
2004	Marauder	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	
2004	Marauder	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2004	Marauder	4. 6L	4V	DDM	✓	✓	✓	✓	
2004	Marauder	4. 6L	4V	EATC	✓	✓	✓	✓	
2004	Marauder	4. 6L	4V	LCM	✓	✓	✓	✓	
2004	Marauder	4. 6L	4V	PCM	✓	✓	✓	✓	0013, 0025, 0028, 0031, 0033
2004	Marauder	4. 6L	4V	RASM	✓	✓	✓	✓	0013
2004	Marauder	4. 6L	4V	RCM	✓	✓	✓	✓	000C
2004	Marauder	4. 6L	4V	VAPS	✓	✓	✓	✓	
2006	Mariner	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2006	Mariner	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2006	Mariner	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Mariner	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Mariner	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2006	Mariner	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Mariner	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2006	Mariner	3. 0L	4V	4X4	✓	✓	✓	✓	
2006	Mariner	3. 0L	4V	ABS	✓	✓	✓	✓	0005, 0008
2006	Mariner	3. 0L	4V	GEM	✓	✓	✓	✓	F042, F04E, F04F, F050, F051, F056, F057, F058, F059
2006	Mariner	3. 0L	4V	GEM	✓	✓	✓	✓	F042, F04E, F04F, F050, F051, F056, F057, F058, F059, F090
2006	Mariner	3. 0L	4V	IC	✓	✓	✓	✓	0005, F040, F043, F04D, F052, F053, F054, F055
2006	Mariner	3. 0L	4V	PAM	✓	✓	✓	✓	
2006	Mariner	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Mariner	3. 0L	4V	RCM	✓	✓	✓	✓	000C
2007	Mariner	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2007	Mariner	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2007	Mariner	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007	Mariner	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	Mariner	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2007	Mariner	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	Mariner	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Mariner	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2007	Mariner	3. 0L	4V	4X4	✓	✓	✓	✓	
2007	Mariner	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2007	Mariner	3. 0L	4V	GEM	✓	✓	✓	✓	
2007	Mariner	3. 0L	4V	IC	✓	✓	✓	✓	
2007	Mariner	3. 0L	4V	PAM	✓	✓	✓	✓	

2007	Mariner	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Mariner	3. 0L	4V	RCM	✓	✓	✓	✓	000C
2006	Mark LT	5. 4L	3V	4X4	✓	✓	✓	✓	
2006	Mark LT	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 000B
2006	Mark LT	5. 4L	3V	DSM	✓	✓	✓	✓	
2006	Mark LT	5. 4L	3V	EATC	✓	✓	✓	✓	
2006	Mark LT	5. 4L	3V	IC	✓	✓	✓	✓	
2006	Mark LT	5. 4L	3V	PAM	✓	✓	✓	✓	
2006	Mark LT	5. 4L	3V	PAM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Mark LT	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Mark LT	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2006	Mark LT	5. 4L	3V	VSM	✓	✓	✓	✓	
2007	Mark LT	5. 4L	3V	4X4	✓	✓	✓	✓	
2007	Mark LT	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2007	Mark LT	5. 4L	3V	DSM	✓	✓	✓	✓	
2007	Mark LT	5. 4L	3V	EATC	✓	✓	✓	✓	
2007	Mark LT	5. 4L	3V	IC	✓	✓	✓	✓	
2007	Mark LT	5. 4L	3V	PAM	✓	✓	✓	✓	
2007	Mark LT	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Mark LT	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2007	Mark LT	5. 4L	3V	VSM	✓	✓	✓	✓	
2008	Mark LT	5. 4L	3V	4X4	✓	✓	✓	✓	
2008	Mark LT	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008
2008	Mark LT	5. 4L	3V	DSM	✓	✓	✓	✓	
2008	Mark LT	5. 4L	3V	HVAC	✓	✓	✓	✓	
2008	Mark LT	5. 4L	3V	IC	✓	✓	✓	✓	
2008	Mark LT	5. 4L	3V	PAM	✓	✓	✓	✓	
2008	Mark LT	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Mark LT	5. 4L	3V	RCM	✓	✓	✓	✓	000C
2008	Mark LT	5. 4L	3V	RETM	✓	✓	✓	✓	0018
2008	Mark LT	5. 4L	3V	VSM	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	CPM	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	DDM	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	DSM	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	HEC	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	PCM	✓	✓	✓	✓	0025
1996	Mark VIII	4. 6L	4V	PSM	✓	✓	✓	✓	
1996	Mark VIII	4. 6L	4V	SCIL	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1997	Mark VIII	4. 6L	4V	CPM	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	DDM	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	DSM	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	EATC	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	HEC	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	MC	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	PCM	✓	✓	✓	✓	0025
1997	Mark VIII	4. 6L	4V	PSM	✓	✓	✓	✓	
1997	Mark VIII	4. 6L	4V	SCIL	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1998	Mark VIII	4. 6L	4V	CPM	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	DDM	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	DSM	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	EATC	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	HEC	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	MC	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	PCM	✓	✓	✓	✓	0025
1998	Mark VIII	4. 6L	4V	PSM	✓	✓	✓	✓	
1998	Mark VIII	4. 6L	4V	SCIL	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2006	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2006	Milan	2. 3L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	F044, F048, F04C, F057, F085
2006	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2006	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2006	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2006	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2006	Milan	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2006	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2006	Milan	3. 0L	4V	EATC	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	GEM	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	IC	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2006	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5

2006	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	
2006	Milan	3. 0L	4V	TCM	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2007	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0016, 0017, 0018, F05A
2007	Milan	2. 3L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	F044, F048, F04C, F057, F085
2007	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005
2007	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2007	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2007	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Milan	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2007	Milan	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	0019
2007	Milan	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	4X4	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2007	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Milan	3. 0L	4V	EATC	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	GEM	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	IC	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	IC	✓	✓	✓	✓	0005
2007	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2007	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2007	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	0005
2007	Milan	3. 0L	4V	SDARS	✓	✓	✓	✓	
2007	Milan	3. 0L	4V	SDARS	✓	✓	✓	✓	0019
2007	Milan	3. 0L	4V	TCM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2008	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0016, 0017, 0018, F05A, F062, F07A
2008	Milan	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2008	Milan	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2008	Milan	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F044, F048, F04C, F057, F085, F086
2008	Milan	2. 3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	F027
2008	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2008	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Milan	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2008	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2008	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	F022, F05D
2008	Milan	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2008	Milan	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	4X4	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2008	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Milan	3. 0L	4V	APIM	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Milan	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2008	Milan	3. 0L	4V	HVAC	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	IC	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2008	Milan	3. 0L	4V	PAM	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2008	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	SDARS	✓	✓	✓	✓	
2008	Milan	3. 0L	4V	TCM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	

2009	Milan	2. 3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008
2009	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F05A, F062, F07A
2009	Milan	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2009	Milan	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0005, 0042, F044, F048, F04C, F057, F085, F086
2009	Milan	2. 3L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	0005, F027
2009	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Milan	2. 3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2009	Milan	2. 3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00C5
2009	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Milan	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	
2009	Milan	2. 3L	DURATEC-HE / I4	SDARS	✓	✓	✓	✓	0005
2009	Milan	2. 3L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	4X4	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2009	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Milan	3. 0L	4V	APIM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Milan	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Milan	3. 0L	4V	HVAC	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	IC	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2009	Milan	3. 0L	4V	PAM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2009	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	SDARS	✓	✓	✓	✓	
2009	Milan	3. 0L	4V	TCM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Milan	2. 5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2010	Milan	2. 5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	Milan	2. 5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2010	Milan	2. 5L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019, 001C
2010	Milan	2. 5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	0005
2010	Milan	2. 5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	0005, F062
2010	Milan	2. 5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2010	Milan	2. 5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C
2010	Milan	2. 5L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	0005
2010	Milan	2. 5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Milan	2. 5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	Milan	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2010	Milan	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0067
2010	Milan	2. 5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	
2010	Milan	2. 5L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	Milan	2. 5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Milan	2. 5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Milan	2. 5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	0005
2010	Milan	2. 5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042

2010	Milan	2. 5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	Milan	2. 5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Milan	2. 5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2010	Milan	2. 5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	0005
2010	Milan	2. 5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2010	Milan	2. 5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	4X4	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	0008, 0012
2010	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Milan	3. 0L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Milan	3. 0L	4V	DSP	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	FCIM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	FCIM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	FDIM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Milan	3. 0L	4V	GPSM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	HVAC	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	IPC	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2010	Milan	3. 0L	4V	PAM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	0067
2010	Milan	3. 0L	4V	PSCM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	SOD-L	✓	✓	✓	✓	
2010	Milan	3. 0L	4V	SOD-R	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0012
2011	Milan	2. 5L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	0017, 0018
2011	Milan	2. 5L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	0019
2011	Milan	2. 5L	DURATEC-HE / I4	DSP	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	FCIM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	FDIM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	0042
2011	Milan	2. 5L	DURATEC-HE / I4	GPSM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	HVAC	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 0015
2011	Milan	2. 5L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2011	Milan	2. 5L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0067
2011	Milan	2. 5L	DURATEC-HE / I4	PSCM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	SOD-L	✓	✓	✓	✓	
2011	Milan	2. 5L	DURATEC-HE / I4	SOD-R	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Milan	2. 5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0018
2011	Milan	2. 5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019
2011	Milan	2. 5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Milan	2. 5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Milan	2. 5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Milan	2. 5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2011	Milan	2. 5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2011	Milan	2. 5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	4X4	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	ABS	✓	✓	✓	✓	0008, 0012
2011	Milan	3. 0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Milan	3. 0L	4V	APIM	✓	✓	✓	✓	0019
2011	Milan	3. 0L	4V	DSP	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	FCIM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	FCIM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	FDIM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	GEM / SJB	✓	✓	✓	✓	0042

2011	Milan	3. 0L	4V	GPSM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	HVAC	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	IPC	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Milan	3. 0L	4V	PAM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	PCM	✓	✓	✓	✓	0067
2011	Milan	3. 0L	4V	PSCM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	RCM	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	SOD-L	✓	✓	✓	✓	
2011	Milan	3. 0L	4V	SOD-R	✓	✓	✓	✓	
1993. 5	Mondeo	1. 6L	Zetec	ABS	✓	✓	✓	✓	
1993. 5	Mondeo	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1993. 5	Mondeo	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1993. 5	Mondeo	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1993. 5	Mondeo	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1993. 5	Mondeo	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1993. 5	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1993. 5	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1993. 5	Mondeo	2. 0L	Zetec	ABS	✓	✓	✓	✓	
1993. 5	Mondeo	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1993. 5	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1993. 5	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1993. 75	Mondeo	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1993. 75	Mondeo	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1993. 75	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1993. 75	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1993. 75	Mondeo	2. 0L	Zetec	ABS	✓	✓	✓	✓	
1993. 75	Mondeo	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1993. 75	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1993. 75	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1994. 5	Mondeo	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1994. 5	Mondeo	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1994. 5	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1994. 5	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1994. 75	Mondeo	2. 5L	Duratec-VE	ABS	✓	✓	✓	✓	
1994. 75	Mondeo	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
1994. 75	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1994. 75	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1995	Mondeo	1. 6L	Zetec	ABS	✓	✓	✓	✓	
1995	Mondeo	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1995	Mondeo	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1995	Mondeo	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1995	Mondeo	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1995	Mondeo	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1995	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1995	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1995	Mondeo	2. 0L	Zetec	ABS	✓	✓	✓	✓	
1995	Mondeo	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1995	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1995	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1995	Mondeo	2. 5L	Duratec-VE	ABS	✓	✓	✓	✓	
1995	Mondeo	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
1995	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1995	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1996	Mondeo	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1996	Mondeo	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1996	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1996	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1996	Mondeo	2. 0L	Zetec	ABS	✓	✓	✓	✓	
1996	Mondeo	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1996	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1996	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1996	Mondeo	2. 5L	Duratec-VE	ABS	✓	✓	✓	✓	
1996	Mondeo	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
1996	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1996	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
1997	Mondeo	1. 6L	Zetec	ABS	✓	✓	✓	✓	
1997	Mondeo	1. 6L	Zetec	CSM	✓	✓	✓	✓	
1997	Mondeo	1. 6L	Zetec	FFH	✓	✓	✓	✓	
1997	Mondeo	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1997	Mondeo	1. 6L	Zetec	PATS	✓	✓	✓	✓	
1997	Mondeo	1. 6L	Zetec	PCM	✓	✓	✓	✓	0025
1997	Mondeo	1. 8L	Endura-DE	ABS	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Endura-DE	CSM	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Endura-DE	FFH	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Endura-DE	PATS	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Endura-DE	PCM	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	ABS	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	CSM	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	FFH	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	PATS	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	PCM	✓	✓	✓	✓	
1997	Mondeo	1. 8L	Zetec	PCM	✓	✓	✓	✓	0025
1997	Mondeo	2. 0L	Zetec	ABS	✓	✓	✓	✓	
1997	Mondeo	2. 0L	Zetec	CSM	✓	✓	✓	✓	
1997	Mondeo	2. 0L	Zetec	FFH	✓	✓	✓	✓	
1997	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	
1997	Mondeo	2. 0L	Zetec	PATS	✓	✓	✓	✓	

1999	Mondeo	2.5L	Duratec-VE	ABS	✓	✓	✓	✓	
1999	Mondeo	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1999	Mondeo	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1999	Mondeo	2.5L	Duratec-VE	FFH	✓	✓	✓	✓	
1999	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
1999	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	
1999	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1999.75	Mondeo	2.5L	Duratec-VE	ABS	✓	✓	✓	✓	
1999.75	Mondeo	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1999.75	Mondeo	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1999.75	Mondeo	2.5L	Duratec-VE	FFH	✓	✓	✓	✓	
1999.75	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
1999.75	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
1999.75	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2000.25	Mondeo	1.8L	Zetec	ABS	✓	✓	✓	✓	
2000.25	Mondeo	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
2000.25	Mondeo	1.8L	Zetec	AFCM	✓	✓	✓	✓	
2000.25	Mondeo	1.8L	Zetec	CSM	✓	✓	✓	✓	
2000.25	Mondeo	1.8L	Zetec	PATS	✓	✓	✓	✓	
2000.25	Mondeo	1.8L	Zetec	PCM	✓	✓	✓	✓	0025
2000.5	Mondeo	2.0L	Zetec	ABS	✓	✓	✓	✓	
2000.5	Mondeo	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	
2000.5	Mondeo	2.0L	Zetec	CSM	✓	✓	✓	✓	
2000.5	Mondeo	2.0L	Zetec	PATS	✓	✓	✓	✓	
2000.5	Mondeo	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2000.5	Mondeo	2.5L	Duratec-VE	ABS	✓	✓	✓	✓	
2000.5	Mondeo	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
2000.5	Mondeo	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
2000.5	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
2000.5	Mondeo	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
2000.5	Mondeo	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2001	Mondeo	1.8L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0032
2001	Mondeo	1.8L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	1.8L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	CSM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0008
2001	Mondeo	1.8L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0025
2001	Mondeo	1.8L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F027, F02D, F02F, F030, F03A, F09D, F09E, F09F, FOA0, FOA1, FOA2, FOA3, FOA4, FOA5
2001	Mondeo	1.8L	DURATEC-HE / I4	HEC	✓	✓	✓	✓	0005
2001	Mondeo	1.8L	DURATEC-HE / I4	LHID	✓	✓	✓	✓	0005, 0032
2001	Mondeo	1.8L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	PATS	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2001	Mondeo	1.8L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-HE / I4	RHID	✓	✓	✓	✓	0005
2001	Mondeo	1.8L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	ABS	✓	✓	✓	✓	0032
2001	Mondeo	1.8L	DURATEC-SCi	ABS/TCS	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	1.8L	DURATEC-SCi	ACM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	CDP	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	CSM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	EATC	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	GDM	✓	✓	✓	✓	0100
2001	Mondeo	1.8L	DURATEC-SCi	GEM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	HEC	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	LHID	✓	✓	✓	✓	0032
2001	Mondeo	1.8L	DURATEC-SCi	NAV	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	PATS	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	PCM	✓	✓	✓	✓	0025
2001	Mondeo	1.8L	DURATEC-SCi	RCM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	RETM	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	RHID	✓	✓	✓	✓	
2001	Mondeo	1.8L	DURATEC-SCi	SRM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0008, 0032
2001	Mondeo	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0005, 0032
2001	Mondeo	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	CDP	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	CSM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	EATC	✓	✓	✓	✓	0008
2001	Mondeo	2.0L	DURATEC-HE / I4	GDM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0005, F027, F02D, F02F, F030, F03A, F09D, F09E, F09F, FOA0, FOA1, FOA2, FOA3, FOA4, FOA5
2001	Mondeo	2.0L	DURATEC-HE / I4	HEC	✓	✓	✓	✓	0005
2001	Mondeo	2.0L	DURATEC-HE / I4	LHID	✓	✓	✓	✓	0005, 0032
2001	Mondeo	2.0L	DURATEC-HE / I4	NAV	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	PATS	✓	✓	✓	✓	

2001	Mondeo	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2001	Mondeo	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	RETM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATEC-HE / I4	RHID	✓	✓	✓	✓	0005
2001	Mondeo	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	ABS	✓	✓	✓	✓	0008
2001	Mondeo	2.0L	DURATORQ DI	ABS/TCS	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	ACM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	CDP	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	CSM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	EATC	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	FFH	✓	✓	✓	✓	00CF
2001	Mondeo	2.0L	DURATORQ DI	FIP	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	GDM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	GDM	✓	✓	✓	✓	0100
2001	Mondeo	2.0L	DURATORQ DI	GEM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	HEC	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	LHID	✓	✓	✓	✓	0032
2001	Mondeo	2.0L	DURATORQ DI	NAV	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	PATS	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	PCM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	RCM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	RETM	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	RHID	✓	✓	✓	✓	
2001	Mondeo	2.0L	DURATORQ DI	SRM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0032
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0032, 00CD
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	0008
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	LHID	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	LHID	✓	✓	✓	✓	0032
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	PATS	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0008, 0032, 00CD, 00CD
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	00CD
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	RHID	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2001	Mondeo	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	00CD
2001	Mondeo	2.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008

2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	CDP	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	GSM	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	EATC	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	GDM	✓	✓	✓	✓	0100
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	LHID	✓	✓	✓	✓	0032
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	NAV	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PATS	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RETM	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RHID	✓	✓	✓	✓	
2001	Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	ABS	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	ABS	✓	✓	✓	✓	0008
2001	Mondeo	2. 5L	Duratec-VE	ABS	✓	✓	✓	✓	0008, 0032
2001	Mondeo	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	2. 5L	Duratec-VE	ACM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	CDP	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	CSM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	EATC	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	EATC	✓	✓	✓	✓	0008
2001	Mondeo	2. 5L	Duratec-VE	GDM	✓	✓	✓	✓	0100
2001	Mondeo	2. 5L	Duratec-VE	GEM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	HEC	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	LHID	✓	✓	✓	✓	0032
2001	Mondeo	2. 5L	Duratec-VE	NAV	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	PATS	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2001	Mondeo	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	0025, 00CD
2001	Mondeo	2. 5L	Duratec-VE	PCM	✓	✓	✓	✓	00CD
2001	Mondeo	2. 5L	Duratec-VE	RCM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	RETM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	RHID	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	SRM	✓	✓	✓	✓	
2001	Mondeo	2. 5L	Duratec-VE	TCM	✓	✓	✓	✓	00CD
2001	Mondeo	3. 0L	Duratec SE	ABS	✓	✓	✓	✓	0008, 0032
2001	Mondeo	3. 0L	Duratec SE	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	3. 0L	Duratec SE	ACM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	CDP	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	CSM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	EATC	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	EATC	✓	✓	✓	✓	0008
2001	Mondeo	3. 0L	Duratec SE	GDM	✓	✓	✓	✓	0100
2001	Mondeo	3. 0L	Duratec SE	GEM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	HEC	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	LHID	✓	✓	✓	✓	0032
2001	Mondeo	3. 0L	Duratec SE	NAV	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	PATS	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	PCM	✓	✓	✓	✓	0025
2001	Mondeo	3. 0L	Duratec SE	RCM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	RETM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	RHID	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec SE	SRM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	ABS	✓	✓	✓	✓	0008, 0032
2001	Mondeo	3. 0L	Duratec-ST	ABS/TCS	✓	✓	✓	✓	0008
2001	Mondeo	3. 0L	Duratec-ST	ACM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	CDP	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	CSM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	EATC	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	EATC	✓	✓	✓	✓	0008
2001	Mondeo	3. 0L	Duratec-ST	GDM	✓	✓	✓	✓	0100
2001	Mondeo	3. 0L	Duratec-ST	GEM	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	HEC	✓	✓	✓	✓	
2001	Mondeo	3. 0L	Duratec-ST	LHID	✓	✓	✓	✓	0032

2001	Mondeo	3.0L	Duratec-ST	NAV	✓	✓	✓	✓	
2001	Mondeo	3.0L	Duratec-ST	PATS	✓	✓	✓	✓	
2001	Mondeo	3.0L	Duratec-ST	PCM	✓	✓	✓	✓	0025
2001	Mondeo	3.0L	Duratec-ST	RCM	✓	✓	✓	✓	
2001	Mondeo	3.0L	Duratec-ST	RETM	✓	✓	✓	✓	
2001	Mondeo	3.0L	Duratec-ST	RHID	✓	✓	✓	✓	
2001	Mondeo	3.0L	Duratec-ST	SRM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓		0008, 0012, 00F5, 010A, 020C
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓		00D4, 00D5, 00FE
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓		0046
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	✓	✓	✓		0151
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	GWM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓		013E
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	PAM	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0108
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2013	Mondeo	1.5L	EcoBoost - Gas Turbocharged Direct Injection	SCM-G	✓	✓	✓		

2013	Mondeo	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SCM-H	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓		
2013	Mondeo	1.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓		0008, 0012, 010A, 020C
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓		00D4, 00D5, 00FE
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓		0046
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓		0151
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GWM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓		013E
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0095, 0108
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-E	✓	✓	✓	✓	
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-G	✓	✓	✓		

2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCM-H	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓		
2013	Mondeo	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓		
Other	Mondeo	1.8L	Endura-DE	ABS	✓	✓	✓	✓	
Other	Mondeo	1.8L	Endura-DE	CSM	✓	✓	✓	✓	
Other	Mondeo	1.8L	Endura-DE	PATS			✓	✓	
Other	Mondeo	1.8L	Endura-DE	PATS	✓	✓	✓	✓	
2006	Montego	3.0L	4V	4X4	✓	✓	✓	✓	
2006	Montego	3.0L	4V	ABS	✓	✓	✓	✓	
2006	Montego	3.0L	4V	ABS	✓	✓	✓	✓	0005, 0008
2006	Montego	3.0L	4V	ACM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2006	Montego	3.0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2006	Montego	3.0L	4V	DSM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	DSM	✓	✓	✓	✓	0005
2006	Montego	3.0L	4V	EATC	✓	✓	✓	✓	
2006	Montego	3.0L	4V	GEM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	GEM	✓	✓	✓	✓	0005
2006	Montego	3.0L	4V	IC	✓	✓	✓	✓	
2006	Montego	3.0L	4V	IC	✓	✓	✓	✓	0005
2006	Montego	3.0L	4V	PAM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	PAM	✓	✓	✓	✓	006C
2006	Montego	3.0L	4V	PCM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	PCM	✓	✓	✓	✓	0025
2006	Montego	3.0L	4V	RCM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	RCM	✓	✓	✓	✓	0005, 000C, 006D
2006	Montego	3.0L	4V	RETM	✓	✓	✓	✓	
2006	Montego	3.0L	4V	TCM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	4X4	✓	✓	✓	✓	
2007	Montego	3.0L	4V	ABS	✓	✓	✓	✓	
2007	Montego	3.0L	4V	ABS	✓	✓	✓	✓	0008
2007	Montego	3.0L	4V	ACM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Montego	3.0L	4V	DSM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	EATC	✓	✓	✓	✓	
2007	Montego	3.0L	4V	GEM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	IC	✓	✓	✓	✓	
2007	Montego	3.0L	4V	PAM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	PAM	✓	✓	✓	✓	006C
2007	Montego	3.0L	4V	PCM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	PCM	✓	✓	✓	✓	0025
2007	Montego	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0037
2007	Montego	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2007	Montego	3.0L	4V	RCM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	RCM	✓	✓	✓	✓	000C
2007	Montego	3.0L	4V	RETM	✓	✓	✓	✓	
2007	Montego	3.0L	4V	SDARS	✓	✓	✓	✓	
2007	Montego	3.0L	4V	SDARS	✓	✓	✓	✓	0019
2007	Montego	3.0L	4V	TCM	✓	✓	✓	✓	
2004	Motorhome / Stripped Chassis / Step	6.8L	2V	ABS/TCS	✓	✓	✓	✓	0008
2004	Motorhome / Stripped Chassis / Step	6.8L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓	0008, 001B
2006	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2006	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓	0008
2007	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2007	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓	0008
2008	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2008	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓	0008
2009	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2009	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2011	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓	
2011	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2011	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS	✓	✓	✓	✓	
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS	✓	✓	✓	✓	0008
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS/TCS	✓	✓	✓	✓	
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	PCM	✓	✓	✓	✓	0025
2012	Motorhome / Stripped Chassis / Step	6.8L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2013	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS	✓	✓	✓	✓	
2013	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2013	Motorhome / Stripped Chassis / Step	6.8L	3V	PCM	✓	✓	✓	✓	0025
2013	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2014	Motorhome / Stripped Chassis / Step	6.8L	3V	ABS	✓	✓	✓	✓	0012

2014	Motorhome / Stripped Chassis / Step	6.8L	3V	IC	✓	✓	✓	✓	
2014	Motorhome / Stripped Chassis / Step Van	6.8L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2014	Motorhome / Stripped Chassis / Step	Other	Other	ABS	✓	✓	✓	✓	
2014	Motorhome / Stripped Chassis / Step	Other	Other	IC	✓	✓	✓	✓	
1997	Mountaineer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓	
1997	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓	000E
1997	Mountaineer	5.0L	Other	GEM	✓	✓	✓	✓	0203
1997	Mountaineer	5.0L	Other	IAB	✓	✓	✓	✓	
1997	Mountaineer	5.0L	Other	PCM	✓	✓	✓	✓	0025
1997	Mountaineer	5.0L	Other	RAP	✓	✓	✓	✓	
1998	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
1998	Mountaineer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓	
1998	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
1998	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
1998	Mountaineer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
1998	Mountaineer	4.0L	V6 SOHC	IAB	✓	✓	✓	✓	
1998	Mountaineer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓	
1998	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
1998	Mountaineer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
1998	Mountaineer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓	
1998	Mountaineer	5.0L	Other	DSM	✓	✓	✓	✓	
1998	Mountaineer	5.0L	Other	EATC	✓	✓	✓	✓	
1998	Mountaineer	5.0L	Other	GEM	✓	✓	✓	✓	0203
1998	Mountaineer	5.0L	Other	IAB	✓	✓	✓	✓	
1998	Mountaineer	5.0L	Other	PATS	✓	✓	✓	✓	
1998	Mountaineer	5.0L	Other	PCM	✓	✓	✓	✓	0025
1998	Mountaineer	5.0L	Other	RAP	✓	✓	✓	✓	
1999	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
1999	Mountaineer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓	000E
1999	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
1999	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
1999	Mountaineer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
1999	Mountaineer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
1999	Mountaineer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓	
1999	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
1999	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
1999	Mountaineer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
1999	Mountaineer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓	000E
1999	Mountaineer	5.0L	Other	DSM	✓	✓	✓	✓	
1999	Mountaineer	5.0L	Other	EATC	✓	✓	✓	✓	
1999	Mountaineer	5.0L	Other	GEM	✓	✓	✓	✓	0005, 0203
1999	Mountaineer	5.0L	Other	IAB	✓	✓	✓	✓	
1999	Mountaineer	5.0L	Other	PAM	✓	✓	✓	✓	
1999	Mountaineer	5.0L	Other	PATS	✓	✓	✓	✓	
1999	Mountaineer	5.0L	Other	PCM	✓	✓	✓	✓	0005, 0008, 0025, 0028, 0031, 0033
1999	Mountaineer	5.0L	Other	RAP	✓	✓	✓	✓	0005, F044
2000	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2000	Mountaineer	4.0L	V6 SOHC	ARC	✓	✓	✓	✓	000E
2000	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2000	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2000	Mountaineer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
2000	Mountaineer	4.0L	V6 SOHC	IAB	✓	✓	✓	✓	
2000	Mountaineer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2000	Mountaineer	4.0L	V6 SOHC	PATS	✓	✓	✓	✓	
2000	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0008, 0025, 0028, 0031, 0033
2000	Mountaineer	4.0L	V6 SOHC	RAP	✓	✓	✓	✓	
2000	Mountaineer	5.0L	Other	ABS/TCS	✓	✓	✓	✓	0005, 0008
2000	Mountaineer	5.0L	Other	ARC	✓	✓	✓	✓	000E
2000	Mountaineer	5.0L	Other	DSM	✓	✓	✓	✓	
2000	Mountaineer	5.0L	Other	EATC	✓	✓	✓	✓	
2000	Mountaineer	5.0L	Other	GEM	✓	✓	✓	✓	0005, 0203
2000	Mountaineer	5.0L	Other	IAB	✓	✓	✓	✓	
2000	Mountaineer	5.0L	Other	PAM	✓	✓	✓	✓	
2000	Mountaineer	5.0L	Other	PATS	✓	✓	✓	✓	
2000	Mountaineer	5.0L	Other	PCM	✓	✓	✓	✓	0005, 0008, 0025, 0028, 0031, 0033
2000	Mountaineer	5.0L	Other	RAP	✓	✓	✓	✓	0005, F044
2002	Mountaineer	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2002	Mountaineer	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2002	Mountaineer	4.0L	V6 SOHC	CSM	✓	✓	✓	✓	
2002	Mountaineer	4.0L	V6 SOHC	DSM	✓	✓	✓	✓	
2002	Mountaineer	4.0L	V6 SOHC	EATC	✓	✓	✓	✓	
2002	Mountaineer	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0203
2002	Mountaineer	4.0L	V6 SOHC	IC	✓	✓	✓	✓	
2002	Mountaineer	4.0L	V6 SOHC	PAM	✓	✓	✓	✓	
2002	Mountaineer	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Mountaineer	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2002	Mountaineer	4.6L	2V	4X4	✓	✓	✓	✓	
2002	Mountaineer	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2002	Mountaineer	4.6L	2V	CSM	✓	✓	✓	✓	
2002	Mountaineer	4.6L	2V	DSM	✓	✓	✓	✓	
2002	Mountaineer	4.6L	2V	EATC	✓	✓	✓	✓	

2002	Mountaineer	4. 6L	2V	GEM	✓	✓	✓	✓	0203
2002	Mountaineer	4. 6L	2V	IC	✓	✓	✓	✓	
2002	Mountaineer	4. 6L	2V	PAM	✓	✓	✓	✓	
2002	Mountaineer	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Mountaineer	4. 6L	2V	RCM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	4X4	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2002. 5	Mountaineer	4. 0L	V6 SOHC	CSM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	DSM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	EATC	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	HEC	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	PAM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002. 5	Mountaineer	4. 0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2002. 5	Mountaineer	4. 0L	V6 SOHC	TPM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	4X4	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2002. 5	Mountaineer	4. 6L	2V	CSM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	DSM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	EATC	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	HEC	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	PAM	✓	✓	✓	✓	
2002. 5	Mountaineer	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002. 5	Mountaineer	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2002. 5	Mountaineer	4. 6L	2V	TPM	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	4X4	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2003	Mountaineer	4. 0L	V6 SOHC	DSM	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	EATC	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	HEC	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	PAM	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Mountaineer	4. 0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2003	Mountaineer	4. 0L	V6 SOHC	TPM	✓	✓	✓	✓	
2003	Mountaineer	4. 0L	V6 SOHC	VSM	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	4X4	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	Mountaineer	4. 6L	2V	DSM	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	EATC	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	HEC	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	PAM	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Mountaineer	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2003	Mountaineer	4. 6L	2V	TPM	✓	✓	✓	✓	
2003	Mountaineer	4. 6L	2V	VSM	✓	✓	✓	✓	
2004	Mountaineer	4. 0L	V6 SOHC	4X4	✓	✓	✓	✓	
2004	Mountaineer	4. 0L	V6 SOHC	ABS	✓	✓	✓	✓	0005, 0008, 0012
2004	Mountaineer	4. 0L	V6 SOHC	DSM	✓	✓	✓	✓	
2004	Mountaineer	4. 0L	V6 SOHC	EATC	✓	✓	✓	✓	0005
2004	Mountaineer	4. 0L	V6 SOHC	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054, F071, F072
2004	Mountaineer	4. 0L	V6 SOHC	PAM	✓	✓	✓	✓	
2004	Mountaineer	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Mountaineer	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2004	Mountaineer	4. 0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2004	Mountaineer	4. 0L	V6 SOHC	TPM	✓	✓	✓	✓	0005
2004	Mountaineer	4. 0L	V6 SOHC	VSM	✓	✓	✓	✓	
2004	Mountaineer	4. 6L	2V	4X4	✓	✓	✓	✓	
2004	Mountaineer	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2004	Mountaineer	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0012
2004	Mountaineer	4. 6L	2V	DSM	✓	✓	✓	✓	
2004	Mountaineer	4. 6L	2V	EATC	✓	✓	✓	✓	0005
2004	Mountaineer	4. 6L	2V	IC	✓	✓	✓	✓	0005
2004	Mountaineer	4. 6L	2V	PAM	✓	✓	✓	✓	
2004	Mountaineer	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Mountaineer	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2004	Mountaineer	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2004	Mountaineer	4. 6L	2V	TPM	✓	✓	✓	✓	0005
2004	Mountaineer	4. 6L	2V	VSM	✓	✓	✓	✓	
2005	Mountaineer	4. 0L	V6 SOHC	4X4	✓	✓	✓	✓	
2005	Mountaineer	4. 0L	V6 SOHC	4X4	✓	✓	✓	✓	0111
2005	Mountaineer	4. 0L	V6 SOHC	ABS	✓	✓	✓	✓	0005, 0008, 0012
2005	Mountaineer	4. 0L	V6 SOHC	DSM	✓	✓	✓	✓	
2005	Mountaineer	4. 0L	V6 SOHC	EATC	✓	✓	✓	✓	
2005	Mountaineer	4. 0L	V6 SOHC	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054, F071, F072
2005	Mountaineer	4. 0L	V6 SOHC	PAM	✓	✓	✓	✓	
2005	Mountaineer	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Mountaineer	4. 0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2005	Mountaineer	4. 0L	V6 SOHC	TPM	✓	✓	✓	✓	0005
2005	Mountaineer	4. 0L	V6 SOHC	VSM	✓	✓	✓	✓	
2005	Mountaineer	4. 6L	2V	4X4	✓	✓	✓	✓	
2005	Mountaineer	4. 6L	2V	ABS	✓	✓	✓	✓	0008, 0012
2005	Mountaineer	4. 6L	2V	DSM	✓	✓	✓	✓	
2005	Mountaineer	4. 6L	2V	EATC	✓	✓	✓	✓	
2005	Mountaineer	4. 6L	2V	IC	✓	✓	✓	✓	
2005	Mountaineer	4. 6L	2V	PAM	✓	✓	✓	✓	

2005	Mountaineer	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Mountaineer	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2005	Mountaineer	4. 6L	2V	TPM	✓	✓	✓	✓	
2005	Mountaineer	4. 6L	2V	VSM	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2006	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2006	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2006	Mountaineer	4. 0L	2V	DSM	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	EATC	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	GEM	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2006	Mountaineer	4. 0L	2V	IC	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2006	Mountaineer	4. 0L	2V	PAM	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Mountaineer	4. 0L	2V	PRB	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2006	Mountaineer	4. 0L	2V	RETm	✓	✓	✓	✓	
2006	Mountaineer	4. 0L	2V	RETm	✓	✓	✓	✓	F04D, F05A
2006	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005, 0019
2006	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	0019
2006	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	0111
2006	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2006	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2006	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	EATC	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	EATC	✓	✓	✓	✓	0005
2006	Mountaineer	4. 6L	3V	GEM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	GEM	✓	✓	✓	✓	0005
2006	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2006	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2006	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Mountaineer	4. 6L	3V	PRB	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	0005
2006	Mountaineer	4. 6L	3V	RETm	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	RETm	✓	✓	✓	✓	0005
2006	Mountaineer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2006	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	
2006	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2007	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	
2007	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2007	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Mountaineer	4. 0L	2V	DSM	✓	✓	✓	✓	F041, F074, F075
2007	Mountaineer	4. 0L	2V	EATC	✓	✓	✓	✓	
2007	Mountaineer	4. 0L	2V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2007	Mountaineer	4. 0L	2V	IC	✓	✓	✓	✓	F027, F040, F044, F04D, F054, F06B
2007	Mountaineer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Mountaineer	4. 0L	2V	PAM	✓	✓	✓	✓	
2007	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Mountaineer	4. 0L	2V	PRB	✓	✓	✓	✓	
2007	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Mountaineer	4. 0L	2V	RETm	✓	✓	✓	✓	F04D, F05A
2007	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	0111
2007	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2007	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	EATC	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	EATC	✓	✓	✓	✓	0005
2007	Mountaineer	4. 6L	3V	GEM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	GEM	✓	✓	✓	✓	0005, F042, F044, F04C
2007	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	F044
2007	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2007	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2007	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	

2007	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2007	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Mountaineer	4. 6L	3V	PRB	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	0005, F04D, F05A
2007	Mountaineer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	
2007	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2008	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	
2008	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2008	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2008	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Mountaineer	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2008	Mountaineer	4. 0L	2V	DSM	✓	✓	✓	✓	F041, F074, F075
2008	Mountaineer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2008	Mountaineer	4. 0L	2V	HVAC	✓	✓	✓	✓	
2008	Mountaineer	4. 0L	2V	IC	✓	✓	✓	✓	
2008	Mountaineer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Mountaineer	4. 0L	2V	PAM	✓	✓	✓	✓	
2008	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Mountaineer	4. 0L	2V	PRB	✓	✓	✓	✓	
2008	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2008	Mountaineer	4. 0L	2V	RET	✓	✓	✓	✓	F04D, F05A
2008	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005
2008	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	0111
2008	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	0008, 0012
2008	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018, F04D, F05A, F073
2008	Mountaineer	4. 6L	3V	APIM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2008	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	F041, F074, F075
2008	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2008	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042, F042, F044, F04C
2008	Mountaineer	4. 6L	3V	HVAC	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2008	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015
2008	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2008	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0028, 0031, 0031, 0033, 0031, 0033, 0033, 00C5
2008	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2008	Mountaineer	4. 6L	3V	PRB	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	F022, F05D
2008	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	F05A
2008	Mountaineer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	
2008	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2009	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2009	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2009	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2009	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0018
2009	Mountaineer	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2009	Mountaineer	4. 0L	2V	DSM	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	DSM	✓	✓	✓	✓	0005, F041, F074, F075
2009	Mountaineer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2009	Mountaineer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0042
2009	Mountaineer	4. 0L	2V	HVAC	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	HVAC	✓	✓	✓	✓	0005
2009	Mountaineer	4. 0L	2V	IC	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	IC	✓	✓	✓	✓	0005, F044
2009	Mountaineer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Mountaineer	4. 0L	2V	PAM	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Mountaineer	4. 0L	2V	PRB	✓	✓	✓	✓	

2009	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Mountaineer	4. 0L	2V	RET	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	RET	✓	✓	✓	✓	F04D, F05A, F076
2009	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	
2009	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	0005
2009	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2009	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2009	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0018
2009	Mountaineer	4. 6L	3V	APIM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	0005, F041, F074, F075
2009	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2009	Mountaineer	4. 6L	3V	HVAC	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	HVAC	✓	✓	✓	✓	0005
2009	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2009	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2009	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2009	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2009	Mountaineer	4. 6L	3V	PRB	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2009	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	RET	✓	✓	✓	✓	F04D, F05A, F076
2009	Mountaineer	4. 6L	3V	SDARS	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	
2009	Mountaineer	4. 6L	3V	TCM	✓	✓	✓	✓	00CE
2010	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	4X4	✓	✓	✓	✓	0111
2010	Mountaineer	4. 0L	2V	ABS	✓	✓	✓	✓	0008, 0012
2010	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2010	Mountaineer	4. 0L	2V	ACM	✓	✓	✓	✓	0016, 0017, 0018, 0018
2010	Mountaineer	4. 0L	2V	APIM	✓	✓	✓	✓	0019, 001C
2010	Mountaineer	4. 0L	2V	DSM	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	GEM / SJB	✓	✓	✓	✓	0042
2010	Mountaineer	4. 0L	2V	GPSM	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	HVAC	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	IC	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Mountaineer	4. 0L	2V	PAM	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025
2010	Mountaineer	4. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Mountaineer	4. 0L	2V	PRB	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	RCM	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	RET	✓	✓	✓	✓	
2010	Mountaineer	4. 0L	2V	SDARS	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	4X4	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018
2010	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, 0018
2010	Mountaineer	4. 6L	3V	APIM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	APIM	✓	✓	✓	✓	0019, 001C
2010	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	DSM	✓	✓	✓	✓	0005, F041, F074, F075
2010	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F042, F044, F04C
2010	Mountaineer	4. 6L	3V	GPSM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	HVAC	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	HVAC	✓	✓	✓	✓	0005
2010	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	IC	✓	✓	✓	✓	0005, F027, F044, F04D, F054
2010	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	PAM	✓	✓	✓	✓	0005
2010	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	
2010	Mountaineer	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2010	Mountaineer	4. 6L	3V	PRB	✓	✓	✓	✓	

2010	Mountaineer	4.6L	3V	RCM	✓	✓	✓	✓	
2010	Mountaineer	4.6L	3V	RETM	✓	✓	✓	✓	
2010	Mountaineer	4.6L	3V	RETM	✓	✓	✓	✓	F04D, F05A, F076
2010	Mountaineer	4.6L	3V	SDARS	✓	✓	✓	✓	
2010	Mountaineer	4.6L	3V	TCM	✓	✓	✓	✓	
2010	Mountaineer	4.6L	3V	TCM	✓	✓	✓	✓	00CE
1994	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1994	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
1995	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1995	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
1996	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1996	Mustang	3.8L	Other	IAB	✓	✓	✓	✓	
1996	Mustang	3.8L	Other	PATS	✓	✓	✓	✓	
1996	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
1996	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1996	Mustang	4.6L	2V	IAB	✓	✓	✓	✓	
1996	Mustang	4.6L	2V	PATS	✓	✓	✓	✓	
1996	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025
1996	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	
1996	Mustang	4.6L	4V	IAB	✓	✓	✓	✓	
1996	Mustang	4.6L	4V	PATS	✓	✓	✓	✓	
1996	Mustang	4.6L	4V	PCM	✓	✓	✓	✓	0025
1996	Mustang	4.6L	Other	ABS/TCS	✓	✓	✓	✓	
1996	Mustang	4.6L	Other	PATS	✓	✓	✓	✓	
1996	Mustang	4.6L	Other	PCM	✓	✓	✓	✓	0025
1997	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1997	Mustang	3.8L	Other	IAB	✓	✓	✓	✓	
1997	Mustang	3.8L	Other	PATS	✓	✓	✓	✓	
1997	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
1997	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1997	Mustang	4.6L	2V	IAB	✓	✓	✓	✓	
1997	Mustang	4.6L	2V	PATS	✓	✓	✓	✓	
1997	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025
1997	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	
1997	Mustang	4.6L	4V	IAB	✓	✓	✓	✓	
1997	Mustang	4.6L	4V	PATS	✓	✓	✓	✓	
1997	Mustang	4.6L	4V	PCM	✓	✓	✓	✓	0025
1997	Mustang	4.6L	Other	ABS/TCS	✓	✓	✓	✓	
1997	Mustang	4.6L	Other	PATS	✓	✓	✓	✓	
1997	Mustang	4.6L	Other	PCM	✓	✓	✓	✓	0025
1998	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Mustang	3.8L	Other	IAB	✓	✓	✓	✓	
1998	Mustang	3.8L	Other	PATS	✓	✓	✓	✓	
1998	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
1998	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1998	Mustang	4.6L	2V	IAB	✓	✓	✓	✓	
1998	Mustang	4.6L	2V	PATS	✓	✓	✓	✓	
1998	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025
1998	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1998	Mustang	4.6L	4V	IAB	✓	✓	✓	✓	
1998	Mustang	4.6L	4V	PATS	✓	✓	✓	✓	
1998	Mustang	4.6L	4V	PCM	✓	✓	✓	✓	0025
1999	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
1999	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Mustang	3.8L	Other	GEM	✓	✓	✓	✓	
1999	Mustang	3.8L	Other	HEC	✓	✓	✓	✓	
1999	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
1999	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1999	Mustang	3.8L	Other	RCM	✓	✓	✓	✓	
1999	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
1999	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1999	Mustang	4.6L	2V	GEM	✓	✓	✓	✓	
1999	Mustang	4.6L	2V	HEC	✓	✓	✓	✓	
1999	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025
1999	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1999	Mustang	4.6L	2V	RCM	✓	✓	✓	✓	
1999	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	
1999	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	0008
1999	Mustang	4.6L	4V	GEM	✓	✓	✓	✓	
1999	Mustang	4.6L	4V	HEC	✓	✓	✓	✓	
1999	Mustang	4.6L	4V	PCM	✓	✓	✓	✓	0025
1999	Mustang	4.6L	4V	RCM	✓	✓	✓	✓	
2000	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	
2000	Mustang	3.8L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Mustang	3.8L	Other	GEM	✓	✓	✓	✓	
2000	Mustang	3.8L	Other	HEC	✓	✓	✓	✓	
2000	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025
2000	Mustang	3.8L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Mustang	3.8L	Other	RCM	✓	✓	✓	✓	
2000	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	
2000	Mustang	4.6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2000	Mustang	4.6L	2V	GEM	✓	✓	✓	✓	
2000	Mustang	4.6L	2V	HEC	✓	✓	✓	✓	
2000	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025
2000	Mustang	4.6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Mustang	4.6L	2V	RCM	✓	✓	✓	✓	
2000	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	
2000	Mustang	4.6L	4V	ABS/TCS	✓	✓	✓	✓	0008
2000	Mustang	4.6L	4V	GEM	✓	✓	✓	✓	

2006	Mustang	4.0L	V6 SOHC	IC	✓	✓	✓	✓	
2006	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	
2006	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
2006	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Mustang	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2006	Mustang	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2006	Mustang	4.6L	3V	ABS	✓	✓	✓	✓	
2006	Mustang	4.6L	3V	ABS	✓	✓	✓	✓	0008
2006	Mustang	4.6L	3V	ACM	✓	✓	✓	✓	
2006	Mustang	4.6L	3V	GEM	✓	✓	✓	✓	
2006	Mustang	4.6L	3V	IC	✓	✓	✓	✓	
2006	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	
2006	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025
2006	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0031, 0033
2006	Mustang	4.6L	3V	RCM	✓	✓	✓	✓	000C
2007	Mustang	4.0L	V6 SOHC	ABS	✓	✓	✓	✓	
2007	Mustang	4.0L	V6 SOHC	ABS	✓	✓	✓	✓	0008
2007	Mustang	4.0L	V6 SOHC	ACM	✓	✓	✓	✓	0005
2007	Mustang	4.0L	V6 SOHC	GEM	✓	✓	✓	✓	0005
2007	Mustang	4.0L	V6 SOHC	IC	✓	✓	✓	✓	0005
2007	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0005, 0005, 0005
2007	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0019
2007	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0019, 0025
2007	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
2007	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Mustang	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2007	Mustang	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2007	Mustang	4.0L	V6 SOHC	SDARS	✓	✓	✓	✓	
2007	Mustang	4.0L	V6 SOHC	SDARS	✓	✓	✓	✓	0019
2007	Mustang	4.6L	3V	ABS	✓	✓	✓	✓	0008
2007	Mustang	4.6L	3V	ACM	✓	✓	✓	✓	
2007	Mustang	4.6L	3V	GEM	✓	✓	✓	✓	
2007	Mustang	4.6L	3V	IC	✓	✓	✓	✓	0005
2007	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0005, 0019
2007	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0005, 0019, 0019
2007	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0005, 0019, 0019, 0019, 0042
2007	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025
2007	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Mustang	4.6L	3V	RCM	✓	✓	✓	✓	000C
2007	Mustang	4.6L	3V	SDARS	✓	✓	✓	✓	
2007	Mustang	4.6L	3V	SDARS	✓	✓	✓	✓	0019
2007	Mustang	5.4L	4V	ABS	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	ABS	✓	✓	✓	✓	0008
2007	Mustang	5.4L	4V	ACM	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	GEM	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	IC	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	PCM	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	PCM	✓	✓	✓	✓	0019
2007	Mustang	5.4L	4V	PCM	✓	✓	✓	✓	0025
2007	Mustang	5.4L	4V	RCM	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	RCM	✓	✓	✓	✓	000C
2007	Mustang	5.4L	4V	SDARS	✓	✓	✓	✓	
2007	Mustang	5.4L	4V	SDARS	✓	✓	✓	✓	0019
2008	Mustang	4.0L	V6 SOHC	ABS	✓	✓	✓	✓	0008
2008	Mustang	4.0L	V6 SOHC	ACM	✓	✓	✓	✓	
2008	Mustang	4.0L	V6 SOHC	GEM / SJB	✓	✓	✓	✓	0042
2008	Mustang	4.0L	V6 SOHC	IC	✓	✓	✓	✓	
2008	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0019, 0025, 0042
2008	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0019, 0028, 0042
2008	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0019, 0042
2008	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
2008	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Mustang	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Mustang	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2008	Mustang	4.0L	V6 SOHC	SDARS	✓	✓	✓	✓	0019
2008	Mustang	4.6L	3V	ABS	✓	✓	✓	✓	0008
2008	Mustang	4.6L	3V	ACM	✓	✓	✓	✓	
2008	Mustang	4.6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2008	Mustang	4.6L	3V	IC	✓	✓	✓	✓	
2008	Mustang	4.6L	3V	IC	✓	✓	✓	✓	0005
2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0005, 0019, 0019, 0019, 0042
2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0019, 0042
2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025
2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Mustang	4.6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Mustang	4.6L	3V	RCM	✓	✓	✓	✓	000C
2008	Mustang	4.6L	3V	SDARS	✓	✓	✓	✓	0019
2008	Mustang	5.4L	4V	ABS	✓	✓	✓	✓	0008
2008	Mustang	5.4L	4V	ACM	✓	✓	✓	✓	

2008	Mustang	5. 4L	4V	GEM / SJB	✓	✓	✓	✓	0042
2008	Mustang	5. 4L	4V	IC	✓	✓	✓	✓	
2008	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0019, 0025, 0042
2008	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0019, 0042
2008	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0025
2008	Mustang	5. 4L	4V	RCM	✓	✓	✓	✓	000C
2008	Mustang	5. 4L	4V	SDARS	✓	✓	✓	✓	0019
2009	Mustang	4. 0L	V6 SOHC	ABS	✓	✓	✓	✓	0008
2009	Mustang	4. 0L	V6 SOHC	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Mustang	4. 0L	V6 SOHC	APIM	✓	✓	✓	✓	
2009	Mustang	4. 0L	V6 SOHC	GEM / SJB	✓	✓	✓	✓	0042
2009	Mustang	4. 0L	V6 SOHC	IC	✓	✓	✓	✓	
2009	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0016, 0016, 0017, 0017, 0018, 0018, 0019, 0025, 0042
2009	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0016, 0016, 0017, 0017, 0018, 0018, 0019, 0028, 0042
2009	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0016, 0016, 0017, 0017, 0018, 0018, 0019, 0042
2009	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
2009	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Mustang	4. 0L	V6 SOHC	RCM	✓	✓	✓	✓	000C
2009	Mustang	4. 0L	V6 SOHC	SDARS	✓	✓	✓	✓	0019
2009	Mustang	4. 6L	3V	ABS	✓	✓	✓	✓	0008
2009	Mustang	4. 6L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Mustang	4. 6L	3V	APIM	✓	✓	✓	✓	
2009	Mustang	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	Mustang	4. 6L	3V	IC	✓	✓	✓	✓	
2009	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0016, 0016, 0017, 0017, 0018, 0018, 0019, 0028, 0042
2009	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0016, 0016, 0017, 0017, 0018, 0018, 0019, 0042
2009	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0025
2009	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Mustang	4. 6L	3V	RCM	✓	✓	✓	✓	000C
2009	Mustang	4. 6L	3V	SDARS	✓	✓	✓	✓	0019
2009	Mustang	5. 4L	4V	ABS	✓	✓	✓	✓	0008
2009	Mustang	5. 4L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Mustang	5. 4L	4V	APIM	✓	✓	✓	✓	
2009	Mustang	5. 4L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Mustang	5. 4L	4V	IC	✓	✓	✓	✓	
2009	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0016, 0016, 0017, 0017, 0018, 0018, 0019, 0042
2009	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0025
2009	Mustang	5. 4L	4V	RCM	✓	✓	✓	✓	000C
2009	Mustang	5. 4L	4V	SDARS	✓	✓	✓	✓	0019
2010	Mustang	4. 0L	V6 SOHC	ABS	✓	✓	✓	✓	0012
2010	Mustang	4. 0L	V6 SOHC	ACM	✓	✓	✓	✓	0017, 0018
2010	Mustang	4. 0L	V6 SOHC	APIM	✓	✓	✓	✓	0019
2010	Mustang	4. 0L	V6 SOHC	BCM-B	✓	✓	✓	✓	0109
2010	Mustang	4. 0L	V6 SOHC	FCIM	✓	✓	✓	✓	
2010	Mustang	4. 0L	V6 SOHC	FDIM	✓	✓	✓	✓	
2010	Mustang	4. 0L	V6 SOHC	GEM / SJB	✓	✓	✓	✓	0042
2010	Mustang	4. 0L	V6 SOHC	GPSM	✓	✓	✓	✓	
2010	Mustang	4. 0L	V6 SOHC	HVAC	✓	✓	✓	✓	
2010	Mustang	4. 0L	V6 SOHC	IPC	✓	✓	✓	✓	
2010	Mustang	4. 0L	V6 SOHC	OCSM	✓	✓	✓	✓	000C
2010	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0017, 0017, 0018, 0018
2010	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
2010	Mustang	4. 0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Mustang	4. 0L	V6 SOHC	RCM	✓	✓	✓	✓	
2010	Mustang	4. 6L	3V	ABS	✓	✓	✓	✓	0012
2010	Mustang	4. 6L	3V	ACM	✓	✓	✓	✓	0017, 0018
2010	Mustang	4. 6L	3V	APIM	✓	✓	✓	✓	0019
2010	Mustang	4. 6L	3V	BCM-B	✓	✓	✓	✓	0109
2010	Mustang	4. 6L	3V	FCIM	✓	✓	✓	✓	
2010	Mustang	4. 6L	3V	FDIM	✓	✓	✓	✓	
2010	Mustang	4. 6L	3V	GEM / SJB	✓	✓	✓	✓	0042
2010	Mustang	4. 6L	3V	GPSM	✓	✓	✓	✓	
2010	Mustang	4. 6L	3V	HVAC	✓	✓	✓	✓	
2010	Mustang	4. 6L	3V	IPC	✓	✓	✓	✓	
2010	Mustang	4. 6L	3V	OCSM	✓	✓	✓	✓	000C
2010	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0012, 0017, 0017, 0018, 0018
2010	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0025
2010	Mustang	4. 6L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Mustang	4. 6L	3V	RCM	✓	✓	✓	✓	
2010	Mustang	5. 4L	4V	ABS	✓	✓	✓	✓	0012
2010	Mustang	5. 4L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Mustang	5. 4L	4V	APIM	✓	✓	✓	✓	0019
2010	Mustang	5. 4L	4V	BCM-B	✓	✓	✓	✓	0109
2010	Mustang	5. 4L	4V	FCIM	✓	✓	✓	✓	
2010	Mustang	5. 4L	4V	FDIM	✓	✓	✓	✓	

2010	Mustang	5. 4L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Mustang	5. 4L	4V	GPSM	✓	✓	✓	✓	
2010	Mustang	5. 4L	4V	HVAC	✓	✓	✓	✓	
2010	Mustang	5. 4L	4V	IPC	✓	✓	✓	✓	
2010	Mustang	5. 4L	4V	OCSM	✓	✓	✓	✓	000C
2010	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0017, 0017, 0018, 0018
2010	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0025
2010	Mustang	5. 4L	4V	RCM	✓	✓	✓	✓	
2011	Mustang	3. 7L	TiVCT	ABS	✓	✓	✓	✓	0012
2011	Mustang	3. 7L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2011	Mustang	3. 7L	TiVCT	APIM	✓	✓	✓	✓	0019
2011	Mustang	3. 7L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2011	Mustang	3. 7L	TiVCT	FCIM	✓	✓	✓	✓	
2011	Mustang	3. 7L	TiVCT	FDIM	✓	✓	✓	✓	
2011	Mustang	3. 7L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2011	Mustang	3. 7L	TiVCT	GPSM	✓	✓	✓	✓	
2011	Mustang	3. 7L	TiVCT	HVAC	✓	✓	✓	✓	
2011	Mustang	3. 7L	TiVCT	IPC	✓	✓	✓	✓	
2011	Mustang	3. 7L	TiVCT	OCSM	✓	✓	✓	✓	000C, 006D
2011	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018
2011	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2011	Mustang	3. 7L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2011	Mustang	3. 7L	TiVCT	RCM	✓	✓	✓	✓	
2011	Mustang	5. 0L	TiVCT	ABS	✓	✓	✓	✓	0012
2011	Mustang	5. 0L	TiVCT	ACM	✓	✓	✓	✓	0017, 0018
2011	Mustang	5. 0L	TiVCT	APIM	✓	✓	✓	✓	0019
2011	Mustang	5. 0L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2011	Mustang	5. 0L	TiVCT	FCIM	✓	✓	✓	✓	
2011	Mustang	5. 0L	TiVCT	FDIM	✓	✓	✓	✓	
2011	Mustang	5. 0L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2011	Mustang	5. 0L	TiVCT	GPSM	✓	✓	✓	✓	
2011	Mustang	5. 0L	TiVCT	HVAC	✓	✓	✓	✓	
2011	Mustang	5. 0L	TiVCT	IPC	✓	✓	✓	✓	
2011	Mustang	5. 0L	TiVCT	OCSM	✓	✓	✓	✓	000C
2011	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018
2011	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0025, 0028, 0031, 0033, 0067, 00CB, 0109
2011	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2011	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2011	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2011	Mustang	5. 0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2011	Mustang	5. 0L	TiVCT	RCM	✓	✓	✓	✓	
2011	Mustang	5. 4L	4V	ABS	✓	✓	✓	✓	0012
2011	Mustang	5. 4L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Mustang	5. 4L	4V	APIM	✓	✓	✓	✓	0019
2011	Mustang	5. 4L	4V	BCM-B	✓	✓	✓	✓	0109
2011	Mustang	5. 4L	4V	FCIM	✓	✓	✓	✓	
2011	Mustang	5. 4L	4V	FDIM	✓	✓	✓	✓	
2011	Mustang	5. 4L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Mustang	5. 4L	4V	GPSM	✓	✓	✓	✓	
2011	Mustang	5. 4L	4V	HVAC	✓	✓	✓	✓	
2011	Mustang	5. 4L	4V	IPC	✓	✓	✓	✓	
2011	Mustang	5. 4L	4V	OCSM	✓	✓	✓	✓	000C
2011	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018
2011	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0025, 0028, 0031, 0033, 0067, 00CB
2011	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2011	Mustang	5. 4L	4V	PSCM	✓	✓	✓	✓	00CB
2011	Mustang	5. 4L	4V	RCM	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	ABS	✓	✓	✓	✓	0012
2012	Mustang	3. 7L	TiVCT	ACM	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	APIM	✓	✓	✓	✓	0019
2012	Mustang	3. 7L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2012	Mustang	3. 7L	TiVCT	FCIM	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	FDIM	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2012	Mustang	3. 7L	TiVCT	GPSM	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	HVAC	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	IPC	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2012	Mustang	3. 7L	TiVCT	PAM	✓	✓	✓	✓	
2012	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2012	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0109
2012	Mustang	3. 7L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2012	Mustang	3. 7L	TiVCT	RCM	✓	✓	✓	✓	
2012	Mustang	5. 0L	BOSS	ABS	✓	✓	✓	✓	0012
2012	Mustang	5. 0L	BOSS	ACM	✓	✓	✓	✓	
2012	Mustang	5. 0L	BOSS	APIM	✓	✓	✓	✓	0019
2012	Mustang	5. 0L	BOSS	BCM-B	✓	✓	✓	✓	0109
2012	Mustang	5. 0L	BOSS	FCIM	✓	✓	✓	✓	

2012	Mustang	5. 0L	BOSS	FDIM	✓	✓	✓	✓	
2012	Mustang	5. 0L	BOSS	GEM / SJB	✓	✓	✓	✓	0042
2012	Mustang	5. 0L	BOSS	GPSM	✓	✓	✓	✓	
2012	Mustang	5. 0L	BOSS	HVAC	✓	✓	✓	✓	
2012	Mustang	5. 0L	BOSS	IPC	✓	✓	✓	✓	00FA
2012	Mustang	5. 0L	BOSS	OCSM	✓	✓	✓	✓	000C
2012	Mustang	5. 0L	BOSS	PAM	✓	✓	✓	✓	
2012	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 00FA, 0109
2012	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	00FA, 0109
2012	Mustang	5. 0L	BOSS	PSCM	✓	✓	✓	✓	00CB
2012	Mustang	5. 0L	BOSS	RCM	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	ABS	✓	✓	✓	✓	0012
2012	Mustang	5. 0L	TiVCT	ACM	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	APIM	✓	✓	✓	✓	0019
2012	Mustang	5. 0L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2012	Mustang	5. 0L	TiVCT	FCIM	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	FDIM	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2012	Mustang	5. 0L	TiVCT	GPSM	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	HVAC	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	IPC	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	OCSM	✓	✓	✓	✓	000C
2012	Mustang	5. 0L	TiVCT	PAM	✓	✓	✓	✓	
2012	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0025, 0028, 0031, 0033, 0067, 00CB, 0109
2012	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2012	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2012	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0109
2012	Mustang	5. 0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2012	Mustang	5. 0L	TiVCT	RCM	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	ABS	✓	✓	✓	✓	0012
2012	Mustang	5. 4L	4V	ACM	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	APIM	✓	✓	✓	✓	0019
2012	Mustang	5. 4L	4V	BCM-B	✓	✓	✓	✓	0109
2012	Mustang	5. 4L	4V	FCIM	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	FDIM	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Mustang	5. 4L	4V	GPSM	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	HVAC	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	IPC	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	OCSM	✓	✓	✓	✓	000C
2012	Mustang	5. 4L	4V	PAM	✓	✓	✓	✓	
2012	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0109
2012	Mustang	5. 4L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	Mustang	5. 4L	4V	PSCM	✓	✓	✓	✓	00CB
2012	Mustang	5. 4L	4V	RCM	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	ABS	✓	✓	✓	✓	0012
2013	Mustang	3. 7L	TiVCT	ACM	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	APIM	✓	✓	✓	✓	0019
2013	Mustang	3. 7L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2013	Mustang	3. 7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	FDIM	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2013	Mustang	3. 7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	IPC	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	Mustang	3. 7L	TiVCT	PAM	✓	✓	✓	✓	
2013	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 00CB, 0109
2013	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067, 00CB, 0109
2013	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2013	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0067
2013	Mustang	3. 7L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2013	Mustang	3. 7L	TiVCT	RCM	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	ABS	✓	✓	✓	✓	0012
2013	Mustang	5. 0L	BOSS	ACM	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	APIM	✓	✓	✓	✓	0019
2013	Mustang	5. 0L	BOSS	BCM-B	✓	✓	✓	✓	0109
2013	Mustang	5. 0L	BOSS	FCIM	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	FDIM	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	GEM / SJB	✓	✓	✓	✓	0042
2013	Mustang	5. 0L	BOSS	GPSM	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	HVAC	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	IPC	✓	✓	✓	✓	00FA
2013	Mustang	5. 0L	BOSS	OCSM	✓	✓	✓	✓	000C
2013	Mustang	5. 0L	BOSS	PAM	✓	✓	✓	✓	
2013	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	0025, 0033, 0067

2013	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	0025, 0033, 0067, 00FA, 0109
2013	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	0067
2013	Mustang	5. 0L	BOSS	PCM	✓	✓	✓	✓	00FA, 0109
2013	Mustang	5. 0L	BOSS	PSCM	✓	✓	✓	✓	00CB
2013	Mustang	5. 0L	BOSS	RCM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	ABS	✓	✓	✓	✓	0008, 0012
2013	Mustang	5. 0L	TiVCT	ABS	✓	✓	✓	✓	0012
2013	Mustang	5. 0L	TiVCT	ACM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	APIM	✓	✓	✓	✓	0019
2013	Mustang	5. 0L	TiVCT	BCM-B	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2013	Mustang	5. 0L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	FDIM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	GEM / SJB	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2013	Mustang	5. 0L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	IPC	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	Mustang	5. 0L	TiVCT	PAM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	PAM	✓	✓	✓	✓	
2013	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025
2013	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2013	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2013	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0109
2013	Mustang	5. 0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2013	Mustang	5. 0L	TiVCT	RCM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	ABS	✓	✓	✓	✓	0012
2013	Mustang	5. 8L	4V	ACM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	APIM	✓	✓	✓	✓	0019
2013	Mustang	5. 8L	4V	BCM-B	✓	✓	✓	✓	0109
2013	Mustang	5. 8L	4V	FCIM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	FDIM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	GEM / SJB	✓	✓	✓	✓	0042
2013	Mustang	5. 8L	4V	GPSM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	HVAC	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	IPC	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	OCSM	✓	✓	✓	✓	000C
2013	Mustang	5. 8L	4V	PAM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2013	Mustang	5. 8L	4V	PCM	✓	✓	✓	✓	0109
2013	Mustang	5. 8L	4V	PSCM	✓	✓	✓	✓	00CB
2013	Mustang	5. 8L	4V	RCM	✓	✓	✓	✓	
2013	Mustang	5. 8L	4V	VDM	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	ABS	✓	✓	✓	✓	0012
2014	Mustang	3. 7L	TiVCT	ACM	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	APIM	✓	✓	✓	✓	0019
2014	Mustang	3. 7L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2014	Mustang	3. 7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	FDIM	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2014	Mustang	3. 7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	IPC	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Mustang	3. 7L	TiVCT	PAM	✓	✓	✓	✓	
2014	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2014	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 00CB, 0109
2014	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2014	Mustang	3. 7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067, 00CB, 0109
2014	Mustang	3. 7L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2014	Mustang	3. 7L	TiVCT	RCM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	ABS	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	ABS	✓	✓	✓	✓	0012
2014	Mustang	5. 0L	TiVCT	ACM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	APIM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	APIM	✓	✓	✓	✓	0019
2014	Mustang	5. 0L	TiVCT	BCM-B	✓	✓	✓	✓	0109
2014	Mustang	5. 0L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	FDIM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	GEM / SJB	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	GEM / SJB	✓	✓	✓	✓	0042
2014	Mustang	5. 0L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	IPC	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Mustang	5. 0L	TiVCT	PAM	✓	✓	✓	✓	
2014	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025
2014	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067
2014	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 0067, 00CB, 0109
2014	Mustang	5. 0L	TiVCT	PCM	✓	✓	✓	✓	0025, 00CB, 0109
2014	Mustang	5. 0L	TiVCT	PSCM	✓	✓	✓	✓	00CB
2014	Mustang	5. 0L	TiVCT	RCM	✓	✓	✓	✓	
2014	Mustang	Other	Other	ABS	✓	✓	✓	✓	

2014	Mustang	Other	Other	ACM	✓	✓	✓	✓	
2014	Mustang	Other	Other	APIM	✓	✓	✓	✓	
2014	Mustang	Other	Other	BCM-B	✓	✓	✓	✓	
2014	Mustang	Other	Other	FCIM	✓	✓	✓	✓	
2014	Mustang	Other	Other	FDIM	✓	✓	✓	✓	
2014	Mustang	Other	Other	GEM / SIB	✓	✓	✓	✓	
2014	Mustang	Other	Other	GPSM	✓	✓	✓	✓	
2014	Mustang	Other	Other	HVAC	✓	✓	✓	✓	
2014	Mustang	Other	Other	IPC	✓	✓	✓	✓	
2014	Mustang	Other	Other	OCSM	✓	✓	✓	✓	
2014	Mustang	Other	Other	PAM	✓	✓	✓	✓	
2014	Mustang	Other	Other	PCM	✓	✓	✓	✓	
2014	Mustang	Other	Other	PSCM	✓	✓	✓	✓	
2014	Mustang	Other	Other	RCM	✓	✓	✓	✓	
1996	Mystique	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1996	Mystique	2.0L	Zetec	CSM	✓	✓	✓	✓	
1996	Mystique	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
1996	Mystique	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1996	Mystique	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1996	Mystique	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1997	Mystique	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1997	Mystique	2.0L	Zetec	CSM	✓	✓	✓	✓	
1997	Mystique	2.0L	Zetec	PATS	✓	✓	✓	✓	
1997	Mystique	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
1997	Mystique	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1997	Mystique	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1997	Mystique	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
1997	Mystique	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1998	Mystique	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	
1998	Mystique	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
1998	Mystique	2.0L	Zetec	CSM	✓	✓	✓	✓	
1998	Mystique	2.0L	Zetec	PATS	✓	✓	✓	✓	
1998	Mystique	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
1998	Mystique	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	
1998	Mystique	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
1998	Mystique	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1998	Mystique	2.5L	Duratec-VE	PATS	✓	✓	✓	✓	
1998	Mystique	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1999	Mystique	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
1999	Mystique	2.0L	Zetec	CSM	✓	✓	✓	✓	
1999	Mystique	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
1999	Mystique	2.0L	Zetec	RCM	✓	✓	✓	✓	
1999	Mystique	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
1999	Mystique	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
1999	Mystique	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
1999	Mystique	2.5L	Duratec-VE	RCM	✓	✓	✓	✓	
2000	Mystique	2.0L	Zetec	ABS/TCS	✓	✓	✓	✓	0008
2000	Mystique	2.0L	Zetec	GSM	✓	✓	✓	✓	
2000	Mystique	2.0L	Zetec	PCM	✓	✓	✓	✓	0025
2000	Mystique	2.0L	Zetec	RCM	✓	✓	✓	✓	
2000	Mystique	2.5L	Duratec-VE	ABS/TCS	✓	✓	✓	✓	0008
2000	Mystique	2.5L	Duratec-VE	CSM	✓	✓	✓	✓	
2000	Mystique	2.5L	Duratec-VE	PCM	✓	✓	✓	✓	0025
2000	Mystique	2.5L	Duratec-VE	RCM	✓	✓	✓	✓	
2008	NOVO KA	1.0L	FFV	IC	✓	✓	✓	✓	
2008	NOVO KA	1.0L	FFV	PCM	✓	✓	✓	✓	0025
2008	NOVO KA	1.0L	FFV	RCM	✓	✓	✓	✓	
2008	NOVO KA	1.0L	FFV	RKE	✓	✓	✓	✓	
2008	NOVO KA	1.0L	Zetec Rocam	IC	✓	✓	✓	✓	
2008	NOVO KA	1.0L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2008	NOVO KA	1.0L	Zetec Rocam	RCM	✓	✓	✓	✓	
2008	NOVO KA	1.0L	Zetec Rocam	RKE	✓	✓	✓	✓	
2008	NOVO KA	1.6L	FFV	IC	✓	✓	✓	✓	
2008	NOVO KA	1.6L	FFV	PCM	✓	✓	✓	✓	0025
2008	NOVO KA	1.6L	FFV	RCM	✓	✓	✓	✓	
2008	NOVO KA	1.6L	FFV	RKE	✓	✓	✓	✓	
2008	NOVO KA	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2008	NOVO KA	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2008	NOVO KA	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2008	NOVO KA	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2008	NOVO KA	Other	Other	IC	✓	✓	✓	✓	
2008	NOVO KA	Other	Other	PCM	✓	✓	✓	✓	0025
2008	NOVO KA	Other	Other	RCM	✓	✓	✓	✓	
2008	NOVO KA	Other	Other	RKE	✓	✓	✓	✓	
2009	NOVO KA	1.0L	FFV	IC	✓	✓	✓	✓	
2009	NOVO KA	1.0L	FFV	PCM	✓	✓	✓	✓	0025
2009	NOVO KA	1.0L	FFV	RCM	✓	✓	✓	✓	
2009	NOVO KA	1.0L	FFV	RKE	✓	✓	✓	✓	
2009	NOVO KA	1.0L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	NOVO KA	1.0L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	NOVO KA	1.0L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2009	NOVO KA	1.0L	Zetec Rocam	RCM	✓	✓	✓	✓	
2009	NOVO KA	1.0L	Zetec Rocam	RKE	✓	✓	✓	✓	
2009	NOVO KA	1.0L	Zetec Rocam	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	NOVO KA	1.6L	FFV	IC	✓	✓	✓	✓	
2009	NOVO KA	1.6L	FFV	PCM	✓	✓	✓	✓	0025
2009	NOVO KA	1.6L	FFV	RCM	✓	✓	✓	✓	
2009	NOVO KA	1.6L	FFV	RKE	✓	✓	✓	✓	
2009	NOVO KA	1.6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3

2009	NOVO KA	1. 6L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	NOVO KA	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	
2009	NOVO KA	1. 6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2009	NOVO KA	1. 6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2009	NOVO KA	1. 6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2009	NOVO KA	1. 6L	Zetec Rocam	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	NOVO KA	1. 0L	FFV	IC	✓	✓	✓	✓	
2011	NOVO KA	1. 0L	FFV	PCM	✓	✓	✓	✓	012E
2011	NOVO KA	1. 0L	FFV	RCM	✓	✓	✓	✓	
2011	NOVO KA	1. 0L	FFV	RKE	✓	✓	✓	✓	
2011	NOVO KA	1. 0L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	NOVO KA	1. 6L	FFV	IC	✓	✓	✓	✓	
2011	NOVO KA	1. 6L	FFV	PCM	✓	✓	✓	✓	012E
2011	NOVO KA	1. 6L	FFV	RCM	✓	✓	✓	✓	
2011	NOVO KA	1. 6L	FFV	RKE	✓	✓	✓	✓	
2011	NOVO KA	1. 6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
1998	Navigator	5. 4L	Other	4WAS	✓	✓	✓	✓	
1998	Navigator	5. 4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Navigator	5. 4L	Other	DSM	✓	✓	✓	✓	
1998	Navigator	5. 4L	Other	GEM	✓	✓	✓	✓	
1998	Navigator	5. 4L	Other	IAB	✓	✓	✓	✓	
1998	Navigator	5. 4L	Other	PATS	✓	✓	✓	✓	
1998	Navigator	5. 4L	Other	PCM	✓	✓	✓	✓	0025
1998	Navigator	5. 4L	Other	RAP	✓	✓	✓	✓	
1998	Navigator	5. 4L	Other	RCC	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	4WAS	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	4WAS	✓	✓	✓	✓	000E
1999	Navigator	5. 4L	4V	ABS/TCS	✓	✓	✓	✓	0008
1999	Navigator	5. 4L	4V	DSM	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	EATC	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	GEM	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	HEC	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	0025
1999	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1999	Navigator	5. 4L	4V	RAP	✓	✓	✓	✓	
1999	Navigator	5. 4L	4V	RCM	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	4WAS	✓	✓	✓	✓	000E
2000	Navigator	5. 4L	4V	ABS/TCS	✓	✓	✓	✓	0008
2000	Navigator	5. 4L	4V	DSM	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	EATC	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	GEM	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	HEC	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	PAM	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Navigator	5. 4L	4V	RAP	✓	✓	✓	✓	
2000	Navigator	5. 4L	4V	RCM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	4X4	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Navigator	5. 4L	4V	DCSM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	DSM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	EATC	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	HEC	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	LTM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	NAV	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	PAM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	000E, 0013, 0014, 0025, 0028, 0031, 0033
2003	Navigator	5. 4L	4V	PCSM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	RCM	✓	✓	✓	✓	000C
2003	Navigator	5. 4L	4V	TPM	✓	✓	✓	✓	
2003	Navigator	5. 4L	4V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2003	Navigator	5. 4L	4V	VSM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	4X4	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	ABS/TCS	✓	✓	✓	✓	0008
2004	Navigator	5. 4L	4V	DCSM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	DSM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	EATC	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	HEC	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	LTM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	NAV	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	PAM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	PCM	✓	✓	✓	✓	000E, 0013, 0014, 0025, 0028, 0031, 0033
2004	Navigator	5. 4L	4V	PCSM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	RCM	✓	✓	✓	✓	000C
2004	Navigator	5. 4L	4V	TPM	✓	✓	✓	✓	
2004	Navigator	5. 4L	4V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2004	Navigator	5. 4L	4V	VSM	✓	✓	✓	✓	
2005	Navigator	5. 4L	3V	4X4	✓	✓	✓	✓	
2005	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	
2005	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2005	Navigator	5. 4L	3V	DCSM	✓	✓	✓	✓	
2005	Navigator	5. 4L	3V	DSM	✓	✓	✓	✓	
2005	Navigator	5. 4L	3V	DSM	✓	✓	✓	✓	F041
2005	Navigator	5. 4L	3V	EATC	✓	✓	✓	✓	
2005	Navigator	5. 4L	3V	EATC	✓	✓	✓	✓	0005
2005	Navigator	5. 4L	3V	IC	✓	✓	✓	✓	

2005	Navigator	5.4L	3V	LTM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	LTM	✓	✓	✓	✓	0005
2005	Navigator	5.4L	3V	NAV	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	NAV	✓	✓	✓	✓	0016
2005	Navigator	5.4L	3V	PAM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0005, F041
2005	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2005	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	F041
2005	Navigator	5.4L	3V	RCM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	RCM	✓	✓	✓	✓	000C
2005	Navigator	5.4L	3V	TCM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	TCM	✓	✓	✓	✓	00C5
2005	Navigator	5.4L	3V	VDM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2005	Navigator	5.4L	3V	VSM	✓	✓	✓	✓	
2005	Navigator	5.4L	3V	VSM	✓	✓	✓	✓	0005, F044
2005	Navigator	5.4L	3V	VSM	✓	✓	✓	✓	F044
2006	Navigator	5.4L	3V	4X4	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	ABS	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2006	Navigator	5.4L	3V	DCSM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	DSM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	DSM	✓	✓	✓	✓	F041
2006	Navigator	5.4L	3V	EATC	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	EATC	✓	✓	✓	✓	0005
2006	Navigator	5.4L	3V	IC	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	IC	✓	✓	✓	✓	0005
2006	Navigator	5.4L	3V	LTM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	LTM	✓	✓	✓	✓	0005
2006	Navigator	5.4L	3V	NAV	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	NAV	✓	✓	✓	✓	0016
2006	Navigator	5.4L	3V	PAM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0005
2006	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0005, F041
2006	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033, 0033, 00C5
2006	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Navigator	5.4L	3V	RCM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	RCM	✓	✓	✓	✓	000C
2006	Navigator	5.4L	3V	TCM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	VDM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2006	Navigator	5.4L	3V	VSM	✓	✓	✓	✓	
2006	Navigator	5.4L	3V	VSM	✓	✓	✓	✓	0005
2006	Navigator	5.4L	3V	VSM	✓	✓	✓	✓	0005, F044
2007	Navigator	5.4L	3V	4X4	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	ABS	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2007	Navigator	5.4L	3V	ACM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F063
2007	Navigator	5.4L	3V	DCSM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	DCSM	✓	✓	✓	✓	F070
2007	Navigator	5.4L	3V	DSM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	DSM	✓	✓	✓	✓	0005, F041, F06C, F06D, F06F
2007	Navigator	5.4L	3V	DSM	✓	✓	✓	✓	F041, F06C, F06D, F06F
2007	Navigator	5.4L	3V	DSP	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	DSP	✓	✓	✓	✓	0005
2007	Navigator	5.4L	3V	EATC	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	GEM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	GEM	✓	✓	✓	✓	F042, F049, F04B, F04C, F05C, F060
2007	Navigator	5.4L	3V	IC	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	IC	✓	✓	✓	✓	0005, F027, F041, F044, F04A, F04C, F04D, F06B, F06E
2007	Navigator	5.4L	3V	IC	✓	✓	✓	✓	F027, F041, F044, F04A, F04C, F04D, F06B, F06E
2007	Navigator	5.4L	3V	LTM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	PAM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	
2007	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0005, 0005, 0005, 0005, 0016, 0016, 0016, 0017, 0017, 0017, 0018, 0018, 0018, 0019, 0025, 0028, 0031, 0033, 00C5, F04D, F05A, F05A, F063, F063, F063

2007	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0005, 0005, 0005, 0016, 0016, 0016, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0019, 0025, 0028, 0031, 0033, 00C5, F04D, F05A, F05A, F063, F063, F063
2007	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Navigator	5. 4L	3V	PRB	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	RCM	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	RCM	✓	✓	✓	✓	0005, F022, F05D
2007	Navigator	5. 4L	3V	RCM	✓	✓	✓	✓	F022, F05D
2007	Navigator	5. 4L	3V	RCU	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	RCU	✓	✓	✓	✓	F05A
2007	Navigator	5. 4L	3V	RETM	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	RETM	✓	✓	✓	✓	0005, F04D, F05A
2007	Navigator	5. 4L	3V	SDARS	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	SDARS	✓	✓	✓	✓	0005, 0019
2007	Navigator	5. 4L	3V	SDARS	✓	✓	✓	✓	0019
2007	Navigator	5. 4L	3V	TCM	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	VDM	✓	✓	✓	✓	
2007	Navigator	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2008	Navigator	5. 4L	3V	4X4	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2008	Navigator	5. 4L	3V	ACM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	ACM	✓	✓	✓	✓	0005, 0016, 0017, 0018, F063
2008	Navigator	5. 4L	3V	APIM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2008	Navigator	5. 4L	3V	DCSM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	DCSM	✓	✓	✓	✓	F070
2008	Navigator	5. 4L	3V	DSM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	DSM	✓	✓	✓	✓	0005
2008	Navigator	5. 4L	3V	DSP	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	DSP	✓	✓	✓	✓	0005
2008	Navigator	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	HVAC	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	IC	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	IC	✓	✓	✓	✓	0005
2008	Navigator	5. 4L	3V	LTM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	PAM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0005, 0005, 0005, 0005, 0016, 0016, 0016, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0019, 0025, 0028, 0031, 0033, 00C5, F04D, F05A, F05A, F063, F063, F063
2008	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0005, 0005, 0005, 0005, 0005, 0005, 0016, 0016, 0016, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0019, 0025, 0028, 0031, 0033, 00C5, F04D, F05A, F05A, F063, F063, F063
2008	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Navigator	5. 4L	3V	PRB	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	RCM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	RCM	✓	✓	✓	✓	0005
2008	Navigator	5. 4L	3V	RCU	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	RCU	✓	✓	✓	✓	F05A
2008	Navigator	5. 4L	3V	RETM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	RETM	✓	✓	✓	✓	0005, F04D, F05A
2008	Navigator	5. 4L	3V	SDARS	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	SDARS	✓	✓	✓	✓	0005
2008	Navigator	5. 4L	3V	TCM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	VDM	✓	✓	✓	✓	
2008	Navigator	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2009	Navigator	5. 4L	3V	4X4	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012, 0067
2009	Navigator	5. 4L	3V	ACM	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Navigator	5. 4L	3V	APIM	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Navigator	5. 4L	3V	DCSM	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	DSM	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	DSP	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	Navigator	5. 4L	3V	HVAC	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	IC	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	LTM	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	PAM	✓	✓	✓	✓	
2009	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	

2012	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0018, 0025, 0028, 0028, 0031, 0031, 0033, 0067, 0108
2012	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0025
2012	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2012	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067
2012	Navigator	5. 4L	3V	PRB	✓	✓	✓	✓	
2012	Navigator	5. 4L	3V	RCM	✓	✓	✓	✓	
2012	Navigator	5. 4L	3V	RCU	✓	✓	✓	✓	
2012	Navigator	5. 4L	3V	RCU	✓	✓	✓	✓	
2012	Navigator	5. 4L	3V	RETM	✓	✓	✓	✓	
2012	Navigator	5. 4L	3V	SDARS	✓	✓	✓	✓	
2012	Navigator	5. 4L	3V	TCCM	✓	✓	✓	✓	
2012	Navigator	5. 4L	3V	VDM	✓	✓	✓	✓	
2012	Navigator	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2013	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	0012
2013	Navigator	5. 4L	3V	ACM	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2013	Navigator	5. 4L	3V	APIM	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	APIM	✓	✓	✓	✓	0019
2013	Navigator	5. 4L	3V	DCSM	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	DSM	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	DSP	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2013	Navigator	5. 4L	3V	GPSM	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	HVAC	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	IC	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	LTM	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	PAM	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0018, 0025, 0028, 0028, 0031, 0031, 0033, 0067, 0108
2013	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033
2013	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	Navigator	5. 4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2013	Navigator	5. 4L	3V	PRB	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	RCM	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	RCU	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	SDARS	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	TBC	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	TCCM	✓	✓	✓	✓	
2013	Navigator	5. 4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2013	Navigator	Other	Other	ABS	✓	✓	✓	✓	
2013	Navigator	Other	Other	ACM	✓	✓	✓	✓	
2013	Navigator	Other	Other	APIM	✓	✓	✓	✓	
2013	Navigator	Other	Other	DCSM	✓	✓	✓	✓	
2013	Navigator	Other	Other	DSM	✓	✓	✓	✓	
2013	Navigator	Other	Other	DSP	✓	✓	✓	✓	
2013	Navigator	Other	Other	GEM / SJB	✓	✓	✓	✓	
2013	Navigator	Other	Other	GPSM	✓	✓	✓	✓	
2013	Navigator	Other	Other	HVAC	✓	✓	✓	✓	
2013	Navigator	Other	Other	IC	✓	✓	✓	✓	
2013	Navigator	Other	Other	LTM	✓	✓	✓	✓	
2013	Navigator	Other	Other	PAM	✓	✓	✓	✓	
2013	Navigator	Other	Other	PCM	✓	✓	✓	✓	
2013	Navigator	Other	Other	PCM	✓	✓	✓	✓	
2013	Navigator	Other	Other	PRB	✓	✓	✓	✓	
2013	Navigator	Other	Other	RCM	✓	✓	✓	✓	
2013	Navigator	Other	Other	RCU	✓	✓	✓	✓	
2013	Navigator	Other	Other	SDARS	✓	✓	✓	✓	
2013	Navigator	Other	Other	TBC	✓	✓	✓	✓	
2013	Navigator	Other	Other	TCCM	✓	✓	✓	✓	
2013	Navigator	Other	Other	VDM	✓	✓	✓	✓	
2014	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2014	Navigator	5. 4L	3V	ABS	✓	✓	✓	✓	0012
2014	Navigator	5. 4L	3V	ACM	✓	✓	✓	✓	
2014	Navigator	5. 4L	3V	ACM	✓	✓	✓	✓	0017, 0018
2014	Navigator	5. 4L	3V	APIM	✓	✓	✓	✓	
2014	Navigator	5. 4L	3V	APIM	✓	✓	✓	✓	0019
2014	Navigator	5. 4L	3V	DCSM	✓	✓	✓	✓	
2014	Navigator	5. 4L	3V	DSM	✓	✓	✓	✓	
2014	Navigator	5. 4L	3V	DSP	✓	✓	✓	✓	
2014	Navigator	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	
2014	Navigator	5. 4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2014	Navigator	5. 4L	3V	GPSM	✓	✓	✓	✓	
2014	Navigator	5. 4L	3V	HVAC	✓	✓	✓	✓	
2014	Navigator	5. 4L	3V	IC	✓	✓	✓	✓	
2014	Navigator	5. 4L	3V	LTM	✓	✓	✓	✓	
2014	Navigator	5. 4L	3V	PAM	✓	✓	✓	✓	

2014	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0017, 0017, 0017, 0017, 0017, 0018, 0018, 0018, 0018, 0018, 0025, 0028, 0028, 0031, 0031, 0033, 0067, 0108
2014	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025
2014	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0028, 0031, 0031, 0033
2014	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Navigator	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2014	Navigator	5.4L	3V	PRB	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	RCM	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	RCU	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	SDARS	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	TBC	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	TCCM	✓	✓	✓	✓	
2014	Navigator	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2007	Navigator L	5.4L	3V	4X4	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2007	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	DSM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	DSP	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	EATC	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	GEM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	IC	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	LTM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	PAM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Navigator L	5.4L	3V	PRB	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	RCM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	RCU	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	RET	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	SDARS	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	SDARS	✓	✓	✓	✓	0019
2007	Navigator L	5.4L	3V	TCM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓	
2007	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2008	Navigator L	5.4L	3V	4X4	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012
2008	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2008	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	DSM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	DSP	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	HVAC	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	IC	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	LTM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	PAM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Navigator L	5.4L	3V	PRB	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	RCM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	RCU	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	RET	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	SDARS	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	TCM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓	
2008	Navigator L	5.4L	3V	VDM	✓	✓	✓	✓	000E, 0013, 0014
2009	Navigator L	5.4L	3V	4X4	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	ABS	✓	✓	✓	✓	0008, 0012, 0067
2009	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	ACM	✓	✓	✓	✓	0016
2009	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	APIM	✓	✓	✓	✓	0019, 001C
2009	Navigator L	5.4L	3V	DCSM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	DSM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	DSP	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	GEM / SJB	✓	✓	✓	✓	0042
2009	Navigator L	5.4L	3V	HVAC	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	IC	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	LTM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	PAM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	PCM	✓	✓	✓	✓	0067
2009	Navigator L	5.4L	3V	PRB	✓	✓	✓	✓	
2009	Navigator L	5.4L	3V	RCM	✓	✓	✓	✓	

1998.5	Puma	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1998.5	Puma	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
1998.5	Puma	1.4L	Zetec-SE	PATS			✓	✓	
1998.5	Puma	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1999.5	Puma	1.4L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1999.5	Puma	1.4L	Zetec-SE	GEM	✓	✓	✓	✓	
1999.5	Puma	1.4L	Zetec-SE	HEC	✓	✓	✓	✓	
1999.5	Puma	1.4L	Zetec-SE	PATS			✓	✓	
1999.5	Puma	1.4L	Zetec-SE	PCM	✓	✓	✓	✓	0025
1999.5	Puma	1.7L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
1999.5	Puma	1.7L	Zetec-SE	GEM	✓	✓	✓	✓	
1999.5	Puma	1.7L	Zetec-SE	HEC	✓	✓	✓	✓	
1999.5	Puma	1.7L	Zetec-SE	PATS	✓	✓	✓	✓	
1999.5	Puma	1.7L	Zetec-SE	PCM	✓	✓	✓	✓	0025
2001	Puma	1.6L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
2001	Puma	1.6L	Zetec-SE	GEM	✓	✓	✓	✓	
2001	Puma	1.6L	Zetec-SE	HEC	✓	✓	✓	✓	
2001	Puma	1.6L	Zetec-SE	PATS	✓	✓	✓	✓	
2001	Puma	1.6L	Zetec-SE	PCM	✓	✓	✓	✓	0025
2001	Puma	1.7L	Zetec-SE	ABS/TCS	✓	✓	✓	✓	
2001	Puma	1.7L	Zetec-SE	GEM	✓	✓	✓	✓	
2001	Puma	1.7L	Zetec-SE	HEC	✓	✓	✓	✓	
2001	Puma	1.7L	Zetec-SE	PATS	✓	✓	✓	✓	
2001	Puma	1.7L	Zetec-SE	PCM	✓	✓	✓	✓	0025
2000	ROADSTER / MX-5	1.6L	B6	ABS	✓	✓	✓	✓	
2000	ROADSTER / MX-5	1.8L	BP	ABS	✓	✓	✓	✓	
2002	ROADSTER / MX-5	1.6L	B6	ABS/TCS	✓	✓	✓	✓	
2002	ROADSTER / MX-5	1.6L	B6	PCM	✓	✓	✓	✓	
2002	ROADSTER / MX-5	1.8L	BP	ABS/TCS	✓	✓	✓	✓	
2002	ROADSTER / MX-5	1.8L	BP	PCM	✓	✓	✓	✓	
2003	ROADSTER / MX-5	1.8L	BP Turbo	ABS/TCS	✓	✓	✓	✓	
2003	ROADSTER / MX-5	1.8L	BP Turbo	PCM	✓	✓	✓	✓	
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	ABS	✓	✓	✓	✓	
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	ABS	✓	✓	✓	✓	001E
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	IC	✓	✓	✓		
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	PCM	✓	✓	✓	✓	
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RCM	✓	✓	✓	✓	
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RHT	✓	✓	✓	✓	
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RKE	✓	✓	✓	✓	
2005	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	TCM	✓	✓	✓	✓	
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	ABS	✓	✓	✓	✓	
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	ABS	✓	✓	✓	✓	001E
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	IC	✓	✓	✓		
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	PCM	✓	✓	✓	✓	
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RCM	✓	✓	✓	✓	
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RHT	✓	✓	✓	✓	
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	RKE	✓	✓	✓	✓	
2008	ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	TCM	✓	✓	✓	✓	
2005.5	Ranger	3.0L	I4 DSL Electronic	4X4	✓	✓	✓	✓	
2005.5	Ranger	3.0L	I4 DSL Electronic	ABS/TCS	✓	✓	✓	✓	0008
2005.5	Ranger	3.0L	I4 DSL Electronic	GEM	✓	✓	✓	✓	0063
2005.5	Ranger	3.0L	I4 DSL Electronic	IC	✓	✓	✓	✓	
2005.5	Ranger	3.0L	I4 DSL Electronic	PCM	✓	✓	✓	✓	
2005.5	Ranger	3.0L	I4 DSL Electronic	RCM	✓	✓	✓	✓	
2005.5	Ranger	3.0L	I4 DSL Electronic	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2006	Ranger	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2006	Ranger	2.3L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008
2006	Ranger	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	
2006	Ranger	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2006	Ranger	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2006	Ranger	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2009.5	Ranger	2.3L	DURATEC-HE / I4	4X4	✓	✓	✓	✓	
2009.5	Ranger	2.3L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	0008
2009.5	Ranger	2.3L	DURATEC-HE / I4	GEM	✓	✓	✓	✓	0063
2009.5	Ranger	2.3L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2009.5	Ranger	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2009.5	Ranger	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	000C
2009.5	Ranger	2.3L	DURATEC-HE / I4	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2003	Ranger / Courier / Mazda B Series /Bravo	4.0L	V6 SOHC	ABS/TCS	✓	✓	✓	✓	0008
2003	Ranger / Courier / Mazda B Series /Bravo	4.0L	V6 SOHC	ESOF	✓	✓	✓	✓	

2011	Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	TCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	TRM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 001E, 00CA
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	00D5
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	DDM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	HVAC	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00B0, 00B1, 00B3, 00BC, 00BD, 00C1, 00E7, 0133
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	PDM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	TBM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	4X4	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	ABS	✓	✓	✓	✓	0008, 0012
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	GEM / SJB	✓	✓	✓	✓	0042
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	IC	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	OCSM	✓	✓	✓	✓	000C
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0008, 0012, 0019, 0042
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	RCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	SDARS	✓	✓	✓	✓	0019
2011	Ranger / Mazda B-Series / Courier	Other	Other	ABS	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	ABS	✓	✓	✓	✓	00CA
2011	Ranger / Mazda B-Series / Courier	Other	Other	ACM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	BCMii	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	DDM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	FCDIM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	HVAC	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	IPC	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	PAM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	PDM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	RCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	SRM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	Ranger / Mazda B-Series / Courier	Other	Other	TCM	✓	✓	✓	✓	
2011	Ranger / Mazda B-Series / Courier	Other	Other	TRM	✓	✓	✓	✓	
2007	S. A. Courier	1.6L	FFV	PCM	✓	✓	✓	✓	0025
2009	S. A. Courier	1.6L	FFV	IC	✓	✓	✓	✓	
2009	S. A. Courier	1.6L	FFV	PCM	✓	✓	✓	✓	0025
2009	S. A. Courier	1.6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2009	S. A. Courier	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	S. A. Courier	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2009	S. A. Courier	1.6L	Zetec Rocam	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	S. A. Courier	1.6L	FFV	IC	✓	✓	✓	✓	
2011	S. A. Courier	1.6L	FFV	PCM	✓	✓	✓	✓	012E
2011	S. A. Courier	1.6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2002.5	S. A. Fiesta	1.0L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.0L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008
2002.5	S. A. Fiesta	1.0L	Zetec Rocam	IC	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.0L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2002.5	S. A. Fiesta	1.0L	Zetec Rocam	RCM	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.0L	Zetec Rocam	RKE	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2002.5	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	

2002.5	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓		
2002.5	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2002.5	S. A. Fiesta	1.6L	FFV	IC	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2002.5	S. A. Fiesta	1.6L	FFV	RCM	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	FFV	RKE	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008
2002.5	S. A. Fiesta	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2002.5	S. A. Fiesta	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2002.5	S. A. Fiesta	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2006	S. A. Fiesta	1.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2006	S. A. Fiesta	1.0L	FFV	ABS/TCS	✓	✓	✓	✓	000B
2006	S. A. Fiesta	1.0L	FFV	IC	✓	✓	✓	✓	
2006	S. A. Fiesta	1.0L	FFV	PCM	✓	✓	✓	✓	0025
2006	S. A. Fiesta	1.0L	FFV	RCM	✓	✓	✓	✓	
2006	S. A. Fiesta	1.0L	FFV	RKE	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2006	S. A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	000B
2006	S. A. Fiesta	1.6L	FFV	IC	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2006	S. A. Fiesta	1.6L	FFV	RCM	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	FFV	RKE	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	0008
2006	S. A. Fiesta	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2006	S. A. Fiesta	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2006	S. A. Fiesta	1.6L	Zetec Rocam	TCM	✓	✓	✓	✓	
2009	S. A. Fiesta	1.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2009	S. A. Fiesta	1.0L	FFV	IC	✓	✓	✓	✓	
2009	S. A. Fiesta	1.0L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2009	S. A. Fiesta	1.0L	FFV	RCM	✓	✓	✓	✓	
2009	S. A. Fiesta	1.0L	FFV	RKE	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	0008, 000B
2009	S. A. Fiesta	1.6L	FFV	IC	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	FFV	PCM	✓	✓	✓	✓	0025, 012E
2009	S. A. Fiesta	1.6L	FFV	RCM	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	FFV	RKE	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	Zetec Rocam	ABS/TCS	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	Zetec Rocam	IC	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	Zetec Rocam	PCM	✓	✓	✓	✓	0025
2009	S. A. Fiesta	1.6L	Zetec Rocam	RCM	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	Zetec Rocam	RKE	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	Zetec Rocam	TCM	✓	✓	✓	✓	
2009	S. A. Fiesta	1.6L	Zetec Rocam	TCM	✓	✓	✓	✓	00CE
2010	S. A. Fiesta	1.0L	FFV	ABS/TCS	✓	✓	✓	✓	000B
2010	S. A. Fiesta	1.0L	FFV	IC	✓	✓	✓	✓	
2010	S. A. Fiesta	1.0L	FFV	PCM	✓	✓	✓	✓	012E
2010	S. A. Fiesta	1.0L	FFV	RCM	✓	✓	✓	✓	
2010	S. A. Fiesta	1.0L	FFV	RKE	✓	✓	✓	✓	
2010	S. A. Fiesta	1.0L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2011	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2011	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2011	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0025
2011	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓		
2011	S. A. Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	RKE	✓	✓	✓	✓	
2011	S. A. Fiesta	1.6L	FFV	ABS/TCS	✓	✓	✓	✓	000B
2011	S. A. Fiesta	1.6L	FFV	IC	✓	✓	✓	✓	
2011	S. A. Fiesta	1.6L	FFV	PCM	✓	✓	✓	✓	012E
2011	S. A. Fiesta	1.6L	FFV	RCM	✓	✓	✓	✓	
2011	S. A. Fiesta	1.6L	FFV	RKE	✓	✓	✓	✓	
2011	S. A. Fiesta	1.6L	FFV	TBM	✓	✓	✓	✓	00D1, 00D2, 00D3
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	ABS	✓	✓	✓	✓	
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	PCM	✓	✓	✓	✓	
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	RCM	✓	✓	✓	✓	
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A T	ABS	✓	✓	✓	✓	
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A T	PCM	✓	✓	✓	✓	
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A T	RCM	✓	✓	✓	✓	
2005	SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A T	TCM	✓	✓	✓	✓	
1996	Sable	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
1996	Sable	3.0L	4V	GEM	✓	✓	✓	✓	
1996	Sable	3.0L	4V	IAB	✓	✓	✓	✓	
1996	Sable	3.0L	4V	PATS	✓	✓	✓	✓	
1996	Sable	3.0L	4V	PCM	✓	✓	✓	✓	0025

2003	Sable	3.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Sable	3.0L	2V	RCM	✓	✓	✓	✓	
2003	Sable	3.0L	4V	ABS/TCS	✓	✓	✓	✓	
2003	Sable	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Sable	3.0L	4V	EATC	✓	✓	✓	✓	
2003	Sable	3.0L	4V	GEM	✓	✓	✓	✓	0203
2003	Sable	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Sable	3.0L	4V	RCM	✓	✓	✓	✓	
2003	Sable	3.0L	FFV	ABS/TCS	✓	✓	✓	✓	
2003	Sable	3.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
2003	Sable	3.0L	FFV	EATC	✓	✓	✓	✓	
2003	Sable	3.0L	FFV	GEM	✓	✓	✓	✓	0203
2003	Sable	3.0L	FFV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Sable	3.0L	FFV	RCM	✓	✓	✓	✓	
2004	Sable	3.0L	2V	ABS	✓	✓	✓	✓	0008
2004	Sable	3.0L	2V	EATC	✓	✓	✓	✓	
2004	Sable	3.0L	2V	GEM	✓	✓	✓	✓	0203
2004	Sable	3.0L	2V	IC	✓	✓	✓	✓	
2004	Sable	3.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Sable	3.0L	2V	RCM	✓	✓	✓	✓	000C
2004	Sable	3.0L	4V	ABS	✓	✓	✓	✓	0008
2004	Sable	3.0L	4V	EATC	✓	✓	✓	✓	
2004	Sable	3.0L	4V	GEM	✓	✓	✓	✓	0203
2004	Sable	3.0L	4V	IC	✓	✓	✓	✓	
2004	Sable	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Sable	3.0L	4V	RCM	✓	✓	✓	✓	000C
2005	Sable	3.0L	2V	ABS	✓	✓	✓	✓	0008
2005	Sable	3.0L	2V	EATC	✓	✓	✓	✓	
2005	Sable	3.0L	2V	GEM	✓	✓	✓	✓	0203
2005	Sable	3.0L	2V	IC	✓	✓	✓	✓	0005
2005	Sable	3.0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Sable	3.0L	2V	RCM	✓	✓	✓	✓	000C
2005	Sable	3.0L	4V	ABS	✓	✓	✓	✓	0008
2005	Sable	3.0L	4V	EATC	✓	✓	✓	✓	
2005	Sable	3.0L	4V	GEM	✓	✓	✓	✓	0203
2005	Sable	3.0L	4V	IC	✓	✓	✓	✓	0005
2005	Sable	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Sable	3.0L	4V	RCM	✓	✓	✓	✓	000C
2008	Sable	3.5L	4V	4X4	✓	✓	✓	✓	
2008	Sable	3.5L	4V	ABS	✓	✓	✓	✓	0008
2008	Sable	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Sable	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Sable	3.5L	4V	DSM	✓	✓	✓	✓	
2008	Sable	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2008	Sable	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042, 0203
2008	Sable	3.5L	4V	HVAC	✓	✓	✓	✓	
2008	Sable	3.5L	4V	IC	✓	✓	✓	✓	
2008	Sable	3.5L	4V	OCSM	✓	✓	✓	✓	000C
2008	Sable	3.5L	4V	PAM	✓	✓	✓	✓	006C
2008	Sable	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Sable	3.5L	4V	RCM	✓	✓	✓	✓	
2008	Sable	3.5L	4V	RETM	✓	✓	✓	✓	
2008	Sable	3.5L	4V	SDARS	✓	✓	✓	✓	
2008	Sable	3.5L	4V	SECM	✓	✓	✓	✓	
2009	Sable	3.5L	4V	4X4	✓	✓	✓	✓	
2009	Sable	3.5L	4V	ABS	✓	✓	✓	✓	0008
2009	Sable	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Sable	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Sable	3.5L	4V	DSM	✓	✓	✓	✓	
2009	Sable	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Sable	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042, 0203
2009	Sable	3.5L	4V	HVAC	✓	✓	✓	✓	
2009	Sable	3.5L	4V	IC	✓	✓	✓	✓	
2009	Sable	3.5L	4V	OCSM	✓	✓	✓	✓	000C
2009	Sable	3.5L	4V	PAM	✓	✓	✓	✓	006C
2009	Sable	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Sable	3.5L	4V	RCM	✓	✓	✓	✓	
2009	Sable	3.5L	4V	RETM	✓	✓	✓	✓	
2009	Sable	3.5L	4V	SDARS	✓	✓	✓	✓	
2009	Sable	3.5L	4V	SECM	✓	✓	✓	✓	
2003.5	Street Ka	1.6L	DURATEC 8V	ABS/TCS	✓	✓	✓	✓	
2003.5	Street Ka	1.6L	DURATEC 8V	CSM	✓	✓	✓	✓	
2003.5	Street Ka	1.6L	DURATEC 8V	ECS	✓	✓	✓	✓	
2003.5	Street Ka	1.6L	DURATEC 8V	GEM	✓	✓	✓	✓	
2003.5	Street Ka	1.6L	DURATEC 8V	PCM	✓	✓	✓	✓	0025
2004	TITAN (Isuzu OEM)	3.1L	4JG2	PCM	✓	✓	✓	✓	
2004	TITAN (Isuzu OEM)	3.1L	4JG2 LPG	PCM	✓	✓	✓	✓	
2004	TITAN (Isuzu OEM)	4.3L	4HF1 CNG	PCM	✓	✓	✓	✓	0149
2004	TITAN (Isuzu OEM)	4.6L	4HG1 LPG	PCM	✓	✓	✓	✓	0149
2004	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	PCM	✓	✓	✓	✓	
2004	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	TCM	✓	✓	✓	✓	
2004	TITAN (Isuzu OEM)	4.8L	4HL1	PCM	✓	✓	✓	✓	0149
2004	TITAN (Isuzu OEM)	4.8L	4HL1	TCM	✓	✓	✓	✓	
2004	TITAN (Isuzu OEM)	4.8L	4HL1 T	PCM	✓	✓	✓	✓	0149
2004	TITAN (Isuzu OEM)	4.8L	4HL1 T	TCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	3.0L	4J11 T	ABS	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	3.0L	4J11 T	GEM	✓	✓	✓	✓	

2007	TITAN (Isuzu OEM)	3.0L	4JJ1 T	PATS	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	3.0L	4JJ1 T	PCM	✓	✓	✓	✓	0149
2007	TITAN (Isuzu OEM)	3.0L	4JJ1 T	RCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	3.0L	4JJ1 T	TCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	ABS	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	GEM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	PCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	RCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	TCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	5.2L	4HK1 T	ABS	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	5.2L	4HK1 T	GEM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	5.2L	4HK1 T	PATS	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	5.2L	4HK1 T	PCM	✓	✓	✓	✓	0149
2007	TITAN (Isuzu OEM)	5.2L	4HK1 T	RCM	✓	✓	✓	✓	
2007	TITAN (Isuzu OEM)	5.2L	4HK1 T	TCM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	3.0L	4JJ1 T	ABS	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	3.0L	4JJ1 T	GEM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	3.0L	4JJ1 T	PATS	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	3.0L	4JJ1 T	PCM	✓	✓	✓	✓	0149
2011	TITAN (Isuzu OEM)	3.0L	4JJ1 T	RCM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	3.0L	4JJ1 T	TCM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	ABS	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	GEM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	PCM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	RCM	✓	✓	✓	✓	
2011	TITAN (Isuzu OEM)	4.6L	4HV1 CNG	TCM	✓	✓	✓	✓	
1996	Taurus	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
1996	Taurus	3.0L	4V	GEM	✓	✓	✓	✓	
1996	Taurus	3.0L	4V	IAB	✓	✓	✓	✓	
1996	Taurus	3.0L	4V	PATS	✓	✓	✓	✓	
1996	Taurus	3.0L	4V	PCM	✓	✓	✓	✓	0025
1996	Taurus	3.0L	4V	RAP	✓	✓	✓	✓	
1996	Taurus	3.0L	4V	RCC	✓	✓	✓	✓	
1996	Taurus	3.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
1996	Taurus	3.0L	FFV	GEM	✓	✓	✓	✓	
1996	Taurus	3.0L	FFV	IAB	✓	✓	✓	✓	
1996	Taurus	3.0L	FFV	PATS	✓	✓	✓	✓	
1996	Taurus	3.0L	FFV	PCM	✓	✓	✓	✓	0025
1996	Taurus	3.0L	FFV	RAP	✓	✓	✓	✓	
1996	Taurus	3.0L	FFV	RCC	✓	✓	✓	✓	
1996	Taurus	3.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1996	Taurus	3.0L	Other	GEM	✓	✓	✓	✓	
1996	Taurus	3.0L	Other	IAB	✓	✓	✓	✓	
1996	Taurus	3.0L	Other	PATS	✓	✓	✓	✓	
1996	Taurus	3.0L	Other	PCM	✓	✓	✓	✓	0025
1996	Taurus	3.0L	Other	RAP	✓	✓	✓	✓	
1996	Taurus	3.0L	Other	RCC	✓	✓	✓	✓	
1996	Taurus	3.4L	SHO	ABS/TCS	✓	✓	✓	✓	0008
1996	Taurus	3.4L	SHO	GEM	✓	✓	✓	✓	
1996	Taurus	3.4L	SHO	IAB	✓	✓	✓	✓	
1996	Taurus	3.4L	SHO	PATS	✓	✓	✓	✓	
1996	Taurus	3.4L	SHO	PCM	✓	✓	✓	✓	0025
1996	Taurus	3.4L	SHO	RAP	✓	✓	✓	✓	
1996	Taurus	3.4L	SHO	RCC	✓	✓	✓	✓	
1996	Taurus	3.4L	SHO	SARC	✓	✓	✓	✓	
1997	Taurus	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008
1997	Taurus	3.0L	4V	GEM	✓	✓	✓	✓	0203
1997	Taurus	3.0L	4V	IAB	✓	✓	✓	✓	
1997	Taurus	3.0L	4V	PATS	✓	✓	✓	✓	
1997	Taurus	3.0L	4V	PCM	✓	✓	✓	✓	0025
1997	Taurus	3.0L	4V	RAP	✓	✓	✓	✓	
1997	Taurus	3.0L	4V	RCC	✓	✓	✓	✓	
1997	Taurus	3.0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
1997	Taurus	3.0L	FFV	GEM	✓	✓	✓	✓	
1997	Taurus	3.0L	FFV	IAB	✓	✓	✓	✓	
1997	Taurus	3.0L	FFV	PATS	✓	✓	✓	✓	
1997	Taurus	3.0L	FFV	PCM	✓	✓	✓	✓	0025
1997	Taurus	3.0L	FFV	RAP	✓	✓	✓	✓	
1997	Taurus	3.0L	FFV	RCC	✓	✓	✓	✓	
1997	Taurus	3.0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Taurus	3.0L	Other	GEM	✓	✓	✓	✓	0203
1997	Taurus	3.0L	Other	IAB	✓	✓	✓	✓	
1997	Taurus	3.0L	Other	PATS	✓	✓	✓	✓	
1997	Taurus	3.0L	Other	PCM	✓	✓	✓	✓	0025
1997	Taurus	3.0L	Other	RAP	✓	✓	✓	✓	
1997	Taurus	3.0L	Other	RCC	✓	✓	✓	✓	
1997	Taurus	3.4L	Other	ABS/TCS	✓	✓	✓	✓	0008
1997	Taurus	3.4L	Other	GEM	✓	✓	✓	✓	0203
1997	Taurus	3.4L	Other	PATS	✓	✓	✓	✓	
1997	Taurus	3.4L	Other	PCM	✓	✓	✓	✓	0025
1997	Taurus	3.4L	SHO	ABS/TCS	✓	✓	✓	✓	0008
1997	Taurus	3.4L	SHO	GEM	✓	✓	✓	✓	
1997	Taurus	3.4L	SHO	IAB	✓	✓	✓	✓	
1997	Taurus	3.4L	SHO	PATS	✓	✓	✓	✓	
1997	Taurus	3.4L	SHO	PCM	✓	✓	✓	✓	0025
1997	Taurus	3.4L	SHO	RAP	✓	✓	✓	✓	
1997	Taurus	3.4L	SHO	RCC	✓	✓	✓	✓	
1997	Taurus	3.4L	SHO	SARC	✓	✓	✓	✓	
1998	Taurus	3.0L	4V	ABS/TCS	✓	✓	✓	✓	0008

1998	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
1998	Taurus	3. 0L	4V	IAB	✓	✓	✓	✓	
1998	Taurus	3. 0L	4V	PATS	✓	✓	✓	✓	
1998	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025
1998	Taurus	3. 0L	4V	RAP	✓	✓	✓	✓	
1998	Taurus	3. 0L	4V	RCC	✓	✓	✓	✓	
1998	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
1998	Taurus	3. 0L	FFV	GEM	✓	✓	✓	✓	
1998	Taurus	3. 0L	FFV	IAB	✓	✓	✓	✓	
1998	Taurus	3. 0L	FFV	PATS	✓	✓	✓	✓	
1998	Taurus	3. 0L	FFV	PCM	✓	✓	✓	✓	0025
1998	Taurus	3. 0L	FFV	RAP	✓	✓	✓	✓	
1998	Taurus	3. 0L	FFV	RCC	✓	✓	✓	✓	
1998	Taurus	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1998	Taurus	3. 0L	Other	GEM	✓	✓	✓	✓	0203
1998	Taurus	3. 0L	Other	IAB	✓	✓	✓	✓	
1998	Taurus	3. 0L	Other	PATS	✓	✓	✓	✓	
1998	Taurus	3. 0L	Other	PCM	✓	✓	✓	✓	0025
1998	Taurus	3. 0L	Other	RAP	✓	✓	✓	✓	
1998	Taurus	3. 0L	Other	RAP	✓	✓	✓	✓	0005, F044
1998	Taurus	3. 0L	Other	RCC	✓	✓	✓	✓	
1998	Taurus	3. 4L	SHO	ABS/TCS	✓	✓	✓	✓	0008
1998	Taurus	3. 4L	SHO	GEM	✓	✓	✓	✓	
1998	Taurus	3. 4L	SHO	IAB	✓	✓	✓	✓	
1998	Taurus	3. 4L	SHO	PATS	✓	✓	✓	✓	
1998	Taurus	3. 4L	SHO	PCM	✓	✓	✓	✓	0025
1998	Taurus	3. 4L	SHO	RAP	✓	✓	✓	✓	
1998	Taurus	3. 4L	SHO	RCC	✓	✓	✓	✓	
1998	Taurus	3. 4L	SHO	SARC	✓	✓	✓	✓	
1999	Taurus	3. 0L	4V	ABS/TCS	✓	✓	✓	✓	0008
1999	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
1999	Taurus	3. 0L	4V	IAB	✓	✓	✓	✓	
1999	Taurus	3. 0L	4V	PATS	✓	✓	✓	✓	
1999	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025
1999	Taurus	3. 0L	4V	RAP	✓	✓	✓	✓	
1999	Taurus	3. 0L	4V	RCC	✓	✓	✓	✓	
1999	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
1999	Taurus	3. 0L	FFV	GEM	✓	✓	✓	✓	
1999	Taurus	3. 0L	FFV	IAB	✓	✓	✓	✓	
1999	Taurus	3. 0L	FFV	PATS	✓	✓	✓	✓	
1999	Taurus	3. 0L	FFV	PCM	✓	✓	✓	✓	0025
1999	Taurus	3. 0L	FFV	RAP	✓	✓	✓	✓	
1999	Taurus	3. 0L	FFV	RCC	✓	✓	✓	✓	
1999	Taurus	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
1999	Taurus	3. 0L	Other	GEM	✓	✓	✓	✓	0203
1999	Taurus	3. 0L	Other	IAB	✓	✓	✓	✓	
1999	Taurus	3. 0L	Other	PATS	✓	✓	✓	✓	
1999	Taurus	3. 0L	Other	PCM	✓	✓	✓	✓	0025
1999	Taurus	3. 0L	Other	RAP	✓	✓	✓	✓	
1999	Taurus	3. 0L	Other	RCC	✓	✓	✓	✓	
1999	Taurus	3. 4L	SHO	ABS/TCS	✓	✓	✓	✓	0008
1999	Taurus	3. 4L	SHO	PATS	✓	✓	✓	✓	
1999	Taurus	3. 4L	SHO	PCM	✓	✓	✓	✓	0025
1999	Taurus	3. 4L	SHO	RAP	✓	✓	✓	✓	
1999	Taurus	3. 4L	SHO	RCC	✓	✓	✓	✓	
2000	Taurus	3. 0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2000	Taurus	3. 0L	4V	EATC	✓	✓	✓	✓	
2000	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
2000	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Taurus	3. 0L	4V	RCM	✓	✓	✓	✓	
2000	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
2000	Taurus	3. 0L	FFV	EATC	✓	✓	✓	✓	
2000	Taurus	3. 0L	FFV	GEM	✓	✓	✓	✓	0203
2000	Taurus	3. 0L	FFV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Taurus	3. 0L	FFV	RCM	✓	✓	✓	✓	
2000	Taurus	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2000	Taurus	3. 0L	Other	EATC	✓	✓	✓	✓	
2000	Taurus	3. 0L	Other	GEM	✓	✓	✓	✓	0203
2000	Taurus	3. 0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Taurus	3. 0L	Other	RCM	✓	✓	✓	✓	
2002	Taurus	3. 0L	4V	ABS/TCS	✓	✓	✓	✓	
2002	Taurus	3. 0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2002	Taurus	3. 0L	4V	EATC	✓	✓	✓	✓	
2002	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
2002	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Taurus	3. 0L	4V	RCM	✓	✓	✓	✓	
2002	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	
2002	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
2002	Taurus	3. 0L	FFV	EATC	✓	✓	✓	✓	
2002	Taurus	3. 0L	FFV	GEM	✓	✓	✓	✓	0203
2002	Taurus	3. 0L	FFV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Taurus	3. 0L	FFV	RCM	✓	✓	✓	✓	
2002	Taurus	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	
2002	Taurus	3. 0L	Other	ABS/TCS	✓	✓	✓	✓	0008
2002	Taurus	3. 0L	Other	EATC	✓	✓	✓	✓	
2002	Taurus	3. 0L	Other	GEM	✓	✓	✓	✓	0203
2002	Taurus	3. 0L	Other	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Taurus	3. 0L	Other	RCM	✓	✓	✓	✓	
2003	Taurus	3. 0L	2V	ABS/TCS	✓	✓	✓	✓	

2003	Taurus	3. 0L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	Taurus	3. 0L	2V	EATC	✓	✓	✓		
2003	Taurus	3. 0L	2V	GEM	✓	✓	✓	✓	0203
2003	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Taurus	3. 0L	2V	RCM	✓	✓	✓		
2003	Taurus	3. 0L	4V	ABS/TCS	✓	✓	✓	✓	
2003	Taurus	3. 0L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Taurus	3. 0L	4V	EATC	✓	✓	✓		
2003	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
2003	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Taurus	3. 0L	4V	RCM	✓	✓	✓		
2003	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	
2003	Taurus	3. 0L	FFV	ABS/TCS	✓	✓	✓	✓	0008
2003	Taurus	3. 0L	FFV	EATC	✓	✓	✓		
2003	Taurus	3. 0L	FFV	GEM	✓	✓	✓	✓	0203
2003	Taurus	3. 0L	FFV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Taurus	3. 0L	FFV	RCM	✓	✓	✓		
2004	Taurus	3. 0L	2V	ABS	✓	✓	✓	✓	0008
2004	Taurus	3. 0L	2V	EATC	✓	✓	✓	✓	
2004	Taurus	3. 0L	2V	GEM	✓	✓	✓	✓	0203
2004	Taurus	3. 0L	2V	IC	✓	✓	✓	✓	
2004	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	
2004	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Taurus	3. 0L	2V	RCM	✓	✓	✓	✓	000C
2004	Taurus	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2004	Taurus	3. 0L	4V	EATC	✓	✓	✓	✓	
2004	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
2004	Taurus	3. 0L	4V	IC	✓	✓	✓	✓	
2004	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	
2004	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Taurus	3. 0L	4V	RCM	✓	✓	✓	✓	000C
2005	Taurus	3. 0L	2V	ABS	✓	✓	✓	✓	0008
2005	Taurus	3. 0L	2V	EATC	✓	✓	✓	✓	
2005	Taurus	3. 0L	2V	GEM	✓	✓	✓	✓	0203
2005	Taurus	3. 0L	2V	IC	✓	✓	✓	✓	0005
2005	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	
2005	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Taurus	3. 0L	2V	RCM	✓	✓	✓	✓	000C
2005	Taurus	3. 0L	4V	ABS	✓	✓	✓	✓	0008
2005	Taurus	3. 0L	4V	EATC	✓	✓	✓	✓	
2005	Taurus	3. 0L	4V	GEM	✓	✓	✓	✓	0203
2005	Taurus	3. 0L	4V	IC	✓	✓	✓	✓	0005
2005	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	
2005	Taurus	3. 0L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Taurus	3. 0L	4V	RCM	✓	✓	✓	✓	000C
2006	Taurus	3. 0L	2V	ABS	✓	✓	✓	✓	0008
2006	Taurus	3. 0L	2V	EATC	✓	✓	✓	✓	
2006	Taurus	3. 0L	2V	GEM	✓	✓	✓	✓	0203
2006	Taurus	3. 0L	2V	IC	✓	✓	✓	✓	0005
2006	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	
2006	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Taurus	3. 0L	2V	RCM	✓	✓	✓	✓	000C
2007	Taurus	3. 0L	2V	ABS	✓	✓	✓	✓	0008
2007	Taurus	3. 0L	2V	EATC	✓	✓	✓	✓	
2007	Taurus	3. 0L	2V	GEM	✓	✓	✓	✓	0203
2007	Taurus	3. 0L	2V	IC	✓	✓	✓	✓	0005
2007	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Taurus	3. 0L	2V	PCM	✓	✓	✓	✓	0203
2007	Taurus	3. 0L	2V	RCM	✓	✓	✓	✓	000C
2008	Taurus	3. 5L	4V	4X4	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	ABS	✓	✓	✓	✓	0008
2008	Taurus	3. 5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Taurus	3. 5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Taurus	3. 5L	4V	DSM	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2008	Taurus	3. 5L	4V	GEM / SJB	✓	✓	✓	✓	0042, 0203
2008	Taurus	3. 5L	4V	HVAC	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	IC	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	OCSM	✓	✓	✓	✓	000C
2008	Taurus	3. 5L	4V	PAM	✓	✓	✓	✓	006C
2008	Taurus	3. 5L	4V	PCM	✓	✓	✓	✓	0019, 001C
2008	Taurus	3. 5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Taurus	3. 5L	4V	RCM	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	RETN	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	SDARS	✓	✓	✓	✓	
2008	Taurus	3. 5L	4V	SECM	✓	✓	✓	✓	
2009	Taurus	3. 5L	4V	4X4	✓	✓	✓	✓	
2009	Taurus	3. 5L	4V	ABS	✓	✓	✓	✓	0008
2009	Taurus	3. 5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Taurus	3. 5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Taurus	3. 5L	4V	DSM	✓	✓	✓	✓	
2009	Taurus	3. 5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Taurus	3. 5L	4V	GEM / SJB	✓	✓	✓	✓	0042, 0203
2009	Taurus	3. 5L	4V	HVAC	✓	✓	✓	✓	
2009	Taurus	3. 5L	4V	IC	✓	✓	✓	✓	
2009	Taurus	3. 5L	4V	OCSM	✓	✓	✓	✓	000C
2009	Taurus	3. 5L	4V	PAM	✓	✓	✓	✓	006C
2009	Taurus	3. 5L	4V	PCM	✓	✓	✓	✓	0019, 001C

2009	Taurus	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Taurus	3.5L	4V	RCM	✓	✓	✓	✓	
2009	Taurus	3.5L	4V	RETM	✓	✓	✓	✓	
2009	Taurus	3.5L	4V	SDARS	✓	✓	✓	✓	
2009	Taurus	3.5L	4V	SECM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	4X4	✓	✓	✓	✓	0108
2010	Taurus	3.5L	4V	ABS	✓	✓	✓	✓	0008
2010	Taurus	3.5L	4V	ACM	✓	✓	✓	✓	0005, 0017, 0018
2010	Taurus	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Taurus	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Taurus	3.5L	4V	C-CM	✓	✓	✓	✓	0046
2010	Taurus	3.5L	4V	DCSM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	DDM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	DSM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	DSP	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	FCIM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	FCIM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	FDIM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Taurus	3.5L	4V	GPSM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	HCM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	HCM-2	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	HUD	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	HVAC	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	ILCM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	IPC	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 006D
2010	Taurus	3.5L	4V	PAM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	PCM	✓	✓	✓	✓	0025
2010	Taurus	3.5L	4V	PSCM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	RCM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	RETM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	RFA	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	SASM	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	SOD-L	✓	✓	✓	✓	
2010	Taurus	3.5L	4V	SOD-R	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019, 001C
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	

2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2010	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	4X4	✓	✓	✓	✓	0108
2011	Taurus	3.5L	4V	ABS	✓	✓	✓	✓	0008
2011	Taurus	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Taurus	3.5L	4V	ACM	✓	✓	✓	✓	0018
2011	Taurus	3.5L	4V	APIM	✓	✓	✓	✓	0019
2011	Taurus	3.5L	4V	C-CM	✓	✓	✓	✓	0046
2011	Taurus	3.5L	4V	DCSM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	DDM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	DSM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	DSP	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	FCIM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	FCIM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	FDIM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Taurus	3.5L	4V	GPSM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	HCM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	HCM-2	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	HUD	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	HVAC	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	ILCM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	IPC	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	OCSM	✓	✓	✓	✓	000C
2011	Taurus	3.5L	4V	PAM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	PCM	✓	✓	✓	✓	000C, 000C, 0025, 0028, 0031, 0033
2011	Taurus	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Taurus	3.5L	4V	PSCM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	RCM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	RETM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	RFA	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	SASM	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	SOD-L	✓	✓	✓	✓	
2011	Taurus	3.5L	4V	SOD-R	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019

2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FDIM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ILCM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 000C, 0017, 0018
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2011	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	4X4	✓	✓	✓	✓	0108
2012	Taurus	3.5L	4V	ABS	✓	✓	✓	✓	0008
2012	Taurus	3.5L	4V	ACM	✓	✓	✓	✓	0018
2012	Taurus	3.5L	4V	APIM	✓	✓	✓	✓	0019
2012	Taurus	3.5L	4V	C-CM	✓	✓	✓	✓	0046
2012	Taurus	3.5L	4V	DCSM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	DDM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	DSM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	DSP	✓	✓	✓	✓	

2012	Taurus	3.5L	4V	FCIM	✓	✓	✓		
2012	Taurus	3.5L	4V	FCIM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	FDIM	✓	✓	✓		
2012	Taurus	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Taurus	3.5L	4V	GPSM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	HCM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	HCM-2	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	HUD	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	HVAC	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	IHCM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	IPC	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	OCSM	✓	✓	✓	✓	000C
2012	Taurus	3.5L	4V	PAM	✓	✓	✓		
2012	Taurus	3.5L	4V	PCM	✓	✓	✓	✓	000C, 000C, 0025, 0028, 0031, 0033
2012	Taurus	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2012	Taurus	3.5L	4V	PSCM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	RCM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	RETM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	RFA	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	SASM	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	SOD-L	✓	✓	✓	✓	
2012	Taurus	3.5L	4V	SOD-R	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	4X4	✓	✓	✓	✓	0108
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0008
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017, 0018
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0018
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓		
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	FDIM	✓	✓	✓		
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GEM / SJB	✓	✓	✓	✓	0042
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HCM-2	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IHCM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C

2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓		
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 000C, 0017, 0018
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0067
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RETM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2012	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2012	Taurus	Other	Other	4X4	✓	✓	✓	✓	
2012	Taurus	Other	Other	ABS	✓	✓	✓	✓	
2012	Taurus	Other	Other	ACM	✓	✓	✓	✓	
2012	Taurus	Other	Other	APIM	✓	✓	✓	✓	
2012	Taurus	Other	Other	C-CM	✓	✓	✓	✓	
2012	Taurus	Other	Other	DCSM	✓	✓	✓	✓	
2012	Taurus	Other	Other	DDM	✓	✓	✓	✓	
2012	Taurus	Other	Other	DSM	✓	✓	✓	✓	
2012	Taurus	Other	Other	DSP	✓	✓	✓	✓	
2012	Taurus	Other	Other	FCIM	✓	✓	✓	✓	
2012	Taurus	Other	Other	FCIM	✓	✓	✓	✓	
2012	Taurus	Other	Other	FDIM	✓	✓	✓	✓	
2012	Taurus	Other	Other	GEM / SJB	✓	✓	✓	✓	0042
2012	Taurus	Other	Other	GPSM	✓	✓	✓	✓	
2012	Taurus	Other	Other	HCM	✓	✓	✓	✓	
2012	Taurus	Other	Other	HCM-2	✓	✓	✓	✓	
2012	Taurus	Other	Other	HUD	✓	✓	✓	✓	
2012	Taurus	Other	Other	HVAC	✓	✓	✓	✓	
2012	Taurus	Other	Other	ILCM	✓	✓	✓	✓	
2012	Taurus	Other	Other	IPC	✓	✓	✓	✓	
2012	Taurus	Other	Other	OCSM	✓	✓	✓	✓	
2012	Taurus	Other	Other	PAM	✓	✓	✓	✓	
2012	Taurus	Other	Other	PCM	✓	✓	✓	✓	
2012	Taurus	Other	Other	PSCM	✓	✓	✓	✓	
2012	Taurus	Other	Other	RCM	✓	✓	✓	✓	
2012	Taurus	Other	Other	RETM	✓	✓	✓	✓	
2012	Taurus	Other	Other	RFA	✓	✓	✓	✓	
2012	Taurus	Other	Other	SASM	✓	✓	✓	✓	
2012	Taurus	Other	Other	SOD-L	✓	✓	✓	✓	
2012	Taurus	Other	Other	SOD-R	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0018
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	

2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 0015, 0018, 0028, 0031, 0033, 0046, 0067, 0095
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 0015, 0018, 0028, 0031, 0033, 0046, 0067, 0095, 0108
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0018
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	

2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C, 0015
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 0015, 0018, 0028, 0031, 0033, 0046, 0067, 0095, 0108
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2013	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	ABS	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	ACM	✓	✓	✓	✓	0018
2013	Taurus	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	0042, 00D4, 00D5, 00FE
2013	Taurus	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Taurus	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	DDM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	FCD1M	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	GFM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	HCM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	HSWM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	IPC	✓	✓	✓	✓	

2013	Taurus	3.5L	TiVCT	IPM-A	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C, 0015
2013	Taurus	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	PCM	✓	✓	✓	✓	000C, 0015, 0018, 0025, 0028, 0031, 0033, 0046, 0067, 0095, 0108
2013	Taurus	3.5L	TiVCT	PCM	✓	✓	✓	✓	000C, 0015, 0018, 0028, 0031, 0033, 0046, 0067, 0095, 0108
2013	Taurus	3.5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0067, 0095, 0108
2013	Taurus	3.5L	TiVCT	PCM	✓	✓	✓	✓	0028, 0031, 0033, 0067, 0095, 0108
2013	Taurus	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	RACM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Taurus	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	ACM	✓	✓	✓	✓	0018
2013	Taurus	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE
2013	Taurus	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2013	Taurus	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	GFM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2013	Taurus	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	PCM	✓	✓	✓	✓	000C, 0025, 0028, 0031, 0033, 0046, 00D4, 00D5, 00FE
2013	Taurus	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2013	Taurus	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2013	Taurus	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	

2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 0046, 00D4, 00D5, 00FE, 0112, 013E
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Taurus	2.0L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	C-CM	✓	✓	✓	✓	0046
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DCSM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	DSP	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GFM	✓	✓	✓	✓	

2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HSWM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HUD	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	IPM-A	✓	✓	✓	✓	013E
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	000C, 0046, 00D4, 00D5, 00FE, 0112, 013E
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RACM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RFA	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	RTM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SCCM	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-L	✓	✓	✓	✓	
2014	Taurus	3.5L	EcoBoost – Gas Turbocharged Direct Injection	SOD-R	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	ABS	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	ACM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	APIM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112
2014	Taurus	3.5L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Taurus	3.5L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	DDM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	DSM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	DSP	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	GFM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	HSWM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	HUD	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	IPC	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	Taurus	3.5L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Taurus	3.5L	TiVCT	PAM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	PCM	✓	✓	✓	✓	000C, 0046, 00D4, 00D5, 00FE, 0112, 013E
2014	Taurus	3.5L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 0108
2014	Taurus	3.5L	TiVCT	PSCM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	RACM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	RCM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	RFA	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	RTM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Taurus	3.5L	TiVCT	SOD-R	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	ABS	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	ACM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	APIM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 00FE, 0112

2014	Taurus	3.7L	TiVCT	C-CM	✓	✓	✓	✓	0046
2014	Taurus	3.7L	TiVCT	DCSM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	DDM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	DSM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	DSP	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	FCDIM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	FCIM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	GFM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	GPSM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	HSWM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	HUD	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	HVAC	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	IPC	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	IPM-A	✓	✓	✓	✓	013E
2014	Taurus	3.7L	TiVCT	OCSM	✓	✓	✓	✓	000C
2014	Taurus	3.7L	TiVCT	PAM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	PCM	✓	✓	✓	✓	000C, 0046, 00D4, 00D5, 00FE, 0112, 013E
2014	Taurus	3.7L	TiVCT	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2014	Taurus	3.7L	TiVCT	PSCM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	RACM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	RCM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	RFA	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	RTM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	SCCM	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	SOD-L	✓	✓	✓	✓	
2014	Taurus	3.7L	TiVCT	SOD-R	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	4X4	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	ABS	✓	✓	✓	✓	0008
2008	Taurus X	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2008	Taurus X	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Taurus X	3.5L	4V	DSM	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2008	Taurus X	3.5L	4V	HVAC	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	IC	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	LTM	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	OCSM	✓	✓	✓	✓	000C
2008	Taurus X	3.5L	4V	PAM	✓	✓	✓	✓	006C
2008	Taurus X	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2008	Taurus X	3.5L	4V	RCM	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	RETM	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	SDARS	✓	✓	✓	✓	
2008	Taurus X	3.5L	4V	SECM	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	4X4	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	ABS	✓	✓	✓	✓	0008
2009	Taurus X	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Taurus X	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Taurus X	3.5L	4V	DSM	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2009	Taurus X	3.5L	4V	HVAC	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	IC	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	LTM	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	OCSM	✓	✓	✓	✓	000C
2009	Taurus X	3.5L	4V	PAM	✓	✓	✓	✓	006C
2009	Taurus X	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2009	Taurus X	3.5L	4V	RCM	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	RETM	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	SDARS	✓	✓	✓	✓	
2009	Taurus X	3.5L	4V	SECM	✓	✓	✓	✓	
Other	Telstar	1.8L	Other	PCM	✓	✓	✓	✓	
Other	Telstar	2.0L	Other	PCM	✓	✓	✓	✓	
Other	Telstar	2.5L	Other	PCM	✓	✓	✓	✓	
2004	Territory	4.0L	DOHC VCT	ABS	✓	✓	✓	✓	0008, 0005
2004	Territory	4.0L	DOHC VCT	ABS/TCS	✓	✓	✓	✓	0008
2004	Territory	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2004	Territory	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0035, 0005, F002, F004, F005, F007, F008, F009, F00A, F011, F014, F015, F016, F00D, F010
2004	Territory	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0035, 0005, F002, F004, F005, F007, F008, F009, F00A, F011, F014, F015, F016, F010
2004	Territory	4.0L	DOHC VCT	HIM	✓	✓	✓	✓	003A, 0005
2004	Territory	4.0L	DOHC VCT	IC	✓	✓	✓	✓	005F, 0044, 0061, F00B, F00C, F00F
2004	Territory	4.0L	DOHC VCT	IC	✓	✓	✓	✓	005F, 0044, 0061, F00B, F00C, F00F, F017, F018
2004	Territory	4.0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2004	Territory	4.0L	DOHC VCT	PCM	✓	✓	✓	✓	003A, 0005, 0025
2004	Territory	4.0L	DOHC VCT	RCM	✓	✓	✓	✓	
2006	Territory	4.0L	DOHC VCT	ABS	✓	✓	✓	✓	0008, 0005
2006	Territory	4.0L	DOHC VCT	ACM	✓	✓	✓	✓	0040
2006	Territory	4.0L	DOHC VCT	BEM	✓	✓	✓	✓	0035, 0005, F002, F004, F005, F007, F008, F009, F00A, F011, F014, F015, F016, F00D, F010

2006	Territory	4. 0L	DOHC VCT	BEM	✓	✓	✓	✓	0035, 0005, F002, F004, F005, F007, F008, F009, F00A, F011, F014, F015, F016, F00D, F010
2006	Territory	4. 0L	DOHC VCT	HIM	✓	✓	✓	✓	003A, 0005
2006	Territory	4. 0L	DOHC VCT	IC	✓	✓	✓	✓	005F, 0044, 0061, F00B, F00F, F019
2006	Territory	4. 0L	DOHC VCT	PAM	✓	✓	✓	✓	0005
2006	Territory	4. 0L	DOHC VCT	PCM	✓	✓	✓	✓	003A, 0005, 0025
2006	Territory	4. 0L	DOHC VCT	RCM	✓	✓	✓	✓	
2006	Territory	4. 0L	DOHC VCT	TCM	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Territory	2 7L	Direct Injection -	ACM	✓	✓	✓	✓	0017
2011	Territory	2 7L	Direct Injection -	ACM	✓	✓	✓	✓	0017, 0005, F024
2011	Territory	2 7L	Direct Injection -	AWD#1	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	BEM	✓	✓	✓	✓	0005
2011	Territory	2 7L	Direct Injection -	BEM	✓	✓	✓	✓	0005, 0035
2011	Territory	2 7L	Direct Injection -	BEM	✓	✓	✓	✓	0035
2011	Territory	2 7L	Direct Injection -	FDIM	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	FDIM	✓	✓	✓	✓	0005
2011	Territory	2 7L	Direct Injection -	HIM	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	HIM	✓	✓	✓	✓	0005
2011	Territory	2 7L	Direct Injection -	IPC	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	IPC	✓	✓	✓	✓	F020
2011	Territory	2 7L	Direct Injection -	PAM	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	PAM	✓	✓	✓	✓	0005
2011	Territory	2 7L	Direct Injection -	PCM	✓	✓	✓	✓	0025
2011	Territory	2 7L	Direct Injection - Turbo	PCM	✓	✓	✓	✓	00BB, 009A, 0099, 00C1, 00B3, 00B2
2011	Territory	2 7L	Direct Injection -	PSCM	✓	✓	✓	✓	00CB, 00CC
2011	Territory	2 7L	Direct Injection -	RCM	✓	✓	✓	✓	
2011	Territory	2 7L	Direct Injection -	RCM	✓	✓	✓	✓	0005
2011	Territory	2 7L	Direct Injection -	TCM	✓	✓	✓	✓	
2011	Territory	4. 0L	DOHC VCT	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Territory	4. 0L	DOHC VCT	ACM	✓	✓	✓	✓	0017, F024
2011	Territory	4. 0L	DOHC VCT	BEM	✓	✓	✓	✓	0035
2011	Territory	4. 0L	DOHC VCT	FDIM	✓	✓	✓	✓	
2011	Territory	4. 0L	DOHC VCT	HIM	✓	✓	✓	✓	
2011	Territory	4. 0L	DOHC VCT	IPC	✓	✓	✓	✓	F020
2011	Territory	4. 0L	DOHC VCT	PAM	✓	✓	✓	✓	
2011	Territory	4. 0L	DOHC VCT	PCM	✓	✓	✓	✓	0025
2011	Territory	4. 0L	DOHC VCT	PSCM	✓	✓	✓	✓	00CB, 00CC
2011	Territory	4. 0L	DOHC VCT	RCM	✓	✓	✓	✓	
2011	Territory	4. 0L	DOHC VCT	TCM	✓	✓	✓	✓	
2011	Territory	Other	Other	ABS	✓	✓	✓	✓	00CA, 0008, 0012
2011	Territory	Other	Other	ACM	✓	✓	✓	✓	0017, 0005, F024
2011	Territory	Other	Other	BEM	✓	✓	✓	✓	0005
2011	Territory	Other	Other	FDIM	✓	✓	✓	✓	0005
2011	Territory	Other	Other	HIM	✓	✓	✓	✓	0005
2011	Territory	Other	Other	IPC	✓	✓	✓	✓	F020
2011	Territory	Other	Other	PAM	✓	✓	✓	✓	0005
2011	Territory	Other	Other	PSCM	✓	✓	✓	✓	00CB, 00CC
2011	Territory	Other	Other	RCM	✓	✓	✓	✓	0005
1994	Thunderbird	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1995	Thunderbird	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1996	Thunderbird	3. 8L	Other	PCM	✓	✓	✓	✓	0025
1996	Thunderbird	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1996	Thunderbird	4. 6L	Other	PCM	✓	✓	✓	✓	0025
1997	Thunderbird	3. 8L	Other	PCM	✓	✓	✓	✓	0025
1997	Thunderbird	4. 6L	2V	PCM	✓	✓	✓	✓	0025
2002	Thunderbird	3. 9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2002	Thunderbird	3. 9L	4V	ACM	✓	✓	✓	✓	
2002	Thunderbird	3. 9L	4V	DDM	✓	✓	✓	✓	
2002	Thunderbird	3. 9L	4V	EATC	✓	✓	✓	✓	
2002	Thunderbird	3. 9L	4V	GEM	✓	✓	✓	✓	
2002	Thunderbird	3. 9L	4V	HEC	✓	✓	✓	✓	
2002	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	0025
2002	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	0028, 0031, 0033, 00C7
2002	Thunderbird	3. 9L	4V	RCM	✓	✓	✓	✓	
2002	Thunderbird	3. 9L	4V	REM	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2003	Thunderbird	3. 9L	4V	ACM	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	DDM	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	EATC	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	GEM	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	HEC	✓	✓	✓	✓	00C7
2003	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Thunderbird	3. 9L	4V	RCM	✓	✓	✓	✓	
2003	Thunderbird	3. 9L	4V	REM	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2004	Thunderbird	3. 9L	4V	ACM	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	DDM	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	EATC	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	GEM	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	HEC	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	
2004	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Thunderbird	3. 9L	4V	RCM	✓	✓	✓	✓	

2004	Thunderbird	3. 9L	4V	RCM	✓	✓	✓	✓	000C
2004	Thunderbird	3. 9L	4V	REM	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	ABS/TCS	✓	✓	✓	✓	0008
2005	Thunderbird	3. 9L	4V	ACM	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	DDM	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	EATC	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	GEM	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	HEC	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Thunderbird	3. 9L	4V	RCM	✓	✓	✓	✓	
2005	Thunderbird	3. 9L	4V	REM	✓	✓	✓	✓	
2000	Titan	4. 0L	TF	PCM	✓	✓	✓	✓	
2002	Titan	4. 0L	TF	PCM	✓	✓	✓	✓	
1995	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1995	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
1995	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
1995	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
1995	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
1995	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1996	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1996	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
1996	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
1996	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
1996	Town Car	4. 6L	2V	IAB	✓	✓	✓	✓	
1996	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
1996	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1997	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1997	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
1997	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
1997	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
1997	Town Car	4. 6L	2V	IAB	✓	✓	✓	✓	
1997	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
1997	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1998	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1998	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	CPM	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	IAB	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	NGSC	✓	✓	✓	✓	
1998	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1998	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
1999	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	0005
1999	Town Car	4. 6L	2V	CPM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	0005
1999	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	0005
1999	Town Car	4. 6L	2V	NGSC	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025
1999	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	
1999	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2000	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008, 0008
2000	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	CPM	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	F044, F045
2000	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	F041
2000	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	F027, F042, F043
2000	Town Car	4. 6L	2V	NGSC	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	
2000	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2002	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008, 0008
2002	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	0005
2002	Town Car	4. 6L	2V	CPM	✓	✓	✓	✓	
2002	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	0005, F044, F045
2002	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	F041
2002	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2002	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
2002	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	0005, F027, F042, F043
2002	Town Car	4. 6L	2V	NGSC	✓	✓	✓	✓	
2002	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	000C, 0025, 0028, 0031, 0033
2002	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	
2002	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2002	Town Car	4. 6L	2V	RESCU	✓	✓	✓	✓	

2003	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2003	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	CPM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	NGSC	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2003	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	0013
2003	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2003	Town Car	4. 6L	2V	RESCU	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	ABS/TCS	✓	✓	✓	✓	0008
2004	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	0005, F044, F045
2004	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	F041
2004	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	0005, F042, F043
2004	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2004	Town Car	4. 6L	2V	NGSC	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2004	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2004	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	0005, 0013
2004	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2005	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0008
2005	Town Car	4. 6L	2V	ACM	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	HEC	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2005	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2005	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0008, 000C
2005	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2005	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	0013
2005	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2006	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0008
2006	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	IC	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2006	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0008, 000C
2006	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2006	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2006	Town Car	4. 6L	2V	RASM	✓	✓	✓	✓	0013
2006	Town Car	4. 6L	2V	RATC	✓	✓	✓	✓	
2006	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2007	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0008
2007	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	EATC	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	IC	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2007	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0008, 000C
2007	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2007	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2007	Town Car	4. 6L	2V	RATC	✓	✓	✓	✓	
2007	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2007	Town Car	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2008	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0008
2008	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	0042
2008	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	HVAC	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	IC	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	

2008	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2008	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0008, 000C, 0016
2008	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2008	Town Car	4. 6L	2V	RATC	✓	✓	✓	✓	
2008	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2008	Town Car	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2009	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0008
2009	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	0042
2009	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	HVAC	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	IC	✓	✓	✓	✓	0005
2009	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2009	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0005, 0008, 000C, 0016, 0042
2009	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0005, 0008, 000C, 0016, 0042, 00C5
2009	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2009	Town Car	4. 6L	2V	RATC	✓	✓	✓	✓	
2009	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2009	Town Car	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2010	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0008, F046
2010	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
2010	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	F041
2010	Town Car	4. 6L	2V	HVAC	✓	✓	✓	✓	
2010	Town Car	4. 6L	2V	IC	✓	✓	✓	✓	0005
2010	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	F042, F043
2010	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2010	Town Car	4. 6L	2V	MC	✓	✓	✓	✓	
2010	Town Car	4. 6L	2V	NAV	✓	✓	✓	✓	0016
2010	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2010	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0005, 0008, 000C, 0016, F046
2010	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2010	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033, 00C5
2010	Town Car	4. 6L	2V	RATC	✓	✓	✓	✓	
2010	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2010	Town Car	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
2011	Town Car	4. 6L	2V	ABS	✓	✓	✓	✓	0005, 0008, F046
2011	Town Car	4. 6L	2V	DDM	✓	✓	✓	✓	
2011	Town Car	4. 6L	2V	DSM	✓	✓	✓	✓	F041
2011	Town Car	4. 6L	2V	HVAC	✓	✓	✓	✓	
2011	Town Car	4. 6L	2V	IC	✓	✓	✓	✓	0005
2011	Town Car	4. 6L	2V	LCM	✓	✓	✓	✓	F042, F043
2011	Town Car	4. 6L	2V	LTM	✓	✓	✓	✓	
2011	Town Car	4. 6L	2V	PAM	✓	✓	✓	✓	
2011	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0005, 0008, 000C, F046
2011	Town Car	4. 6L	2V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Town Car	4. 6L	2V	RATC	✓	✓	✓	✓	
2011	Town Car	4. 6L	2V	RCM	✓	✓	✓	✓	000C
2011	Town Car	4. 6L	2V	VDM	✓	✓	✓	✓	0013, 0014
1996	Tracer	1. 9L	1. 4 PT-E SFI	ABS/TCS	✓	✓	✓	✓	
1996	Tracer	1. 9L	1. 4 PT-E SFI	PCM	✓	✓	✓	✓	0025
1996	Tracer	1. 9L	1. 4 PT-E SFI	RAP	✓	✓	✓	✓	
1997	Tracer	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
1997	Tracer	2. 0L	SPI	PCM	✓	✓	✓	✓	0025
1997	Tracer	2. 0L	SPI	RAP	✓	✓	✓	✓	
1998	Tracer	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
1998	Tracer	2. 0L	SPI	ECS	✓	✓	✓	✓	
1998	Tracer	2. 0L	SPI	PCM	✓	✓	✓	✓	0008, 0025
1998	Tracer	2. 0L	SPI	RAP	✓	✓	✓	✓	
1999	Tracer	2. 0L	SPI	ABS/TCS	✓	✓	✓	✓	0008
1999	Tracer	2. 0L	SPI	IAB	✓	✓	✓	✓	
1999	Tracer	2. 0L	SPI	PCM	✓	✓	✓	✓	0008, 0025
1999	Tracer	2. 0L	SPI	PCM	✓	✓	✓	✓	0025
1999	Tracer	2. 0L	SPI	RAP	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	00DD, 00E8
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	AWD#1	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	FCIM	✓	✓	✓	✓	

2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	GPSM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓	✓	00E5
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	IPM-B	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	PRB	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓		
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓	✓	00DD, 00E8
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓	✓	00CF
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	APIM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	AWD#1	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	011C
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	CCMii	✓	✓	✓	✓	00F9
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	FCIM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	GPSM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-A	✓	✓	✓	✓	00E5
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-B	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	PRB	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2014	Transit	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓		
2014	Transit	2. 2L	TDCi StgVI	ABS	✓	✓	✓		00DD, 00E8
2014	Transit	2. 2L	TDCi StgVI	ACM	✓	✓	✓		
2014	Transit	2. 2L	TDCi StgVI	AHCM	✓	✓	✓		00CF
2014	Transit	2. 2L	TDCi StgVI	APIM	✓	✓	✓		
2014	Transit	2. 2L	TDCi StgVI	AWD#1	✓	✓	✓		
2014	Transit	2. 2L	TDCi StgVI	BCMii	✓	✓	✓	✓	011C
2014	Transit	2. 2L	TDCi StgVI	CCMii	✓	✓	✓	✓	00F9
2014	Transit	2. 2L	TDCi StgVI	FCDIM	✓	✓	✓	✓	

2014	Transit	2.2L	TDCi StgVI	FCIM	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	GPSM	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	HCM	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	IPC	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	IPM-A	✓	✓	✓	✓	00E5
2014	Transit	2.2L	TDCi StgVI	IPM-B	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	PAM	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	PCM	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	PRB	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	RCM	✓	✓	✓	✓	00EF
2014	Transit	2.2L	TDCi StgVI	SASM	✓	✓	✓	✓	
2014	Transit	2.2L	TDCi StgVI	TRM	✓	✓	✓	✓	
2014	Transit	3.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0025, 0059, 0091, 009C, 009D, 009E, 009F, 00A0
2014	Transit	3.2L	Duratorq Turbo Diesel Common Rail Injection	RDCM#1	✓	✓	✓	✓	
2014	Transit	3.2L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓	
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PATS	✓	✓	✓	✓	
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1995	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓	
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1996	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓	
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PATS	✓	✓	✓	✓	
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1997	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓	
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1997.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓	
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1998	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	GSM	✓	✓	✓	✓	
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1998.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS	✓	✓	✓	✓	
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	ABS/TCS	✓	✓	✓	✓	
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	AFCM	✓	✓	✓	✓	
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	CSM	✓	✓	✓	✓	
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	
1999.5	Transit Connect	2.0L	2.0 DOHC SFI (8V)	PCM	✓	✓	✓	✓	0025
2000	Transit Connect	2.4L	DURATORQ DI	ABS/TCS	✓	✓	✓	✓	0008
2000	Transit Connect	2.4L	DURATORQ DI	CSM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	EPB	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	FFH	✓	✓	✓	✓	00CF
2000	Transit Connect	2.4L	DURATORQ DI	FIP	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	HEC	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	PAM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	PCM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	PCM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	RASM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	RCM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	RCM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	DURATORQ DI	TCM	✓	✓	✓	✓	003F
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2000	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	ABS/TCS	✓	✓	✓	✓	0008
2001	Transit Connect	2.0L	DURATORQ DI	CSM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	EPB	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	FFH	✓	✓	✓	✓	00CF

2001	Transit Connect	2.0L	DURATORQ DI	FIP	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	HEC	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	PAM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	PCM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	RASM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	RCM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	DURATORQ DI	TCM	✓	✓	✓	✓	003F
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	0008
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	FIP	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓		
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	RASM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	
2001	Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	TCM	✓	✓	✓	✓	003F
2001	Transit Connect	2.3L	DOHC SFI (16V)	ABS/TCS	✓	✓	✓	✓	0008
2001	Transit Connect	2.3L	DOHC SFI (16V)	GSM	✓	✓	✓	✓	
2001	Transit Connect	2.3L	DOHC SFI (16V)	HEC	✓	✓	✓	✓	
2001	Transit Connect	2.3L	DOHC SFI (16V)	PAM	✓	✓	✓	✓	
2001	Transit Connect	2.3L	DOHC SFI (16V)	PCM	✓	✓	✓	✓	0025
2001	Transit Connect	2.3L	DOHC SFI (16V)	RASM	✓	✓	✓	✓	
2001	Transit Connect	2.3L	DOHC SFI (16V)	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0053, 00DD, 00E3, 00E4, 00E8, 011F, 0135
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 00A6, 00A7, 00A8, 00A9, 00B0, 00B1, 00B5, 00B6, 00C0, 00C1, 00C2
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	ABS	✓	✓	✓	✓	0053, 00E3, 00E4, 00E8, 011F, 0135
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	ABS/TCS	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	FFH	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	IPC	✓	✓	✓	✓	F020
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	PCM	✓	✓	✓	✓	0090, 0098, 0099, 009A, 00B0, 00B1, 00B7, 00B9
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq Turbo Diesel_C ommon Rail Inj Stage V	SRM	✓	✓	✓	✓	

2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	ABS	✓	✓	✓	✓	0053, 00DD, 00E3, 00E4, 011F, 0135
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	FFH	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	IPC	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0098, 0099, 009A, 00B0, 00B1, 00B7, 00B9
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0008, 0053, 00DD, 00E3, 00E4, 00E8, 011F, 0135
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	ABS/TCS	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	FFH	✓	✓	✓	✓	00CF
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	IPC	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025, 00AC
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	2.3L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0053, 00DD, 00E3, 00E4, 00E8, 011F, 0135
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 00A6, 00A7, 00A8, 00A9, 00B0, 00B1, 00B5, 00B6, 00C0, 00C1, 00C2
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	TBM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0008, 0053, 00DD, 00E3, 00E4, 00E8, 011F, 0135
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 00A6, 00A7, 00A8, 00A9, 00B0, 00B1, 00B5, 00B6, 00C0, 00C1, 00C2
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common Rail Injection	ABS	✓	✓	✓	✓	0053, 00DD, 00E3, 00E4, 011F, 0135
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common Rail Injection	ABS/TCS	✓	✓	✓	✓	

2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common Rail Injection	ACM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common Rail Injection	BCMii	✓	✓	✓	✓	011C
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common Rail Injection	CSM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common Rail Injection	FFH	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common Rail Injection	IPC	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common Rail Injection	PAM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common Rail Injection	PCM	✓	✓	✓	✓	0090, 0098, 0099, 009A, 00B0, 00B1, 00B7, 00B9
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common Rail Injection	RCM	✓	✓	✓	✓	
2006.5	Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common Rail Injection	SRM	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0012
2010	Transit Connect	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2010	Transit Connect	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2010	Transit Connect	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2010	Transit Connect	2.0L	DURATEC-HE / I4	VSM	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0012
2011	Transit Connect	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2011	Transit Connect	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2011	Transit Connect	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2011	Transit Connect	2.0L	DURATEC-HE / I4	VSM	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicle	ABS	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicle	ABS	✓	✓	✓	✓	0012
2011	Transit Connect	28kWh	Battery Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicle	ACM	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicle	GEM / SJB	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicle	IC	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2011	Transit Connect	28kWh	Battery Electric Vehicle	PAM	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicle	PSCM	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicle	RCM	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicle	SRM	✓	✓	✓	✓	
2011	Transit Connect	28kWh	Battery Electric Vehicle	VSM	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	ABS	✓	✓	✓	✓	0012
2012	Transit Connect	2.0L	DURATEC-HE / I4	ACM	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	APIM	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	GEM / SJB	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	IC	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	OCSM	✓	✓	✓	✓	000C, 006D
2012	Transit Connect	2.0L	DURATEC-HE / I4	PAM	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	PCM	✓	✓	✓	✓	0025
2012	Transit Connect	2.0L	DURATEC-HE / I4	RCM	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	SRM	✓	✓	✓	✓	
2012	Transit Connect	2.0L	DURATEC-HE / I4	VSM	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicle	ABS	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicle	ABS	✓	✓	✓	✓	0012
2013	Transit Connect	28kWh	Battery Electric Vehicle	ACCM#2	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicle	ACM	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicle	APIM	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicle	GEM / SJB	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicle	IC	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicle	OCSM	✓	✓	✓	✓	000C
2013	Transit Connect	28kWh	Battery Electric Vehicle	PAM	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicle	PSCM	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicle	RCM	✓	✓	✓	✓	
2013	Transit Connect	28kWh	Battery Electric Vehicle	VSM	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	ABS	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	ACM	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	APIM	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	GEM / SJB	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	IC	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	OCSM	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	PAM	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	RCM	✓	✓	✓	✓	
2013	Transit Connect	Other	Other	VSM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012

2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	009A, 00BC, 0114
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CC
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2014	Transit Connect	1.0L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	ABS	✓	✓	✓		0012
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	ACM	✓	✓	✓		0017
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	AHCM	✓	✓	✓		00CF
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	APIM	✓	✓	✓		0019
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	BCMii	✓	✓	✓	✓	00D5, 0101
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	DDM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FCDIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FCIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	FDSM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	GPSM	✓	✓	✓	✓	

2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	HCM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	HVAC	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	IPC	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	IPM-B	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PAM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PCM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PDM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	PSCM	✓	✓	✓	✓	00CC
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	RCM	✓	✓	✓	✓	00EF
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	SASM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	TRM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ABS	✓	✓	✓	✓	0012
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	ACM	✓	✓	✓	✓	0017
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	AHCM	✓	✓	✓	✓	00CF
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	APIM	✓	✓	✓	✓	0019
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCM#1	✓	✓	✓	✓	00D4, 00D5, 0101, 020F
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	BCMii	✓	✓	✓	✓	00D5, 0101
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	DDM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCDIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FCIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	FDSM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	GPSM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HCM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	HVAC	✓	✓	✓		

2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	HVAC	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPC	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	IPM-B	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	OCSM	✓	✓	✓	✓	000C
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PAM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	0025
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PCM	✓	✓	✓	✓	00BC, 0108
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PDM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	PSCM	✓	✓	✓	✓	00CC
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	RCM	✓	✓	✓	✓	00EF
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	SASM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓		
2014	Transit Connect	1.6L	EcoBoost – Gas Turbocharged Direct Injection	TRM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	ABS	✓	✓	✓	✓	0012
2014	Transit Connect	1.6L	TDCi ECO III	ACM	✓	✓	✓	✓	0017
2014	Transit Connect	1.6L	TDCi ECO III	AHCM	✓	✓	✓	✓	00CF
2014	Transit Connect	1.6L	TDCi ECO III	APIM	✓	✓	✓	✓	0019
2014	Transit Connect	1.6L	TDCi ECO III	BCMii	✓	✓	✓	✓	00D5, 0101
2014	Transit Connect	1.6L	TDCi ECO III	DDM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	FCDIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	FCIM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	FDSM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	GPSM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	HCM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	HVAC	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	IPC	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	IPM-B	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	PAM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	PCM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	PDM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	PSCM	✓	✓	✓	✓	00CC
2014	Transit Connect	1.6L	TDCi ECO III	RCM	✓	✓	✓	✓	00EF
2014	Transit Connect	1.6L	TDCi ECO III	SASM	✓	✓	✓	✓	
2014	Transit Connect	1.6L	TDCi ECO III	TRM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	ABS	✓	✓	✓	✓	0012
2014	Transit Connect	2.5L	IVCT	ABS	✓	✓	✓	✓	0012
2014	Transit Connect	2.5L	IVCT	ACM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	APIM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	BCM#1	✓	✓	✓	✓	00D4, 00D5, 0101, 020F
2014	Transit Connect	2.5L	IVCT	DDM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	FCDIM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	FCIM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	GPSM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	HCM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	HVAC	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	IPC	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	IPM-B	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	OCSM	✓	✓	✓	✓	000C
2014	Transit Connect	2.5L	IVCT	PAM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	PCM	✓	✓	✓	✓	0025
2014	Transit Connect	2.5L	IVCT	PDM	✓	✓	✓	✓	
2014	Transit Connect	2.5L	IVCT	PSCM	✓	✓	✓	✓	

2014	Transit Connect	2.5L	IVCT	RCM	✓	✓	✓		
2014	Transit Connect	2.5L	IVCT	SASM	✓	✓	✓		
2014	Transit Connect	2.5L	IVCT	TRM	✓	✓	✓		
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	ABS	✓	✓	✓	✓	
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	ABS/TCS	✓	✓	✓	✓	
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	CSM	✓	✓	✓	✓	
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	PCM			✓	✓	
Other	Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	PCM	✓	✓	✓	✓	0025
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ECS	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	HEC	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ICU			✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	ABS/TCS	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	CSM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	ECS	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	FFH	✓	✓	✓	✓	00CF
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	FIP	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	HEC	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	PAM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Endura DI	PCM	✓	✓	✓	✓	0008, 0012, 0032
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	ABS/TCS	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	AFCM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	CSM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	ECS	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	FFH	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	FFH	✓	✓	✓	✓	00CF
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	HEC	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	PAM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	PCM	✓	✓	✓	✓	
2002.5	Transit Connect / Tourneo Connect	1.8L	Zetec	PCM	✓	✓	✓	✓	0025, 00CF
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS/TCS	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	CSM	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ECS	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0098, 0099, 00AB, 00AC, 00B4, 00C1
2007	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0029, 002B, 0054, 00D7, 00DD, 00E8
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	0029, 00E8
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	002B, 0054, 00D7, 00DD, 00E8
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	00E8
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	FFH	✓	✓	✓	✓	00CF
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	GEM	✓	✓	✓	✓	F02D, F030, F0A2
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	IC	✓	✓	✓	✓	F020

2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	006F, 0090, 0098, 0099, 00AB, 00AC, 00B4, 00C1
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	
2009.5	Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	SRM	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	ABS	✓	✓	✓	✓	00DD, 00E8
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	ACM	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	AHCM	✓	✓	✓	✓	00CF
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	APIM	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	BCMii	✓	✓	✓	✓	011C
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	CCMii	✓	✓	✓	✓	00F9
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	FCDIM	✓	✓	✓		
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	GPSM	✓	✓	✓		
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	HCM	✓	✓	✓		
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPC	✓	✓	✓		
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPM-A	✓	✓	✓		00E5
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	IPM-B	✓	✓	✓		
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	PAM	✓	✓	✓		
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	PCM	✓	✓	✓	✓	0092, 0098, 0099, 009A, 00B0, 00B1, 00B3, 00BC, 00BD, 00C1, 00C3, 00E7, 013B
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	PRB	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	RCM	✓	✓	✓	✓	00EF
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	SASM	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	TBC	✓	✓	✓	✓	
2012.75	V362	2.2L	Duratorq Turbo Diesel Common Rail Injection	TRM	✓	✓	✓		
Other	VX-1	1.4L	K14B	ABS	✓	✓	✓	✓	0212
Other	VX-1	1.4L	K14B	BCM#1	✓	✓	✓	✓	
Other	VX-1	1.4L	K14B	EPS	✓	✓	✓	✓	
Other	VX-1	1.4L	K14B	IC	✓	✓	✓	✓	
Other	VX-1	1.4L	K14B	PCM	✓	✓	✓	✓	
Other	VX-1	1.4L	K14B	RCM	✓	✓	✓	✓	
2001	Villager	3.3L	Other	PCM	✓	✓	✓	✓	
2002	Villager	3.3L	Other	PCM	✓	✓	✓	✓	
1995	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1995	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1995	Windstar	3.0L	V6 OHV	GEM	✓	✓	✓	✓	
1995	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1995.5	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1996	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1996	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1996	Windstar	3.0L	V6 OHV	GEM	✓	✓	✓	✓	
1996	Windstar	3.0L	V6 OHV	IAB	✓	✓	✓	✓	
1996	Windstar	3.0L	V6 OHV	PATS	✓	✓	✓	✓	
1996	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1996	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1996	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1996	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1996	Windstar	3.8L	V6 OHV	GEM	✓	✓	✓	✓	
1996	Windstar	3.8L	V6 OHV	IAB	✓	✓	✓	✓	
1996	Windstar	3.8L	V6 OHV	PATS	✓	✓	✓	✓	
1996	Windstar	3.8L	V6 OHV	PCM	✓	✓	✓	✓	0025
1997	Windstar	3.0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1997	Windstar	3.0L	V6 OHV	GEM	✓	✓	✓	✓	
1997	Windstar	3.0L	V6 OHV	IAB	✓	✓	✓	✓	
1997	Windstar	3.0L	V6 OHV	PATS	✓	✓	✓	✓	
1997	Windstar	3.0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1997	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1997	Windstar	3.8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1997	Windstar	3.8L	V6 OHV	GEM	✓	✓	✓	✓	
1997	Windstar	3.8L	V6 OHV	IAB	✓	✓	✓	✓	
1997	Windstar	3.8L	V6 OHV	PATS	✓	✓	✓	✓	

1997	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025
1998	Windstar	3. 0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1998	Windstar	3. 0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1998	Windstar	3. 0L	V6 OHV	GEM	✓	✓	✓	✓	
1998	Windstar	3. 0L	V6 OHV	IAB	✓	✓	✓	✓	
1998	Windstar	3. 0L	V6 OHV	PATS	✓	✓	✓	✓	
1998	Windstar	3. 0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1998	Windstar	3. 0L	V6 OHV	RAP	✓	✓	✓	✓	
1998	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1998	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1998	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	0008
1998	Windstar	3. 8L	V6 OHV	GEM	✓	✓	✓	✓	
1998	Windstar	3. 8L	V6 OHV	IAB	✓	✓	✓	✓	
1998	Windstar	3. 8L	V6 OHV	PATS	✓	✓	✓	✓	
1998	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025
1998	Windstar	3. 8L	V6 OHV	RAP	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	DDM	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	FEM	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	IC	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	MC	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	NGSC	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	PAM	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	PCM	✓	✓	✓	✓	0025
1999	Windstar	3. 0L	V6 OHV	RCM	✓	✓	✓	✓	
1999	Windstar	3. 0L	V6 OHV	REM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	DDM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	0005, F042, F045, F08D, F090, F091, F092
1999	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	0005, F042, F045, F08D, F090, F091, F092, FOB4
1999	Windstar	3. 8L	V6 OHV	IC	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	LPSDM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	MC	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	NGSC	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	PAM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025
1999	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
1999	Windstar	3. 8L	V6 OHV	RCM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	REM	✓	✓	✓	✓	
1999	Windstar	3. 8L	V6 OHV	RPSDM	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	0005
2000	Windstar	3. 8L	V6 OHV	DDM	✓	✓	✓	✓	0005
2000	Windstar	3. 8L	V6 OHV	DDM	✓	✓	✓	✓	0005, F045
2000	Windstar	3. 8L	V6 OHV	DSM	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	0005, F042, F045, F08D, F090, F091, F092
2000	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	0005, F042, F045, F08D, F090, F091, F092, FOB4
2000	Windstar	3. 8L	V6 OHV	IC	✓	✓	✓	✓	F027, F08E, F08F
2000	Windstar	3. 8L	V6 OHV	LPSDM	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	MC	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	NGSC	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	PAM	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2000	Windstar	3. 8L	V6 OHV	RCM	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	RCM	✓	✓	✓	✓	000C
2000	Windstar	3. 8L	V6 OHV	REM	✓	✓	✓	✓	
2000	Windstar	3. 8L	V6 OHV	RPSDM	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	0005
2002	Windstar	3. 8L	V6 OHV	DDM	✓	✓	✓	✓	0005
2002	Windstar	3. 8L	V6 OHV	DSM	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	0005
2002	Windstar	3. 8L	V6 OHV	IC	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	LPSDM	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	MC	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	NGSC	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	PAM	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2002	Windstar	3. 8L	V6 OHV	RCM	✓	✓	✓	✓	000C
2002	Windstar	3. 8L	V6 OHV	REM	✓	✓	✓	✓	
2002	Windstar	3. 8L	V6 OHV	RPSDM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	ABS/TCS	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	DDM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	DSM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	FEM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	IC	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	LPSDM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	MC	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	NGSC	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	PAM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2003	Windstar	3. 8L	V6 OHV	RCM	✓	✓	✓	✓	000C
2003	Windstar	3. 8L	V6 OHV	REM	✓	✓	✓	✓	
2003	Windstar	3. 8L	V6 OHV	RPSDM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	ABS	✓	✓	✓	✓	
2006	Zephyr/MKZ	3. 0L	4V	ABS	✓	✓	✓	✓	0008

2006	Zephyr/MKZ	3.0L	4V	ACM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3.0L	4V	ACM	✓	✓	✓	✓	0017, 0018
2006	Zephyr/MKZ	3.0L	4V	DCSM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3.0L	4V	DDM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3.0L	4V	DSM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3.0L	4V	DSP	✓	✓	✓	✓	
2006	Zephyr/MKZ	3.0L	4V	EATC	✓	✓	✓	✓	
2006	Zephyr/MKZ	3.0L	4V	GEM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3.0L	4V	IC	✓	✓	✓	✓	
2006	Zephyr/MKZ	3.0L	4V	OCSM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3.0L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2006	Zephyr/MKZ	3.0L	4V	PCM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3.0L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2006	Zephyr/MKZ	3.0L	4V	RCM	✓	✓	✓	✓	
2006	Zephyr/MKZ	3.0L	4V	TCM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	4X4	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	0008
2007	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2007	Zephyr/MKZ	3.5L	4V	DCSM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	DDM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	DSP	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	EATC	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	GEM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	IC	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2007	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2007	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	SDARS	✓	✓	✓	✓	
2007	Zephyr/MKZ	3.5L	4V	SDARS	✓	✓	✓	✓	0019
2007	Zephyr/MKZ	3.5L	4V	TCM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	4X4	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	0008
2008	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018, F05A, F062, F07A
2008	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2008	Zephyr/MKZ	3.5L	4V	DCSM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	DDM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	0005, F041
2008	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	F041
2008	Zephyr/MKZ	3.5L	4V	DSP	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F044, F048, F04C, F057, F085, F086, F08A
2008	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042, F044, F048, F04C, F057, F085, F086, F08A
2008	Zephyr/MKZ	3.5L	4V	HVAC	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	IC	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	IC	✓	✓	✓	✓	0005, F027
2008	Zephyr/MKZ	3.5L	4V	IC	✓	✓	✓	✓	F027
2008	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2008	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	0005
2008	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2008	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	F022, F05D
2008	Zephyr/MKZ	3.5L	4V	SDARS	✓	✓	✓	✓	
2008	Zephyr/MKZ	3.5L	4V	SDARS	✓	✓	✓	✓	0005
2008	Zephyr/MKZ	3.5L	4V	TCM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	4X4	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2009	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	0016, 0017, 0018
2009	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2009	Zephyr/MKZ	3.5L	4V	DCSM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	DCSM	✓	✓	✓	✓	0005
2009	Zephyr/MKZ	3.5L	4V	DDM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	0005, F041
2009	Zephyr/MKZ	3.5L	4V	DSP	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0005, 0042, F044, F048, F04C, F057, F085, F086, F08A
2009	Zephyr/MKZ	3.5L	4V	HVAC	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	IC	✓	✓	✓	✓	

2009	Zephyr/MKZ	3.5L	4V	IC	✓	✓	✓	✓	0005, F027
2009	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2009	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	0005
2009	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037, 00C5
2009	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	F022, F05D
2009	Zephyr/MKZ	3.5L	4V	SDARS	✓	✓	✓	✓	
2009	Zephyr/MKZ	3.5L	4V	SDARS	✓	✓	✓	✓	0005
2009	Zephyr/MKZ	3.5L	4V	TCM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	4X4	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	0005, 0008, 0012
2010	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2010	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	0017
2010	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2010	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	0019, 001C
2010	Zephyr/MKZ	3.5L	4V	DCSM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	DCSM	✓	✓	✓	✓	0005
2010	Zephyr/MKZ	3.5L	4V	DDM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	DDM	✓	✓	✓	✓	0005
2010	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	0005, F041
2010	Zephyr/MKZ	3.5L	4V	DSP	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	DSP	✓	✓	✓	✓	0005
2010	Zephyr/MKZ	3.5L	4V	FCIM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	FDIM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	FDIM	✓	✓	✓	✓	0005, F062
2010	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2010	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042, F042, F048, F049, F04B, F04C, F08A
2010	Zephyr/MKZ	3.5L	4V	GPSM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	HCM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	HVAC	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	ILCM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	IPC	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	IPC	✓	✓	✓	✓	0005
2010	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015, 006D
2010	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	0005
2010	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037
2010	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	0005
2010	Zephyr/MKZ	3.5L	4V	SOD-L	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	SOD-R	✓	✓	✓	✓	
2010	Zephyr/MKZ	3.5L	4V	TCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DCSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DDM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	HCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ILCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0025, 0028, 0031, 0033
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2011	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	4X4	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2011	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2011	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	0019

2011	Zephyr/MKZ	3.5L	4V	DCSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	DDM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	DSP	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	FCIM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	FDIM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2011	Zephyr/MKZ	3.5L	4V	GPSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	HCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	HVAC	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	IILCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	IPC	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2011	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037
2011	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	SOD-L	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	SOD-R	✓	✓	✓	✓	
2011	Zephyr/MKZ	3.5L	4V	TCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	4X4	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ABS	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACCM#2	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	ACM	✓	✓	✓	✓	0017, 0018
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	APIM	✓	✓	✓	✓	0019
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	BECM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DCDC	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DCSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DDM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	DSP	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	FCIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	FDIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	GPSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	HCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	HVAC	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	IILCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	IPC	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PAM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PCM	✓	✓	✓	✓	0028, 0031, 0033
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	PSCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	RCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	SOD-L	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	SOD-R	✓	✓	✓	✓	
2012	Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	TCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	4X4	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	ABS	✓	✓	✓	✓	0008, 0012
2012	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	ACM	✓	✓	✓	✓	0017, 0018
2012	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	APIM	✓	✓	✓	✓	0019
2012	Zephyr/MKZ	3.5L	4V	DCSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	DDM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	DSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	DSP	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	FCIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	FDIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	GEM / SJB	✓	✓	✓	✓	0042
2012	Zephyr/MKZ	3.5L	4V	GPSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	HCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	HVAC	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	IILCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	IPC	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	OCSM	✓	✓	✓	✓	000C, 0015
2012	Zephyr/MKZ	3.5L	4V	PAM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	PCM	✓	✓	✓	✓	0025, 0037
2012	Zephyr/MKZ	3.5L	4V	RCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	SOD-L	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	SOD-R	✓	✓	✓	✓	
2012	Zephyr/MKZ	3.5L	4V	TCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	4X4	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	ABS	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	ACM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	APIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	DCSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	DDM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	DSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	DSP	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	FCIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	FDIM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	GEM / SJB	✓	✓	✓	✓	0042

2012	Zephyr/MKZ	Other	Other	GPSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	HCM	✓	✓	✓		
2012	Zephyr/MKZ	Other	Other	HVAC	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	IILCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	IPC	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	OCSM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	PAM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	RCM	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	SOD-L	✓	✓	✓	✓	
2012	Zephyr/MKZ	Other	Other	SOD-R	✓	✓	✓	✓	

XTool



Shenzhen Xtooltech Co., Ltd.

VW Function List V10.15

√ This function is supported. ※ This function may be supported which depends on the actual condition of the vehicle.

× This function is not supported.

As for special function please refer to the special function table.

Year	Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live data	Freeze Frame	Active Test	Special Function
2012 (C)- 2017 (H)	12/BL - up! 2012 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	23-Brake Boost	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2017 (H)	12/BL - up! 2012 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	AD-Sensors Brake Systems	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	C0-Actuator For Exterior Noise	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	12/BL - up! 2012 >	C6-Battery Charger Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2017 (H)	13 - Scirocco 2009 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2017 (H)	13 - Scirocco 2009 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2017 (H)	13 - Scirocco 2009 >	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	62-Door Electronics Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	63-Entry Assistance Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	6C-Camera System Rear View	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	6D-Deck Lid Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	72-Door Electronics Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	73-Entry Assistance Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	7D-Auxiliary Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	B9-Auxiliary Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	BD-High Voltage Battery Charge Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	13 - Scirocco 2009 >	BE-Sliding Door Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2017 (H)	13 - Scirocco 2009 >	BF-Sliding Door Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	04-Steering Angle Sender	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	1C-Vehicle Position Detection	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	20-High Beam Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2017 (H)	16 - Jetta 2011 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2017 (H)	16 - Jetta 2011 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	B8-Electronic Roof Control 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 >	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	B8-Electronic Roof Control 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	16 - Jetta 2011 > only USA / Canada	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2016 (G)	18 - Lavida 2012 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2016 (G)	18 - Lavida 2012 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	35-Central Locking Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	39-Light Control Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	54-Rear Spoiler	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2010 (A)	1C - Beetle 1998 > only USA / Canada	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	35-Central Locking Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	39-Light Control Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	54-Rear Spoiler	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2011 (B)	1C/9C - New Beetle 1998 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	0F-Radio Tuner - Digital	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	11-Engine Control Module 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2017 (H)	1F - Eos 2006 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2017 (H)	1F - Eos 2006 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2017 (H)	1F - Eos 2006 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	BE-Sliding Door Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 >	BF-Sliding Door Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	62-Door Electronics Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	63-Entry Assistance Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	6C-Camera System Rear View	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	6D-Deck Lid Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	72-Door Electronics Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	73-Entry Assistance Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	7D-Auxiliary Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	B9-Auxiliary Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	BD-High Voltage Battery Charge Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	BE-Sliding Door Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2017 (H)	1F - Eos 2006 > only USA/Canada	BF-Sliding Door Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	35-Central Locking Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

1999 (X)- 2005 (5)	1J - Bora 1999 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	1J - Bora 1999 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	35-Central Locking Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

1998 (W)- 2006 (6)	1J - Golf 1998 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	39-Light Control Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2006 (6)	1J - Golf 1998 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	35-Central Locking Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	39-Light Control Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2004 (4)	1J - Golf 1998 > only USA/Canada	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2004 (4)- 2009 (9)	1K - Golf 2004 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2004 (4)- 2009 (9)	1K - Golf 2004 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2004 (4)- 2009 (9)	1K - Golf 2004 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2009 (9)	1K - Golf 2004 >	BE-Sliding Door Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2004 (4)- 2009 (9)	1K - Golf 2004 >	BF-Sliding Door Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	04-Steering Angle Sender	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	0F-Radio Tuner - Digital	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	11-Engine Control Module 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	14-Wheel Dampening Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	B8-Electronic Roof Control 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	BE-Sliding Door Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Golf 2004 > only USA/Canada	BF-Sliding Door Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	3C-Lane Change Assistant	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	3D-Special Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	42-Door Electronics Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	4F-Central Electrics 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	51-Drive Motor Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	53-Parking Brake	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	62-Door Electronics Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	63-Entry Assistance Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	6C-Camera System Rear View	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	6D-Deck Lid Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	72-Door Electronics Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	73-Entry Assistance Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	7D-Auxiliary Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	B8-Electronic Roof Control 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	B9-Auxiliary Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	BD-High Voltage Battery Charge Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	BE-Sliding Door Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2009 (9)	1K - Golf Variant 2004 >	BF-Sliding Door Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	B8-Electronic Roof Control 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	BE-Sliding Door Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2009 (9)	1K - Rabbit 2006 > only USA/Canada	BF-Sliding Door Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	1C-Vehicle Position Detection	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	20-High Beam Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	26-Electronic Roof Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	2B-Steering Column Locking	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	2E-Media Player Position 3	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	3C-Lane Change Assistant	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	3D-Special Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	42-Door Electronics Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	4F-Central Electrics 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	51-Drive Motor Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	62-Door Electronics Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	72-Door Electronics Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	7D-Auxiliary Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	B8-Electronic Roof Control 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	1K/AJ - Bora/Jetta/Vento 2006 >	B9-Auxiliary Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	04-Steering Angle Sender	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	0F-Radio Tuner - Digital	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	4F-Central Electrics 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	51-Drive Motor Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	62-Door Electronics Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	72-Door Electronics Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	7D-Auxiliary Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	B8-Electronic Roof Control 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2005 (5)- 2010 (A)	1K/AJ - Jetta 2005 > only USA/Canada	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2003 (3)- 2010 (A)	1T - Touran 2003 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2003 (3)- 2010 (A)	1T - Touran 2003 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2003 (3)- 2010 (A)	1T - Touran 2003 >	7D-Auxiliary Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	B9-Auxiliary Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	BD-High Voltage Battery Charge Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	BE-Sliding Door Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1T - Touran 2003 >	BF-Sliding Door Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	0F-Radio Tuner - Digital	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	11-Engine Control Module 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2016 (G)	1T - Touran 2011 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2016 (G)	1T - Touran 2011 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2016 (G)	1T - Touran 2011 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	BE-Sliding Door Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	1T - Touran 2011 >	BF-Sliding Door Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	45-Interior Monitoring	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2011 (B)	1Y - New Beetle Convertible 2003 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	45-Interior Monitoring	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	1Y - New Beetle Convertible 2003 > only USA / Canada	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2017 (H)	35 - Passat CC 2009 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2017 (H)	35 - Passat CC 2009 >	4F-Central Electrics 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	53-Parking Brake	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	5C-Lane Departure Warning System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	5D-Operation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	62-Door Electronics Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	6C-Camera System Rear View	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	6D-Deck Lid Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	72-Door Electronics Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2017 (H)	35 - Passat CC 2009 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 >	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	04-Steering Angle Sender	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	0F-Radio Tuner - Digital	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	14-Wheel Dampening Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	5C-Lane Departure Warning System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	5D-Operation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2017 (H)	35 - Passat CC 2009 > only USA/Canada	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2015 (F)	36 - Passat 2011 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2015 (F)	36 - Passat 2011 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	5C-Lane Departure Warning System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	5D-Operation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2015 (F)	36 - Passat 2011 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2015 (F)	36 - Passat 2011 >	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

1997 (V)- 2005 (5)	3B - Passat 1997 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	58-Fuel Supply	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1997 (V)- 2005 (5)	3B - Passat 1997 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	58-Fuel Supply	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2005 (5)	3B - Passat 1998 > only USA/Canada	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	04-Steering Angle Sender	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2011 (B)	3C - Passat 2006 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2011 (B)	3C - Passat 2006 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	5C-Lane Departure Warning System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	5D-Operation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2011 (B)	3C - Passat 2006 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 >	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	5C-Lane Departure Warning System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	5D-Operation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2011 (B)	3C - Passat 2006 > only USA/Canada	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	07-Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2003 (3)- 2017 (H)	3D - Phaeton 2003 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	23-Brake Boost	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	28-Climate Control Unit Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	34-Ride Control System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	38-Roof Electronic Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2003 (3)- 2017 (H)	3D - Phaeton 2003 >	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	66-Seat Adjustment Rear	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	68-Wiper Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	6C-Camera System Rear View	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	71-Battery Charger	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2017 (H)	3D - Phaeton 2003 >	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	07-Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	23-Brake Boost	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	28-Climate Control Unit Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	34-Ride Control System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	38-Roof Electronic Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	66-Seat Adjustment Rear	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	68-Wiper Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	71-Battery Charger	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2006 (6)	3D - Phaeton 2003 > only USA/Canada	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	14-Wheel Dampening Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2015 (F)- 2017 (H)	3G - Passat 2015 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	23-Brake Boost	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	3A-Special Vehicle Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	4B-Multifunction Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2015 (F)- 2017 (H)	3G - Passat 2015 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	5D-Operation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	82-Head Up Display	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	A9-Actuator For Structure-Borne Sound	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	B7-Access Startsystem Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	BB-Door Electronics Rear Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	BC-Door Electronics Rear Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2015 (F)- 2017 (H)	3G - Passat 2015 >	C0-Actuator For Exterior Noise	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	C6-Battery Charger Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	CA-Control Module For Sunroof	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2017 (H)	3G - Passat 2015 >	CF-Control Unit Lane Change Assistant 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	4F-Central Electrics 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	51-Drive Motor Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	53-Parking Brake	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	62-Door Electronics Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	63-Entry Assistance Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	6C-Camera System Rear View	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	6D-Deck Lid Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	72-Door Electronics Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	73-Entry Assistance Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	7D-Auxiliary Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	B9-Auxiliary Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	BD-High Voltage Battery Charge Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	BE-Sliding Door Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	51 - Golf Cabriolet 2012 >	BF-Sliding Door Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	0F-Radio Tuner - Digital	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	BE-Sliding Door Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2014 (E)	52 - Golf Plus 2009 >	BF-Sliding Door Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2016 (G)	59 - Tiguan 2010 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2016 (G)	59 - Tiguan 2010 >	4F-Central Electrics 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	53-Parking Brake	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	62-Door Electronics Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	6C-Camera System Rear View	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	72-Door Electronics Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	59 - Tiguan 2010 >	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	04-Steering Angle Sender	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2017 (H)	5C - Beetle 2012 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2017 (H)	5C - Beetle 2012 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2017 (H)	5C - Beetle 2012 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	7D-Auxiliary Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	B8-Electronic Roof Control 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 >	B9-Auxiliary Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	04-Steering Angle Sender	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	B8-Electronic Roof Control 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2017 (H)	5C - Beetle 2012 > USA/Canada only	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	23-Brake Boost	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	32-Lock Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	3A-Special Vehicle Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	4B-Multifunction Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	5D-Operation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	82-Head Up Display	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	A9-Actuator For Structure-Borne Sound	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	B7-Access Startsystem Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	BB-Door Electronics Rear Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	BC-Door Electronics Rear Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	C0-Actuator For Exterior Noise	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	C5-Thermal Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	C6-Battery Charger Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	CA-Control Module For Sunroof	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	CF-Control Unit Lane Change Assistant 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	D6-Light Control Left 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	5G / BA / BE / BX - Golf 2013 >	D7-Light Control Right 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	0F-Radio Tuner - Digital	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	11-Engine Control Module 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	14-Wheel Dampening Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2013 (D)	5K - Golf 2009 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2013 (D)	5K - Golf 2009 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2013 (D)	5K - Golf 2009 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	7D-Auxiliary Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	B9-Auxiliary Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	BD-High Voltage Battery Charge Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	BE-Sliding Door Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5K - Golf 2009 >	BF-Sliding Door Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	0F-Radio Tuner - Digital	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	11-Engine Control Module 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	BE-Sliding Door Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	5K - Golf 2010 > only USA/Canada	BF-Sliding Door Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	BE-Sliding Door Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2009 (9)	5M - Golf Plus 2005 >	BF-Sliding Door Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	0F-Radio Tuner - Digital	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	11-Engine Control Module 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	14-Wheel Dampening Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2008 (8)- 2016 (G)	5N - Tiguan 2008 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2008 (8)- 2016 (G)	5N - Tiguan 2008 >	51-Drive Motor Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	53-Parking Brake	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	62-Door Electronics Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	63-Entry Assistance Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	6C-Camera System Rear View	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	6D-Deck Lid Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	72-Door Electronics Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	73-Entry Assistance Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2008 (8)- 2016 (G)	5N - Tiguan 2008 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	7D-Auxiliary Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	B9-Auxiliary Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	BD-High Voltage Battery Charge Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	BE-Sliding Door Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2016 (G)	5N - Tiguan 2008 >	BF-Sliding Door Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	0F-Radio Tuner - Digital	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	11-Engine Control Module 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	BE-Sliding Door Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2008 (8)- 2017 (H)	5N - Tiguan 2008 > only USA/Canada	BF-Sliding Door Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2016 (G)- 2017 (H)	5T - Touran 2016 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	14-Wheel Dampening Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	20-High Beam Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	23-Brake Boost	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	2B-Steering Column Locking	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	32-Lock Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	39-Light Control Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	3A-Special Vehicle Assistant	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2016 (G)- 2017 (H)	5T - Touran 2016 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	4B-Multifunction Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	5D-Operation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2016 (G)- 2017 (H)	5T - Touran 2016 >	82-Head Up Display	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	A9-Actuator For Structure-Borne Sound	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	B7-Access Startsystem Interface	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	BB-Door Electronics Rear Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	BC-Door Electronics Rear Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	BD-High Voltage Battery Charge Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	C0-Actuator For Exterior Noise	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	C5-Thermal Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	C6-Battery Charger Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	CA-Control Module For Sunroof	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	CF-Control Unit Lane Change Assistant 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	D6-Light Control Left 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	5T - Touran 2016 >	D7-Light Control Right 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	07-Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2005 (5)- 2011 (B)	5Z - Fox 2005 - Europe >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	04-Steering Angle Sender	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	45-Interior Monitoring	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2017 (H)	60/61 - Polo/Vento 2010 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	04-Steering Angle Sender	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	62 - Polo 2011 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	45-Interior Monitoring	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2017 (H)- 2017 (H)	63 - Polo Ameo 2017 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2014 (E)- 2017 (H)	6C - Polo 2014 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	6C - Polo 2014 >	A9-Actuator For Structure-Borne Sound	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	45-Interior Monitoring	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2015 (F)	6R - Polo 2010 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2015 (F)	6R - Polo 2010 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	35-Central Locking Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	45-Interior Monitoring	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	6X/6E - Lupo 1999 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	2B-Steering Column Locking	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2017 (H)	6Z - XL1 2013 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	6Z - XL1 2013 >	BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2003 (3)- 2010 (A)	7L - Touareg 2003 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	32-Lock Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	34-Ride Control System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2003 (3)- 2010 (A)	7L - Touareg 2003 >	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	64-Stabilizers	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	68-Wiper Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	6C-Camera System Rear View	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	6D-Deck Lid Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	6E-Display Control Roof	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	0F-Radio Tuner - Digital	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	32-Lock Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	34-Ride Control System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	3C-Lane Change Assistant	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	64-Stabilizers	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	68-Wiper Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	6C-Camera System Rear View	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	6D-Deck Lid Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	6E-Display Control Roof	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2010 (A)	7L - Touareg 2003 > only USA/Canada	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2001 (1)- 2010 (A)	7M - Sharan 2001 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	39-Light Control Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2010 (A)	7M - Sharan 2001 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2017 (H)	7N - Sharan 2011 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	0F-Radio Tuner - Digital	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	11-Engine Control Module 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	14-Wheel Dampening Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	1C-Vehicle Position Detection	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	20-High Beam Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2017 (H)	7N - Sharan 2011 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2017 (H)	7N - Sharan 2011 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	63-Entry Assistance Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2017 (H)	7N - Sharan 2011 >	B9-Auxiliary Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	BD-High Voltage Battery Charge Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	BE-Sliding Door Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	7N - Sharan 2011 >	BF-Sliding Door Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	0E-Media Player Position 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	11-Engine Control Module 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2017 (H)	7P - Touareg 2010 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	1E-Media Player Position 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	28-Climate Control Unit Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	32-Lock Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	34-Ride Control System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	40-Air Conditioning Compressor	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2017 (H)	7P - Touareg 2010 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	85-On-Board Camera	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	8B-Adaptive Cruise Control 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	8E-Image Processing Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	8F-Pretensioner Front Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 >	90-Pretensioner Front Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2017 (H)	7P - Touareg 2010 >	A7-Infotainment Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	0E-Media Player Position 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	1E-Media Player Position 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	28-Climate Control Unit Rear	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	32-Lock Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	34-Ride Control System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	40-Air Conditioning Compressor	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	53-Parking Brake	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	85-On-Board Camera	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	8B-Adaptive Cruise Control 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	8E-Image Processing Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	8F-Pretensioner Front Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	90-Pretensioner Front Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2017 (H)	7P - Touareg 2010 > only USA/Canada	A7-Infotainment Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	35-Central Locking Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9M - Jetta 1999 > RoW	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	35-Central Locking Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2014 (E)	9M - Jetta 1999 > only USA / Canada	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	07-Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	45-Interior Monitoring	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N1/9N3 - Polo 2002 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	05-Kessy	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	1C-Vehicle Position Detection	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	2B-Steering Column Locking	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	2E-Media Player Position 3	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	3C-Lane Change Assistant	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	42-Door Electronics Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	4F-Central Electrics 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 > only USA/Canada	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	A3 - Passat/New Midsize Sedan 2011 >	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	42-Door Electronics Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	4F-Central Electrics 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	53-Parking Brake	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	6D-Deck Lid Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	6F-Central Module Comfort System 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2016 (G)	A4 - Passat/New Midsize Sedan 2011 >	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2016 (G)- 2017 (H)	AD - Tiguan 2016 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	14-Wheel Dampening Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	20-High Beam Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	23-Brake Boost	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	2B-Steering Column Locking	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	32-Lock Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	39-Light Control Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	3A-Special Vehicle Assistant	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2016 (G)- 2017 (H)	AD - Tiguan 2016 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	4B-Multifunction Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	5D-Operation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2016 (G)- 2017 (H)	AD - Tiguan 2016 >	82-Head Up Display	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	A9-Actuator For Structure-Borne Sound	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	B7-Access Startsystem Interface	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	BB-Door Electronics Rear Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	BC-Door Electronics Rear Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	BD-High Voltage Battery Charge Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	C0-Actuator For Exterior Noise	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	C5-Thermal Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	C6-Battery Charger Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	CA-Control Module For Sunroof	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	CF-Control Unit Lane Change Assistant 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	D6-Light Control Left 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2016 (G)- 2017 (H)	AD - Tiguan 2016 >	D7-Light Control Right 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	1C-Vehicle Position Detection	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	26-Electronic Roof Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	4F-Central Electrics 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	62-Door Electronics Rear Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	72-Door Electronics Rear Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	B8-Electronic Roof Control 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	AJ - Golf Variant 2010 >	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	05-Kessy	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	1C-Vehicle Position Detection	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	20-High Beam Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	26-Electronic Roof Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	2B-Steering Column Locking	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	2E-Media Player Position 3	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	3C-Lane Change Assistant	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	42-Door Electronics Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	4F-Central Electrics 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	51-Drive Motor Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	62-Door Electronics Rear Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	72-Door Electronics Rear Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	77-Telephone	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	7D-Auxiliary Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	B8-Electronic Roof Control 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2014 (E)	AJ - Jetta SportWagen/Golf Wagon 2010 > only USA/Canada	B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	06-Seat Adjustment Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	13-Adaptive Cruise Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	14-Wheel Dampening Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	18-Auxiliary Parking Heater	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	20-High Beam Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	23-Brake Boost	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	2B-Steering Column Locking	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	32-Lock Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	3A-Special Vehicle Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	3C-Lane Change Assistant	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	3D-Special Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	42-Door Electronics Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	4B-Multifunction Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	51-Drive Motor Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	52-Door Electronics Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	5D-Operation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	69-Trailer Function	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	6C-Camera System Rear View	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	6D-Deck Lid Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	75-Telematics Communication Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	82-Head Up Display	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	8C-Battery Energy Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	A9-Actuator For Structure-Borne Sound	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	B7-Access Startsystem Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	BB-Door Electronics Rear Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	BC-Door Electronics Rear Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	C0-Actuator For Exterior Noise	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	C5-Thermal Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	C6-Battery Charger Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	CA-Control Module For Sunroof	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	CF-Control Unit Lane Change Assistant 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	D6-Light Control Left 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2017 (H)	AM - Golf Sportsvan 2014 >	D7-Light Control Right 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	14-Wheel Dampening Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	20-High Beam Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	23-Brake Boost	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	2B-Steering Column Locking	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	32-Lock Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	39-Light Control Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	3A-Special Vehicle Assistant	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	3C-Lane Change Assistant	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	3D-Special Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	42-Door Electronics Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	4B-Multifunction Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	51-Drive Motor Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	5D-Operation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	65-Tire Pressure Monitoring 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	6C-Camera System Rear View	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	6D-Deck Lid Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	82-Head Up Display	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	A5-Front Sensors Driver Assistance System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	A9-Actuator For Structure-Borne Sound	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	B7-Access Startsystem Interface	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	BB-Door Electronics Rear Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	BC-Door Electronics Rear Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	BD-High Voltage Battery Charge Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	C0-Actuator For Exterior Noise	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	C5-Thermal Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	C6-Battery Charger Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	CA-Control Module For Sunroof	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	CF-Control Unit Lane Change Assistant 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	D6-Light Control Left 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2017 (H)	AU / BE / BX - Golf 2013 > only USA/Canada	D7-Light Control Right 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	14-Wheel Dampening Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2015 (F)- 2016 (G)	BM - Lamando 2015 >	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	2B-Steering Column Locking	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	39-Light Control Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	3C-Lane Change Assistant	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	42-Door Electronics Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	4B-Multifunction Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	52-Door Electronics Passenger Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	6C-Camera System Rear View	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	6D-Deck Lid Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	82-Head Up Display	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2015 (F)- 2016 (G)	BM - Lamando 2015 >	A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	A9-Actuator For Structure-Borne Sound	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	B7-Access Startsystem Interface	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	BB-Door Electronics Rear Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	BC-Door Electronics Rear Passenger Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	CA-Control Module For Sunroof	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	CF-Control Unit Lane Change Assistant 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	D6-Light Control Left 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2016 (G)	BM - Lamando 2015 >	D7-Light Control Right 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	BR - Santana NF 2013 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	BR - Santana NF 2013 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	BR - Santana NF 2013 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	BR - Santana NF 2013 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	BR - Santana NF 2013 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	BR - Santana NF 2013 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	BR - Santana NF 2013 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	BR - Santana NF 2013 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	BR - Santana NF 2013 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2013 (D)- 2016 (G)	BR - Santana NF 2013 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	BR - Santana NF 2013 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	BR - Santana NF 2013 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	BR - Santana NF 2013 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2013 (D)- 2016 (G)	BR - Santana NF 2013 >	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining passenger vehicles	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining passenger vehicles	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining passenger vehicles	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining passenger vehicles	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining passenger vehicles	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining passenger vehicles	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining passenger vehicles	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining passenger vehicles	35-Central Locking Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining passenger vehicles	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All model years- All model years	Remaining passenger vehicles	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	04-Steering Angle Sender	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	11-Engine Control Module 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	45-Interior Monitoring	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	55-Headlight Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	61-Battery Regulation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2016 (G)	6S - Polo VIVO 2010 >	77-Telephone	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	23-Brake Boost	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	51-Drive Motor Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	61-Battery Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	69-Trailer Function	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	8C-Battery Energy Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	AD-Sensors Brake Systems	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	BD-High Voltage Battery Charge Management	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	C0-Actuator For Exterior Noise	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2016 (G)	12 - up! / cross up! 2014 - Brazil >	C6-Battery Charger Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2007 (7)	3X - Santana 1991 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2007 (7)	3X - Santana 1991 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5U - Gol / Voyage / Saveiro 2009 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5U - Gol / Voyage / Saveiro 2009 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5U - Gol / Voyage / Saveiro 2009 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5U - Gol / Voyage / Saveiro 2009 >	07-Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5U - Gol / Voyage / Saveiro 2009 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5U - Gol / Voyage / Saveiro 2009 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5U - Gol / Voyage / Saveiro 2009 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2009 (9)- 2013 (D)	5U - Gol / Voyage / Saveiro 2009 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5U - Gol / Voyage / Saveiro 2009 >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5U - Gol / Voyage / Saveiro 2009 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5U - Gol / Voyage / Saveiro 2009 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2009 (9)- 2013 (D)	5U - Gol / Voyage / Saveiro 2009 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2015 (F)	5W - Gol / Parati / Saveiro / Pointer 2006 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2015 (F)	5W - Gol / Parati / Saveiro / Pointer 2006 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2015 (F)	5W - Gol / Parati / Saveiro / Pointer 2006 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2015 (F)	5W - Gol / Parati / Saveiro / Pointer 2006 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2015 (F)	5W - Gol / Parati / Saveiro / Pointer 2006 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2015 (F)	5W - Gol / Parati / Saveiro / Pointer 2006 >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2015 (F)	5W - Gol / Parati / Saveiro / Pointer 2006 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2015 (F)	5W - Gol / Parati / Saveiro / Pointer 2006 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	5X - Gol / Parati / Saveiro / Pointer 1999 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	5X - Gol / Parati / Saveiro / Pointer 1999 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	5X - Gol / Parati / Saveiro / Pointer 1999 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	5X - Gol / Parati / Saveiro / Pointer 1999 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	5X - Gol / Parati / Saveiro / Pointer 1999 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

1999 (X)- 2006 (6)	5X - Gol / Parati / Saveiro / Pointer 1999 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2005 (5)	5Y - Gol 1995 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	2E-Media Player Position 3	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2014 (E)	5Z - Fox / CrossFox / Lupo 2014 >	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	10-Parking Assistance 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	2E-Media Player Position 3	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2014 (E)- 2015 (F)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2014 >	5F-Information Control Unit 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	2E-Media Player Position 3	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - New Fox / New CrossFox 2015 >	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	2E-Media Player Position 3	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2015 (F)- 2015 (F)	5Z - Nova SpaceFox / Space Cross / Suran 2015 >	5F-Information Control Unit 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2010 (A)	5Z - Fox / CrossFox / Lupo 2004 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	07-Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2010 (A)- 2013 (D)	5Z - Fox / CrossFox / Lupo 2010 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2010 (A)	5Z - SpaceFox / Suran / Sportvan 2006 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2010 (A)	5Z - SpaceFox / Suran / Sportvan 2006 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2010 (A)	5Z - SpaceFox / Suran / Sportvan 2006 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2010 (A)	5Z - SpaceFox / Suran / Sportvan 2006 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2010 (A)	5Z - SpaceFox / Suran / Sportvan 2006 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2010 (A)	5Z - SpaceFox / Suran / Sportvan 2006 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2010 (A)	5Z - SpaceFox / Suran / Sportvan 2006 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2010 (A)	5Z - SpaceFox / Suran / Sportvan 2006 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2010 (A)	5Z - SpaceFox / Suran / Sportvan 2006 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2010 (A)	5Z - SpaceFox / Suran / Sportvan 2006 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2010 (A)	5Z - SpaceFox / Suran / Sportvan 2006 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	07-Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2011 (B)- 2013 (D)	5Z - SpaceFox / Space Cross / Suran / Sportvan 2011 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2015 (F)	7X - Kombi 1997 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2015 (F)	7X - Kombi 1997 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2015 (F)	7X - Kombi 1997 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2006 (6)- 2015 (F)	7X - Kombi 1997 >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2007 (7)	9A1 / 9A2 - Polo 2003 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2007 (7)	9A1 / 9A2 - Polo 2003 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2007 (7)	9A1 / 9A2 - Polo 2003 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2003 (3)- 2007 (7)	9A1 / 9A2 - Polo 2003 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2007 (7)	9A1 / 9A2 - Polo 2003 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2007 (7)	9A1 / 9A2 - Polo 2003 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2007 (7)	9A1 / 9A2 - Polo 2003 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2007 (7)	9A1 / 9A2 - Polo 2003 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2007 (7)	9A1 / 9A2 - Polo 2003 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2007 (7)	9A1 / 9A2 - Polo 2003 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2007 (7)	9A1 / 9A2 - Polo 2003 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2007 (7)	9A1 / 9A2 - Polo 2003 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2003 (3)- 2007 (7)	9A1 / 9A2 - Polo 2003 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	07-Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	44-Steering Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	45-Interior Monitoring	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2012 (C)	9A3 / 9A4 - Polo 2003 >	76-Parking Assistance	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	01-Engine Control Module 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	02-Transmission Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	03-Brakes 1	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	07-Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	09-Central Electrics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2012 (C)- 2015 (F)	9A5 / 9A6 - Polo 2003 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	07-Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

1999 (X)- 2015 (F)	9B - Golf 1999 >	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	35-Central Locking Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	39-Light Control Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2015 (F)	9B - Golf 1999 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	07-Display Control Unit	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	08-Air Conditioning	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	15-Airbag	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	16-Steering Column Electronics	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	17-Dash Board	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	19-Gateway	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	22-All Wheel Control	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	25-Immobilizer	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	29-Light Control Left	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	30-Special Function 2	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	35-Central Locking Control Module	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	37-Navigation	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	39-Light Control Right	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	46-Central Module Comfort System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	47-Sound System	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	56-Radio	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007
2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	57-TV Tuner	√	√	√	√	※	※	0001 0002 0003 0004 0005 0006 0007

2007 (7)- 2011 (B)	9B - Golf 1999 - Canada >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	22-All Wheel Control	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	35-Central Locking Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	36-Seat Adjustment Driver Side	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	39-Light Control Right	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	47-Sound System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	55-Headlight Regulation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	57-TV Tuner	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	75-Telematics Communication Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1999 (X)- 2006 (6)	9B - Golf 1999 - USA/Canada >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2005 (5)	9N2 - Polo 2004 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2005 (5)	9N2 - Polo 2004 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2005 (5)	9N2 - Polo 2004 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2005 (5)	9N2 - Polo 2004 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2005 (5)	9N2 - Polo 2004 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2005 (5)	9N2 - Polo 2004 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2005 (5)	9N2 - Polo 2004 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2005 (5)	9N2 - Polo 2004 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2005 (5)	9N2 - Polo 2004 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2005 (5)	9N2 - Polo 2004 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2005 (5)	9N2 - Polo 2004 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2005 (5)	9N2 - Polo 2004 >	45-Interior Monitoring	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2004 (4)- 2005 (5)	9N2 - Polo 2004 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2004 (4)- 2005 (5)	9N2 - Polo 2004 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	07-Display Control Unit	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	19-Gateway	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	29-Light Control Left	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	30-Special Function 2	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	37-Navigation	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	44-Steering Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	45-Interior Monitoring	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2002 (2)- 2010 (A)	9N - Polo 2003 >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

2002 (2)- 2010 (A)	9N - Polo 2003 >	76-Parking Assistance	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All models up to MY 2000 (Old dash)-	9V - Polo 2000 (Old Polo) >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All models up to MY 2000 (Old dash)-	9V - Polo 2000 (Old Polo) >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All models up to MY 2000 (Old dash)-	9V - Polo 2000 (Old Polo) >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All models up to MY 2000 (Old dash)-	9V - Polo 2000 (Old Polo) >	35-Central Locking Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All models up to MY 2000 (Old dash)-	9V - Polo 2000 (Old Polo) >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2009 (9)	17 - Golf 1(Citi, Caddy Bakkie) >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2009 (9)	17 - Golf 1(Citi, Caddy Bakkie) >	09-Central Electrics	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2009 (9)	17 - Golf 1(Citi, Caddy Bakkie) >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2009 (9)	17 - Golf 1(Citi, Caddy Bakkie) >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2009 (9)	17 - Golf 1(Citi, Caddy Bakkie) >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
1998 (W)- 2009 (9)	17 - Golf 1(Citi, Caddy Bakkie) >	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All Year Models- All Year Models	GeKo online	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All Year Models- All Year Models	GeKo online	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All Year Models- All Year Models	GeKo online	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All Year Models- All Year Models	GeKo online	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All Year Models- All Year Models	GeKo online	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All Year Models- All Year Models	GeKo online	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

All Year Models- All Year Models	GeKo online	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All Year Models- All Year Models	GeKo online	35-Central Locking Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All Year Models- All Year Models	GeKo online	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
All Year Models- All Year Models	GeKo online	56-Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	7D - T4 Caravelle 2001 >	01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	7D - T4 Caravelle 2001 >	02-Transmission Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	7D - T4 Caravelle 2001 >	03-Brakes 1	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	7D - T4 Caravelle 2001 >	08-Air Conditioning	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	7D - T4 Caravelle 2001 >	15-Airbag	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	7D - T4 Caravelle 2001 >	17-Dash Board	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	7D - T4 Caravelle 2001 >	25-Immobilizer	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	7D - T4 Caravelle 2001 >	35-Central Locking Control Module	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	7D - T4 Caravelle 2001 >	46-Central Module Comfort System	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007
2001 (1)- 2003 (3)	7D - T4 Caravelle 2001 >	56 - Radio	✓	✓	✓	✓	※	※	0001 0002 0003 0004 0005 0006 0007

Index	Specil Function Name	Index	Specil Function Name
0001	Coding	0002	Basic Settings
0003	Adaptation	0004	Security Access
0005	AdvancedDataStream	0006	Login CodingII
0007	Advanced ID		